


5 Watt Remote Multi-Colour LCD Speaker Mic Super Compact UHF CB Fixed Mount Radio EXG3000 USER GUIDE


Radio Installation 1

For full instructions on the EXG3000 radio installation, visit the website for the online user guide.



Quick Release Mounting Bracket (Base Mount):
Install the Quick Release Mounting Bracket to a desired location.


Magnetic Mic Hanger (Mic Mount):
Install the Mic Hanger within cable extension range of the Microphone.



Base Connections:
Connect DC power plug to **+12V DC**.
Connect antenna connector to an external **UHF-CB** antenna.

Microphone Connection:
Connect microphone cable to RJ45 jack at the base unit.

Power ON/OFF | Volume 2




Press **and hold** to turn Power On or Off.

When power is on, adjust the Volume using **vol UP** and **vol DOWN**.

After the ECOXGEAR logo appears, the display will change to the Active mode, indicating the current channel and settings, and Live RSSI graphic.

If there is no signal activity for 8 seconds the display will change to the Simple mode display.



Selecting a Channel 3

- There are three ways to navigate to a channel.
- Main Method:** Press **UP** or **DOWN** to change channel one step at a time. (Press **and hold** to change channels rapidly.)
- One-Touch Shortcut Keys:** Press **PRI** to recall the Priority Channel (Default is CH11). To store any current channel as the Priority Channel, press **and hold PRI**.
- Press **EMG** to recall Emergency Channels 05 and 35.

Channel Usage 4

The EXG3000 has 80 UHF-CB Channels to select from. Visit the ACMA website for details of citizen band radio usage.

Designated Channels

- Channels **05** and **35** are for Emergency communications only.
- CH.11 Call Channel. Once contact is made, switch to another channel.
- Channels **01-08** and **41-48** are repeater output channels. Channels **31-38** and **71-78** are the matching repeater input channels.

Limited Use Channels

- CH.22, 23 No voice (talk) is permitted on these channels.
- CH.61, 62, 63 Reserved for future use.

Commonly used for...

- CH.10 4WD Clubs, Convoys & National Parks
 - CH.18 Caravan & Campers, Convoys
 - CH.29 Road Safety (Pacific Hwy NSW-QLD)
 - CH.40 Road Safety (Truckies) Australia Wide
- All other channels are for general use.


CH: 01 02 03 04 **05** 06 07 08 09 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 **35** 36 37 38 39 40

CH: 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80

LISTENING: Receive (RX) Basics 5


Live RSSI (Receive Signal Strength Indicator)

The Live RSSI graphic (*Patent Pending*) shows the signal activity on the current channel.




SQL is Squelch. The squelch keeps the radio's speaker muted.

☐ is the squelch point, the threshold allowing signals to un-mute the radio's speaker.




Adding CTCSS & DCS to the Squelch





Make sure, when you set a CTCSS or DCS squelch code, to share the code with others you want to communicate with.

Monitor Mode



TALKING: Transmit (TX) Basics 6

Always listen on a channel, or check the LiveRSSI, to ensure it is not already being used before transmitting. To communicate, all radios in your group must be set to the same Channel and, if it is set, the same CTCSS / DCS Code.



Making Contact Using Call

