



# ICONX HEATED GEAR

**USING YOUR ICONX HEATED CORE GEAR** Prior to first use, plug the charger directly into a wall outlet and insert charging cord into the battery, fully charging the battery overnight. (Avoid the use of power strips and surge protectors.) Disconnect the battery from charger and shake battery well. To reveal the batterie's white indicator lights and approximate charge status, turn the battery upside down: 1 light = 25% charge, 2 lights = 50%, 3 lights = 75%, 4 lights = Fully charged. Indicator lights on the battery, will go into sleep mode after being still for several seconds and may flicker if moved or turned upside down. Depending on the model of your charger, you may see a red light that indicates the battery is charging. Green or no light indicates a fully charged battery. (Some charger models may not have indicator lights.)

**POWERING ON/OFF** Shake your fully charged battery well, connecting it to the charging port in the battery pocket. Find the power button on your Heated Gear, which will be a small raised square with the Pnuma mountains. Left upper chest, for vest. Right inside of waist, for pant, and inside zipper pocket of handwarmer. Once the power button is located, press, and hold for 2-3 seconds. Your Heated Gear will go into pre-heat mode and should flash red. After 5 minutes, the power button should automatically change to yellow or medium heat setting.

## VEST SPECS & SETTINGS

**LOW**



**100°F**

Average Duration  
**6.5 HRS**

Low setting on hand-warmer is blue

**MED**



**113°F**

Average Duration  
**3.0 HRS**

Medium setting on hand-warmer is green

**HIGH**



**131°F**

Average Duration  
**2.0 HRS**

**ADJUSTING TEMPERATURE** At any time during or after pre-heat mode, adjust your gear's temperature by pressing the power button once to cycle to the next setting.

## HEATED GEAR SYSTEM CARE

To prolong battery life and optimal performance use only the charger provided with this system. Unplug battery from charger after charging. Fully charge the battery prior to first use, until light on charger goes off. Charge battery before storage and every 3 months during storage. Lithium batteries provide shorter storage capacity when exposed to extremely cold temperatures. Keep battery inside garment to improve performance.

LIFETIME

WARRANTY

# ICONX HEATED GEAR CARE

Use carefully, especially when worn directly against skin. Can cause serious burns. Do not use over sensitive skin areas or in presence of poor circulation. The IconX Heated Vest and Pant is designed to be worn directly against the skin. Depending on exertion and comfort level, some users may opt to wear a lightweight layer underneath their IconX Heated Gear, such as our Rogue or Merino base layer.

**ICONX  
HEATED  
VEST**

**ICONX  
HEATED  
HAND  
WARMER**



**ICONX  
HEATED  
PANT**

## OPTIMIZING THE PERFORMANCE OF ICONX HEATED GEAR

- Hand wash in cold water with a mild detergent and air dry.
- IconX Heated Gear contains elements for heat delivery and connection wire in the charging pocket.
- Prior to hand washing, disconnect and remove battery from pocket.
- Never machine wash or machine dry IconX Heated Gear.
- Pnuma's Lifetime Guarantee void if:
  - Machine wash and/or machine drying of ICONX Gear
  - Use of ozone products, cabinets, or chambers on IconX Heated Gear.
  - Use of batteries and/or chargers other than offered by Pnuma, specified for IconX Heated Gear.

**CHARGER**



**BATTERY**

