

LOCKING BAR for use with Counting Stations & Slitting Stations

INSTALLATION:

- Place the center two holes on the **Locking Bar** over the Screw holes on the **Counter** or **Slitter** Base Plate.
- Place a Screw and Flat Washer into each Hole.
- Tighten, but make sure to not over-tighten, the Screws.
Damaged screws are not covered under the Warranty.
- Slightly lift the **Counter** or **Slitter** Unit and slide the **Rewinder** and **Unwinder** Base Plates under the ends of the **Locking Bar**.
- Align the Screw Hole in the Base Plates under the grooves on the **Locking Bar**.
- Start a Screw with Flat Washer into each threaded Hole in the Base Plates.
- Position the **Rewinder** and **Unwinder** to align the label path.
- Tighten the Screws on both units making sure not to over-tighten the Screws.

IMPORTANT: Do not lift the units while they are attached to the **Locking Bar**.
The **Locking Bar** is meant only to keep the units aligned.
A bent **Locking Bar** or broken screws are not covered under the Warranty.

INCLUDED HARDWARE

8-32 x 3/8" Phillips-head Screws (4)
Thick Flat Washers (4)

IMPORTANT:

Do not lift or move the Units together. The **Locking Bar** must be removed from the **Rewinder** and **Unwinder** before moving the Units.

