

AIR RIVET GUN – 10172


Far[®] air rivet gun for structural rivets diameters 6.4 & 7.9mm*

The RT-10172 is a heavy-duty hydro-pneumatic rivet tool suitable for medium to high volume production workshops. This tool features a quick cycle time with high-traction force and a vacuum rivet holding capacity even in the vertical position. It also features has a vacuum-powered mandrel extraction system. The Far rivet tools are renowned for being high quality Italian-made riveting guns that are trusted and supported with stocked spare parts.



RT-10172 Specifications	
Weight	2.8Kg
Type	Hydro-Pneumatic
Construction	ABS Plastic & Steel
Traction Force	6 bar – 22,725 N
Stroke	19.5 mm
Fastener Capacity	6.4mm (1/4") Structural Rivets in all materials. * 7.9mm (5/16") with optional extra nosepiece.

Rivet gun comes with nose tips X 2, stem deflector, wrench, spanner, oil bottle, allen key, air fitting and manual.




Safety Measures & Requirements

- Read the instructions carefully before using the tool.
- The tool must be used only by expert workers.
- A protective visor and gloves must be put on when using the tool.
- Use equipment recommended in the maintenance chapter to do any maintenance and/or regulation of the tool.
- For topping up the oil, we suggest using only fluids in accordance with the features specified in this working book. If any drop of oil touches your skin, you must wash with water and alkaline soap.
- The tool can be carried and we suggest putting it into its box after using.
- The tool needs a thorough six-monthly overhaul.
- There are no special requirements for storage.
- Repairing and cleaning operations must be done when the tool is not fed.
- If it is possible, we suggest a safety balancer.
- If the A-weighted emission sound pressure level is more than 70 dB (A), you must use some hearing protections (anti-noise headset, etc.).
- The workbench and the work surface must be always clean and tidy. The untidy can cause damages to people.
- Do not allow unauthorized persons to use the working tools.
- Make you sure that the compressed air feeding hoses have the correct size to be used.
- Do not carry the connected tool by pulling the hose. The hole must be far from any heating sources or from cutting parts.
- Keep the tools in good conditions; do not remove either safety parts or silencers.
- After repairing and/or adjusting, make sure you have already removed the adjusting spanners.
- Before disconnecting the compressed air hose from the tool make sure that there is no pressure in the hose.
- **WARNING:** Before using the tool, assemble the protection bottom supplied with the tool.

Tool Identification

Main Components

- A) Nozzle
- B) Head carrying nozzle
- C) Balancer connection
- D) Nails tank
- E) Oil tank plug
- F) Protection bottom
- G) Compressed air connection
- H) Tensile strenght button
- I) Suction opening lever



Technical Data

Working pressure	6 BAR
Min. int. diam. of the compressed air feeding hose	min. diam = 8 mm
Air consumption per cycle	10,9 NI
Maximum force	6 BAR - 22725 N
Stroke	19,5 mm
Weight	2,800 Kg
Working temperature	-5°/+50°
Root mean square in total acceleration frequency (Ac) to which the arms are subjected	2,5 m/s ²
A-weighted emission sound pressure level	74 dBA
Peak C-weighted instantaneous sound pressure ..	<130 dBC
A-weighted sound power	87 dBA

Air Feed

The air feed must be free from foreign bodies and humidity in order to protect the tool from premature wear and tear of the components in movement, therefore we suggest to use a lubricator group for compressed air.


Usage (fig. f1-f2-f3)



Press lightly for assembling the nails baffle (L), as shown in the figure f3.

After the clamping, the sheared nail is piped by the riveting tool and ejected from the back. By swinging the lever (I) you can activate the suction. By the suction nail system, the rivet remains in the nozzle also turning over the head of the riveting tool downwards: this detail increases a lot the usefulness of the riveting tool.

Do not keep the rivet with your fingers!

If the mandrel/pin tank (D) is full, do not use the riveting tool. Disconnect the tool, unscrew the mandrel/pin tank (D) and empty it properly. Screw the pin/mandrel tank (D) and start again to work.






Topping Up The Oil-Dynamic Circuit (fig. f8)

You need to top up the oil-dynamic circuit after a long period of work (15000 cycles), when you note a power loss. Put the riveting tool (DWELL AND NOT FED) in a horizontal position and remove the plug (E) and the nozzle (A) using the appropriate wrenches provided with the tool. During this operation, check the oil level in order to avoid any overflowing. Then, slowly pour the oil HLP 32 cSt into the bellows container (O) which shall be screwed to its seat on the plug (E). While keeping the riveting tool in a horizontal position and starting air feeding, push the tensile strength button and make the riveting tool carry out some cycles until air bubbles inside the container (O) stop coming out. This condition indicates that the topping up of the oil has fully been achieved. At this point, while keeping the riveting tool in a horizontal position, unscrew the oil container (O) and close it again. **Do not push the tensile strength button during this operation.** Go on by closing the oil tank plug (E).

WARNING: it is very important to follow the about mentioned instructions and use gloves and protection glasses or protective visors. If you need to empty fully the hydraulic circuit, you must put the oil in a suitable container and contact a Company that is authorized to discharge any waste.








Maintenance and Change of Size (fig. f4-f5-f6-f7)

The extended utilization of the riveting tool can cause the slipping of the clamps on the nail due to the deposited impurities. For this reason, it is necessary to lubricate the clamps after having cleaned them with benzine or derivatives. However, if clamps are worn out and as a consequence their working is jeopardized, replace them. First remove the head which carries the nozzle (B), by means of a standard spanner of 27 mm. Then, by using two standard spanners of 18 mm and 14 mm, remove the chuck (M) and extract the clamps (N).


The riveting tool is supplied, besides the nozzles set for FAR rivets, with a series of accessories for setting high-performance blind rivets $\varnothing 6,0 / 6,4$.

When replacing the nozzle (A), use the proper supplied wrench.

 **WARNING!**
Disconnect air feed when performing those operations.



Spare Parts Diagram



KIT C

47C(x5)
46C(x5)

KIT A

9A(x1)
10A(x1)
11A(x1)

KIT B

31B(x1)
32B(x1)

KIT D

52D(x1)
53D(x3)
54D(x3)
55D(x1)

86
87
88

89
90
91

