

SUPPORT BULLETIN

Positioning Services

Configuring Trimble SPS 585 For New Frequency and Baud Rate

The following instructions will instruct you how to change the frequency and baud on your Trimble SPS 585. To determine what new frequency and baud rate should be used in your region, please refer to www.trimble.com/sat.

Changing the Frequency and Baud Rate Settings for RTX on the SPS 585

The following set of instructions will instruct you how to change the frequency on your Trimble SPS 585.

You can change the frequency and baud rate for tracking the Trimble RTX satellite by using the web user interface (WebUI).


Connecting to the web user interface (WebUI) of the receiver

1. Make sure the receiver is on and in close proximity to your PC.
2. Connect to the receiver via WiFi – it should be listed as Trimble GNSS XXXX, where XXXX is the last 4 digits of the receiver's serial number.
 - a. If you are prompted for a password, the default password is *abcdeabcde*
3. Once connected to the GNSS receiver, open any modern web browser, such as Google Chrome, and type in <http://192.168.142.1>
 - a. If you are prompted for login credentials, the default username is *'admin'* and the default password is *'password'*

This document is for informational purposes only and is not a legally binding agreement or offer. Trimble makes no warranties and assumes no obligations or liabilities hereunder.

Trimble Navigation Limited, Positioning Services Division, 10368 Westmoor Drive, Westminster, CO 80021, USA


© 2015, Trimble Navigation Limited. All rights reserved. Trimble, the Globe & Triangle logo, OmniSTAR, and CenterPoint are trademarks of Trimble Navigation Limited, registered in the United States and in other countries. RangePoint is a/are trademark/trademarks of Trimble Navigation Limited. All other trademarks are the property of their respective owners.



Note: If the SPS 585 is not listed under WiFi connections, verify that the Wi-Fi icon on the front panel of the receiver is on and blinking; if it is not blinking, hold down the power button for 15 seconds, until you see all the lights on the front panel light up, and then release the power button. This will reset the SPS 585 receiver to default settings, which will turn WiFi on again.

Changing the frequency and baud rate

1. Connect to the WebUI
2. Navigate to the **MSS Corrections**→**Configuration** page
 - a. Confirm that **RTX/xFill** is selected
 - b. Set **SV name** to **Custom**
3. Enter the new satellites settings for your region
 - a. Enter the new frequency in the **Frequency [Mhz]** field
 - b. Enter the new baud rate in the **Bit Rate [Hz]** field
4. Click **OK**



Changing the Frequency and Baud Rate for xFill on the SPS 585

Trimble xFill utilizes the same satellite beams as Trimble RTX; you can follow the same directions presented in [Changing the Frequency and Baud Rate for RTX](#) and xFill will automatically use the new satellite beam settings.

Verifying Correct Operation for Trimble RTX

Once you have reconfigured your receiver to the correct new satellite settings for your region, you can confirm that you are receiving the signal by following the steps below.

Verification through the webUI


1. Make sure the receiver is outside with a clear and open view of the sky
2. Connect to the WebUI
3. Navigate to the **MSS Corrections**→**Summary** page
4. The **Mode** field should display **Tracking**

MSS Summary


Service	RTXvF#
Setting	RTX
SV name	AutoRTXvN
Frequency [MHz]	1557.8615
Bit Rate [bit/s]	600
Mode	Tracking
C/N0 [dBHz]	40.35
SNR [Eb/No]	9.49
Total messages	50
Bad messages	1
Total unique word bits	3328
Bad unique word bits	0
Total Viterbi symbols	414528
Corrected Viterbi symbols	51
Estimated BER	6.59140e-06
I/Q ratio	4.72712
Unique words with bit errors	0

Verification through the SitePulse field software


1. Make sure the receiver is on, and outside with a clear and open view of the sky and then connect to the receiver by following steps 2-7
2. Tap the **gear icon** to navigate to the Settings page




3. Tap GNSS Setup



4. Select the correct receiver, or tap **Scan** to search for it




5. Select CenterPoint RTX for the correction method




Note: You may not be able to select **CenterPoint RTX** if you do not have a valid **CenterPoint RTX** subscription

6. Enter user defined **GNSS horizontal and vertical precision tolerances**, and tap **Accept**, then tap **OK**




Note: You may be prompted to measure a datum shift after completing GNSS setup; review the SitePulse user guide for more information

7. Navigate to the **Settings** page and select the button next to **GNSS tolerances**




8. Select the Status button



9. The Status field will display Initializing or Initialized





For Additional Assistance

If you need additional assistance, please contact your regional Customer Care team.

North, Central & South America and the Caribbean

Phone: +1- 832-538-0210

US Toll Free Phone: +1- 877-407-4743

Brazil Phone: +55 (19) 3113 7099

Email: am_corrections@trimble.com

Australia, South East Asia and India

Australia Toll Free Phone: 1800 062 221

Phone: +61 8 9322 5295

Email: au_corrections@trimble.com (Australia)

Email: asia_corrections@trimble.com (South East Asia)

Email: in_corrections@trimble.com (India)

China

Phone: +86 10 8857 7575

Email: asia_corrections@trimble.com

New Zealand

NZ Toll Free Phone: 0800 888 864

Phone: +64 3 354 9195

Email: nz_corrections@trimble.com

Europe/CIS & Middle East

Phone: +31 70 317 0912 (Service & Support)

Phone: +46 8622 1063 (Sweden)

Phone: +49 6142 177 2035 (Germany)

Phone: +44 1256 746 220 (UK)

Email: eu_corrections@trimble.com (Europe, Russia & CIS)

Email: me_corrections@trimble.com (Middle East)

Africa

Phone: +27 21 404 1870

Email: africa_corrections@trimble.com