



# IntelliFlow™ RF2 Automatic and Manual Systems



Scan the related QR code above for other languages of this RF2 user manual and additional product information.





# CONTENTS

<b>SAFETY</b>	<b>5-9</b>
Safety Precautions.....	5
Hazards/Safeguards .....	6-9
<b>EU CONFORMITY</b>	<b>10-11</b>
EU Declaration of Conformity .....	10
Additional Safety Information .....	11
<b>INTRODUCTION</b>	<b>13-50</b>
Introduction (Automatic).....	13
System Components (Automatic).....	13
System Configuration (Automatic) .....	16
Theory of Operation (Automatic) .....	17
Introduction (Automatic w/Dispense Pump) .....	19
System Components (Automatic w/Dispense Pump).....	19
System Configuration (Automatic w/Dispense Pump) .....	23
Theory of Operation (Automatic w/Dispense Pump) .....	24
Introduction (Manual).....	27
System Components (Manual).....	27
System Configuration (Manual).....	30
Theory of Operation (Manual) .....	31
Introduction (Manual w/Dispense Pump).....	33
System Components (Manual w/Dispense Pump).....	33
System Configuration (Manual w/Dispense Pump) .....	37
Theory of Operation (Manual w/Dispense Pump) .....	38
Product Introduction.....	41
Complete System Part Numbering .....	44
Technical Specifications (Color Stacks) .....	45
Technical Specifications (Color Stack/Dispense Pump) .....	46
Process Configuration .....	47
<b>INSTALLATION</b>	<b>51-77</b>
Electrical.....	51
Pneumatics.....	53
Paint Materials .....	55
Air Cut Off Kit (Manual Mode) .....	57
CCV Pulse Setup (Manual Mode).....	62
External Air Connections .....	65
Auxiliary Signals .....	66
Disposal Information .....	73
RF2 Cloud Setup .....	74
<b>OPERATION</b>	<b>79-134</b>
Powering Up the System.....	79
Navigation Bar .....	79

# CONTENTS (cont.)

## OPERATION (cont.)

Language Settings.....	81
Running The System .....	81
Calibration .....	90
Manual Override/Local Fluid Control.....	91
Shutting Down The System.....	93
Administrator Functions .....	98
Startup Guide .....	102
Daily Operations.....	104
Dispense Pump Operation.....	108
Flow Meter .....	109
Setup .....	111
Diagnostics .....	130
Data Log Reporting .....	132
Multi-Color Status Light Functions.....	134

## MAINTENANCE, TROUBLESHOOTING & SPARE PARTS .....135-192

Regular Maintenance Procedures and Recommendations.....	135
Top Level Part Numbering.....	135
Component View and Spare Parts.....	136
Troubleshooting .....	170
Troubleshooting (Dispense Pump) .....	175
Troubleshooting, Festo VTEM Regulator .....	178
Troubleshooting, Festo VTUG Solenoid.....	182
Introduction-Dispense Pump Troubleshooting.....	185
Solenoid Connection Reference-Color Stack.....	186
Solenoid Connection Reference-Dispense Pump.....	188
Standard Flow Meter Troubleshooting .....	190
Maintenance Procedure .....	191
Preventative Maintenance .....	192

## APPENDIX .....193-265

Fieldbus I/O.....	193
PLC Array Tables .....	198
Schematics Table Of Contents .....	210
Schematics Revision List .....	211
Electrical Diagrams.....	212

## MANUAL CHANGE SUMMARY .....266

## WARRANTY POLICY .....268



# SAFETY

## SAFETY PRECAUTIONS

Before operating, maintaining or servicing any electrostatic coating system, read and understand all of the technical and safety literature for your products. This manual contains information that is important for you to know and understand. This information relates to **USER SAFETY and PREVENTING EQUIPMENT PROBLEMS.**

### ⚠ WARNING

WARNING!: Indicates a hazardous situation that, if not avoided, could result in death or serious injury.

### ⚠ CAUTION

Caution!: Indicates a hazardous situation that, if not avoided, could result in minor or moderate injury or equipment damage.

### NOTICE

Notice: Indicates information considered important but not hazard related.

To help you recognize this information, we use the following symbols. Please pay particular attention to these sections.

While this manual lists standard specifications and service procedures, some minor deviations may be found between this literature and your equipment. Differences in local codes and plant requirements, material delivery requirements, etc., make such variations inevitable. Compare this manual with your system installation drawings and associated equipment manuals to reconcile such differences.

Careful study and continued use of this manual will provide a better understanding of the equipment and process, resulting in more efficient operation, longer trouble-free service and faster, easier troubleshooting. If you do not have the manuals and safety literature for your equipment, contact your local Carlisle Fluid Technologies representative or Carlisle Fluid Technologies technical support.

### ⚠ WARNING

The user **MUST** read and be familiar with the Safety Section in this manual and the safety literature therein identified.

This equipment is intended to be used by trained personnel **ONLY**.


This manual **MUST** be read and thoroughly understood by **ALL** personnel who operate, clean or maintain this equipment! Special care should be taken to ensure that the **WARNINGS** and safety requirements for operating and servicing the equipment are followed.



The user should be aware of and adhere to **ALL** local building and fire codes and ordinances as well as **NFPA 33 AND EN 16985 SAFETY STANDARDS, LATEST EDITION**, or applicable country safety standards, prior to installing, operating, and/or servicing this equipment.


### ⚠ WARNING



The hazards shown on the following pages may occur during the normal use of this equipment.

**Repairs may only be performed by personnel authorized by Carlisle Fluid Technologies.**

<b>AREA</b> Tells where hazards may occur	<b>HAZARDS</b> Tells what the hazard is	<b>SAFEGUARDS</b> Tells how to avoid the hazard
<p><b>Spray Area</b></p> 	<p><b>Fire Hazard</b></p> <p>Improper or inadequate operation and maintenance procedures will cause a fire hazard.</p> <p>Protection against inadvertent arcing that is capable of causing fire or explosion is lost if any safety interlocks are disabled during operation. Frequent Power Supply or Controller shutdown indicates a problem in the system requiring correction.</p>	<p>Fire extinguishing equipment must be present in the spray area and tested periodically.</p> <p>Spray areas must be kept clean to prevent the accumulation of combustible residues.</p> <p>Smoking must never be allowed in the spray area.</p> <p>The high voltage supplied to the atomizer must be turned off prior to cleaning, flushing, or maintenance.</p> <p>Spray booth ventilation must be kept at the rates required by NFPA 33, EN 16985, country, and local codes. In addition, ventilation must be maintained during cleaning operations using flammable or combustible solvents.</p> <p>Electrostatic arcing must be prevented. Safe sparking distance must be maintained between the parts being coated and the applicator. A distance of 1 inch (25mm) for every 10KV of output voltage is required at all times.</p> <p>Test only in areas free of combustible material.</p> <p>Testing may require high voltage to be on, but only as instructed.</p> <p>Non-factory replacement parts or unauthorized equipment modifications may cause fire or injury.</p> <p>If used, the key switch bypass is intended for use only during setup operations. Production should never be done with safety interlocks disabled.</p> <p>The paint process and equipment should be set up and operated in accordance with NFPA 33, NEC, OSHA, local, country, and European Health and Safety Norms.</p>

<b>AREA</b> Tells where hazards may occur	<b>HAZARDS</b> Tells what the hazard is	<b>SAFEGUARDS</b> Tells how to avoid the hazard
<p><b>Spray Area</b></p> 	<p><b>Explosion Hazard</b></p> <p>Improper or inadequate operation and maintenance procedures will cause a fire hazard.</p> <p>Protection against inadvertent arcing that is capable of causing fire or explosion is lost if any safety interlocks are disabled during operation.</p> <p>Frequent Power Supply or Controller shutdown indicates a problem in the system requiring correction.</p>	<p>Electrostatic arcing must be prevented. Safe sparking distance must be maintained between the parts being coated and the applicator. A distance of 1 inch (25mm) for every 10KV of output voltage is required at all times.</p> <p>Unless specifically approved for use in hazardous locations, all electrical equipment must be located outside or applicable county code hazardous areas, in accordance with NFPA 33.</p> <p>Test only in areas free of flammable or combustible materials.</p> <p>The current overload sensitivity (if equipped) MUST be set as described in the related section of the equipment manual. Protection against inadvertent arcing that is capable of causing fire or explosion is lost if the current overload sensitivity is not properly set. Frequent power supply shutdown indicates a problem in the system which requires correction.</p> <p>Always turn the control panel power off prior to flushing, cleaning, or working on spray system equipment.</p> <p>Before turning high voltage on, make sure no objects are within the safe sparking distance.</p> <p>Ensure that the control panel is interlocked with the ventilation system and conveyor in accordance with NFPA-33, EN 16985.</p> <p>Have fire extinguishing equipment readily available and tested periodically.</p>
<p><b>General Use and Maintenance</b></p> 	<p>Improper operation or maintenance may create a hazard.</p> <p>Personnel must be properly trained in the use of this equipment.</p>	<p>Personnel must be given training in accordance with the requirements of NFPA 33.</p> <p>Instructions and safety precautions must be read and understood prior to using this equipment.</p> <p>Comply with appropriate local, state, and national codes governing ventilation, fire protection, operation maintenance, and housekeeping. Reference OSHA, NFPA 33, EN Norms and your insurance company requirements.</p>

<b>AREA</b> Tells where hazards may occur	<b>HAZARDS</b> Tells what the hazard is	<b>SAFEGUARDS</b> Tells how to avoid the hazard
<p><b>Spray Area / High Voltage Equipment</b></p> 	<p><b>Electrical Discharge</b></p> <p>There is a high voltage device that can induce an electrical charge on ungrounded objects which is capable of igniting coating materials.</p> <p>Inadequate grounding will cause a spark hazard. A spark can ignite many coating materials and cause a fire or explosion.</p>	<p>Parts being sprayed and operators in the spray area must be properly grounded.</p> <p>Parts being sprayed must be supported on conveyors or hangers that are properly grounded. The resistance between the part and earth ground must not exceed 1 Meg Ohm. (Refer to NFPA 33, EN 16985).</p> <p>Operators must be grounded. Grounding straps on wrists or legs may be used to assure adequate ground contact.</p> <p>Footware to be used by operator must comply with EN ISO 20344, resistance not to exceed 100 Meg Ohm. Protective clothing including gloves should comply with EN 1149-5, resistance not to exceed 100 Meg Ohm.</p> <p>Operators must not be wearing or carrying any ungrounded metal objects.</p> <p>When using an electrostatic handgun, operators must assure contact with the handle of the applicator via conductive gloves or gloves with the palm section cut out.</p> <p>NOTE: REFER TO NFPA 33, EN 16985 OR SPECIFIC COUNTRY SAFETY CODES REGARDING PROPER OPERATOR GROUNDING.</p> <p>All electrically conductive objects in the spray area, with the exception of those objects required by the process to be at high voltage, must be grounded. Grounded conductive flooring must be provided in the spray area.</p> <p>Always turn off the power supply prior to flushing, cleaning, or working on spray system equipment or applicable county code.</p> <p>Unless specifically approved for use in hazardous locations, all electrical equipment must be located outside or applicable country code, hazardous areas, in accordance with NFPA 33.</p> <p>Avoid installing an applicator into a fluid system where the solvent supply is ungrounded.</p> <p>Do not touch the applicator electrode while it is energized.</p>

<b>AREA</b> Tells where hazards may occur	<b>HAZARDS</b> Tells what the hazard is	<b>SAFEGUARDS</b> Tells how to avoid the hazard
<p><b>Electrical Equipment</b></p> 	<p><b>Electrical Discharge</b></p> <p>High voltage equipment is utilized in the process. Arcing in the vicinity of flammable or combustible materials may occur. Personnel are exposed to high voltage during operation and maintenance.</p> <p>Protection against inadvertent arcing that may cause a fire or explosion is lost if safety circuits are disabled during operation.</p> <p>Frequent power supply shut-down indicates a problem in the system which requires correction.</p> <p>An electrical arc can ignite coating materials and cause a fire or explosion.</p>	<p>Unless specifically approved for use in hazardous locations, the power supply, control cabinet, and all other electrical equipment must be located outside or applicable country codes, hazardous areas in accordance with NFPA 33 and EN 16985.</p> <p>Turn the power supply OFF before working on the equipment.</p> <p>Test only in areas free of flammable or combustible material.</p> <p>Testing may require high voltage to be on, but only as instructed.</p> <p>Production should never be done with the safety circuits disabled.</p> <p>Before turning the high voltage on, make sure no objects are within the sparking distance.</p>
<p><b>Toxic Substances</b></p> 	<p><b>Chemical Hazard</b></p> <p>Certain materials may be harmful if inhaled, or if there is contact with the skin.</p>	<p>Follow the requirements of the Safety Data Sheet supplied by coating material manufacturer.</p> <p>Adequate exhaust must be provided to keep the air free of accumulations of toxic materials. Reference EN 12215 or applicable code.</p> <p>Use a mask or respirator whenever there is a chance of inhaling sprayed materials. The mask must be compatible with the material being sprayed and its concentration. Equipment must be as prescribed by an industrial hygienist or safety expert, and be NIOSH approved.</p>



<b>Product Description / Object of Declaration:</b>	<b>IntelliFlow RF2</b>
<b>This Product is designed for use with:</b>	Solvent-based and waterborne materials
<b>Suitable for use in hazardous area:</b>	
<b>Protection Level:</b>	Not applicable
<b>Notified body details and role:</b>	Intertek USA 7250 Hudson Blvd N STE 100, St Paul, MN 55128, USA
<b>This Declaration of Conformity / Incorporation is issued under the sole responsibility of the manufacturer:</b>	Carlisle Fluid Technologies Inc 7166 4th St. N. Oakdale, MN 55128 USA
<b>Representative authorised to compile the technical file</b>	Sales and Marketing Director. CFT UK Ltd 1 Avenue de Lattre de Tassigny 94736 Nogent, Cedex. France

**EU Declaration of Conformity**



**This Declaration of Conformity / Incorporation is issued under the sole responsibility of the manufacturer:**

Machinery Directive 2006/42/EC  
 EMC Directive 2014/30/EU  
 RoHS Directive 2011/65/EU  
 by complying with the following statutory documents and harmonised standards:  
 EN ISO 12100:2010 Safety of Machinery - General Principles for Design  
 EN 60204-1:2006 Safety of Machinery - Electrical Equipment of Machines - General requirements.  
 BS EN 61000-6-2:2019 Electromagnetic Compatibility Generic Standards Immunity for residential/commercial/light industry environments  
 EN 63000: 2018 Technical documentation for the assessment according to REACH  
 BS EN 61000-6-4:2019 Electromagnetic Compatibility (EMC) - Generic standards - Emission standard for industrial environments

Providing all conditions of safe use / installation stated within the product manuals have been complied with and also installed in accordance with any applicable local codes of practice.

Signed for and on behalf of  
 Carlisle Fluid Technologies:

F. A. Sutter Executive President: Engineering and  
 Operations, Scottsdale, AZ, 85254. USA  
 1-Dec-21

X-XXXX-X

**⚠ CAUTION**

Do not operate the RF2 before this section is read.

**ADDITIONAL SAFETY INFORMATION**

The RF2 has a main operator panel emergency stop (E-Stop) pushbutton included with the unit. In the event of a safety fault, all operations for the RF2 will halt, all solenoid outputs will be turned off, and all pressure pilot signals will go to zero psi/BAR. Recovery from this state requires the user to reload material to reset all solenoids, etc. before operation resumes.

**⚠ WARNING**

Do not contact, disconnect, or manipulate electrical connections or devices while the system is under power. The main disconnect on the right side of the controller can be locked out, and proper Lockout-Tagout (LOTO) procedures must be used for electrical work internal to the controller.

If this is not possible for the purpose of diagnosis and troubleshooting during working conditions, then only qualified electrical personnel are to perform the work.

**NOTICE**

During the initial commission of the equipment, and at periodic times throughout the life of the equipment, all fluid fittings must be visually inspected for leaks. Periodically, all pieces of this equipment must be visually inspected for signs of obvious degradation due to chemicals or other conditions present in the environment where the equipment is installed.

**⚠ WARNING**

Local regulations may require fire suppression equipment to be installed where the equipment is operated.

**⚠ WARNING**

To prevent possible chemical spillage when personnel are not on site, air and fluid supplies for the equipment must be disabled when the equipment is idled for an extended period of time such as end-of-day shutdown, etc.

Optionally, some sensors, switches, or other ancillary equipment, connected to this equipment may be located in the presence of flammable gases and vapors. All such equipment must be connected through the use of intrinsic-safe or Zener barriers and will be classified as a 'simple apparatus' or themselves be approved for use in these areas.

**Page is intentionally left blank.**



## INTRODUCTION—AUTOMATIC

The IntelliFlow RF2 is a standalone system designed to control material delivery from a supply source (pressure pot or circulation system) to an applicator. It accurately controls material mixture ratio and/or material flow in a coating process, which can include single component, 2k, or 3k materials, and handles flushing and loading of the materials.

The RF2 can include up to four fluid channels (for additional details on Channels, refer to page 17 of this manual) which can be arranged in many ways. The available channels can be configured into 1, 2, or 3 component mixes (guns), using any combination of these mixes to utilize all the available channels. The RF2 can be configured to include anywhere from 32 to 128 solenoids, all of which are fully addressable to be used in various ways to control the process (examples include applicator triggers, dump, solvent flush, color-valve selects, etc).

The channels and fluid mixes can be grouped into up to two stations with individual sets of color stacks, which can be controlled completely independently of one another.


The RF2 can be operated locally, from its included 15-inch touch screen, or it can be easily integrated into an automated process by use of discrete signals for simple systems or by multiple different industrial fieldbus protocols for more advanced control.

The RF2 can be connected to the cloud, allowing access to Carlisle Fluid Technologies technical experts for the purpose of remote troubleshooting. This access may also be granted to local plant personnel.

Data gathered by the RF2, including alarms and flow-totalization data is stored in an onboard SD card, and can be accessed via FTP, or other methods.

### SYSTEM COMPONENTS


1. Control Panel
2. Fluid Control Module
3. Valve Stacks
4. Mixing Module



## CONTROL PANEL


### External Components

1. Status Light
2. Main Power Entry
3. Main Power Disconnect Switch
4. Panel Opening Latch
5. Emergency Stop Button
6. HMI



### Internal Components


1. Safety Relay
2. Electronic Circuit Protector
3. Local Ethernet Switch
4. CPU/Controller
5. DC Power Supply
6. Main Power Circuit Breaker
7. Line Filter
8. Status Light Connection
9. Main Power Disconnect Switch
10. I/O Block & Terminals
11. Terminal Blocks
12. HMI & E-Stop Button Connection



## FLUID COMPONENTS


### Valve Stack

1. Fluid Pressure Regulator (Optional)
2. Fluid Panel Connection
3. Solenoid Connection
4. Fluid Valves
5. Air Push Valve
6. Air Regulator
7. Solvent Flush Valve



### Flow Control Module


1. Valve Stack Connection
2. MVR (Material Valve Regulator) w/Air Gauge
3. Flow Meter
4. Control Panel Connection
5. Calibration Block
6. Mix Module Connection








Component A


## Mix Module

1. Mix Block
2. Flow Control Module A Connection
3. Flush Valve
4. Dispense Pump Connection
5. Static Mix Tube
6. Gun Connection



### RF2 AUTOMATIC SYSTEM CONFIGURATION


- |   |                                  |                           |
|---|----------------------------------|---------------------------|
|  <b>Air Hosing</b>           | 1. Air Manifold                  | 5. Material B Valve Stack |
|  <b>Solvent Hosing</b>       | 2. Valve Stack Solenoid Manifold | 6. Material A Fluid Panel |
|  <b>Material A Lines</b>     | 3. Pressure Solenoid Manifold    | 7. Material B Fluid Panel |
|  <b>Material B Lines</b>     | 4. Material A Valve Stack        | 8. Mix Chamber            |
|  <b>Mixed Material Lines</b> |                                  |                           |




## THEORY OF OPERATION

The RF2's operating principle is as follows:


1. The material is fed through the hoses towards the material valves in each stack.
2. If multiple materials of the same type (Resin, Hardener, or Reducer) are used, each valve will control its flow separately.




3. The material valves are normally closed. When material flow is needed, the system controller opens the valve via the solenoid addressed to it.



4. The material flows from the valves to the flow control module.
5. The flow meter sends a signal to the control panel to indicate the material's current flow rate.
6. The control panel determines if the flow rate is within specification.
7. The control panel increases or decreases the flow rate of material passed through the MVR until it reaches the desired value.



8. The material flows to the mix manifold where it combines with the second and/or third material.



9. The mixed material then flows to the gun's inlet connection.

**Page is intentionally left blank.**



## INTRODUCTION—AUTOMATIC w/DISPENSE PUMP

The IntelliFlow RF2 is a standalone system designed to control material delivery from a supply source (pressure pot or circulation system) to an applicator. It accurately controls material mixture ratio and/or material flow in a coating process, which can include single component, 2k, or 3k materials, and handles flushing and loading of the materials.

The RF2 can include up to four fluid channels (for additional details on Channels, refer to page 24 of this manual) which can be arranged in many ways. The available channels can be configured into 1, 2, or 3 component mixes (guns), using any combination of these mixes to utilize all the available channels. The RF2 can be configured to include anywhere from 32 to 128 solenoids, all of which are fully addressable to be used in various ways to control the process (examples include applicator triggers, dump, solvent flush, color-valve selects, etc).

The channels and fluid mixes can be grouped into up to two stations with individual sets of color stacks, which can be controlled completely independently of one another.

Control and positioning of the dispense pump is precise. An electronically controlled stepper motor with integral linear actuator allow for dispense from 2 cc to 600 cc per minute depending on the chosen dispense pump size.


The RF2 can be operated locally, from its included 15-inch touch screen, or it can be easily integrated into an automated process by use of discrete signals for simple systems or by multiple different industrial fieldbus protocols for more advanced control.

The RF2 can be connected to the cloud, allowing access to Carlisle Fluid Technologies technical experts for the purpose of remote troubleshooting. This access may also be granted to local plant personnel.

Data gathered by the RF2, including alarms and flow-totalization data is stored in an onboard SD card, and can be accessed via FTP, or other methods.

### SYSTEM COMPONENTS


1. Control Panel
2. Fluid Control Module
3. Valve Stacks
4. Dispense Pump
5. Mixing Module



## CONTROL PANEL


### External Components

1. Status Light
2. Main Power Entry
3. Main Power Disconnect Switch
4. Panel Opening Latch
5. Emergency Stop Button
6. HMI



### Internal Components


1. Safety Relay
2. Electronic Circuit Protector
3. Local Ethernet Switch
4. CPU/Controller
5. DC Power Supply
6. Main Power Circuit Breaker
7. Line Filter
8. Status Light Connection
9. Main Power Disconnect Switch Connector
10. I/O Block & Terminals
11. Terminal Blocks
12. HMI & E-Stop Button Connection



## FLUID COMPONENTS


### Valve Stack

1. Fluid Pressure Regulator (Optional)
2. Fluid Panel Connection
3. Solenoid Connection
4. Fluid Valves
5. Air Push Valve
6. Air Regulator
7. Solvent Flush Valve



### Flow Control Module


1. Valve Stack Connection
2. MVR (Material Valve Regulator) w/Air Gauge
3. Flow Meter
4. Control Panel Connection
5. Calibration Block
6. Mix Module Connection



Component A

### Dispense Pump Assembly


1. Dispense Pump Enclosure
2. Linear Actuator Assembly
3. Material Outlet Connection
4. Dispense Pump (300 cc or 600 cc)
5. Material Inlet Connection








Component B


### Mix Module

1. Mix Block
2. Flow Control Module A Connection
3. Flush Valve
4. Dispense Pump Connection
5. Static Mix Tube
6. Gun Connection



**RF2 AUTOMATIC SYSTEM w/DISPENSE PUMP CONFIGURATION**


- |   |                             |                                  |                           |
|---|-----------------------------|----------------------------------|---------------------------|
|  | <b>Air Hosing</b>           | 1. Air Manifold                  | 5. Material A Fluid Panel |
|  | <b>Solvent Hosing</b>       | 2. Valve Stack Solenoid Manifold | 6. Dispense Pump          |
|  | <b>Material A Lines</b>     | 3. Pressure Solenoid Manifold    | 7. Mix Chamber            |
|  | <b>Material B Lines</b>     | 4. Material A Valve Stack        |                           |
|  | <b>Mixed Material Lines</b> |                                  |                           |




## THEORY OF OPERATION

The RF2's operating principle is as follows:


1. The material is fed through the hoses towards the A material valves in each stack.
2. If multiple materials of the same type (Resin, Hardener, or Reducer) are used, each valve will control its flow separately.



3. The material valves are normally closed. When material flow is needed, the system controller opens the valve via the solenoid addressed to it.




4. The material flows from the valves to the flow control module.
5. The flow meter sends a signal to the control panel to indicate the material's current flow rate.
6. The control panel determines if the flow rate is within specification.
7. The control panel increases or decreases the flow rate of material passed through the MVR until it reaches the desired value.






8. The material flows into the dispense pump from the B material supply.



9. The material flows to the mix manifold where it combines with the second and/or third material.



10. The mixed material then flows to the gun's inlet connection.



# INTRODUCTION—MANUAL

The IntelliFlow RF2 is a standalone system designed to control material delivery from a supply source (pressure pot or circulation system) to an applicator. It accurately controls material mixture ratio and/or material flow in a coating process, which can include single component, 2k, or 3k materials, and handles flushing and loading of the materials.

The RF2 can include up to four fluid channels (for additional details on Channels, refer to page 31 of this manual) which can be arranged in many ways. The available channels can be configured into 1, 2, or 3 component mixes (guns), using any combination of these mixes to utilize all the available channels. The RF2 can be configured to include anywhere from 32 to 128 solenoids, all of which are fully addressable to be used in various ways to control the process (examples include applicator triggers, dump, solvent flush, color-valve selects, etc.).

The channels and fluid mixes can be grouped into up to two stations with individual sets of color stacks, which can be controlled completely independently of one another.


The RF2 can be operated locally, from its included 15-inch touch screen, or it can be easily integrated into an automated process by use of discrete signals for simple systems, or by multiple different industrial fieldbus protocols for more advanced control.

The RF2 can be connected to the cloud, allowing access to Carlisle Fluid Technologies technical experts for the purpose of remote troubleshooting. This access may also be granted to local plant personnel.

Data gathered by the RF2, including alarms and flow-totalization data is stored in an onboard SD card, and can be accessed via FTP, or other methods.

## SYSTEM COMPONENTS


1. Control Panel
2. Fluid Control Module
3. Valve Stacks
4. Mixing Module



## CONTROL PANEL


### External Components

1. Status Light
2. Main Power Entry
3. Main Power Disconnect Switch
4. Panel Opening Latch
5. Emergency Stop Button
6. HMI



### Internal Components


1. Safety Relay
2. Electronic Circuit Protector
3. Local Ethernet Switch
4. CPU/Controller
5. DC Power Supply
6. Main Power Circuit Breaker
7. Line Filter
8. Status Light Connection
9. Main Power Disconnect Switch Connector
10. I/O Block & Terminals
11. Terminal Blocks
12. HMI & E-Stop Button Connection



## FLUID COMPONENTS


### Valve Stack

1. Fluid Pressure Regulator (Optional)
2. Fluid Panel Connection
3. Solenoids Connection
4. Fluid Valves
5. Air Push Valve
6. Air Regulator
7. Solvent Flush Valve



### Flow Control Module


1. Valve Stack Connection
2. Flow Meter
3. Control Panel Connection
4. Calibration Block
5. Mix Module Connection








Component A



## Mix Module

1. Gun Connection
2. Static Mix Tube
3. Mix Block
4. Solvent Flush Valve
5. Flow Control Module Connection
6. Gun Connection



### RF2 MANUAL SYSTEM CONFIGURATION

- |   |                                  |                           |
|---|----------------------------------|---------------------------|
|  <b>Air Hosing</b>           | 1. Air Manifold                  | 5. Material B Valve Stack |
|  <b>Solvent Hosing</b>       | 2. Valve Stack Solenoid Manifold | 6. Material A Fluid Panel |
|  <b>Material A Lines</b>     | 3. Pressure Solenoid Manifold    | 7. Material B Fluid Panel |
|  <b>Material B Lines</b>     | 4. Material A Valve Stack        | 8. Mix Chamber            |
|  <b>Mixed Material Lines</b> |                                  |                           |




## THEORY OF OPERATION

The RF2's operating principle is as follows:


In RF2 manual gun configurations with a pulse valve channel type for the B and/or C components, fluid from the hardener or reducer channels is "dosed" into the mixture in order to accurately control the material ratio. The rate of pulsing and length of each pulse of fluid is regulated in order to achieve the desired ratio.

For optimal performance, the pulse valve will operate at 3Hz rate of fire, and all adjustments by the controller will be through varying the length of each pulse. To achieve this, adjust the pulse valve so the flow through the valve when it is open is at 3Hz rate. Further instructions for adjusting the pulse valve are:


1. The material is fed through the hoses towards the material valves in each stack.
2. If multiple materials of the same type (Resin, Hardener, or Reducer) are used, each valve will control its flow separately.




3. The material valves are normally closed. When material flow is needed, the system controller opens the valve via the solenoid addressed to it.



4. The material flows from the valve to the flow meter.
5. The flow meter sends a signal to the control panel indicating the material's current flow rate.
6. The control panel determines if the flow rate is within specification or not.
7. Through the pulse valve, the control panel increases or decreases the flow rate of material passing through, to reach the desired value.



8. The material proceeds to the mix manifold where it combines with the second and/or third material.



9. The mixed material then flows to the gun's inlet connection.
10. If needed, the system can flush only mixed material through the mix manifold, or through the valve stack for color changes.

**Page is intentionally left blank.**



## INTRODUCTION—MANUAL w/DISPENSE PUMP

The IntelliFlow RF2 is a standalone system designed to control material delivery from a supply source (pressure pot or circulation system) to an applicator. It accurately controls material mixture ratio and/or material flow in a coating process, which can include single component, 2k, or 3k materials, and handles flushing and loading of the materials.

The RF2 can include up to four fluid channels (for additional details on Channels, refer to page 38 of this manual) which can be arranged in many ways. The available channels can be configured into 1, 2, or 3 component mixes (guns), using any combination of these mixes to utilize all the available channels. The RF2 can be configured to include anywhere from 32 to 128 solenoids, all of which are fully addressable to be used in various ways to control the process (examples include applicator triggers, dump, solvent flush, color-valve selects, etc).

The channels and fluid mixes can be grouped into up to two stations with individual sets of color stacks, which can be controlled completely independently of one another.

Control and positioning of the dispense pump is precise. An electronically controlled stepper motor with integral linear actuator allow for dispense from 2 cc to 600 cc per minute depending on the chosen dispense pump size.


The RF2 can be operated locally, from its included 15-inch touch screen, or it can be easily integrated into an automated process by use of discrete signals for simple systems or by multiple different industrial fieldbus protocols for more advanced control.

The RF2 can be connected to the cloud, allowing access to Carlisle Fluid Technologies technical experts for the purpose of remote troubleshooting. This access may also be granted to local plant personnel.

Data gathered by the RF2, including alarms and flow-totalization data is stored in an onboard SD card, and can be accessed via FTP, or other methods.

### SYSTEM COMPONENTS


1. Control Panel
2. Fluid Control Module
3. Valve Stacks
4. Dispense Pump
5. Mixing Module



## CONTROL PANEL


### External Components

1. Status Light
2. Main Power Entry
3. Main Power Disconnect Switch
4. Panel Opening Latch
5. Emergency Stop Button
6. HMI



### Internal Components


1. Safety Relay
2. Electronic Circuit Protector
3. Local Ethernet Switch
4. CPU/Controller
5. DC Power Supply
6. Main Power Circuit Breaker
7. Line Filter
8. Status Light Connection
9. Main Power Disconnect Switch Connector
10. I/O Block & Terminals
11. Terminal Blocks
12. HMI & E-Stop Button Connection



## FLUID COMPONENTS


### Valve Stack

1. Fluid Pressure Regulator (Optional)
2. Fluid Panel Connection
3. Solenoids Connection
4. Fluid Valves
5. Air Push Valve
6. Air Regulator
7. Solvent Flush Valve



### Flow Control Module


1. Valve Stack Connection
2. Flow Meter
3. Control Panel Connection
4. Calibration Block
5. Mix Module Connection



Component A

### Dispense Pump Assembly


1. Dispense Pump Enclosure
2. Linear Actuator Assembly
3. Material Outlet Connection
4. Dispense Pump (300 cc or 600 cc)
5. Material Inlet Connection








Component B



### Mix Module

1. Mix Block
2. Flow Control Module A Connection
3. Flush Valve
4. Dispense Pump Connection
5. Static Mix Tube
6. Gun Connection



### RF2 MANUAL SYSTEM w/DISPENSE PUMP CONFIGURATION


- |   |                                  |                           |
|---|----------------------------------|---------------------------|
|  <b>Air Hosing</b>           | 1. Air Manifold                  | 5. Material A Fluid Panel |
|  <b>Solvent Hosing</b>       | 2. Valve Stack Solenoid Manifold | 6. Dispense Pump          |
|  <b>Material A Lines</b>     | 3. Pressure Solenoid Manifold    | 7. Mix Chamber            |
|  <b>Material B Lines</b>     | 4. Material A Valve Stack        |                           |
|  <b>Mixed Material Lines</b> |                                  |                           |




## THEORY OF OPERATION

The RF2's operating principle is as follows:


1. The material is fed through the hoses towards the A material valves in each stack.
2. If multiple materials of the same type (Resin, Hardener, or Reducer) are used, each valve will control its flow separately.



3. The A material valves are normally closed. When material flow is needed, the system controller opens the valve via the solenoid addressed to it.




4. The material flows from the valves to the flow control module.
5. The flow meter sends a signal to the control panel to indicate the material's current flow rate.
6. The control panel determines if the flow rate is within specification.
7. The control panel increases or decreases the flow rate of material passed through the MVR until it reaches the desired value.






8. The material flows into the dispense pump from the B material supply.



9. The material flows to the mix manifold where it combines with the second and/or third material.



10. The mixed material then flows to the gun's inlet connection.

# INTRODUCTION

The RF2 is a versatile system that can be configured in many ways. This section details the terminology of the various components that make up the system and process.

It should be noted, that although the following is relatively complex, the vast majority of RF2 units will be factory-configured based on the fluid components that were purchased, and will only require slight modifications, if any, before operating the system.

## TERMINOLOGY

In demonstrating the ways to configure and operate the RF2, the following terminology will be used throughout the manual.

### Outputs

Outputs are either (1) discrete signals that are assigned to pneumatic solenoids (up to 128 can be controlled by the RF2 via four separate manifolds) or (2) hardwired digital signals.

Outputs can be configured as several types:

- Color Valve (CCV)—used on a material stack to select different materials. Each CCV output has a number associated with it for the valve number on the color stack.
- Dump—output is used as a dump, which operates much like a trigger. The system expects flow when this is active.
- Flow Control Pulse—used as a flow control method for manual configurations that use a pulsing channel.
- Dispense Pump—dispenses an electronically controlled and precise flow of fluid controlled by a stepper motor with an integrated linear actuator.
- Dump—output acts as a trigger and flow will be expected when this output is on.
- In-Booth: Alarm indicator "Wink-Eye" for in booth controller accessory.

Assigned to a specific channel.

- Flow Test—used by each channel as an automated calibration port.
- FL. OVRD. (Fluid Override)—used when a DR-1 or HGB air-piloted fluid regulator is used as the flow control device. Fluid override port forces the unit open for cleaning. The flow control functionality is stopped.
- Material Select—used on a mix manifold to allow or disallow a material channel from entering the mixed section.
- Pass Through—allows the user to assign a solenoid to a user-defined input, basically giving direct control of the solenoid to external processes.
- Sequence—output used in flush, load, and other fluid sequences.
- Standard—output is active during a sequence but has no particular effect on flow control (examples are solvent and air valves).
- Trigger—starts an applicator
- Unused

## Functions

Functions of different types are assigned to the programmed outputs and operate on them in different ways. Functions are called during fluid sequences. Types are:

- Unused
- Simple—output assigned to the function is active while the function is active during a fluid sequence.
- Latch—when the function is activated during a fluid sequence, the output assigned to the function turns on and holds on until an unlatch command is given.
- Unlatch—opposite of latch example: when the function is activated during a fluid sequence, the output assigned to the process turns off and stays off.
- Chop—this function contains two outputs, and when active, alternates between the two. This is typically used with stack solvent and air solenoids.
- Pulse—the assigned output turns on for a set period (programmable) when the function becomes active.
- Wait—(future feature)—the function causes the fluid sequence to pause until the assigned input is true.

Functions can be made available to any of the available fluid sequences.

## Sequences

A sequence consists of twelve steps with programmable times per step. During each step, specific functions can be activated or deactivated, causing their outputs to react according to the function setup.

## Channel

A channel is a single flow-control path for fluid. Channels can be grouped together to build a gun or mixer. The RF2 controller can handle up to four channels.

Channels have multiple possible configurations – options include:

### Flow Control Type

1. MVR—the channel uses a 0-100psi pressure pilot signal to control an MVR (Material Volume Regulator) to control flow.
2. DR1—the channel uses a 0-100psi pressure pilot signal to control a DR1 pressure regulator to actuate flow.
3. Gear Pump (Future)—the channel uses a gear-pump to actuate flow.
4. Pulse—for manual slave channels only—the channel uses a pulsing valve to regulate the ratio of the mixture—note in manual applications, flow control is carried out by the handgun.
5. Dispense Pump—the channel uses the dispense pump to actuate flow.
6. Feedback Only (Future)—for manual master channels only—no flow regulator is used.

### Feedback Type

1. Square Wave—a flow meter that produces a quadrature signal is used for reading flow.

### Inlet Pressure Regulation

1. Enabled or disabled to control the fluid pressure to the inlet of the flow control device.

## Gun/Mixer

A gun or mix is a combination of 1-3 fluid channels. Depending on ratio setpoints, the flow command of the gun is divided into flow rates for the assigned channels, to accurately mix the material.

Configurations for gun/mixers are:

### Fluid Type

1. Unused, 1K, 2K, 3K.

### Control Type

1. Automatic—an automatic gun is used triggered by an external request of some type. Flow and ratio are controlled.
2. Manual Pulse—a manual gun is controlled using pulse channels to modulate the secondary materials. Only ratio is controlled.

The RF2 can have up to four gun / mixers configured. Note that these can be built out of only four channels, and each channel can only be assigned to one mixer. There can only be two 2k mixers, but there can be four 1k mixers.


## Station

A station is a collection of guns/mixers—up to four, which are built from their assigned channels, and several outputs and fluid stacks. The RF2 can control up to two stations with independent color stacks to make it a two-applicator controller.

Configuration of Stations and Guns must be built out of the components available—four fluid channels and up to 128 solenoid outputs.

COMPLETE SYSTEM PART NUMBERING

RF2 - # # # - # # - # # - #



**TECHNICAL SPECIFICATIONS—MATERIAL A/B VALVE COLOR STACKS**

ITEM	DETAILS
Dimensions	Main control console: 24"x 24"x 10" Pneumatic interface panel: 24"x 12"x 9"
Weight	150-250 lb (Depending on added components)
Operating temperature	40°F to 122°F (5-50°C) inside enclosures 100°F (38°C) maximum ambient temperature
Operating humidity	5% to 85% RH (non condensing)
Environmental conditions	Indoor use, pollution degree 2, installation category II
Air input pressure	75 to 105 PSI (5.17-7.24 BAR)
Air filtration	5 micron or better, -40°F (-40°C) dew point
Ratio tolerance	< = 1% (Ratio accuracy can be affected by process factors such as hardware configuration, extremely low flow rates, etc.)
Mixing ratio range	1:1 to 50:1
Power input	85-264 VAC 0.8A @ 115 VAC, 0.4A @ 230 VAC
LCD display	15" True Glass Capacitive Multitouch display, 1366x768 pixels, HD
Flow capacity	<10 ml/min to 3500 ml/min per channel (depending on material and flow meter limitations)
Viscosity range	<1 cp to >500 cp (depending on flow meter & hardware selected)
Fluid filtration	100 mesh or better (150 micron)
I/O update time	5 ms (200 times/s), Process scan at 10 ms
Recipe tables	250 per station (2 stations available)
Wetted parts	300 & 400 series stainless steel, PTFE, perfluoroelastomer, UHMW polyethylene

## TECHNICAL SPECIFICATIONS-MATERIAL A COLOR STACK w/DISPENSE PUMP

ITEM	DETAILS
Dimensions	Main control console: 24"x 24"x 10" Pneumatic interface panel: 24"x 12"x 9"
Weight	150-250 lb (Depending on added components)
Operating temperature	40°F to 122°F (5-50°C) inside enclosures 100°F (38°C) maximum ambient temperature
Operating humidity	5% to 85% RH (non condensing)
Environmental conditions	Indoor use, pollution degree 2, installation category II
Air input pressure	75 to 105 PSI (5.17-7.24 BAR)
Air filtration	5 micron or better, -40°F (-40°C) dew point
Ratio tolerance	< = 1% (Ratio accuracy can be affected by process factors such as hardware configuration, extremely low flow rates, etc.)
Mixing ratio range	1:1 to 50:1
Power input	85-264 VAC 0.8A @ 115 VAC, 0.4A @ 230 VAC
LCD display	15" True Glass Capacitive Multitouch display, 1366x768 pixels, HD
Flow capacity	<10 ml/min to 3500 ml/min per channel (depending on material and flow meter limitations)
Viscosity range	<1 cp to >500 cp (depending on flow meter & hardware selected)
Fluid filtration	100 mesh or better (150 micron)
I/O update time	5 ms (200 times/s), Process scan at 10 ms
Recipe tables	250 per station (2 stations available)
Wetted parts	300 & 400 series stainless steel, PTFE, perfluoroelastomer, UHMW polyethylene



## PROCESS CONFIGURATION

In addition to the multiple configurations of the RF2's physical hardware, the flow control processes can vary greatly from one application to another. The RF2 software can be configured through global setup parameters, which affect system behavior independently of the material being used, and through "recipe" parameters, which can be modified per the material in use.

### Recipes

A recipe is a set of material-specific parameters used to govern system operations. Each Station (see above) can store up to 250 recipes. The parameters for each recipe are organized into three groups:

#### Materials—parameters that apply to the system as a whole

- Channel A (Resin)—CCV Number—the color valve assignment for the resin stack for the selected recipe.
- Channel B (Catalyst)—CCV Number—the color valve assignment for the catalyst stack for the selected recipe. Available only for 2 or 3 component materials.
- Channel C (Reducer)—CCV Number—the color valve assignment for the reducer stack for the selected recipe. Available only for 3 component materials.
- Pot-Life Time—the amount of time, in minutes, that a mixed material can remain in the line before it must be flushed from the system. This dictates the pot-life warning alarm. Setting this to zero disables the feature.
- Ratio (A, B, C)—the ratio for 2 or 3 component mixers. A: B (resin: catalyst) are given in parts—Channel C is given in percentage of total flow.
- Sequence Assignments:
  1. Flush A Only—programmable sequence number that is run when a "purge A only" command is given. This occurs when a new material is loaded that uses the same catalyst and reducer.
  2. Flush All—programmable sequence number that is run when a "purge all" command is given.
  3. This occurs when a new material is loaded, requiring either a change in catalyst or reducer.
  4. Load—programmable sequence number that is run when a "load" command is given. This occurs when a new material is loaded, after any necessary purges have been completed.

#### Gun/Mix—parameters apply to the gun or mixers that are used by the selected station

- Trigger-On Delay—when a trigger occurs, the applicator trigger solenoid opens this amount of time prior to the actuation of flow.
- Trigger-Off Delay—when a trigger stops, the applicator trigger solenoid will remain on for this amount of time after flow has been shut down.
- MVR Hold—for channels that use an MVR type controller, the MVR will hold at its previous value after a "trigger-off" event for this amount of time, before returning to the "minimum control pressure" value.
- Minimum/Maximum Flow—these parameters scale an optional analog (0-10V or 4/20mA) flow command between these values. These parameters are also used to scale the gauges on the main status screen showing the flow feedback.

- Default Flow—if no flow command is given by either fieldbus signal or analog input, this flow will be used.
- Sequence High Flow Rate—optional higher flow rate for when "Max Flow" system output is active.
- Flow Rate Tolerance—the percentage error in flow rate for the gun/mixer or any of its channels that is tolerable.
- Flow Rate Tolerance Time—the amount of time that the flow rate must be out of tolerance before a flow rate tolerance alarm will occur.
- Ratio Tolerance—the percentage error in mixture ratio that is tolerable.
- Ratio Tolerance Volume—the amount of volume that the ratio is measured over before producing a ratio alarm.

## Channel—parameters applied to individual fluid channels used by the selected mixer

- Flow Calibration:
  1. For quadrature flow meters—the number of pulses per liter. There are four pulses per flow- meter cycle, so if a flow meter is rated for 14000 cycles / liter, the pulses per liter = 56000.
  2. For analog flow meters—given in a simple scaling (In High, In Low, Scaled High, Scaled Low)
  3. NOTE: Flow calibration can be done by an automated process, in which a measured output of material can be inputted and compared with the counts during a calibration cycle to fine-tune the calibration for different materials. See more about flow calibration below.
- Flow Control PID parameters:
  1. Kp/Ki—the P and I components of the PID which govern flow control. While these may need to be adjusted slightly based on different materials and nominal flow rates, good numbers to start with are 2000 and 150.
  2. C-band—given in cc/min—if the flow rate error is greater than this, than the Flow control PID Kp value will be multiplied to give a faster response.
  3. I-Band—given in cc/min—if the flow rate error is greater than this, the Ki value will be multiplied to give a faster response.
  4. For C-band and I-band, a setting of 5-6 will suffice for higher flow rate channels. For lower flow rate (typically catalyst) channels, a lower setting may be used. If too low of a setting is used, it may cause oscillations in flow rate and unstable operation. A zero setting disables this feature.
- Minimum Control Pressure—this is the lowest pressure that an MVR pilot valve will operate. This should be set at slightly below the "cracking pressure" of the MVR to give a faster response. Typically with weep-less MVRs, a value of 10 psi is used. Weeping MVRs use a value closer to 20 psi.
- MVR Enable—this feature, available only when an MVR is used for the flow control of a channel, allows the channel's color valves to shut off when no trigger exists.
- Inlet Pressure Control—if inlet pressure regulation is used, this is the pressure that the channel will operate. Note: In gear-pump systems, this value represents the "delta" above or below the outlet pressure of the pump.

## Global parameters

Global parameters affect operation independently of the material(s) being used. These are organized into several groups:

### Gun/channel parameters

- **Mixed Volume**—given in cc or mL, the volume of tubing between the mix block and the applicator. This is used to track material pot-life time.
- **Blowoff Time**—for manual guns only, this time elapses as the gun trigger is detected (through installed air-flow switches utilizing the Manual Gun/Flux Box interface kit). If the set time elapses before flow is detected, a "No Master Pulses" alarm will occur.
- **Default Flow Meter Calibration**—PPL or Analog scaling values – in the event a recipe is loaded that has not been appropriately defined, these values will be used in calculation of actual flow rate.
- **Inlet/Outlet Pressure Scaling**—used to calculate inlet and outlet pressures from pressure sensors. Used only with gear-pump systems.
- **Reverse Flow Volume**—the amount of volume (cc or mL) that is allowed before a fault is generated—this is used to protect against stuck check valves that might allow material to feed backward in circulation lines.

### Alarm masking

- This allows various alarms to be used as warning only or "spray-shutdown" alarms that halt the system.

### Fluid system setup

- **Outputs**—defines the description, type, and interlocks for each output in the fluid system. See more about configuring the fluid system below.
- **Functions**—defines the description, function type, outputs acted upon. Sequences which use the function are defined here. See more about configuring the fluid system below.
- **Sequence**—defines the description, whether the sequence is used or not in the system, and global times for "chop air" and "chop solvent." See more about configuring the fluid system below.
- **Sequences**—defines timing and which functions are active per step in each fluid sequence.

### Display preferences

- **"Show Summary Page On Startup"**—when enabled, shows a configuration summary page for the system when powered up.
- **Flow Totals Units**—Liters or Gallons—units for material total display.
- **Pressure Unit**—PSI or Bar—units for pressure display.
- **Default Max-Y Values for Flow Trend Displays**—when a trend display is open, it will revert to this value for scaling the flow feedback.
- **Language:** Language shown on the display.

Note some items that are defined by user entry will not be translated, but these values are editable by the user.

## Security

The system administrator has access to settings not available to other users. This includes the ability to add, delete, or modify users, as well as the ability to assign access to various features to different user groups (levels 1-10).

Functions that can be access-controlled are:

- Edit Recipe: User can enter the recipe edit menu and make changes.
- Copy Recipe: User can copy recipe parameters from one location to others.
- Setup Menu: User can access the global setup menu (besides administrator only functions).
- Edit Fluid System: User can access fluid system configuration pages (Sequence Definition, Function Definition, Output Setup).
- Edit Fluid Sequences: User can modify sequence timing for sequences that have been defined.
- Edit Active Flow Settings: User can modify the active parameters (recipe driven) pertaining to flow.
- Edit Active Mix/Gun Settings: User can modify the active parameters (recipe driven) pertaining to a mixer or gun.
- Edit Active Inlet: User can modify the active parameters (recipe driven) pertaining to inlet pressure.
- Calibrate Flow Meter: User can calibrate the flow meter.
- Hardware Browser: User can access the "hardware browser" page, which gives access via a webpage for various internal system components.
- Local Control: Allows individual functions and solenoid valves to be controlled manually.

## INSTALLATION

Before operating the RF2, Make sure all the below installation steps are complete. Schematics and further information are provided separately from this manual.

The RF2 can accept either 120VAC or 240VAC as a power source. Its internal 24VDC power supply automatically detects the input voltage and produces control power accordingly.

Main power entry to the cabinet is located at the top right-hand side of the cabinet. A 1/2" hole is pre-drilled in the enclosure to accept a conduit or cord-grip, etc.

### **⚠ WARNING**

Before making electrical, air, and fluid connections to the RF2, be sure to understand and verify all requirements for installation, including but not limited to: electrical codes, OSHA and NFPA requirements, and all applicable local codes and ordinances.

Read and understand all operating manuals for connected equipment. Do not supply RF2 with higher fluid or air pressures than recommended in the technical specifications section of this manual.

### **⚠ WARNING**

Control enclosure cannot be placed in a hazardous location. Do not use equipment not approved for hazardous locations. Do not modify system equipment.

### **⚠ WARNING**

To maintain non-hazardous classification of this equipment, the dispense pump and fluid panel components and assemblies must be monitored for leaks and serviced regularly to prevent leaks from occurring. If a leak is discovered, the system must be immediately shut down, de-energized, and repaired to correct the problem.

### **⚠ WARNING**

The equipment is only to be used in the manner specified. If not used in the specified manner the protection provided by the equipment may be impaired.

### **⚠ WARNING**

Do not replace the detachable main supply power cord with inadequately rated cords.

### **⚠ WARNING**

This equipment is intended to be installed outside of classified hazardous areas. There are accessories for this equipment (sold separately) to allow devices such as flowmeters to be installed within the hazardous zone; this should only be done following the instructions provided with those accessories.

## Process

1. Locate the main power entry in the upper right section of the cabinet.
2. Use a plug and insert a wire sized at 16 gauge (minimum) to 10 gauge (maximum) into the slot.
3. Locate the disconnect switch connector inside of the control panel.
4. With a wire, connect the L1 and N lines to the top lugs opposite their secondary connections.
5. Connect a ground wire to the ground block inside the cabinet.



1



3



5

## NOTICE

Any conductive parts within 2.5 m of this equipment (ladders, rails, fences, etc.) must be bonded appropriately to ground.

## PNEUMATICS


For convenience, all necessary air input connections are centralized in a single manifold, so that incoming air pressure can be managed in one place.

**Always use clean, dry air to operate the RF2.**

**The maximum air input pressure is 105 PSI/7 BAR.**


### Pneumatic Connections

1. Locate the air manifold inlet connection at the top right corner of the system chassis.
2. Attach a 3/8" main air line with 1/4" NPS swivel connection to the main air inlet.



**The following steps may have been completed by the factory before shipment.**


3. On the opposite side of the air inlet, locate the manifold fittings for the interconnected air tubing.
4. Connect the manifold to each destination:
  - a. Resin and catalyst solenoid manifold.
  - b. Flow & pressure solenoid manifold.
  - c. Resin air flush valve.
  - d. Depending on your gun type, the gun's air regulator.



4a



4b




4c

4d




## Resin and Catalyst Solenoid Manifold and Valve Stacks

5. Locate the solenoid manifold on the back left side of the system. This manifold houses all the air outputs to the valve stacks for the three materials.
6. Using the desired mapping, connect the manifold outputs (e) to each resin/catalyst valve (f).



## Flow and Pressure Solenoid Manifold

7. Locate the solenoid manifold on the back right side of the system. This manifold houses all the air outputs for the fluid regulators and MVRs.
8. Using the desired mapping, connect the manifold outputs (g) to each material pressure valve (h).
9. Using the desired mapping, connect the manifold outputs (g) to each MVR (i).



## PAINT MATERIALS


Your system may include up to three valve stacks for three different channels. The process to connect each is the same; repeat the steps below as needed. The number of valves each stack will have depends on your application and needs.

### Paint Material Connections

1. Locate the valve stack you want to connect.

Either side of the system can have two different stacks with one above the other.


*One stack configuration*




*Two stack configuration*



2. Locate each of the material input connections on each valve on the stack (a).
3. Connect your material supply to the material input connection according to your desired mapping. Be careful not to mix different kinds of materials into the same stack. Each material (Resin, Catalyst and Reducer) must have his own.
4. Connect your solvent supply to the input valve below the stack (b).
5. Locate the fluid pressure regulator on the top of the stack.






c




d

6. Connect the regulator (c) to the MVR (d) in the fluid panel.
7. Depending on your configuration, connect the flow meter (e) below the MVR to the calibration block (f). If not using a calibration block, skip this step and connect the flow meter to the mixing block (g) directly.
8. If you are using a calibration block, connect it to the mix block (g).
9. Plug your gun's material input to the mixing tube's output connection (h).



e

f



g

h



## INSTALLATION OF AIR CUT OFF KIT

The air cut off (ACO) kit is installed when the RF2 system is to be used in manual mode. The ACO kit can be used in conjunction with a gun flush box or on its own. The functions of the ACO kit are (1) to control air flow to prevent solvent atomization when using the flush box and (2) to sense air flow through the gun and send a trigger signal to the controller to enable material flow.

The air cut off kit is capable of controlling the air flow for two guns. The first set of connections, labeled with a 1 on the ACO box, is for gun one. The second set, labeled 2, is for gun two. Installing the second set of connections is unnecessary if only using one gun.

The box consists of three main components:

1. Air cut off valves: disable air flow to the guns when flushing them.
2. Flow switches: used to sense when the operator has opened the spray applicator. The trigger signal is fed to the system controller to enable material flow.
3. Gun-in-box (GIB) pressure switches: used in conjunction with the flush box. They send a signal to the controller when the flush box is closed and the gun is ready for flushing.

### Possible Configurations for Air Cut Off Kit

- 310-3905-S0 (for one gun at standard air flowrate)
- 310-3905-L0 (for one gun at low-volume air flowrate)
- 310-3905-LL (for two guns at low-volume air flowrate)
- 310-3905-SS (for two gun at standard air flowrate)
- 310-3905-SL (for two gun, one at standard and one at low-volume air flowrate)

### Parts Included

1. Air cut off box
2. Air cut off valves and associated fittings
3. 10 ft of 5/32" pneumatic tubing per gun
4. 10 m of M12 cable

## ACO Connections

- a. GIB1 (Gun-in-box pressure switch for gun one, 5/32" or 4 mm tube)
- b. GIB2 (Gun-in-box pressure switch for gun two, 5/32" or 4 mm tube)
- c. M12 cable to controller
- d. ACO valve signal gun 1 (5/32" or 4 mm tube)
- e. ACO valve signal gun 2 (5/32" or 4 mm tube)
- f. Atomization air connection to gun 1 (1/4" NPS male)
- g. Atomization air connection to gun 2 (1/4" NPS male)
- h. Air supply input for gun 1 (1/4" NPS male)
- i. Air supply input for gun 2 (1/4" NPS male)

See the next page for terminal connections.

If used with a gun flush box:

7. Route 5/32" tubing from GIB 1 and 2 (a and b) to each respective gun flush box for each gun.




**⚠ WARNING**



Installation should be performed by a qualified electrician. Improper installation could create a spark, resulting in fire or explosion.

## ACO Kit Installation

1. Mount the ACO box near the RF2 controller in a non-hazardous location.
2. Next, mount the solenoid valves to the air cut off box, as shown.
3. Route 5/32" pneumatic tubing from the air cut off valve (d and e) to port 10 (trigger g1) and port 11 (trigger g2) on the RF2 solenoid outputs.
4. Connect the air supply inlet to the air supply inputs for gun one and/or gun two (h and i).
5. Connect the atomized air to the atomization air connection for gun 1 and/or gun 2 (f and g). The air supplied to the air supply input for gun one (h) will be output in the atomization air connection to gun one (f).
6. Route the M12 cable from the M12 cable connection (c) and into the RF2 enclosure either (1) through an available strain relief or (2) by replacing the hole plug with the strain relief included with the RF2 controller.




Once the M12 cable from the air cut off box is in the enclosure, connect it to the terminals indicated below.




Verify the M12 cable from air cut off box to RF2 connections in the table below.

ITEM	WIRE COLOR	SIGNAL	PLC and TERMINAL BLOCK-LANDING LOCATION
a	BROWN	24VDC	TERMINAL BLOCK 1141
b	BLUE	GUN-IN-BOX, GUN 1	SLOT 1, PIN 4
c	WHITE	GUN-IN-BOX, GUN 2	SLOT 1, PIN 8
d	GRAY	FLOW SWITCH, GUN 1	SLOT 2, PIN 5
e	BLACK	FLOW SWITCH, GUN 2	SLOT 2, PIN 6

# Air Cut Off Box Connections Diagram







## MANUAL VALVE PULSE SETUP

### CCV Pulse Flow Adjustment-Below Range


The correct pulse flow range is in the green zone as shown between the green arrows.

In the image shown at the right, the blue diamond shape is left of the green zone and below range.

The flow must be increased to a specified 50%. Follow the steps below to adjust the valve flow.




1. Use a 13 mm wrench and turn it counterclockwise to loosen the jam nut on the adjustment screw.
2. Turn the adjustment screw clockwise until the blue diamond moves to the center of the green zone range.
3. Turn the wrench clockwise to set the adjustment screw in position.




## CCV Pulse Flow Adjustment-Above Range

The correct pulse flow range is in the green zone as shown between the green arrows.

In the image shown at the right, the blue diamond shape is right of the green zone and above range. The flow must be decreased to a specified 50%. Follow the steps below to adjust the valve flow.



1. Use a 13 mm wrench and turn it counterclockwise to loosen the jam nut on the adjustment screw.
2. Turn the adjustment screw counterclockwise until the blue diamond moves to the center of the green zone range.
3. Turn the wrench clockwise to set the adjustment screw in position.




## CCV Pulse Flow Adjustment-In Range

The correct pulse flow range is in the green zone as shown between the green arrows.

In the image shown at the right, the blue diamond shape is in the center of the green zone and is in range. This is the optimal position, and no more adjustment is necessary.

To enable pulse valve flow control, go to page 2 of 4 in the System Configuration menu (discussed on manual page 109). Select "Pulse" for Channel 2.



## EXTERNAL AIR CONNECTIONS

The RF2 can (and in some cases must) control air signals that are external to the RF2; these include gun trigger and dump signals. Every solenoid controlled by the RF2 is programmable, so the individual port location for any signal depends on the programmed location for that signal.

The RF2 will be pre-programmed from the factory with a standard list of signals for the purchased configuration. A list will be provided showing the air connections as programmed. It is also possible to view and modify this list as desired.

To view the list of connections:


1. Navigate to the Setup Menu -> Output Configuration (see "Running the System" section for more information).
2. Select the manifold (on the top of the output config menu) to view. Note the RF2 can control up to four solenoid manifolds, but in many cases the system will only be configured for one. Only manifolds that are present will be shown.
3. The list of outputs is shown as Port 4 and Port 2, with 16 rows represent the possible 16 modules (each having two solenoids) in the selected manifold. The orientation is the same as the view of the air connections at the base of the solenoid manifold.

All air signals that control elements that are provided with the RF2 will be pre-programmed, and their air tubing will be pre-installed if possible. But their solenoid locations may also be viewed or modified using the same procedure as above.

If a solenoid fails due to wear, or other damage, etc., a quick "output swap" process is provided so that any two outputs configurations and functionality can be swapped. This function is located in the Output Configuration section of the System Setup Menu.

Normally, the system will be provided with some unused solenoids that can be used for this purpose. Refer to the Setup section of this manual for more details.

More information about output configuration is given in "System Configuration" and "Running the System" sections.



<p><b>CCV Output Definition Key</b></p> <p>k = Component</p> <p># = Channel/Component #</p> <p>ss = Stack Solvent</p> <p>sa = Stack Air</p> <p>c = Color</p> <p>pv = Pulse Valve</p> <p>cal = Calibration</p> <p>mbs = Mix Block Solvent</p>	<p>For example:</p> <p>k1cal = Component 1 Calibration</p> <p>k1c3 = Component 1 Color 3</p> <p>k2c3 = Component 2 Color 3</p> <p>k1pv = Component 1 Pulse Valve</p>
--	--

## AUXILIARY SIGNALS

The RF2 is designed to be placed inside a larger process to take commands from paint / assembly lines, robotic cells, etc. Commands and Status information can be communicated to and from the unit via discrete wiring or by fieldbus. Both methods can be used simultaneously if desired. While it is possible to fully run the RF2 system with hardwired signals, much more functionality is available through fieldbus communications.

### Hardwired I/O (Discreet Wiring)

If it is desired to use hardwired signals to give basic commands and receive basic status information, the following digital signals are available.

The table on the preceding pages references I/O slot and pin numbers. These correspond to the physical location of the connection. Slots being cards, numbered low to high from the left, and pin numbers being the connection from low to high from the top of a given slot.

PIN NUMBER	SLOT 1 (DIGITAL INPUTS)
1	Station #1 Sequence Interlock-24V = Interlock OK
2	Station #1 Spray Interlock-24V = Interlock OK
3	Station #1 Recipe Strobe-24V Pulse loads selected Recipe
4	Auto gun = Station #1 Applicator ready; Manual Gun = Station #1 Flush box
5	Station #2 Sequence Interlock-24V = Interlock OK
6	Station #2 Spray Interlock-24V = Interlock OK
7	Station #2 Recipe Strobe-24V Pulse loads selected Recipe
8	Auto gun = Station #2 Applicator ready; Manual Gun = Station #2 Flush box

PIN NUMBER	SLOT 2 (DIGITAL INPUTS)
1	User Input #1 (For Pass-Through)
2	User Input #2 (For Pass-Through)
3	User Input #3 (For Pass-Through)
4	User Input #4 (For Pass-Through)
5	Auto Gun = Mix #1 Trigger Cmd, Manual Gun = Mix #1 Manual Trig Flow Switch
6	Auto Gun = Mix #2 Trigger Cmd, Manual Gun = Mix #2 Manual Trig Flow Switch
7	Auto Gun = Mix #3 Trigger Cmd, Manual Gun = Mix #3 Manual Trig Flow Switch
8	Auto Gun = Mix #3 Trigger Cmd, Manual Gun = Mix #4 Manual Trig Flow Switch
9	Job Data Binary 1
10	Job Data Binary 2
11	Job Data Binary 4
12	Job Data Binary 8
13	Job Data Binary 16
14	Job Data Binary 32
15	Job Data Binary 64
16	Job Data Binary 128

PIN NUMBER	SLOT 3 (DIGITAL INPUTS)
3	System Fault Reset Pulse
4	Station 1 Run Pulse
5	Station 1 Halt Pulse
6	Station 2 Run Pulse
7	Station 2 Halt Pulse
8	Reserved
9	Reserved
10	Reserved
11	Reserved
12	User Input #5 (For Pass-Through)
13	User Input #6 (For Pass-Through)
14	User Input #7 (For Pass-Through)
15	User Input #8 (For Pass-Through)
16	User Input #9 (For Pass-Through)

PIN NUMBER	SLOT 4 (DIGITAL OUTPUTS)
1	Station #1 HV Enable
2	Station #2 HV Enable
6	Station #1 Run Mode
7	Station #2 Run Mode
13	Gun/Mix #1 Pot Life Expired
14	Gun/Mix #2 Pot Life Expired
15	Gun/Mix #3 Pot Life Expired
16	Gun/Mix #4 Pot Life Expired

PIN NUMBER	SLOT 5 (ANALOG INPUTS)
1+, 2-	Programmable Analog Input #1
3+, 4-	Programmable Analog Input #2
5+, 6-	Programmable Analog Input #3
7+, 8-	Programmable Analog Input #4
9+, 10-	Programmable Analog Input #5
11+, 12-	Programmable Analog Input #6
13+, 14-	Programmable Analog Input #7
15+, 16-	Programmable Analog Input #8


PIN NUMBER	SLOT 6 (HIGH-SPEED COUNTER)
1-5	Channel #1 Flow Meter
6-10	Channel #2 Flow Meter

PIN NUMBER	SLOT 7 (HIGH-SPEED COUNTER)
1-5	Channel #3 Flow Meter
6-10	Channel #4 Flow Meter



## Analog hardwired inputs

Additionally, the RF2 has eight analog inputs, which can be configured for various system functions, including flow command for a gun or mixer.



The analog input module used by the RF2 will be pre-configured for eight 2-wire 4/20mA signals, but each channel can also be configured as a 0-10V, 1-5V, etc. input type. Changing the configuration of the input itself requires the user to access the onboard webpage for the Turck I/O module. Only qualified personnel should perform this procedure.

Assignment of an analog input to a given function is done through the following procedure:

1. Log in as an administrator.
2. Navigate to Setup -> System Configuration.
3. Press "Next" until reaching the fourth page, which contains the assignments for analog inputs.
4. Assign each analog input as desired. See screenshot to the right.
5. Press "Finish" to store the configuration—the system will reboot.



Analog Types available are:

- Inlet Pressure (Channel 1 to Channel 4)—used by gear-pump (future addition) channels to read inlet pressure.
- Outlet Pressure (Channel 1 to Channel 4)—used by gear-pump (future addition) channels to read outlet pressure.
- Flow Command (Gun/Mix 1 to 4)—used as the overall flow command for the indicated gun or mixer.
- Flow Feedback (Channel 1 to 4)—analog flow feedback sensor if used instead of a pulsing sensor (future addition).
- Solvent Flow Meter (Station 1 or 2)—used as a solvent flow meter for verification of a flush, etc.

Wiring for the analog signals is done on slot 5, pins (1+, 2- for input 1, 3+, 4- for input 2...). See schematics for more details.

To modify the type of analog input:

1. Connect a laptop to the open RJ45 port on the Turck I/O Block.
2. Set the laptop IP address to 101.1.1.99
3. Open a web browser, such as Google Chrome, and type 101.1.1.25 in the URL.
4. Log in with the password = "password."
5. Select the analog input module: Slot 5 – BL20-E-8AI-U/I-4PT/NI

The screenshot shows the 'Gateway Information' page. The left sidebar has a menu with the following items: Gateway Information (selected), Gateway Diagnostics, Event Log, Ethernet Statistics, EtherNet/IP™ Memory Map, Modbus TCP Memory Map, Links, Gateway Configuration, Network Configuration, and Change Admin Password. Below these are slot-specific menus for SLOTS 1 through 6. A red arrow points to 'SLOT 5 - BL20-E-8AI-U/I-4PT/NI'. The main content area shows 'Gateway Information' with fields for Type (BL20-E-GW-EN), Identification Number (6827329), Firmware Revision (V3.3.18.0), Bootloader Revision (V7.2.0.0), EtherNet/IP™ Revision (V2.7.39.0), PROFINET Revision (V1.7.14.0), Modbus TCP Revision (V2.4.2.0), Build Number (458), and Addressing Mode (PGM). Below that is 'Network Settings' with fields for Ethernet Port 1 setup (Autonegotiate), Ethernet Port 2 setup (Autonegotiate), IP Address (101.1.1.25), and Netmask (255.255.255.0).


6. Modify the channels as necessary. Consult Turck BL20 IO manual for more details.

The screenshot shows the 'Slot 5 - BL20-E-8AI-U/I-4PT/NI - Parameters' page. The left sidebar has the same menu as the previous screenshot, with 'SLOT 5 - BL20-E-8AI-U/I-4PT/NI' selected. The main content area displays parameters for six analog input channels. A red callout box with an arrow points to the 'Data format' dropdown for Analog In 1, containing the text 'Modify analog signal type, etc.' The parameters are as follows:

Channel	Operation mode	Data format	Deactivate diagnostics
Analog In 1	voltage 0...10 V standard	15 bit + sign	no
Analog In 2	voltage 0...10 V standard	15 bit + sign	no
Analog In 3	voltage 0...10 V standard	15 bit + sign	no
Analog In 4	voltage 0...10 V standard	15 bit + sign	no
Analog In 5	voltage 0...10 V standard	15 bit + sign	no
Analog In 6	voltage 0...10 V standard		



7. Press the "Submit" button.

Analog In 8 - Data format	15 bit + sign
Analog In 8 - Deactivate diagnostics	no
	
<input type="button" value="Submit"/> <input type="button" value="Reset"/> <input type="button" value="Refresh"/>	

## NOTICE

For analog current inputs, both 2-wire and 4-wire styles are possible, but note that if using 4-wire channels, it eliminates another input channel, reducing the number of inputs available. It is recommended to use only two wire current inputs or voltage inputs with the RF2.

## Fieldbus Communications: Ethernet

The RF2 can communicate via fieldbus through its RJ-45 ethernet connector.

The RF2 uses Ethernet/IP communications protocol in its most basic configuration. The plant or supervisory PLC can utilize CIP Data Transfer Read or Write commands via a Message instruction (MSG - Rockwell) or equivalent to get status information or give commands.

If desired, the RF2 can be configured to use a gateway module that establishes an implicit communications path between the RF2 and some other industrial protocol, such as ProfiNet, Modbus TCP, CC-Link, etc.

Sample codes are available from Carlisle Fluid Technologies. They can be imported into the supervisory PLC to facilitate communications more quickly with the RF2 and provide data structures for the communicated information.

Signal lists and more detailed information to establish communications with the RF2 are given at the end of this manual.

## Fieldbus Communications: IP Address Setting (without gateway)

Series 1 RF2 control units use an Allen Bradley–Compact Logix PLC with two separate ethernet networks as the primary controller. Network A1 is used for local communications to RF2 devices such as I/O and solenoid manifolds. Network A2 is used for communications to a plant.

To prepare the RF2 control:

1. Plug an RJ-45 ethernet cable into an open port on a local ethernet switch (ESW128).
2. Set the Allen Bradley PLC to "PROG" mode.

To set the IP address, download RSLinx Classic software from Rockwell Automation (found online). There is a free version (Lite) available.

### **RSLinx Classic version 4.30 or higher must be used.**

Use the following procedure for setting the IP address for Network A2 on Series 1 RF2 units:

1. Set the IP address of the user's laptop or PC to 101.1.1.99, subnet Mask 255.255.255.0
2. Open RSLinx software.
3. Select Communications - > "RSWho."
4. Select the ethernet IP driver and scan the network (Most likely this will be named AB\_ETHIP1). Refer to the configuration note\* if the protocol is not present.
5. Find the RF2 controller at IP address 101.1.1.20—right click and select module configuration.
6. Select "Port Configuration Tab."
7. Select Network A2.  
**WARNING: Do not modify anything in Network A1. The system can be rendered inoperable.**
8. Set the IP address as desired to communicate to the Plant controller and click "OK."

With these steps completed, set the PLC/IP address back to Run or remote mode.

**Configuration note:** If RSLinx is not configured to have an ethernet IP driver, do the following:

- a. Select Communications -> "Configure Driver."
- b. In the "Available Driver Types" pulldown, select Ethernet/IP Driver, click "Add New."
- c. Click "OK"—the new driver will be added.

## Fieldbus Communications: IP Address Setting (with gateway)

When the AnyBus communications gateway is installed in the system, the RF2 will already be configured to communicate with it. The gateway itself must be configured on the plant side to talk to the plant.

To configure the plant side of the gateway, download and install HMS IPconfig Software from: [www.AnyBus.com/support](http://www.AnyBus.com/support)

Connect the PC with HMS IPconfig software loaded to the plant side network ports of the gateway device. Set the IP address of the laptop to the network that you wish to place the gateway on. Start HMS IPconfig software.

When HMS IPconfig is started it will automatically scan for compatible and active HMS devices. To change the IP configuration for a device, click on the device in the list.

Pressing "refresh" in the IPconfig software will cause the software to rescan the network. When selecting a device, pressing the "wink" button will cause the device LEDs to flash, verifying that the correct device has been chosen.

IP and DNS settings can be configured manually or dynamically using DHCP by modifying them in the right hand section of the page and pressing apply.

See the User Manual for HMS IPconfig software for more detailed information.

Select the ethernet IP driver and scan the network (most likely this will be named AB\_ETHIP1).

1. Refer to the configuration note\* if the protocol is not present.
2. Find the RF2 controller at IP address 101.1.1.20—right click and select module configuration.
3. Select "Port Configuration Tab."
4. Select Network A2.  
**WARNING: Do not modify anything in Network A1. The system can be rendered inoperable.**
5. Set the IP address as desired to communicate to the Plant controller and click "OK."

With these steps completed, set the PLC/IP address back to Run or remote mode.

**Configuration note:** If RSLinx is not configured to have an ethernet IP driver, do the following:

- a. Select Communications -> "Configure Driver."
- b. In the "Available Driver Types" pulldown, select Ethernet/IP Driver, click "Add New."
- c. Click "OK"—the new driver will be added.




## Configure High-Speed Counter I/O (non-quadrature flow meters)

In some installations, the standard flow meter may not be used. Some pulsing flow meters do not have quadrature output. If this is the case, the channel must be modified in order to accept a single pulse input. To do this:

1. Connect a laptop PC to the open RJ45 connector on the Turck I/O block. Set the laptop IP address to 101.1.1.99
2. Using a web browser, enter 101.1.1.25 into the URL.
3. In the Login field, enter "password."
4. Click "Parameters" for the slot you wish to modify. Channels 1 and 2 are connected to slot 6, channels 3 and 4 are connected to slot 7.
5. Find Counter 1 or Counter 2–Mode CNT.

Counter 1 will be for the first channel connected to the slot, Counter 2 is for the second—for example Slot 7, Counter 1 is for channel 3.

6. The default setting for this field is "AB Mode—4 samples", for a single pulse—change this to "pulse-direction, single sample."
7. Click "Submit." The counter is now configured.



**NOTICE**


In this mode, for the count direction to be positive, the D2 pin for the channel (pin 2 or 7) must be connected to 24VDC. If the flow meter has directional output, this can be used for direction; otherwise, connect a 24V jumper to the direction pin.

## DISPOSAL INFORMATION


Prior to disposal of this equipment at the end of its life cycle, all components containing electronic printed circuit boards (PCBs), sensors, and any wetted parts that may contain hazardous materials should be separated from the unit and recycled/disposed of according to local regulations.

## RF2 CLOUD SETUP


1. Login to "admin" user.
2. Select Menu > Setup > Exor Internal Menu.



3. Select > Show system settings.



4. Select "Network."




5. Select "Edit."



6. Enter Network and network password. Click "Save."



7. Click "Menu" at the top left. Select "Services."



8. Enable these three (3) services:
  - a. VNC Service
  - b. Router/NAT/Port Forwarding
  - c. Cloud/VPN Service



9. In "Cloud/VPN" verify the following settings:
  - Server: us.corvinacloud.com
  - Username: RF2-machineserialnumber/  
organization
  - Example: RF2-1234/CFTLiquid
  - Password: paint123\$





**Page is intentionally left blank.**

# OPERATION

## POWERING UP THE SYSTEM

Before system start-up, make sure the main power has been correctly installed. See the section on electric installation for more details.

To start-up:


1. On the right hand side of the control module enclosure, turn the rotary disconnect switch clockwise.  
The system will go through a boot-up sequence. When ready, a button will show on the screen to access the "Main Menu."
2. On the start-up menu, along the bottom, change the language of the display by pressing the "flag" icons for the appropriate country/language.
3. On the bottom-right-hand side of the start-up menu, press the "config summary" button to access the configuration summary page—which briefly describes how the system hardware has been configured.
4. Pressing the Main Menu button will:
  - a. Open the main "Run" menu if the system has been configured and the user-preference to "show configuration summary on startup" is not set.
  - b. Open the "Configuration Summary Menu" if the system has been configured and the user-preference to "show configuration summary on startup" is set.
  - c. Open the "System Configuration Menu" if the system is not configured.

### NOTICE

If the system is not configured, refer to the configuration section of this manual to proceed.

## NAVIGATION BAR

Except on certain menus that have special purposes, the navigation bar shown below will be visible in the upper section of the screen. Each section will be discussed separately in this manual.



Press the "Menu" button to open a drop-down menu to access other menus.


Press "User" to open a dialog menu to log-in, log-out, and access other functionality available to the administrator.

Press "Alarm" to open the alarm status/history menu.

Press "Log" to open the main data-logging menu.

## Drop-Down Menu

Available options on the drop-down menu are shown below. Access to specific functions is limited by the administrator for designated users.



## LANGUAGE SETTINGS

System Languages can be chosen by selecting the "Language" icon (a) at the bottom of the menu drop down, and selecting the user's language from the list (b) to the right.

### NOTICE

Some objects are not part of this run-time project. These include, for example, user-editable fields: station, gun, channel, and output names, as well as some menus like Exor's internal HMI menus. These cannot be translated in run-time and will remain the same regardless of the selected user's language.




## RUNNING THE SYSTEM

### Loading Recipes

For each station, up to 250 user recipes may be stored. It is recommended that each material being used will have a dedicated recipe. Recipes may be loaded from the operator interface of the RF2, or through commands from a supervisory control process.

To load a recipe from the operator interface, perform the following steps in order:

1. Navigate to the "Run" menu using the drop-down menu.
2. Make sure all faults are reset.
3. The "Run" menu will show a brief list of active alarms if any exist. If not, press the "Reset" button to clear any alarms, or try further troubleshooting as necessary.
4. If the RF2 has been configured for two stations, select the applicable station.
5. Press the "Start" button to place the station in run-state. The text will change to show "Running."
6. Select the appropriate recipes from the dialog.
7. Press the "Load" button to start the load sequence.



When the load sequence starts, the station will determine if a flush is needed before it runs the load sequence. Then it runs the appropriate sequences to load material. When this happens, the bottom of the Run menu will show the load sequence. All Start/Stop/Reset and recipe-select functionality will be unavailable during this time.

When the load sequence is complete, the material is loaded, and the station is in run-state, the system will respond to trigger and flow commands for any configured Guns/Mixers for the station and control.

## Editing Recipes

Select "Recipe" from the drop-down menu to view or change recipe parameters.

The "Materials" section of the recipe menus will open. At the top of this other recipe menus, "Mix/Guns" will be available if configured in the selected station or greyed out if they are not configured.

Access to channel-recipe data is located at the bottom of the "Mix/Gun" recipe menus. It will be available based on the number of channels configured for the selected Gun/Mixer. Channel A, B, or C will navigate to the settings page for the physical channels 1-4, but depends on which channel is configured for each Gun/Mix channel.

To select a recipe to change, press the field that shows the "Recipe to Edit" (a). It will open a pop-up dialog to show selections from the list of recipes. Use the arrow buttons to scroll through the list. There are 250 recipes available per station.

To change the selected recipe's description, press the "Write" (b) icon next to the current recipe description to open the dialog.

Screens will show differently when the materials, guns/mixers, or channels within a recipe are changed.

### Material Editing Screen:

The screenshot shows the "Recipe Configuration - Materials" interface. At the top, it displays "Station #1" and the date "Mar 19 2021 07:03 AM". Below this, there are navigation icons for MENU, USER, ALARM, and LOG. The main content area is titled "Recipe To Edit: 1 - job1" and includes a "Write" icon (labeled 'b') and "Copy and Backup" buttons. Below the title, there are buttons for "Materials" (labeled 'a') and "Gun #1", "Gun #2", "Gun #3", and "Gun #4" (labeled "Select gun options"). The "Recipe - Material Parameters" section includes fields for "Channel A (Resin) - CCV Number: 1", "Channel B (Catalyst) - CCV Number: 1", and "Channel C (Reducer) - CCV Number:". Below this is a "Pot Life Time" field set to "0.00 min." and a "Ratio" section showing "Channel A Ratio: 4.0 parts", "Channel B Ratio: 1.0 parts", and "Channel C Ratio: %". The "Sequence Assignments" section includes "Flush A Only: purge A", "Flush All Channels: purge all", and "Load: load". A "Previous" button is at the bottom left.

### Gun/Mixer Editing Screen

The screenshot shows the 'Recipe Configuration' screen for 'color 1'. The interface includes a top navigation bar with 'MENU', 'USER', 'ALARM', and 'LOG' icons. The main content area is titled 'Recipe - Mix Parameters' and contains several parameter settings. Callouts point to various elements: 'a' points to the 'Recipe To Edit' field; 'Select material' points to the 'Materials' button; 'Select gun options' points to the 'Gun #1' through 'Gun #4' buttons; 'Recipe parameters' points to the parameter list; and 'Select channel' points to the 'Channel A Config', 'Channel B Config', and 'Channel C Config' buttons. A red box on the right highlights 'Copy and Backup buttons' and another highlights 'Select gun options'.

**Recipe To Edit:**  
1 - color 1

**Materials:** Materials, Gun #1, Gun #2, Gun #3, Gun #4

**Recipe - Mix Parameters**

Trigger On-Delay	0 mSec
Trigger Off-Delay	0 mSec
MVR Hold:	0 mSec
Minimum Flow	0 cc / min
Maximum Flow	1000 cc / min
<i>Minimum Flow used only when controlling via analog input.</i>	
Default Flow	200 cc / min
<i>Default Flow used when no command is present.</i>	
Sequence High Flow Rate	500 cc / min
<i>Used in sequences when a dump valve is active.</i>	
Flow Rate Tolerance	+/- 10 %
Flow Rate Tolerance Time	10 sec.
Ratio Tolerance	+/- 10 %
Ratio Tolerance Volume	100 cc

**Channel Configs:** Channel A Config, Channel B Config, Channel C Config

**Navigation:** Previous, Run

**Callouts:**  
a: Recipe To Edit  
Select material: Materials  
Select gun options: Gun #1, Gun #2, Gun #3, Gun #4  
Recipe parameters: Trigger On-Delay, Trigger Off-Delay, MVR Hold, Minimum Flow, Maximum Flow, Default Flow, Sequence High Flow Rate, Flow Rate Tolerance, Flow Rate Tolerance Time, Ratio Tolerance, Ratio Tolerance Volume  
Select channel: Channel A Config, Channel B Config, Channel C Config  
Copy and Backup buttons (discussed later): Copy, Backup

Channel Editing Screen

The screenshot shows the 'Recipe Configuration - Channel' screen. At the top, it displays 'Dec 04 2021 08:55 AM' and the 'CARLISLE' logo. The main content area is titled 'Recipe To Edit: 1 - red'. Below this, it shows 'Gun #1 Hardware Channel' and 'Channel A 1'. The 'Flow Control' section contains a table of parameters:

Flow Calibration	54000 pulses/L
Flow Control PID - Kp	8000
Flow Control PID - Ki	600
Minimum Control Pressure	10 psi
Flow Control PID - C band	0.0
Flow Control PID - I band	0.0

Below the table is the 'MVR Enable' checkbox, which is currently unchecked. A note below it reads: 'When enabled, color valve associated with this channel will turn off when not triggered, unless a different channel connected to the same stack is triggered.' The 'Inlet Pressure' section contains another table:

Inlet Pressure Control	40 psi
Minimum Inlet Pressure	0 psi
Maximum Inlet Pressure	100 psi

At the bottom, there is a 'Previous' button. Callouts from red boxes point to various elements: 'a' points to the 'Recipe To Edit' title; 'Select Material Options' points to the 'Gun #1 Hardware Channel' text; 'Recipe parameters' points to the 'Flow Control' table; 'Return to previous menu' points to the 'Previous' button; and 'Copy and Backup buttons (discussed later)' points to the copy and backup icons in the top right corner.

**NOTICE**

Access to the calibration settings for the flow meter opens the calibration dialog and lets the calibration process occur.

## Copying Recipes

Press the "Copy" icon near the top of the recipe edit menu to open the copy dialog. From this menu, choose the "Source" recipe and the destination locations (1-250) that represent the available 250 recipe data registers in the selected channel. Multiple destinations can be chosen at the same time but can cause longer process times.


When the source and destination fields are set, press the "Copy" button to make a copy of all data from the source recipe to each destination location in the range. Make sure to add a "#" to each description.

## Operate the System (manually or locally)

Though the RF2 will most commonly be put into a process that receives automatic commands, such as trigger, flow rates, and load recipes/materials, it can also be operated from the local interface.

To operate the RF2 from the main panel after the material has been loaded:

1. Navigate to the Run Menu.
2. Select the station you wish to control if the RF2 is configured as a multi-station controller.
3. Press the "Gun/Mix" panel for the unit you wish to control. A pop-up dialog box will show the details of the selected gun or mixer.





- If the logged-in user has permission, the active setpoints from the selected recipe will be editable. If not then the settings will be in view-only mode.

**Gun / Mix Details**  
Gun #1  
Station #1

**Flow (cc/min)**

500.0  
400.0  
300.0  
200.0  
100.0  
0.0

05:52:45 05:57:45

**Active Job Settings**  
*Overridden on job load or refresh.*

Default Flow:	Override	250	(Actual) 250.00
Min. Flow:		0	
Max Flow:		1000	
Flow Tolerance (%):		5	
Flow Tol. Time (sec.)		3	
Pot Life Time (min.):		10.00	9:43
Trigger-On Delay (ms):		0	
Trigger-Off Delay (ms):		0	
Ratio A:		4.0	4.04
Ratio B:		1.0	1.00
Ratio Tolerance (%):		10	
Ratio Tol. Volume:		125	

Flow Test 5.000

**Volume Check**

A: 396.9  
B: 99.7  
C: N/A  
Total: 496.6

Clear  
Ratio Check

Trigger 1

Close

Note: One of these positions is the default flow rate for the recipe. If operated from the interface, it is recommended to press the override button to let this position take precedence over auxiliary positions. Those auxiliary positions can come to the RF2 from a discrete analog signal or via a fieldbus command.

The active flow rate command is shown to the right of the default flow setpoint.

- On the right side of the panels are "Trigger" buttons that start the applicators assigned to the gun/mixer. Press the trigger button to toggle the trigger between active and inactive. If multiple triggers are on during the same time, the flow rate for the gun/mixer will be the command multiplied by the number of triggers currently on.
- When the "Flow Test" button is pressed, it can start and set "Trigger 1" for a given period.
- The status information for the gun/mixer is shown throughout the display.

## NOTICE

Only assigned triggers to the gun/mixer will be visible on this menu.  
In most cases only one will be configured.

The volume check shows the run totals for all materials in cc or mL. Press the "Clear" button to reset the totals when not triggered.


The "Ratio Check" button will cause the material to be moved from the gun trigger to the calibration test ports for all configured materials. It lets the user position beakers under the ports to catch the material, do a quick flow check on all materials, and compare them to the calculated volumes.

## Channel Menu

From the Run Menu, press any of the "Channel" panels shown to open a pop-up dialog with status and active settings for that channel.

If the user has permission, they can change the active recipe parameters. Without permission, the values will be view-only.

Status information is shown throughout the display.



## Alarms Menu

On the main navigation bar, the alarm icon (a) will change color and show an alarm count if an alarm exists.

Press the icon to open the following menu.


On the Alarm menu, the top list shows active alarms, and the bottom list shows historical alarms.

For more alarm details:


1. The right side of any row in the active alarms list that contains an alarm is a button under the "Action" column (b).
2. Press this button to open a pop-up dialog that explains the condition and gives some actions.
3. Active Alarms: If an alarm is active, it will be listed in the top list on the Alarm Menu.
4. Historical Alarms: In the historical alarms list, the duration of the list can be selected through the drop-down combo box. Press the "Backward" and "Forward" buttons to scroll up and down through the list.

To reset an active alarm:

1. Press "Reset Alarms" (c) above and to the left of the active alarms list, or press "Reset" on the Run Menu. If the alarm condition has been cleared, the alarm will clear from the list and be shown only in the historical alarm list.




- In the alarm detail pop-up menu, press "Close" (d) to exit the menu, "Condition" (e) to see the list of conditions that may cause the indicated alarm, and "Action" (f) to see a list of potential corrective actions.



### Audit Log

On the top-right of the Alarm menu, the "Audit Log" button will open a menu and show the events that have been captured by the system.

The audit log menu can be filtered (g) by user, and duration.



## CALIBRATION

### Flow Meter Calibration

Calibration of the flow meter is recommended for each individual material that is run. This is because materials of different viscosities may cause the gears within a flow meter to turn more or less than others.

Further, at low flow rates (less than 100 cc/min) flow meter operation can depend on the flow rate. Therefore, it is also recommended to calibrate material at close to the nominal flow rate for the process.

Calibration data is stored in recipe data. The calibration menu may be accessed from the recipe-edit menu or from the channel detail pop-up menu, accessed from the Run menu.

To calibrate a square wave flow meter:

1. Load a recipe/material into the system.
2. Access the calibration menu, by going through the channel detail pop-up, or through the recipe edit screen.

### NOTICE

A different calibration dialog may open based on the flow meter type (square wave, or 4-20mA).

3. Place a cup under the calibration port for the channel being calibrated.
4. Set a flow pilot command (a)—this will be the command given to the flow-control device during the calibration process. 100-200 cc/min is the recommended start number.
5. Set a delay time (b) (if desired) and a trigger time (c).
6. Press Start. The delay time will occur (in case this time is needed to position the beaker under the calibration port), then the calibration port will open for the set amount of time. The volume of material will be calculated (based on current calibration settings).
7. When complete, enter the measured amount of material into the "Actual Volume" field (d). A suggested calibration will be calculated based on the amount of flow-meter pulses that were counted, and the actual volume entered.
8. Press "Accept" (e) to accept the suggested calibration as the Calibration Value.

The screenshot shows the 'Calibration' dialog box with the following fields and controls:

- Channel:** 1
- Gun #1 - Component A**
- Recipe:** color 1
- Position cup to catch material** (instruction)
- Current Count:** 31595
- Test Count:** 0 (with a 'Clear' button)
- Calibration Value:** 52829 PPL
- Flow Command:** 400 cc/min (labeled 'a')
- Delay (sec):** 1 (labeled 'b')
- Start** (button)
- Time (sec):** 15 (labeled 'c')
- Calculated Volume:** 0.00 cc
- Actual Volume:** 110.00 cc (labeled 'd')
- Suggested Calibration:** (with an 'Accept' button labeled 'e')
- Close** (button)

Alternatively, the calibration value can be directly entered from this menu if desired.

Changes made to the calibration are stored to the recipe parameters for the recipe loaded.


## MANUAL OVERRIDE/LOCAL FLUID CONTROL

The manual-override menu can be accessed from the main dropdown menu or when the mode icon button (a) at the top of the menu bar is pressed. This function is not available from every menu.

The Local Fluid Control menu (shown below) lets individual functions and outputs operate for maintenance and troubleshooting purposes.



To operate functions manually, press the "Manual Override" (b) button. The button will turn yellow and the icon at the top of the menu (c) will change states to indicate manual override is active.



Press the button (d) to the right of any listed function and its corresponding output will activate as if the function is activated in sequence. The output status is shown to the right of the page (e).


NOTICE

Output interlocks that have been configured will continue to work in this mode. It is not possible to turn on two incompatible solenoids at one time from this menu.

When the manual override is active, material A, B, and C color valves (CCVs) can be selected. When a function activates that lets the "load color" system output to be active, the selected material valves will activate. When "load color" is unlatched, it will shut all color valves off.

From this menu, when manual override is not active, it is possible to run fluid sequences directly when their associated buttons near the bottom of the menu (f) are pressed. When active, functions and outputs will indicate their status and let a sequence be viewed in operation from this menu.






Press the "Pressure Regulators" button (g) on the Local Fluid Control menu to open the menu shown below.


From this menu, manual override mode can be activated and deactivated, and all configured pressure regulators can be operated manually.

Press the "Previous" button (h) to return to the Local Fluid Control Menu.



Press the "Solenoid Forcing" button (i) from the Local Fluid Control Menu to open the menu shown on the right. This menu is only available if manual override is selected.

From this menu, each installed solenoid is forced on or off when the button (j) to the right of the output descriptions is pressed.



**⚠ WARNING**  
Output interlocks are not observed in this mode.



## SHUTTING DOWN THE SYSTEM

Before shutting down, it is desirable to purge any material that is in tubing to prevent it from clogging fluid tubing, etc.



All recipes have a "Purge All" sequence designated and when the supervisory controller calls a purge command, the system will run that sequence.

To purge from the HMI – press the triangle (a) button on the bottom right of the start panel on the main run page.

All sequences that have been configured for the selected station will be shown (b) in place of the recipe selection information in the run panel. To run a sequence, the RF2 must be in "Run" mode, and all interlocks from other systems must be ok. Press the button for the sequence that is desired, and it will run.

For the shutdown purge, press the button corresponding to the sequence that has been programmed to purge all material. "Purge All" for example.

After the purge sequence has been completed, you can proceed to shutdown the system using the power switch on the right of the system's enclosure.



### ⚠ CAUTION

Always shut down the RF2 with solvent-loaded (color 0) flushed fluid lines.  
Residual air or paint in the system may cause clogs or stuck system components.

## ADMINISTRATOR FUNCTIONS


Users that are members of the "admin" group can access functions not available to other users and to modify access for other users.

### User Options



To access the user options page, log in as an administrator and then press the "user" (a) menu key to open the user actions dialog.



A dialog box will open and the administrator will see an option called "User Options" (b).



From the user options menu you can Edit users (c), Add users (d), Delete users (e), or change User permissions (f).



### Edit User

To edit a user, press the Edit Users menu.

Select the user you want to edit (g) Modify the user's parameters (h).


This includes user-group assignment.

### Add User

The operator interface supports up to fifty individual users.

To add a user, enter the Add User menu.

Fill in the parameters (i) including user name, group assignment and initial password.




### Delete User

To delete a user, enter the Delete User menu.

Select the user (j) you want to delete.


Click on delete (k).



### User Permissions

Various functions within the operator interface can have their access controlled depending on their group assignment. See more details about this in the

"Security" section in the "Process Configuration" chapter. To assign rights to different user groups, enter the "User Permissions" menu from the User Options menu, and select or deselect access for each function (l) by user level (m).




## Disabling Cloud Access

Although the cloud access feature of the RF2 is an appropriate manner to allow diagnosis, troubleshooting and updates to the equipment, some customers may not want to use this type of service.


Access to the RF2 via Exor's Corvina Cloud service can be disabled in two ways:

1. Disconnecting the RF2's physical "Cloud" RJ-25 port from a network connection.
2. Through the Exor's internal menu:



From the settings menu (when logged in as an administrator), press "Exor Internal Menu" and select "Show system settings" in the dialog box that opens (n).

In the settings menu that opens, press "Services" and then "Cloud Service" to access the menu shown below.



In the Cloud Service menu, press "Edit" (o) at the top right, and then click the "Enabled" slider to disable the service (p). Press "Save."

Press Back, Menu, Exit to return to the runtime environment.

### ⚠ WARNING

Possible malicious actors who may access to the RF2 via the cloud service could have the ability to activate the unit remotely. The greatest hazard in this case is the potential for the release of chemicals while no personnel are present. However, this hazard is mitigated if the air and fluid supplies to the RF2 are deactivated when no personnel are to be present as recommended in the safety section.

If it is suspected that someone has unauthorized access to your RF2. Contact your Corvina Cloud organization's administrator. This could be the distributor of your equipment. If this information is not known, contact Carlisle Fluid Technologies.

## Flushing Recommendations

Name	Suggested Initial Setting	Description
First Flush	AIR	Air or Solvent to initially flush fluid lines.
First Flush Time	15 seconds	Duration of first flush. This flush is used to move paint out of the system before attempting to "clean" with the chop process.
Air Chop Time	1 second	Duration of each air burst in the chop process
Solvent Chop Time	1 second	Duration of solvent burst in the chop process
Chop Duration	30 seconds	Total duration of chop process.
Last Flush Time	20 seconds	Duration of last solvent flush - should be timed to minimize solvent waste but still completely load the fluid lines with solvent.

The following factors will influence the choices listed above:

- **Worst case flushing** - Always set up the flush parameters using the most viscous/worst case resin material.
- **Flushing air and solvent pressure** - Higher pressures may reduce the time needed to flush the system, but can create significant spitting from the spray gun during the process.
- **Material viscosity** - Viscous materials move more slowly and may require additional time to be purged from the system.
- **Hose volume/ length** - Longer fluid lines encompass a larger volume and may require a longer flush time. Pressure drop through a longer hose or smaller diameter hose will affect the time required to purge paint and clean the system.
- **Spray gun tip size** - Small tips may restrict flow during a flush.

**Try to optimize the system to minimize solvent usage during color changes and flushes by:**

- Using air instead of solvent for the first flush.
- Let the "chop" process do most of the cleaning.
- Don't use more solvent than necessary for the last solvent flush.

## STARTUP GUIDE

Use the following pages as a quick reference to make electrical, air, and fluid connections to the RF2 and begin operation. Familiarize with the configuration of the machine and any options or accessories attached. Return to the User Interface Guide section of this manual for information on configuration and settings.

### Startup Checklist

Verify the frame is secured to the ground or wall and that all components are mounted securely to the enclosure, fluid panel or mast. Check that all cables for flow meter, flow sensor and any other electrical components are connected. Connect the enclosure ground stud to earth ground.

Verify all energy sources are de-energized. Inspect for loose wires anywhere inside the enclosure. Do not attempt to operate with loose wiring. Refer to the Maintenance section for wiring diagrams. After wiring verification, it is safe to plug in the system to a proper grounded AC receptacle. Verify all CCV signal lines are properly connected. See the Configuration section for reference.

### Air Connections

Connect the external air connections before use (see below). For more information, see Pneumatics section.

1. Regulated air supply to the solenoid manifold.
2. Regulated air supply to both guns on control enclosure. For atomizing, typically 20-75 psi [1.3 - 5 bar.
3. Regulated air supply to the color stack flushing air (if the system is equipped with gun flush boxes)
4. Regulated air supply to gun flush box(es) "air" connection.
5. Flush Box Trigger signals:
  - a. Gun Flush Box #1: Connect to ACO GUN 1 Port (Without gun flush box, this signal is plumbed to the Atomizing Air Cutoff valve).
  - b. Gun Flush Box #2: Connect to ACO GUN 2 Port (Without gun flush box, this signal is plumbed to the Atomizing Air Cutoff valve).
6. Gun In box signal lines to Gun 1 and Gun 2 Pressure switch inputs.
7. "Air Cutoff" signals from Gun flush box to the Atomizing Air Cutoff pilot signals (Note, without a flush box, this signal is fed from the ACO GUN 1 or 2 ports. Fluid Connections.

Perform the following fluid connections before use. For more information, go the Paint Material section of this manual. Oil Reservoirs should be filled with pump packing lube supplied with the system.

1. Connect hardener supply line to inlet of dispense pump or flow sensor.
2. Verify dispense pump outlet is connected to mix manifold.
3. Connect solvent supply line to the color stack solvent inlet.
4. Connect resin material supply to color stack ports.
5. Confirm flow meter outlet hose is tightly connected to the mix manifold material inlet.
6. Connect static mix tube to outlet of mix manifold. Connect spray gun fluid line(s) to static mix tube.
7. Energize all fluid lines and check for leaks of any kind. If any are present, be sure to remove pressure and repair the leak before continuing with the Startup Procedure.



## Startup Procedure

When air and material connections have been tested for leaks the machine should be ready to power on.

### Startup for systems without gun flush boxes

1. Make sure all compressed air and fluid sources are connected to the RF2 and energized.
2. Turn the AC lock out switch to the on position. Select the PRIME button on the dropdown menu.
3. With atomizing air off for this step, trigger the spray gun into a grounded metal waste container. Press the dispense pump enable button and allow the pump to stroke for at least 2 full cycles (typically about 30 seconds), allowing all air to be removed from the inner chambers.
4. Press dispense pump enable again to stop. Release gun trigger.
5. Make sure Color 0 shows in the display box and press Resin enable to open the solvent valve. Trigger the gun until solvent is loaded in the fluid lines.
6. Repeat the Resin load process for all system colors to Make sure functionality and to clear air from the fluid lines. After each color has been loaded into the fluid lines, be sure to load with solvent (color 0) so that the inner passageways remain clean and all air is removed.
7. Return to the Home screen by pressing the Spray Button in the dropdown menu button.
8. Press the Settings button on the dropdown menu. Proceed through each page and enter the desired values. Refer to User Interface Guide for more information about each screen.
9. Verify the Pot Life Check Volume (cc) setting is correct for the fluid line setup. Refer to the Hose Size table below.
10. For each color used in the system, an initial calibration must be performed to maintain a proper mixed ratio.
11. Open the Color screen and load the desired color.
12. After the completion of the color load energize atomizing air and spray.
13. When spraying is complete, shut off atomizing air and perform a color change or flush as required.

### Startup for systems with gun flush boxes

1. Make sure all compressed air and fluid sources are connected to the RF2 and energized.
2. Turn the AC lock out to the on position. Select the PRIME button on the dropdown menu.
3. Place the spray gun in the gun box and close the lid.
4. Press dispense pump enable and allow the pump to cycle for about 30 seconds to prime the pump and hardener line to the mix manifold. Press again when the pump is primed and no air bubbles are visible in the fluid line leading to the mix manifold.
5. Make sure color 0 shows in the display box and press Resin enable to prime solvent. Press again when solvent is visible downstream from the mix manifold.
6. Repeat this process for the remaining paint colors. Follow up this prime process with a color 0 (solvent) prime again to clear resin from the lines and mix manifold.
7. Press the Spray button in the Dropdown menu.
8. Press the Settings button in the Home screen menu. Proceed through each page and enter the desired values. Refer to User Interface Guide for more information about each screen.
9. Verify Pot Life Check Volume (cc) using the chart below.
10. For each color used in the system, an initial calibration must be performed to maintain a proper mixed ratio.
11. Press the Color button on the dropdown menu and load the desired color.
12. Remove the gun from the gun box, close the gun box lid, and spray.

When spraying is complete, place the gun in the gun box and close the lid. Perform a color change or flush as required.



Hose Size	15 ft	25 ft	50 ft	75 ft	100 ft
1/4" ID est. volume	225 cc	325 cc	600 cc	875 cc	1150 cc
1/4" ID est. volume	400 cc	625 cc	1200 cc	1775 cc	2350 cc

## DAILY OPERATIONS

Daily use of the RF2 system involves several procedures. Understanding how the system works and knowing the properties of the paint materials in use is the best way to Make sure continuous use with few alarms and repairs. Study the procedures and tips below to better understand the function of the system. Refer to the Maintenance section of this manual to review maintenance schedules and repair procedures.

### Daily Start-Up Procedure

Follow the steps below during startup to Make sure proper operation and optimal safety. These daily procedures assume paint solvents, resins, and hardeners have been loaded into the machine, have already been calibrated, and remain connected between each use of the system.

1. Make sure all fluid and air connections on the system are tight and secure. Make sure fluid supply is adequate for duration of operations.
2. Check all valves on the system for fluid supply leaks. Correct if necessary.
3. Connect regulated pressurized air to the system and open. Maintain 75psi (5 bar) minimum at all times to the enclosure main air inlet.
4. Energize fluid supplies and open valves supplying RF2 with resin(s), hardener, and solvent.
5. Connect power and turn the power switch to the "On" position.
6. Navigate to the Alarms History page. Verify no alarms have occurred recently. If an alarm has occurred, verify that the problem has been resolved.
7. Load the desired color. Go to Loading a Color section for additional detail.
8. Verify Inlet and Outlet hardener pressures are correct for the application, and that the Inlet Pressure is 2-5% higher than the Outlet.
9. If using a gun flush box, remove the gun from the box and begin to spray. If not using a gun box, turn on atomizing air and begin to spray.
10. Fine tune gun settings for the application (flow rate, atomizing air pressure, fan control). Remember that changing the resin pressure to adjust flow rate at the spray gun should be followed by a matching change to the hardener pressure to maintain the 2 to 5% higher target inlet pressure.

### **⚠ CAUTION**

If using a GUN BOX, Make sure gun is in box with the lid closed. If loading a color or flushing without a gun box, Make sure atomizing air is turned off, and trigger material into a grounded metal waste container.

## Loading a Color

1. Follow steps 1 through 8 of the Daily Start-Up Procedure section before proceeding.
2. Go to the Home screen and Make sure atomizing air is turned off. For systems with gun flush boxes, place the gun in the box and close the lid.
3. Press the Color button on the dropdown menu to access the Color Change screen.
4. Enter the color number desired, and press 1 GUN GO or 2 GUN GO to load the color to one or both guns respectively. If not using a flush box, trigger the gun into a grounded metal waste container. When loading a color if the current color is 0, the fluid lines will not be flushed, since it is assumed there is no material in the lines following the End of Day Flushing Procedure.
5. The color should be loaded and ready to spray. If adjustments need to be made to the flush sequence, go to Flushing Setup. If an alarm occurs, correct the problem and restart the procedure.

### **NOTICE**

For a color change with gun flush boxes, the GO button will not display if:

The spray gun(s) are not in the Gun Box(es).

The Gun Box lids are not closed.

## Color Change Procedure

1. To change colors, the initial color must be loaded per Loading a Color procedure.
2. Press the Color button on the dropdown menu to access the Color Change screen.
3. Enter the color number desired, and press 1 GUN GO or 2 GUN GO to load the color. The system will proceed to flush the gun(s) in sequence and then load the desired color at the mix ratio for that color.

The color selected will be loaded, completing the color change procedure. Enable atomizing air to start spraying. If an ACO valve is installed it will enable atomizing air after the gun air delay time has passed.

### NOTICE

The Remote Color Change Box is an optional purchase compatible with this system.

The color-change controller is connected through an Intrinsic Barrier (Zener Barrier) located outside the hazardous area to the RF2 device.

Instructions for installation of the remote color change box are included with it.

### In-Booth Control—Remote Color Change Box Configuration


Press the In-Booth Control button (1) to open the Remote Color Change Box Configuration screen.

To calibrate the optional Remote Color Change selector box.

Each "color" (0-7) selector switch can be set. Press "Set X" when an analog value is present.

Retrieve an analog value and ask someone to set the selector switch on the remote selector box when in this menu. A level of 500 below and above the measured value will be set.

Alternatively, the levels can be manually set. Enter the choices in the associated fields.



Digital value of the analog input reading from the Remote Color Change box

**NOTICE**

This button (1) is visible only if 'Remote CC Selector' is enabled in System Configuration.



Select Color 0 (Purge), or 1-7 (Colors 1-7)

Alarm Indicator

When alarm is present, press and hold to clear and restart, otherwise pressing this will initiate a color change to the color selected.

## System Depressurization Process

1. Flush the system if it will not be used for extended periods. Make sure all guns are in gun flush boxes, and that lids are securely closed. If not using flush boxes or ACO, shut off atomizing air for the next steps and use a grounded metal waste container.
2. From the dropdown menu, press the Color button. Enter Color 0 (Solvent) and press 1 GUN GO (or 2 GUN GO if two guns are in use). If not using a flush box trigger the spray gun.
3. Wait for the system to flush the fluid lines and load the solvent. This will purge resin from the color stack and flow meter and also remove mixed material from the mix manifold. If there is still material visible in the lines, load color 0 again, or switch the system to Flush mode as long as needed to clear any debris from the fluid lines.
4. Shut supply of all paint resin and hardener. Do NOT shut off solvent supply yet - it will be needed in a later step.
5. The fluids in the Color Stack and Dispense Pump are still under pressure. To release this pressure, go to the Prime screen.
6. On the Prime screen press Dispense Pump Prime to engage the Dispense Pump and cycle it to release any internal pressure. Allow it to run for 5 seconds, and then press Dispense Pump Prime again to stop.
7. Press Color Stack Prime with the spray gun triggered and open color stack valves 1 through 5 to bleed pressure. Finally, open valve 0 to allow solvent through the system until all lines have been flushed with solvent. Press Color Stack Prime again to close valves.
8. Shut off Solvent supply to the system. Trigger gun and press Color Stack Prime again, opening valve 0 to bleed remaining pressure in the solvent valve.
9. Power off the system.
10. Shut the main air supply to the system.


## DISPENSE PUMP OPERATION

Material is delivered to be mixed by a piston and cylinder dispense pump. An inlet and an outlet valve on each end of the pump control the material flow. When the piston moves down, the bottom inlet valve is closed, and the bottom outlet valve is open. As the piston moves down, the material in the cylinder below the piston is dispensed through the bottom outlet valve.

Also, as the piston moves down, the top outlet valve is closed, and the top inlet is open. This action lets material get drawn into the top of the cylinder above the piston. When the piston reaches the bottom of its stroke, the valve settings and the piston direction reverse. This action causes the material in the top of the cylinder to be dispensed and the bottom to be filled.

A balancing mechanism is programmed into the system controller to minimize pressure fluctuations during piston reversals. This logic assumes that the inlet material pressure is higher than the dispenser output pressure. When the dispenser reaches the limit of the potentiometer, the inlet valve will close, and the outlet valve will open. This action continues dispensing material on the output side while filling material on the inlet side. At the point where the inlet side pressure is drawn down to match the output pressure, the direction will reverse. The appropriate valves will open, and the filling side will dispense.

The dispense pump is fitted with a linear potentiometer with a wiper. The movement of the motor's screw slides the wiper on the potentiometer and communicates the position of the pump piston.




### NOTICE

The 300 cc and 600 cc versions of the dispense pump operate in the same manner.

## FLOW METER

The flow meter is a gear-type positive displacement meter specially designed for paint and will measure flow up to 1900 cc per minute. A sensor detects the movement of the inner gears and sends an electronic signal in the form of a pulse to the controller.



### Flow Meter Do:

- Filter the paint with a minimum 100 mesh filter. Change filter screens regularly.
- Use pressure regulators upstream from the flow meter to prevent false readings from fluctuating pump pressure spikes.
- Make sure the system is properly grounded and avoid electrical noise at the machine location.
- Calibrate the flow meter cc's/pulse frequently. Even different batches of the same paint can have different flow characteristics.
- Store the meter filled with solvent.
- Remove the tube/nut when removing the flow meter from the fluid panel (the flow meter is mounted to the base of the color stack using a tube fitting).
- Leave the flow meter inlet and outlet fittings intact.

### Flow Meter Do Not:

- Run the meter dry or spin the gears for a prolonged time with air only.
- Leave the meter to sit or stagnate with air or water inside the flow meter.
- Let the meter dangle by the cable.
- Let the meter drop onto the floor.

### Flow Meter Calibration

Perform flow meter calibration regularly as described on the next page. The A+B calibration will verify ratio and flow meter calibration in one simple operation.

## Flow Meter Calibration

For the best accuracy in ratio performance of the RF2, it is necessary to calibrate the flowmeter per the material that is being used.

The calibration menu can be reached through the recipe menu and allows a quick check of the material volume dispensed versus what is calculated.

The currently loaded recipe is indicated at the top right of this pop-up-menu.

In "A" calibration mode, the pump will not cycle. Only resin material will flow when the gun is triggered. Press and hold "Reset" and the pulse count will be set to zero.

Next trigger the gun into a measuring cup and enter the measured volume. The pulse count and expected volume will be compared to the measured volume and will suggest a calculated PPL (pulses-per-liter) calibration value for the flow meter. Pressing the "Save" button will save this value to the recipe of the material that is currently loaded.

In "A+B" calibration mode, the pump will operate and the measured volume will include both A and B materials according to the ratio.

If there is a problem with the catalyst pump, it will be detectable if the A+B volume is consistently incorrect, while the A volume is consistently correct.

**Flow Meter Calibration**  
Select A or A+B to start Calibration.

**A**

Pulse Count: 1578 / Pulses Per Liter: 44830 = Expected Volume (cc): 35

Measured Volume (cc): 44 / Calculated PPL: 35864

Press and hold reset button to reset Pulse Count

Reset Save  
Saves cc/Pulse to recipe

**A+B**

Effective Ratio (A/B): 5.00:1

Pulse Count: 1578 / Pulses Per Liter: 44830 = Expected Volume (cc): 42

Measured Volume (cc): 44 / Calculated PPL: 44830

Press and hold reset button to reset Pulse Count

Reset Save  
Saves cc/Pulse to recipe

Close

### NOTICE

During active calibration, the atomizing air to the gun will be disabled. If using a Gun Flush Box, make sure the lid stays open to turn off atomization air.

### NOTICE

A different calibration dialog may open based on the flowmeter type (square wave, or 4-20mA).



## SETUP

To access the main setup menu, select "Setup" from the main pull-down menu.


On the main setup page, the top two selections are available only to administrators. These are "Exor Internal Menu" (a) that opens a pop-up dialog to allow internal settings for the Exor operator interface to be modified, and "System Configuration" (b) that opens the system configuration menu.

The next group of selections involve setting up the "Fluid System" (c) which involves setting up outputs, functions, and overall sequence definitions and settings.

These selections are access-controlled by the administrator. The "Show Config Summary" (d) button will open a page showing an overview of the system configuration.

The "Fluid Sequences" (e) selection allows individual fluid sequences, including step timing and order of operations to be modified. This menu is access controlled by the administrator.


The final group of menus (f) are for modifying several miscellaneous parameters used by the system that dictate its behavior.



## Exor Internal Menu

The dropdown dialog allows access to the root settings for the Exor operator interface's internal settings. Setting IP addresses for the three networks provided with the interface (described in the Installation section above), and setting the date and time displayed on the panel are the only operations that are necessary to operate the RF2.

For more information, consult the user manual for the Exor eX715 operator interface.



## System Configuration

System configuration is a group of four menus that are used to define the hardware installed on the RF2:


- Fluid Mix/Guns
- Channels
- Stations and AnyBus Gateways
- Solenoid Manifolds, Pressure/Regulators, and Analog Outputs

## Fluid Mix/Guns

The first page allows the Fluid Mix/Guns to be configured.

Definitions for each Gun/Mix include:

1. **Description:** Each unit can be named, and the name will be displayed on the main menus and will be what is used for referencing the gun/mixer.
2. **Fluid Type:** Unused, 1, 2, or 3 component fluids.
3. **Control Type:** Auto, Manual Pulse (Future), Manual Analog (Future).
4. **Channel Selections:** Depending on the fluid type selected, Channels A, B, and C may be available. These can be mapped to physical channels 1-4.



## NOTICE

Since only four channels are available to the RF2, selections for one of the four gun/mix units will affect the availability of others. For example, if 3k is selected for Gun/Mix 1, then only 1K will be available for the other three units, only one of which will be allowed to use the remaining channel.

## NOTICE

A physical channel can only be mapped to one channel of one gun/mixer. When one is already selected elsewhere, it will be deselected in the other location.

## Channels


Press "Next" to open the next system configuration menu, for configuration of channels.

Channels that have been selected for use by a gun/mixer in the first system configuration menu will be available for configuration on this page.

1. Definitions for each channel.
2. Description. Each unit can be named—this name will be displayed on the main menus and will be what is used for referencing the channel.

Flow Control: The type of flow-actuation device that is used by the channel.

- a. MVR: A Material Volume Regulator is used to control flow.
  - b. Pulse: Fluid flow is controlled by a pulsing valve. This option is only available for secondary (B or C) channels in a gun/mixer.
  - c. Feedback Only: Flow is not controlled by the RF2 such as with a manual gun. This option is only available for manual systems on the master channel (A).
3. Inlet Pressure Regulation: Select if a pressure regulator is to be used with a flow control device.
  4. Feedback Type:
    - a. Square Wave: Flow feedback is given by the flow meter pulse connected to a High-Speed-Counter input on the I/O block.



## Stations and AnyBus Gateways

Press the "Next" button to open the next system configuration menu, for further configuration.

Station definitions include:

1. Station assignments: Each gun/mixer configured can be assigned to either panel #1 or 2.
2. Description: Description of each station that is used to reference stations throughout the operator interface.
3. Material Counts: For each channel, the amount of solenoid valves available for materials.
4. Manual Gun Enable: Enables manual gun for either station #1 or 2.

System Config 3 of 4

System Configuration

### Station Configuration

**Station Assignment**

	1	2
Panel 1	<input checked="" type="checkbox"/>	<input type="checkbox"/>
Panel 2	<input type="checkbox"/>	<input checked="" type="checkbox"/>

**Manual Gun Enable**

1	<input type="checkbox"/>
2	<input type="checkbox"/>

**Material Counts**

	Color / Mat. A Count	Cat. / Mat. B Count	Mat. C Count
Panel 1	1	1	0
Panel 2	1	1	0

**Mixer Accessories**

	Air Cutoff Installed	Flush Box Count
Panel 1	<input type="checkbox"/>	0
Panel 2	<input type="checkbox"/>	0

**Anybus Gateway**

This system may employ an optional Anybus gateway to facilitate fieldbus communications between the Ransflow 2 and the master controller.

Anybus Gateway Installed:

Previous Next

Current User: admin

5. Mixer Accessories: Enables the configuration of two new options:
  - a. Air Cutoff Installed—Check this box when an air cut-off box is installed on a mixer that does not use one or more flush boxes. When enabled, the trigger 1 (one) and trigger 2 (two) outputs of the corresponding mixer will be turned on and off when the assigned station is started or stopped. The trigger outputs are plumbed to the air cut-off box solenoids to disable the atomization air for each gun. When a flush box is installed, the flush box controls the air cut-off. When the Flush box is set, the count to a value greater than 0 will disable this option. This option does not affect mixers configured for auto mode.
  - b. Flush Box Count—Set this field to match the number of flush boxes connected to a mixer. This option does not affect mixers configured for auto mode.
6. AnyBus Gateway: If the HMS AnyBus gateway is used for communications with supervisory processes, this box (6) must be selected.

System Config 3 of 4

System Configuration

### Station Configuration

Station Assignment	1	2	Manual Gun Enable
Panel 1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	1 <input type="checkbox"/>
Panel 2	<input type="checkbox"/>	<input checked="" type="checkbox"/>	2 <input type="checkbox"/>

	Color / Mat. A Count	Cat. / Mat. B Count	Mat. C Count
Panel 1	1	1	0
Panel 2	1	1	0

### Mixer Accessories

	Air Cutoff Installed	Flush Box Count
Panel 1	<input type="checkbox"/>	0
Panel 2	<input type="checkbox"/>	0

### Anybus Gateway

*This system may employ an optional Anybus gateway to facilitate fieldbus communications between the Ransflow 2 and the master controller.*

Anybus Gateway Installed:

Previous Next

Current User: admin

5

6

## Solenoid Manifolds, Pressure/Regulators, and Analog Outputs

Press the "Next" button to open the next system configuration menu, for further configuration.

1. Solenoid Manifolds: Up to four solenoid manifolds may be used by the RF2 (each having up to 16 2-solenoid modules). Manifold #1 is always enabled and must be used.

2. Pressure Outputs: The RF2 can control up to eight pressure regulators. In this section, define the amount of regulators that the RF2 will control, and the assignment for each regulator.

a. Regulator assignments include:

- Channel 1-4 Inlet Pressure Control Pilot: Pilot signal (0-100psi) to a DR1 or equivalent pressure regulation device.
- Channel 1-4 Flow Pilot: Pilot signal (0-100psi) to an MVR or DR1 that is used for controlling flow.

3. Analog Inputs: The RF2 has eight Analog Inputs that can be utilized for different purposes:

a. Unused: The analog input is not used by the RF2.

b. Gun/Mix 1-4 Flow Command: Used as the flow command from an external/supervisory process (PLC or Robot, etc.).


c. Channel 1-4 Inlet Pressure: For gear-pump flow actuators, the inlet pressure feedback from an installed sensor.

d. Channel 1-4 Outlet Pressure: For gear-pump flow actuators, the outlet pressure feedback from an installed sensor.

e. Channel 1-4 Analog Feedback: Analog input is connected to an analog type flow meter for the channel.

f. Station 1-2 Solvent Flow Meter Feedback: Analog input is connected to a solvent flow meter which is used to verify that enough solvent was used per sequence.

Press the "Finish" button to save the system configuration parameters and reboot the RF2.





## Function Configuration



To access this menu, press: "Function Configuration" button (1) in the Setup Main Menu.

In this menu, the functions can be selected along the left side of the menu. There are fifty functions available per station, pressing the arrow keys toward the bottom of the function list will page up and down.

When a function is selected, its configuration information is shown on the right-hand side of the menu. These parameters can be modified by changing the parameters.

Parameters that can get changed are:

1. Description: Description of the function selected—often this mirrors the output it works on.
2. Type: Type of function. For more information, consult the section System Configuration—Terminology—Functions
3. Output 1:
  - a. For simple, latch, unlatch and pulse types—this is the output that is acted on when the function becomes active.
  - b. For chop type functions, this is the first output that is active when the two outputs are toggled.
4. Active in Sequences: Select all sequences for the selected function to be used.






## System Outputs

System outputs are predefined outputs used internally to the system to activate certain features, etc. Just like configured outputs, these are called by functions.

Options available are:

1. Station "x" Load—when active, the material valve(s) for the selected recipe for the station will be active.
2. Stn "x" Max Flow—when active (to be used during a load sequence), the flow command for the Gun/ Mixer will be the recipe defined "Sequence High Flow Rate." Materials will mix on ratio at this rate instead of the "Default Flow Rate."
3. Stn "x" A,B, or C Fill—when active the A, B, or C channel for the station will be forced to 100% open. This is typically used by purging operations or for quickly loading material to the flow meter.



## Output Configuration

To access this menu, press the "Function Configuration" button (1) in the Setup Main Menu.


1. Along the top of this menu, the various solenoid manifolds that are installed in the system, and the discrete (hardwired) outputs can be selected. Only manifolds that are installed will be visible for selection.
2. Selecting a manifold causes the list of solenoids in the manifold to be updated. Each Output on the manifold (0-31) can be selected. Note, the outputs are arranged in two columns (Port 4 and Port 2) and their orientation represents the view of the back of the solenoid manifold, looking at the air connections.
3. Selecting one of the outputs will cause the Selection Details to the right side of the menu to be updated.
4. Select the interlocks to be updated. To modify the output details, press the area showing the selection details—this will open a pop-up dialog menu (see on next page).
5. Swap Outputs: This button opens the swap outputs configuration screen seen on the next page.

Output Interlocks prevent two incompatible outputs from being active at any given time. Up to twenty interlocks can be programmed for any individual output. To select or deselect an output as an interlock, simply press the button representing the interlocked output.

5. Swap Outputs: This button opens the swap outputs configuration screen seen on the next page.

### NOTICE

System outputs that can be interlocked to the S1 or S2 load identify a material valve set to on and—for example—interlocked with solvent or air signals. As a result, it is not necessary to interlock various CCV outputs from one to the other because the RF2 can only operate one CCV output number at a time.



Output Setup    Oct 25 2022    02:56 PM

MENU    USER    CARLISLE    ALARM    LOG

1    Sol. Man 0    Discrete

Output Definition

Port 4		Port 2	
0 k1ss	1 k1sa		
2 k2ss	3 spare		
4 spare	5 spare		
6 k1ca1	7 k2ca1		
8 mbs	9 spare		
10 trigger g1	11 trigger g2		
12 dump 1	13 dump 2		
14 k1c1	15 k1c2		
16 k1c3	17 k1c4		
18 k1c5	19 k1c6		
20 k1c7	21 k1c8		
22 k1c9	23 k1c10		
24 k1c11	25 k1c12		
26 k2c1	27 k2c2		
28 k2c3	29 k2c4		
30 k1pv	31 k2pv		

2    Selection Details

- k1ss
- Seq. Out
- Station 1
- Standard

3    Swap Outputs

Interlocks    \*Max 20 Interlocks per output

Solenoid Manifold 0

0	2	4	6	8	10	12	14	16	18	20	22	24	26	28	30
1	3	5	7	9	11	13	15	17	19	21	23	25	27	29	31

4

Discrete Outputs

0	2	4	6	8	10	12	14	16	18	20	22	24	26	28	30
1	3	5	7	9	11	13	15	17	19	21	23	25	27	29	31

5

Previous    Run    System Outputs    S1 Load    S2 Load

## Output Configuration (cont.)

Parameters to be modified in the "Configure Output" pop-up menu are:

1. Description: Description of the output—it is recommended that each output be labeled the same as any tubing labels that are connected to the solenoid valve.
2. Output Type Selection: Refer to page 45 for more information about the different output types in the section—System Configuration—Terminology—Outputs.
- 3/4. Output ID: Depending on the type selection, different values will be asked for:
  - a. Station Number: For Sequence Output or Material CCV output types, this represents the station that the output is assigned to.
  - b. Mix/Gun Number: For Trigger output types, this represents the gun or mixer that the output is assigned to.
  - c. Channel Number: For "Flow Test" output types, this is the channel that the output is assigned to.
  - d. Input Number: For "Pass Through" output types, this is the input ID that will affect the output.
5. Press the "Accept" button to set the configured parameters.
6. Press the "Cancel" button to stop the reconfiguration procedure.




## Swap Outputs

1. Select any two solenoids to swap their configuration assignments.
2. Press the "Swap Outputs" button to complete the output swap procedure.

**NOTICE**



When two outputs are swapped, their respective interlocks are also swapped over. If they are part of a sequence function, the function definition is also automatically updated.



## Sequence Definitions


To access this menu, press the "Sequence Definitions" button (1) in the Setup Main Menu.

1. Up to sixteen programmable sequences can be given names
2. Programmable sequences can be enabled or disabled depending on whether they are necessary for the user's process.
3. If a solvent flow meter is used for the station, enter a "solvent-check" value which will be compared to the actual solvent used during a fluid sequence do generate an alarm if not met.
4. Additionally, global values for chop timing (air and solvent on times) are programmed here.



## Fluid Sequences

The Fluid Sequence Setup menu allows individual sequences of valve operation to be programmed. Sequences may be used for loading or purging of materials, as well as for other operations, such as bell cup wash, etc. When a sequence is called from the main menu, or from a supervisory process, the sequence will operate. To open this menu, press "Fluid Sequences" (a) in the Setup Main Menu.



To change a sequence:

1. Select the panel by pressing "Panel 1" or "Panel 2" buttons. The selected panel will be highlighted.
2. Select the Sequence to edit by pressing the "Seq" button or the description to its right. This will open a pop-up dialog which will allow the sequence to be selected from the list of available sequence definitions.
3. When the panel or sequence is changed, or when the refresh (b) button is pressed, the stored parameters will be loaded into the edit fields below.
4. Chop Override: If global timing values for chop air and solvent are not desired, enabling this feature allows these times to be entered in the fields below.
5. Set step times for 12 steps. If a step is not required, enter 0 seconds.
6. Step Volume: The minimum volume that must flow during each step before the next step. The step volume is measured as the total sum of all mixers configured for the current station; configure the sequence to ensure the calculated volume follows the desired flow path.

The screenshot shows the 'Fluid Sequence Setup' screen with the following elements and callouts:

- 1**: Points to the 'Panel 1' button.
- 2**: Points to the 'Seq' button.
- 3**: Points to the 'Refresh' button.
- 4**: Points to the 'Chop Override' checkbox.
- 5**: Points to the 'Step Times' row, which contains 12 input fields with values: 0.5s, 5.0s, 10.0s, 10.0s, 0.0s, 0.0s, 0.0s, 0.0s, 0.0s, 0.0s, 0.0s, 0.0s.
- 6**: Points to the 'Function' row, which contains 12 input fields for various functions like latch color, unlatch color, max flow, trigger 1, dump 1, a-fill, and b-fill.

At the bottom of the screen, there is a 'Save Edits' button, a 'Total Sequence Time' of 25.5 Seconds, and navigation buttons for 'Previous', 'Run', and 'Edit Sequence Text'.

For the sequence to progress to the next step, both the Step Time AND the Step Volume values must be met. The system will wait until enough volume has flowed through the system or until the Step time has passed, whichever takes longer.



7. The list of functions (c) that are used in the selected sequence will be shown.
8. Each function represents a row in the sequence and pressing the buttons (d) in each column will enable or disable the function in the given step. Buttons are highlighted blue when selected and white when not.
9. The total sequence time (e) is shown near the bottom of the page.
10. When finished with edits, press "Save Edits" (f) to store them in memory so that they can be used.
11. Edit Sequence Text: Opens the sequence step description editor window.




12. Sequence Descriptions: The sequence description editor lets the user add user-defined text that is displayed for each step of a sequence. Each sequence has its own set of 12 user-defined strings. The default values (g) are shown below.

The text fields on the sequence description editor page are the same as the field on the sequence run window. The text entered on this page will also appear on the sequence run window.

The sequence descriptions are not enabled until the user enters the sequence descriptions window and saves their changes.

**NOTICE**

The user text entered on this page will not be translated when the system language is changed.





## Global Setup

To modify several parameters that affect system behavior regardless of the recipe that is loaded, press "Global Parameters" (1) on the Main Setup Menu.

Parameters that are not relevant based on the system configuration will not be shown.

More information about the various parameters is given in "Process Configuration"—Global parameters.

**Global Configuration**

1 → Global Setup Alarm Masking Display Preferences

---

Setup - Global Parameters Mar 19 2021 07:44 AM

MENU USER **CARLISLE** FLUID TECHNOLOGIES ALARM LOG

Gun #1

Mixed Volume (cc): 100

	Channel #1	Channel #2
Default PPL:	56000	56000
Default Flow Anlg In Low:		
Default Flow Anlg In High:		
Default Flow Anlg Scaled Low:		
Default Flow Anlg Scaled High:		

*Default flow sensor configuration is applied only if invalid values are used within the active job. If the sensor is square-wave type, default PPL is used. If the sensor is analog type, analog scaling values are used.*

Inlet Pressure - Anlg Low:	0	0
Inlet Pressure - Anlg High:	0	0
Input Pressure - Scaled Low:	0	0
Input Pressure - Scaled High:	0	0

*Required only if inlet pressure sensor is used.*

Outlet Pressure - Anlg Low:		0
Outlet Pressure - Anlg High:		
Outlet Pressure - Scaled Low:		
Outlet Pressure - Scaled High:		
Outlet Overpressure Setting:		

*Required only if outlet pressure sensor is used.*

Reverse Flow Volume:	10	10
MVR Optimum Pressure:	35	35



◀ Previous

## Alarm Masking

You can setup various system alarms to cause the system to shut down spray or, if deselected, they will provide a warning while the system keeps running. To do this, press "Alarm Masking" (1) in the Main Setup Menu.



Not all available alarms are shown here, as some alarms will always result in spray shutdowns or warnings.

Selecting "Disable Audible Alarm" (a) disables the alarm horn from chirping when an alarm is activated.



## Display Preferences

The display preferences menu allows various items to be changed that do not affect system performance, but affect the way that data is displayed to the user, to include language and unit of measure selections.



Select to display configuration summary on startup

Choose default units

Set scaling options for trends when opening Mix/Gun or Channel pop-up menus

Choose system language

## BACK-UP/RESTORE


All stored settings, including recipe data, global setup data, fluid system configuration and sequences, etc. can be backed up to a USB stick or restored from USB or other media.

Additionally, this data is automatically backed up to SD card daily, with each daily archive being stored for one year before being deleted.

This functionality allows the entire system configuration (or individual parts of it) to be passed from one RF2 to another or restored in the event of a system failure resulting in the loss of data.

To access the backup and restore menu, navigate to the Main Setup Menu, and click on the "Backup/Restore" (1) icon on the lower right of the page.

When clicked, the system will display the screen below.



## Back-Up Data

To backup to USB, first connect a USB flash drive into the USB port (a) provided on the left side of the control enclosure. The system will indicate that a device is found (b). To eject the USB drive, press the "Eject USB" button (c) and follow the prompts.

When a USB stick is detected, each row will have a "Store to USB" (d) file available. When pressed, any of these stored .CSV file with the contained information is selected. The "All System Data" row (e) will store ALL system information.

It is possible to open and view the above file with software capable of viewing .CSV files such as Microsoft Excel.



## Restore Data



Press the "Restore" button (f) on any row to open a file dialog to access the operator interface's file system (including the USB drive and SD Card), etc. to look for the appropriate .CSV file.

The file restore dialog can be resized.

Within the operator interface file system, which is Linux based, the following paths are commonly used, and may contain file information.

- /mnt/sdcard (contents of SD card inserted in the slot).
- /mnt/usbmemory (contents of USB card inserted).

Once the file is found in the navigation menu, opening the file will restore the row selected. Note, if an invalid file is selected, the data will not be restored, and a warning message will be displayed.




## DIAGNOSTICS

The diagnostics menu contains miscellaneous functions for further diagnosing the RF2. Navigate to the diagnostics menu by pressing the "Diagnostics" pushbutton on the main dropdown menu.

### Audit Log Actions


The operator interface audits specific events such as user logged in, etc. From the diagnostics menu, it is possible to export the audit log to USB (in .CSV format), or to delete the audit log if desired.



### Hardware Browser

Some of the ethernet-enabled devices that are used by the RF2 have built-in web pages that allow for further diagnosis. The Exor operator interface that is used by the RF2 has a browser that allows viewing of those pages.

The home screen of the device browser shows the RF2s PLC web page. Hyperlinks along the top of the menu access the web pages of the other available devices.



## NOTICE

The RF2 web browser does not support all functionality for some of the pages. In special cases, a laptop may be needed to browse to those pages to perform certain tasks.

## Auxiliary Input Status

To check the functionality of inputs coming from auxiliary devices or some of the sensors that may be connected to the RF2, the Auxiliary Input Status menu allows the viewing of the input states.



## Restart HMI

The HMI can be rebooted from the Main Diagnostics Menu showcased in the previous page by pressing the button Restart HMI (a).






## DATA LOG/REPORTING

The RF2 stores flow total data and in the future, more detailed runtime data will be tracked. To access the main menu for data logging, press the "Log" button (1) on the right of the upper menu bar.



After pressing the button, the system will display the following screen:




### Flow Totals

The RF2 stores basic material flow data for viewing.

Data is organized by gun/mixer (a), time range (yearly, monthly, weekly, daily, hourly, grand) (b), by recipe (c)– or by all recipes. Data can be shown in liters or gallons (d).

If more detailed data is needed for storage– it is best to connect the RF2 to a SCADA or supervisory PLC, and routinely poll the grand total, and other identifiers to store the changes in a database.


More information about connecting the RF2 to fieldbus can be found earlier in this manual starting on page 66 and in the Appendix starting on page 189.



## File Access Via FTP

Files stored on the operator interface, including daily archives of system settings, alarm logs, etc. can be accessed via FTP if a computer is connected to one of its three networks.

An FTP access program such as WinSCP may be used for this type of access. Use the following configuration to access the RF2 data.



To Log in—press the login button (a) and enter the credentials for any administrator user account configured.

### **NOTICE**

File transfer is allowed in both directions, but it is highly recommended not to overwrite any files that are stored on the system.

## MULTI-COLOR STATUS LIGHT FUNCTIONS

The status/stack light is found on the top of the exterior of the RF2 control panel. The light will change color and/or flash depending on the status of the RF2. Each light function is defined below.

LIGHT	FUNCTION
Green—Solid	Machine is in "RUN" state, and no trigger signal is present on any stations.
Green—Flashing	Machine is in "RUN" state, and trigger signal is present on one or more stations.
Red—Solid	Machine fault is present.
Yellow—Solid	Warning indication, No fault is currently present.
Blue—Solid	Pot life is nearing expiration.
White—Solid	Machine stopped idle state, no system warnings or faults.
White—Flashing	Exor (HMI) Communication Timeout, no system warnings or faults.
Light Cyan—Solid	Machine is running in an active sequence state.

# MAINTENANCE

## REGULAR MAINTENANCE PROCEDURES AND RECOMMENDATIONS

### Material Purge

After a job is completed, remember to thoroughly purge the system. Failure to do so can cause clogs, leaks, or cross-contamination of colors and material when the system is disassembled.


### Regular Inspection

Continuous use or lack of use of the system can cause a system malfunction. Do regular interval system inspections as shown at the table below.

FREQUENCY	DESCRIPTION	INSPECTION METHOD
Daily	System flushed with solvent	Visual
Daily	Check for leaks	Visual
Daily	Clean spray guns	Visual
Daily	Check alarm history	Visual
Daily	Check for material supply	Visual
Monthly	Check static mixer for clogs	Visual
Monthly	Check all hoses for kinks and wear	Visual
Monthly	Perform flow meter calibration check	Test with beaker
Monthly	Check CCV operation	Trigger manually or from HMI
Monthly	Clean mix manifold and check valves	Disassemble
Monthly	Check fluid hoses for material buildup	Disassemble
As needed	Clean flow meter	Disassemble
As needed	Rebuild color change valves	Disassemble
As needed	Rebuild MVR valve	Disassemble
As needed	Replace static mixer assembly	Disassemble


## TOP LEVEL PART NUMBERING

310 - C ## - ###









# COMPONENT VIEWS & SPARE PARTS

## RF2 CONTROLLER



<b>RF2 CONTROLLER-TOP LEVEL</b>			
<b>Item</b>	<b>QTY</b>	<b>Part No.</b>	<b>Description</b>
1	1	310-5000	Control Enclosure
1CD	* See 1CD	–	Flow meter cables for different channel counts
3	* See Table 3	310-3940	Pressure Regulator
4	* See Table 4	310-3960	Solenoids
5	–	310-2010	Mounting Bracket
6	–	–	Cover-Pressure Regulators
7	–	–	Cover-Solenoids
<b>FLOW METER OPTIONS (DIFFERENT CHANNEL COUNTS)</b>			
<b>Code-Top Level Columns CD</b>	<b>QTY</b>	<b>Part No.</b>	<b>Description</b>
0	–	–	–
02	2	310-4138	M12-M12, 5PIN, 1M, SHIELDED
04	4	310-4138	M12-M12, 5PIN, 1M, SHIELDED
06	6	310-4138	M12-M12, 5PIN, 1M, SHIELDED
08	8	310-4138	M12-M12, 5PIN, 1M, SHIELDED
<b>Z</b>	2	310-4138	M12-M12, 5PIN, 1M, SHIELDED
22	4	310-4138	M12-M12, 5PIN, 1M, SHIELDED
24	6	310-4138	M12-M12, 5PIN, 1M, SHIELDED
26	8	310-4138	M12-M12, 5PIN, 1M, SHIELDED
40	4	310-4138	M12-M12, 5PIN, 1M, SHIELDED
42	6	310-4138	M12-M12, 5PIN, 1M, SHIELDED
44	8	310-4138	M12-M12, 5PIN, 1M, SHIELDED
60	6	310-4138	M12-M12, 5PIN, 1M, SHIELDED
62	8	310-4138	M12-M12, 5PIN, 1M, SHIELDED
80	8	310-4138	M12-M12, 5PIN, 1M, SHIELDED
<b>COMMUNICATIONS MODULE</b>			
<b>Code-Top Level Column A</b>	<b>QTY</b>	<b>Part No.</b>	<b>Description</b>
0	–	–	–
1	1	310-4142	GATEWAY, EIP-EIP
2	1	310-4143	GATEWAY, PROFINET-EIP
3	1	310-4144	GATEWAY, DEVICENET-EIP
4	1	310-4145	GATEWAY, CCLINK-EIP
5	1	310-4146	GATEWAY, ETHERCAT-EIP
<b>WIRELESS COMMUNICATION OPTION</b>			
<b>Code-Top Level Column B</b>	<b>QTY</b>	<b>Part No.</b>	<b>Description</b>
0	–	–	–
1, 3	–	310-4170	USB Wifi Module
2, 3	–	310-4171	Exor Cellular Module
2, 3	–	310-4172	Cellular Antenna
2, 3	–	310-4173	Antenna Cable


OUTER ENCLOSURE





OUTER ENCLOSURE			
Item	Qty	Part No.	Description
101	1	–	Control Enclosure Door Frame
102	1	–	Control Enclosure Thermoform
103	1	–	Slotted Door Latch
104	1	–	E-Stop Decal
105	1	310-4127	USB WATERPROOF COVER
106	1	310-4128	CABLE, USB, PANEL MOUNT, 1M CABLE
107	4	310-4129	ETHERNET BULKHEAD, RJ45 FEMALE TO FEMALE
108	6	–	CONNECTOR, BULKHEAD, M12, 5PIN, FEMALE TO LEAD, 1M
109	1	–	BULKHEAD CONNECTOR, 7/8" 5 POLE, FEMALE TO LEAD
110	1	–	LIGHT INDICATOR W/ HORN, 7 COLOR, 10-30VDC,
111	1	240-5159	LOAD SWITCH, 16A, FRONT/DOOR, W/ ACTUATOR
112	1	310-4002	HMI, EX SERIES, 15", W/ CODESYS
113	1	–	SD CARD, 32GB, CDW P/N 3052120, MFG P/N SDSDB-032G-A46
114	1	310-5166	Non-Illuminated Mushroom Operators, Twist to Release, 40 mm,
115	1	310-4102	800F Latch, Plastic Latch, Standard Pack
116	2	310-4103	22.5mm PB No Latch, Screw Contact Block, 1 N.C. Self-monitoring
117	4	–	FERRITE (EMI TOROID 12.2OD x 7x1ID x 12.7MM)

CONTROL BACKPANEL






<b>CONTROL BACKPANEL</b>			
<b>Item</b>	<b>QTY</b>	<b>Part No.</b>	<b>Description</b>
201	1	–	Electronics Back Panel
202	1	310-4116	SAFETY RELAY
203	1	310-4104	ELEC CIRC PROT, 4CH, CLASS 2
204	1	310-4105	ETH SWITCH, UNMANAGED, 8PRT
205	1	–	PLC, 2MB
206	1	–	TERMINAL, SCREW, KIT, 5069 CPU
207	1	310-4147	POWER SUPPLY, 24VDC, 240W, 10A
208	1	240-5176	CIRC. BREAKER, 2 POLE, 5A
209	19	–	BOLT, MOUNTING
210	1	310-4126	LINE FILTER, 6A, 2STAGE
211	41	–	TERMINAL BLOCK
	5	–	GROUND TERMINAL BLOCK
	2	–	TERMINAL BLOCK END
	3	–	TERMINAL BLOCK END - YELLOW
	1	–	JUMPER 2-pole
	1	–	JUMPER 4-pole
	1	–	JUMPER 6-pole
	12	–	END RETAINER
212	1	310-4115	REMOTE I/O, ADAPTER, ETHERNET
213	3	310-4111	REMOTE I/O, 16 PT. DIG. INPUT
214	1	310-4112	REMOTE I/O, 16 PT. DIG. OUTPUT
215	1	310-4114	REMOTE I/O, 8 CH. ANLG INPUT
216	2	310-4113	REMOTE I/O, 2 CH HIGH SPEED IN
217		–	–
218	4	–	SPACER FOR BACK PANEL
219	1	–	GROUND STRAP FOR BACK PANEL
220	4	310-4134	CABLE, ETHERNET, 5FT
221	4	310-4135	CABLE, ETHERNET, 3FT
222	4 ft	–	Panduit 1 x 4", Gray
223	4 ft	–	Panduit Cover, 1" Gray
224	3 ft	–	DIN Rail, Perforated

**FLUID MODULE**

WEEPING

(See manual No. LN-9112-00 for additional details)






FLUID MODULE-WEEPING			
Item	QTY	Part No.	Description
1	1	310-3301	FLUID CONTROL PANEL
2	–	TR-SSMM-147	02 WEEPING MVR
2	–	TR-SSMM-148	03 WEEPING MVR
2	–	TR-SSMM-225	04 WEEPING MVR
3	3	4-6JIC	FITTING, 1/4" NPS (M) x 3/8" JIC (F)
4	1	4SN-6JIC	FITTING, 1/4" NPS (F) x 3/8" JIC (M)
5	1	310-2806	MOUNTING BRACKET
6	–	310-9000	GEAR FLOW METER, DUAL PROBE
6	–	310-9001	GEAR FLOW METER, FIBER OPTIC
6	–	A13296	PISTON FLOW METER
7	1	4-6B	FITTING, 1/4" NPS (M) x 3/8" NPS (M)
8	1	4SN-6B	FITTING, 1/4" NPS (M) x 3/8" NPS (M)
9	2	TR-100952	SEAL
10	1	6T-4-90	FITTING, ELBOW, 3/8" NPS (M) x 1/4" NPS (M)
11	1	310-2802	MVR MOUNTING BRACKET
12	1	GA-338	1/8" NPT BACK MOUNT GAUGE (0-160 PSI), 1 1/2" DIA
13	1	JML-14-2T	ELBOW 1/8" NPT (M) x 1/4" ODT
14	1	310-8200	CALIBRATION BLOCK
15	1	CCV-503-SS	CCV VALVE
16	1	JML-532-2T	ELBOW 1/8" NPT (M) x 1/4" ODT
17	1	4T-4T	FITTING, 1/4" NPT (M) x 1/4" NPT (M)
18	1	SSP-6443	FITTING, ELBOW, 1/4" NPT (M) x 3/8" ODT
19	1	LSMM0059-01	CALIBRATION TUBE

**FLUID MODULE**

WEEPLESS

(See manual No. LN-9225-00 for additional details)





<b>FLUID MODULE-WEEPLESS</b>			
<b>Item</b>	<b>QTY</b>	<b>Part No.</b>	<b>Description</b>
1	1	310-3301	FLUID CONTROL PANEL
2	–	76624-02	02 WEEPLESS MVR
2	–	76624-03	03 WEEPLESS MVR
2	–	76624-04	04 WEEPLESS MVR
3	1	4SN-6JIC	FITTING, 1/4" NPS (F) x 3/8" JIC (M)
4	4	4-6JIC	FITTING, 1/4" NPS (M) x 3/8" JIC (M)
5	1	310-2806	MOUNTING BRACKET
6	–	310-9000	GEAR FLOW METER, DUAL PROBE
6	–	310-9001	GEAR FLOW METER, FIBER OPTIC
6	–	A13296	PISTON FLOW METER
7	1	310-2802	MVR MOUNTING BRACKET
8	1	GA-338	1/8" NPT BACK MOUNT GAUGE (0-160 PSI), 1 1/2" DIA
9	1	JML-14-2T	ELBOW 1/8" NPT (M) x 1/4" ODT
10	1	310-8200	CALIBRATION BLOCK
11	1	CCV-503-SS	CCV VALVE
12	1	JML-532-2T	ELBOW 1/8" NPT (M) x 1/4" ODT
13	1	4T-4T	FITTING, 1/4" NPT (M) x 1/4" NPT (M)
14	1	SSP-6443	FITTING, ELBOW, 1/4" NPT (M) x 3/8" ODT
15	1	LSMM0059-01	CALIBRATION TUBE



**DISPENSE PUMP**




300 cc and 600 cc



<b>DISPENSE PUMP</b>			
<b>Item</b>	<b>QTY</b>	<b>Part No.</b>	<b>Description</b>
1	1	310-4007	PUMP ENCLOSURE MOUNT
2	1	310-4006	DISPENSE PUMP ENCLOSURE
3	1	310-4131	BULKHEAD, M12, 5 PIN, M2L, 1M
4	1	310-4218	LINEAR MOTOR ASSEMBLY, RF2
5	2	240-3117	OIL RESEVOIR ASSEMBLY
6	2	240-5161	NYLON STRESS RELIEF FITTING, PG9
7	2	240-5162	GRAY NYLON LOCKING NUT, PG9
8	1	240-5136-XXX	DISPENSE PUMP (300 cc OR 600 cc)
9	1	310-3301	FLUID CONTROL PANEL
10	1	310-4161	BULKHEAD, M8, 4 PIN, M2L, 0.5 mm
11	2	240-5186	PRESSURE SENSOR, 0-500 psi
12	2	4T-4	FITTING, 1/4" NPT(M) X 1/4" NPS(M)
13	1	4SN-4-90	ELBOW FITTING, 1/4" NPS (M) x 1/4" NPS (F)



**COLOR STACK w/OPTIONAL FLUID PRESSURE REGULATOR**

Shown with optional Air Pressure Regulator





<b>DISPENSE PUMP</b>			
<b>Item</b>	<b>QTY</b>	<b>Part No.</b>	<b>Description</b>
1	2	CCV-37	CCV MANIFOLD BRACKET
2	1	CCV-18-SS	MANIFOLD BLOCK, OUTLET, 303 SS
3	2	CCV-16-SS	MANIFOLD BLOCK, CENTER, 303 SS
4	1	CCV-17-SS	MANIFOLD BLOCK, INLET, 303 SS
5	3	SSV-809	CHECK VALVE
6	1	HGB-510-R1-CO	HGB FLUID PRESSURE REGULATOR
7	1	CCV-21	HEX PORT PLUG
8	N/A	CCV-503-SS	CCV VALVE ASSEMBLY
9	N/A	41-FTP-1006	TUBE ELBOW, 1/8" NPT (M) x 5/32"
10	1	240-5350-X	AIR PRESSURE REGULATOR
11	1	4-6	FITTING, 1/4" NPS (M) x 3/8" NPS (M)
12	1	375-557-SW CRIMPED	SWIVEL NUT 303 SS
13	1	6SN-6JIC-C	FITTING, 3/8" SN x 3/8" JIC
14	1	SSP-1421	PIPE PLUG, 1/4" 316 SS



PRESSURE REGULATOR MODULES




301.4



313





301.8





PRESSURE REGULATOR MODULES				
Code-Top Level Column C	Item	QTY	Part No	Description
0	-	-	-	-
2	301.4	1	310-3910	PRESSURE MANIFOLD ASSEMBLY, 4 REGULATORS (VTEM-S1-27-E1-B1-Q10-U-Q6-CC-BAP-2PD)
	302	Included w/ manifold	-	COMM MODULE, FOR FESTO VTEM REGULATORS (50E-F36GCQP-P)
	303	1	310-4136	CBL, ETHERNET, RJ45-M12-90, 1M
	304	1	310-4140	CBL, MINI (7/8"), 5P, 2M, F-M
	305	Included w/ 310-3911	UC-3/8	PNEUMATIC MUFFLER (W/310-3911)
	306	1	20-7023	G3/8 - 3/8" Tube VTEM inlet
	307	2	20-7024	G1/8 - 1/4" Tube VTEM to MVR
	308	16	20-7022	G1/8 - 4 mm Tube VTEM to HGB
	309	6	20-7028	VTUG MOUNTING BOLTS
	310	6	20-7026	VTUG MOUNTING WASHERS
	311	6	20-7027	VTUG MOUNTING TOOTHED WASHERS
	313	1	310-2801	VTEM MOUNTING BRACKET
4	301.8	1	310-3911	PRESSURE MANIFOLD ASSEMBLY, 8 REGULATORS (VTEM-S1-27-E1-B1-Q10-U-Q6-4C-BAP-4PD)
	302	Included w/ manifold	-	COMM MODULE, FOR FESTO VTEM REGULATORS (50E-F36GCQP-P)
	303	1	310-4136	CBL, ETHERNET, RJ45-M12-90, 1M
	304	1	310-4140	CBL, MINI (7/8"), 5P, 2M, F-M
	305	Included w/ manifold	UC-3/8	PNEUMATIC MUFFLER (W/310-3911)
	306	1	20-7023	G3/8 - 3/8" TUBE VTEM INLET
	307	2	20-7024	G1/8 - 1/4" TUBE VTEM to MVR
	308	16	20-7022	G1/8 - 4 mm TUBE VTEM to HGB
	309	6	20-7028	VTUG MOUNTING BOLTS
	310	6	20-7026	VTUG MOUNTING WASHERS
	311	6	20-7027	VTUG MOUNTING TOOTHED WASHERS
	313	1	310-2801	VTEM MOUNTIN BRACKET



PRESSURE REGULATOR MODULES (cont.)




301.4



313




301.8







PRESSURE REGULATOR MODULES (cont.)				
Code-Top LevelColumn C	Item	QTY	Part No	Description
6	301.4	1	310-3910	PRESSURE MANIFOLD ASSEMBLY, 4 REGULATORS (VTEM-S1-27-E1-B1-Q10-U-Q6-CC-BAP-2PD)
	301.8	1	310-3911	PRESSURE MANIFOLD ASSEMBLY, 8 REGULATORS (VTEM-S1-27-E1-B1-Q10-U-Q6-4C-BAP-4PD)
	302	incl. w/ manifold	–	COMM MODULE, FOR FESTO VTEM REGULATORS (50E-F36GCQP-P)
	303	1	310-4136	CBL, ETHERNET, RJ45-M12-90, 1M
	304	2	310-4140	CBL, MINI (7/8"), 5P, 2M, F-M
	305	incl. w/ manifold	UC-3/8	PNEUMATIC MUFFLER (W/310-3911)
	306	2	20-7023	G3/8 - 3/8" TUBE VTEM INLET
	307	3	20-7024	G1/8 - 1/4" TUBE VTEM to MVR
	308	32	20-7022	G1/8 - 4 mm TUBE VTEM to HGB
	309	12	20-7028	VTUG MOUNTING BOLTS
	310	12	20-7026	VTUG MOUNTING WASHERS
	311	12	20-7027	VTUG MOUNTING TOOTHED WASHERS
	312	1	310-4133	CABLE, CAT 5E, M12, 1M
	313	2	310-2801	VTEM MOUNTING BRACKETS
8	301.8	2	310-3911	PRESSURE MANIFOLD ASSEMBLY, 8 REGULATORS (VTEM-S1-27-E1-B1-Q10-U-Q6-4C-BAP-4PD)
	302	incl. w/ manifold	–	COMM MODULE, FOR FESTO VTEM REGULATORS (50E-F36GCQP-P)
	303	1	310-4136	CBL, ETHERNET, RJ45-M12-90, 1M
	304	2	310-4140	CBL, MINI (7/8"), 5P, 2M, F-M
	305	incl. w/ manifold	UC-3/8	PNEUMATIC MUFFLER (W/310-3911)
	306	2	20-7023	G3/8 - 3/8" TUBE VTEM INLET
	307	3	20-7024	G1/8 - 1/4" TUBE VTEM to MVR
	308	32	20-7022	G1/8 - 4 mm TUBE VTEM to HGB
	309	12	20-7028	VTUG MOUNTING BOLTS
	310	12	20-7026	VTUG MOUNTING WASHERS
	311	12	20-7027	VTUG MOUNTING TOOTHED WASHERS
	312	1	310-4133	CABLE, CAT 5E, M12, 1M
	313	2	310-2801	VTEM MOUNTING BRACKET

SOLENOID MANIFOLDS



SOLENOID MANIFOLDS						
Item	QTY				Part No.	Description
-	E=1	E=2	E=3	E=4	-	-
401	1	2	3	4	310-3921	VALVE COMM MODULE, EIP
402	1	2	3	4	310-3920	VALVE, PNEUMATIC MANIFOLD 16PORT-16 DUAL SOLENOIDS (VTUG-10-VRPT-B1T-T516B-UB-QH-4SU-16K)
403	1	2	3	4	UC-3/8	PNEUMATIC MUFFLER (W/310-3920)
404	2	4	6	8	20-7022	G1/8 - 4 mm TUBE
405	4	8	12	16	20-7028	VTUG MOUNTING BOLTS (M4 20 mm)
406	4	8	12	16	20-7026	VTUG MOUNTING WASHERS
407	4	8	12	16	20-7027	VTUG MOUNTING TOOTHED WASHERS
408	0	1	2	3	310-4133	CABLE, CAT 5E, M12, 1M
409	1	1	1	1	310-4136	CBL, ETHERNET, RJ45-M12-90, 1M
410	1	2	3	4	310-4148	CBL, M12, 5PIN, 0.3M, 0-90DEG
411	1	2	3	4	310-2800	VTUG MOUNTING BRACKET




-  = THREAD SEALANT  
LOCTITE 567
-  = THREAD LUBRICANT [80092-00]  
NICKEL ANTI-SIEZE
-  = GUN LUBRICANT / OIL [SSL-10]  
DeVILBISS GUN LUBE

**DISPENSE PUMP-300 cc**

Item	Part No.	Description	Qty.	Notes
1	240-3020	Pump Rod Adapter	1	–
2	20-6953	Nut, Hex jam, 1/4"-28	1	–
3	237-729	Snap Ring, Internal	1	–
4	237-727	Flat Washer	1	–
5	240-3211	Rod Seal	2	–
6	240-3084	Holder, Seal	1	–
7	79001-09	O-Ring, 2-015, FFKM	1	–
8	77367-00	Valve Seat Assembly, MCV	4	–
9	78949-00	MCV Valve Assembly	4	–
10	240-3102	1/4" ODT Cap	2	–
11	FEP-0403	Teflon Paint Hose, 1/4" OD x 3/16" ID, 210 psi wp	2	–
12	240-3116	Elbow, 10-32 x 1/4" ODT	2	–
13	JML-532-2T	Male Elbow, 1/8" NPT (M) x 5/32" Tube	4	–
14	240-5186	Pressure Sensor, 0-500 psi, M12 4 pin, 4-20MA	2	–
15	4T-4	Fitting, 1/4" NPS (M) x 1/4" NPT (M)	2	–
16	240-5133	Top Block	1	–
17	20-4844	Dowel Pin (not shown), 3/16" DIA x 12 LG, SS	2	–
18	79001-21	O-Ring, 2-020, FFKM	2	–
19	240-3018-300	300 cc Cylinder	1	–
20	240-3212-300	300 cc Piston Seal	2	–
21	240-5135	Fluid Tube	2	–
22	79001-05	O-Ring, 2-010, FFKM	4	–
23	240-3224-300	300 cc Rod and Piston Assembly	1	–
24	240-5132	Bottom Block	1	–
25	7959-176C	Socket Head Cap Screw, 1/4"-20 UNC, 5.5" LG	4	12.25 N•m (9 lb-ft)
—	0114-016099	Pump Packing Lube, 250mL	1	–

See service manuals 77-2983 for complete assembly instructions.




-  = THREAD SEALANT  
LOCTITE 567
-  = THREAD LUBRICANT [80092-00]  
NICKEL ANTI-SIEZE
-  = GUN LUBRICANT / OIL [SSL-10]  
DeVILBISS GUN LUBE

**DISPENSE PUMP-600 cc**

Item	Part No.	Description	Qty.	Notes
1	240-3020	Pump Rod Adapter	1	–
2	20-6953	Nut, Hex jam, 1/4"-28	1	–
3	237-729	Snap Ring, Internal	1	–
4	237-727	Flat Washer	1	–
5	240-3211	Rod Seal	2	–
6	240-3084	Holder, Seal	1	–
7	79001-09	O-Ring, 2-015, FFKM	1	–
8	77367-00	Valve Seat Assembly, MCV	4	–
9	78949-00	MCV Valve Assembly	4	–
10	240-3102	1/4" ODT Cap	2	–
11	FEP-0403	Teflon Paint Hose, 1/4" OD x 3/16" ID, 210 psi wp	2	–
12	240-3116	Elbow, 10-32 x 1/4" ODT	2	–
13	JML-532-2T	Male Elbow, 1/8" NPT (M) x 5/32" Tube	4	–
14	240-5186	Pressure Sensor, 0-500 psi, M12 4 pin, 4-20MA	2	–
15	4T-4	Fitting, 1/4" NPS (M) x 1/4" NPT (M)	2	–
16	240-5133	Top Block	1	–
17	20-4844	Dowel Pin (not shown), 3/16" DIA x 12 LG, SS	2	–
18	79001-21	O-Ring, 2-020, FFKM	2	–
19	79001-18	O-Ring, 2-027, FFKM	2	–
20	240-3022	Cylinder Adapter	2	–
21	240-3018-600	600 cc Cylinder	1	–
22	240-3212-600	600 cc Piston Seal	2	–
23	240-5135	Fluid Tube	2	–
24	79001-05	O-Ring, 2-010, FFKM	4	–
25	240-3224-600	600 cc Rod and Piston Assembly	1	–
26	240-5132	Bottom Block	1	–
27	7959-176C	Socket Head Cap Screw, 1/4"-20 UNC, 5.5" LG	4	14.0 N•m (10 lb-ft)
—	0114-016099	Pump Packing Lube, 250mL	1	–

See service manuals 77-2983 for complete assembly instructions.






**TS** = THREAD SEALANT  
LOCTITE 567

**GL** = GUN LUBRICANT / OIL [SSL-10]  
DeVILBISS GUN LUBE

## 24VDC LINEAR MOTOR ASSEMBLY

Item	Part No.	Description	Qty.	Notes
1	240-3027	Spring Plunger	1	Sold as assembly PN 240-3065
2	240-3039	Track Roller	1	
3	20-5916	Set Screw, #10-32	1	
4	240-3013	Pot Wiper Bracket	1	
5	8212-16F	Socket Head Cap Screw, #10 Zinc Plated	4	–
6	240-3025	Linear Screw, 3/8"-12 Acme Threaded Rod, SS	1	–
7	240-3061-1	Actuator Motor (w/o linear screw)	1	–
8	240-3066	Linear Potentiometer	1	Sold as assembly PN 240-3060
9	20827-00	Cable Tie Mount, Adhesive Backed	2	
10	SSW-7323	Cable Tie	2	
11	240-3012	Potentiometer Bracket	1	
12	N/A	Cable Sweep	1	–
13	77578-16C	Button Head Cap Screw, 1/4"-20 x 1/2", SS	2	–
14	20-6952	O-Ring, BUNA-223	1	–
15	20-4844	Dowel Pin, 3/16" DIA x 1/2" LG, SS	2	Assembly PN 240-3048
16	240-3048	Motor Mount	1	
17	N/A	X-Ring, Static Seal, Elastomeric	1	–
18	20-6953	Nut, Hex Jam, 1/4"-28	1	–
19	102-3327	Nozzle Cap	1	–
20	240-3021	Motor Rod Adapter, Swivel Nut, SS	1	–
21	240-3014	Pump Coupling, 6061-T6, 2" OD x 0.375" (1.25" ID)	1	–
22	A12772-01	Button Head Cap Screw, 1/4" x 1/2", SS	4	–

See service manuals 77-2983 for complete assembly instructions.



found in repair kit KK-5094.  
 Manuals 77-2983 and 77-3117 for complete assembly instructions.

**TS** = THREAD SEALANT  
 LOCTITE 567




**SG** = SYNTHETIC GREASE  
 PLUNGER SEALING CUP LUBE

**CCV VALVE ASSEMBLY**

Item	Part No.	Description	Qty.	Notes
1	CCV-43-1	END CAP, ALUMINUM, ANODIZED BLUE	1	8.5-14.0 N•m (75-125 in-ft)
2	CCV-45	NUT, CLAMPING, BRASS	1	0.2-0.5 N•m (2-4 in-ft)
3	VA-246	CUP, SEALING, TEFLON	1	–
4	CCV-3	NUT, BRASS	1	1.4-2.0 N•m (12-18 in-ft)
5	CCV-42	VALVE INDICATOR, ALUMINUM, ANODIZED RED	4	–
6	CCV-41	SPRING	1	–
7	CCV-4	WASHER, FLAT, WASHER	1	–
8	CCV-6	SEAL, VALVE NEEDLE	1	–
9	SSP-1421	PIPE PLUG, 1/4"	2	–
10	240-2039	VALVE BODY	2	–
11	CCV-13	SPANNER NUT	1	–
12	240-2032	SPRING CLIP	1	–
13	240-2030	SPLIT COLLAR	2	–
14	CCV-40	POPPET SEAT	1	–
15	CCV-39	STEM	2	–
–	–	SYNTHETIC GREASE (SUPER LUBE)	1	–
–	80092-00	THREAD LUBRICANT, ANTI-SEIZE	1	–

**FLUID MIX PANEL**




2K High Pressure & 3K Low Pressure: Flushable Staged Mixing



FLUID MIX PANEL-2K LOW PRESSURE: FLUSHABLE/NON-FLUSHABLE						
Item	Part No.	Description	2K Low Pressure Flushable (-11)	2K Low Pressure Non-Flushable (-11)	3K Low Pressure Flushable (-13)	2K High Pressure (-22)
1	310-3807	FLUID MIX PANEL WELDMENT	1	1	1	1
2	78015	2K MIX BLOCK	1	1	2	–
3	22-280	CHECK VALVE ASSEMBLY	2	2	4	–
4	22-285	SEAL	2	2	4	–
5	LSMM0056-00	3/8" ID x 18 ELEMENT MIXER	1	1	2	1
6	LSMM0057-00	MIX TUBE RETAINING KIT	1	1	2	–
7	20-7047	FITTING, 1/2" ODT x 3/8" NPT (F), ACETAL	1	1	2	–
8	6T-4RB	FITTING, 3/8" NPT (M) x 1/4" NPS (M), BULKHEAD	1	1	2	–
9	CCV-503-SS	VALVE ASSEMBLY	1	–	2	–
10	41-FTP-1006	1/8" NPT (M) x 5/32" TUBE ELBOW	1	–	2	–
11	KK-4370	PLUG KIT		1	–	–
12	4SN-4-90	FITTING, ELBOW, 1/4" NPS (M) x 1/4" NPS (F)	2	2	4	–
13	20-7016	SPACER, 1/2" OD, 1/4" ID, 3/4" LG	2	2	4	2
14	–	SHCS, 1/4"-20, 1-7/8" LG, 18-8	2	2	4	2
15	–	WASHER, LOCK, 1/4", 18-8	2	2	4	2
16	–	WASHER, FLAT, 1/4", 18-8	2	2	4	2
17	310-3808	MIXER MOUNT BRACKET	1	1	2	1
18	–	WASHER, M6, 18-8	2	2	4	2
19	–	WASHER, LOCK, 18-8	2	2	4	2
20	–	SHCS, M6 x 1, 14MM LG, 18-8	2	2	4	2

**FLUID MIX PANEL**

2K High Pressure & 3K Low Pressure: Flushable Staged Mixing





**FLUID MIX PANEL-2K LOW PRESSURE (FLUSHABLE/NON-FLUSHABLE)**

Item	Part No.	Description	2K Low Pressure Flushable (-11)	2K Low Pressure Non-Flushable (-11)	3K Low Pressure Flushable (-13)	2K High Pressure (-22)
1	310-3807	FLUID MIX PANEL WELDMENT	1	1	1	1
2	78015	2K MIX BLOCK	1	1	2	–
3	22-280	CHECK VALVE ASSEMBLY	2	2	4	–
4	22-285	SEAL	2	2	4	–
5	LSMM0056-00	3/8" ID x 18 ELEMENT MIXER	1	1	2	1
6	LSMM0057-00	MIX TUBE RETAINING KIT	1	1	2	–
7	20-7047	FITTING, 1/2" ODT x 3/8" NPT (F), ACETAL	1	1	2	–
8	6T-4RB	FITTING, 3/8" NPT (M) x 1/4" NPS (M), BULKHEAD	1	1	2	–
9	CCV-503-SS	VALVE ASSEMBLY	1	–	2	–
10	41-FTP-1006	1/8" NPT (M) x 5/32" TUBE ELBOW	1	–	2	–
11	KK-4370	PLUG KIT	–	1	–	–
12	4SN-4-90	FITTING, ELBOW, 1/4" NPS (M) x 1/4" NPS (F)	2	2	4	–
13	20-7016	SPACER, 1/2" OD, 1/4" ID, 3/4" LG	2	2	4	2
14	–	SHCS, 1/4"-20, 1-7/8" LG, 18-8	2	2	4	2
15	–	WASHER, LOCK, 1/4", 18-8	2	2	4	2
16	–	WASHER, FLAT, 1/4", 18-8	2	2	4	2
17	310-3808	MIXER MOUNT BRACKET	1	1	2	1
18	–	WASHER, M6, 18-8	2	2	4	2
19	–	WASHER, LOCK, 18-8	2	2	4	2
20	–	SHCS, M6 x 1, 14MM LG, 18-8	2	2	4	2
21	LBAL0016-00	"Y"-BLOCK, 2K	–	–	–	1
22	LBAL0022-00	JACKET, HIGH PRESSURE, FOR DISPOSABLE MIXER	–	–	–	1
23	–	–	–	–	–	1
24	LBAL0023-00	ADAPTER, FLUID HOSE, HIGH PRESSURE	–	–	–	1
25	240-3133	FITTING, 1/4" NPT (M) x 1/4" NPT (F)	–	–	–	1
26	4T-4RB	FITTING, 1/4" NPT (M) x 1/4" NPS (M), BULKHEAD	–	–	–	1
27	6GTX	FITTING, 1/4" NPT (F) x 3/8" JIC (M)	–	–	–	2
28	SSV-809	CHECK VALVE	–	–	–	2
29	4-4T (F)	FITTING, 1/4" NPS (M) x 1/4" NPT (F)	–	–	–	2

REPAIR KITS (WEAR ITEMS)

REPAIR KITS (WEAR ITEMS)						
PN	Description	Category	Auto LP qty.	MAN LP qty.	Auto HP qty.	MAN HP qty.
KK-4841	CCV Repair Kit, LP	Fluid Panel	5	5	0	0
240-2048	HP CCV Seal Kit, Internal	Fluid Panel	0	0	5	5
240-2048	HP CCV Seal Kit, External	Fluid Panel	0	0	5	5
310-9017-K5	Flow meter Seal Kit, 5 Pack	Fluid Panel	1	1	1	1
77052-00	MVR Repair Kit, Weepless	Fluid Panel	2	0	2	0
TR-SSMM-151	Air Diaphragm, MVR Assembly (Weeping Only)	Fluid Panel	3	0	0	0
78783-00	Compression Spring, MVR (Weeping Only)	Fluid Panel	1	0	0	0
SSG-8125	O-Ring, PTFE (Weeping Only)	Fluid Panel	1	0	0	0
76623-02	#2 MVR Needle, Weepless	Fluid Panel	A/R	0	A/R	0
76623-03	#3 MVR Needle, Weepless	Fluid Panel	A/R	0	A/R	0
76623-04	#4 MVR Needle, Weepless	Fluid Panel	A/R	0	A/R	0
TR-SSMM-149	#2 MVR Needle, Weeping	Fluid Panel	A/R	0	0	0
TR-SSMM-150	#3 MVR Needle, Weeping	Fluid Panel	A/R	0	0	0
TR-SSMM-226	#4 MVR Needle, Weeping	Fluid Panel	A/R	0	0	0
22-280	Check Valve	Fluid Panel	4	4	2	2
SSV-809	Check Valve	Fluid Panel	2	2	4	4
240-2062	Pulse Valve Repair Kit	Fluid Panel	0	2	0	2
6-1306	Repair Kit, HP Fluid Regulator, Manually-Operated	Fluid Panel	0	0	2	2
LSMM0056-00	Static Mixer	Fluid Panel	2	2	2	2
310-3915	Pressure Regulator, Individual Replacement	Fluid Panel	1	1	0	0
310-3925	Solenoid Valve, Individual Replacement	Controller	2	2	2	2

**SPARE ASSEMBLIES (RECOMMENDED)**

<b>SPARE ASSEMBLIES (RECOMMENDED)</b>						
<b>PN</b>	<b>Description</b>	<b>Category</b>	<b>Auto LP qty.</b>	<b>MAN LP qty.</b>	<b>Auto HP qty.</b>	<b>MAN HP qty.</b>
CCV-503-SS	CCV Valve, LP	Fluid Panel	2	2	0	0
240-2012	CCV Valve, HP	Fluid Panel	0	0	2	2
310-9010	Flow meter Body	Fluid Panel	1	1	1	1
310-9011	Flow meter Dual Probe Pickup	Fluid Panel	1	1	1	1
240-2061	Pulse Valve Assembly	Fluid Panel	0	1	0	1
HGB-510-R1-CO	HGB Fluid Regulator, Air-Piloted	Fluid Panel	1	0	0	0
HGB-609-9-R38	HGB Fluid Regulator, Manually-Operated	Fluid Panel	0	1	0	0
84-420	Manual Fluid Regulator, HP	Fluid Panel	0	0	1	1
76624-02	MVR Assembly, #2 Weepless	Fluid Panel	A/R	0	A/R	0
76624-03	MVR Assembly, #3 Weepless	Fluid Panel	A/R	0	A/R	0
76624-04	MVR Assembly, #4 Weepless	Fluid Panel	A/R	0	A/R	0
TR-SSMM-147	MVR Assembly, #2 Weeping	Fluid Panel	A/R	0	0	0
TR-SSMM-148	MVR Assembly, #3 Weeping	Fluid Panel	A/R	0	0	0
TR-SSMM-225	MVR Assembly, #4 Weeping	Fluid Panel	A/R	0	0	0
78015-00	Mix Manifold Assembly, LP, With Solvent Flush	Fluid Panel	1	1	0	0
LBAL0016-00	Mix Manifold Assembly, HP	Fluid Panel	0	0	1	1

# TROUBLESHOOTING

Although the RF2 is a complex machine, troubleshooting the unit is straightforward, with a few basic steps.

## ALARM LIST

The alarm dialog is the first indication that something may be wrong with the RF2 control processes. Below is a list of alarms and troubleshooting steps.

Alarm Description	Details & Troubleshooting Tips
Safety Fault	The safety circuit for the RF2 is open, operation is not possible.
	This fault most occurs in conjunction with other alarms, such as an E-Stop pressed, fire-detect, etc. Address any of these faults before troubleshooting further.
	If no other fault is present with this one, check the wiring of the safety relay. See schematics for more details.
E-Stop PB Pressed	The E-Stop on the front of the RF2 control enclosure has been pressed.
	Pull the emergency stop pushbutton to reset the alarm
Festo VTEM Pressure Regulator Module (x) Fault	The indicated module (x) has on the Festo pressure regulator manifold has a fault.
	Most often, this alarm will occur at the same time as all other pressure regulator modules. This is most often caused by a lack of input air pressure being fed to the manifold.
	Make sure main air pressure is turned on.
	Press "Reset" button on the main HMI.
Comm Loss with Master Controller	After having been established, communications between the supervisory (master) PLC and the RF2 has been interrupted.
	Check master process controller for proper operation.
	Power cycle the RF2. Check cabling between master controller and RF2 unit.
Comm Loss with Aux. Communications Gateway	The AnyBus gateway installed, and communications between it and the RF2 controller have been interrupted.
	Power cycle the RF2.
	Check cabling between the RF2 and the AnyBus gateway.
Station (x)-Recipe Update Failed	The indicated station (x) has had a failure in loading a recipe (timeout occurred).
	Try loading the recipe again.
	Power cycle the RF2. Contact Technical Support.

Alarm Description	Details & Troubleshooting Tips
Station (x)-Fluid Sequence Failed	<p>The indicated station (x) has experienced a failed (incomplete) fluid sequence.</p> <p>Material may not be properly loaded or purged from the system.</p>
	<p>This occurs when an interlock is lost during a sequence. Check all wired interlocks to make sure these are not turning on at inappropriate times.</p> <p>Check other alarms that may have occurred in conjunction with this for more detailed cause analysis.</p> <p>Retry running the fluid sequence.</p>
	<p>The indicated station (x) has run a sequence, and detected not enough solvent flow in comparison to the solvent check settings.</p> <p>Make sure solvent supply is adequate and not restricted.</p> <p>Check Solvent Flow Meter.</p> <p>Check timing of fluid sequence to make sure that solvent flow occurs for enough time to flush the system.</p>
Pot Life Expired	<p>The material pot life for the indicated Gun/Mixer has elapsed.</p>
	<p>If safe to do so, trigger the gun/mixer in order to allow fresh material into the system-OR flush the system.</p>
Ratio Out Of Tolerance	<p>The RF2 has calculated that the ratio of mixtures A:B or %C has deviated by more than the allowed tolerance.</p>
	<p>Determine if fluid delivery is ok, fluid pressures are correctly set, etc.</p>
	<p>Check for restrictions in any of the fluid channels.</p>
	<p>Check material viscosity for abnormalities.</p> <p>Check recipe settings for ratio tolerance.</p>
Flow Rate Out Of Tolerance	<p>The RF2 has calculated that the overall flow rate is out of tolerance.</p>
	<p>Determine if fluid delivery is ok, fluid pressures are correctly set, etc.</p>
	<p>Check for restrictions in any of the fluid channels.</p>
	<p>Check material viscosity for abnormalities.</p> <p>Check recipe settings for flow tolerance.</p>
Ratio Shutdown	<p>A Ratio Out Of Tolerance fault has been generated, shutting down the station.</p>
	<p>Determine if fluid delivery is ok, fluid pressures are correctly set, etc.</p>
	<p>Check for restrictions in any of the fluid channels.</p>
	<p>Check material viscosity for abnormalities.</p>
	<p>Check recipe settings for ratio tolerance.</p> <p>See the alarm-masking instructions to disable the shutdown of the system for this fault.</p>

Alarm Description	Details & Troubleshooting Tips
Flow Rate Shutdown	A Flow Rate Out Of Tolerance Fault has occurred, shutting down the station.
	Determine if fluid delivery is ok, fluid pressures are correctly set, etc.
	Check for restrictions in any of the fluid channels.
	Check material viscosity for abnormalities.
	Check recipe settings for flow tolerance.
	See the alarm-masking instructions to disable the shutdown of the system for this fault.
Channel (x)-Outlet Underpressure	The indicated channel (x) has detected low pressure on its outlet pressure sensor (applicable only for gear-pump controlled channels).
	Determine if fluid delivery is ok, fluid pressures are correctly set, etc.
	Check for restrictions in the tubing feeding this channel.
	Check material viscosity for abnormalities.
	Check settings for low pressure.
	Check pressure sensor scaling/operation.
Channel (x)-Outlet Overpressure	The indicated channel (x) has detected high pressure on its outlet pressure sensor (applicable only for gear-pump controlled channels). This event will cause a spray-shutdown.
	The indicated channel (x) has detected low pressure on its outlet pressure sensor (applicable only for gear-pump controlled channels).
	Determine if fluid delivery is ok, fluid pressures are correctly set, etc.
	Check for restrictions in the tubing downstream from this channel.
	Check material viscosity for abnormalities.
	Check settings for high pressure.
	Check settings for trigger timing.
	Check pressure sensor scaling / operation.
Channel (x)-Inlet Underpressure	The indicated channel (x) has detected low pressure on its inlet pressure sensor (applies only to the gear-pump controlled channels).
	Determine if fluid delivery is ok, fluid pressures are correctly set, etc.
	Check for restrictions in the tubing feeding this channel.
	Check material viscosity for abnormalities.
	Check settings for low pressure.
	Check pressure sensor scaling/operation.
Channel (x)-Inlet Overpressure	The indicated channel (x) has detected high pressure on its inlet pressure sensor (applicable only for gear-pump controlled channels).
	Determine if fluid delivery is ok, fluid pressures are correctly set, etc.
	Check for restrictions in the tubing feeding this channel.
	Check material viscosity for abnormalities.
	Check settings for high pressure.
	Check pressure sensor scaling/operation.

Alarm Description	Details & Troubleshooting Tips
Channel (x)-Low Flow	RF2 has determined flow rate for this channel is low.
	Determine if fluid delivery is ok, fluid pressures are correctly set, etc.
	Check for restrictions in any of the fluid channels.
	Check material viscosity for abnormalities.
	Check recipe settings for flow tolerance.
	Check Flow Sensor Calibration/Operation.
Channel (x)-High Flow	RF2 has determined flow rate for this channel is high.
	Determine if fluid delivery is ok, fluid pressures are correctly set, etc.
	Check for restrictions in any of the fluid channels.
	Check material viscosity for abnormalities.
	Check recipe settings for flow tolerance.
	Check Flow Sensor Calibration/Operation.
Channel (x)-Flow Feedback Loss	Zero flow is detected by the RF2 for the indicated channel (x)
	Determine if fluid delivery is ok, fluid pressures are correctly set, etc.
	Check for restrictions in any of the fluid channels.
	Check material viscosity for abnormalities.
	Check recipe settings for flow tolerance.
	Check Flow Sensor Calibration/Operation.
Channel (x)-Spray Shutdown	The indicated channel (x) has caused a spray shutdown, due to a flow or feedback fault that has been configured to shut down the system.
	Address other channel faults that occurred in conjunction with this fault.
	See the alarm-masking instructions to disable the shutdown of the system for this fault.
Channel (x)-Reverse Flow Detected	The RF2 has detected flow in the reverse direction, exceeding the reverse-flow volume setting. This will cause a spray shutdown.
	Inspect check-valves on mix manifold and color stacks.
	Check wiring to flow meter.
	Check trigger timing settings.
	Check settings for reverse flow volume. It is normal to detect a small reverse reading when triggering off, as the fluid may create a wave in the reverse direction momentarily. This condition does not indicate fluid has passed beyond the check valve.
Channel (x)-Inlet Pressure Loss of Feedback	If an inlet pressure sensor is configured (gear-pump systems only), the RF2 has detected no feedback from the inlet pressure sensor.
	Check pressure sensor scaling/operation.
Channel (x)-Outlet Pressure Loss of Feedback	If an outlet pressure sensor is configured (gear-pump systems only), the RF2 has detected no feedback from the outlet pressure sensor.
	Check pressure sensor scaling/operation.



Alarm Description	Details & Troubleshooting Tips
Channel (x)-Flow Out Of Range	The flow actuator (MVR or DR1) is operating at its maximum pilot pressure signal, but flow rate is low.
	Check that the desired flow rate is attainable given the system flow restrictions (gun tip settings, tubing size and lengths, etc.).
	Check material viscosity for abnormalities.
Channel (x)-Unconfigured Inlet Pressure Pilot	The indicated channel has been configured with inlet pressure control, but no pressure regulator has been assigned for this purpose.
	Check System Configuration Settings.
Channel (x)-Unconfigured Flow Pressure Pilot	No flow rate pilot signal has been assigned to a regulator.
	Check System Configuration Settings.

## TROUBLESHOOTING—DISPENSE PUMP

Alarm Message	Alarm Condition(s)	Action(s)
Low Inlet Pressure	Dispense Pump inlet pressure is below the set limit during operation	Confirm material valve is open
		Confirm material pressure is correct and matches the Home screen reading
		Confirm that material is present
		Check Minimum Inlet Pressure setting on System Settings screen
		Confirm valves B1-B4 correctly function
		Confirm solenoids B1 - B4 correctly function
		Confirm the Dispense Pump pressure transducers correctly function
High Outlet Pressure	Dispense Pump outlet pressure is above the set limit at anytime	Trigger the spray applicator to relieve pressure
		Confirm the main air inlet pressure into RF2 is 75-100 psi (5-7 bar)
		Confirm valves B1-B4 correctly function
		Confirm solenoids B1-B4 correctly function
		Confirm material pressure is below Maximum Outlet Pressure on the System Settings screen
		Remove and Inspect Static Mixer
		Confirm the Dispense Pump pressure transducers correctly function
Material Flow Error	Material flow sensed when system is not spraying	Confirm valve AE (Material Enable) is closed
		Check valve AE for leaks
		Confirm fluid panel is not vibrating
No Material Flow	No flow is detected through dispense pump flow sensor (if equipped) when dispense pump is running	Confirm material valve is open
		Confirm pressure in the supply line
		Confirm material in the supply line
		Check connection of flow transducer cable
		Confirm valves B1-B4 correctly function. Opposite valves should be open (B1&B3 or B2&B4)
		Confirm solenoids B1-B4 correctly function
		Material sensor (if equipped) out of adjustment. See flow sensor (if equipped) calibration procedure in manual
		Confirm no air leaks to include the spray applicator, air flow switch, and air hoses
		Confirm blow off times are not exceeded
		Confirm valve AE are open when the spray gun is triggered
		Check connections on flow meter
		Check solenoid AE
Check for low material pressures. Check that the material pressures and regulators operate correctly		

Alarm Message	Alarm Condition(s)	Action(s)
Upper Transducer Fault	Improper electrical signal from upper pressure transducer on dispense pump	Check electrical connection and wiring
		Confirm upper pressure transducer on dispense pump correctly functions
Lower Transducer Fault	Improper electrical signal from lower pressure transducer on dispense pump	Check electrical connection and wiring
		Confirm upper pressure transducer on dispense pump correctly functions
Check Pump	Dispense pump movement does not match potentiometer output	Check for air in all fluid lines
		Confirm valves B1-B4 correctly function. Opposite valves should be open (B1&B3 or B2&B4)
		Confirm solenoids B1-B4 correctly function
		Perform a calibration (pump-setup) procedure
		Inadequate dispense pump inlet pressure. Increase to 5-10% greater than outlet pressure
		A side material flow rate too high
		Confirm wiper is correctly engaged with potentiometer (check diagnostic screen)
Upper Balancing Fault	Dispense pump top fluid pressure not balanced at pump direction change	Air in the top of dispense pump. If air is present do a material prime
		Excessive dispense pump inlet pressure. Reduce to 5-10% greater than outlet pressure
		Inadequate dispense pump inlet pressure. Increase to 5-10% greater than outlet pressure
		Confirm pressure transducers correctly function
Color Change Fault	Color change sequence has been interrupted	Confirm stop button was not pressed
		Confirm atomization air is not detected during color change
High Material Flow Rate	Material flow rate above set limit during operation	Check for air in fluid lines to color valve valves
		Confirm no leaks in fluid lines
		Verify max material flow rate in System Settings
		Adjust fluid pressure/flow to color valve valves to make sure limit is not exceeded
Air Flow Detected	Atomization air detected during color change or flush mode	Turn off atomization air during color change or flush
		Check operation of air flow switch(es)
EtherCAT Error	An internal error has occurred with PLC communications to the I/O block.	Cycle Power to the RF2.
		Check cables between the HMI and I/O block.

Alarm Message	Alarm Condition(s)	Action(s)
Material Flow Fault	Material flow detected without pump operation	Check material for fluid leaks
		Confirm material valve is open and supply adequate
		Confirm material pressure is correct
		Adjust flow sensor (if equipped) so display returns to red signal after spray applicator trigger stops
		Adjust flow sensor (if equipped) at minimum flow rate so display moves off red signal
		Confirm valves B1-B4 correctly function. Opposite valves should be open (B1&B3 or B2&B4)
Emergency Stop Button Pressed	Emergency stop button is pressed	<p>Pull out emergency stop button on front of machine</p> <p>Press reset button on operator panel</p>
Pump Position Sensor Error	Invalid reading from the pump position sensor.	Check sensor for proper operation.
Max System Pressure Error	Pressure has been measured that is higher than the rated system pressure.	Check for restrictions after the outlet of the dispense pump for fluid flow blockage.
		Check for leaks in the material circuit. Leaks can prevent flow detection.
		Verify that the maximum system pressure settings in the system configuration are correct.

## TROUBLESHOOTING—FESTO VTEM PRESSURE REGULATOR MANIFOLD

If an issue with the Festo VTEM Pressure regulator manifold occurs, the unit can access more detailed troubleshooting.


First locate the RJ45 port (1) used to configure the VTEM module, then connect a PC to this port.



Set the IP address of the connected PC to 101.1.1.99.

Open a web browser and enter 101.1.1.38 (a)

To troubleshoot a module, click the configuration tab (b).



VTEM Home System Configuration Miscellaneous English **FESTO**

### Welcome

VTEM

#### Order Information

Product Key	3STPP10VR46
Part Number	8047502

[App World](#)  
[General Product Support](#)  
[Service](#)


Click on any module to select it (c).

Select the monitor tab (d) to show a list of malfunctions (e).

The example below shows that the supply pressure is too low (f).


If the fluid panels for the RF2 are installed too far from the unit, tune the pressure regulators. To do this, press the login key (g) and enter the password (h) to log into the VTEM unit.

**The factory default password is "vtem." DO NOT change this password.**






Once logged in, select the overview tab (i) and the module (j) to edit. It is necessary to "Take Write Permissions from the PLC" (k) to make any changes. Changes are not permitted when the PLC is in communication with the VTEM manifold, so the M12 Ethernet cable at the front of the manifold must be unplugged to select the box below.



To change the tune, determine the labeled module port (4 or 2) to be connected to the tube type. Select the small, medium, or large volume setting from the dropdown menu to change the "Characteristic" (m) parameter. Additionally, the regulator can be custom tuned.

When edits are made, select "Accept values for configuration" (n), then press "Save Configurations" (o). If the configuration is not saved, the unit will revert to its earlier settings upon start-up.




## TROUBLESHOOTING—FESTO VTUG SOLENOID MANIFOLD

To replace a defective pressure regulator module, loosen the bolts on the module, then pull the module directly out. Make sure the new module's gasket is correctly located in its channel, and press it down and into the open slot. Tighten the bolts, but do not tightly squeeze the gasket.


Consult Festo VTEM operations manual for more details.

### ⚠ WARNING

Make sure the air is disconnected before attempting to remove a solenoid module.



- The RF2 can control up to four solenoid modules. These modules can be installed later in the field if not initially installed in the purchased configuration. Each manifold (1-4) must be set to a specific IP address as listed below:
- Manifold #1: 101.1.1.30
- Manifold #2: 101.1.1.31
- Manifold #3: 101.1.1.32
- Manifold #4: 101.1.1.33
- Subnet mask for all manifolds is 255.255.255.0  
To set the IP address—do the following:
  1. Remove the cover to access the dip switches on the front of the CTEU-EP communications module on the solenoid manifold.
  2. Set the dip switches for the last octet of the IP address.
  3. Connect a PC to the ethernet port of the CTEU, or connect through an ethernet switch. Set the laptop to IP address 192.168.1.99




From left to right.

1-1 = least significant bit.


2-2 = most significant bit.

Leave 2-3 – 2-6 at zero.

4. Open "Festo Field Device Tool" software. This can be downloaded from Festo's website.
5. Scan (a) the network and find the module (b) you wish to modify. Highlight it and select "Network" (c).



6. Change the IP settings (d) to 101.1.1.x (from list specified in the previous page).



7. Click OK (e)
8. Return PC IP Address to normal, re-cover the dip-switches.


# INTRODUCTION

## DISPENSE PUMP TROUBLESHOOTING

Use this checklist to help identify potential problems with the dispense pump to avoid unnecessary disassembly. If the problem is still not corrected, it may be necessary to remove the dispense pump and clean it thoroughly after flushing it with a solvent. Look for clogged passageways and evidence of fluid leaks.

Description	Pass/Fail
Check that the system is not in an Alarm state. It is possible an Alarm is not allowing the pump to run.	
Verify there are no leaks anywhere on the pump fluid end.	
Examine the Oil Reservoir. Look for overflowing or hints of hardener/catalyst material in the reservoir.	
Check for air in all fluid lines. There must be no air bubbles anywhere.	
Visually inspect the threaded actuator rod; look for wear or damage. Check rod for adequate lubrication.	
Verify the ball plunger is correctly contacts the linear potentiometer. Observe the center value change on the Dispense Pump Limits screen during the Jog Up or Jog Down movement.	
Go to the PRIME screen. Trigger the gun and dispense pump. Confirm valve operation and look for a constant stream of material exiting the gun.	
Examine the stepper motor. Verify smooth operation when the pump runs.	
Verify Signal 1A and Signal 1B (Top two LEDs on rightmost card of I/O block) light up and flash when material is travelling through the unit.	

SOLENOID CONNECTION REFERENCE-COLOR STACK




Use the reference below to reconnect the solenoid air lines to their bulkheads and CCVs. Units that are not fully optioned may not have all solenoids.

#	Solenoid	Location	Description	Basic	Optioned
A	INLET	Air Manifold	Solenoid Main Air Inlet	x	
0	K1SS	Color Stack 1	Component 1 Solvent Flush Valve	x	
1	K1SA	Color Stack 1	Component 1 Stack Air	x	
2	K2SS	Color Stack 2	Component 2 Solvent Flush Valve	x	
3	SPARE	Empty	—		
4	SPARE	Empty	—		
5	SPARE	Empty	—		
6	K1CAL	CCV Valve	Component 1 Calibration	x	
7	K2CAL	CCV Valve	Component 2 Calibration	x	
8	MBS	Fluid Mix Panel	Mix Block Solvent	x	
9	SPARE	Empty	—		
10	TRG G1	Spray Gun 1	Gun 1 Trigger	x	
11	TRG G2	Spray Gun 2	Gun 2 Trigger	x	
12	DUMP 1	—	—		
13	DUMP 2	—	—		
14	K1C1	Color Stack 1	Component 1 CCV Color Valve 1	x	
15	K1C2	Color Stack 1	Component 1 CCV Color Valve 2	x	
16	K1C3	Color Stack 1	Component 1 CCV Color Valve 3	x	
17	K1C4	Color Stack 1	Component 1 CCV Color Valve 4	x	
18	K1C5	Color Stack 1	Component 1 CCV Color Valve 5	x	
19	K1C6	Color Stack 1	Component 1 CCV Color Valve 6	x	
20	K1C7	Color Stack 1	Component 1 CCV Color Valve 7	x	
21	K1C8	Color Stack 1	Component 1 CCV Color Valve 8	x	
22	K1C9	Color Stack 1	Component 1 CCV Color Valve 9	x	
23	K1C10	Color Stack 1	Component 1 CCV Color Valve 10	x	
24	K1C11	Color Stack 1	Component 1 CCV Color Valve 11	x	
25	K1C12	Color Stack 1	Component 1 CCV Color Valve 12	x	
26	K2C1	Color Stack 2	Component 2 CCV Color Valve 1	x	
27	K2C2	Color Stack 2	Component 2 CCV Color Valve 2	x	
28	K2C3	Color Stack 2	Component 2 CCV Color Valve 3	x	
29	K2C4	Color Stack 2	Component 2 CCV Color Valve 4	x	
30	K1PV	Fluid Module	Component 1 Pulse valve		x
31	K2PV	Fluid Module	Component 2 Pulse valve		x



SOLENOID CONNECTION REFERENCE-DISPENSE PUMP



Use the reference below to reconnect the solenoid air lines to their bulkheads and CCVs. Units that are not fully optioned may not have all solenoids.


#	Solenoid	Location	Description	Basic	Optioned
A	INLET	Air Manifold	Solenoid Main Air Inlet	x	
0	K1SS	Color Stack 1	Component 1 Solvent Flush Valve	x	
1	K1SA	Color Stack 1	Component 1 Stack Air	x	
2	K2SS	—	—		
3	SPARE	Empty	—		
4	SPARE	Empty	—		
5	SPARE	Empty	—		
6	K1CAL	CCV Valve	Component 1 Calibration	x	
7	K2CAL	—	—		
8	MBS	Fluid Mix Panel	Mix Block Solvent	x	
9	SPARE	—	—		
10	TRG G1	Spray Gun 1	Gun 1 Trigger		x
11	TRG G2	Spray Gun 2	Gun 2 Trigger		x
12	DUMP 1	—	—		
13	DUMP 2	—	—		
14	K1C1	—	—		
15	K1C2	—	—		
16	K1C3	—	—		
17	K1C4	—	—		
18	K1C5	—	—		
19	K1C6	—	—		
20	K1C7	—	—		
21	K1C8	—	—		
22	K1C9	Dispense Pump	Top Inlet	x	
23	K1C10	Dispense Pump	Top Outlet	x	
24	K1C11	Dispense Pump	Bottom Inlet	x	
25	K1C12	Dispense Pump	Bottom Outlet	x	
26	K2C1	—	—		
27	K2C2	—	—		
28	K2C3	—	—		
29	K2C4	—	—		
30	K1PV	—	—		
31	K2PV	—	—		

## STANDARD FLOW METER TROUBLESHOOTING

Particulates in the fluid can cause gear binding, resulting in improper signals for the actual flow rate. Maintain the fluid filters according to the instructions from the filter manufacturer. If repeated disassembly and cleaning for removal of solids and particulates occurs, inspect the entire fluid supply system, and evaluate the system cleaning cycle.

Fluid back-up, that is, reverse flow, can cause reacted/catalyzed material to enter the flow meter. The flow meter should be cleaned immediately, before the fluid gels or hardens. Under normal operation the sensors or electrical connections will not require replacement.

To service the flow meter, refer to Flow Meter Service Manual 77-3154.



## MAINTENANCE PROCEDURES

There are no enclosure components which should require cleaning if the enclosure door is kept shut. If material seepage occurs, be sure to correct the problem and maintain a clean work area. To avoid hardening of the paint inside the fluid lines, the system must be cleaned by a complete flushing procedure at the end of operations.

### **WARNING**

Never expose electrical equipment to flammable liquids or gases including solvent fumes.

### Cleaning of Hoses

If GUN 1 and GUN 2 flush sequences are correct the mixed material line(s) will remain clean and ready for the next use. Always finish spraying operations with a color 0 load that removes all air from the fluid lines. If pot life is greatly exceeded, it is recommended the static mixer and mixed material hose be replaced.

### Maintenance of CCV Valve

If a color change valve has not been used for a prolonged period, it is recommended to remove the valve and clean the fluid passages. Paint material may collect inside the valve or manifold passages. If the valve does not operate properly or if fluid leaks occur the valve must be repaired. Check the valve for proper operation regularly.

### Maintenance of CCV Pulse Valve

If a color change valve has not been used for a prolonged period, it is recommended to remove the valve and clean the fluid passages. Paint material may collect inside the valve or manifold passages. If the valve do not operate properly or if fluid leaks occur the valve must be repaired. Check the pulse valve for proper operation regularly.

### Cleaning The Enclosure Exterior and HMI

The control enclosure's exterior painted surfaces must only be cleaned with a soft damp cloth and household cleaners. Cleaning of the touch-screen-display with solvents is not allowed. If contamination of the display is expected, use disposable screen protectors 310-8030.

### **WARNING**

Read and understand all operating manuals for connected equipment. Failure to properly follow the operating instructions could result in severe injury.

## PREVENTIVE MAINTENANCE

The RF2 system requires periodic inspection and regular maintenance. Follow the corresponding table as a guide to perform routine maintenance at suggested intervals. These intervals are recommendations and largely depend on the material being sprayed.

### Daily/Each Shift:

- Make sure mixed material is properly flushed at the end of the shift. Verify there are no air pockets in the fluid lines.
- Identify and correct air and fluid leaks on the system to include the fluid hoses and dispense pump.
- Make sure the spray guns are function correctly and that air does not leak from the air valve.
- Examine the Alarm History and review errors with operator. Verify issues have been corrected.
- Make sure material supplies are filled and pressures are correct.

### Monthly:

- Examine the static mixer assembly at the dispense pump outlet. If the static mix elements are clogged, replace the static mixer as needed. Balancing alarms or an increase in outlet pressure indicates blockage.
- If equipped: Make sure the dispense pump oil reservoir tubes have no hardener or contamination.
- Make sure to keep sufficient lubricant levels at all times.
- Examine all air and fluid lines for kinks, cuts, or wear.
- Perform a calibration to make sure the dispense pump correctly operates.
- Make sure the CCVs are opening and closing properly. Remove valves and clean if needed.
- Make sure all CCV pulse valves can properly open and close. Remove pulse valves and clean if needed.
- Clean, examine, and reassemble the valves.
- Examine fluid hoses for material buildup. Material buildup is common around hose fittings. This can be a source of contamination to finished products. Replace if needed.

### As Needed:

- Rebuild the dispense pump. This is required if there is material leakage from the oil reservoirs, or if the calibration is incorrect or inaccurate.
- Rebuild Color Change Valves – monitor valves for air leaks or slow response time when triggering.
- Rebuild Pulse Valves – monitor the valves for air leakage or slow response time when triggering.
- Examine the dispense pump for excessive wear or buildup of material. Verify smooth dispense pump movement.
- Set limits of the dispense pump/perform calibration.

## **NOTICE**

Reactive fluid properties greatly vary. If material blockage occurs to any component, adjust the maintenance schedule accordingly.

## APPENDIX

### FIELDBUS I/O

There are two methods for communicating to the RF2 over fieldbus.


- Direct CIP access to tag arrays given below. No gateway is used.
  - RF2 Input Array (PLC -> RF2):
    - AuxInArr (SINT 496)
  - RF2 Output Arrays (RF2 -> PLC):
    - AuxOut1Arr (SINT 496)
    - AuxOut2Arr (SINT 496)
- Access through AnyBus gateway (if purchased).
  - In this method, the communications protocol is converted from the customer's side to Ethernet/ IP on the RF2 side. Tag registers within the RF2 are overwritten by the tags communicated through the gateway.

Carlisle can provide sample or importable code for Rockwell software solutions for both methods above.

Datatypes that are in the form of BOOL, integer (INT), double integer (DINT), or Floating Point (REAL), are represented by varying amounts of bytes. The code used in the master controller must take this into account – for example:



The above code copies a real value into 4 bytes.



The above code copies 4 bytes into a real value.

### NOTICE

The examples shown above are Allen Bradley software. Other PLC software can have different methods to accomplish datatype conversions.

**Communications Handshake:** The RF2 will fault if it detects a connection has been lost between its master controller and itself after communications has been established. It detects communications through a handshaking word which it increments after the master controller has echoed it back. The master controller communicating must set its output byte #1 equal to its input byte #1 continuously.

## Direct Access/CIP Communications

If an Allen Bradley Logix PLC is used, or another controller where direct access to the RF2 input and output arrays (AuxInArr, AuxOut1Arr, AuxOut2Arr) is possible, no gateway or special hardware is needed to communicate to the RF2. All the RF2 communications arrays are in the form of 496 SINT Data types.

## CIP Message Setup

To make the RF2 as flexible as possible in being able to communicate to as many devices as possible, with different IP address configurations, etc. All communications are handled by the master controller, and the RF2 simply contains the tag arrays used for the transfer. Examples of Allen Bradley message setups are shown below.

**Note:** The code examples below will be put into the master PLC. Other PLCs or systems can use different methods to get the data into the RF2's tag arrays.

The screenshot displays the 'RF2 Node Setup' configuration window. The 'General' tab is active, showing the following details:

- Type: 5069-L320ER CompactLogix™ 5380 Controller
- Vendor: Rockwell Automation/Allen-Bradley
- Parent: Local
- Name: RF2
- Description: (Empty text area)

The 'Ethernet Address' section is expanded, showing three options:

- Private Network: 192.168.1. (dropdown)
- IP Address: 101 . 1 . 1 . 20
- Host Name: (Empty text field)

The 'Module Definition' section shows:

- Revision: 32.001
- Electronic Keying: Disable Keying
- Connection: None

Buttons at the bottom include 'OK', 'Cancel', 'Apply', and 'Help'. The status at the bottom left is 'Offline'.

RF2 Node Setup in an Allen Bradley PLC.

**IP Address:** Set to IP assigned to the A2 port of the RF2s Compact Logix PLC. See "Setting the IP Address for Fieldbus Communications (No Gateway)" in the Installation Chapter for more details.



The image displays two overlapping windows from a PLC configuration software. The top window is titled "Message Configuration - cftRF2Write" and has three tabs: "Configuration", "Communication", and "Tag". The "Configuration" tab is active, showing the following settings:
 

- Message Type: CIP Data Table Write (dropdown)
- Source Element: cftWriteArr (dropdown) with a "New Tag..." button to its right.
- Number Of Elements: 496 (spin box)
- Destination Element: AuxInArr (text field)

 Below these settings are radio buttons for "Enable", "Enable Waiting", "Start", and "Done", along with a "Done Length: 0" field. There are also fields for "Error Code" and "Extended Error Code", and a "Timed Out" checkbox.

The bottom window is also titled "Message Configuration - cftRF2Write" and has the same tabs. The "Communication" tab is active, showing:
 



- Path: RF2 (text field) with a "Browse..." button.
- RF2 section with a "Broadcast" dropdown.
- Communication Method section with radio buttons for "CIP" (selected) and "DH+", a "Channel" dropdown set to 'A', and a "Destination Link" spin box set to 0.

To the right of the dialog boxes is a portion of a ladder logic diagram. It features a blue "MSG" instruction block labeled "Message Control cftRF2Write" with three output lines labeled EN, DN, and ER. A red circle with the letter 'a' is positioned to the left of this block, with a red arrow pointing to it. Below the MSG block is a grey "MOV" instruction block with the following configuration:
 


- Source: cftRF2Read1Arr[495]
- Dest: cftWriteArr[495]

 The diagram also shows a search bar with the text "Search..." and various colored horizontal bars representing different parts of the ladder logic rungs.

RF2 Input Array (Master PLC Write) (a)



RF2 Output Array 1 (Master PLC Read) (b)



### RF2 Output Array 2 (Master PLC Read) (c)

Message Polling: It is recommended to poll the messages on a periodic interval. In the example code the RF2 Inputs and Outputs are offset by 20 milliseconds. Note—it is not always necessary to receive both RF2 Output Arrays—the second array is used only if active recipe data is being communicated, which is not required for running the RF2.

The RF2 Communications arrays represent the following data:

RF2 INPUT ARRAY-SINT 496			
Address	Length	Datatype	Description
0	1 Byte	SINT	System Control Byte 0 - See Detail Below
1	1 Byte	SINT	Handshake Word
2	1 Byte	SINT	Station 1 Control Byte 0-See Detail Below
3	1 Byte	SINT	Station 1 Control Byte 1-See Detail Below
4, 5	2 Byte	INT	Station 1 Job Select (1-250). This job will be loaded when the Station Job Strobe bit is activated.
6	1 Byte	SINT	Station 2 Control Byte 0-See Detail Below
7	1 Byte	SINT	Station 2 Control Byte 1-See Detail Below
8, 9	2 Byte	INT	Station 2 Job Select (1-250). This job will be loaded when the Station Job Strobe bit is activated.
10..13	4 Byte	—	Reserved
14	1 Byte	SINT	Gun / Mix 1 Trigger
15, 16	2 Byte	INT	Gun / Mix 1 Flow Command (0-3500 cc)
17	1 Byte	SINT	Gun / Mix 2 Trigger
18, 19	2 Byte	INT	Gun / Mix 2 Flow Command (0-3500 cc)
20	1 Byte	SINT	Gun / Mix 3 Trigger
21, 22	2 Byte	INT	Gun / Mix 3 Flow Command (0-3500 cc)
23	1 Byte	SINT	Gun/Mix 4 Trigger
24, 25	2 Byte	INT	Gun / Mix 4 Flow Command (0-3500 cc)
26..39	14 Byte		Reserved
40	1 Byte	SINT	Request Totals - Gun/Mix (1-4 = View Totals for Gun / Mix 1-4)
41	1 Byte	SINT	Request Totals - Job (0 = All Jobs,1-250 = Job 1-250)
42	1 Byte	SINT	Request Totals - Time Range (0=Grand, 1=Yearly, 2=Monthly, 3=Weekly,4=Daily,5=Hourly)
43..49	7 Byte	—	Reserved
50	1 Byte	SINT	Request Station Command Data (1-2)
51	1 Byte	SINT	Override Station Command Data (1-2 -- Selected Station Active Command Data - materials portion- overwritten with data given below.
52	1 Byte	SINT	Override Data - Station Selected In Byte 51 - Component A - Valve Number
53	1 Byte	SINT	Override Data - Station Selected In Byte 51 - Component B - Valve Number
54	1 Byte	SINT	Override Data - Station Selected In Byte 51 - Component C - Valve Number
55, 56	2 Byte	INT	Override Data - Station Selected In Byte 51 - Pot Life Time - Minutes x 100
57..60	4 Byte	REAL	Override Data - Station Selected In Byte 51 - Ratio A
61..64	4 Byte	REAL	Override Data - Station Selected In Byte 51 - Ratio B
65..68	4 Byte	REAL	Override Data - Station Selected In Byte 51 - Ratio C
69	1 Byte	SINT	Override Data - Station Selected In Byte 51 - Purge A Seq Select (1-16)
70	1 Byte	SINT	Override Data - Station Selected In Byte 51 - Purge All Seq Select (1-16)

RF2 INPUT ARRAY-SINT 496 (cont.)			
Address	Length	Datatype	Description
71	1 Byte	SINT	Override Data - Station Selected In Byte 51 - Load Seq Select (1-16)
72..80	9 Byte	SINT	Reserved
81	1 Byte	SINT	Request Gun / Mix Command Data (1-4)
82	1 Byte	SINT	Override Gun / Mix Command Data (1-4 -- Selected Gun/Mix Active Command Data - materials portion - overwritten with data given below.
83, 84	2 Byte	INT	Override Data - Gun/Mix Selected In Byte 82 - Default Flow Command (0-3500)
85, 86	2 Byte	INT	Override Data - Gun/Mix Selected In Byte 82 - Max Flow Command (0-3500)
87, 88	2 Byte	INT	Override Data - Gun/Mix Selected In Byte 82 - Min Flow Command (0-3500)
89, 90	2 Byte	INT	Override Data - Gun/Mix Selected In Byte 82 - Min Flow Command (0-3500)
91, 92	2 Byte	INT	Override Data - Gun/Mix Selected In Byte 82 - Ratio Tolerance Volume
93, 94	2 Byte	INT	Override Data - Gun/Mix Selected In Byte 82 - Flow Rate Tolerance (0-100%)
95, 96	2 Byte	INT	Override Data - Gun/Mix Selected In Byte 82 - Flow Rate Tolerance Time
97, 98	2 Byte	INT	Override Data - Gun/Mix Selected In Byte 82 - Trigger On Delay
99, 100	2 Byte	INT	Override Data - Gun/Mix Selected In Byte 82 - Trigger Off Delay
101, 102	2 Byte	INT	Override Data - Gun/Mix Selected In Byte 82 - Sequence High Flow Rate
103..122	20 Byte	—	Reserved
123	1 Byte	SINT	Request Channel Command Data (1-4)
124	1 Byte	DINT	Override Channel Command Data (1-4 -- Selected Channel Active Command Data - materials portion - overwritten with data given below.
125..128	4 Byte	DINT	Override Data - Channel Selected In Byte 124 - Pulse Flow Meter Calibration (PPL)
129, 130	2 Byte	INT	Override Data - Channel Selected In Byte 124 - Analog Flow Meter Calibration- Input Low
131, 132	2 Byte	INT	Override Data - Channel Selected In Byte 124 - Analog Flow Meter Calibration- Input High
133, 134	2 Byte	INT	Override Data - Channel Selected In Byte 124 - Analog Flow Meter Calibration- Scaled Low
135, 136	2 Byte	INT	Override Data - Channel Selected In Byte 124 - Analog Flow Meter Calibration- Scaled Low
137..140	4 Byte	REAL	Override Data - Channel Selected In Byte 124 - Flow Kp
141..144	4 Byte	REAL	Override Data - Channel Selected In Byte 124 - Flow Ki
145..148	4 Byte	REAL	Override Data - Channel Selected In Byte 124 - Flow Kd
149..150	2 Byte	INT	Override Data - Channel Selected In Byte 124 - Inlet Pressure Setpoint
151..154	4 Byte	REAL	Override Data - Channel Selected In Byte 124 - Inlet Pressure Kp
155..158	4 Byte	REAL	Override Data - Channel Selected In Byte 124 - Inlet Pressure Ki
159..162	4 Byte	REAL	Override Data - Channel Selected In Byte 124 - Inlet Pressure Kd
163..166	4 Byte	REAL	Override Data - Channel Selected In Byte 124 - Inlet Pressure PID Deadband
167, 168	2 Byte	INT	Override Data - Channel Selected In Byte 124 - Minimum Inlet Pressure

**RF2 INPUT ARRAY-SINT 496 (cont.)**

Address	Length	Datatype	Description
169, 170	2 Byte	INT	Override Data - Channel Selected In Byte 124 - Maximum Inlet Pressure
171, 172	2 Byte	INT	Override Data - Channel Selected In Byte 124 - Minimum Control Pressure
173, 174	2 Byte	INT	Override Data - Channel Selected In Byte 124 - Foldback Pressure
175..178	4 Byte	REAL	Override Data - Channel Selected In Byte 124 - I Band
179..182	4 Byte	REAL	Override Data - Channel Selected In Byte 124 - C Band
183..219	37 Byte	—	Reserved
220	1 Byte	SINT	User Input Bits (0..7 = Input 1-8)
221	1 Byte	SINT	User Input Bits (0..7 = Input 9-16)
222	1 Byte	SINT	User Input Bits (0..7 = Input 17-24)
223	1 Byte	SINT	User Input Bits (0..7 = Input 25-32)
224..495	272 Byte	—	Reserved

**SYSTEM CONTROL BYTE 0 ( Byte 0)**

Address	Length	Datatype	Description
0.0	1 Bit	Bool	Fault Reset
0.1	1 Bit	Bool	Spare
0.2	1 Bit	Bool	Spare
0.3	1 Bit	Bool	Spare
0.4	1 Bit	Bool	Spare
0.5	1 Bit	Bool	Spare
0.6	1 Bit	Bool	Spare
0.7	1 Bit	Bool	Spare

**SYSTEM CONTROL BYTE 0 (BYTE 2,6)**

Address	Length	Datatype	Description
x.0	1 Bit	Bool	Strobe Job
x.1	1 Bit	Bool	Purge
x.2	1 Bit	Bool	Spare
x.3	1 Bit	Bool	Seq Run Bit *
x.4	1 Bit	Bool	Seq Select Bit 0 *
x.5	1 Bit	Bool	Seq Select Bit 1 *
x.6	1 Bit	Bool	Seq Select Bit 2 *
x.7	1 Bit	Bool	Seq Select Bit 3 *

When Seq Run Bit is active, the selected sequence is the binary representation of the Seq Select Bits. A value of 0-15 will call sequence 1-16 in the sequence list.

**SYSTEM CONTROL BYTE 1 (BYTE 3,7)**

Address	Length	Datatype	Description
x.0	1 Bit	Bool	Run Mode Pulse
x.1	1 Bit	Bool	Halt Pulse
x.2	1 Bit	Bool	Spare
x.3	1 Bit	Bool	Spare
x.4	1 Bit	Bool	Spare
x.5	1 Bit	Bool	Spare
x.6	1 Bit	Bool	Spare
x.7	1 Bit	Bool	Spare

**GUN/MIX TRIGGER BYTE (BYTE 14,17,20,23)**

Address	Length	Datatype	Description
x.0	1 Bit	Bool	Trigger 1
x.1	1 Bit	Bool	Trigger 2
x.2	1 Bit	Bool	Trigger 3
x.3	1 Bit	Bool	Trigger 4
x.4	1 Bit	Bool	Spare
x.5	1 Bit	Bool	Spare
x.6	1 Bit	Bool	Spare
x.7	1 Bit	Bool	Spare



## RF2 OUTPUT ARRAY 1-SINT 496

Address	Length	Datatype	Description
0	1 Byte	SINT	System Status Byte 0 - See Detail Below
1	1 Byte	SINT	Handshake word
2	1 Byte	SINT	Station 1 Status Byte 0 - See Detail Below
3	1 Byte	SINT	Reserved
4..5	2 Byte	INT	Station 1 Active Recipe (1-250), 0= No Recipe Loaded
6	1 Byte	SINT	Station 2 Status Byte 0 - See Detail Below
7	1 Byte	SINT	Reserved
8..9	2 Byte	INT	Station 2 Active Recipe (1-250), 0= No Recipe Loaded
10..13	4 Byte	—	Reserved
14	1 Byte	SINT	Gun / Mixer #1 Status Byte - See Detail Below
15..18	4 Byte	REAL	Gun / Mixer #1 Actual Flow A (cc/min)
19..22	4 Byte	REAL	Gun / Mixer #1 Actual Flow B (cc/min)
23..26	4 Byte	REAL	Gun / Mixer #1 Actual Flow C (cc/min)
27..30	4 Byte	REAL	Gun / Mixer #1 Actual Total Flow (cc/min)
31..34	4 Byte	REAL	Gun / Mixer #1 Actual Ratio A (parts)
35..38	4 Byte	REAL	Gun / Mixer #1 Actual Ratio B (parts)
39..42	4 Byte	REAL	Gun / Mixer #1 Actual Ratio C (%)
43	1 Byte	SINT	Gun / Mixer #2 Status Byte - See Detail Below
44..47	4 Byte	REAL	Gun / Mixer #2 Actual Flow A (cc/min)
48..51	4 Byte	REAL	Gun / Mixer #2 Actual Flow B (cc/min)
52..55	4 Byte	REAL	Gun / Mixer #2 Actual Flow C (cc/min)
56..59	4 Byte	REAL	Gun / Mixer #2 Actual Total Flow (cc/min)
60..63	4 Byte	REAL	Gun / Mixer #2 Actual Ratio A (parts)
64..67	4 Byte	REAL	Gun / Mixer #2 Actual Ratio B (parts)
68..71	4 Byte	REAL	Gun / Mixer #2 Actual Ratio C (%)
72	1 Byte	SINT	Gun / Mixer #3 Status Byte - See Detail Below
73..76	4 Byte	REAL	Gun / Mixer #3 Actual Flow A (cc/min)
77..80	4 Byte	REAL	Gun / Mixer #3 Actual Flow B (cc/min)
81..84	4 Byte	REAL	Gun / Mixer #3 Actual Flow C (cc/min)
85..88	4 Byte	REAL	Gun / Mixer #3 Actual Total Flow (cc/min)
89..92	4 Byte	REAL	Gun / Mixer #3 Actual Ratio A (parts)
93..96	4 Byte	REAL	Gun / Mixer #3 Actual Ratio B (parts)
97..100	4 Byte	REAL	Gun / Mixer #3 Actual Ratio C (%)
101	1 Byte	SINT	Gun / Mixer #4 Status Byte - See Detail Below
102..105	4 Byte	REAL	Gun / Mixer #4 Actual Flow A (cc/min)
106..109	4 Byte	REAL	Gun / Mixer #4 Actual Flow B (cc/min)
110..113	4 Byte	REAL	Gun / Mixer #4 Actual Flow C (cc/min)
114..117	4 Byte	REAL	Gun / Mixer #4 Actual Total Flow (cc/min)
118..121	4 Byte	REAL	Gun / Mixer #4 Actual Ratio A (parts)
122..125	4 Byte	REAL	Gun / Mixer #4 Actual Ratio B (parts)
126..129	4 Byte	REAL	Gun / Mixer #4 Actual Ratio C (%)

<b>RF2 OUTPUT ARRAY 1-SINT 496 (cont.)</b>			
<b>Address</b>	<b>Length</b>	<b>Datatype</b>	<b>Description</b>
130	1 Byte	SINT	Channel #1 Status Byte 0 - See Detail Below
131	1 Byte	SINT	Reserved
132..135	4 Byte	REAL	Channel #1 Actual Inlet Pressure (psi) if applicable
136..139	4 Byte	REAL	Channel #1 Actual Outlet Pressure (psi) if applicable
140..143	4 Byte	REAL	Channel #1 Actual Flow (cc/min)
144..147	4 Byte	REAL	Channel #1 Actual Flow Command (cc/min)
148..151	4 Byte	REAL	Channel #1 Actual Inlet Pressure Pilot (psi)
152..155	4 Byte	REAL	Channel #1 Actual Flow Pilot (psi)
156..171	16 Byte	—	Reserved
172	1 Byte	SINT	Channel #2 Status Byte 0 - See Detail Below
173	1 Byte	SINT	Reserved
174..177	4 Byte	REAL	Channel #2 Actual Inlet Pressure (psi) if applicable
178..181	4 Byte	REAL	Channel #2 Actual Outlet Pressure (psi) if applicable
182..185	4 Byte	REAL	Channel #2 Actual Flow (cc/min)
186..189	4 Byte	REAL	Channel #2 Actual Flow Command (cc/min)
190..193	4 Byte	REAL	Channel #2 Actual Inlet Pressure Pilot (psi)
194..197	4 Byte	REAL	Channel #2 Actual Flow Pilot (psi)
198..213	16 Byte	—	Reserved
214	1 Byte	SINT	Channel #3 Status Byte 0 - See Detail Below
215	1 Byte	SINT	Reserved
216..219	4 Byte	REAL	Channel #3 Actual Inlet Pressure (psi) if applicable
220..223	4 Byte	REAL	Channel #3 Actual Outlet Pressure (psi) if applicable
224..227	4 Byte	REAL	Channel #3 Actual Flow (cc/min)
228..231	4 Byte	REAL	Channel #3 Actual Flow Command (cc/min)
232..235	4 Byte	REAL	Channel #3 Actual Inlet Pressure Pilot (psi)
236..239	4 Byte	REAL	Channel #3 Actual Flow Pilot (psi)
240..255	16 Byte	—	Reserved
256	1 Byte	SINT	Channel #4 Status Byte 0 - See Detail Below
257	1 Byte	SINT	Reserved
258..261	4 Byte	REAL	Channel #4 Actual Inlet Pressure (psi) if applicable
262..265	4 Byte	REAL	Channel #4 Actual Outlet Pressure (psi) if applicable
266..269	4 Byte	REAL	Channel #4 Actual Flow (cc/min)
270..273	4 Byte	REAL	Channel #4 Actual Flow Command (cc/min)
274..277	4 Byte	REAL	Channel #4 Actual Inlet Pressure Pilot (psi)
278..281	4 Byte	REAL	Channel #4 Actual Flow Pilot (psi)
282..297	16 Byte	—	Reserved
298	1 Byte	SINT	Alarm Word 0 - Byte 0
299	1 Byte	SINT	Alarm Word 0 - Byte 1
300	1 Byte	SINT	Alarm Word 0 - Byte 2
301	1 Byte	SINT	Alarm Word 0 - Byte 3
302	1 Byte	SINT	Alarm Word 1 - Byte 0

## RF2 OUTPUT ARRAY 1-SINT 496 (cont.)

Address	Length	Datatype	Description
303	1 Byte	SINT	Alarm Word 1 - Byte 1
304	1 Byte	SINT	Alarm Word 1 - Byte 2
305	1 Byte	SINT	Alarm Word 1 - Byte 3
306	1 Byte	SINT	Alarm Word 2 - Byte 0
307	1 Byte	SINT	Alarm Word 2 - Byte 1
308	1 Byte	SINT	Alarm Word 2 - Byte 2
309	1 Byte	SINT	Alarm Word 2 - Byte 3
310	1 Byte	SINT	Alarm Word 3 - Byte 0
311	1 Byte	SINT	Alarm Word 3 - Byte 1
312	1 Byte	SINT	Alarm Word 3 - Byte 2
313	1 Byte	SINT	Alarm Word 3 - Byte 3
314	1 Byte	SINT	Alarm Word 4 - Byte 0
315	1 Byte	SINT	Alarm Word 4 - Byte 1
316	1 Byte	SINT	Alarm Word 4 - Byte 2
317	1 Byte	SINT	Alarm Word 4 - Byte 3
318	1 Byte	SINT	Alarm Word 5 - Byte 0
319	1 Byte	SINT	Alarm Word 5 - Byte 1
320	1 Byte	SINT	Alarm Word 5 - Byte 2
321	1 Byte	SINT	Alarm Word 5 - Byte 3
322	1 Byte	SINT	Alarm Word 6 - Byte 0
323	1 Byte	SINT	Alarm Word 6 - Byte 1
324	1 Byte	SINT	Alarm Word 6 - Byte 2
325	1 Byte	SINT	Alarm Word 6 - Byte 3
326	1 Byte	SINT	Alarm Word 7 - Byte 0
327	1 Byte	SINT	Alarm Word 7 - Byte 1
328	1 Byte	SINT	Alarm Word 7 - Byte 2
329	1 Byte	SINT	Alarm Word 7 - Byte 3
330	1 Byte	SINT	Alarm Word 8 - Byte 0
331	1 Byte	SINT	Alarm Word 8 - Byte 1
332	1 Byte	SINT	Alarm Word 8 - Byte 2
333	1 Byte	SINT	Alarm Word 8 - Byte 3
334	1 Byte	SINT	Alarm Word 9 - Byte 0
335	1 Byte	SINT	Alarm Word 9 - Byte 1
336	1 Byte	SINT	Alarm Word 9 - Byte 2
337	1 Byte	SINT	Alarm Word 9 - Byte 3
338..340	3 Bytes	—	Reserved
341..344	4 Byte	REAL	Fluid Usage Data - Selected Data - Mat. A
345..348	4 Byte	REAL	Fluid Usage Data - Selected Data - Mat. B
349..352	4 Byte	REAL	Fluid Usage Data - Selected Data - Mat. C
353..356	4 Byte	REAL	Fluid Usage Data - Selected Data - Mat. Total
357..360	4 Byte	REAL	Fluid Usage Data - Selected Data - Clean

<b>RF2 OUTPUT ARRAY 1-SINT 496 (cont.)</b>			
<b>Address</b>	<b>Length</b>	<b>Datatype</b>	<b>Description</b>
361..493	133 Byte	—	Reserved
494	1 Byte	SINT	Output Array Identifier (1=Output Array 1, 2= Output Array 2) -- used with Anybus Gateway Only

<b>RF2 OUTPUT ARRAY 2-SINT 496 (Used only to report active recipe values)</b>			
<b>Address</b>	<b>Length</b>	<b>Datatype</b>	<b>Description</b>
0	1 Byte	SINT	Station selected in RF2 Input Array[50] - Active Command Data - Component A - Valve Number
1	1 Byte	SINT	Station selected in RF2 Input Array[50] - Active Command Data - Component B - Valve Number
2	1 Byte	SINT	Station selected in RF2 Input Array[50] - Active Command Data - Component C - Valve Number
3..4	2 Byte	INT	Station selected in RF2 Input Array[50] - Active Command Data - Pot Life Time (min x100)
5..8	4 Byte	REAL	Station selected in RF2 Input Array[50] - Active Command Data - Ratio A (parts)
9..12	4 Byte	REAL	Station selected in RF2 Input Array[50] - Active Command Data - Ratio B (parts)
13..16	4 Byte	REAL	Station selected in RF2 Input Array[50] - Active Command Data - Ratio C (%)
17	1 Byte	SINT	Station selected in RF2 Input Array[50] - Active Command Data - Purge A Seq (1-16)
18	1 Byte	SINT	Station selected in RF2 Input Array[50] - Active Command Data - Purge All Seq (1-16)
19	1 Byte	SINT	Station selected in RF2 Input Array[50] - Active Command Data - Load Seq (1-16)
20..30	11 Byte	—	Reserved
31..32	2 Byte	INT	Gun/Mix selected in RF2 Input Array[82] - Active Command Data - Default Flow (0-3500)
33..34	2 Byte	INT	Gun/Mix selected in RF2 Input Array[82] - Active Command Data - Max Flow
35..36	2 Byte	INT	Gun/Mix selected in RF2 Input Array[82] - Active Command Data - Min Flow
37..38	2 Byte	INT	Gun/Mix selected in RF2 Input Array[82] - Active Command Data - Ratio Tolerance
39..40	2 Byte	INT	Gun/Mix selected in RF2 Input Array[82] - Active Command Data - Ratio Tolerance Volume
41..42	2 Byte	INT	Gun/Mix selected in RF2 Input Array[82] - Active Command Data - Flow Rate Tolerance
43..44	2 Byte	INT	Gun/Mix selected in RF2 Input Array[82] - Active Command Data - Flow Rate Tolerance Time
45..46	2 Byte	INT	Gun/Mix selected in RF2 Input Array[82] - Active Command Data - Trigger On Delay
47..48	2 Byte	INT	Gun/Mix selected in RF2 Input Array[82] - Active Command Data - Trigger Off Delay
49..50	2 Byte	INT	Gun/Mix selected in RF2 Input Array[82] - Active Command Data - Sequence High Flow Rate
51..70	20 Byte	—	Reserved
71..74	4 Byte	DINT	Channel selected in RF2 Input Array[123] - Active Command Data - Calibration PPL
75..76	2 Byte	INT	Channel selected in RF2 Input Array[123] - Analog Flow Meter Calibration- Input Low

<b>RF2 OUTPUT ARRAY 2-SINT 496 (Used only to report active recipe values (cont.))</b>			
<b>Address</b>	<b>Length</b>	<b>Datatype</b>	<b>Description</b>
77..78	2 Byte	INT	Channel selected in RF2 Input Array[123] - Analog Flow Meter Calibration- Input High
79..80	2 Byte	INT	Channel selected in RF2 Input Array[123] - Analog Flow Meter Calibration- Scaled Low
81..82	2 Byte	INT	Channel selected in RF2 Input Array[123] - Analog Flow Meter Calibration- Scaled Low
83..86	4 Byte	REAL	Channel selected in RF2 Input Array[123] - Flow Kp
87..90	4 Byte	REAL	Channel selected in RF2 Input Array[123] - Flow Ki
91..94	4 Byte	REAL	Channel selected in RF2 Input Array[123] - Flow Kd
95..96	2 Byte	INT	Channel selected in RF2 Input Array[123] - Inlet Pressure Setpoint
97..100	4 Byte	REAL	Channel selected in RF2 Input Array[123] - Inlet Pressure Kp
101..104	4 Byte	REAL	Channel selected in RF2 Input Array[123] - Inlet Pressure Ki
105..108	4 Byte	REAL	Channel selected in RF2 Input Array[123] - Inlet Pressure Kd
109..112	4 Byte	REAL	Channel selected in RF2 Input Array[123] - Inlet Pressure PID Deadband
113..114	2 Byte	INT	Channel selected in RF2 Input Array[123] - Minimum Inlet Pressure
115..116	2 Byte	INT	Channel selected in RF2 Input Array[123] - Maximum Inlet Pressure
117..118	2 Byte	INT	Channel selected in RF2 Input Array[123] - Minimum Control Pressure
119..120	2 Byte	INT	Channel selected in RF2 Input Array[123] - Foldback Pressure
121..124	4 Byte	REAL	Channel selected in RF2 Input Array[123] - I Band
125..128	4 Byte	REAL	Channel selected in RF2 Input Array[123] - C Band
129..493	365 Bytes	—	Reserved
494	1 Byte	SINT	Output Array Identifier (1=Output Array 1, 2= Output Array 2) -- Used with Anybus Gateway Only
495	1 Byte	SINT	Handshake word

**SYSTEM STATUS BYTE 0 (BYTE 0)**

Address	Length	Datatype	Description
0.0	1 Bit	Bool	Comm Heartbeat
0.1	1 Bit	Bool	Fault Exists
0.2	1 Bit	Bool	Data Stable (Mix/Channel Status Data Stable)
0.3	1 Bit	Bool	Spare
0.4	1 Bit	Bool	Spare
0.5	1 Bit	Bool	Spare
0.6	1 Bit	Bool	Spare
0.7	1 Bit	Bool	Spare

**Station STATUS BYTE 0 (BYTE 2,6)**

Address	Length	Datatype	Description
0.0	1 Bit	Bool	Run Mode
0.1	1 Bit	Bool	Spare
0.2	1 Bit	Bool	Fluid Sequence Active
0.3	1 Bit	Bool	HV Enable
0.4	1 Bit	Bool	Spare
0.5	1 Bit	Bool	Spare
0.6	1 Bit	Bool	Spare
0.7	1 Bit	Bool	Spare

**GUN/MIXER STATUS BYTE (BYTE 14,43,72,101)**

Address	Length	Datatype	Description
0.0	1 Bit	Bool	Trigger 1
0.1	1 Bit	Bool	Trigger 2
0.2	1 Bit	Bool	Trigger 3
0.3	1 Bit	Bool	Trigger 4
0.4	1 Bit	Bool	Spare
0.5	1 Bit	Bool	Pot Life Expired
0.6	1 Bit	Bool	Warning
0.7	1 Bit	Bool	Spray Shutdown

**CHANNEL STATUS BYTE 0 (BYTE 130,172,214,256)**

Address	Length	Datatype	Description
0.0	1 Bit	Bool	Flow Started
0.1	1 Bit	Bool	Calibration Active
0.2	1 Bit	Bool	Manual Override Active
0.3	1 Bit	Bool	Spare
0.4	1 Bit	Bool	Spare
0.5	1 Bit	Bool	Spare
0.6	1 Bit	Bool	Spare
0.7	1 Bit	Bool	Spare



## Communications via AnyBus gateway

If purchased, the RF2 may come equipped with an AnyBus gateway which uses Ethernet/IP on the RF2 network, and a protocol of the customer's choosing on its secondary network. It is also possible to add the gateway at a later time. This gateway connects implicitly to both networks and transfers 496 bytes of input data and 496 bytes of output data between the networks. When using the gateway, the arrays listed in the section below are mapped into the AnyBus tag addresses.

Programming must be done on the side of the customer to copy the data into the correct registers. The input and output sizes in the customer's network must be 496 bytes each.

See user manual for the specific model of AnyBus gateway provided for more information on programming it.

# SCHEMATICS

## TABLE OF CONTENTS


<b>INTELLIFLOW RF2 MAIN CONTROL</b>	
<b>Drawing #</b>	<b>Description</b>
0	Cover Sheet/Table of Contents
Preliminary 1	Schematic Legend Descriptions
Preliminary 2	Wire Colors
Preliminary 3	Wire Gauges and Ampacity
Preliminary 4	Reserved for IEC Notes
Preliminary 5	Cables
1	Power, PLC, HMI
2	Safety I/O Cards
3	Digital Input Card 1
4	Digital Input Card 2
5	Digital Input Card 3
6	Digital Output Card 1
7	Analog Input Card
8	High Speed Analog Input/Output Card
8B	High Speed Analog Input/Output Card Using a Coriolis or Fiber Optic Gear Meter
8C	High Speed Analog Input/Output Card Using a Piston Meter
9	Spare
10	Spare
11	Voltage to Pressure Air Control
12	Air Solenoid Controls
13-20	Unused
21	Exor Detail
22	Ethernet Switch Detail
23	Solenoid Manifold Detail
24	Voltage to Pressure Manifold Detail
25	Spare
26	AnyBus Ethernet Communications Module
26B	AnyBus DeviceNet Communications Module
26C	AnyBus CC-Link Communications Module
26D	AnyBus ProfiNet Communications Module
26E	AnyBus EtherCat Communications Module

**REVISION LIST**

<b>REVISION LIST</b>			
<b>Version</b>	<b>Engineer</b>	<b>Date</b>	<b>Description</b>
A	SA	06/01/2020	DESIGN
B	JV	12/10/2020	AS BUILT-ALPHA
C	JV	01/25/2021	DESIGN UPDATES
D	JV	05/26/2021	PRE-PRODUCTION UPDATES
E	JV	07/27/2021	UPDATES AFTER EMC TESTING
F	JV	08/23/2021	AFTER FIRST BETA TEST
1	JV	02/03/2022	PRODUCTION RELEASE
J	RDH	02/13/2023	UPDATES

PRELIMINARY 1



LEGEND DESCRIPTIONS  
 NUMBERING CODE  
 XX???? = COMPONENT TYPE  
 ??XX?? = SHEET  
 ????XX = COLUMN



WIRE  
CROSS

CABLE NUMBER  
CORE IDENTIFIER

CBLXXXX / COLOR




WIRE  
CONNECTION

CIRCUIT BREAKER  
WITH RATING

CBXXXX


??A



TERMINAL BLOCK  
WIRE NUMBER


XXXX

TB???




CONTROL  
RELAY COIL

CRXXXX



PUSHBUTTON  
NORMALLY OPEN


PBXXXX



CONTROL  
RELAY COIL


CRXXXX

?



PUSHBUTTON  
NORMALLY CLOSED

PBXXXX



CONTROL  
RELAY COIL

CRXXXX


?



FUSE WITH  
RATING


FUXXXX

[[??A]]



SOLENOID


SOLXXXX



FUSED DISCONNECT  
WITH RATING


DSXXXX

??A



NORMALLY CLOSED  
LIMIT SWITCH


LSXXXX



NORMALLY OPEN  
SELECTOR SWITCH


SSXXXX

OX









NORMALLY OPEN  
PRESSURE SWITCH


PSXXXX



PRELIMINARY 1 (cont.)



CONNECTIONS OUTSIDE THE ELECTRICAL ENCLOSURE



RIGHT UPPER MAST LOCATION



## PRELIMINARY 2

## WIRE COLORS

Wire Reference	Color
BLK	BLACK
WHT	WHITE
BLU	BLUE
RED	RED
GRN	GREEN
ORG	ORANGE
BRN	BROWN
YLW	YELLOW

## FERRULES TO BE USED ON ALL WIRES (UNLESS NOTED)

Wire Reference	Description
BLACK	UNGROUNDING LINE VOLTAGE
WHITE	UNGROUNDING DC VOLTAGE
WHITE/BLUE	GROUNDING DC COMMON
GREEN/YELLOW	GROUND

## WIRE COLORS

Wire Reference	Color
RED_GRY	RED w/GRAY STRIPE
GRY_RED	GRAY w/RED STRIPE
WHT_BRN	WHITE w/BROWN STRIPE
BRN_WHT	BROWN w/WHITE STRIP
WHT_GRY	WHITE w/GRAY STRIPE
GRY_WHT	GRAY w/WHITE STRIPE
RED_BLU	RED w/BLUE STRIPE
BLU_RED	BLUE w/RED STRIPE
RED_ORG	RED w/ORANGE STRIPE
ORG_RED	ORANGE w/RED STRIPE
RED_GRN	RED w/GREEN STRIPE
GRN_RED	GREEN w/RED STRIPE
BRN_RED	BROWN w/RED STRIPE
RED_BRN	RED w/BROWN STRIPE
WHT_GRN	WHITE w/GREEN STRIPE
GRN_WHT	GREEN w/WHITE STRIPE
WHT_BLU	WHITE w/BLUE STRIPE
BLU_WHT	BLUE w/ WHITE STRIPE

**PRELIMINARY 2 (cont.)**

<b>WIRE COLORS (CONT.)</b>	
<b>Wire Reference</b>	<b>Color</b>
WHT_ORG	WHITE w/ORANGE STRIPE
ORG_WHT	ORANGE w/WHITE STRIPE
GRN_YLW	GREEN w/YELLOW STRIPE

**PRELIMINARY 3**

<b>WIRE GAUGE (UNLESS NOTED) USE MIN 75 DEGREE C COPPER WIRE</b>			
<b>American Wire Gauge (AWG)</b>	<b>Diameter (Inches)</b>	<b>Cross Sectional Area (mm<sup>2</sup>)</b>	<b>Ampacity (75° C Copper)</b>
3	0.2292	26.65	100
4	0.2043	21.14	85
6	0.162	13.29	65
8	0.1285	8.36	52
10	0.1019	5.26	30
12	0.0808	3.31	20
14	0.0641	2.08	15
16	0.0508	1.31	10
18	0.0403	0.82	7



PRELIMINARY 4


**RESERVED FOR IEC DOCUMENTATION**

## PRELIMINARY 5


<b>CABLE LIST</b>			
<b>Cable</b>	<b>Cable Type</b>	<b>Part</b>	<b>Location</b>
CBL 128A	ETHERNET 3FT	310-4135	ETHERNET SWITCH X1 TO BULKHEAD
CBL 128A-1	ETHERNET RJ45-M11-90, 1M	310-4136	BULKHEAD CP128 TO E/P PRESSURE MANIFOLD X1
CBL 128B	ETHERNET 3FT	310-4135	ETHERNET SWITCH X2 TO PLC A1
CBL 128C	ETHERNET 5FT	310-3134	ETHERNET SWITCH X3 TO HMI E1
CBL 128F	ETHERNET 3FT	310-4135	ETHERNET SWITCH X6 TO RIO230 (TURCK I/O) ETH1
CBL 128G	ETHERNET 3FT	310-4135	ETHERNET SWITCH TO ANYBUS GATEWAY X1.1
CBL 128H	ETHERNET 5FT	310-4134v	ETHERNET SWITCH X8 TO BULKHEAD CP128H
CBL 128H-1	ETHERNET RJ45-M11-90, 1M	310-4136	BULKHEAD CP128H YO PRESSURE REGULATOR X1
CBL 134	ETHERNET 3FT	310-4135	HMI E0 TO BULKHEAD CP134
CBL 137	DUAL PORT USB, 1.5M	09454521952	HMI USB TO BULKHEAD/PLUG CP 137
CBL 150	ETHERNET 5FT	310-4134	PLC A2 TO BULKHEAD CP150
CBL 629	7 COLOR STACK LIGHT w/ AUDIB	240-5160	RIO234 SLOT 4 TO STACK LIGHT
CBL 1105	BULKHEAD CONN; 7/8", 5 POLE	310-4132	BULKHEAD TO SOLM 1102 POWER
CBL 1203	CAT 5E, M12, 1M	310-4133	SOLM 1203 TP2 TO SOLM 1207 TP1 (OPTIONAL)
CBL 1205-1	M12 5 PIN, 0.3M, 90°	310-4148	BULKHEAD CP1205 TO SOLM 1203 X0
CBL 1207	CAT 5E, M12, 1M	310-4133	SOLM 1207 TP2 TO SOLM 1212 TP1 (OPTIONAL)
CBL 1209-1	BULKHEAD M12 5 PIN	310-4130	BULKHEAD 1204 TO SOLM 1207 X0 (OPTIONAL)
CBL 1212	CAT 5E, M12, 1M	310-4133	SOLM 1212 TP2 TO SOLM 1217 TP1 (OPTIONAL)
CBL 1214-1	BULKHEAD M12 5 PIN	310-4130	BULKHEAD 1214 TO SOLM 1212 X0 (OPTIONAL)
CBL 1219-1	BULKHEAD M12 5 PIN	310-4130	BULKHEAD 1219 TO SOLM 1207 X0 (OPTIONAL)
CBL 2405-1	MIN (7/8"), 5P, 2M, F-M	310-4140	BULKHEAD CP1105 TO SOLM 1102 P2405
CBL 2609	ETHERNET 3FT	310-4135	ANYBUS X2.1 TO BULKHEAD CP 2609

DRAWING 1


100 120/240VAC, 60/50Hz  
 10AMP  
 101 SUPPLY BY OTHERS




# DRAWING 1 (cont.)



DRAWING 2




# DRAWING 2 (cont.)






### DRAWING 3 (cont.)






DRAWING 4


+ 24 VDC -




### DRAWING 4 (cont.)




DRAWING 5




### DRAWING 5 (cont.)



DRAWING 6




# DRAWING 6 (cont.)




DRAWING 7

+ 24 VDC -




DRAWING 7 (cont.)





DRAWING 8


+ 24 VDC -






DRAWING 8B


+ 24 VDC -




DRAWING 8B (cont.)



DRAWING 8C



DRAWING 8C (cont.)



DRAWING 9

+ 24 VDC -

900 from 114  
1141

from 125  
1092


901  
902  
903  
904  
905  
906  
907  
908  
909  
910  
911  
912  
913  
914  
915  
916  
917  
918  
919  
920  
921  
922  
923  
924  
925

SPARE SCHEMATIC SPACE

1092  
to 926

1141  
to 926


DRAWING 9 (cont.)






DRAWING 10

+ 24 VDC -




DRAWING 10 (cont.)






DRAWING 11 (cont.)




DRAWING 12


+ 24 VDC -



DRAWING 12 (cont.)





DRAWING 21



DRAWING 21 (cont.)

2126  
2127  
2128  
2129  
2130  
2131  
2132  
2133  
2134  
2135  
2136  
2137  
2138  
2139  
2140  
2141  
2142  
2143  
2144  
2145  
2146  
2147  
2148  
2149  
2150





DRAWING 22

2201

2202

2203

2204

2205

2206

2207

2208

2209

2210

2211

2212

2213

2214

2215

2216

2217

2218

2219

2220


2221

2222


2223

2224


2225





SOLENOID  
MANIFOLD



PLC Port  
Eth A1



EXOR - PORT  
Eth 1



### DRAWING 22 (cont.)

2201

2202

2203

2204

2205

2206

2207

2208

2209

2210

2211

2212

2213

2214

2215

2216

2217

2218

2219

2220



2221

2222

2223

2224

2225




CBL128F → CBL128F to 223 **DISTRIBUTED I/O**


CBL128G → CBL128G to 405 **ANYBUS GATEWAY**

CBL 128H → BLKHD 128H → CBL128H-1 to 1104 **E/P PRESSURE MANIFOLD**


DRAWING 23



DRAWING 23 (cont.)



DRAWING 24



RIGHT UPPER MAST LOCATION

DRAWING 24 (cont.)

2426

2427

2428

CPX-FB36

2429

2430

2431

2432

2433

2434

2435

2436

2437

2438

2439

2440

2441

2442

2443

2444

2445


2446

2447

2448


2449

2450




DRAWING 25

+ 24 VDC -



SPARE SCHEMATIC SPACE



DRAWING 25 (cont.)






DRAWING 26

2600  
2601  
2602  
2603  
2604  
2605  
2606  
2607  
2608  
2609  
2610  
2611  
2612  
2613  
2614  
2615  
2616  
2617  
2618  
2619  
2620  
2621  
2622  
2623  
2624  
2625



DRAWING 26 (cont.)



DRAWING 26B

2600

2601

TERMINAL TORQUE  
1.4NM = 12 lb-in


2602

2603

2604

2605

2606



2607

2608

X2


2609

2610

2611

2612

2613



\*SEE NOTE

2614

2615

2616

2617

2618

2619

2620

2621

2622

2623

2624

2625



**DRAWING 26B (cont.)**

2626

2627

2628

2629

2630

2631

2632

2633

2634

2635

2636

2637

2638

2639

2640

2641

2642

2643

2644

2645


2646



2647

X2 DeviceNet Connector

2648



2649

Pin	Signal
1	V -
2	CAN L
3	Shield
4	CAN H
5	V +

2650

2651

NOTE: A termination resistor of 121 Ohms, 1%, 1/4W must be attached at each end of the DeviceNet cable.  
The resistors must be connected to pins 2 (Can L) and pins 5 (V+).

DRAWING 26C

2600

2601

TERMINAL TORQUE  
1.4NM = 12 lb-in

2602

DV2603

+ 24VDC

- 0VDC

X1.1

X1.2

from 114

1141

from 125

1092

from 131

CBL 128G

CBL 128G

2607

1 DA

2608

2 DB

2609

3 DG

2610

4 SHIELD

2611

5 FG/PE (FRAME GROUND)

GND2611

DV2603

CBL 2609

CUSTOMER SUPPLIED

'PLANT'

2612

2613

2614

2615

2616

2617

2618

2619

2620

2621

2622

2623

2624

2625



**DRAWING 26C (cont.)**

2626

2627

2628

2629

2630

2631

2632

2633

2634

2635

2636

2637

2638

2639

2640

2641

2642

2643

2644

2645

2646


2647

2648


2649

2650

2651



X2 CC-Link Connector



Pin	Signal
1	DA (Communication signal)
2	DB (Communication signal)
3	DG (Digital Ground)
4	Shield (Cable shield)
5	FG/PE (Frame Ground)


DRAWING 26D

2600

2601

TERMINAL TORQUE  
1.4NM = 12 lb-in

2602




2606

2607

2608

DV2603-2

2609



2610

2611

DV2603

2612

2613

2614

2615

2616

2617

2618

2619

2620

2621

2622


2623

2624

2625



DRAWING 26D (cont.)





DRAWING 26E

2600

2601

2602

2603

2604

2605

2606

2607

2608

2609

2610

2611

2612

2613

2614

2615

2616

2617

2618

2619

2620



2621

2622

2623

2624


2625



DV2603



DRAWING 26E (cont.)



**REVISIONS**

<b>Date</b>	<b>Changes</b>	<b>Version</b>
10/12/2021	1st Draft	R1
12/20/2022	Added Rev. H electrical schematics (Appendix section)	R1
03/13/2023	Added Rev. J electrical schematics (Appendix section)	R2
03/23/2023	Added pulse valve adjustment and Cloud/Internet connection pages	R2
05/22/2023	Added pressure limitations due to Coriolis	R3
06/28/2023	Corrected Output Array tables (pages 194-204)	R3
10/16/2023	Added dispense pump configuration and schematics	R4



## WARRANTY POLICY

This product is covered by Carlisle Fluid Technologies' materials and workmanship limited warranty. The use of any parts or accessories, from a source other than Carlisle Fluid Technologies, will void all warranties.

Failure to reasonably follow any maintenance guidance provided, may invalidate any warranty.

For specific warranty information please contact Carlisle Fluid Technologies.

For technical assistance or to locate an authorized distributor, contact one of our international sales and customer support locations.

Region	Industrial / Automotive	Automotive Refinishing
Americas	Tel: 1-800-992-4657 Fax: 1-888-246-5732	Tel: 1-800-445-3988 Fax: 1-800-445-6643
Europe, Africa Middle East, India	Tel: +44 (0)1202 571 111 Fax: +44 (0)1202 573 488	
China	Tel: +8621-3373 0108 Fax: +8621-3373 0308	
Japan	Tel: +81 45 785 6421 Fax: +81 45 785 6517	
Australia	Tel: +61 (0) 2 8525 7555 Fax: +61 (0) 2 8525 7575	

For the latest information about our products, visit [www.carlisleleft.com](http://www.carlisleleft.com).

Carlisle Fluid Technologies is a global leader in innovative finishing technologies.

Carlisle Fluid Technologies reserves the right to modify equipment specifications without prior notice.

BGKTM, Binks®, DeVilbiss®, Hosco®, MS®, and Ransburg® are registered trademarks of Carlisle Fluid Technologies, Inc.

©2023 Carlisle Fluid Technologies, Inc.  
All rights reserved.



16430 North Scottsdale Rd.  
Scottsdale, AZ 85254 USA