

Battery Charge-Discharge Testing System ITS5300 User Manual



Model: ITS5300-IT6000 Version: V1.5



Notices

© Itech Electronic, Co., Ltd. 2022 No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior permission and written consent from Itech Electronic, Co., Ltd. as governed by international copyright laws.

Manual Part Number

ITS5300

Revision

1st Edition: Sept. 2nd, 2022 Itech Electronic, Co., Ltd.

Trademarks

Pentium is U.S. registered trademarks of Intel Corporation.

Microsoft, Visual Studio, Windows and MS Windows are registered trademarks of Microsoft Corporation in the United States and/or other countries and regions.

Warranty

The materials contained in this document are provided "as is", and is subject to change, without prior notice, in future editions. Further, to the maximum extent permitted by applicable laws. ITECH disclaims all warrants, either express or implied, with regard to this manual and any information contained herein, including but not limited to implied warranties the of merchantability and fitness for a particular purpose. ITECH shall not be held liable for errors or for incidental or indirect damages in connection with the furnishing, use or application of this document or of any information contained herein. Should ITECH and the user enter into a separate written agreement with warranty terms covering the materials in this document that conflict with these terms, the warranty terms in the separate agreement shall prevail.

Technology Licenses

The hardware and/or software described herein are furnished under a license and may be used or copied only in accordance with the terms of such license.

Restricted Rights Legend

Restricted permissions of the U.S. government. Permissions for software and technical data which are authorized to the U.S. Government only include those for custom provision to end users ITECH provides this customarv commercial license in software and technical data pursuant to FAR 12.211 (Technical Data) and 12.212 (Computer Software) and, for the Department of DFARS 252.227-7015 Defense. (Technical Data - Commercial Items) and DFARS 227.7202-3 (Rights in Commercial Computer Software or Computer Software Documentation).

Safety Notices

CAUTION

A CAUTION sign denotes a hazard.

It calls attention to an operating procedure or practice that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a CAUTION sign until the indicated conditions are fully understood and met.

WARNING

A WARNING sign denotes a hazard. It calls attention to an operating procedure or practice that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a WARNING sign until the indicated conditions are fully understood and met.



A NOTE sign denotes important hint. It calls attention to tips or supplementary information that is essential for users to refer to

Chapter1	System Overview	. 1
1.1 System	Introduction	. 1
1.2 System	Features	. 1
1.3 Functio	n Introduction	. 1
1.4 Support	ting Hardware	. 2
Chapter2	Test Configuration	. 3
2 1 Brief Int	roduction	3
2.2 Configu	ring Test Program	.4
2.2.1 Col	nfiguring Battery Information	. 4
2.2.2 Co	nfiguring Physical Hardware Device	. 5
2.2.3 Co	nfiguring Channel	. 7
2.2.4 De	ploying Hardware Device	10
2.2.5 Col	nfiguring Test Items	11
2.2.6 Pul	blic Setting	13
2.2.7 Sal	/ing Test Program	24 25
	Charge Test Items	20 25
2.3.7 CC	Charge Test	30 36
2.3.3 CP	Charge Test	37
2.3.4 Dri	ving Cycle Simulation	38
2.3.5 CC	Discharge Test	39
2.3.6 CV	Discharge Test	40
2.3.7 CR	Discharge Test	41
2.3.8 DC	IR Test	42
2.3.9 CC	-CV Charge Test	42
2.3.10 C	P Discharge Test	43 44
2.3.11 0	Control	44 15
2.3.12.10	P-CV Discharge Test	40 46
2.3.13 C	AN Message Control	47
2.3.15 A	CIR Test	 47
2.3.16 Sc	caling (Applicable to 34980)	48
2.3.17 Au	xiliary Channel Settings (Applicable to 34980)	49
2.3.18 Au	ixiliary Power Supply Setting	51
2.3.19 Lo	pop	51
2.3.20 W	ait	52
2.3.21 D	əlay	54 57
2.3.22 R	eset	55
Chapter3	Test Run	57
3.1 Interfac	e Introduction	57
3.2 Running	g Test Program	58
3.3 View Cl	nannels	58
3.4 View Al	arm Information	59
3.5 View Pr	otection Information	59
Chapter4	Data Analysis	61
4 1 Statistic	Analysis	61
4.1.1 Bas	sic Information	62
4.1.2 Wa	veform	62
4.1.3 Tes	t Data	64
4.1.4 Sta	tistical Information	65
4.1.5 CA	N Message	<i>65</i>
4.2 Integrat	ed Query	56
4.3 CAN M	essage Query	56
4.4 Test Da	ta Manager	57
Chapter5	Tool	59
5.1 Databa	se Configuration	69

Content

5.2 Server Settings	
5.3 User Manager	
5.4 Manage Formula	
5.5 System Log	74
5.6 Setting Data Accuracy	75
5.7 Language	75



Chapter1 System Overview

1.1 System Introduction

ITS5000 is a kind of battery test system software. By editing test steps, the user may perform constant current charge, constant voltage charge, and constant current/power/resistance discharge tests. It supports charge/discharge under fixed value and pulse mode, and is available for recycle operation.

During the charge-discharge testing process, the user can conduct all-round protection and alarm settings, and set conditions and select data saving. After test, provide report and other methods to inquire data for data statistic analysis.

1.2 System Features

Advantages of ITS5300 battery charge-discharge testing system are shown in the following:

- It is built based on the WINDOWS test system and adopts the graphical test interface. Therefore, it can be operated easily and conveniently.
- The software supports both Chinese and English operation interfaces
- It has the user permission setting function, thereby preventing error operations of the unauthorized testing personnel
- It is provided with a wizard configuration interface for configuring basic characteristic parameters of the DUT, thereby saving test time.
- Support ITECH multi-series power supply and electronic load, with wide range of optional power;
- Support RS232, USB, CAN and Network interface communication;
- Standard modular design not only makes it easy for hardware extension and follow-up maintenance but also expand its applications;
- Power-off memory protection function (optional)
- Complete charge/discharge protection.
- Support battery internal resistance test.
- ITS5300 Test System integrates an ITECH multi-channel temperature logger used for temperature monitoring.
- A complete alarm and protection setup for effectively preventing overcharge, over-discharge and other unexpected faults;
- It is capable for long-time data record and save;
- The user can display the test curve, and run and save the data curve;
- The user can inquire several test data for convenient comparison;
- The test data form is named automatically by date and time. Various data screening conditions are provided for convenient check;

1.3 Function Introduction

ITS5000 software is divided into the following functions based on modules. The initial login interface displays each module at "Navigation", as shown below.

1





Main module functions:

- **Run:** control the operation and stop of the test program.
- **Config:** configure test programs, including battery information, test equipment, test steps and relevant parameters.
- Data Analysis: include Statistic Analysis, Integrated Query, CAN Message Query, Test Data Management. Statistic Analysis: view statistic analysis report of test data. Integrated Query: view several test data report. CAN Message Query: view the received CAN message. Test Data Management: query and delete the test data.
- **Tool:** includes Database Configuration, Server Configuration, User Management, Formula, System Log, Data Accuracy, and Language.

Database Configuration: configure the database information of system connection.

Server Configuration: configure the server information of system connection.

User Management: configure the user information and user permissions.

Formula: create a new formula, used to be a condition parameter for cut-off conditions, alarm setting and protection setting.

System Log: view system log information.

Data Accuracy: set the interface accuracy and report accuracy. Language: set the language.

1.4 Supporting Hardware

ITS5300 test system is a complete battery test solution provided by ITECH with a series of software and hardware options. You can choose different models based on different measurement ranges.



Chapter2 Test Configuration

This chapter introduces test program configuration methods of ITS5300 test system software.

2.1 Brief Introduction

Test programs and test steps of ITS5300 battery test system are configured in the "Test Configuration" menu, which are saved in the database; during test, the user can select existing test programs in the "Test Run" interface for test.

The test configuration functions are divided into five steps for configuring battery information, test equipment information, channel information, deployment of test equipment and test work steps. The configuration process is performed based on sequence with simple operation and clear process. The user can make step-by-step configuration based on interface prompts.

Click "Test Configuration" menu to enter the Test Program Configuration Interface, as shown below.

ITECH ITS5000	Battery Charge/Di	scharge Test System - Professional Edition	×
Run(<u>R)</u> Config(E)	😅 Data Analysis(D)	% Tool① 🔞	Chan tab
w Open Save Save	Import/Export	Toolbar	Step tab
New		Test program name	Step1> Step3> (Step3> (Step3) (Step3) (Step3)
Setting UUT Name	Slice		
Nominal Voltage(V)		Floating Voltage(V)	
Rated Current(A)		Charging Voltage(V)	
Rated Capacity(Ah)		Weight(Kg)	
Hour Rates(HR)		Volume(L)	8
Comment		Battery basic informatio	ิท
Barcode Setting			
Enable			
Length			
Key Words	Delete		
Key Words	Starting Position		10
		Battery barcode information	I∉ Back Next ▶
jin Name: Admin(Administ	rator)	1% Server: 1	127.0.0.1 A Database: it9320_std_v50(192.168.2.221) 2021/08/20 16:38:28

- Toolbar:
 - New: create a new test program.
 - Open: open already-existed test program files.
 - Save: save the test program files under operation.
 - Save as: save the test program as a new file.
 - Import/Export: Export the configuration content in the Step1~Step5 tab page as a database file or import an existing configuration file.
- Step tab: Step1-Step5.
- Test program name: newly-created or already-opened test program name.
- Battery basic information: input basic information of battery under test.
- Battery barcode information: input barcode information of battery under test.



2.2 Configuring Test Program

In the ITS5300 test system, different hardware platforms are selected based on supporting instruments.

The test program configuration of the IT6000 platform is introduced as below. For detailed hardware introduction, please refer to System Description. The user can create new test program files based on DUT requirements and hardware device configuration. The test program configuration method is introduced below with specific examples.

2.2.1 Configuring Battery Information

This is the first step of test program configuration. The user needs to fill in the battery information, which serves as the search basis in later report viewing and data statistics. The battery name cannot be empty. The user can select to fill in other information based on actual conditions.

1. Click "Test Configuration" to enter the Step1 Interface of Test Program Configuration.

In the Step1 Battery Information Configuration interface, the user can configure battery-related information, as shown below.

Setting			
Battery Name	Slice		
Nominal Voltage(V)			
Rated Current(A)			
Rated Capacity(Ah)		Hour Rates(HR)	
Floating Voltage(V)			
Charging Voltage(V)			
Weight(Kg)			
Volume(L)			
Comment			*
			-

Parameter description:

Cell Name: Name the cell under test. Please keep the name unique as much as possible for further check.

- Nominal Voltage: rated voltage provided for external usage.
- Rated Current: rated current provided for external usage.
- Rated Capacity: rated capacity value of the battery.
- Hour Rates: discharge rate shown by discharging hours.
- Floating Voltage: floating voltage of the battery.
- Charging Voltage: maximum charging voltage of the battery.
- Weight: battery weight. Volume: battery volume.
- 2. When there are several cells under test, the user can distinguish cells with barcodes. In the barcode setting area, the user can input barcode information, as shown below.



Enable	Barcode Length		
arcode Key			Delete
Barcode Key		Initial	Position

- Enable: enable the barcode function.
- Barcode Length: input the total length of Barcode.
- Barcode key: input barcode keyword.
- Initial Position: start bit of barcode key.

If the battery barcode information is set, when running the test, the system will prompt the following interface, prompting you to enter the barcode of the battery under tested.

Status	11 Voltage(V)	Current(A)	apacity(Ah)	y(Wh)	Power(W)	Step 0 Cycles
	Battery Information				×	
	Channel Name	Sequence No.	Part No.	Version	Step	
	11	342795798453495	NO.2	V1.0		
		ОК	Cancel			

Note: You can input the barcode (serial number) data as shown in the figure above by the code scanner or manually inputting it.

2.2.2 Configuring Physical Hardware Device

ITS5300 test system can be configured with several ITECH supporting hardware devices. For details, refer to system description.

During configuration of physical devices, please select power supply, load, measuring instrument and IO card. The user can also configure interface parameters and channel information for each hardware device. Detailed steps are as follows.

1. After configuring battery information, click "Next Step". Enter the step2 Hardware Device Configuring Interface.



TECH ITS5000 Battery	y Charge/Discharge Test Sys	tem - Professional Edition	- 🗆 ×
😳 Run(R) 🔛 Config(E) 🔍 Data /	Analysis(D) 🧏 Tool(T) 🔞		
New Open Save Save As Impor	rt/Export		
New			<step1> <step2> <step3> <step4> <step5></step5></step4></step3></step2></step1>
Device List	UUT		
Power Supply	No. Type Mo	del Interface	Interface Parameters
Meter			
IO Card			
			•
			Aller
	No. Device Alias	Channel Number	Multiplexing
Import	tform IT6000_V1 ·		◀ Back Next ▶
Legis Name: Admin(Administrator)		127.00	1 Detabases it0220 atd v50(127.0.0.1) 2021(10/27.15:14:50

- Device List: list of supporting hardware devices of this system, including power supply, load, measuring instrument and IO card.
- UUT: configured device information and channel information.
- Import/Export: import existing hardware configuration file/export and save configuration files of existing hardware.

Note: The import/export here only involves the contents of the Step2 tab.

- Platform: supporting hardware platform of ITS5300 test system.
- 2. Select and right click "Power", and select "Add Device".

Device List		
Model	Number	Device Alias
IT6000	1	Power
	ок с	ancel

Note: For IT6000 series devices, the ITS5300 system software will automatically turn on the Sense function. Before adding hardware devices, make sure that the Sense terminals are connected to the DUT.



3. In the "Select Device" pop-up box, select the power supply model in the supporting hardware device of existing test system.

If there are several devices with same model, the user can simultaneously add several devices by setting "Count". "Mapping Name" is the mapping name of the instrument channel automatically generated by the system.



4. Click "OK", and the Test Device column appears existing-configured power supply model.

The channel information automatically generated by the system is displayed on the bottom area of the window.

Include mapping name generated based on creating sequence, and channel number automatically generated based on instrument channel count.

New Open Save Save As	Import/Export						
New					(Step)> <step< th=""><th>2) (Step3) (Step</th><th></th></step<>	2) (Step3) (Step	
Device List	UUT						
Power Supply	No.	Туре	Model	Interface	Interface Para	ameters	
	1	Power Supply	IT6000				
IO Card							
IO Card	< No.	Device Alias	Channel	Number	m Allow Multiplexing		
io Card	< No.	Device Alias Power1	Channel 1	Number	Allow Multiplexing		

- No.: The device number in present device column.
- Type: The device type in present device column.
- Model: The device model.
- Interface: existing communication interface for PC connection, which can be selected based on actual conditions.
- Interface Parameters: detailed parameters of communication interface.
- Device Alias: The alias name of device that generated automatically.
- Channel Number: The channel number of device.

Note

- Each device has corresponding channel information. The system automatically generates channel information based on instrument model. For example, IT5601 and IT5102 are multi-way measuring instruments. When such device is selected, the system automatically creates several channels.
- "Allow Multiplexing" is applicable to the situation where one CAN card corresponds to multiple DUTs. If it is not involved, please do not check it.
- 5. Add "Measuring Instrument" and other devices in the same way.

2.2.3 Configuring Channel

There is no one-to-one correspondence between the physical hardware device in the ITS5300 test system and the functional role in the actual channel. For example, IT64 series power supply can be used both as equalized charging power supply and equalized discharging load. Therefore, after configuration of physical hardware device, it is necessary to configure detailed information (such as channel power supply and load) in the system.

At first, the user creates grouping information. Each group can have several



channels, in which, each channel can be created with several test sequences, and each sequence comprises several work steps. The step3 Channel configuration means to configure physical hardware information necessary for all channels during test. Detailed configuration steps are as follows.

1. After hardware configuration, click "Next Step" to enter the step3 Channel Configuring Interface.

TECH ITS5000 Batte	ry Char	ge/Discharge	e Test System - 1	Professional Editi	on		– 🗆 ×
😳 Run(R) 🔡 Config(E) 🔍 Da	ta Analysi	s(D) 🛛 🏆 Tool(1	0 😢				
New Open Save Save As Imp	port/Expo	rt					
New						Step1> <step2> <step3></step3></step2>	<pre> Step4> Step5> </pre>
	No.	Name	Туре	Model	Interface	Interface Parameters	Associa Types
							k
						-	∎Back Next
Login Name: Admin(Administrator)				🕬 Server: 127.0.0.1	🔛 Database:	it9320_std_v50(192.168.2.221)	2021/06/30 15:47:21

Select existed group (such as "1" in the figure above) from the left grouping 2. column. Right click and select "Add Channel", and input test channel name in the "Add Channel" pop-up box.

Add Channel	х
Channel Name	
СН1	
OK Cancel	

If several groups are required during actual test, refer to step 3 for adding. Otherwise, enter step 4.

3. Right click the left device area, and select "Add Group" from the pop-up menu. Input number of groups to be added in the "Add Group" pop-up box, and click "OK".

If "2" is input, 2 groups will be added, and each group is numbered from top to bottom.

Add Group			х
Correct New	-h		
Group Nun	iber		
8			
	ОК	Cancel	

Click "OK" and the system pops up the mapping relationship configuration 4. Copyright © Itech Electronic Co., Ltd. 8



window of all virtual devices.

The user can directly configure device model corresponding to each device type in this window. The user can also skip this step and make additional setting in the left window.

Alias Allocation	х
Device Type	Model
Channel Power Supply	IT6000
Channel E-load	IT6000
Equalizing Source	
Equalizing Load	
Equalizing IO	
Thermometer	
Battery Cell Tester	
ACIR Tester	
ОК	Skip

Note: Equalizing Source / Equalizing Load is a situation where the battery pack contains multiple cells. If your DUT does not involve cells, you do not need to set related parameters.

5. Click "OK" and all device information of the existing channel will be displayed.



Note: For example, "Temp-control Device", "Cooling Device", etc., are customized, optional types of equipment, if your system is not configured with related hardware, you do not need to configure here.

The following is a sample configuration screenshot. Taking the 4-channel IT6000 series equipment as an example, configuring it in the following way



(i.e. setting up 4 groups) can achieve 4 channels of simultaneous runs, which can relatively improve the test efficiency compared to adding 4 channels in a single group (4 channels perform tests in turn).



- The user can independently configure physical device information for the virtual device. Select virtual device type, and right click and select "Add Device". Select mapping relationship between this virtual device and physical device in the pop-up box. The user can also remove existing device information or add associated device. The instructions are as follows.
 - Add device

Configure physical device information for the present selected virtual device.



Add an associated device

Configure associated device information for the present selected virtual device such as series or parallel.

The figure below displays two devices connected in parallel mode, in right of interface shows the device information.



Clean device

Remove the added physical devices from the virtual mapping relationship.

2.2.4 Deploying Hardware Device

After configuration of channel information, click "Next Step" to Step4 check the schematic diagram of existing channel configuration and to deploy test configuration.

Under initial status, the cell count is 1. If the user needs to add cell count, right click the battery and select Setting Cell Count to add cell counts of existing channel or all channels.





On this page, the system automatically numbers each cell starting from 1, and displays corresponding relationship between the battery and the device during measurement. The user can right click the battery for "Custom Rename", "Auto Rename" and "Reset Device".

2.2.5 Configuring Test Items

Each test sequence has a specific test requirement. Based on the test requirement, the user can add different test items for each sequence to form specific test steps.

1. After hardware device deployment, click "Next Step" to enter the Step5 Configuring Test Work Step interface.

TECH ITS5000 Battery Ch	arge/Discharge Test System - Professional	Edition		
🛇 Run(<u>R</u>) 🔛 Config(E) 🔍 Oata Ar	nalysis(D) 🧏 Tool(T) (
New Open Save Save As Import/	Export			
💼 test-6000-V1 🛛 🗮 DBC				Step2> <step3> <step4> <step5></step5></step4></step3>
□ ♥ ■ 1 □ ♥ ■ CH1 ♥ ■ seq1	No. Step 1 CP-CV Discharge 2 CC Charge	Goto Step Rei	marks	Basic Settings Judgement for preventing strike fir Connection Confirm Millerik Kulsen Talmare 1
↓ ↓				Loop Resistance
Channel Information	Work Step Informatic	'n		DBC Configuration Common Parameters Config
	Column	Public Setting	g 🔶	
	Te	st Work S	tep ┥ 🛶	Apply to present sequence X settings
				Back Next M
Login Name: Admin(Administrator)		175 Server: 127.0.0	0.1 🚯 Database: it9320_	std_v50(127.0.0.1) 2021/09/16 15:48:02

Channel information: display channel information configured by the user.



The user can select channel and add test sequence for the channel.

- Work Step Information Column: display information of the work step added in the sequence. The user can select and edit the work step parameter.
- Public Setting: alarm setting, protection setting, sampling rate and protection data condition. After this setting, the user can click "Apply to existing sequence" to uniformly apply this setting to each work step of this sequence.
- Test Work Step: detailed steps forming the test sequence.
- 2. Select CH1 channel, and right click and select "Add Test Sequence". Input test sequence name in the pop-up box.

Add Test Sequ	ence		х
Name			
Seq1			
	ок	Cancel	

 Click "OK" to display existing test sequence information in the left channel information column. Select this test sequence Seq1. The user can edit detailed test work steps for this test sequence. Detailed steps are as shown below.

Add Test Work Step

The test work step serves as the subject of the test program. The "Test Work Step" column at the right bottom corner of the interface provides different test methods. The user can double click the test work step needed to add it into the Work Step Information Column. Several work steps form a test program sequence based on sequence, and are executed based on sequence.

Double click corresponding work step in the "Work Step Information Column" to open detailed parameter setting page of this work step.

- 1. Double click the test work step in the "Test work step" column to add it into the work step information column.
- 2. Double click corresponding test work step in the "Work Step Information Column" to edit work step information.

The work step information divided into five tabs include "Working Mode", "Basic Setting", "Cut-off Conditions", "Alarm", "Protection". Different work steps have different parameter setting interfaces. For detailed description of work step parameters, please refer to **2.3Introduction of Test Items**.

3. After the test step is added, you can customize the execution sequence of the test step and set the sequence number to jump to the next step.

No.	Step	Goto Step	Remarks
1	CC Charge	3	
2	CV Charge	4	
3	CP Charge		
4	CC Discharge		
5	CV Discharge		

Also you can select a test step and right click to select copy, delete, or other operation.



No.	Step		Goto Step		Remarks	
1	CC Charge		3			
2	CV Charge			4	1	
3	CP Charge	*	Cut(Ctrl+X)			
4	CC Discharge					
5	CV Discharge Paste(Ctrl+V)					
			Delete(Delete)			
		ā	All Delete(Ctrl+A,	Delete)		

- 4. After the test step sequence adjustment is completed, double-click a step command to open the edit page of the step to set the parameters (for details, see **2.3Introduction of Test Items**).
- 5. When the parameter settings for the test step are completed, click OK.

2.2.6 Public Setting

The user can set public settings for each sequence at the right side of Step5 interface, and apply the existing setting value to all settings of the sequence.

Settings

Basic Settings		
📝 Judgement for preventing st	rike fire	
📝 Connection Confirm		
📄 Allowable Voltage Tolerance	1	v
🔲 Loop Resistance	1	Ω

- Basic Settings
 - Judgement for preventing strike fire: Identifies whether the system is equipped with an anti-sparking module. If yes, select this item, otherwise, do not select this item.
 - Connection Confirm: Judge the DUT connection state and the voltage value of DUT is 1V, please tick it off in the box always.
 - Allowable Voltage Tolerance: The allowable voltage difference between with charge voltage and battery voltage, if tick it off in the box, if the difference is larger than this setting, the test cannot be executed.
 - Loop Resistance: It is used to set the impedance judgment value in the test circuit. During the execution of the test, the current and voltage in the loop will be collected in real time, and then calculated to obtain the actual impedance value in the loop, which is compared with the set value here. If the set value is exceeded, the test will stop.

DBC

The software provides control interfaces for special devices and systems, and supports the parsing of CAN communication protocols, sending and receiving of messages and handling of related data. The interface is available for import of DBC files related to CAN communication so that the sub-module can automatically parse and handle different protocols.

1. Click the "DBC" button at the left top of the interface. Select to import or create new DBC files.





Select Import: Import existing DBC files from the local.

Select New/Modify: The user can create a new DBC file or select and edit existing DBC file in the system based on original CAN message.

• Import existing DBC file, and select Import. Click "Import" in the popped-up Import box, and select the DBC file.

DBC Import	:		×
Name		Delete	
		20.010	
	Import	Close	

After the importing is completed, close the "DBC Import" window.

You can click "DBC" button at the left top of the interface again, and select "New/Modify" to modify the DBC file, or create a new DBC file.

New/Modify DBC File		×
File Name	•	
OK	Canad	
OK	Cancel	

- Fill in the new file name in the window, and click "OK" to create new DBC file and enter the editing status.
- Select the file name in the window, and click "OK" to edit the existing DBC file.
- Create a new DBC file.
 - a) Fill in the new file name in the window, and click "OK" to enter the



editing status.

The user can edit and modify the real-time messages or add new message information in the Editing interface.

2BC Editor - 1[New DBC File]							×
Network Nodes Messages	Name	Address	Comment				
					ок	Apply	Cancel

b) Right-click "Network Nodes" to add a node and other operations.

्र्यू Network Nodes			
Message	New Network		
_	Сору		
	Paste		
	Delete		

c) Edit the details of the network node.

Network		×
Name	New_Node_1	
Address	0x0	
Comment		
	OK Cance	;I

d) Right-click "Messages" to add a message and other operations.

- Messag	es	
	New Message	
	Сору	
	Paste	
	Delete	

e) Edit the details of the message.



Message		X
Definition Transmi	tters Layout	
Name	New_Message_1	
ID-Format	CAN Standard •	
ID	0x0	
DLC[Byte]	8	
Cycle Time[ms]	0	
Comment		
		OK Cancel

f) Select the **Transmitters**, right click on the blank and select **Edit**.

Message			
Definition	Transmitters	Layout	
Name		Address	
		Edit	
		Remove	
		Remove All	

g) Select the network node.

Network	×
Name	Address
New_Node_1	0x21
New_Node_2	0x22
	OK Cancel

- h) After the message details are set, click **OK**.
- i) Right-click the message information to add signals and other operations.

🚐 🚑 Network N	lodes				
🚊 📻 Messages					
<mark>,</mark> New_N	New Massage				
L	New Nessage				
	New Signal				
	Edit Message				
	Сору				
	Paste				
	Delete				

j) Edit the detailed signal information.



Signal								×
Definition	Multiple	xing	Receivers	Valu	e Descriptions			
Name	[New_	_Signal_1]
Length[Bit]	1			Startbit	0]
Byte Ore	der	Moto	orola	•	Unit]
Value Ty	/pe	Signe	ed	•	Initial Value	0]
Factor	[0			Offset	0]
Minimur	m	0			Maximum	0]
Commer	nt							
							ОК	Cancel

- k) After the signal details are set, click OK.
- After the above information is set, click OK on the DBC Editor interface.
- 2. DBC file configuration.
 - Select the test sequence in the left column. If the test sequence is not created, it is unable to execute the DBC configuration.
 - Click "DBC Configuration" in the public configuration, and set the DBC configuration for this test sequence.
 - Response Message-Signal Mapping

Indicates that the message information from the battery is continuously received.

The user can configure corresponding message name and corresponding signal name based on the real-time command function. After the configuration is completed, tick and initiate this option.

DBC C	onfiguration										×
Selec	Select DBC File SPA4110_ConfigurationsSPA3_Rear1CANCf 💌										
Respo	nse Message-Signal N	apping Request Messag	e-Signal	Mapping	Request-Respon	se Mapj	ping	Åt	tribute Mapp	ing Error (Configuration Cy 🔹 🕨
	Instruction	Message		Signal			R/W		Enabled	Get Value	Comment
۲×	GetCellVolt		•			•	r	•			Query Cell Volt
~	GetCellTemp		•			•	r	•			Query Cell Temp
V	GetNeedAdjustVolt		•			-	r	•			Query Current Adjust
V	GetNeedAdjustCurr		•			-	r	•			Query Current Adjust
~	GetNeedAdjustRes		-			-	r	•			Query Current Adjust
~	GetNeedAdjustPow		-			-	r	•			Query Current Adjust
~	GetNeedAdjustDC		•			•	r	•			Query Current Adjust
~	GetNeedAdjustDC		•			-	r	•			Query Current Adjust
×	GetNeedAdjustDC 🗢		•			•	r	•			Query Current Adjust
•								_			+
			Reset		OK	Cancel					

Request Message-Signal Mapping

Indicates that a request message needs to be sent before receiving a message, and the battery sends a response message after receiving this request message.



DBC Co	nfiguration								×
Select	DBC File SPA4110_Configure	ations	SPA3_Rear1CANCf 👻						
Respons	se Message-Signal Mapping	Reque	st Message-Signal Mapping	Reques	t-Response Mapping	Attribute Mapp	ping	Error Configuration	Cy 🔹 🕨
	Instruction		Message		Signal		Valu	ue	
./ v 6	GetCellVolt	•	DEMDevRear1Fr01	-	DftlCtrlInfo1Byte0	-	32		
VG	GetCellTemp			•		-			
VG	GetNeedAdjustVolt			•		-			
VG	GetNeedAdjustCurr			•		-			
VG	GetNeedAdjustRes			•		-			
VG	GetNeedAdjustPow			•		-			
VG	GetNeedAdjustDChaVolt			-		-			
VG	GetNeedAdjustDChaCurr			-		-			
VG	GetNeedAdjustDChaPow			-		-			
			Reset	OK	Cancel				

Request-Response Mapping

Configure the mapping relationship between request message and response message.

Right-click in the blank and select Add to configure the request-response message mapping relationship.

Select DBC File [SPA4110_ConfigurationsSFA3_RearICANCF • Response Message-Signal Mapping Request Mapping Request Request Request Response DEMDevRear1Fr01 •	Cy 🔹 🕨
Response Message-Signal Mapping Request Message-Signal Mapping Request-Response Mapping Attribute Mapping Error Configuration Request Response DEMDevRear1Fr01 IDEMtoETCXcpFr01 •	Cy 🔹 🕨
Request Response DEMDevRear1FrO1 DEMtoETCKcpFrO1	
DEMDevRear1FrO1 DEMtoETC%cpFrO1	
Reset OK Cancel	

• Configure "Attribute Mapping". If the user redefines the property in the DBC file, it is necessary to configure the corresponding mapping relationship in the "Attribute Mapping" tab. If the definition in the DBC file is consistent with the naming method of the system, no setup is required.



DBC Configuration						×
Select DBC File SPA4110_Configure	ationsSPA3_Rear1CANCf 💌					
Response Message-Signal Mapping	Request Message-Signal Mapping	Requ	iest-Response Mapping	Attribute Ma	pping	Error Configuration Cy 4 >
Lable	DBC Attribute Name		Attribute Type		Comme	nt
GenMsgSendType	Baudrate	-	DBC	-	Messa	ge Send Type
GenMsgCycleTime		-		•	Messa	ge Cycle Time
	Reset	OK	Cancel			
		- UN	Juictz			

Label: the property name of the message sending type of the DBC file in the system, and the property name of the recycled sending time interval of messages.

DBC Attribute Name: the name in the actual DBC file to which the property corresponds, which can be selected based on the DBC definition.

Attribute Type: the objective type to which the property belongs, which can be automatically displayed based on selected property.

Comment: the explanation of the property.

At the same time, you can customize the **Label** and **Comment** of **Message Signal Mapping** and **Attribute Mapping** with the built-in tools of the system.

i. Enter the system software installation directory, for example:

D:\Program Files (x86)\ITECH\ITS5000\ITS5000 Client\StepPlugIn\IT6000

- ii. Run the DBCConfigBase.exe
- iii. Click Import and select DBCC_BA.cxml
- iv. Select the **Command** or **Attribute** tab and click **Add** to add and set.

D:\Program Files (x86)\ITECH\ITS5000\ITS5000 Client\StepPlugIn\IT6000\DBCC_BA.cxml - DBC Config Base 👘 💷 💻 🗮								
🕑 Import 🛃 Exp	ort 💾 Save 🕂 Add 🌔	🗙 Delete 🍝 Clear 🛛	🕖 Exit					
Command Attribute		An - 1 An 199 (A) 12 - 1						
Command Name	说明(简体中文)	說明 (繁體中文)	Comment (English)					
GetCellVolt	获取单体电压	獲取單體電壓	Query Cell Volt					
GetCellTemp	获取单体温度	獲取單體溫度	Query Cell Temp					
GetNeedAdjustVolt	获取当前需要调整的电压值	獲取當前需要調整的電壓值	Query Current Adjust Voltage					
GetNeedAdjustCurr	获取当前需要获取的电流值	獲取當前需要調整的電流值	Query Current Adjust Current					
GetNeedAdjustRes	获取当前需要调整的电阻值	獲取當前需要調整的電阻值	Query Current Adjust Res					
GetNeedAdjustPow	获取当前需要调整的功率值	獲取當前需要調整的功率值	Query Current Adjust Pow					
test	test	test	test					
11 页面 结果								
-								
2.2.5 Comiguni								
2.2.7 Saving Tec								
•		III	At-the					



- v. When the setup is complete, click **Save**.
- vi. Close the **DBCConfigBase.exe**
- vii. Click **DBC** on the **Step 5** interface and a user-defined **Label** will appear.



• Configure "Error Configuration": define the fault message information in this system.

DBC Configuration			:
Select DBC File SPA4110_Configurati	onsSPA3_Rear1CANCf 👻		
Response Message-Signal Mapping Re	quest Message-Signal Mapping Request-Resp	onse Mapping Attribute Mapping	Error Configuration Cy 4
🕀 Add 🔹 🛞 Delete 🔲 Select Al	1/Not		
DEMDevRear1Fr01			~
		₩ 4~DftlCtrlInfolByte ₩ 4~DftlCtrlInfolByte	2 5
	Reset OK	Cancel	

Click "Add", and select the name of message to be added. By default, the system will tick all message signals. The user can select specific message signal as the fault message information based on requirements. The system will stop test after receiving the fault message.

Select the message signal, and click "Delete" to delete the message information.

• Configure "Cyclic Message". If the user wants to modify the message cycle time, the user can directly define the message recycle time in this tab. After the configuration is completed, the message cycle will be subject to this configuration.



DBC Configuration					×
Select DBC File SPA4110_Configu	rationsSPA3_Rear1CANCf 👻				
Request Message-Signal Mapping	Request-Response Mapping	Attribute Mapping	Error Configuration	Cyclic Message	4 >
Message Name	Cycle Time(ms)				
DEMDevRear1Fr01	10				
	Reset	OK	Cancel		

Right click the blank and select "Add", select the required message name in the drop-down list to set the recycle interval time.

Select the message signal, and right click "Delete" to delete this message information.

• After the above information is set, click OK on the DBC Configuration interface.

Common Parameters Config

• "Basic"				
Common Parameters Config				×
	Data Saving Conditions			
Basic	I Time	1.0000 🚔	s	
Alarm	© ∆v	0.0000	V V	
	$\odot \Delta I$	0.0000	A	
Protect	© ∆c	0.0000	Ah	
	Semple Rate			
	Channel Sample	1.000	s	
	Temperature Sample	1.000 🚔	z	
	Cell Sample	1.000 🚔	s	
	Auxiliary Channel Sample			
	Voltage Current Sample	1.000 🚔	5	
	Temperature Sample	1.000 🚔	s	
	CAN Message	1.000 🚔	s	
		_		
	0K Cano	cel		

Select one of the time, voltage difference, current difference, and capacity difference, and set the condition value for trigger data saving. When the condition is met, the system will automatically save the test data.

The setting here is the same as the "Data Saving Conditions" function tab in each test item "Basic Setting", here is the unified setting (after applying to the sequence). You can also set each test item separately, and the priority in the test item is higher.



-Data Saving Condi	tions
Time	1.0000 🔿 s
	0.0000 🔹 V
	0.0000 Å
Δc Δ	0.0000 Åb
CC Charge	x
Working Mode Basic	Setting Sample Set Cut-Off Conditions Goto Conditions Al ()
	BMS Uption Real-time Adjustment According to BMS
	Cell Sample for BMS
	Equalizing Charge
	Voltage 0.000
	Data Saving Conditions
	O Time 1.0000 ▲ s
	ΔV 0.0000 ΔV V
	ΔI 0.000 A
	Ο ΔC 0.0000 Ah
	OK Cancel
Parameters	Description
Time	Time interval for saving data, indicating that
	data is saved every X seconds, wherein, X is a
A.). (setting value
ΔV	Compare sampling voltage values. When
	difference between them meets setting value,
ΔI	Compare campling current values When
	difference between them meets setting value
	the data is saved
٨C	Compare sampling capacity values When
	difference between them meets setting value
	the data is saved.

The setting here is the same as the "Sample Set" function tab in each test item, here is the unified setting (after applying to the sequence). You can also set each test item separately, and the priority in the test item is higher.

Sample Rate				
Channel Sample	1.000	s		
Temperature Sample	1.000	z		
Cell Sample	1.000	s		
Auxiliary Channel Sample				
Voltage Current Sample	1.000	S		
Temperature Sample	1.000	s		
CAN Message	1.000	s		



Working Mode | Basic Setting | Sample Set | Cut-Off Conditions | Goto Conditions | Al

Shannel Sample	1.000	÷ s
Temperature Sample	1.000	÷ s
Cell Sample	1.000	s
Auxiliary Channel Sampl	e	
Auxiliary Channel Sampl Voltage Current Sample	e 1.000	S
Auxiliary Channel Sampl Voltage Current Sample Temperature Sample	e 1.000 1.000	s

Parameters	Description
Channel Sample Rate	Channel Sample Rate
Temperature Sample Rate	Temperature Sample Rate
Cell Sample Rate	Cell Sample Rate
Voltage Current Sample	Auxiliary Channel Sample
Temperature Sample	
CAN Message	

• Alarm/Protection

The parameter settings for the alarm and protection functions are basically the same. The system determines whether an alarm or protection is generated based on the trigger condition and the set value. The difference is that after the alarm is triggered, the alarm information is generated, but the test process is not interrupted (for example, the output of the power supply device will not be turned off); after the protection is triggered, the test will be stopped (for example, the output of the power supply device is turned off).

The setting here is the same as the "Alarm"/"Protection" function tab in each test item, here is the unified setting (after applying to the sequence). You can also set each test item separately, and the priority in the test item is higher.

Common Paramet	ers Config						×
	Channel		CAN Msg				
Basic	🔲 Over Voltage	0.000 × V	Enable	Alias	Type	Operator	
Alarm	🔄 Under Voltage	0.000 × V					
	📄 Over Current	0.000 Å					
Protect	🔲 Over Capacity	0.000 🐥 Ah					
	🕅 Over Power	0.000 × Y					
	Δ٧	0.000 × V					
		0.000 Å					
	Cell						
	🔲 Over Voltage	0.000 × V					
	📃 Under Voltage	0.000 ×					
	🔲 Over TEMP	0.000 × °C					
	Σ Δ۷	0.000 × V					
			•	m			F
			0K Can	cel			



	Channel		CAN Msg			
3	🔲 Over Voltage	0.000 × V	Enable	Alias	Туре	Operator
m	🔲 Under Voltage	0.000 γ				
	📃 Over Current	0.000 A				
ct	🔲 Over Capacity	0.000 🌲 Ah				
	🔲 Over Power	0.000 🚔 W				
	□ △ V	0.000 🗼 V				
		0.000 A				
	Cell					
	🔲 Over Voltage	0.000 🗼 V				
	🔲 Under Voltage	0.000 🛓 V				
	🔲 Over TEMP	0.000 × °C				
	ΔV	0.000 🔺 V				
	Protect Delaw	500.000 🚔 🔤				
	Trotect Deray		•			

Parameters	Description
Channel Over Voltage	If channel voltage is higher than voltage setting
	value, the system gives alarm/protection.
Channel Under Voltage	If channel voltage is lower than voltage setting
	value, the system gives alarm/protection.
Channel Over Current	If channel current is higher than current setting
	value, the system gives alarm/protection.
Channel Over Capacity	If channel capacity is higher than capacity
	setting value, the system gives
	alarm/protection.
Over Power	If channel power is higher than power setting
	value, the system gives alarm/protection.
Channel AV	If channel voltage fluctuation higher than
	voltage setting value, the system gives
	alarm/protection.
Channel Al	If channel current fluctuation higher than
	current setting value, the system gives
	If DUT voltage is higher then voltage acting
Cell Over voltage	I DOT voltage is higher than voltage setting
Coll Linder Voltage	If DUT voltage is lower then voltage acting
Cell Under Voltage	I DOT voltage is lower than voltage setting
Coll Over Temperature	If DLT temporature is higher than temporature
Cell Over Temperature	softing value the system gives
	alarm/protection
	Compare sampling voltage value and highest
	voltage value during test When difference
	between them meets setting value, the system
	gives alarm/protection.
Protect Delay	Delay time of system protect

2.2.7 Saving Test Program

After test program configuration is completed, the user can click "Save" or "Save As" in the Tool column to save the configured test program or save it as another file name. If the existing test program is a newly-created test program, the user needs to input the test program file name at the time of saving.



2.3 Introduction of Test Items

The test sequences in the test program are formed by different test work steps based on sequence. Each work step is a step. The user needs to edit values for each step based on test requirements. Detailed description will be given below for parameters and editing methods of all test work steps in this system.

For the steps related to the battery charge and discharge test, the parameter settings of the "Basic Setting", "Cut-off Conditions", "Alarm", and "Protection" tabs are identical. The following is a general introduction to the setting methods of these types of parameters.

Attention: The test item involves the setting parameters of charging and discharging current values, which need to be distinguished, charging current shall be set to positive value and discharging current shall be set to negative value.

• **Pulse mode:** When charging and discharging test items include pulse mode, in addition to supporting the editing mode of the test item interface, it also supports importing Excel.

When selecting "Excel Import",	the newly created	template parameters are
introduced as follows:		

Parameter	Description
Sub Wave Count	The number of wave files, keep the default settings, no need to modify.
Waveform1 Type	Waveform type, keep the default setting, no need to modify.
Step Count	The total number of steps. The number set here must be consistent with the number of Value rows below.
Mode	The working mode of the device (CC/CV/CP), keep the default setting, no need to modify.
LIMIT+(V)	The maximum value of output voltage, that is, the set value of Vh , represents the rated voltage value of battery charging.
LIMIT-(V)	The minimum value of the output voltage, that is, the set value of VI , represents the cut-off voltage value for battery discharge.
Repeat	The number of repetitions of List, setting range: 1~65535.
value(A) / value(W)	The current value or power value of a single step.
	Note: The charging current/power is set to a positive value, and the discharging current/power is set to a negative value.
Slew Rate(s)	The slope of a single step.
Pulse(s)	The pulse width of a single step.



• **Basic Setting**: configuring the basic settings for work step, include Equalizing charge setting, sample rate and data saving conditions.

Working Mode Basic Setting Sample Set Co BMS Option Real-time Adjustmen	at-Off Conditions Goto Conditions Al 4
Cell Sample for BMS Equalizing Charge	
Voltage	0.000 (A) V 0.000 (A) V
-Data Saving Conditions	1.0000 🚖 s
 Δv ΔI Δc 	0.0000 A V 0.0000 A A
	ral
OK	Cancel

Item	Parameter	Description
RMS Option	Real-time Adjustment According to BMS	Tick it off in the box indicates the BMS system adjusts the charging/discharging voltage value or current value in real time.
ыма орнон	Cell Sample for BMS	Whether the voltage of the battery chip is read by the BMS system. If this item is selected, it is read from the BMS system, otherwise it is read from the IT5102.
Fauglizing	Enable	Indicates whether the charge equalization function is enabled during the charge test. If this option is checked, the charge equalization function is enabled.
Charge	Voltage	Indicates the voltage value when the charge equalization function is performed.
	ΔV	Indicates the difference between the maximum voltage and the minimum voltage of the battery in the circuit during the charge test.
	Time	Time interval for saving data, indicating that data is saved every X seconds, wherein, X is a setting value
Save the	ΔV	Compare sampling voltage values. When difference between them meets setting value, the data is saved.
Data Condition	ΔΙ	Compare sampling current values. When difference between them meets setting value, the data is saved.
	ΔC	Compare sampling capacity values. When difference between them meets setting value, the data is saved.



Yorking Mode	Basic Setting	Sample Set	Cut-Off C	Conditions	Goto	Conditions	Al 🔸 🕨	
	-Sample	Rate						
	Channe	l Sample		1.000	s			
	Temper	ature Sample		1.000	s			
	Cell S	ample		1.000	s			
	Auxili	ary Channel S	ample					
	Voltag	e Current Sam	nple	1.000	z			
	Temper	ature Sample		1.000	s			
	CAN Me	ssage		1.000	s			

Item	Parameter	Description		
	Channel Sample	Sampling rate of the channel		
Sample Rate	Temperature Sample	Temperature sampling rate		
	Cell Sample	ell Sample Sampling rate of cell		
Auxiliary Channel	Voltage Current Sample	Auxiliary channel voltage and current sampling interval		
Sample	Temperature	Temperature sampling interval of		
	Sample	auxiliary channel		
	CAN Message	CAN message sampling interval		

• **Cut-off Conditions**: configure the cut-off conditions for work step, right click in blank and add the condition.

Working Mode Basic	Setting Sample Set Cut-Off Condition	ns Goto Conditions Al 🌁 🗎
Logic Condition 0	R 🗸	
Common Conditions	Formula CAN Message Variation Rate	
Type	Set Value	Delete
Cut-Off Time	3600.000 🚖 s 🔻	×

Note: Right-click on the blank space under the "Common Conditions", "Formula", "CAN Message", "Variation Rate" tabs and select "Add" to select the parameter settings for adding multiple cut-off conditions. The parameters displayed by different test items may be different. The following table covers all the descriptions of the cut-off condition parameters.



Item	Parameter	Description				
nom		Indicates that there is "AND" relationship				
Logic		between several cut-off conditions				
Condition	OR	Indicates that there is "OR" relationship				
Contaition		between several cut-off conditions.				
	Cut-Off Time	The test is stopped when the cut-off time				
		meets the setting value.				
	Cut-Off	The test is stopped when the voltage meets				
	Voltage	the setting value.				
	Ũ	Sampling from IT6000 channel				
	Cut-Off	The test is stopped when the current meets				
	Current	the setting value.				
		Sampling from IT6000 channel				
	Cut-Off	The test is stopped when the capacity meets				
	Capacity	the setting value.				
		Sampling from IT6000 channel				
	Cut-Off Energy	The test is stopped when the energy meets				
		the setting value.				
		Sampling from IT6000 channel				
	Over Power	The test is stopped when the over power				
		meetings the setting value.				
Common		Sampling from 116000 channel				
Conditions	Voltage	I he test is stopped when the voltage				
	Fluctuation	fluctuation meets the setting value.				
	Current	The test is stepped when the surrent				
	Eluctuation	The test is stopped when the current				
	Fluctuation	Sampling from IT6000 channel				
		The test is stopped when the cell voltage				
	Cell Vollage	meets the setting value				
		Sampling from BMS or data recorder				
	Cell	The test is stopped when the cell temperature				
	Temperature	meets the setting value.				
		Sampling from BMS or data recorder				
	Cell ΔV	Compare the existing sampling voltage value				
		with the maximum voltage value during the				
		test process. The test is stopped when the				
		difference of compared voltages meets the				
		setting value.				
		Sampling from BMS or data recorder				
Formula	Name	The name of selected formula, which is				
		defined in the "Iool" menu.				
	Operator	I he operator to be followed by the formula				
	Set Value	The setting value of cut-off conditions. The				
		test is stopped when the formula after				
	Maaaaaa	calculation meets the setting value.				
CAN	wiessage	The message name in the selected CAN				
wessage	Operator	The operator to be followed in the CAN				
		message				
	Set Value	The setting value of cut-off conditions. The				
		test is stopped when the CAN message after				
		calculation meets the setting value				
Variation	ΔTime	Set time range				
Rate	ΔVoltage	The test is stopped when the voltage change				
		rate within the set time meets the setting				
		value.				



Item	Parameter	Description
	∆Energy	The test is stopped when the energy change rate within the set time meets the setting value.
	ΔCapacity	The test is stopped when the capacity change rate within the set time meets the setting value.
	∆Temperature	The test is stopped when the temperature change rate within the set time meets the setting value.

• **Goto Conditions**: Indicates the relationship of going to the next step when the jump conditions are met. You can choose which step to jump to according to the set jump conditions.

	Sample Set	Cut-Off C	onditions	Goto Conditions	Alarm	Protection		4
	Internal C	onditions	CAN F	ormula				
	Name			Set Value	Uni t		Goto	
l								
l								

Right-click in an empty area and select "Add" to add a Goto Condition.

Item	Parameter	Description		
Internal	Name	Internal condition name. Not editable.		
Conditions	Set Value	Set the value of the Goto condition, that is, jump to the specified test item when the measurement reaches this value.		
	Unit	The unit corresponding to the set value of the Goto condition.		
	Goto	When this condition is met, it is used to specify which test item to jump to for execution.		
CAN	Message	The message name in the CAN message.		
	Operator	The operator to be followed in the CAN message		
	Set Value	The set value of the Goto condition. When the CAN message meets the set value after operation, it will jump to the specified test item for execution.		
	Goto	When this condition is met, it is used to specify which test item to jump to for execution.		
Formula	Name	The name of the expression, which is defined in the Tool menu.		
	Operator	The operator to be followed by the formula		
	Set Value	The set value of the Goto condition. When the expression matches the set value after operation, it will jump to the specified test item for execution.		



Item	Parameter	Description
	Goto	When this condition is met, it is used to specify
		which test item to jump to for execution.

• Alarm: configure the alarm conditions. The user can directly select the general alarm items, and set condition values. The user can right click the Formula tab to select Add. When the formula after calculation meets the setting value, an alarm is generated.

Basic Setting Sample Set Cut-Off Condi	tions Goto Conditions Alarm Protecti
Alarm Formula CAN	
Check	Set Value
Channel Over Vol	tage 0.000 📩 V
🔲 Channel Under Vo	ltage 0.000 🛓 V
Channel Over Cur	rent 0.000 🔺 A
Channel Over Cap	acity 0.000 🛓 Ah
🔲 Over Power	0.000 ×
□ Channel △V	0.000 🔺 V
□ Channel △I	0.000 🔺 A
🔲 Cell Over Voltag	se 0.000 🔺 V
🔲 Cell Under Volta	age 0.000 ▲ V
🔲 Cell Over Temper	ature 0.000 📩 °C
Cell 🛆 V	0.000 🔺 V
OK	Cancel

Alarm	Description				
Channel Over Voltage	If channel voltage is higher than voltage setting value, the system gives alarm information.				
Channel Under Voltage	If channel voltage is lower than voltage setting value, the system gives alarm information.				
Channel Over Current	If channel current is higher than current setting value, the system gives alarm information.				
Channel Over Capacity	y If channel capacity is higher than capacity settin value, the system gives alarm information.				
Over Power	If channel power is higher than power setting value, the system gives alarm information.				
Channel ΔV	If channel voltage fluctuation higher than voltage setting value, the system gives alarm information.				
Channel ∆l	If channel current fluctuation higher than current setting value, the system gives alarm information.				
Cell Over Voltage	If DUT voltage is higher than voltage setting value, the system gives alarm information. When Cell Sample for BMS is selected, the corresponding message getcellvolt				



Alarm	Description
Cell Under Voltage	If DUT voltage is lower than voltage setting value, the system gives alarm information. When Cell Sample for BMS is selected, the corresponding message getcellvolt
Cell Over Temperature	If DUT temperature is higher than temperature setting value, the system gives alarm information. When Cell Sample for BMS is selected, the corresponding message getcelltemp
Cell ΔV	Compare sampling voltage value and highest voltage value during test. When difference between them meets setting value, the system gives alarm information. When Cell Sample for BMS is selected, the corresponding message getcellvolt

Basic Setting	Sample Set	Cut-Off Conditions	Goto Conditions	Alarm	Protecti 🔹 🕨
Alarm Formula CAN					
Enable	Alias	Function	Oper	ator	Set Value
Formula		Do	agription		

Formula	Description			
Enable	Choose whether to enable the formula (the			
	expression is defined in the "Tools" menu)			
Alias	Alias of formula			
Function	The name of the formula			
Operator	The operator that the formula must follow			
Set Value	The set value of the alarm condition. When the			
	formula meets the set value after calculation, an			
	alarm will be generated			

Basic Setting	; Sample Set	Cut-Off Conditions	Goto Conditions	Alarm	Protecti 🔹 🕨
Alarm For	mula CAN				
Enable	Alias	Type	Op	erator	Set Value
V	CanWarn1	GetCellVolt	>	-	0
			· · · · ·		

The setting method of CAN message trigger alarm:

1. Click the "Common Parameters Config" button on the right side of the interface.



Basic Settings	
Judgement for preventing strike fire	
🔽 Connection Confirm	
Allowable Voltage Tolerance	v
Loop Resistance	
	77
DBC Configuration	
	_
Common Parameters Config	
•	•
Apply to present sequence	
🖌 Settings 🛛 🏭 Step	

2. Select "Basic", "Alarm" or "Protect" in the opened interface.

Common Parameters Config			×
	Data Saving Conditions		
Basic	Time	1.0000 🚔 s	
Alarm	○ △V	0.0000 🛓 γ	
	$\odot \Delta I$	0.0000 Å	
Protect		0.0000 Åh	
	Sample Rate		
	Channel Sample	1.000 🚖 s	
	Temperature Sample	1.000 💉 s	
	Cell Sample	1.000 🚖 s	
	Auxiliary Channel Sample		
	Voltage Current Sample	1.000 🚔 s	
	Temperature Sample	1.000 🚖 s	
	CAN Message	1.000 🔹 s	
	OK Can	cel	

	Channel	CAN Msg			
Dasic	Channel Over Voltage 000 🐥 V	Enable	Alias	Type	Operator
il arm	Channel Under Voltage 100 🐥 V		CanWarn1	GetCellVolt	>
TTT OF M	Channel Over Current 000	V	CanWarn2	GetCellTemp	>
			CanWarn3	GetNeedAdjus	>
	Channel Over Capacity 100 V Ah				
	Over Power 0.000 🖨 W				
	Channel △V 0.000 ↓ V				
	Channel ∆I				
	Cell Over Voltage U. UUU 🚔 V				
	Cell Under Voltage 0.000 🔺 V				
	📃 Cell Over Temperature 💷 🔶 °C				
	□ Cell AV 0.000 ▲ V				
		•			


3. Right-click in the blank area on the right to add the alarm settings of the CAN message.

☑ CanWarn1 GetCellVolt > ☑ CanWarn2 GetCellTemp >
✓ CanWarn2 GetCellTemp >
🔽 CanWarn3 GetNeedAdjus >

4. Select the message name and click "OK".



- 5. Set the "Alias", "Operator" and other parameters, and set the alarm trigger conditions.
- 6. After setting is complete, click "Apply to present sequence" and click "OK".



7. At this time, open the "Alarm" in the test item, and you can see the newly added CAN message options.



Protection: set the protection conditions. The user can directly select the general protection items, and set condition values. The user can right click the Formula tab to select Add. When the formula after calculation meets the setting value, a protection is generated.

Sample Set Cut-Off Co	nditions	Goto Conditions	Alarm	Protection	4 >
Protection Formula (CAN				
(Check		Set Value		
[Channel	Over Voltage	0.000	÷ V	
[Channel	Under Voltage	0.000		
I	Channel	Over Current	0.000	Å	
[Channel	Over Capacity	0.000	Åh	
[Over Pow	er	0.000	▲	
I	Channel .	ΔV	0.000		
[Channel		0.000	Å	
[Cell Ove	r Voltage	0.000	<u>▲</u> V	
[🗌 Cell Und	er Voltage	0.000	<u>↓</u> V	
[Cell Ove	r Temperature	0.000	D, L	
[Cell ∆V	,	0.000	× V	
I	rotect Del	ay	0.500	s s	
		OK Ca	ncel		

Protection	Description
Channel Over Voltage	If channel voltage is higher than voltage setting value, the system gives protect information.
Channel Under Voltage	If channel voltage is lower than voltage setting value, the system gives protect information.
Channel Over Current	If channel current is higher than current setting value, the system gives protect information.
Channel Over Capacity	If channel capacity is higher than capacity setting value, the system gives protect information.
Over Power	If channel power is higher than power setting value, the system gives protect information.
Channel ΔV	If channel voltage fluctuation higher than voltage setting value, the system gives protect information.
Channel ∆l	If channel current fluctuation higher than current setting value, the system gives protect information.
Cell Over Voltage	If DUT voltage is higher than voltage setting value, the system gives protect information. When Cell Sample for BMS is selected, the corresponding message getcellvolt
Cell Under Voltage	If DUT voltage is lower than voltage setting value, the system gives protect information. When Cell Sample for BMS is selected, the corresponding message getcellvolt



Protection	Description
Cell Over Temperature	If DUT temperature is higher than temperature setting value, the system gives protect information. When Cell Sample for BMS is selected, the corresponding message getcelltemp
Cell ∆V	Compare sampling voltage value and highest voltage value during test. When difference between them meets setting value, the system gives protect information. When Cell Sample for BMS is selected, the corresponding message getcellvolt
Protect Delay	Delay time of system protect

Note: Formula and CAN are the same setting method with Alarm tab.

2.3.1 CC Charge Test

Parameter Description:

Working Mode: configure the voltage and current value

CC Charge						×
Working Mode	Basic Setting	Sample Set	Cut-Off	Conditions	Goto Condi	tions Al 🔸 🕨
Working	Mode CC Chargi	ng	•			
	Wa	rking Volta	ge	0	٧	
	cc	:		0	A	
		<u> </u>		ICET		

Item	Parameter	Description
	CC	The current value in CC charging mode
CC Charging	Working	The voltage limit value in CC charging mode
	Voltage	
	Pulse Edit / Import Excel File	Choose one of the two options. When you select "Pulse Edit", you need to customize the following parameters; when "Import Excel File" is selected, "New" an Excel template, edit parameters, and import into the interface.
Pulse	Cycle Number	Number of loops performed in existing list.
Charging	Charging Voltage	Voltage value of the single step in the list.
	Current	Current value of the single step in the list.
	Pulse	Pulse width of the single step in the list.
	Slew Rate	Single step rise/fall time during pulse charging.



Item	Parameter	Description
	Add	Add a single step.
	Insert	Insert a single step in existing step.
	Delete	Delete selected single step.
	Clear	Clear all steps in the list.
RAMP	Working	Ramp charging voltage value
Charging	Voltage	
	Starting	Starting current value of ramp charging
	Current	
	Cut-off	Cut-off current value of ramp charging
	Current	
	Rise Time	Ramp charging time

2.3.2 CV Charge Test

CV Charge						×
Working Mode	Basic Setting	Sample Set	Cut-Off Cond	itions	Goto Conditions	Al arr 🔸 🕨
Working Mc	de CV Charg	ing 🔻				
	Work	ing Current	0	Å		
	CV		0	v		
		40	Cance	1		

Item	Parameter	Description
CV Charging	Working Current	The current limit value in CV charging mode
	CV	The voltage value in CV charging mode
Pulse Pulse Edit Charging / Import Excel File		Choose one of the two options. When you select "Pulse Edit", you need to customize the following parameters; when "Import Excel File" is selected, "New" an Excel template, edit parameters, and import into the interface.
	Cycle Number	Number of loops performed in existing list.
	Charging Voltage	Voltage value of the single step in the list.
	Current	Current value of the single step in the list.
	Pulse	Pulse width of the single step in the list.



Item	Parameter	Description				
	Slew Rate	Single step rise/fall time during pulse charging.				
Add		Add a single step.				
	Insert	Insert a single step in existing step.				
	Delete	Delete selected single step.				
	Clear	Clear all steps in the list.				
RAMP	Working	Ramp charging voltage value				
Charging	Voltage					
	Starting	Starting current value of ramp charging				
	Current					
	Cut-off	Cut-off current value of ramp charging				
	Current					
	Rise Time	Ramp charging time				

2.3.3 CP Charge Test

CP Charge						×
Working Mode	Basic Setting	Sample Set	Cut-Off	Conditions	Goto Conditions	Aları 🔹 🕨
Working Mod	e CP Chargin	ag 🔻				
	Work	ing Voltage	0	v		
	CP	[0	W		
OK Cancel						

Item	Parameter	Description			
	CP	The power value in CP charging mode			
CP Charging	Working Voltage	The voltage limit value in CP charging mode			
Pulse Edit / Import Excel File		Choose one of the two options. When you select "Pulse Edit", you need to customize the following parameters; when "Import Excel File" is selected, "New" an Excel template, edit parameters, and import into the interface.			
Charging	Cycle Number	Number of loops performed in existing list.			
	Charging Voltage	Voltage value of the single step in the list.			
	Power	Power value of the single step in the list.			

Item	Parameter	Description
	Pulse	Pulse width of the single step in the list.
	Slew Rate	Single step rise/fall time during pulse charging.
	Add	Add a single step.
	Insert	Insert a single step in existing step.
	Delete	Delete selected single step.
	Clear	Clear all steps in the list.

2.3.4 Driving Cycle Simulation

Driving Cycle Simulation			х
Working Mode Basic Setting S	Sample Set Cut-Off Condition	s Goto Conditions	Al arr 🔸 🕨
Mode CC 💌			
) Pulse Edit 🔘 Import Exc	el File		
List			
Cycle Number 1 🚔	Charging Voltage	0	v
	Discharge Voltage	0	γ
Current (A)	Width(s)	Slope(s)	
2.4	1	5	
Add Insert Delete	e Clear		
	OK Cancel		

Item	Parameter	Description
СС	Pulse Edit / Import Excel File	Choose one of the two options. When you select "Pulse Edit", you need to customize the following parameters; when "Import Excel File" is selected, "New" an Excel template, edit parameters, and import into the interface.
	Cycle Number	Number of loops performed in existing list.
	Charging Voltage	Charging voltage value during vehicle road condition simulation test
	Discharge Voltage	Discharge voltage value during vehicle road condition simulation test
	Current	Charging or discharge current value of the single step in the list.
	Width	Time width of the single step in the list.
	Slope	Current rise or fall time of the single step in the list.

Item	Parameter	Description			
	Pulse Edit / Import Excel File	Choose one of the two options. When you select "Pulse Edit", you need to customize the following parameters; when "Import Excel File' is selected, "New" an Excel template, edit parameters, and import into the interface.			
	Cycle Number	Number of loops performed in existing list.			
СР	Charging Voltage	Charging voltage value during vehicle road condition simulation test			
	Discharge Voltage	Discharge voltage value during vehicle road condition simulation test			
	Power	Charging or discharge power value of the single step in the list.			
	Width	Time width of the single step in the list.			
	Slope	Power rise or fall time of the single step in the list.			

2.3.5 CC Discharge Test

CC Discharge				х
Working Mode Basic Setting	: Sample Set	Cut-Off Conditions	Goto Conditions	Al arr 🔸 🕨
Working Mode CC Discharg	e 🔻 Son	nce 🔺		
Wor	king Voltage	0 V		
сс		0 A		
	OK	Cancel		

Item	Parameter	Description		
<u> </u>	CC	The current value in CC discharge mode		
Discharge	Working Voltage	The voltage limit value in CC discharge mode		
Source/Load	Source: Use the sink mode of IT6000C series to discharge. Load: Use the Load mode of IT6000B series to discharge.			



Item	Parameter	Description				
	Pulse Edit	Choose one of the two options. When you				
	/ Import	select "Pulse Edit", you need to customize the				
	Excel File	following parameters; when "Import Excel File"				
		is selected, "New" an Excel template, edit				
		parameters, and import into the interface.				
	Cycle	Number of loops performed in existing list.				
	Number					
Pulse	Discharge	Voltage value of the single step in the list.				
Discharge	Voltage					
	Current	Current value of the single step in the list.				
	Pulse	Pulse width of the single step in the list.				
	Slew Rate	Single step rise/fall time during pulse discharge.				
	Add	Add a single step.				
	Insert	Insert a single step in existing step.				
	Delete	Delete selected single step.				
	Clear	Clear all steps in the list.				
RAMP	Working	Ramp discharge voltage value				
Discharge	Voltage					
	Starting	Starting current value of ramp discharge				
	Current					
	Cut-off	Cut-off current value of ramp discharge				
	Current					
	Fall Time	Ramp discharge time				

2.3.6 CV Discharge Test

CV Discharge						×
Working Mode	Basic Setting	Sample Set	Cut-Off Conditi	ons	Goto Conditions	Aları 🚹 🕨
Work Mode	CV Discharge	▼ Son	urce 🔻			
	cı	r	0	v		
	Wa	ork Current	0	A		
		ОК	Cancel			

Parameter Description:

Item	Parameter	Description	
	CV	The voltage value in CV discharge mode	
CV Discharge	Work	The current limit value in CV discharge mode	
_	Current		
Conviriant @ Itach Electronic Co. Ltd 40			

Copyright © Itech Electronic Co., Ltd.



Item	Parameter	Description
Source/Load	Source: Use	e the sink mode of IT6000C series to discharge.
	Load: Use tl	he Load mode of IT6000B series to discharge.
	Pulse Edit	Choose one of the two options. When you
	/ Import	select "Pulse Edit", you need to customize the
	Excel File	following parameters; when "Import Excel
		File" is selected, "New" an Excel template,
		edit parameters, and import into the interface.
	Cycle	Number of loops performed in existing list.
	Number	
Pulse	Discharge	Voltage value of the single step in the list.
Discharge	Voltage	
	Current	Current value of the single step in the list.
	Pulse	Pulse width of the single step in the list.
	Slew Rate	Single step rise/fall time during pulse discharge.
	Add	Add a single step.
	Insert	Insert a single step in existing step.
	Delete	Delete selected single step.
	Clear	Clear all steps in the list.
RAMP	Working	Ramp discharge voltage value
Discharge	Voltage	
	Starting	Starting current value of ramp discharge
	Current	
	Cut-off	Cut-off current value of ramp discharge
	Current	
	Fall Time	Ramp discharge time

2.3.7 CR Discharge Test





Item	Parameter	Description
CR	CR	The resistance value in CR discharge mode
Discharge	Voltage	The voltage limit value in CR discharge mode

2.3.8 DCIR Test

DCIR Test						×
Discharge	Basic Setting	Auxiliary Chann	el Alarm	Protect:	i on	
	Sourc	e v Workin	g Voltage	1	v	
			6 . of cafe	•	,	
	-1st	Discharge				
	Di	scharge Current	1.00	0 🔺	A	
	п;	saborgo Timo	3600.0		-	
	DI	scharge lime	3000.0		2	
	Dela	y				
	De	lay Time	1.00	0 🚖	s	
	-2nd	Discharge				
	Di	scharge Current	1.00	0	Å	
	Di	scharge Time	3600.0	000 🚖	s	
L						
		OK	Cance	1		

Parameter Description:

Item	Parameter	Description						
Source/Load	Source: Use the sink mode of IT6000C series to discharge.							
	Load: Use t	Load: Use the Load mode of IT6000B series to discharge.						
Work Voltago	Work	The voltage limit value in DCIR Test mode						
work voltage	Voltage							
1 st Discharge	Discharge	Discharge current setting for the first discharge						
_	Current							
	Discharge	Discharge time setting for the first discharge						
	Time							
Delay	Delay	The time the battery stops discharging after the						
	Time	first discharge.						
2 nd Voltage	Discharge	Discharge current setting for the second						
	Current	discharge						
	Discharge	Discharge time setting for the second						
	Time	discharge						

2.3.9 CC-CV Charge Test



CC-CV Charge			×
Working Mode Basic Setting Sample Se	t Cut-Off Conditions	Goto Conditions	Aları 🔸 🕨
Working Mode CC-CV Charging	T		
Working Volt	tage O	v	
Working Curr	rent O	A	
	OK Cancel		

Item	Parameter	Description	
CC-CV	Working Voltage	Voltage value at constant voltage charging	
Charging	Working Current	Current value at constant current charging	
	Pulse Edit / Import Excel File	Choose one of the two options. When you select "Pulse Edit", you need to customize the following parameters; when "Import Excel File" is selected, "New" an Excel template, edit parameters, and import into the interface.	
Pulse Charging	Cycle Number	Number of loops performed in existing list.	
	Charging Voltage	Voltage value of the single step in the list.	
	Current	Current value of the single step in the list.	
	Pulse	Pulse width of the single step in the list.	
	Slew Rate	Single step rise/fall time during pulse charging.	

2.3.10 CP Discharge Test



CP Discharge			х
Working Mode Basic Setting Sample Set	Cut-Off Conditio	ons Goto Conditions	Aları 🔸 🕨
Working Mode CP Discharge 🔻 So	ource 🔻		
Work Voltage	0	v	
Const Power	0	W	
OK	Cancel		

Item	Parameter	Description			
CD	CP	The power value in CP discharging mode			
Dischargo	Work	The voltage limit in CP discharging mode			
Discharge	Voltage				
Source/Load	Source: Use	e the sink mode of IT6000C series to discharge.			
	Load: Use t	ne Load mode of IT6000B series to discharge.			
	Pulse Edit	Choose one of the two options. When you			
	/ Import	select "Pulse Edit", you need to customize the			
	Excel File	following parameters; when "Import Excel File"			
		is selected, "New" an Excel template, edit			
		parameters, and import into the interface.			
	Cycle	Number of loops performed in existing list.			
	Number				
Pulse	Discharge	Voltage value of the single step in the list.			
Discharge	Voltage				
-	Power	Power value of the single step in the list.			
	Pulse	Pulse width of the single step in the list.			
	Slew Rate	Single step rise/fall time during pulse discharge.			
	Add	Add a single step.			
	Insert	Insert a single step in existing step.			
	Delete	Delete selected single step.			
	Clear	Clear all steps in the list.			

2.3.11 CC-CV Discharge Test



CC-CV Dischar	ge					х
Working Mode	Basic Setting Sample	Set (Cut-Off Cor	nditions	Goto Conditions	Aları 🔹 🕨
Work Mod	e CC-CV Discharge •	• 5	Source 🔻			
	Working Volt	age	0	v		
	Working Curr	ent	0	A		
	C	OK	Cano	el		

Item	Parameter	Description				
	Working	Voltage value at constant voltage discharge				
CC-CV	Voltage					
Discharge	Working	Current value at constant current discharge				
	Current					
Source/Load	Source: Use	e the sink mode of IT6000C series to discharge.				
	Load: Use t	he Load mode of IT6000B series to discharge.				
	Pulse Edit	Choose one of the two options. When you				
	/ Import	select "Pulse Edit", you need to customize the				
	Excel File	following parameters; when "Import Excel File"				
		is selected, "New" an Excel template, edit				
		parameters, and import into the interface.				
Pulse	Cycle	Number of loops performed in existing list.				
Discharge	Number					
	Discharge	Voltage value of the single step in the list.				
	Voltage					
	Current	Current value of the single step in the list.				
	Pulse	Pulse width of the single step in the list.				
	Slew Rate	Single step rise/fall time during pulse discharge.				

2.3.12 IO Control



Io Name	Status	Function
)	on	10
l	on	IO
2	on	IO
3	on	IO
1	on	IO

Corresponds to the functions of each pin of the digital I/O interface (P-IO) of the IT6000 series instruments.

Parameter	Description
IO Name	Indicates the number of the digital I/O pin.
Status	Turns the function of the corresponding pin
	on or off.
	Off represents closed IO pin, on represents
	disconnected IO pin.
Function	Select the existing pin function.
Add	Add a pin configuration.
Delete	Remove the selected pin configuration.
Sort	Reorder the pin numbers.
Clear	Clear all pin configurations.

2.3.13 CP-CV Discharge Test

CP-CV Dischar	ge						×
Working Mode	Basic Setting	Sample Set	Cut-Off	Conditions	Goto Condi	tions	Aları 1
		Power	0	w			
		IONEI	0				
	1	Voltage	0	v			
		OK		ancel			





Parameter	Description
Voltage	Voltage value at constant voltage discharge
Power	Power value at constant power discharge

2.3.14 CAN Message Control

CAN Message Control	×	CAN Me	ssage Control			×
Pattern=1 Pattern=2		Pattern	-1 Pattern-2			
Message	Status	ID (0x)	Messa;	ge (Ox)	Cycle	Status
				Add	lelete Inser	rt Clear
		L	r			
OK	Cancel			OK Canc	2	

Parameter Description:

Parameter	Description
Add	Right-click in the blank space and select Add to
	add a message.
Message	The message to be sent.
Status	Message sent status
ID (0x)	Node ID
Message	Message content
(0x)	
Cycle	Number of times the message is sent cyclically
Status	Message sent status

2.3.15 ACIR Test



CIR Tes	t				х
BM	NS Option]Cell Sample for BMS				
Cu Cu	nt-Off Condition nt-Off Time	3600.000	×.	z v	
S: C:	mple Rate ≥ll Sample	1.000	<u>*</u>	5	
-Da	ata Saving Conditions) Time	1.0000	×	5	
	OK	Cancel			

Item	Parameter	Description
BMS Option	Cell Sample for BMS	Whether the voltage of the battery chip is read by the BMS system. If this item is selected, it is read from the BMS system, otherwise it is read from the IT5102.
Cut-Off	Cut-Off	Test cutoff time
Condition	Time	
Sample Rate	Cell Sample	Cell sample rate
Data Saving Conditions	Time	Time interval for saving data, indicating that data is saved every X seconds, wherein, X is a setting value

2.3.16 Scaling (Applicable to 34980)

Note: If the hardware is configured with 34980 and the test item needs to be set, please place the test item at the first step of the test sequence and let the data acquisition instrument start up first.





Item	Parameter	Description
	Y	Editable items. The data collected by the auxiliary channel is calculated by Mx+B.
Voltage / Current / Temperature	Name	Non-editable items. The channel name of the data acquisition instrument (34980) whose type is "Auxiliary Channel Voltage/Current/Temperature" defined on the " <step 3="">" page.</step>
	Μ	Editable items. Set the gain factor.
	В	Editable items. Set the offset value.
	Unit	Editable items. Set the unit of the collected data.

2.3.17 Auxiliary Channel Settings (Applicable to 34980)

Note: If the hardware is configured with 34980 and the test item needs to be set, please place the test item at the first step of the test sequence and let the data acquisition instrument start up first.

Auxiliary	Channel	Settings				>
Voltage	Current	Temperature	Auxiliary Sample Time	60	ms	📝 Whether Sample
Name		Range	Integration Auto 2	ero	Resistance	Channel Delay
			OK Car	cel		

Item	Parameter	Description
Voltage	Name	Non-editable items. The channel name of the data logger (34980) whose type is "Auxiliary Voltage" defined on the " <step3>" page.</step3>
	Range	Editable items. Select the range of a single channel of the data logger.



Item	Parameter	Description	
	Integration	Editable items.	
		• NPLC: Number of power frequency	
		cycles	
		IIME: User-defined measurement	
	A	sampling period.	
	Auto Zero	Editable items. Indicates whether to	
	Desistance	Editable itema. Configure the input	
	Resistance		
	Channel	Editable items. Configure the channel	
	Delay	delay time	
	Name	Non-editable items. The channel name of	
	i tuillo	the data logger (34980) whose type is	
		"Auxiliary Current" defined on the	
		" <step3>" page.</step3>	
	Range	Editable items. Select the range of a	
		single channel of the data logger.	
	Integration	Editable items.	
		• NPLC: Number of power frequency	
Current		cycles	
		• TIME: User-defined measurement	
	Auto Zana	sampling period.	
	Auto Zero	Editable items. Indicates whether to	
	Posistanco	Editable items Configure the input	
	Resistance	resistance	
	Channel	Editable items. Configure the channel	
	Delav	delav time.	
	Name	Non-editable items. The channel name of	
		the data logger (34980) whose type is	
		"Auxiliary Temperature" defined on the	
		" <step3>" page.</step3>	
	Probe Type	Select "Thermocouple" from the	
		drop-down menu, and set the	
		thermocouple type, thermocouple check,	
		reference junction source, and	
Tomporaturo	Integration	Editable items	
remperature	Integration	 NPLC: Number of power frequency. 	
		cycles	
		• TIME: User-defined measurement	
		sampling period.	
	Auto Zero	Editable items. Indicates whether to	
		automatically calibrate zero.	
	Unit	Editable items. Configure the temperature	
		unit.	
	Channel	Editable items. Configure the channel	
	Delay	delay time.	
Auxiliary Sample	Set the delay time for the software to read the data		
	of each chan	ne auxiliary channel, here is the delay time	
Whether Sample	Whether to e	nable auxiliary channel sampling. If it is not	
	checked the	auxiliary channel will not sample.	
Add	Right-click and select "Add" to add a new channel set.		
Delete	Right-click and select "Delete" to delete a channel set.		



2.3.18 Auxiliary Power Supply Setting

Auxiliary Power Supply S	etting	×
DC Source	Power2 🔻	
Voltage	2 V	
Current	2 A	
Output	Off 🔻	
OK	Cancel	

Parameter	Description
DC Source	Editable items. The channel name of the auxiliary
	source whose type is "DC Power Supply" defined
	on the " <step 3="">" page.</step>
Voltage	The output voltage value of the auxiliary DC power
-	supply.
Current	The output current limit value of the auxiliary DC
	power supply.
Output	The output switch of the auxiliary DC power supply.

2.3.19 Loop

Loop		×
Step No.	1	
Logic Condition	AND -	
🥅 Cycle Number	1	
🥅 Charge Cut-Off Voltage	10	v
🥅 Charge Capacity	10	Ah
🥅 Charge Energy	10	Wh
🥅 Discharge Cut-Off Voltage	10	٧
🥅 Discharge Capacity	10	Ah
🥅 Discharge Energy	10	Wh
OK Cancel		

Item	Description



Item	Description
Step No.	Work step number for beginning cycle
Logic Condition	The relationship between Cut-off conditions
Cycle Number	Number of loops performed by the work step
Charge Cut-off Voltage	The loop is stopped when the charging
	voltage meets the setting value.
Charge Capacity	The loop is stopped when the charging
	capacity meets the setting value.
Charge Energy	The loop is stopped when the charging
	energy meets the setting value.
Discharge Cut-off Voltage	The loop is stopped when the discharging
	voltage meets the setting value.
Discharge Capacity	The loop is stopped when the discharging
	capacity meets the setting value.
Discharge Energy	The loop is stopped when the discharging
	energy meets the setting value.

2.3.20 Wait

Basic Setting:

Wait						x
Basic Setting	Sample Set Cut-Off Condi	tions	Goto Condi	tions	Alarm-CAN	Pr 4 🕨
	🔽 CAN Message Check					
	Data Source	PO	YER	•		
	BMS Option					
	🥅 Cell Sample for BMS					
	Data Saving Conditions					
	O Time		1.0000 🚔	s		
			0.2000	v		
			0.0500	A		
			1.0000	Ah		
		_				
	OK	Ca	ncel			

Item	Parameter	Description
-	Data Source	Select the data source
BMS Option	Cell Sample for BMS	Whether the voltage of the battery chip is read by the BMS system. If this item is selected, it is read from the BMS system, otherwise it is read from the IT5102.
	Channel Sample	Channel sample rate
Sample Rate	Temperature Sample	Temperature sample rate
	Cell Sample	Cell sample rate
Data Saving Conditions	Time	Time interval for saving data, indicating that data is saved every X seconds, wherein, X is a setting value



Item	Parameter	Description
	ΔV	Compare sampling voltage values. When difference between them meets setting value, the data is saved.
	ΔΙ	Compare sampling current values. When difference between them meets setting value, the data is saved.
	ΔC	Compare sampling capacity values. When difference between them meets setting value, the data is saved.

Cut-Off Conditions:

Wait		×
Basic Setting Sampl	e Set Cut-Off Conditions Goto (Conditions Alarm-CAN Pr 🔸 🕨
Logic Condition OR	▼ CAN message time	-out 0.000 🚔 s
Common Conditions	CAN Message	
Type	Set Value	Delete
	OK Cancel	

Item	Parameter	Description
	AND	Indicates that there is "AND" relationship
Logic		between several cut-off conditions.
Condition	OR	Indicates that there is "OR" relationship
		between several cut-off conditions.
Common	Cut-Off	The test is stopped when the voltage meets
Conditions	Voltage	the setting value.
CAN	Message	The message name in the selected CAN
Message		message
	Operator	The operator to be followed in the CAN
		message
	Set Value	The setting value of cut-off conditions. The
		Wait step is stopped and continues to the next
		step when the CAN message after calculation
		meets the setting value. Otherwise, the test
		will stop and the system will prompt that the
		CAN message does not meet the conditions.
CAN	The time when	the CAN message is sent or responded to
message	timeout. Once tir	ned out, the test stops.
time-out		

Goto Conditions:



Wait				×
Basic Setting	Sample Set Cut	-Off Conditions	Goto Conditions	Alarm-CAN Pr 4 🕨
CAN message ti	.me-out 0.000	z		
Normal Condit:	ion CAN			
Name	Symbol	Set Value	Goto	Delete
		OK Car	acel	

Item	Parameter	Description					
	Voltage	Indicates the voltage of the cell battery.					
	Symbol	Indicates the judgment symbol.					
Normal	Set Value	Indicates the judgment voltage of the cell					
Condition		battery.					
Condition	Goto	Indicates which step to jump to. When the					
		collected cell voltage meets the set value					
		condition, a jump is performed.					
CAN	Message	The message name in the selected CAN					
Message		message					
	Operator	The operator to be followed in the CAN					
		message					
	Set Value	The setting value of Goto conditions. The test					
		step will jump to the next step when the CAN					
		message after calculation meets the setting					
		value. Otherwise, the test will stop and the					
		system will prompt that the CAN message					
		does not meet the conditions.					
	Goto	Indicates which step to jump to.					
CAN	The time when	the CAN message is sent or responded to					
message	timeout. Once ti	med out, the test stops.					
time-out							

2.3.21 Delay



Delay					×
Basic Set	Sample Set	Alarm-CAN	Protection-CAN		
	CAN Me Data Sow BMS Optio Cell S Delay Delay Delay Tim	ssage Check rce n ample for B e	FOWER	× 5	
	Derah 11W	e	1.000	▼ 2	
	-Data Savi	ng Conditio	ns		
	💿 Time		1.0000	S	
	© ∆۷		0.2000	÷ V	
	○ ΔI		0.0500	÷ A	
			0.0500	Ah	
		OK	Cancel		

Item	Parameter	Description					
-	Data Source	Select the data source					
	Cell Sample	Whether the voltage of the battery chip is read					
BMS Option	for BMS	by the BMS system. If this item is selected, it is					
Dine option		read from the BMS system, otherwise it is read					
		from the IT5102.					
Delay	Delay Time	Delay Time of Battery					
	Time	Time interval for saving data, indicating that					
		data is saved every X seconds, wherein, X is a					
		setting value					
	ΔV	Compare sampling voltage values. When					
		difference between them meets setting value,					
Data Saving		the data is saved.					
Conditions	ΔΙ	Compare sampling current values. When					
		difference between them meets setting value,					
		the data is saved.					
	ΔC	Compare sampling capacity values. When					
		difference between them meets setting value,					
		the data is saved.					

2.3.22 Reset



Reset		×
	🦳 Total Charging Time	
	🥅 Total Discharge Time	
	🥅 Total Charge Capacity	
	🥅 Total Discharge Capacity	
	🥅 Total Charge Energy	
	🥅 Total Discharge Energy	
	🥅 Total Mileage	
	🔲 Save Before Reset	
	OK Cancel	

Parameter	Description
Total Charging Time	Reset the total charge test time.
Total Discharge Time	Reset the total discharge test time.
Total Charge Capacity	Reset the total charge capacity.
Total Charge Energy	Reset the total charge energy.
Total Discharge Capacity	Reset the total discharge capacity.
Total Discharge Energy	Reset the total discharge energy.
Total Mileage	Reset the total test mileage.
Save Before Reset	Perform data saving before resetting.



Chapter3 Test Run

After test configuration, ITS5300 test system starts test for battery. The test running module is provided with such functions as running test steps and test process observation.

3.1 Interface Introduction

Click "Test Run" module in the main interface, which is shown below.



- Main functions of toolbar:
 - Open: open configured test files.
 - Run All: run test files. When the user clicks this key for running, all channel tests in the test files will be run. If a single channel test is to be performed, select running key corresponding to the channel.
 - Pause All: pause test files in running.
 - Stop All: stop test files in running.
- Start Time: time for opening the test file.
- Run Time: time for executing the test file.
- Run: Green indicates that existing test is running normally.
- Alarm: Red indicates that existing test appears alarm. The user can set voice prompt for alarm status.
- Protection: Blue indicates that protection occurs during existing test. The user can set voice prompt for protection status.
- Mute: close the voice prompt.
- Voltage/Resistance/Temperature: when different parameter buttons are selected, the virtual battery displays voltage/resistance/temperature respectively.
- Virtual battery: unfold detailed information of this channel, and all battery status under this channel will be displayed. Each cell displays existing voltage, resistance or temperature value. When the user clicks the battery, the battery name, voltage, resistance and temperature values will be displayed.
- Running information of channel test: Display detailed running information of this channel, including voltage, current, capacity, work step, cycle count and running status.



3.2 Running Test Program

Running sequences of the test program are related to the sequence of the user's selection of test items. Run test items based on such sequence. Run the configured test programs in the 2.2 configuration test program as an example, detailed running steps are as shown below.

- 1. Click "Open" to open edited test file.
- 2. Click "OK", and the file starts loading.
- 3. Based on test item to be selected, click "Run All" to run edited test files, and the test program stops test based on stopping conditions.

3.3 View Channels

The user can check detailed information of channel test by clicking the channel name in the running interface. Click Return at the top left corner to return to the Running Interface of Test Programs.



In the above figure, the voltage, current, power, capacity, and energy parameters in the upper left corner area (**Parameter Name, Value, Show Curve**) are those of the IT6000 series instrument and will always be displayed in this area. Other parameters will only be displayed when checked and the test item is controlled to the device.

For example, the thermostat and water-cooling equipment are externally connected equipment. If the system is not configured, they will not be displayed.

- The main window area in the middle displays the test point name, cell voltage, cell temperature and other information.
- The left window area displays the battery voltage, capacity, water cooling/thermostat equipment (if configured) parameters, etc.
- The right window displays the running status, including the step parameters and running information of the test program.
- The lower window displays the battery cell test curve, and the user can click the button in the upper right corner to select the display voltage,



current and capacity or multiple selections as needed.

3.4 View Alarm Information

During test, if alarm conditions are configured, when circumstances meeting the alarm conditions appear, the system will automatically report an alarm.

 When channel alarm information is generated, the mouse points to the channel and the running status red marker displays the channel alarm information, as shown below.



 When cell alarm information is generated, the battery cell turns red. The mouse points to the cell, and the cell alarm information is displayed, as shown below.



3.5 View Protection Information

During test, if protection conditions are configured, when circumstances



meeting the protection conditions appear, the system will automatically report protection and stop test.

 When channel protection information is generated, the mouse points to the channel and the running status blue marker displays the channel protection information, as shown below.



 When cell protection information is generated, the battery cell turns blue. The mouse points to the cell, and the cell protection information is displayed, as shown below.



🛄 Note

When the channel generates protection and alarm information simultaneously, the Status column appears red marker and blue marker at the same time. When the cell generates protection and alarm information at the same time, the cell box turns into half red and half blue. The mouse points to the battery cell, and the battery cell protection and alarm information are displayed.



Chapter4 Data Analysis

This chapter introduces statistic analysis, integrated query, CAN message query, test data manager and template manager function after finishing executing the test program.

4.1 Statistic Analysis

After test is completed, the user can query statistics of the test results. Click "Data Analysis" on the main test interface, and select "Statistic Analysis" to enter the Statistic Analysis interface of test results. The user can analyze and check results as required.

tusuc Analysis							
reening	Basic Information Wa	veform TestData St	atistical Information C	AN Message	Data lab		
t Jata	Battery Information	n					
	Sequence No		P	arts No			
	Version		St	ep			
	Battery Name						
	Rated Voltage(V)	R	ted Current (A)			
	Rated Capacity(Ah)	C	11 Count			
	Volumn (L)		W	ight (Kg)			
	Cell Name						
	Memo						
				Basi	c information		
	Test Information						
	Program Name						
	Channel Name		Te	t Sequence			
	Run Date		0p	erator			
	Alarn						
	Measured Value	Set Value	Run Time(S)	Occur Time	Type	Warning Source	Step Name
					Alarm inform	nation	
	Protection						
	Measured Value	Set Value	Run Time(S)	Occur Time	Type	Protect Source	Step Name
Test file name					Protection in	formation	

- All: display all test file name, user can select the test data according to test file name.
- Screening: the screening condition of test file, user can setup the condition to screening data.
- Basic Information: View the basic information of the selected test data, including battery information, test channel information, charge and discharge statistics, alarm and protection information.
- Waveform: Show detailed test curve information.
- Test Data: Users can customize the query conditions, filter the required test information, and export it as an Excel file.
- Statistical Information: Accumulated data information for performing battery charge and discharge tests, including statistical information such as charge energy, discharge energy, charge capacity, discharge capacity, and total mileage.
- CAN Message: Display the test value contained in the parsed CAN message.



Select a test data file, the basic information page displays the following parts:

- Battery information: the battery parameter information set in Step 1 of the program configuration.
- Test information: channel, sequence name and other information in the program configuration.
- Alarm: Alarm information generated during the test.
- Protection: Protection information generated during the test.

Alarm and protection information supports exporting data to Excel files (right-click in the table interface and select "Export"), which is convenient for users to perform statistics and analysis.

Note

The "Run time" in the alarm and protection information indicates the time point when the alarm or protection occurred, which can help users quickly locate and analyze.

4.1.2 Waveform

Select "Waveform" on the "Statistical Analysis" page, the display interface is as follows:



First select a test data file, and then set the following parameters:

 Channel/Battery Cell: Users can choose to view the test waveform of the channel or cell battery.



- Query Condition: The user can filter some waveforms for viewing according to the test step, cycle (that is, the number of cycles executed by the step), and test time.
- X/Y Axis Definition: users can customize the type of test data represented by the coordinate axis.

For example, choose X axis as time and Y axis as voltage, as shown in the figure below.

-X/Y Axes	Definitio	Definition							
X Axes	Time(S) 🔹								
Y Axes	Name	YAxes							
	¥1	Voltage(V) 💌							
		Add Delete							

Click "Add" to set multiple waveforms indicated by the Y axis; you can also select a Y axis and click "Delete".

• Query: After setting the query conditions and defining the X/Y axis, click the "Query" button to display the eligible waveforms, as shown in the figure below.



Right-click on the waveform interface to display the following functions:





Cursor: select and display a certain coordinate information of a certain waveform (such as "power"), as shown in the figure below.

	F					
		(12.)	806	297.23)	•••••••
	K	<u> </u>				
			·			

- Adaptive Size: adjust the waveform interface to an appropriate size, allowing users to see the complete waveform.
- Export (waveform): Export the waveform interface as a picture.
- Export (waveform-data): Export the waveform data to an Excel file.
- Adjust Curve

The user can tick the existing curve name off at the right of the interface, and select to display or not to display the curve. The user can also click the Curve icon to adjust the curve. The user can change the color and operation method of the curve, as shown below.

💀 Statistics			×
Name	Voltage1		
Function		-	
Color	Lime	•	
ОК		Cancel	

4.1.3 Test Data

The user can select "Test Data" in the Data tab, and view detailed test data of the existing file.



🥓 Statistic Analysis		- 🗆 ×
All Screening Be	asic Information Waveform TextData Statistical Information	
🖃 🗐 Test Data	Screen	
5300-64-11	✔ Channel Voltage (V) : Curren: ▼	
☐ ITS5300-S0067 — I2~er d=20201117144446 12~er d=202011171444504	Other Config Result/Meno/Cycle - Coll Slicel - Voltage (V)/40 Resists -	
12-erd-20201117144700	Auxiliary Auxiliary Mame:Sar -	
12-er d-20201117144857	Step CR Dizcharge (1)	
12-crd-20201117144855		
	Export	
	Channel Data 0/0 🦟 🏹 📎	0 Go
	Voltage(V) Current(A) Capacity(Ah) Energy(Wh) Specific dentry Mover(W) Specific dentry (Mh/L) (Mh/L)	fic (W/kg)
	٠ ۲	F

- Screen: Set the filter conditions for test data query.
- Query: After setting the filter conditions, click "Query" to display the test data that meets the conditions.
- Export: Export the "Basic Information" and "Channel Data" of the selected test data file as an Excel file as shown below.

Basic Information.xlsx Channel Data.csv

• Channel data: the test data of the selected channel.

4.1.4 Statistical Information

Accumulated data information for performing battery charge and discharge tests, including statistical information such as charge energy, discharge energy, charge capacity, discharge capacity, and total mileage.

Basic Information 1	Waveform TestData	Statistical Information							
Charge Energy(Wh)	Discharge Energy(Wh)	DischargeEnergy / ChargeEnergy	Charge Capacity(Ah)	Discharge Capacity(Ah)	DischargeCapacity / ChargeCapacity	Total Mileage(Km)	Charge Time(S)	Discharge Time(S)	Memo
0.000	0.071	0	0.000	0.001	0	0.000	0.000	11.461	

4.1.5 CAN Message

The parsed value of CAN message is displayed on this interface. Different from the function of the **4.3 CAN Message Query** chapter, the interface function of the 4.3 chapter is the query of the original message.



asic Information	Waveform TestData St	atistical Information	CAN Message			
nstruction	Value	Memo	Run Time(s)	Time	Step No.	Step Name

4.2 Integrated Query

The running data of several test programs or different running file data of a same test program can be viewed, which can be used to compare data curves as required. The screening conditions and curve adjustment operation are the same as those in the Statistic Analysis function.



4.3 CAN Message Query

During test, it is necessary to establish CAN communication with the DUT. On the main test interface, click "Data Analysis -> CAN Message Query" to enter the CAN Message Query interface. The user can view the content of all CAN messages received by the system.



Screening	Test Informatio	a						
Testlata	Trogram Same	ch vght 2019062515442			Seguence No:			
617		0010-005-05-00-00						
il- 🛄 ch	840 310e	2010/06/25 15:44:21			Louises Bune:	<pre>ch</pre>		
III ok veht 20190625154920	Operator:	rd			Test Sequence:	vght		
- d.vght_20190625155000	Stap ND. :	A11		-	Query			
- d. vgh (_20190625155259	C19 8							
- ch_vgh(_20190625160949	Cha Bessages							
eh_vgh1_20190625160400	HI export	11 1 1 11 1 1	4					
20190625164721	13	Channel Rane	Step 10	Hessage ID		Data	and a second	Hessage Time
ITS5300+40043	1	ch	0	274	_	67 00 00 44 00 00 00 00	8	2019/06/25 15:44:06
	2	ch	0	274		67 00 00 44 00 00 00 00	8	2019/06/25 15:44:07
	3	ch	0	274		67 00 00 44 00 00 00 00	8	2010/06/25 15:44:07
	4	ch	0	274	-	67 00 00 44 00 00 00 00	8	2019/06/25 15:44:07
	5	ch	1	51		33 33 33 33 33 33 33 33 03	8	2019/06/25 15:44:07
	8	ch	2	274		67 00 00 44 00 00 00 00	8	2019/06/25 15:44:07
	7	ch	2	51		33 33 33 33 33 33 33 33 03	8	2019/06/25 15:44:07
	8	ch	2	274		67 00 00 44 00 00 00 00	8	2010/06/25 15 44 07
	9	ch	2	51		33 33 33 33 33 33 33 03	8	2019/06/25 15:44:07
	10	ch	2	274		67 00 00 44 00 00 00 00	8	2019/06/25 15:44:07
	11	ch	2	51		33 33 33 33 33 33 33 03	8	2019/06/25 15:44:07
	12	ch	2	274		67 00 00 44 00 00 00 00	8	2019/06/25 15:44:07
	13	ch	2	51		33 33 33 33 33 33 33 33 03	8	2019/06/25 15:44:07
	14	ch	2	274		67 00 00 44 00 00 00 00	0	2019/06/25 15:44:07
	15	ch	2	51		33 33 33 33 33 33 33 33 03	8	2019/06/25 15:44:07
	16	ch	2	274		57 00 00 44 00 00 00 00	0	2019/06/25 15:44:07
	17	ch	2	51		33 33 33 33 33 33 33 03	B	2019/06/25 15:44:07
	10	ch	2	274		67 00 00 44 00 00 00 00	0	2019/06/25 15:44:07
	19	ch	2	51		33 33 33 33 33 33 33 33 03	0	2019/06/25 15:44:00
	20	eh	2	274		67 00 00 44 00 00 00 00	0	2019/06/25 15:44:00
	21	ch	2	\$1		33 33 33 33 33 33 33 33 03	0	2019/06/25 15:44:00
	22	ch	2	274		67 00 00 44 00 00 00 00	0	2019/06/25 15:44:00
	23	ch	2	51		33 33 33 33 33 33 33 33 03	0	2019/06/25 15:44:08
	24	eb	2	274		67 00 00 44 00 00 00 00	6	2019/06/25 15:44:08
	25	ch	2	\$1		33 33 33 33 33 33 33 33 33	0	2019/06/25 15:44:00
	26	ch	2	274		67 00 00 44 00 00 00 00	0	2019/06/25 15:44:08
	27	ch	2	\$1		33 33 33 33 33 30 30 30 03	0	2019/06/25 15:44:08
	20	th	2	274	12	67 00 00 44 00 00 00 00	8	2019/06/25 15:44:08

On the CAN Message Query interface, the user can directly click the test program file name for viewing or click the "Screen" for viewing based on screening conditions.

If it is necessary to export the CAN message, click "Export" to export the existing CAN message records to the Excel for saving.

4.4 Test Data Manager

The user can check and delete data generated by all test tasks, and select required data based on test date or test name for checking or deletion.

式 Те	stDataManager					
Run De File N	ate : 2022-06-08	~ 2022-06-08	Delete			
📄 Check i	A11					
ID	Channel Test Number	File Name	Test Program Name	Group Number	Channel Name	Test Se 🔦
49950	132974336259680000	ITS5300-S0098_202205191128460	ITS5300-S0098	1	CH1	22
49951	132974336554380000	ITS5300-S0098_202205191128460	ITS5300-S0098	1	CH1	11
49952	132974337973790000	ITS5300-S0098_202205191133410	ITS5300-S0098	1	CH1	11
49953	132974338473160000	ITS5300-S0098_20220519113433175	ITS5300-S0098	1	CH1	11
49954	132974341273560000	ITS5300-S0098_202205191139090	ITS5300-S0098	1	CH1	11
49955	132974344398830000	ITS5300-S0098_20220519114124936	ITS5300-S0098	1	CH1	11
49956	132974345100870000	ITS5300-S0098_2022051911453445	ITS5300-S0098	1	CH1	11
49957	132974345632660000	ITS5300-S0098_2022051911453445	ITS5300-S0098	1	CH1	11
49958	132974348011770000	ITS5300-S0098_202205191150220	ITS5300-S0098	1	CH1	11
49959	132974451178260000	ITS5300-S0098_202205191442140	ITS5300-S0098	1	CH1	11
49960	132974461017200000	ITS5300-S0098_20220519145755385	ITS5300-S0098	1	CH1	11
49961	132974462285910000	ITS5300-S0098_20220519150102536	ITS5300-S0098	1	CH1	11
49962	132974465290100000	ITS5300-S0098_20220519150601253	ITS5300-S0098	1	CH1	CC
49963	132975149727320000	ITS5300-S0098_20220520100619893	ITS5300-S0098	1	CH1	11
49964	132975152110110000	ITS5300-S0098_20220520101035908	ITS5300-S0098	1	CH1	11
49965	132975152850520000	ITS5300-S0098_20220520101138723	ITS5300-S0098	1	CH1	11
49966	132975155341790000	ITS5300-S0098_20220520101138723	ITS5300-S0098	1	CH1	11
49967	132975155912150000	ITS5300-S0098_20220520101701296	ITS5300-S0098	1	CH1	11
49968	132975156727980000	ITS5300-S0098_20220520101826397	ITS5300-S0098	1	CH1	11
49969	132975157598040000	ITS5300-S0098_20220520101953317	ITS5300-S0098	1	CH1	11
49970	132975158214220000	ITS5300-S0098_20220520102054560	ITS5300-S0098	1	CH1	11
49971	132975181216240000	ITS5300-S0098_20220520104204443	ITS5300-S0098	1	CH1	11
49972	132975288511120000	v1-6000-zd_20220520140453486	v1=6000=zd	1	ch1	tttt
49973	132975364306550000	ITS5300-S0098_20220520160409232	ITS5300-S0098	1	CH1	11
49974	132975384587710000	ITS5300-S0098_20220520163811493	ITS5300-S0098	1	CH1	11
10075	132075387666120000	TTSS300-S0008 90990590164318793	80002-00227T	1	CHI	11

- Run Date: Filter test data based on the set date range.
- File Name: Test data file name. The user can enter the keyword of the file name (such as the test date 20190610) to filter the test data.



- Query: Query the test data that meets the conditions according to the "Run Date" and "File Name".
- Delete: Check the box before a test data record or select "Check All" to delete the test data.

Right-click a test data record and the following menu appears:

ID	Channel Test Number	File Name		Test Program Name
49950	132974336259680000	ITS5300-S	0098_202205191128460	ITS5300-S0098
49951	132974336554380000	ITS5300-S	0098_202205191128460	ITS5300-S0098
49952	132974337973790000	ITS5300-S	0098_202205191133410	ITS5300-S0098
49953	132974338473160000	ITS5300-S	0098_20220519113433175	ITS5300-S0098
49954	132974341273560000	ITS5300-S	0098_202205191139090	ITS5300-S0098
49955	132974344398830000	ITS530	Channel Data	ITS5300-S0098
49956	132974345100870000	ITS530	channel Data	ITS5300-S0098
49957	132974345632660000	ITS530	Battery Cell Data	ITS5300-S0098
49958	132974348011770000	ITS530	DCIR Data	ITS5300-S0098
49959	132974451178260000	ITS5300 -	0080_202203181442140	ITS5300-S0098
49960	132974461017200000	ITS5300-S	0098_20220519145755385	ITS5300-S0098

• Channel Data: Displays the test data of a specific test channel.

Voltage(V)	Current (A)	Power(W)	Energy(Wh)	Capacity(Ah)	Run Time(S)	Cycle	Continue Time(S)	Running Date	
Step No:1									
45.2108	3.08241	139.358222	0.0810987	0.0017938		1	1.761	2022/5/19 11:44:42	
45.202	3.08006	139.2248721	0.1197723	0.0026494		1	2.761	2022/5/19 11:44:43	
45.1934	3.07808	139.1089007	0.1586069	0.0035087		1	3.761	2022/5/19 11:44:44	
45.1862	3.07774	139.0713752	0.1970061	0.0043585		1	4.761	2022/5/19 11:44:45	
45.1794	3.07777	139.0518019	0.2356702	0.0052143		1	5.761	2022/5/19 11:44:46	
45.1728	3.07716	139.0039332	0.2744755	0.0060733		1	6.761	2022/5/19 11:44:47	
45.1657	3.07531	138.8985289	0.3130584	0.0069276		1	7.761	2022/5/19 11:44:48	
45.1597	3.07615	138.9180112	0.3518397	0.0077864		1	8.761	2022/5/19 11:44:49	

• Battery Cell Data: Display the test data of the cell.

1329742918666	70000						
SingleVoltage(V)	ACResistance (Ω)	Temperature	Time	Cycle	Continue Time(S)	Running Date	_
Step No:1							^
		26.0897750	0.0000000	1	2.297	2022/5/19 10:17:08	=
		26.1640240	0.0000000	1	2.297	2022/5/19 10:17:08	
		26.4609910	0.0000000	1	2.297	2022/5/19 10:17:08	
		-270.0000000		1	2.297	2022/5/19 10:17:08	
		-270.0000000		1	2.297	2022/5/19 10:17:08	
		-270.0000000		1	2.297	2022/5/19 10:17:08	
		-270.0000000		1	2.297	2022/5/19 10:17:08	
		-270.0000000		1	2.297	2022/5/19 10:17:08	
		-270.0000000		1	2.297	2022/5/19 10:17:08	
		-270.0000000		1	2.297	2022/5/19 10:17:08	
		26.0650250	0.0000000	1	3.298	2022/5/19 10:17:09	

• DCIR Data: Displays the test data of DC internal resistance.

1329777160765	132977716076590000										
DCResistance(Ω)	Run Time(S)	Cycle	Continue Time(S)	Running Date							
Step No:9											
0.1922202		1	46.949	2022/5/23 9:25:07							


Tool

This chapter introduces system tool function, including database configuration, server settings, user manager and system log query.

5.1 Database Configuration

All test data of ITS5300 test system are saved in the database. During test system installation, the database has been installed and configured. For future change of database configuration, the user can select Tool > DataBase Configuration on the main interface of ITS5300 system.

Input the database information in the following DataBase Configuration window.

🔯 Database Config	juration	×		
Host	192 . 168 . 2 . 221			
Port	3308			
Database	it9320_std_V50			
User Name	root			
Password				
OK Cancel				

Filling information shall be consistent with the information configured during database creation. For detailed description of database creation, refer to the *DB info.txt* file in Installation package path.

5.2 Server Settings

ITS5300 Test System is divided into Client and Server. At the Client, the user can run test and check test results. At the Server, the user can process all tasks and data, and manage communication and connection between the system and the instrument.

The user can install Client and Server programs on the same PC or on different PCs. The Client program installation environment shall be convenient for operation, and the Server program installation environment shall be stable and convenient for connection with hardware devices.

During running of ITS5300 test system, it is necessary to run the Server program and the Client program simultaneously. All user operations shall be performed in the Client programs. Before logging in the Client programs, it is necessary to configure Client program address and ensure successful connection.

When the connection information of Server program changes, the user can change the information with the Server configuration function under the tool module.

The detailed operations are shown as follows.

- 1. Select Tool> Server Settings on the main interface.
- 2. Input the server address and port number to connect on the Server



Settings.

📄 🖻 Server 🗄	Settings		×
Server	127 . 0	. 0 . 1	
Port	8008		
	ОК	Cancel	

5.3 User Manager

In initial login of ITS5300 battery testing system, user name and password are Admin/123, and the user type is Administrator. After login, the user can add the user information and user permissions in the User Management module. Main page is as shown below.

🐳 User Manager								×
📑 Add 📄 Edit 🕤	Delete							
User Name	User Type	Test Run	Test Config	Statistic And	Template	Test Data	System Manager	
Admin	Administr	Allow	Allow	Allow	Allow	Allow	Allow	
Operation	Common User	Allow	Allow	Not Allow	Not Allow	Allow	Not Allow	
123	Common User	Allow	Allow	Not Allow	Not Allow	Not Allow	Not Allow	
zm	Common User	Allow	Allow	Not Allow	Allow	Allow	Allow	
12	Common User	Allow	Allow	Allow	Not Allow	Not Allow	Not Allow	
111	Common User	Allow	Allow	Allow	Not Allow	Allow	Not Allow	
				11				

Add User

- 1. Select Tool> User Manager on the main interface.
- 2. Click "Add" on the user manager interface.
- 3. Set the username, password, user type and user permissions.



📑 Add User		х
Username Password		
User Type	Common User 🔹	
Limit	 Test Run Test Config Statistic And Query Template Manager Test Data Manager System Manager 	
Memo	OK Cancel	

4. Click "OK", and the system prompts "Add user successful".

Edit User

- 1. Select Tool> User Manager on the main interface.
- 2. Select the user information to edit and click "Edit".

You can also double-click the user information to edit.

3. Edit the username, password and relevant limit information on the User Edit interface.

📝 User Edit		×
Username	Admin	
Password	***	
User Type	Administrator 👻	
Limit	 Test Run Test Config Statistic And Query Template Manager Test Data Manager System Manager 	
Memo	OK Cancel	

4. Click "OK" and the system prompts "Save successful".



Delete User

- 1. Select Tool> User Manager on the main interface.
- Select one user data record, and click "Delete".
 The system prompts to confirm deletion.
- 3. Click "OK".

The system deletes the selected user.

5.4 Manage Formula

The user can create a formula in this menu. After successful creation, the formula will serve as a condition in the cut-off conditions, alarm conditions and protection conditions for selection. The test is stopped or alarm and protection are generated when the formula after calculation meets the setting value.

Right click the left formula list to create the formula name, and right click the Formula Edit area to add operand and operator, and edit the required formula. The Formula Edit Area at the bottom will display the formula in real time based on the edited formula.

The user can manage related configurations of the formula based on the existing platform.

Formula	x
Published Unpublished MaxVolt Name2 Name3 Formula list	Platform Common
	Name3 = ABS(Voltage) + 10 Formula display area
	Save

Formula configuration steps are as follows:

1. Select the "Unpublished" tab, and right click in blank and select "Add".



Published	Unpublished
 MaxVolt Name2 Name3 Name4 	
	Add

2. Set the formula name, and click Enter for confirmation.

After the formula is successfully added, right click the formula and you can re-edit the formula name, delete the formula or publish the formula.



3. In the right Formula Edit Area, double click the box under "Operate" to set the property.



4. Right click the box under the "Operate" and select to add operator.

Published	Unpublished	Platform Common -
间 MaxVolt		
🧃 Name2		Operand Operator
🧃 Name3		
间 Name4		🛶 Add Operator
Name4		Add Operator

5. Double click the box under the "Operator" and select the operator, as shown below.



Published	Unpublished	Platform Common -
间 MaxVolt		
间 Name2		Operand Operator
间 Name3		Voltage
间 Name4		+
		*
		96

6. Right click the box under the "Operator" and select to add the operand.

Published	Unpublished	Platform Common 🔹
 MaxVolt Name2 Name3 Name4 		Operand Operator Voltage + Add Operand

7. After formula configuration is completed, click "Save".

Formula		×
Formula Published MaxVolt Name2 Name3 Name4	Platform Common Operand Operator Operand Operand Voltage +	×
	Name4 = Voltage + 20	
	Save	

5.5 System Log

The user can view the system login information in latest 2 months and clear all login information on this interface.



5.6 Setting Data Accuracy

In this interface, the user can select the interface data accuracy or report data accuracy, and set the number of data digits after the decimal point for the data displayed in the interface and that during data analysis.

5.7 Language

The user can switch software interface language according to the requirement. Select the desired language in Tool> Language setting. The change will take effect after restarting the system client.

Contact US

Thank you for purchasing ITECH products. If you have any doubt about this product, please contact us as follow.

- 1. Visit ITECH website www.itechate.com.
- 2. Select the most convenient contact for further consultation.