

enquiries@domuslighting.com.au | www.domuslighting.com.au

Installation Manual

Date: October 18, 2023 1:42 PM


Muro-Max Series

Specifications

Voltage:	240V	Lumen (±5%): 3000K 4000K 5000K	16W 1700lm 1800lm 1600lm	32W 3500lm 3600lm 3300lm	Dimmable:	No
Power:	16W/32W	Beam Angle:	100°		Operating Temp:	-20~+40° C
IP Rating:	IP65*	CCT:	3000K - 4000K -5000K		Power Frequency::	60Hz
CRI:	≥90	Lifespan:	50,000hrs		Power Consumption:	0.5W Aprox
Detection Range:	120°	Detection Distance:	2-10m (Adjustable)		Detection Moving Speed:	0.6-1.5m/s
Rated Load:	Max 300W					
* Sensor cover must shield Lux & time settings to retain IP65 rating						

As the sensor responds to changes in temperature and movement please avoid the following:

- Pointing the sensor towards objects with highly reflective surfaces
- Mouting the sensor near heat sources, such as heating vents, air conditioning units
- Pointing the sensor towards objects that may move in the wind



Waterproof Installation Tips:


- Fasten the waterproof gasket into the mounting screws
- Feed the cable through the waterproof grommet
- Feed the cable through the cable gland and tighten
- Use water resistant silicone to seal and visible holes





enquiries@domuslighting.com.au | www.domuslighting.com.au

Installation Manual



DOMUS®

29–31 Richland St. Kingsgrove. Sydney NSW 2208 Australia Phone: 02 9554 9600 | Fax: 02 9554 9433 enguiries@domuslighting.com.au | www.domuslighting.com.au

Installation Manual

Function

- 1. **Time Adjustable:** The time adjustment controls how the light will stay after the motion has been detected. Turn the time control knob clockwise to increase (up to about 12 minutes) how long the lights stay on or anti-clockwise to decrease (down to about 5 seconds) the time delay.
- 2. Lux adjustment: The Lux adjustment controls sensor mode under different setting. Turn the Lux control knob clockwise to (**), it is daytime mode, the lamp can induct properly at both daytime and night. Turn the Lux control knob anti-clockwise to (), it is night mode, the lamp can induct properly only at night. Please adjust the control knob according to the picture 1, if rotate to hard with 360 degree, the knob will be broken or cannot be adjusted normally.
- 3. Manual mode: When there has no need for induction setting, start manual mode, the lamp will operate without induction fuction for a long time, once there has induction demand, the lamp should be operated by hand and start automatic mode.
 - 3.1 Manual Mode functions:
 - a. Only the lamp can operate be operated properly can manual mode be started
 - b. Enter into manual mode; turn Off the lamp twice (OFF-ON-OFF-ON) with in 0.5s~2S when the lamp operate properly, the the lamp will eprate without induction function for 5 hours, after the lamp will chnage into induction mode automatically in 1~2 minutes, then it means failed enter, need to try again.
 - c. Exit manual mode; turn off lamp twice (OFF-ON-OFF-ON) within 0.55~25 when the lamp operate properly, then the lamp will be operated with induction function.

