



**Albatros**  
3.1.9

## ***Numeric control***

---



**Tecnologie e Prodotti per l'Automazione**

This documentation is property of TPA S.p.A.  
Any unauthorized duplication is forbidden.  
The Company reserves the right to modify the contents at  
any time.

---

# Table of Contents

|          |  |           |
|----------|--|-----------|
| <b>1</b> | <b>Introduction</b>  | <b>1</b>  |
| 1.1      | How to use this manual                                       | 1         |
| 1.2      | Work windows   | 1         |
| <b>2</b> | <b>System composition</b>                                    | <b>3</b>  |
| 2.1      | Access rights to the system                                  | 3         |
| 2.2      | Multilingual support   | 3         |
| 2.3      | Typical architecture of the system                           | 3         |
| 2.4      | Organisation and logic configuration                         | 5         |
| 2.5      | Devices  | 7         |
| <b>3</b> | <b>Synoptic View</b>   | <b>9</b>  |
| 3.1      | Using the Synoptic View                                      | 9         |
| 3.2      | How to operate on the Synoptic View                          | 9         |
| 3.3      | How to act on Devices  | 9         |
| 3.4      | Manual Axes Movement   | 9         |
| <b>4</b> | <b>Technological and Tools parameters</b>                    | <b>11</b> |
| 4.1      | Technological Parameter window                               | 11        |
| 4.2      | Tools Parameter Window                                       | 12        |
| <b>5</b> | <b>Diagnostic</b>  | <b>15</b> |
| 5.1      | The Diagnostic window  | 15        |
| 5.2      | Diagnostic window composition                                | 15        |
| 5.3      | Representation of the Devices                                | 15        |
| 5.4      | Interacting with Devices                                     | 16        |
| 5.5      | List of navigation keys to navigate through a tree structure | 17        |
| 5.6      | Axis calibration control board                               | 17        |
| <b>6</b> | <b>System Errors</b>   | <b>21</b> |
| 6.1      | Introduction to System Errors                                | 21        |
| 6.2      | Errors generated by axes control                             | 22        |
| 6.2.1    | 1 AxisName: incorrect encoder connection                     | 22        |
| 6.2.2    | 2 AxisName: not ended movement                               | 22        |
| 6.2.3    | 3 AxisName: servoerror                                       | 22        |
| 6.2.4    | 4 AxisName: limit switch positive                            | 23        |
| 6.2.5    | 5 AxisName: limit switch negative                            | 23        |
| 6.2.6    | 6 AxisName: error writing SLM data                           | 23        |
| 6.2.7    | 7 AxisName: error reading SLM data                           | 23        |
| 6.2.8    | 8 AxisName: error executing SLM command                      | 23        |
| 6.2.9    | 9 AxisName: communication error                              | 23        |

|               |  |           |
|---------------|--|-----------|
| <b>6.2.10</b> | <b>10 AxisName: the Real-Time execution is faster than the profile construction</b>                              | <b>24</b> |
| <b>6.3</b>    | <b>Errors generated by remote I/O</b>  | <b>24</b> |
| <b>6.3.1</b>  | <b>262 Test failed on dual-port memory of remote IO</b>  | <b>24</b> |
| <b>6.3.2</b>  | <b>2049 Receiver number: incorrect configuration</b>   | <b>24</b> |
| <b>6.3.3</b>  | <b>2050 Receiver number: disconnected</b>  | <b>24</b> |
| <b>6.3.4</b>  | <b>2051 Receiver number: reconnected</b>   | <b>24</b> |
| <b>6.3.5</b>  | <b>2052 Receiver number: error in reading Output not connected number<br/>OutputNumber</b>                       | <b>25</b> |
| <b>6.3.6</b>  | <b>2053 Receiver number: error on the expansion module number ModuleNumber</b>                                   | <b>25</b> |
| <b>6.3.7</b>  | <b>2054 Receiver number: wrong type</b>  | <b>25</b> |
| <b>6.3.8</b>  | <b>2055 Receiver number: initialized</b>   | <b>25</b> |
| <b>6.3.9</b>  | <b>2056 Receiver number: +24 V DC power fail</b>   | <b>25</b> |
| <b>6.3.10</b> | <b>2057 GreenBus power fail</b>  | <b>25</b> |
| <b>6.3.11</b> | <b>2058 Receiver number: error reading DeviceType DeviceName</b>   | <b>26</b> |
| <b>6.3.12</b> | <b>2059 Test failed on dualport memory of transmitter</b>  | <b>26</b> |
| <b>6.3.13</b> | <b>2060 Error initializing transmitter</b>   | <b>26</b> |
| <b>6.3.14</b> | <b>2061 Error transmitting firmware to transmitter</b>   | <b>26</b> |
| <b>6.3.15</b> | <b>2062 Error transmitting configuration to transmitter</b>  | <b>26</b> |
| <b>6.3.16</b> | <b>2063 Error transmitting configuration to receiver</b>   | <b>27</b> |
| <b>6.3.17</b> | <b>2064 Receiver number: firmware version not compatible</b>   | <b>27</b> |
| <b>6.3.18</b> | <b>2065 Receiver number: error in an asynchronous communication</b>  | <b>27</b> |
| <b>6.3.19</b> | <b>2066 Receiver number: generic error</b>   | <b>27</b> |
| <b>6.3.20</b> | <b>2067 Receiver number: error during the transmission of the configuration</b>                                  | <b>27</b> |
| <b>6.3.21</b> | <b>2068 Receiver number: internal error no. errornumber</b>  | <b>27</b> |
| <b>6.3.22</b> | <b>2069 Receiver number: power supply error +24 Vcc bench number</b>   | <b>27</b> |
| <b>6.3.23</b> | <b>4610 Plug number: error reading DeviceType DeviceName</b>   | <b>28</b> |
| <b>6.4</b>    | <b>Errors generated by Mechatrolink II</b>   | <b>28</b> |
| <b>6.4.1</b>  | <b>2308 Plug PlugNumber: inzialization failed. A parameter configuration setting was<br/>not correct</b>         | <b>28</b> |
| <b>6.4.2</b>  | <b>2341 Plug PlugNumber: the number of servo drives exceeds the maximum allowed</b>                              | <b>28</b> |
| <b>6.4.3</b>  | <b>2342 Plug PlugNumber: the hardware address of the Servo servo drive exceeds the<br/>maximum value allowed</b> | <b>28</b> |
| <b>6.4.4</b>  | <b>2349 Plug PlugNumber: servodrive SERVO is not connected</b>   | <b>29</b> |
| <b>6.5</b>    | <b>Errors generated by the CanBUS control</b>  | <b>29</b> |
| <b>6.5.1</b>  | <b>2761 Plug CAN number: node number: not connected</b>  | <b>29</b> |
| <b>6.5.2</b>  | <b>2762 Node number: replugged</b>   | <b>29</b> |
| <b>6.5.3</b>  | <b>2763 Node number: error missing transmission</b>  | <b>29</b> |
| <b>6.5.4</b>  | <b>2764 Node number: error missing answer</b>  | <b>29</b> |
| <b>6.5.5</b>  | <b>2765 Node number: inzialized</b>  | <b>30</b> |
| <b>6.5.6</b>  | <b>2766 Fault condition on CAN interface</b>   | <b>30</b> |
| <b>6.5.7</b>  | <b>2767 CAN open state loss</b>  | <b>30</b> |
| <b>6.5.8</b>  | <b>2768 Node number: error - PDO has not been received</b>   | <b>30</b> |
| <b>6.5.9</b>  | <b>2769 Node number: error receiving a non-configured node</b>   | <b>30</b> |
| <b>6.5.10</b> | <b>2770 Node number: wrong configuration</b>   | <b>30</b> |
| <b>6.5.11</b> | <b>2771 Node number: SDO communication error</b>   | <b>30</b> |
| <b>6.5.12</b> | <b>2772 Timeout on querying nodes CAN cycle</b>  | <b>30</b> |
| <b>6.5.13</b> | <b>3073 Node number: emergency error no.</b>   | <b>30</b> |
| <b>6.5.14</b> | <b>3074 Node number: internal CAN error no.</b>  | <b>31</b> |
| <b>6.5.15</b> | <b>3088 CAN Board number: Node NUMNODO: SDO communication error n.<br/>NUMERRORE - description</b>               | <b>31</b> |
| <b>6.6</b>    | <b>Errors generated by bus Powerlink control</b>   | <b>31</b> |
| <b>6.6.1</b>  | <b>2817 PowwerLink board number: none</b>  | <b>31</b> |
| <b>6.6.2</b>  | <b>2818 PowerLink board number: Type of CN unknown</b>   | <b>31</b> |
| <b>6.6.3</b>  | <b>2819 PowerLink board number: wrong MN number</b>  | <b>31</b> |
| <b>6.6.4</b>  | <b>2820 PowerLink board number: wrong CN number</b>  | <b>31</b> |
| <b>6.6.5</b>  | <b>2822 PowerLink board number: Multiplexing setup error</b>   | <b>32</b> |
| <b>6.6.6</b>  | <b>2823 PowerLink board number: Board initialisation error</b>   | <b>32</b> |

|        |  |    |
|--------|--|----|
| 6.6.7  | 2824 PowerLink board number: Wrong setting of the master board                   | 32 |
| 6.6.8  | 2825 PowerLink board number: Bus control frequency not correct                   | 32 |
| 6.6.9  | 2826 PowerLink board number: Device connected to a board not configured          | 32 |
| 6.6.10 | 2827 PowerLink board number: Wrong Board Number                                  | 32 |
| 6.6.11 | 2828 PowerLink board number: Disabling a board                                   | 32 |
| 6.6.12 | 2829 PowerLink board number: Wrong PDO dimension                                 | 33 |
| 6.7    | Errors generated by bus EtherCAT control   | 33 |
| 6.7.1  | 3329 Error in communication socket initialisation                                | 33 |
| 6.7.2  | 3330 Error while scanning the EtherCAT network                                   | 33 |
| 6.7.3  | 3331 Error in the configuration of the transmission mailbox                      | 33 |
| 6.7.4  | 3332 Error in the configuration of the receive mailbox                           | 33 |
| 6.7.5  | 3333 PowerLink board number: Error in the kind of expansions of the NUMNODO node | 33 |
| 6.7.6  | 3334 Error during the configuration of the PDOs                                  | 34 |
| 6.7.7  | 3335 NUMNODO node in ErrorNumber alarm   | 34 |
| 6.7.8  | 3336 EtherCAT board number: the NUMNODO node expansion number is wrong           | 35 |
| 6.7.9  | 4400 The node has not not responded to the request                               | 35 |
| 6.8    | Errors generated by initialization   | 35 |
| 6.8.1  | 769 Error in software configuration  | 35 |
| 6.8.2  | 770 Wrong IRQ number in configuration  | 35 |
| 6.8.3  | 772 Error reading backup memory  | 36 |
| 6.8.4  | 773 Reached maximum number of axes in configuration                              | 36 |
| 6.8.5  | 774 Axes Real-Time not running   | 36 |
| 6.8.6  | 775 Not enough time for GPL execution  | 36 |
| 6.8.7  | 776 Real-Time execution time too long  | 36 |
| 6.8.8  | 777 Watch Dog timeout  | 37 |
| 6.8.9  | 778 Main firmware code is blocked  | 37 |
| 6.8.10 | 779 Error in opening communication channel                                       | 37 |
| 6.8.11 | 1025 Plug PlugNumber: don't reply  | 37 |
| 6.8.12 | 1026 Plug PlugNumber: error on axes plug firmware transmission                   | 37 |
| 6.8.13 | 1028 Plug PlugNumber: firmware not present                                       | 37 |
| 6.8.14 | 1029 Plug PlugNumber: MAIN blocked   | 37 |
| 6.8.15 | 1030 Plug PlugNumber: axes control blocked                                       | 38 |
| 6.8.16 | 1031 Plug PlugNumber: initialization error                                       | 38 |
| 6.8.17 | 1032 Plug PlugNumber: test failed in dual-port memory                            | 38 |
| 6.8.18 | 1033 Plug PlugNumber: firmware Boot code is not running                          | 38 |
| 6.8.19 | 1034 Plug PlugNumber: IRQ could not be set                                       | 38 |
| 6.8.20 | 1035 Plug PlugNumber: not present  | 38 |
| 6.8.21 | 1036 Plug PlugNumber: error in software configuration                            | 39 |
| 6.8.22 | 1037 Plug PlugNumber: failed opening dualport memory                             | 39 |
| 6.8.23 | 1038 Plug PlugNumber: error in ISA bus reading                                   | 39 |
| 6.8.24 | 1039 Plug PlugNumber: Watch Dog timeout  | 39 |
| 6.8.25 | 1040 Plug PlugNumber: +24 VDC power failed                                       | 39 |
| 6.8.26 | 1041 Plug PlugNumber: +24 VDC SLM power failed                                   | 39 |
| 6.8.27 | 1042 Plug PlugNumber: +5 VDC power failed  | 39 |
| 6.8.28 | 1043 Plug PlugNumber: axes power failed  | 40 |
| 6.8.29 | 1044 Plug PlugNumber: disconnected   | 40 |
| 6.8.30 | 1045 Plug PlugNumber: connected  | 40 |
| 6.8.31 | 1046 Plug PlugNumber: initialized  | 40 |
| 6.8.32 | 1047 Plug PlugNumber: software configuration not permitted                       | 40 |
| 6.8.33 | 1048 Plug PlugNumber: axis analog output write error                             | 40 |
| 6.8.34 | 1049 Plug PlugNumber: analog output write error                                  | 40 |
| 6.8.35 | 1050 Plug PlugNumber: main power supply error                                    | 41 |
| 6.8.36 | 1051 Plug PlugNumber: firmware Main code is corrupt                              | 41 |
| 6.8.37 | 1052 Plug PlugNumber: boot code is running                                       | 41 |
| 6.8.38 | 1053 Plug PlugNumber: axes Watch Dog Expired                                     | 41 |
| 6.8.39 | 1054 Plug PlugNumber: axes Real-Time not running                                 | 41 |

|                |   |           |
|----------------|---|-----------|
| <b>6.8.40</b>  | <b>1055 Watchdog expired for plug PlugNumber</b>  | <b>41</b> |
| <b>6.8.41</b>  | <b>1056 Plug PlugNumber: CAN Interface power failed</b>   | <b>42</b> |
| <b>6.8.42</b>  | <b>1057 Plug NumeroPlug: Errore interno numero NumeroErrore</b>                                   | <b>42</b> |
| <b>6.9</b>     | <b>Errors generated by memory management</b>  | <b>42</b> |
| <b>6.9.1</b>   | <b>1281 Error in the memory allocation on the heap area</b>                                       | <b>42</b> |
| <b>6.9.2</b>   | <b>1286 Error handling heap</b>   | <b>42</b> |
| <b>6.9.3</b>   | <b>1287 Too many heap memory deallocations</b>  | <b>42</b> |
| <b>6.9.4</b>   | <b>1289 Error creating global variables</b>   | <b>42</b> |
| <b>6.9.5</b>   | <b>1290 Error in the dimension on non volatile variables</b>                                      | <b>42</b> |
| <b>6.9.6</b>   | <b>1291 Error in the dimension of read only variables</b>   | <b>43</b> |
| <b>6.10</b>    | <b>Errors generated by faults</b>   | <b>43</b> |
| <b>6.10.1</b>  | <b>1559 Breakpoint Trace</b>  | <b>43</b> |
| <b>6.10.2</b>  | <b>1569 Invalid microprocessor operating code</b>   | <b>43</b> |
| <b>6.10.3</b>  | <b>1586 INTEGER value division by zero</b>  | <b>43</b> |
| <b>6.10.4</b>  | <b>1600 Overflow in a floating point operation</b>  | <b>43</b> |
| <b>6.10.5</b>  | <b>1601 Underflow in a floating point operation</b>   | <b>43</b> |
| <b>6.10.6</b>  | <b>1602 Invalid argument in a floating point operation</b>  | <b>44</b> |
| <b>6.10.7</b>  | <b>1603 Floating point value divided by zero</b>  | <b>44</b> |
| <b>6.10.8</b>  | <b>1604 Incorrect result in a floating point operation</b>  | <b>44</b> |
| <b>6.10.9</b>  | <b>1605 Incorrect value for a floating point data</b>   | <b>44</b> |
| <b>6.10.10</b> | <b>1728 Attempt to get access to an invalid address</b>   | <b>44</b> |
| <b>6.10.11</b> | <b>1736 Data not aligned</b>  | <b>44</b> |
| <b>6.10.12</b> | <b>1735 Generic exception</b>   | <b>44</b> |
| <b>6.10.13</b> | <b>1801 Temperature alarm</b>   | <b>45</b> |
| <b>6.10.14</b> | <b>1802 Fan alarm</b>   | <b>45</b> |
| <b>6.10.15</b> | <b>1803 Unstable CPU frequency</b>  | <b>45</b> |
| <b>6.11</b>    | <b>Errors generated by GPL functions</b>  | <b>45</b> |
| <b>6.11.1</b>  | <b>4097 The DeviceType DeviceName device is not configurated</b>                                  | <b>45</b> |
| <b>6.11.2</b>  | <b>4098 Global variable VariableName missing</b>  | <b>45</b> |
| <b>6.11.3</b>  | <b>4099 Function FunctionName missing</b>   | <b>45</b> |
| <b>6.11.4</b>  | <b>4101 Inconsistent axis AxisName management</b>   | <b>46</b> |
| <b>6.11.5</b>  | <b>4105 Instruction not executable on step motor axis AxisName</b>                                | <b>46</b> |
| <b>6.11.6</b>  | <b>4106 Remote module of the setp-by-step axis AxisName is not connected</b>                      | <b>46</b> |
| <b>6.11.7</b>  | <b>4107 SYSOK instruction with incorrect arguments</b>  | <b>46</b> |
| <b>6.11.8</b>  | <b>4108 AxisName: Final quote beyond software limits</b>  | <b>46</b> |
| <b>6.11.9</b>  | <b>4110 Wrong speed</b>   | <b>46</b> |
| <b>6.11.10</b> | <b>4111 Negative Acceleration on axis AxisName</b>  | <b>47</b> |
| <b>6.11.11</b> | <b>4112 Negative Deceleration on axis AxisName</b>  | <b>47</b> |
| <b>6.11.12</b> | <b>4113 Axis AxisName: SLM command TimeOut expired</b>  | <b>47</b> |
| <b>6.11.13</b> | <b>4114 Axis AxisName: reset on Fast Input not effected</b>                                       | <b>47</b> |
| <b>6.11.14</b> | <b>4115 Axis AxisName: zero pulse not found</b>   | <b>47</b> |
| <b>6.11.15</b> | <b>4353 Unknown instruction operational code (Function: FunctionName line:LineNumber)</b>         | <b>47</b> |
| <b>6.11.16</b> | <b>4354 Incorrect mathematical operation (Function: FunctionName: LineNumber)</b>                 | <b>48</b> |
| <b>6.11.17</b> | <b>4355 Incorrect address of matrix or vector (Function: FunctionName line: LineNumber)</b>       | <b>48</b> |
| <b>6.11.18</b> | <b>4356 Instruction RET without CALL (Function: FunctionName line: LineNumber)</b>                | <b>48</b> |
| <b>6.11.19</b> | <b>4357 Local variable missing (Function:FunctionName line LineNumber)</b>                        | <b>48</b> |
| <b>6.11.20</b> | <b>4358 Jump label missing Function: FunctionName line: LineNumber)</b>                           | <b>48</b> |
| <b>6.11.21</b> | <b>4359 Incorrect macro argument (Function:FunctionName line: LineNumber)</b>                     | <b>48</b> |
| <b>6.11.22</b> | <b>4360 Error in the memory allocation for executing (Function: FunctionName line:LineNumber)</b> | <b>49</b> |
| <b>6.11.23</b> | <b>4361 Too many tasks enabled (Function: FunctionName line: LineNumber)</b>                      | <b>49</b> |
| <b>6.11.24</b> | <b>4362 Incorrect matrix format (Function: FunctionName line: LineNumber)</b>                     | <b>49</b> |
| <b>6.11.25</b> | <b>4363 Too many active ONINPUT instruction (Function: FunctionName line:LineNumber)</b>          | <b>49</b> |

|         |  |           |
|---------|--|-----------|
| 6.11.26 | 4364 Already engaged axis with local reference (Function: FunctionName line:LineNumber)                    | 50        |
| 6.11.27 | 4365 Instruction ONINPUT actived on the same INPUT Function: FunctionName line: LineNumber                 | 50        |
| 6.11.28 | 4366 Too many ONFLAG instruction active (Function: FunctionName line: LineNumber)                          | 50        |
| 6.11.29 | 4367 Instruction ONFLAG actived on the same FLAG (Function: FunctionName line:LineNumber)                  | 50        |
| 6.11.30 | 4368 A ReadOnly variable writing has been attempted (Function: FunctionName line: Line Number)             | 50        |
| 6.11.31 | 4369 Too many master axes active (Function: FunctionName line: LineNumber)                                 | 51        |
| 6.11.32 | 4370 Too many slave axes active (Function: FunctionName line: LineNumber)                                  | 51        |
| 6.11.33 | 4372 Incorrect use of an instruction (Function: FunctionName line LineNumber)                              | 51        |
| 6.11.34 | 4373 Can't read feed rate (Function: FunctionName line: LineNumber)  | 51        |
| 6.11.35 | 4374 Too many IPC instruction in execution (Function: FunctionName line: LineNumber)                       | 51        |
| 6.11.36 | 4375 Not all axes are connected to the same board (Function: FunctionName line: LineNumber)                | 51        |
| 6.11.37 | 4378 Instruction not enabled (Function: FunctionName line LineNumber)                                      | 52        |
| 6.11.38 | 4379 Instruction can't be used in function called by events (Function: FunctionName line: LineNumber)      | 52        |
| 6.11.39 | 4380 Too many writing request into backup memory area (Function: FunctionName line: LineNumber)            | 52        |
| 6.11.40 | 4381 Can't use a serial channel not yet open (Function: FunctionName line: LineNumber)                     | 52        |
| 6.11.41 | 4382 Can't open a serial channel already open (Function: FunctionName line: LineNumber)                    | 52        |
| 6.11.42 | 4383 Too many auxiliary processes open (Function: FunctionName line: LineNumber)                           | 52        |
| 6.11.43 | 4384 Auxiliary process not in execution (Function: FunctionName line: LineNumber)                          | 53        |
| 6.11.44 | 4385 Attempt to open an auxiliary process from another task (Function: FunctionName line: LineNumber)      | 53        |
| 6.11.45 | 4386 Attempt to use a CanBUS communication port not yet opened (Function: FunctionName line: LineNumber)   | 53        |
| 6.11.46 | 4388 Attempt to close a CanBUS communication port not yet opened (Function: FunctionName line: LineNumber) | 53        |
| 6.11.47 | 4387 Error opening CanBUS communication (Function: FunctionName line: LineNumber)                          | 53        |
| 6.11.48 | 4389 Attempt to open a CanBUS communication already opened (Function: FunctionName line: LineNumber)       | 53        |
| 6.11.49 | 4390 CanBUS communication error (Function: FunctionName line: LineNumber)                                  | 54        |
| 6.11.50 | 4391 Error activating SYSOK (Function: FunctionName line: LineNumber)                                      | 54        |
| 6.11.51 | 4392 Synchronized movement channel not opened (Function: FunctionName line: LineNumber)                    | 54        |
| 6.11.52 | 4393 No lines to process (Function: FunctionName line: LineNumber)   | 54        |
| 6.11.53 | 4394 Too many cycle errors (Function: FunctionName line: LineNumber)                                       | 54        |
| 6.11.54 | 4395 Too many messages (Function: FunctionName line: LineNumber)   | 54        |
| 6.11.55 | 4397 Stack overflow on the function FunctionName (Function: FunctionName line: LineNumber)                 | 55        |
| 6.11.56 | 4398 Stack underflow on the function FunctionName (Function: FunctionName line: LineNumber)                | 55        |
| 6.11.57 | 4399 Parameter out of range (Function: FunctionName line: LineNumber)                                      | 55        |
| 6.11.58 | 4865 The definition of the machine for the interpolation (G216 or G217) is missing                         | 55        |
| 6.11.59 | 4866 The definition of the indeces of the selected machine configuration (M6) is missing                   | 55        |
| 6.12    | <b>Errors generated by CNCTPA communication driver</b>   | <b>55</b> |
| 6.12.1  | 16385 Disconnected module  | 55        |
| 6.12.2  | 16386 Connected module   | 56        |
| 6.12.3  | 16387 Reconnected module   | 56        |
| 6.12.4  | 16388 Initialized module   | 56        |
| 6.12.5  | 16389 Module interrupted connection  | 56        |
| 6.12.6  | 16641 AlbRtx doesn't answer to the commands  | 56        |

|                |   |           |
|----------------|---|-----------|
| <b>6.12.7</b>  | <b>16642 AlbNet doesn't answer to the commands</b>                                    | <b>56</b> |
| <b>6.12.8</b>  | <b>16643 Operating System doesn't allow use of RTX</b>                                | <b>57</b> |
| <b>6.12.9</b>  | <b>16644 Operating System doesn't allow use of AlbNet</b>                             | <b>57</b> |
| <b>6.12.10</b> | <b>16645 Error sending firmware code ...</b>  | <b>57</b> |
| <b>6.12.11</b> | <b>16646 Could not restart firmware code</b>  | <b>57</b> |
| <b>6.12.12</b> | <b>16647 Error while sending CanBUS hardware configuration</b>                        | <b>57</b> |
| <b>6.12.13</b> | <b>16897 RTX not installed</b>  | <b>57</b> |
| <b>6.12.14</b> | <b>16898 User has no Administrator rights</b>   | <b>58</b> |
| <b>6.12.15</b> | <b>16899 Wrong dimension of module RAM</b>  | <b>58</b> |
| <b>6.12.16</b> | <b>16900 Incorrect module IP address</b>  | <b>58</b> |
| <b>6.12.17</b> | <b>16901 Module is already connected to another equipment</b>                         | <b>58</b> |
| <b>6.12.18</b> | <b>16902 The module is not configured</b>   | <b>58</b> |
| <b>6.12.19</b> | <b>16903 Firewall settings prevent communication</b>                                  | <b>58</b> |
| <b>6.12.20</b> | <b>16904 Network card not present or disabled</b>                                     | <b>59</b> |
| <b>6.12.21</b> | <b>16905 Main firmware code missing</b>   | <b>59</b> |
| <b>6.12.22</b> | <b>16906 RTX version incompatible with main firmware code</b>                         | <b>59</b> |
| <b>6.12.23</b> | <b>16907 Operating system version incompatible with the Main code of the firmware</b> | <b>59</b> |
| <b>6.12.24</b> | <b>17153 PLUGTYPE: firmware code of GreenBus transmitter not found</b>                | <b>59</b> |
| <b>6.12.25</b> | <b>17154 PLUGTYPE: firmware code of GreenBus transmitter damaged</b>                  | <b>59</b> |
| <b>6.12.26</b> | <b>17155 PLUGTYPE: error sending bootstrap code of GreenBus transmitter</b>           | <b>59</b> |
| <b>6.12.27</b> | <b>17156 PLUGTYPE: error sending main code to GreenBus transmitter</b>                | <b>60</b> |
| <b>6.12.28</b> | <b>17157 PLUGTYPE: bootstrap code not found</b>                                       | <b>60</b> |
| <b>6.12.29</b> | <b>17158 PLUGTYPE: main code not found</b>  | <b>60</b> |
| <b>6.12.30</b> | <b>17159 PLUGTYPE: error sending bootstrap code</b>                                   | <b>60</b> |
| <b>6.12.31</b> | <b>17160 PLUGTYPE: error sending main code</b>  | <b>60</b> |
| <b>6.12.32</b> | <b>17409 Could not send auxiliary executable ...</b>                                  | <b>60</b> |
| <b>6.12.33</b> | <b>17410 Could not run auxiliary executable ...</b>                                   | <b>61</b> |
| <b>6.12.34</b> | <b>17665 Communication library not found ...</b>                                      | <b>61</b> |
| <b>6.12.35</b> | <b>17666 Error using communication library ...</b>                                    | <b>61</b> |
| <b>6.12.36</b> | <b>17667 DLLNAME: firmware code could not start running</b>                           | <b>61</b> |
| <b>6.12.37</b> | <b>17668 DLLNAME: could not get pointer to shared RAM</b>                             | <b>61</b> |
| <b>6.12.38</b> | <b>17669 DLLNAME: key 'Bin=' missing in TPA.INI</b>                                   | <b>61</b> |
| <b>6.12.39</b> | <b>17921 Could not send NODETPA ...</b>   | <b>61</b> |
| <b>6.12.40</b> | <b>17922 NODETPA did not restart ...</b>  | <b>62</b> |
| <b>6.12.41</b> | <b>17923 NODETPA not running ...</b>  | <b>62</b> |
| <b>6.12.42</b> | <b>18177 NodeTpa tried to access to an invalid address</b>                            | <b>62</b> |

## **7 System Configuration 63**

|              |                              |           |
|--------------|------------------------------|-----------|
| <b>7.1</b>   | <b>Introduction</b>          | <b>63</b> |
| <b>7.2</b>   | <b>Devices Configuration</b> | <b>63</b> |
| <b>7.2.1</b> | <b>Introduction</b>          | <b>63</b> |
| <b>7.2.2</b> | <b>Generic Device</b>        | <b>63</b> |
| <b>7.2.3</b> | <b>Digital output</b>        | <b>64</b> |
| <b>7.2.4</b> | <b>Analog input</b>          | <b>65</b> |
| <b>7.2.5</b> | <b>Axis</b>                  | <b>67</b> |
|              | Base Data                    | 67        |
|              | Movement parameters          | 67        |
|              | Interpolation parameters     | 68        |
|              | Other parameters             | 70        |
|              | Reference parameters         | 71        |
|              | Access levels                | 72        |
|              | Axes chaining                | 72        |
|              | Screw linearity correction   | 73        |
| <b>7.3</b>   | <b>Logical Configuration</b> | <b>74</b> |
| <b>7.3.1</b> | <b>Plant configuration</b>   | <b>74</b> |
| <b>7.3.2</b> | <b>Groups Configuration</b>  | <b>76</b> |



|              |  |            |
|--------------|--|------------|
| <b>7.3.3</b> | <b>Machine configuration</b>   | <b>79</b>  |
| <b>7.4</b>   | <b>Physical Configuration</b>  | <b>80</b>  |
| <b>7.4.1</b> | <b>System Configuration</b>  | <b>80</b>  |
| <b>7.4.2</b> | <b>Hardware Configuration</b>  | <b>81</b>  |
|              | How to write CANBUS.DEF. file  | 84         |
|              | How to write CANBUS.DEF file for S-CAN devices per dispositivi S-CAN | 86         |
|              | Characteristics of the EtherCat Management in Albatros               | 88         |
|              | Foreword   | 88         |
|              | ECATBUS.DEF file   | 88         |
|              | EtherCAT Hardware configuration                                      | 89         |
|              | Description of a PDO   | 91         |
|              | Example of EtherCAT hardware configuration                           | 93         |
|              | Configuration of the virtual-physical EtherCAT links                 | 94         |
|              | Virtual-physical links in the TRS-CAT                                | 95         |
|              | Example of virtual-physical link                                     | 96         |
|              | How to write EPLBUS.def file   | 97         |
| <b>7.4.3</b> | <b>Virtual physical Configuration</b>                                | <b>99</b>  |
| <b>7.4.4</b> | <b>Cabling maps</b>  | <b>101</b> |
| <b>7.4.5</b> | <b>List of navigation keys to navigate through a tree structure</b>  | <b>101</b> |
| <b>8</b>     | <b>Development tools</b>   | <b>103</b> |
| <b>8.1</b>   | <b>Editor GPL</b>  | <b>103</b> |
| <b>8.1.1</b> | <b>GPL Editor functions</b>  | <b>103</b> |
| <b>8.1.2</b> | <b>Avalaible keyboard shortcut list</b>                              | <b>105</b> |
| <b>8.1.3</b> | <b>Insert Message</b>  | <b>106</b> |
| <b>8.1.4</b> | <b>Cryptography</b>  | <b>107</b> |
| <b>8.2</b>   | <b>Libraries</b>   | <b>108</b> |
| <b>8.2.1</b> | <b>Create and modify</b>   | <b>108</b> |
| <b>8.3</b>   | <b>Debug</b>   | <b>110</b> |
| <b>8.3.1</b> | <b>The debugger</b>  | <b>110</b> |
| <b>8.3.2</b> | <b>Task in execution</b>   | <b>111</b> |
| <b>8.3.3</b> | <b>All tasks</b>   | <b>112</b> |
| <b>8.3.4</b> | <b>Show call stack</b>   | <b>113</b> |
| <b>8.3.5</b> | <b>Breakpoints</b>   | <b>114</b> |
| <b>8.3.6</b> | <b>Variable content</b>  | <b>115</b> |
| <b>8.3.7</b> | <b>Available keyboard shortcut list</b>                              | <b>115</b> |
| <b>8.4</b>   | <b>Control initialization</b>  | <b>116</b> |
| <b>8.4.1</b> | <b>Network Connections</b>   | <b>116</b> |
| <b>8.4.2</b> | <b>Hardware Diagnostic</b>   | <b>117</b> |
| <b>8.5</b>   | <b>Test</b>  | <b>117</b> |
| <b>8.5.1</b> | <b>Print global on disk</b>  | <b>117</b> |
| <b>8.5.2</b> | <b>Start single function</b>   | <b>117</b> |
| <b>8.5.3</b> | <b>Message Import and Export</b>                                     | <b>118</b> |
| <b>8.6</b>   | <b>Tools</b>   | <b>119</b> |
| <b>8.6.1</b> | <b>Customise...</b>  | <b>119</b> |
| <b>8.7</b>   | <b>Browser</b>   | <b>121</b> |
| <b>8.7.1</b> | <b>The browser</b>   | <b>121</b> |
| <b>8.7.2</b> | <b>Identifier Search</b>   | <b>121</b> |
| <b>8.7.3</b> | <b>Available keyboard shortcut list</b>                              | <b>123</b> |
| <b>9</b>     | <b>GPL Language</b>  | <b>125</b> |
| <b>9.1</b>   | <b>Basic Feature</b>   | <b>125</b> |
| <b>9.1.1</b> | <b>Conventions and terminology</b>                                   | <b>125</b> |

|               |  |            |
|---------------|--|------------|
| <b>9.1.2</b>  | <b>Introduction to GPL language</b>              | <b>127</b> |
| <b>9.1.3</b>  | <b>Variables</b>                                 | <b>127</b> |
|               | Type of data                                     | 127        |
|               | Data conversion                                  | 129        |
|               | Declaration and Visibility of the variables      | 130        |
|               | Modifiers  | 130        |
|               | Assigning a RANGE                                | 131        |
|               | Writing and Reading Rights                       | 131        |
|               | Constants  | 132        |
| <b>9.1.4</b>  | <b>Predefined constants</b>                      | <b>132</b> |
| <b>9.1.5</b>  | <b>Keywords</b>                                  | <b>133</b> |
| <b>9.1.6</b>  | <b>Functions</b>                                 | <b>134</b> |
| <b>9.1.7</b>  | <b>Device parameters</b>                         | <b>136</b> |
| <b>9.1.8</b>  | <b>Multitasking</b>                              | <b>137</b> |
| <b>9.1.9</b>  | <b>Communication</b>                             | <b>138</b> |
| <b>9.1.10</b> | <b>Variables used in programming</b>             | <b>139</b> |
| <b>9.1.11</b> | <b>Axes</b>                                      | <b>139</b> |
| <b>9.1.12</b> | <b>Message handling in different languages</b>   | <b>141</b> |
| <b>9.1.13</b> | <b>System Error Management</b>                   | <b>141</b> |
| <b>9.1.14</b> | <b>Special functions</b>                         | <b>142</b> |
|               | Axis movement customization                      | 142        |
|               | Standard calibration and movement functions      | 144        |
|               | Function OnUIEnd                                 | 148        |
|               | Function OnUIPlugged#                            | 148        |
|               | Function OnUIUnplugged#                          | 148        |
| <b>9.2</b>    | <b>Instructions</b>                              | <b>148</b> |
| <b>9.2.1</b>  | <b>Conventions</b>                               | <b>148</b> |
| <b>9.2.2</b>  | <b>Types of instructions in the GPL language</b> | <b>148</b> |
| <b>9.2.3</b>  | <b>Input/Output</b>                              | <b>155</b> |
|               | GETFEED  | 155        |
|               | GETVF  | 155        |
|               | INPANALOG  | 156        |
|               | INPBCD   | 156        |
|               | INPFLAGPORT                                      | 156        |
|               | INPPORT  | 156        |
|               | MULTIINPPORT                                     | 156        |
|               | MULTIOUTPORT                                     | 157        |
|               | MULTIRESETFLAG                                   | 157        |
|               | MULTIRESETOUT                                    | 157        |
|               | MULTISETFLAG                                     | 158        |
|               | MULTISETOUT                                      | 158        |
|               | MULTIWAITFLAG                                    | 158        |
|               | MULTIWAITINPUT                                   | 159        |
|               | OUTANALOG  | 159        |
|               | OUTBCD   | 159        |
|               | OUTFLAGPORT                                      | 160        |
|               | OUTPORT  | 160        |
|               | RESETFLAG  | 160        |
|               | RESETOUT   | 160        |
|               | SETFLAG  | 160        |
|               | SETOUT   | 161        |
|               | WAITFLAG   | 161        |
|               | WAITINPUT  | 161        |
|               | WAITPERSISTINPUT                                 | 162        |
| <b>9.2.4</b>  | <b>Axes</b>                                      | <b>162</b> |
|               | CHAIN  | 162        |
|               | CIRCABS  | 163        |

---

|                         |     |
|-------------------------|-----|
| CIRCINC                 | 164 |
| CIRCLE                  | 165 |
| COORDIN                 | 165 |
| DISABLECORRECTION       | 166 |
| EMERGENCYSTOP           | 167 |
| ENDMOV                  | 167 |
| ENABLECORRECTION        | 167 |
| FASTREAD                | 168 |
| FREE                    | 168 |
| HELICABS                | 169 |
| HELICINC                | 169 |
| JERKCONTROL             | 170 |
| JERKSMOOTH              | 170 |
| LINEARABS               | 171 |
| LINEARINC               | 171 |
| MOVABS                  | 172 |
| MOVINC                  | 172 |
| MULTIABS                | 173 |
| MULTINC                 | 174 |
| NORMAL                  | 175 |
| RESRIFLOC               | 175 |
| SETINDEXINTERP          | 175 |
| SETLABELINTERP          | 175 |
| SETPFLY                 | 176 |
| SETPFLYCHAINSTRAT       | 176 |
| SETPZERO                | 177 |
| SETQUOTECHAINSTRAT      | 177 |
| SETPZEROCCHAINSTRAT     | 177 |
| SETQUOTE                | 178 |
| SETRIFLOC               | 178 |
| SETTOLERANCE            | 178 |
| START                   | 180 |
| STARTINTERP             | 180 |
| STOP                    | 181 |
| SWITCHENC               | 181 |
| SYNCRROOPEN             | 181 |
| SYNCRROCLOSE            | 182 |
| SYNCRROMOVE             | 182 |
| SYNCRROSETACC           | 183 |
| SYNCRROSETDEC           | 183 |
| SYNCRROSETVEL           | 183 |
| SYNCRROSETFEED          | 183 |
| SYNCRROSTARTMOVE        | 184 |
| WAITCOLL                | 184 |
| WAITDEC                 | 185 |
| WAITREG                 | 185 |
| WAITSTILL               | 186 |
| WAITTARGET              | 186 |
| WAITWIN                 | 186 |
| WAITACC                 | 186 |
| Axis Parameter          | 187 |
| Reading/Writing         | 187 |
| DEVICEID                | 187 |
| GETAXIS                 | 187 |
| Point-to-point Movement | 192 |
| SETACC                  | 192 |
| SETDEC                  | 193 |

|                       |            |
|-----------------------|------------|
| SETDERIV              | 193        |
| SETFEED               | 193        |
| SETFEEDF              | 193        |
| SETFEEDFA             | 194        |
| SETINTEG              | 194        |
| SETMULTIFEED          | 194        |
| SETPROP               | 195        |
| SETVEL                | 195        |
| Interpolated Movement | 195        |
| LOOKAHEAD             | 195        |
| SETACCI               | 196        |
| SETACCLIMIT           | 196        |
| SETACCSTRATEGY        | 196        |
| SETAXPARTYPE          | 196        |
| SETCONTORNATURE       | 197        |
| SETDECI               | 197        |
| SETDERIVI             | 197        |
| SETFEEDFAI            | 198        |
| SETFEEDI              | 198        |
| SETFEEDFI             | 198        |
| SETINTEGI             | 199        |
| SETPROPI              | 199        |
| SETSLOWPARAM          | 199        |
| SETVELI               | 200        |
| SETVELILIMIT          | 200        |
| Coordinated Movement  | 200        |
| SETFEEDCOORD          | 200        |
| SETOFFSET             | 202        |
| Chained Movement      | 202        |
| RATIO                 | 202        |
| SETDYNRATIO           | 202        |
| Generic Parameters    | 203        |
| DYNLIMIT              | 203        |
| ENABLESTARTCONTROL    | 203        |
| NOTCHFILTER           | 204        |
| RESLIMNEG             | 204        |
| RESLIMPOS             | 204        |
| SETADJUST             | 205        |
| SETBACKLASH           | 205        |
| SETBIGWINFACTOR       | 207        |
| SETDEADBAND           | 207        |
| SETENCLIMIT           | 208        |
| SETINDEXEN            | 208        |
| SETINTEGTIME          | 208        |
| SETIRMPP              | 208        |
| SETLIMNEG             | 209        |
| SETLIMPOS             | 209        |
| SETMAXER              | 209        |
| SETMAXERNEG           | 210        |
| SETMAXERPOS           | 210        |
| SETPHASESINV          | 211        |
| SETMAXERTYPE          | 211        |
| SETREFINV             | 212        |
| SETRESOLUTION         | 212        |
| <b>9.2.5 Counter</b>  | <b>213</b> |
| DECOUNTER             | 213        |
| INCOUNTER             | 213        |

|               |  |            |
|---------------|--|------------|
|               | SETCOUNTER                             | 213        |
| <b>9.2.6</b>  | <b>Timer</b>                           | <b>213</b> |
|               | HOLDTIMER                              | 213        |
|               | SETTIMER                               | 214        |
|               | STARTTIMER                             | 214        |
| <b>9.2.7</b>  | <b>Variables, Vectors and Matrixes</b> | <b>214</b> |
|               | CLEAR                                  | 214        |
|               | FIND                                   | 214        |
|               | FINDB                                  | 215        |
|               | LASTELEM                               | 215        |
|               | LOCAL                                  | 215        |
|               | MOVEMAT                                | 216        |
|               | PARAM                                  | 216        |
|               | SETVAL                                 | 217        |
|               | SORT                                   | 217        |
| <b>9.2.8</b>  | <b>Strings</b>                         | <b>218</b> |
|               | ADDSTRING                              | 218        |
|               | CONTROLCHAR                            | 218        |
|               | LEFT                                   | 218        |
|               | LEN                                    | 219        |
|               | MID                                    | 219        |
|               | RIGHT                                  | 219        |
|               | SEARCH                                 | 219        |
|               | SETSTRING                              | 220        |
|               | STR                                    | 220        |
|               | VAL                                    | 220        |
| <b>9.2.9</b>  | <b>Communications</b>                  | <b>221</b> |
|               | CLEARRECEIVE                           | 221        |
|               | COMCLEARRXBUFFER                       | 221        |
|               | COMCLOSE                               | 221        |
|               | COMGETERROR                            | 221        |
|               | COMGETRXCOUNT                          | 222        |
|               | COMOPEN                                | 222        |
|               | COMREAD                                | 222        |
|               | COMREADSTRING                          | 223        |
|               | COMWRITE                               | 223        |
|               | COMWRITESTRING                         | 223        |
|               | RECEIVE                                | 223        |
|               | SEND                                   | 228        |
|               | SENDIPC                                | 233        |
|               | WAITIPC                                | 234        |
|               | WAITRECEIVE                            | 234        |
| <b>9.2.10</b> | <b>Mathematics</b>                     | <b>234</b> |
|               | ABS                                    | 234        |
|               | ADD                                    | 235        |
|               | AND                                    | 235        |
|               | ARCCOS                                 | 235        |
|               | ARCSIN                                 | 236        |
|               | ARCTAN                                 | 236        |
|               | COS                                    | 236        |
|               | DIV                                    | 236        |
|               | EXP                                    | 237        |
|               | EXPR                                   | 237        |
|               | LOG                                    | 238        |
|               | LOGDEC                                 | 238        |
|               | MOD                                    | 239        |
|               | MUL                                    | 239        |

|               |                        |            |
|---------------|------------------------|------------|
|               | NOT                    | 240        |
|               | OR                     | 240        |
|               | RANDOM                 | 240        |
|               | RESETBIT               | 241        |
|               | ROUND                  | 241        |
|               | SETBIT                 | 242        |
|               | SHIFTL                 | 242        |
|               | SHIFTR                 | 243        |
|               | SIN                    | 244        |
|               | SQR                    | 244        |
|               | SUB                    | 245        |
|               | TAN                    | 245        |
|               | TRUNC                  | 245        |
|               | XOR                    | 246        |
| <b>9.2.11</b> | <b>Multitasking</b>    | <b>246</b> |
|               | ENDMAIL                | 246        |
|               | ENDREALTIMETASK        | 247        |
|               | ENDTASK                | 247        |
|               | GETPRIORITYLEVEL       | 247        |
|               | GETREALTIME            | 247        |
|               | GETREALTIMECOUNT       | 247        |
|               | HOLDTASK               | 248        |
|               | RESUMETASK             | 248        |
|               | SENDMAIL               | 248        |
|               | SETPRIORITYLEVEL       | 249        |
|               | STARTTASK              | 249        |
|               | STARTREALTIMETASK      | 249        |
|               | STOPTASK               | 249        |
|               | WAITMAIL               | 250        |
|               | WAITTASK               | 250        |
| <b>9.2.12</b> | <b>Flux management</b> | <b>250</b> |
|               | CALL                   | 250        |
|               | FCALL                  | 251        |
|               | DELONFLAG              | 251        |
|               | DELONINPUT             | 251        |
|               | FOR/NEXT               | 251        |
|               | FRET                   | 252        |
|               | GOTO                   | 253        |
|               | IF/IFVALUE/IFTHENELSE  | 253        |
|               | IFACC                  | 254        |
|               | IFAND                  | 254        |
|               | IFBIT                  | 255        |
|               | IFBLACKBOX             | 256        |
|               | IFCHANGELEVEL          | 256        |
|               | IFCOUNTER              | 256        |
|               | IFDEC                  | 257        |
|               | IFDIR                  | 257        |
|               | IFERRAN                | 258        |
|               | IFERROR                | 258        |
|               | IFFLAG                 | 259        |
|               | IFOR                   | 260        |
|               | IFINPUT                | 260        |
|               | IFMESSAGE              | 261        |
|               | IFOUTPUT               | 261        |
|               | IFQUOTER               | 262        |
|               | IFQUOTET               | 262        |
|               | IFRECEIVED             | 263        |

|               |  |            |
|---------------|--|------------|
|               | IFREG  | 263        |
|               | IFSAME   | 264        |
|               | IFSTILL  | 264        |
|               | IFSTR  | 264        |
|               | IFTARGET                                       | 265        |
|               | IFTASKHOLD                                     | 265        |
|               | IFTASKRUN                                      | 266        |
|               | IFTIMER  | 266        |
|               | IFVEL  | 266        |
|               | IFWIN  | 267        |
|               | IFXOR  | 267        |
|               | ONERRSYS                                       | 268        |
|               | ONFLAG   | 269        |
|               | ONINPUT  | 269        |
|               | REPEAT/ENDREP                                  | 269        |
|               | RET  | 270        |
|               | SELECT   | 270        |
|               | TESTIPC  | 271        |
|               | TESTMAIL                                       | 271        |
| <b>9.2.13</b> | <b>Various</b>                                 | <b>272</b> |
|               | CLEARERRORS                                    | 272        |
|               | CLEARMESSAGES                                  | 272        |
|               | DEFMSG   | 273        |
|               | DELAY  | 274        |
|               | DELERROR                                       | 274        |
|               | DELMESSAGE                                     | 274        |
|               | ERROR  | 275        |
|               | IFDEF/ELSEDEF/ENDDEF                           | 276        |
|               | MESSAGE  | 278        |
|               | SYSFAULT                                       | 280        |
|               | SYSOK  | 280        |
|               | TYPEOF   | 280        |
|               | WATCHDOG                                       | 281        |
| <b>9.2.14</b> | <b>CANopen</b>                                 | <b>281</b> |
|               | TMSbus boards with CAN control                 | 281        |
|               | GETCNSTATE                                     | 281        |
|               | GETSDOERROR                                    | 281        |
|               | GETMNSTATE                                     | 282        |
|               | RECEIVEDPDO                                    | 282        |
|               | SENDPDO  | 282        |
|               | SETNMTSTATE                                    | 283        |
|               | Board CIF30                                    | 283        |
|               | CANOPENDRIVER                                  | 283        |
|               | CANCLOSEDRIVER                                 | 284        |
|               | CANRESETBOARD                                  | 284        |
|               | CANSETOBJECT                                   | 284        |
|               | CANGETOBJECT                                   | 284        |
| <b>9.2.15</b> | <b>Mechatrolink II</b>                         | <b>285</b> |
|               | MECCOMMAND                                     | 285        |
|               | MECGETPARAM                                    | 285        |
|               | MECGETSTATUS                                   | 286        |
|               | MECSETPARAM                                    | 288        |
| <b>9.2.16</b> | <b>PowerlinkII and EtherCAT</b>                | <b>288</b> |
|               | Instructions to initialize the Powerlink nodes | 288        |
|               | AXCONTROL                                      | 289        |
|               | ACTIVATEMODE                                   | 290        |
|               | AXSTATUS                                       | 290        |

|               |  |            |
|---------------|--|------------|
|               | CNBYDEVICE   | 292        |
|               | GETPDO   | 292        |
|               | HOMING   | 292        |
|               | READDICTIONARY   | 293        |
|               | SETPDO   | 293        |
|               | WRITEDICTIONARY  | 294        |
| <b>9.2.17</b> | <b>SLM</b>   | <b>294</b> |
|               | SLMCOMMAND   | 294        |
|               | SLMEEPROMDISABLE   | 294        |
|               | SLMEEPROMENABLE  | 294        |
|               | SLMGETEEPROM   | 295        |
|               | SLMGETPARAM  | 295        |
|               | SLMGETREGISTER   | 295        |
|               | SLMGETSTATUS   | 296        |
|               | SLMSETEEPROM   | 296        |
|               | SLMSETPARAM  | 296        |
|               | SLMSETREGISTER   | 296        |
| <b>9.2.18</b> | <b>Simulation</b>  | <b>297</b> |
|               | DISABLE  | 297        |
|               | DISABLEFORCEDINPUT                                       | 297        |
|               | ENABLE   | 297        |
|               | ENABLEFORCEDINPUT  | 297        |
|               | RESETFORCEDINPUT   | 298        |
|               | SETFORCEDANALOG  | 298        |
|               | SETFORCEDBCD   | 298        |
|               | SETFORCEDINPUT   | 298        |
|               | SETFORCEDPORT  | 299        |
| <b>9.2.19</b> | <b>Blackbox</b>  | <b>299</b> |
|               | ENDBLACKBOX  | 299        |
|               | PAUSEBLACKBOX  | 300        |
|               | STARTBLACKBOX  | 300        |
| <b>9.2.20</b> | <b>ISO</b>   | <b>300</b> |
|               | ISOG0  | 300        |
|               | ISOG1  | 301        |
|               | ISOG9  | 302        |
|               | ISOG90   | 302        |
|               | ISOG91   | 302        |
|               | ISOG93   | 302        |
|               | ISOG94   | 303        |
|               | ISOG216  | 303        |
|               | ISOG217  | 303        |
|               | ISOM2  | 304        |
|               | ISOM6  | 304        |
|               | ISOSETPARAM  | 305        |
|               | KINEMATICEXPR  | 306        |
| <b>9.2.21</b> | <b>Instructions which can not be used with interrupt</b> | <b>307</b> |
| <b>9.2.22</b> | <b>Instructions which are no longer available</b>        | <b>308</b> |
| <b>9.3</b>    | <b>Examples</b>  | <b>309</b> |
| <b>9.3.1</b>  | <b>Homing on Interrupt</b>                               | <b>309</b> |
| <b>9.3.2</b>  | <b>Axis movement server</b>                              | <b>310</b> |
| <b>9.3.3</b>  | <b>Main Cycle with error management</b>                  | <b>312</b> |
| <b>9.3.4</b>  | <b>Operations on strings</b>                             | <b>312</b> |
| <b>9.3.5</b>  | <b>Sequential / Parallel Execution</b>                   | <b>313</b> |
| <b>9.3.6</b>  | <b>Homing Routine</b>                                    | <b>314</b> |
| <b>9.3.7</b>  | <b>Synchronized movement</b>                             | <b>315</b> |
| <b>9.3.8</b>  | <b>Iso movements</b>                                     | <b>315</b> |







# 1 Introduction

## 1.1 How to use this manual

This user's guide describes the functions of *Albatros s'* numeric control. Thanks to the structure of the manual, getting to know the system and learning how to use it will be an easy task for the operator.

The main subjects of each section of the guide are:

- *Albatros s'* windows and tools.
- description of the typical architecture of a system, such as *Albatros* .
- how to display the devices and operate on them with manual and diagnostic functionality, using the Synoptic window.
- how to display Technological Parameters, Geometrical Parameters and Tools Parameter and how to modify them if necessary.
- how to display the Devices and operate on them with manual and diagnostic functionality.

---

To avoid overcharging this guide, for further information concerning the use of the *mouse, menus* and *toolbar* and all the current operative functions of Windows, we refer the reader to Windows Operative System manuals.

---

## 1.2 Work windows

There are various types of work windows, depending on the kind of operation required, and more than one can be kept open at the same time.

The types of windows are the following:

| <b>Window</b>                  | <b>Description</b>   |
|--------------------------------|--|
| <i>Main</i>                    | Albatros's main window. It allows you to call functions and contains all the other windows whose content depends on the specific application they represent. |
| <i>Synoptic</i>                | it contains a graphic representation of the machine, or of parts of the machine, and allows you to operate on them.  |
| <i>Technological Parameter</i> | it enables to display and modify the technological parameters and the machine parameters.  |
| <i>Tools Parameter</i>         | it enables to display and modify the tools parameters.   |
| <i>Diagnostic</i>              | it enables to display the state of the devices and, if possible, to operate on them.   |
| <i>System Errors</i>           | window containing the list of the most recent system errors. It is also possible to display cycle errors and messages.                                       |




## 2 System composition

### 2.1 Access rights to the system

Albatros has four access levels to the system:

- **User:** is the level with most access restrictions. It does not allow you to modify any of the devices settings. It is the level used for machining and normal machine operations. When the system is booted this access level is automatically enabled .
- **Service:** is the level used for ordinary maintenance of the machine. The operator should be able to modify certain configuration parameters, without altering the structure of the machine.
- **Manufacturer:** is the level used to configure plants and machines. At this level almost any kind of modification is possible. It is used by developers.
- **Tpa:** is the highest access level of the system. Its function is to protect access to particularly delicate settings whose modification requires a detailed knowledge of Albatros. This level is very rarely used and the access password must be requested directly at T.P.A. S.p.a.

To access the system at a higher level than User, or to return to User level after introducing changes at a higher level, the corresponding password must be introduced.

To recall the login window, press **[CTRL+ \*]**(asterisk). Alternatively, click on the  icon at the right end of the Windows' "**applications bar**" with the right mouse button to view a menu in which the **Change pass level** command appears.

The window you are opening looks like this:



Now introduce the password and press the **[OK]** key to confirm. The letters composing the word will be visualised as "\*" characters, to avoid anyone reading the password typed in. By typing in the password you have logged into the corresponding access level. To have a confirmation of the level accessed, select the heading **About Albatros** from the **Help** menu.

If the introduced password is not correct the error message "Warning! Wrong Password!" will appear.


### 2.2 Multilingual support

Albatros supports the display of text in multiple languages.

Albatros does not currently support some languages such as the oriental languages, which use a special set of characters or don't use the left->right direction typical of the western languages.

#### Change language

The language may be changed at any access level of the system. To select a different language press

**[CTRL + /]** or select the icon  from Windows "**applications bar**". In the now opening window select the language required and click on **[OK]** .

Change of language is not made immediately, but at the following restart of Albatros.

### 2.3 Typical architecture of the system

Because many aspects of graphic representation and the structure of basic data of the Machine depend greatly on the kind of Machine, this Manual provides by way of example a description of the composition of a typical system, as well as some general information.

The detailed information, the diagrams and the graphics of the real system obviously depend on the specific application, and are consequently prepared by the Manufacturer of the Machine Tool.

The Albatros numeric control system is composed by a supervisor PC, showing the Operator-Machine interface, and a number of modules (ranging between 1 and 16) for the piloting and control of all operative resources of the Machine Tool or Plant.


So, you can have two kind or plants:

- Monomodule* consisting of one module connected directly to the PC bus.
- Multimodule* consisting of a minimum of 1 and a maximum of 16 modules, usually used for applications on Plants or Lines with a number of machines; the PC unit in this case is physically separate from the modules, which can be located in various points of the Line or Plant.

In both architectures the modules are composed by one or more axis cards for the direct control of the Machine Axes and the logic management of the Input/Output system.

In the monomodule version, the axis cards are installed directly in the Supervisor PC, while in the multimodule version they are installed in an industrial PC (with or without screen and keyboard) connected to the Supervisor PC via Ethernet. The following figure shows the diagram of the connection between the Supervisor PC and the remote module (Clipper). The main activities of the single components are also described.

**Connection layout of a remote module**



**Connection diagram of a remote module**

Intelligent remote devices pilot I/O devices and axes (TRS-AX remote) directly on the machine. These devices read the Digital Input (ON/ OFF) or Analog Input channels, refresh the Digital or Analog Output channels and are connected to the Modules by means of a Greenbus (serial bus RS485 - 1 Mbaud) and CAN bus and PowerLink II and Ethercat optionally. The profile machining of Albatros is protected by a USB hardware key, configured by T.P.A. S.p.A.

---

## 2.4 Organisation and logic configuration


In the Albatros system the descriptive structure of the plant or single machine tool is organised in a technological file with a hierarchical structure.

This approach allows you, if necessary, to maintain the modular structure of the machine as far as the configuration data and access modalities are concerned, by classifying it in terms of dynamic association of various modules, aggregates and devices that may be enabled or disabled according to the required setting.

Following this logical structure, in the most general and complex case the higher hierarchical level will be composed by:

- 1. Plant** simply a set of machines. It represents the operational parts managed by the Numeric Control. The plant is always present, even in the case of a single machine and it is not necessary to mention it explicitly.
- 2. Machine** from a "logic" point of view it is defined as a set of devices (axes, timer etc.) and control cyclics, corresponding to a GPL language code that applies the control algorithms of the machine itself. Generally the machine is provided with a large number of devices which are organised into groups.
- 3. Groups** are "containers" which allows you to organize the components of the machine following a logical criteria. For example we could define an "axes" group containing all the axes of the machine, the limit switches, the cyclic performing the axes homing etc.
- 4. Subgroups** indicate a further subdivision of a group. For example, the "axes group" could be divided into "digital axes" and "step-by-step axes".
- 5. Devices** are the lowest level of the hierarchy. They are a logic representation of the electrical and mechanical components of the machine and are independent of the hardware below.


The following figure schematises the structure of a hypothetical plant composed by two machines:



**Example of hierarchical structure of a plant.**

**NOTE:** The Groups do not necessarily have to be divided into Subgroups, they can be made up directly of Devices.

In the case of a plant with more than one machine, to access determined functions, such as Diagnostic, System configuration and Technological Parameter, it is necessary to select the machine whose data we are interested in, through the following dialog window














## Window for machine selection

## 2.5 Devices

The devices can be grouped into two categories: physical devices and logic devices. In the system all the devices are identified by a name describing their function.














### Physical devices

By physical devices, we intend all those parts which act on the electrical or pneumatic parts of the machine or verify their state. These are:

| <b>Symbol</b>   | <b>Device</b>  | <b>Function</b>   |
|---|----------------|---|
|    | Digital input  | it verifies the state, "on" or "off", of a device. For example, the safety switch of a door.  |
|    | Digital output | it enables or disables a device, setting it on "on" or "off". It is used, for example, to pilot solenoid valves.  |
|    | Analog input   | it measures the voltage of input power in the corresponding terminal. For example the power generated by a tachimetric dynamo.  |
|    | Analog output  | it defines the output voltage of the corresponding terminal. It can be used, for example, to pilot an inverter.   |
|    | Input port     | it is composed by 8 digital input channels.   |
|    | Output port    | it is composed by 8 digital output channels.  |
|    | Input Nibble   | it is composed by 4 digital input channels.   |
|   | Output Nibble  | it is composed by 4 digital output channels.  |
|  | Axis           | it controls the movement of electrical axes. It is possible to control various kinds of axes: analog controlled, digitally controlled, step-by-step motors, counting axes (only encoder reading) and frequency/direction controlled axes. |

### Logic devices

Logic devices are parts which act exclusively within the operating programs and do not have a physical counterpart:

| <b>Symbol</b>   | <b>Device</b> | <b>Function</b>   |
|---|---------------|---|
|  | Timer         | time counting device. The measurement unit is the second. Resolution:4 ms. It can only indicate positive numbers, displaying a maximum time span of 8.589.934 seconds (with Real Time at 250 Hz). The amount is recorded in the non-volatile memory of the axis card. |
|  | Counter       | operation counting device. It may display any number between -2.147.483.648 and +2.147.483.647. The amount is recorded in the non-volatile memory of the axes card.   |
|  | Flag bit      | off/on indicator.   |
|  | Flag switch   | special flags that can be connected to certain buttons on the tool bar, as the Start flag, for example.   |
|  | Flag Port     | it is composed of 8 flag bit channels.  |
|  | Function      | the basic unit of the GPL code which, together with other functions, forms a program. It is the logic control device for other devices  |
|  | Variable      | GPL code <i>integer</i> type global variable.   |
|  | Variable      | GPL code <i>char</i> type global variable.  |
|  | Variable      | GPL code <i>float</i> type global variable.   |
|  | Variable      | GPL code <i>double</i> type global variable.  |
|  | Variable      | GPL code <i>string</i> type global variable.  |
|  | Variable      | GPL code <i>array</i> type global variable.   |
|  | Variable      | GPL code <i>matrix</i> type global variable   |



## 3 Synoptic View

### 3.1 Using the Synoptic View

During machine functioning it is possible to open the *Synoptic View* window to verify the state of the most important devices.




Synoptic views display the same information contained in the diagnostic window. However, while in the latter the information is displayed in a tree structure (which includes all the devices present on the machine), synoptics illustrate the information graphically (displaying, for example, an image of the machine and setting the position of the axes next to the axes themselves). Synoptics also allow you to select the most significant information, grouping the remaining information in secondary screen pages, to be recalled by the user when necessary.

### 3.2 How to operate on the Synoptic View

The Operator can select the various pages composing the synoptic, for diagnostic purposes, by double clicking with the mouse on one of the areas of the machine. The different areas are delimited by a hatched rectangle, and are also known as "hot spots".

To select a "hot spot", a device or an axis, simply move the mouse pointer into the image of the required object. The name of the selected device appears immediately in the Status Bar.

The appearance of the mouse pointer changes according to the selected object, to indicate what kind of operation is allowed on that specific object. The pointer will appear as a:

|   |                         |                          |
|---|-------------------------|--------------------------|
|  | <i>magnifying glass</i> | if it's a "hot spot"     |
|  | <i>hand</i>             | if it's an output device |
|  | <i>text cursor</i>      | if it's a set-value box  |

### 3.3 How to act on Devices


To act on a device, point the mouse on the required device, and complete action as described below (actions vary according to the type of device).

| Representation          | Action                            | Device   |
|-------------------------|-----------------------------------|--|
| <b>mode</b>             |                                   |  |
| <i>Device icon</i>      | point and <i>click</i>            | Digital output<br>Flag switch<br>Flag bit                                      |
| <i>Set-Value box</i>    | point, <i>click</i> and set value | Analog output<br>Output port<br>Flag port<br>Axis position<br>Timer<br>Counter |
| <i>Select-value box</i> | point and <i>click</i>            | Output Nibble  |

### 3.4 Manual Axes Movement

To access the manual axis movement function, it is necessary to have the required access rights. Access rights are assigned by the manufacturer of the machine.




To interact with an axis, simply *double click* with the mouse on the positions display field of the required axis. The dialog window in the figure below will open. In the case of Virtual, Stepping motor and Count axes, the dialog window contains less data. For example, in the case of a Count axis, only the Real Position and Speed values are displayed.



**Manual axis movement window**



The window is composed of two areas, whose contents are described below.



#### Visualization area



- Three cells displaying axis *Real Position [mm]*, its *Speed [m/min]* and the *Loop Error* or tracking error.
- Two select buttons which indicate axis *Status* (*Free* = open loop, for ex. because of a system error, *Normal* = closed loop, corresponding to normal position control status). It is also possible to set the status by using these buttons.
- During movement, the signaling of axis *Status* (ex. Acceleration).
- Two buttons to select negative  or positive  direction axis movement.
- The  button, to Stop axis movement at any moment, during movement in *Absolute* or *Step* mode.

#### Movement area




- Two cells to set a *Negative Position* and a *Positive Position*, which will be used in *Absolute* mode.
- One cell to set the *Speed* imposed on the axis during manual movements.
- Three select buttons to choose what kind of movement to apply: *Jog*, *Absolute* position or *Step*.
- One cell to set the *Step* value to be used in *Step* mode.

To move an axis, set the parameters described above as required. Select movement mode and press the  button (to move the axis in positive direction) or the  button (to move the axis in negative direction).

In *Jog* mode the axis will keep on moving as long as the  or  minus button is kept pressed.

In *Step* mode, the axis will move as far as indicated in the "Step" cell each time the  or  button is pressed.

In *Absolute* mode, the axis reaches directly the position indicated in the Positive position or Negative position cell.

It is also possible to use the keyboard "+" (or Ctrl+P), "-" (or Ctrl+M) and "Space bar", instead of the ,  and  buttons.

## 4 Technological and Tools parameters

### 4.1 Technological Parameter window


The Technological Parameter file allows you to record the geometrical and technical information of a machine. The numeric control needs this information to handle machine functioning correctly.

To open: menu **File->Open Technological Parameters**.

Technological Parameters are usually organized in Groups / Subgroups (Normally the groups and subgroups of the Technological Parameters are independent of the groups and subgroups in which the machine devices are divided). The display modes are defined by the Machine Manufacturer and depend on the specific application.

The values listed in the file are usually set by the manufacturer in the Machine calibration phase and can not be modified by the User, if not exceptionally. Therefore, some data may be protected by Password to avoid accidental modifications which could affect correct machine functioning.

The Technological Parameter window displays in a tree structure all the Groups and Subgroups of parameters that compose the file, as shown in the following figure.



**Structure of the Technological Parameter file.**

The window contains Groups, displayed in a tree structure, with their relative Subgroups of parameters. The tree structure can be expanded or collapsed using the  $\pm$  and  $\square$  buttons found at each node. The +, -, Right/Left arrows and **Enter** keys and the **Space Bar** can also be used to open and close parts of the tree.

#### How to operate on Technological Parameters

Once the required Group / SubGroup tree is opened, it is possible to access the page containing the data. The data can be listed in a table, or in text or selection cells, depending on the type of data and how the Manufacturer set the data.

If any data is modified, it is necessary to press **[OK]** to make the changes permanent.

#### How to associate datatable rows to axes defined in the machine

To do that, you need to configure in the DataTable in PaStudio as follows:

- the suffix of the matrix name must be ":axis" (for ex: "MxConf:axis"), regardless of it is a group either a global or a library matrix;
- in the first Column you have to indicate that the character number must be greater of 20. In this column write the name of the axis, like in GPL.

In Albatros you have to enter in the first Column the names of the axes, whose parameters you wish to set. When you perform the "Cnc->Initialise" command, Albatros replaces the axis name with its logic address. From GPL through the instruction DEVICEID you retrieve the logic address of an axis, through which you can make a search into the parameter matrix.

#### Tooling

Tooling is an unusual kind of machine data. Typically, any information concerning the set of tools the machine is equipped with (tooling) is saved in the Technological Parameter file. However, any information concerning the tools themselves is saved in the Tools Parameter file. For this reason, to define the tooling of a machine it is necessary to combine the information contained in the two files. If the system provides for this situation it will be possible to recall information contained in the Tools Parameter file from the Technological Parameters file. Usually the connection is implemented by means


of a button with a similar icon to the one below.



Selecting the icon and double clicking on it with the mouse's left hand button will open a window containing the list of tools defined in the Tools Parameter file, allowing you to select the required tool. When this has been done, the icon button changes, displaying the icon that represents the specified tool. It is also possible to display the tool data by double clicking on the icon with the right hand button of the mouse.



## 4.2 Tools Parameter Window

The window of Tools Parameters can be opened in Menu **File->Open Tools Parameters**. Tools parameters, determined by the Manufacturer on the basis of the operations performed by the machine, are usually organised as shown in the figure below:



Example of a Tools Parameter Window.

The Tools Parameter window is divided in two areas:

- the *left-hand area* contains the Groups, with the corresponding Subgroups of tools, displayed in a tree structure. The tree structure can be expanded or collapsed using the  and  buttons placed at each node. For example we could have a Milling Cutters Group composed by Subgroups of cutters with different characteristics, such as profile milling cutters, traverse milling cutters etc. Each one of these subgroups is associated to one or more tools whose characteristics are assigned in a dialog window defined by the manufacturer. The tools contained in each subgroup are displayed in the right-hand side of the screen.
- the *right-hand area*, that takes the name of the selected Subgroup, contains the list of Tools belonging to the Subgroup. The tools defined in this area do not necessarily exist on the machine. The association between the tool and the position on the machine (tooling) is normally done in the technological parameter file.

### How to operate on Tools Parameters

Tools are added, modified and deleted from the file by means of buttons located in the lower section of the window:

- |                 |  |
|-----------------|--|
| <b>[New]</b>    | enables to add a new tool to the Subgroup. It opens the "New Tool" dialog window, in which the following data can be inserted: <ul style="list-style-type: none"> <li>- <i>Description</i>: a message that identifies the tool. The description can be chosen from the ones already in the list, if it has not already been assigned to another tool, or a new description can be written.</li> <li>- <i>Image</i>: an icon that identifies the tool. It can be chosen from the ones already in the list, or it can be called from a folder using the <b>[Image]</b> button. The tool is inserted in the list following the alphabetical order of the descriptions.</li> </ul> |
| <b>[Remove]</b> | allows you to remove a tool from the Subgroup, although it is subject to confirmation; the description of the tool is not deleted and remains available for another tool.  |
| <b>[Edit]</b>   | allows you to replace the <i>description</i> or <i>image</i> of the selected tool, through the same dialog window described in the <b>[New]</b> command.   |







## 5 Diagnostic

### 5.1 The Diagnostic window

The Diagnostic window can be opened during machine execution to allow the operator to keep machine functioning under control, by monitoring the logic state of the I/O digital signals, analog I/O data, counters and timers data and axes movement.

Depending on the access rights conceded by the manufacturer, it may also be possible to modify the state of the devices.

If permitted by the access level, it is possible in real time:

- to display the state (ON/OFF) of all the digital Input and Output signals.
- to able and disable the digital Output signals.
- to display the voltage (ranging between +/-10V) of the Analog inputs.
- to assign a voltage (ranging between +/-10V) to all the Analog outputs.
- to move an axis in Manual by selecting the speed, the Pitch or the final absolute Position, and display real position, speed and loop error.
- to display and modify the global variables.

In the next paragraphs the devices and global variables will be described in detail, together with their graphic representation.



**NOTE:** In the diagnostic window only the devices enabled for the current access level are displayed.

### 5.2 Diagnostic window composition


It is possible to access the devices through the "Groups / Subgroups" structure, already described in the chapter System composition, which are then displayed in a tree structure.

At the head of the structure we find the machine, indicated by the icon:

, followed by its Name and a Comment.

The structure can be expanded or collapsed by clicking on the  or  buttons. The tree can also be opened and closed by clicking on: +, -, left/right arrow key.

When a Group is opened, the following items are displayed in the tree:

- the "Devices List" of the Group, indicated by the icon 
- the Subgroups composing the Group, if any.

When a Subgroup is opened, the devices composing the subgroup are also displayed.

### 5.3 Representation of the Devices

The following information is shown with all the devices displayed.

- a graphic symbol;
- its State or current value;
- its Name;
- a Comment.

The list below contains the graphic representations of the devices, the type of device and the value displayed in real-time.

The state of digital inputs, digital outputs and flags is represented graphically by a LED which changes colour depending on whether the input is enabled or disabled.

In the case of Ports and Nibbles, that is, a number of lines ( 8 or 4 respectively) represented at the same time, a row of LEDs will be shown, where the first line of the group is indicated by the right hand LED and the last one by the left hand LED.

| Device          | Symbol | State        | Real-time display  |
|-----------------|--------|--------------|--|
| Digital input   |        |              | state: Enabled = GREEN, Disabled = GREY  |
| Digital output  |        |              | state: Enabled = RED, Disabled = GREY  |
| Analog input    |        | 22.000       | current value  |
| Analog output   |        | 22.000       | current numeric value in Volts   |
| Input port      |        |              | state of each line (as Digital input). State: Enabled = GREEN, Disabled = GREY |
| Output port     |        |              | state of each line (as Digital output). State: Enabled = RED, Disabled = GREY  |
| Input Nibble    |        |              | state of each line (as Digital input). State: Enabled = GREEN, Disabled = GREY |
| Output Nibble   |        |              | state of each line (as Digital output). State: Enabled = RED, Disabled = GREY  |
| Axis            |        | 100.000      | current absolute position  |
| Timer           |        | 12.000       | current value in seconds   |
| Counter         |        | 58           | current numeric value  |
| Flag bit        |        |              | state: Enabled = YELLOW, Disabled = GREY                                       |
| Flag switch     |        |              | state (as Flag bit). State: Enabled = YELLOW, Disabled = GREY                  |
| Flag port       |        |              | state of each line (as Flag bit). State: Enabled = YELLOW, Disabled = GREY     |
| Global variable |        | 2            | GPL code integer type global variable  |
| Global variable |        | 127          | GPL code char type global variable   |
| Global variable |        | 50.00000000  | GPL code float type global variable  |
| Global variable |        | 200.00000000 | GPL code double type global variable   |
| Global variable |        | Area         | GPL code string type global variable   |
| Global variable |        | [256]        | GPL code array type global variable  |
| Global variable |        | [10][3]      | GPL code matrix type global variable   |

## 5.4 Interacting with Devices

It is possible to interact with devices to read their state or modify their value, for diagnostic purposes. However, this is not possible for some types of devices, such as input devices and other devices protected by the Manufacturer. Should the Operator try to operate on these devices, a message will notify him.

When the device has been selected, double click on it with the mouse, or press **Enter**, or the **Space Bar**, to access the window that allows you to change the state or the value of the device.

If the device concerned is a **Digital output** or a **Flag bit**, no window will appear, but the state of the device will be automatically changed. If the output is functioning correctly, the LED indicating its state will change colour.

If the device concerned is an **Output port** or an **Output Nibble**, point the mouse on the LED corresponding to the required output and *double click* on it to change its state. The same applies to **Flag switches** and **Flag ports**.

As far as **Analog outputs**, **Timers** and **Counters** are concerned, a dialog window is displayed, showing the current value and enabling to set immediately the new value we want applied to the device.

Axes interaction modes are described in the Manual Axes movement paragraph.

## 5.5 List of navigation keys to navigate through a tree structure

| Key         | Description  |
|-------------|--|
| Up arrow    | moves the selection to the immediately previous row or to the following one                                    |
| Down arrow  |  |
| Right arrow | expands the selected branch to an extra level and, if already expanded, moves the selection on the next branch |
| Left arrow  | collapses the selected branch and, if already collapsed, transfers the selection on the previous branch        |
| +           | expands the selected branch to one level   |
| -           | collapses the selected branch  |
| *           | expands all the levels of the selected branch  |

## 5.6 Axis calibration control board

The axis calibration control board allows you to modify axis configuration parameters and, at the same time, to move the axes and see its behaviour displayed on a virtual oscilloscope.

The axis calibration board is only accessible as from the "Manufacturer" access level. The calibration board is accessed in diagnostic or manual mode by double clicking on the axis to be calibrated while keeping the "shift" key pressed.

The calibration control board shown in the following figure will be displayed:




Axis calibration control board window

To verify axis behaviour as parameters change, the axis is moved continuously between two limit positions called **Positive Position** and **Negative Position**. As well as these parameters, axis movement **Speed** will also have to be set. In the early stages of calibration we suggest using a low speed value. A **Delay**, to be applied between movements, can also be fixed.

The oscilloscope window will display the axis loop error graph or one of the other axis' values. It is

possible, as with bench oscilloscopes, to scale the graph to adapt it to the size of the window and to examine it in detail. By means of a mouse or control keys and buttons you can examine the last calibration minute again, display one or two cursors to measure and check on the sampled data, enlarge an area of the graph to analyse the details of the sampled data, change the offset and the scale both in the x and y-coordinates. Moreover graph scrolling can be interrupted by pressing the **Stop** button, to allow a careful study of the graph without having to stop the axis. Besides the graph, two boxes showing (on the left) the real position and (on the right) the size displayed graphically. This can be set using the combo box situated above the display box.

To change the parameters of the axes, press the **[Parameters...]** button, which activates the window shown in figure 6.2 where most axis parameters can be edited directly. Once a change has been made to one or more parameters it can be activated by pressing the **[Apply]** button. For such changes to be saved in the Configuration press the **[Ok]** button.



**Parameter definition window for axis calibration**

The principal parameters to be operated on are the following:

- **Proportional** coefficient
- **Integral** coefficient
- **Derivative** coefficient
- **Feed Forward** percentage of current speed provided directly by operation (independent of loop error)
- **Feed Forward Accel.** percentage of speed reference provided directly by operation during axis acceleration and deceleration phases (in addition to feed forward)
- **Acceleration** time of acceleration ramp
- **Deceleration** time of deceleration ramp

### Axis Calibration

Axis calibration is a delicate operation to be carried out with great care and caution.

Through the "CalibSampleTime" option in the [Albatros] unit in Tpa.ini you can modify the data sampling time of an axis for the calibration window. The value in milliseconds and cannot be less than the frequency value of the control axis or less than 100.

Before calibrating the axes from the control board, set all the parameters in configuration and set the full-scale value for drive speed. At maximum speed Albatros reaches a voltage of 9 Volts.

To avoid damaging the machine by setting incorrect parameters, it is advisable to set a low speed, for

example the equivalent of 10% of axis max speed. This will avoid excessively violent reactions of the axes, even when the gain is set too high.

Normally the machine is calibrated first for point to point movements and then for interpolation movements.

The first step, if it hasn't been done in configuration, is setting the acceleration and deceleration times. The longer the time, less will be the acceleration to which the axis is submitted.

The second step is setting a minimum gain, that allows axis movement. This is necessary to verify the correct drive calibration. Albatros is set to provide a reference of 9 volts when it reaches the maximum speed set in axis configuration. For example, if the axis is moved at a speed corresponding to 10% of maximum speed, and if the drive is calibrated correctly, the reference power should be 1'0% of maximum power, that is 0.9 volts. If this reference voltage is not obtained, the drive's full-scale value must be modified.

When the drive has been calibrated, we begin to increase the position loop gain, a little at a time and with great caution. Each time the position loop is increased we must check that this has not caused conditions of excessive deflection or instability. In this phase, speed must be kept at 10% of max speed, or less, at all times. Moreover, it is always advisable to analyze the obtained speed profile carefully with the virtual oscilloscope, enlarging the image as much as possible to highlight the details.

When stable and ready axis performance has been obtained, movement speed can be gradually increased. Check axis behaviour each time the speed is modified. The value of the gain must also be modified if it is not satisfactory. Gain and speed must never be increased abruptly, as apparently stable calibration conditions at a low speed may not be as stable at a higher speed.

When the optimal value of the Gain has been determined, if necessary, Integrative and Derivative coefficients and then the Feed Forward may be gradually increased to reduce the loop error, bringing it within acceptably precise values. The feed forward allows you to eliminate the loop error almost completely during movement, but not during acceleration and deceleration. To further reduce the loop error in these phases, Feed Forward Acceleration can be increased. Normally, even very low values in this parameter are sufficient for satisfactory results.

As far as axis calibration for interpolation movements is concerned, the same values set for point to point movement can be used, although the other axes of the machine must be taken into account. It is particularly important to balance the axes' loop errors to obtain maximum precision during interpolation movements. This means that once the axis with the greatest loop error (at equal speed) has been identified, the calibration of the others must be adapted (limitedly to the interpolation parameters) to obtain identical loop errors.



## 6 System Errors

### 6.1 Introduction to System Errors

By *System Errors* we mean all the errors that the *Albatros* system is able to detect automatically, both during program execution phases and during maintenance operations and plant diagnostic.

These include all kinds of errors, ranging from axis management problems to program execution problems.

System errors can be dealt with directly inside the machining program, by means of the ONERRSYS instruction. If this is not possible, program execution of the module where the error occurred is terminated.

The most recent system error is displayed in the Error Bar, together with the last cycle error and the last message.

**System errors** are indicated in red.

**Cycle errors** are indicated in yellow. These are errors occurring during program execution, which, however, usually allows execution to continue as soon as the error has been cleared.

**Messages** are indicated in green. These may be alert messages generated in anomalous situations during program execution or notifications of help request from the operator. They do not interrupt execution of the program itself.

|                                |       |
|--------------------------------|-------|
| Machine 1: Reconnected module  | 00002 |
| Machine 1: MSG_ESEGUI_SETPOINT | 00001 |
| Machine 1: Err_MSG             | 00001 |
| 00000 00001 NUM                |       |

**Errors Bar**

All the errors are saved in a file, creating an error data base. Any errors generated as from booting are displayed in a window opened either by double clicking on the *Errors bar* with the mouse or using the three commands in the **View** menu. Additional information about system errors is also displayed in this window.

| Hour&Date           | Description                  | Code         | Task    | Module    |
|---------------------|------------------------------|--------------|---------|-----------|
| 15.13.35 25/02/2009 | The module is not configured | 16902        |         | Machine 2 |
| 15.13.35 25/02/2009 | Reconnected module           | 16387        |         | Machine 1 |
| 15.13.47 25/02/2009 | MSG_ESEGUI_SETPOINT          | MAIN.MSG ... | MAIN... | Machine 1 |

Cycle Errors       Messages  
 Modules  
 All  
 Machine 1

Remove All    Remove    OK

**System errors window**

The window is divided into areas, as following: The **top** part of the window lists the following information:

- *Hour&Date* hour and date in which the error occurred.
- *Description* description of the error.
- *Code* number of error message.
- *Task* name of the task that generated the error (not indicated in Errors Bar).

By *double clicking* on one of these columns, the information is ordered according to the content of the column.

The **bottom** part contains the cells:

- *Cycle Errors* if this cell is enabled, cycle errors are also displayed .
- *Messages* if this cell is enabled, messages are also displayed.
- *All* if enabled, it lists all the messages, sent by any module of the system, concerning the type of information displayed.
- *Module Name Cell* shows the name of the module whose information is being displayed. It also allows you to select, in the case of multi-module systems, the module whose information is required.

The control **buttons** are:

- **[Remove All]** clears from memory all the information displayed, without deleting it from the file.
- **[Remove]** clears current information from memory, without deleting it from the file.
- **[OK]** closes window.

## 6.2 Errors generated by axes control

### 6.2.1 1 AxisName: incorrect encoder connection

**Cause:**

The difference between the theoretical position of a still axis, and the real position of the axis, exceeded 1024 encoder steps.

This often happens during axis commissioning, when the encoder phases are reversed. During normal functioning it occurs when an axis is moved manually, with the drive off, without setting the axis on FREE, or when the axis is subject to overshoot in the arrival phase, due to inaccurate calibration.

When this error occurs, the reference signal is set to zero and the axis is set on FREE.

**Solution:**

During axis commissioning, check the connection of the axis' encoder phases (if necessary enable the encoder phases inversion option in axis configuration).

Verify axis calibration using the specific Diagnostic mode.

### 6.2.2 2 AxisName: not ended movement

**Cause:**

When the move has concluded, 5 seconds after the end of theoretical movement, the gap between the theoretical position and the real position of the axis exceeds the window indicated in Configuration.

This could be simply because the drive is off or disabled or it could be due to inaccurate drive offset regulation.

However, it could also be due to mechanical backlash on the axis or an excessively low axis position loop gain.

**Solution:**

Check that the drive is on and enabled. Verify axis calibration and adjust the drive offset of the concerned axis.

### 6.2.3 3 AxisName: servoerror

**Cause**

In any type of movement, the difference between the theoretical position and the real position of the axis exceeded the maximum error indicated in Configuration or set with the instruction SETMAXER.

Normally this is due to the incorrect setting of the position loop gain or of the full-scale value of operation speed. It could also depend on excessive axis inertia.

**Solution:**

Verify the gain setting and the full-scale value of drive speed.

Check that the encoder and the motor/drive group are functioning correctly.



Check for any mechanical block.

#### 6.2.4 4 AxisName: limit switch positive

**Cause:**

The theoretical position of the axis exceeded the positive position limit indicated in Configuration or set using the SETLIMPOS instruction.

**Solution:**

Correct in the program the position exceeding the positive position limit or set new axis position limits .

#### 6.2.5 5 AxisName: limit switch negative

**Cause:**

The theoretical position of the axis exceeded the negative position limit indicated in Configuration or set using the SETLIMPOS instruction.

**Solution:**

Correct the position exceeding the negative position limit in the program or set new axis position limits .

#### 6.2.6 6 AxisName: error writing SLM data

**Cause:**

The axis card does not communicate properly with the drive. Normally, this communication problem is due to the fact that the drive is switched off or the cables are not properly connected or are damaged. It is also possible that external power supply (+24VDC) of the AlbSLM card is absent.

**Solution:**

Check that the drive is switched on and is functioning correctly. Verify card power supply, verify connection cables. If the problem persists, please contact the constructor.

#### 6.2.7 7 AxisName: error reading SLM data

**Cause:**

The axis card does not communicate properly with the drive. Normally, this communication problem is due to the fact that the drive is switched off or the cables are not properly connected or are damaged. It is also possible that external power supply (+24VDC) of the AlbSLM card is absent.

**Solution:**

Check that the drive is switched on and is functioning correctly, verify card power supply, verify connection cables. If the problem persists, please contact the constructor.

#### 6.2.8 8 AxisName: error executing SLM command

**Cause:**

The axis card does not communicate properly with the drive. Normally, this communication problem is due to the fact that the drive is switched off or the cables are not properly connected or are damaged. It is also possible that external power supply (+24VDC) of the AlbSLM card is absent.

**Solution:**

Check that the drive is switched on and is functioning correctly, verify card power supply, verify connection cables. If the problem persists, please contact the constructor.

#### 6.2.9 9 AxisName: communication error

**Cause:**

The axis card (AlbNt o ALbSLM) is not communicating correctly.

**Solution:**

Contact T.P.A. S.p.A.

### 6.2.10 10 AxisName: the Real-Time execution is faster than the profile construction

**Cause**

The realtime execution of the movement profile goes faster than the gpl generation of the profile itself. The lookahead is emptied faster than its filling. The error might be due to two generally simultaneous causes:

- the interpolation speed rate is too high with respect to the space dimensions to be covered.
- The spaces to be covered are too short.

**Solution:**

Verify that the set interpolation rate speed is not too high with respect to the space dimension to cover; furthermore, verify that the interpolation spaces to cover are not too shorts.

## 6.3 Errors generated by remote I/O

### 6.3.1 262 Test failed on dual-port memory of remote IO

**Cause:**

An error was generated during axis card initialization tests. Namely, the GreenBus transmitter (i296 microcontroller) Dual Port Memory test failed. This could be due to the incorrect configuration of the card's I/O and IRQ addresses or to conflict with other peripherals in the system. It could also be the consequence of a damaged axis card.

**Solution:**

Check the card configuration, and that there are no conflicts with other peripherals. Qualified technicians can test the Hardware of the i296 microcontroller Dual Port Memory. If the problem persists, please contact the constructor.

### 6.3.2 2049 Receiver number: incorrect configuration

**Cause:**

The remote receiver received a different I/O expansions configuration from the one detected on the field. This can happen, if the remote is not equal to the one chosen in the hardware configuration of Albatros. For example, the remote receiver is an Albre16 and in Albatros a remote ALbre24 (GreenBus v3.0) or another TRS-IO with a wrong TRS-IO-E expansion number (GreenBus v4.0) has been configured.

**Solution:**

Verify Hardware configuration.

### 6.3.3 2050 Receiver number: disconnected

**Cause:**

The remote receiver does not respond to the transmitter's commands.

**Solution:**

Verify the receiver's power supply and the serial connection.

### 6.3.4 2051 Receiver number: reconnected

**Cause:**

The connection between the transmitter and the receiver has been restored.

### 6.3.5 2052 Receiver number: error in reading Output not connected number OutputNumber

**Cause:**

The indicated digital output is in protection or in short circuit state, however, it is not in the state expected by control. The output is not associated to any logic device in Virtual-Physical Configuration, which indicates an incongruity between Configuration and the real cabling of the machine.

**Solution:**

Verify Virtual-Physical Configuration. Remove short circuit or verify that the applied load does not exceed maximum limits (consult technical documentation).

### 6.3.6 2053 Receiver number: error on the expansion module number ModuleNumber

**Cause:**

Error related to Albrem modules and their relative AlbIN and AlbOUT expansions. The configuration read on the field during functioning does not correspond to initialisation configuration. Generally, this is due to an interruption of the connection between Albrem and the expansion modules.

**Solution:**

Verify connection between Albrem and expansions.

### 6.3.7 2054 Receiver number: wrong type

**Cause:**

During remotes initialization, a different receiver from the one specified in configuration has been detected at a certain address.

**Solution:**

Verify that the Hardware Configuration agrees with the remote module setting.

### 6.3.8 2055 Receiver number: initialized

**Cause:**

The receiver has reconnected to the transmitter after an interruption caused by a power fail.

### 6.3.9 2056 Receiver number: +24 V DC power fail

**Cause:**

Field power (+24 V DC) of a receiver module is not active or not working.

**Solution:**

Check the +24 V DC power.

### 6.3.10 2057 GreenBus power fail

**Cause:**

The field bus power supply, connecting the I/O modules with the control, is not working properly. This power supply should have a nominal value of +12 Vcc and it is supplied by the control.

**Solution:**

Check the presence of the GreenBus power line, check the GreenBus cables. Switch-off and switch back on. If necessary, replace the control board.

### 6.3.11 2058 Receiver number: error reading DeviceType DeviceName

**Cause:**

The state of the specified output does not correspond to the set state. This could be due to a shortcircuit, to overload protection or simply to the lack of power. The specified output can be a digital output, an analog output, an axis control output. The kind of output is specified in the error view.

**Solution:**

If it is a digital output, verify the +24V power supply (field side), remove the possible short circuit or the excessive output adsorption (see technical documentation). If it is an analog output or a axis control output, verify the presence and the value of the voltage set at the output (tester or oscilloscope), remove the possible short circuit or the excessive output adsorption (see technical documentation).

### 6.3.12 2059 Test failed on dualport memory of transmitter

**Cause:**

An error was generated during axis card initialization tests. Namely, initialization of the GreenBus transmitter (i296 microcontroller) failed. This could be due to the incorrect configuration of the card's I/O and IRQ addresses or to conflict with other peripherals in the system. It could also be the consequence of a damaged axis card.

**Solution:**

Check the card configuration, check that there are no conflicts with other peripherals. If a remote module is used, retransmit the firmware to the module. Qualified technicians can test the Hardware of the i296 microcontroller Dual Port Memory. If the problem persists, contact the manufacturer.

### 6.3.13 2060 Error initializing transmitter

**Cause:**

An error was generated during axis card initialization tests. Namely, firmware transmission to the GreenBus transmitter (i296 microcontroller ) failed. This could be due to the incorrect configuration of the card's I/O and IRQ addresses or to conflict with other peripherals in the system. It could also be the consequence of a damaged axis card.

**Solution:**

Check the card configuration, check that there are no conflicts with other peripherals. If a remote module is used, retransmit the firmware to the module. Qualified technicians can test the Hardware of the i296 microcontroller Dual Port Memory. If the problem persists contact the manufacturer.

### 6.3.14 2061 Error transmitting firmware to transmitter

**Cause:**

An error was generated during axis card initialization tests. Namely, transmission of the remote I/O module configuration to the GreenBus transmitter (i296 microcontroller) failed.

**Solution:**

Verify hardware configuration, if a remote module is used, retransmit the firmware to the module. Qualified technicians can carry out a Hardware test on the i296 microcontroller RAM. If the problem persists contact the manufacturer.

### 6.3.15 2062 Error transmitting configuration to transmitter

**Cause:**

An error was generated during axis card initialization tests. Namely, remote I/O modules initialization failed.

**Solution:**

Verify the hardware configuration, if a remote module is used, retransmit the firmware to the module. Qualified technicians can carry out a Hardware test on the i296 microcontroller RAM. If the problem persists contact the manufacturer.

### 6.3.16 2063 Error transmitting configuration to receiver

**Cause:**

Error detected during initialization of a remote module.

**Solution:**

Verify the hardware configuration. Qualified technicians can carry out a Hardware test on the remote module. If the problem persists contact the technical support service.

### 6.3.17 2064 Receiver number: firmware version not compatible

**Cause:**

Remote receiver has a firmware version not compatible with the controller's firmware.

**Solution:**

Check installation of controller. If the problem persists, please contact the technical support service.

### 6.3.18 2065 Receiver number: error in an asynchronous communication

**Cause:**

There was an error or a non-response during the communication of a command with the remote (GreenBus v.4.0).

**Solution:**

Check the connections and the GreenBus power supply. If the problem persists, please contact the technical support service.

### 6.3.19 2066 Receiver number: generic error

**Cause:**

There was a generic error while communicating an event or an alarm from a remote (GreenBus v4.0)

**Solution:**

Check the connections and the GreenBus power supply. If the problem persists, please contact the technical support service.

### 6.3.20 2067 Receiver number: error during the transmission of the configuration

**Cause:**

A communication error while transmitting some configuration data to a remote (GreenBus v.4.0) occurred.

**Solution:**

Check the connections and the GreenBus power supply. Switch-off and switch back on. If the problem persists, please contact the technical support service.

### 6.3.21 2068 Receiver number: internal error no. errornumber

**Cause:**

An internal error on the indicated remote has occurred.

**Solution:**

Contact T.P.A. S.p.A.

### 6.3.22 2069 Receiver number: power supply error +24 Vcc bench number

**Cause:**

Field power supply (+24 Vcc) of a output group connected to the same feed clamp is not active or does not work correctly.

**Solution:**

Check the +24 Vcc power.

### 6.3.23 4610 Plug number: error reading DeviceType DeviceName

**Cause:**

The state of the specified output does not correspond to the set state. This could be due to a shortcircuit, to overload protection or simply to the lack of field side power (+24V) in the AlbIO32 card (+24V).

**Solution:**

Verify that the +24V power supply is functioning correctly, if necessary remove the shortcircuit or verify that the load does not exceed limits (consult technical documentation).

## 6.4 Errors generated by Mechatrolink II

### 6.4.1 2308 Plug PlugNumber: initialization failed. A parameter configuration setting was not correct

**Cause:**

In virtual physical Configuration any axis (logical device) was not connected to the board with Mechatrolink II bus (physical device).

**Solution:**

Check the connections in Virtual physical Configuration

### 6.4.2 2341 Plug PlugNumber: the number of servo drives exceeds the maximum allowed

**Cause:**

A number of servodrives, exceeding the configuration set, was connected to a Mechatrolink II bus.

**Solution:**

Check the Axis Control Frequency value in system configuration.

In the table below the right values to be set according the number of servodrives controlled by the board:

| Board         | Frequency Axis Control (Hz) | Maximum Number of servodrives |
|---------------|-----------------------------|-------------------------------|
| AlbMech       | 1000                        | 8                             |
| AlbMech       | <=500                       | 16                            |
| DualMech Mono | 1000                        | 8                             |
| DualMech Mono | 500                         | 20                            |
| DualMech Mono | 250                         | 30                            |
| DualMech      | 1000                        | 16                            |
| DualMech      | 500                         | 40                            |
| DualMech      | 250                         | 60                            |

### 6.4.3 2342 Plug PlugNumber: the hardware address of the Servo servo drive exceeds the maximum value allowed

**Cause:**

An axis (logical device), whose hardware address (physical device) is higher than the number of the servodrives, that can be controlled by the board, has been connected to a Mechatrolink II bus.

**Solution:**

Check in system configuration the Axis Control Frequency value. In the table below the right values to be set according the number of servodrives controlled by the board:

| Board         | Axis Frequency Control (Hz) | Maximum Number of servodrives |
|---------------|-----------------------------|-------------------------------|
| AlbMech       | 1000                        | 8                             |
| AlbMech       | <=500                       | 16                            |
| DualMech Mono | 1000                        | 8                             |
| DualMech Mono | 500                         | 20                            |
| DualMech Mono | 250                         | 30                            |
| DualMech      | 1000                        | 16                            |
| DualMech      | 500                         | 40                            |
| DualMech      | 250                         | 60                            |

Check in Physical-Virtual Configuration the connection between logical device and physical device. For example, if the maximum number of servodrives is 8, so the connection between logical and physical device must included among the first 8 axes (from Ax1 to Ax8).

#### 6.4.4 2349 Plug PlugNumber: servodrive SERVO is not connected

**Cause:**

Physical connection to servodrive *PlugNumber* is interrupted.

**Solution:**

Check servodrive and Mechatrolink II bus cablings.

### 6.5 Errors generated by the CanBUS control

#### 6.5.1 2761 Plug CAN number: node number: not connected

**Cause:**

The Can node shown seems currently not to be plugged to field bus, that makes reference to the board shown, although it is included in the configuration.

#### 6.5.2 2762 Node number: replugged

**Cause:**

The Can node shown seems to be just plugged to field bus, that makes reference to the board shown.

#### 6.5.3 2763 Node number: error missing transmission

**Cause:**

Error inside the indicated board. Data transmission to the indicated Can node failed.

**Solution:**

Contact T.P.A. S.p.A.

#### 6.5.4 2764 Node number: error missing answer

**Cause:**

Data reception from the node Can failed.

**Solution:**

Check connection and power supply of the indicated Can device. Check wiring of the whole Can line. Check line connection to the numeric control. Check coherence in the protocol settings of the indicated device Can in respect of transmitter settings in the numeric control (baud rate, address, specific settings of the adopted protocol)

### 6.5.5 2765 Node number: initialized

**Cause:**

The CAN node shown has been plugged to the field bus, and then it has been properly initialized

### 6.5.6 2766 Fault condition on CAN interface

**Cause:**

An internal power supply failure of the CAN Interface device is reported.

**Solution:**

Contact T.P.A. S.p.A.

### 6.5.7 2767 CAN open state loss

**Cause:**

Because of a serious problem CAN transmitter is not operational anymore.

**Solution:**

Contact T.P.A. S.p.A.

### 6.5.8 2768 Node number: error - PDO has not been received

**Cause:**

CAN node has not received the expected PDO.

**Solution:**

Check PDO node transmission settings.

### 6.5.9 2769 Node number: error receiving a non-configured node

**Cause:**

On the CAN network has been detected a node, that was not described in the file CANBUS.DEF.

**Solution:**

Check the node hardware address and the address declared in the CANBUS.DEF file.

### 6.5.10 2770 Node number: wrong configuration

**Cause:**

In the file CANBUS.DEF RPDO and TPDO data descriptions are wrong.

**Solution:**

Correct CANBUS.DEF file.

### 6.5.11 2771 Node number: SDO communication error

**Cause:**

CAN node has not responded in an asynchronous communication (SDO).

**Solution:**

Check connection node status. If the problem persists, contact T.P.A. S.p.A.

### 6.5.12 2772 Timeout on querying nodes CAN cycle

**Cause:**

A timeout error on querying nodes CAN cycle occurred

**Solution:**

In the file CANBUS.DEF change the value of the set sampling time.

### 6.5.13 3073 Node number: emergency error no.

**Cause:**

CANopen device has detected an error situation of the node, specified by the displayed code. It is a matter of error situations pertaining to a single node and in keeping with the standard CiA DS301-



EMERGENCY protocol.

**Solution:**

Make reference to the node documentation

### 6.5.14 3074 Node number: internal CAN error no.

**Cause:**

An internal error on the indicated node has occurred.

**Solution:**

Contact T.P.A. S.p.A.

### 6.5.15 3088 CAN Board number: Node NUMNODO: SDO communication error n. NUMERRORE - description

**Cause:**

In a ReadDictionary or WriteDictionary instruction, one or more requests for SDO read/write failed. The failure of the instructions can be caused, for example, by the read request of a CANOpen object that is not implemented in the device to which we are referring to; or it can be related to the write, in a CANOpen register, of a not compatible data with the object type (for example: writing attempt of a string into an object whose type is integer). The provided error code complies with the DS402 specifications and the textual description is also provided, in addition to the numerical code.

**Solution:**

check the parameters correctness of BAUDRATE, TIME, etc. set in the file CANBUS.DEF and the parameters of possible Readdictionary and/or Writedictionary instructions which are in the GPL code.

## 6.6 Errors generated by bus Powerlink control

### 6.6.1 2817 PowwerLink board number: none

**Cause:**

Missing board for the communication on PowerLink bus.

**Solution:**

Check that in the PC one of the communication boards, supported by T.P.A. is inserted and that the address on the board is correct.

### 6.6.2 2818 PowerLink board number: Type of CN unknown

**Cause:**

A CN has been defined with an unrecognised type.

**Solution:**

Check the definitions in the EPLBUS.DEF file: the two types of recognised CN are those defines as SERVO or as IO.

### 6.6.3 2819 PowerLink board number: wrong MN number

**Cause:**

A communication board on a PowerLink board could not be used.

**Solution:**

Check the definitions in the EPLBUS.DEF file

### 6.6.4 2820 PowerLink board number: wrong CN number

**Cause:**

One of the devices configured on the PowerLink bus could not be used.

**Solution:**

Check the definitions in the EPLBUS.DEF file

**6.6.5 2822 PowerLink board number: Multiplexing setup error****Cause:**

Multiplexing setup of one of the devices configured on PowerLink bus could not be used.

**Solution:**

Check the definitions in the EPLBUS.DEF file, in particular the MPX fields.

**6.6.6 2823 PowerLink board number: Board initialisation error****Cause:**

A communication board on PowerLink bus could not be initialised.

**Solution:**

Check that the address set on the board is the same as the address indicated in the EPLBUS.DEF configuration file.

Check that the model board is included into the controlled models and that it works properly.

**6.6.7 2824 PowerLink board number: Wrong setting of the master board****Cause:**

Configuration of more than one master board

**Solution:**

Check that in the EPLSDEF one only Master board is defined.

**6.6.8 2825 PowerLink board number: Bus control frequency not correct****Cause:**

Frequency of PowerLink control bus is not coherent with the programmed control frequency of the axes.

**Solution:**

Control frequency of the PowerLink bus is 1000Hz. The frequency corresponds to the MPX highest value and it should not exceed the frequency value of the control axis set in the configuration.

**6.6.9 2826 PowerLink board number: Device connected to a board not configured****Cause:**

One of the logical devices, mapped on PowerLink buses, is connected to a board, that is not present.

**Solution:**

Check the definitions in the EPLBUS.DEF file

**6.6.10 2827 PowerLink board number: Wrong Board Number****Cause:**

Error in the configuration of a board for the communication on PowerLink bus.

**Solution:**

Check the definitions in the EPLBUS.DEF file, in particular the MN fields.

**6.6.11 2828 PowerLink board number: Disabling a board****Cause:**

A communication board on PowerLink bus could not be disabled.

**Solution:**

Check that the address set on the board is the same as the address indicated in the EPLBUS.DEF configuration file.

Check that the model board is included into the controlled models and that it works properly.

Remove the board from the PC.

## 6.6.12 2829 PowerLink board number: Wrong PDO dimension

**Cause:**

The dimension of a PDO exceed the value of 1490 bytes.

**Solution:**

Modify the PDO definition in the EPLSBUS.DEF file, so that its dimension return into the limit.

## 6.7 Errors generated by bus EtherCAT control

### 6.7.1 3329 Error in communication socket initialisation

**Cause:**

The firmware could not communicate with the network card

**Solution:**

If the board has been configured in a RTX System, check that the ini.files available in the Albatros FW subfolder are properly written. To check the syntax of the files, see "Albatros installation manual".

### 6.7.2 3330 Error while scanning the EtherCAT network

**Cause:**

While prescanning the EtherCAT network, the master has not received any answer from some or from all the configured slaves or the configuration does not match the real network EtherCAT available in the field.

**Solution:**

Check the wiring between EtherCAT master and Slave  
Check the descriptions in the ECATBUS.DEF file Hardware Diagnostic window helps you to find the error. Here, the existing nodes are displayed and, if wrongly configured, besides the name of the device found, the name of the expected device is displayed.

### 6.7.3 3331 Error in the configuration of the transmission mailbox

**Cause:**

The EtherCAT node has not responded to the command given by the Master. Potential causes: absent communication, faulty node ...

**Solution:**

Check the wiring and the remote operation.

### 6.7.4 3332 Error in the configuration of the receive mailbox

**Cause:**

The EtherCAT node has not responded to the command given by the Master. Potential causes: absent communication, node failure...

**Solution:**

Check the wiring and the remote operation.

### 6.7.5 3333 PowerLink board number: Error in the kind of expansions of the NUMNODO node

**Cause:**

The kind of expansions configured on an EtherCAT node in the ECATBUS.DEF file does not correspond to the kind of the expansion actually present. (For example, in the ECATBUS.DEF file a TRS-CAT has been defined with a TRS-IO-E expansion, while in the system a TRS-CAT is available with a TRS-AN-E expansion).

**Solution:**

Check that the devices described in the ECATBUS.DEF file correspond to those available.

## 6.7.6 3334 Error during the configuration of the PDOs

**Cause:**

The EtherCAT node, for which you tried to configure the PDOs, is not available or has a trouble.

**Solution:**

Check that the EtherCAT network configuration described in the ECATBUS.DEF file correspond to the physical network configuration.

## 6.7.7 3335 NUMNODO node in ErrorNumber alarm

**Cause:**

The indicated node is in an alarm situation.

**Solution:**

Check the alarm code in the following table

| Alarm code | Description                        |
|------------|------------------------------------|
| 0x0001     | Unspecified error                  |
| 0x0002     | No memory                          |
| 0x0011     | Invalid requested state change     |
| 0x0012     | Unknown requested state            |
| 0x0013     | Bootstrap not supported            |
| 0x0014     | No valid firmware                  |
| 0x0015     | Invalid mailbox configuration      |
| 0x0016     | Invalid mailbox configuration      |
| 0x0017     | Invalid sync manager configuration |
| 0x0018     | No valids inputs available         |
| 0x0019     | No valid outputs                   |
| 0x001A     | Synchronization error              |
| 0x001B     | Sync manager watchdog              |
| 0x001C     | Invalid Sync Manager Types         |
| 0x001D     | Invalid Output Configuration       |
| 0x001E     | Invalid Input Configuration        |
| 0x001F     | Invalid Watchdog Configuration     |
| 0x0020     | Slave needs cold start             |
| 0x0021     | Slave needs INIT                   |
| 0x0022     | Slave needs PREOP                  |
| 0x0023     | Slave needs SAFEOP                 |
| 0x0024     | Invalid input mapping              |
| 0x0025     | Invalid output mapping             |
| 0x0026     | Inconsistent settings              |
| 0x0027     | Free-Run not supported             |
| 0x0028     | Synchronization not supported      |
| 0x0029     | Free-Run needs 3 buffer mode       |
| 0x002A     | Background watchdog                |
| 0x002B     | No valid inputs and outputs        |
| 0x002C     | Fatal Sync error                   |

|        |                                |
|--------|--------------------------------|
| 0x002D | No Sync error                  |
| 0x0030 | Invalid DC SYNCH Configuration |
| 0x0031 | Invalid DC Latch Configuration |
| 0x0032 | PLL Error                      |
| 0x0033 | Invalid DC IO Error            |
| 0x0034 | Invalid DC Timeout Error       |
| 0x0035 | DC Invalid Sync Cycle Time     |
| 0x0036 | DC Sync0 Cycle Time            |
| 0x0037 | DC Sync1 Cycle Time            |
| 0x0041 | MBX_AOE                        |
| 0x0042 | MBX_EOE                        |
| 0x0043 | MBX_COE                        |
| 0x0044 | MBX_FOE                        |
| 0x0045 | MBX_SOE                        |
| 0x004F | MBX_VOE                        |
| 0x0050 | EEPROM no access               |
| 0x0051 | EEPROM error                   |
| 0x0060 | Slave restarted locally        |

### 6.7.8 3336 EtherCAT board number: the NUMNODO node expansion number is wrong

**Cause:**

The configured expansion number on an EtherCAT node in the ECATBUS.DEF file does not correspond to the type of the expansion actually present. (For example, in the ECATBUS.DEF file a TRS-CAT has been defined with a TRS-IO-E expansion, while one only expansion is available in the system).

**Solution:**

Check that the devices described in the ECATBUS.DEF file correspond to those available.

### 6.7.9 4400 The node has not not responded to the request

**Cause:**

In a ReadDictionary or WriteDictionary instruction, performed on EtherCAT nodes, the node did not respond.

**Solution:**

Check if the the node has declared in the CN parameter of the GPL instruction is an existing node.

## 6.8 Errors generated by initialization

### 6.8.1 769 Error in software configuration

**Cause**

The hardware configuration of the remote module does not correspond to the software configuration specified in the system configuration.

**Solution**

Verify that the hardware parameters of the remote module and the software parameter correspond.

### 6.8.2 770 Wrong IRQ number in configuration

**Cause:**

The IRQ of the axis card has not been set correctly in the Module configuration. Normally a hardware conflict with other peripherals in the system is the cause.

**Solution:**

Verify in the motherboard BIOS settings that the IRQ used by the axis card is reserved for "Legacy ISA" only. Verify that no other peripherals are using the same IRQ assigned to the axis card. If possible, modify the IRQ of the peripheral in conflict with the axis card, otherwise modify the axis card IRQ.

### 6.8.3 772 Error reading backup memory

**Cause:**

An error was generated during axis card initialization tests. Namely, the buffered RAM (Dallas) test failed. This could be due to the incorrect configuration of the card's I/O and IRQ addresses or to conflict with other peripherals in the system. It could also be the consequence of a damaged axis card.

**Solution:**

Verify the hardware configuration. Qualified technicians may carry out a Hardware test on the i296 microcontroller RAM. Notice that the RAM Hardware test implies clearing all the data saved in it. The buffered RAM contains the values of certain devices, such as counters, timers and axis DAC offsets. Save these values before running the test. If the problem persists, please contact the manufacturer.

### 6.8.4 773 Reached maximum number of axes in configuration

**Cause:**

An attempt to configure more axes than allowed.

**Solution:**

Reduce the number of axis to be configured. Please, contact T.P.A. S.p.A. for further information.

### 6.8.5 774 Axes Real-Time not running

**Cause:**

The axes management firmware was initialized but is not functioning properly. Normally, a hardware conflict with other peripherals in the system is the cause.

**Solution:**

Check that there is no conflict with other peripherals. Modify the configuration of the peripherals causing the conflict or remove these peripherals from the system. The cause of a conflict can be an IRQ value assigned to the heading "IRQ line for albnt master" in module configuration different from the IRQ value set on albnt card.

### 6.8.6 775 Not enough time for GPL execution

**Cause:**

The execution of a real-time task takes up too much cycle time. This is generated when a Real-time task does not end before the start of the next axis real-time task (for example when an infinite cycle has been created).

**Solution:**

Change the GPL code so as to reduce the length of the real-time task.

### 6.8.7 776 Real-Time execution time too long

**Cause:**

The execution of a real-time task takes up too much cycle time. The execution time is slightly over the maximum allowed.

**Solution:**

Change the GPL code so as to reduce the length of the real-time task.

### 6.8.8 777 Watch Dog timeout

**Cause:**

The firmware is stuck.

**Solution:**

Contact T.P.A. S.p.A..

### 6.8.9 778 Main firmware code is blocked

**Cause:**

The firmware has crashed for more than 5 realtimes.

**Solution:**

Contact T.P.A. S.p.A..

### 6.8.10 779 Error in opening communication channel

**Cause:**

Couldn't open communication channel with cn2004 card.

**Solution:**

Check configuration of network card used for realtime TCP/IP communication with cn2004 card. If the problem persists, please contact the technical support service.

### 6.8.11 1025 Plug PlugNumber: don't reply

**Cause:**

An axis plug was detected during initialization but it does not respond correctly to commands.

**Solution:**

Qualified technicians can carry out a Hardware test on the axis card. If the problem persists, please contact the constructor.

### 6.8.12 1026 Plug PlugNumber: error on axes plug firmware transmission

**Cause:**

An axis plug was detected during initialization but it is not possible to transmit any firmware to it.

**Solution:**

Qualified technicians can carry out a Hardware test on the axis card. If the problem persists, please contact the manufacturer.

### 6.8.13 1028 Plug PlugNumber: firmware not present

**Cause:**

Firmware on board is not compliant with detected plug.

**Solution:**

Transmit correct version of firmware.

### 6.8.14 1029 Plug PlugNumber: MAIN blocked

**Cause:**

The axis card firmware was blocked during normal functioning.

**Solution:**

Qualified technicians can carry out a Hardware test on the axis card. Please, contact T.P.A. S.p.A.

### 6.8.15 1030 Plug PlugNumber: axes control blocked

**Cause:**

The axis card firmware was blocked during normal functioning for more than 5 realtimes

**Solution:**

Contact T.P.A. S.p.A.

### 6.8.16 1031 Plug PlugNumber: initialization error

**Cause:**

An error was generated during axis card initialization tests.

**Solution:**

Check and fix the causes of the system errors occurred in the moments before the occurrence of the current error.

Then initialize the system.

### 6.8.17 1032 Plug PlugNumber: test failed in dual-port memory

**Cause:**

An error was generated during axis card initialization tests. Namely, the i960 microcontroller's Dual Port Memory initialisation failed. Generally this is due to hardware conflict with other peripherals in the system, although it could also be the consequence of a damaged card.

**Solution:**

Verify the card configuration, check that there are not conflicts with other peripherals. If a remote module is used, retransmit the firmware to the module. Qualified technicians can carry out a Hardware test on the i960 microcontroller Dual Port Memory. If the problem persists, please contact the manufacturer.

### 6.8.18 1033 Plug PlugNumber: firmware Boot code is not running

**Cause:**

The i960 microcontroller's booting firmware was initialized but is not functioning correctly. Generally this is due to hardware conflict with other peripherals in the system.

**Solution:**

Verify the card configuration, check that there are not conflicts with other peripherals. If a remote module is used, retransmit the firmware to the module. Qualified technicians can carry out a Hardware test on the i960 microcontroller Dual Port Memory. If the problem persists, please contact the manufacturer.

### 6.8.19 1034 Plug PlugNumber: IRQ could not be set

**Cause:**

IRQ assigning to the AlbSLM axis card failed.

**Solution:**

Contact T.P.A. S.p.A..

### 6.8.20 1035 Plug PlugNumber: not present

**Cause:**

An error was generated during axis card initialization tests. Namely, the card was not detected.

**Solution:**

Verify that the card is actually in the system and that it is not damaged. Qualified technicians can carry out a Hardware test on the card. If the problem persists, please contact the manufacturer.



### 6.8.21 1036 Plug PlugNumber: error in software configuration

**Cause:**

The card hardware configuration does not correspond to the software configuration specified in system configuration. A possible cause, is that an axis was connected, in the Virtual-Physical Configuration, to the 5th, 6th, 7th or 8th connector of a card axis with only four connectors.

**Solution:**

Verify that the card hardware and software parameters correspond.

### 6.8.22 1037 Plug PlugNumber: failed opening dualport memory

**Cause:**

It failed opening the i960 microcontroller Dual Port Memory.

**Solution:**

Qualified technicians can run a Hardware test on the axis card. Please, contact T.P.A. S.p.A.

### 6.8.23 1038 Plug PlugNumber: error in ISA bus reading

**Cause:**

An error occurred during axis card access.

**Solution:**

Verify that the card is actually present in the system and that it is not damaged. Qualified technicians can carry out a Hardware test on the card. If the problem persists, please contact the constructor.

### 6.8.24 1039 Plug PlugNumber: Watch Dog timeout

**Cause:**

The firmware of the axis card *PlugNumber* is stuck.

**Solution:**

Contact T.P.A. S.p.A..

### 6.8.25 1040 Plug PlugNumber: +24 VDC power failed

**Cause:**

There is not any field power (+24 VDC) of the exits or it is not working properly

**Solution:**

Check the +24 VDC field power.

### 6.8.26 1041 Plug PlugNumber: +24 VDC SLM power failed

**Cause:**

Internal power supply of a cn2004 card does not fall within range prescribed by specifications. This power supply is also used as a backup supply of encoders for SLM drives.

**Solution:**

Check operation and stability of +24 VDC power supply. When using digital SLM drives, check their wiring (for short-circuits). If the problem persists, please contact the technical support service.

### 6.8.27 1042 Plug PlugNumber: +5 VDC power failed

**Cause:**

+5 VDC power supply of a cn2004 card does not fall within range prescribed by specifications. This power supply is available to supply external devices, such as encoders.

**Solution:**

Check wiring of external devices (for short-circuits). If the problem persists, please contact the

technical support service.

### 6.8.28 1043 Plug PlugNumber: axes power failed

**Cause:**

Power supply of DACs of a cn2004 card does not fall within range prescribed by specifications.

**Solution:**

Check wiring of axes (for short-circuits). If the problem persists, please contact the technical support service.

### 6.8.29 1044 Plug PlugNumber: disconnected

**Cause:**

The connection between the PC and a cn2004 board was interrupted.

The possible causes are as follows:

- power failure of the cn2004 board
- Ethernet cable disconnection, even if temporary, due to a false contact in the connectors or to damaged cables.
- firmware stop
- CPU reset due to overheating or to EM disturbance

**Solution:**

Verify that the module is switched on and properly powered. Verify Ethernet cables and connectors. If necessary update the firmware aboard. If the problem persists, please contact the technical support service.

### 6.8.30 1045 Plug PlugNumber: connected

**Cause:**

A cn2004 card has been connected to controller after initialization phase. Normally generated following a previous disconnection (error 1044).

### 6.8.31 1046 Plug PlugNumber: initialized

**Cause:**

A cn2004 card has been connected to controller after disconnection as a result of power failure.

### 6.8.32 1047 Plug PlugNumber: software configuration not permitted

**Cause:**

The device has received a configuration that is not compatible with the hardware in use or enabled. For instance, an axis has been configured whereas actual hardware axis is disabled.

**Solution:**

Verify that the card hardware and software parameters correspond.

### 6.8.33 1048 Plug PlugNumber: axis analog output write error

**Cause:**

Error detected during analogue output writing of an axis owing to a probable malfunction of the axis expansion module.

**Solution:**

Qualified technicians can carry out a Hardware test on the board. Please, contact the technical support service.

### 6.8.34 1049 Plug PlugNumber: analog output write error

**Cause:**

Error detected during analogue output writing.

**Solution:**

Qualified technicians can carry out a Hardware test on the board. Please, contact the technical support service.

### 6.8.35 1050 Plug PlugNumber: main power supply error

**Cause:**

Main power supply of a cn2004 card does not fall within range prescribed by specifications. Error may also be generated when power supply is irregular.

**Solution:**

Check operation and stability of power supply. If the problem persists, please contact the technical support service.

### 6.8.36 1051 Plug PlugNumber: firmware Main code is corrupt

**Cause:**

The cn2004 card is in Safe mode (only boot code active) because hardware has been forced (see card's technical literature).

It appears the flash memory is not enabled. This error generally indicates that a previous attempt to upgrade has failed, leaving the firmware code incomplete or corrupt.

**Solution:**

Upgrade firmware on the card, then switch off the card, disable Safe mode and switch back on. If the problem persists, please contact the technical support service.

### 6.8.37 1052 Plug PlugNumber: boot code is running

**Cause:**

The cn2004 card is in Safe mode (only boot code active) because hardware has been forced. The card is generally set to Safe mode so that an upgrade of firmware on the card can be forced. To find out how to enable or disable Safe mode, consult the card's technical literature.

**Solution:**

If necessary, upgrade firmware on the card, then switch off the card, disable Safe mode and switch back on. If the problem persists, please contact the technical support service.

### 6.8.38 1053 Plug PlugNumber: axes Watch Dog Expired

**Cause:**

A serious error while executing the firmware of the axis control board has occurred. Axes are disabled and the SYSOK signal, if any, is lowered. Do not reset the system.

**Solution:**

Contact T.P.A. S.p.A.

### 6.8.39 1054 Plug PlugNumber: axes Real-Time not running

**Cause:**

The cn2004 card has disabled axes and the SYSOK signal, if any, as a result of a serious system error on the ALBESLM plug. Do not reset the system.

**Solution:**

Contact T.P.A. S.p.A.

### 6.8.40 1055 Watchdog expired for plug PlugNumber

**Cause:**

The firmware of the card *PlugNumber* is stuck.

**Solution:**

Contact T.P.A. S.p.A..

### 6.8.41 1056 Plug PlugNumber: CAN Interface power failed

**Cause:**

Power supply of the transmission device on CanBus line in the indicated plug failed. It can depend on a short circuit, on a bus wiring error or on a damaged plug.

**Solution:**

Check the wiring of the whole Can line. Check the line connection to the numeric control. Remove the short circuit, if any. If the communication cannot be restored, please contact T.P.A. S.p.A.

### 6.8.42 1057 Plug NumeroPlug: Errore interno numero NumeroErrore

**Causa:**

Error in the hardware of the remote.

**Solution:**

Contact T.P.A.

## 6.9 Errors generated by memory management

### 6.9.1 1281 Error in the memory allocation on the heap area

**Cause:**

Available RAM memory is not sufficient to satisfy the requirement, for example, of a global matrix.

**Solution:**

Reduce the size of the global variables allocated in RAM.

### 6.9.2 1286 Error handling heap

**Cause:**

Error in the firmware's memory handling.

**Solution:**

Contact T.P.A. S.p.A.

### 6.9.3 1287 Too many heap memory deallocations

**Cause:**

Error in the firmware's memory handling.

**Solution:**

Contact T.P.A. S.p.A.

### 6.9.4 1289 Error creating global variables

**Cause:**

Too many global variables were defined, or the defined global matrixes are too large.

**Solution:**

Reduce the number of global variables or the size of the matrixes.

### 6.9.5 1290 Error in the dimension on non volatile variables

**Cause:**

Too many non volatile variables were defined, or the defined non volatile matrixes are too large.

**Solution:**

Reduce the number of non volatile variables or the size of the non volatile matrixes.

## 6.9.6 1291 Error in the dimension of read only variables

**Cause:**

Too many read only variables were defined, or the defined read only matrixes are too large.

**Solution:**

Reduce the number of read only variables or the size of the read only matrixes.

## 6.10 Errors generated by faults

### 6.10.1 1559 Breakpoint Trace

**Cause:**

Serious firmware error.

**Solution:**

Contact T.P.A. S.p.A.

### 6.10.2 1569 Invalid microprocessor operating code

**Cause:**

The microprocessor has encountered an unknown instruction. This could either be due to PC hardware problems or the files containing Albatros's firmware could be damaged.

**Solution:**

In the case of a local module, check that the files are not damaged and try reinstalling Albatros. In the case of Clipper modules, update the firmware. Run a PC hardware test, especially on the RAM. If the problem persists, please contact T.P.A. S.p.A.

### 6.10.3 1586 INTEGER value division by zero

**Cause:**

An attempt to divide an INTEGER by zero.

**Solution:**

Verify that all the divisions in the GPL functions are correct.

### 6.10.4 1600 Overflow in a floating point operation

**Cause:**

The result of an operation between FLOATs is greater than the capacity of the recipient.

$\pm 3,402823E+38$  for floats  
 $\pm 1,79769313486231E+308$  for doubles.

**Solution:**

Verify that the floating point calculations in the GPL functions are correct.

### 6.10.5 1601 Underflow in a floating point operation

**Cause:**

The result of an operation between FLOATs is smaller than the capacity of the recipient.

$\pm 1,401298E-45$  for floats  
 $\pm 4,94065645841247E-324$  for doubles.

**Solution:**

Verify that the float calculations in the GPL functions are correct.

### 6.10.6 1602 Invalid argument in a floating point operation

**Cause:**

An operand different from float type was used in a float operation.

**Solution:**

Verify that float calculations in the GPL functions are correct.

### 6.10.7 1603 Floating point value divided by zero

**Cause:**

An attempt to divide a float or double by zero. Raised also when a logarithm of zero is executed.

**Solution:**

Verify that all the divisions in the GPL functions are correct.

### 6.10.8 1604 Incorrect result in a floating point operation

**Cause:**

The result of an operation between floats is incorrect.

**Solution:**

Verify that the float calculations in the GPL functions are correct.

### 6.10.9 1605 Incorrect value for a floating point data

**Cause:**

The use of a smaller floating point value than the minimum representable value:

$\pm 1,401298E-45$  for floats  
 $\pm 4,94065645841247E-324$  for doubles.

**Solution:**

Verify that float calculations in the GPL functions are correct.

### 6.10.10 1728 Attempt to get access to an invalid address

**Cause:**

The program accessed an invalid memory area.

**Solution:**

Verify global/local variable congruity, if the problem persists, please report the anomaly.

### 6.10.11 1736 Data not aligned

**Cause:**

Serious error of the firmware.

**Solution:**

Contact T.P.A. S.p.A.

### 6.10.12 1735 Generic exception

**Cause:**

An unknown exception occurred.

**Solution:**

Contact T.P.A. S.p.A.

### 6.10.13 1801 Temperature alarm

**Cause:**

Temperature of controller's CPU has exceeded maximum permissible limits.

**Solution:**

Make sure there is no ventilation problem or anything causing overheating. If the problem persists, please contact the technical support service.

### 6.10.14 1802 Fan alarm

**Cause:**

Fan of controller's CPU is not working properly. Problem can lead to CPU overheating in no time.

**Solution:**

Contact technical support service.

### 6.10.15 1803 Unstable CPU frequency

**Cause:**

CPU work frequency is not stable.

**Solution:**

Contact T.P.A. S.p.A..

## 6.11 Errors generated by GPL functions

### 6.11.1 4097 The DeviceType DeviceName device is not configured

**Cause:**

A GPL instruction used a non configured device, that is a device with no Virtual-Physical connection. It can be generated by all the instructions in which a device is passed as parameter.

**Solution:**

Check in the control configuration that all the devices used by the function have a Virtual-Physical connection. Then retransmit configurations to the card.

### 6.11.2 4098 Global variable VariableName missing

**Cause:**

A GPL instruction received an undefined global variable as argument. This usually happens when the control was not correctly initialized.

**Solution:**

Recompile the whole GPL code and initialize control again.

### 6.11.3 4099 Function FunctionName missing

**Cause:**

An absent function was called. It can occur when the control has not been initialized after modifying the GPL code.

**Solution:**

Recompile the whole GPL code and initialize control again.

#### 6.11.4 4101 Inconsistent axis AxisName management

**Cause:**

An illegal state change was performed on an axis. For state changes consult the relative documentation.

The error could be generated by any of the instructions managing the axes, normally it occurs in the following cases:

- if an attempt is made to interpolate, coordinate an axis already occupied in a point-to-point movement (or vice versa).
- if a Chain, SetPFly or SetPZero instruction is executed on an axis in transparent mode.
- if an attempt is made to interpolate, coordinate a slave axis.

**Solution:**

Check that all axis transfers end with a wait in position instruction, especially if the axes alternate different types of movements (point-to-point, interpolation, etc)

#### 6.11.5 4105 Instruction not executable on step motor axis AxisName

**Cause:**

An attempt to execute an instruction on an axis which does not support it. For example, an interpolation instruction on a step-by-step axis.

**Solution:**

Correct the GPL code.

#### 6.11.6 4106 Remote module of the setp-by-step axis AxisName is not connected

**Cause:**

An attempt to operate on a step-by-step axis that is not connected to the control.

**Solution:**

Check the connection of the remote controlling the axis.

#### 6.11.7 4107 SYSOK instruction with incorrect arguments

**Cause:**

A SYSOK instruction with incorrect arguments was executed. Verify whether one or more digital outputs passed as instruction arguments are not correctly configured.

**Solution:**

Verify the GPL code and the Virtual-Physical configuration.

#### 6.11.8 4108 AxisName: Final quote beyond software limits

**Cause:**

An attempt to move an axis beyond the limits set in configuration or by the GPL code.

**Solution:**

Correct the machining program that caused the error. If necessary, correct the GPL code or axis configuration.

#### 6.11.9 4110 Wrong speed

**Cause:**

An axis was assigned a null or negative speed.

**Solution:**

Correct GPL code.



---

### 6.11.10 4111 Negative Acceleration on axis AxisName

**Cause:**

An axis was assigned negative acceleration.

**Solution:**

Correct GPL code.

### 6.11.11 4112 Negative Deceleration on axis AxisName

**Cause:**

An axis was assigned negative deceleration.

**Solution:**

Correct the GPL code.

### 6.11.12 4113 Axis AxisName: SLM command TimeOut expired

**Cause:**

An SLM command was not executed within maximum time allowed.

**Solution:**

Contact T.P.A. S.p.A.

### 6.11.13 4114 Axis AxisName: reset on Fast Input not effected

**Cause:**

The Fast Input Reset (on the fly homing) was not completed correctly. This procedure enables to reset to zero the position of a moving axis, the moment the corresponding fast input changes state. If the axis concludes the movement in process with no input switching, the system error is generated. This could be due to the incorrect setting of axis movement parameters or to a cabling problem in the fast input.

**Solution:**

Check the GPL code implementing on the fly homing, check fast input cabling.

### 6.11.14 4115 Axis AxisName: zero pulse not found

**Cause:**

The encoder zero pulse reset was not completed correctly. This procedure enables to reset to zero the position of a moving axis the moment the encoder 's zero pulse is detected. If the axis reaches the pulse search position without detecting the zero pulse, the system error is generated. This could be due to the incorrect setting of axis movement parameters or to a cabling problem in the pulse signal (axis connector C phase).

**Solution:**

Check the GPL code implementing pulse homing, check axis cabling.

### 6.11.15 4353 Unknown instruction operational code (Function: FunctionName line:LineNumber)

**Cause:**

An illegal instruction was detected during the execution of a GPL function. Generally this indicates that the files containing the compiled GPL code are damaged. Verify also whether the control software and firmware were updated without recompiling the GPL code, as the earlier version could contain instructions which are no longer supported by the new one.

**Solution:**

Recompile the whole GPL code and initialize control. If the problem persists, please contact T.P.A. S.p.A.

### **6.11.16 4354 Incorrect mathematical operation (Function: FunctionName: LineNumber)**

**Cause:**

A GPL instruction tried executing an incorrect mathematical operation, such as dividing by zero. Or data introduced in the GPL instruction is incongruent. This error is often generated by interpolation movement instructions, as this is the Firmware that performs the most mathematical operations.

**Solution:**

Check that the data passed to interpolation instructions is correct. If the problem persists, please report the problem to T.P.A. S.p.A..

### **6.11.17 4355 Incorrect address of matrix or vector (Function: FunctionName line: LineNumber)**

**Cause:**

A GPL instruction tried accessing an array or matrix element exceeding maximum size. For example, it tried accessing element 10 of a 5-element array. It could be generated by any instruction accepting an array or matrix as a parameter.

**Solution:**

Verify that all the matrix and array indexes passed to the instructions are within the array and matrix size.

### **6.11.18 4356 Instruction RET without CALL (Function: FunctionName line: LineNumber)**

**Cause:**

A RET instruction was executed although the stack did not contain the relative return address. Declaring a subprocedure before the exit function FRET instruction, without protecting it with a GOTO to avoid accidental execution, is the most frequent cause. It is also possible that an accidental jump occurred in a subprocedure.

**Solution:**

Check the GPL program flow. When possible, place subprocedures at the end of the body of the function (after the FRET instruction)

### **6.11.19 4357 Local variable missing (Function:FunctionName line LineNumber)**

**Cause:**

A GPL instruction tried to access a local variable which has not been allocated.

**Solution:**

Recompile and retransmit all card functions. If the problem persists, please report the problem.

### **6.11.20 4358 Jump label missing Function: FunctionName line: LineNumber)**

**Cause:**

A GPL instruction jumped to a non-existing jump label. It can be generated by GOTO, CALL, FCALL and all IFs.

**Solution:**

Recompile and retransmit all the functions to the card. If the problem persists, please report the problem.

### **6.11.21 4359 Incorrect macro argument (Function:FunctionName line: LineNumber)**

**Cause:**

A GPL instruction was passed invalid arguments. It can be generated by any instruction. However, in the great majority of cases, the GPL system tries to correct the situation automatically, by performing automatic type conversions (cast), which may imply wasting time. The error is generated when these

conversions are not possible and especially in the following cases:

- instructions operating on specific devices (SETTIMER, SETCOUNTER) that are given a different type of device.
- instructions operating on bits that are given a floating point number (AND, OR, etc)
- instructions operating on matrixes or arrays that are given a simple variable (SORT, MOVEMAT, etc.)
- instructions that operate on strings that are not given strings.

The error is generated even when the system tries to carry out an instruction in a board that does not manage such an instruction (for example an instruction SENDPDO or an instruction RECEIVEPDO in a board that is not a TMSCan or a TMSCan+ board)

**Solution:**

Correct the GPL code.

### 6.11.22 4360 Error in the memory allocation for executing (Function: FunctionName line:LineNumber)

**Cause:**

The GPL function tried to allocate a region of memory for internal use, but did not find available memory.

The error could indicate a temporary situation, due, for example, to an excessive number of tasks in execution at the same time or to excessively large global variables.

**Solution:**

Check the size of the global and local variables and if possible reduce their size. Verify if too many tasks are in execution at the same time and if necessary reduce them.

### 6.11.23 4361 Too many tasks enabled (Function: FunctionName line: LineNumber)

**Cause:**

An attempt to execute more than 256 tasks at the same time.

**Solution:**

Reduce the number of tasks in execution at the same time.

### 6.11.24 4362 Incorrect matrix format (Function: FunctionName line: LineNumber)

**Cause:**

An instruction operating on matrixes has found an invalid format. The instructions that could generate this error are the following:

- MOVEMAT if the format of the source matrix and the destination matrix do not correspond.
- CLEAR if a non-existing row of the matrix is being deleted.
- GETAXIS if the format of the matrix, passed as a parameter, does not correspond to the format expected by the instruction (consult GPL language documentation)

**Solution:**

Verify the above mentioned instructions in the task that generated the error. Check especially that the matrixes passed to MOVEMAT have the same number of columns of the same type and that the matrix passed to GETAXIS has the right format.

### 6.11.25 4363 Too many active ONINPUT instruction (Function: FunctionName line:LineNumber)

**Cause:**

More than 128 OnINput instructions have been activated.

**Solution:**

Reduce the number of ONINPUT.

### **6.11.26 4364 Already engaged axis with local reference (Function: FunctionName line:LineNumber)**

**Cause:**

The error concerns the activation of the rototraslate axis terns to execute interpolations on a number of Cartesian axes.

There was an attempt to execute a SETRIFLOC passing to the instruction an axis that was already engaged in a reference axis tern. It can also be generated if a RESRIFLOC is executed on an axis which is not engaged in any axis tern. It is also possible that no reference terns were available (there can be a maximum of 32 terns ).

**Solution:**

Check that the terns passed by the SETRIFLOC have no axes in common.

Check RESRIFLOCs.

Check that the RESRIFLOC is preceded by wait in position instructions.

Remember that the RESRIFLOC is not executed until the interpolation has concluded.

### **6.11.27 4365 Instruction ONINPUT actived on the same INPUT Function: FunctionName line: LineNumber**

**Cause:**

The same input was passed to an ONINPUT instruction more than once.

**Solution:**

Check that the same input is not sent as a parameter to two ONINPUTs.

### **6.11.28 4366 Too many ONFLAG instruction active (Function: FunctionName line: LineNumber)**

**Cause:**

More than 128 OnFlags instructions were activated.

**Solution:**

Reduce the number of ONFLAGs.

### **6.11.29 4367 Instruction ONFLAG actived on the same FLAG (Function: FunctionName line:LineNumber)**

**Cause:**

An ONFLAG instruction was passed to the same flag more than once.

**Solution:**

Check that the same flag is not passed as a parameter to two ONFLAGs.

### **6.11.30 4368 A ReadOnly variable writing has been attempted (Function: FunctionName line: Line Number)**

**Cause:**

An attempt to write on a readonly variable.

Readonly variables are always global and reside in the command flash. They are indicated as "static" in the global variables editor. If an attempt is made to write on one of these global variables this system error is generated.

The error is also generated if variables residing in the buffered RAM ("non volatile") are used as arguments of certain write instructions.

These instructions are:

- CRF the matrix passed for the milling cutter radius correction must be in RAM.
- COORDIN the variable passed to indicate the row in elaboration must be in RAM.

**Solution:**

Check all the static and non volatile variables.

---

### 6.11.31 4369 Too many master axes active (Function: FunctionName line: LineNumber)

**Cause:**

An attempt to activate more than four axes as master at the same time. This error is only generated by the CHAIN instruction.

**Solution:**

Reduce the number of master axes.

### 6.11.32 4370 Too many slave axes active (Function: FunctionName line: LineNumber)

**Cause:**

An attempt to activate more than eight axes as slaves of a single master axis. This error is only generated by the CHAIN instruction.

**Solution:**

Reduce the number of slave axes.

### 6.11.33 4372 Incorrect use of an instruction (Function: FunctionName line: LineNumber)

**Cause:**

An attempt to use a mailbox handling instruction (Sendmail, Waitmail, Endmail, Ifmail) inside a function called by an Errsys, Oninput or Onflag instruction.

**Solution:**

Clear the instruction that caused the error.

### 6.11.34 4373 Can't read feed rate (Function: FunctionName line: LineNumber)

**Cause:**

The Getfeed instruction was used on another card, instead of the ALBNT card or ALBSLM or ALBMEC or CN2004.

**Solution:**

Clear the instruction GetFeed from the function code. In hardware configuration check that the master board is an ALBNT or an ALBSLM or an ALBMEC or a CN2004 one.

### 6.11.35 4374 Too many IPC instruction in execution (Function: FunctionName line: LineNumber)

**Cause:**

The maximum limit of 16 IPC instruction in execution at the same time was exceeded.

**Solution:**

Modify the GPL code.

### 6.11.36 4375 Not all axes are connected to the same board (Function: FunctionName line: LineNumber)

**Cause:**

A FASTREAD instruction was executed, although the axes passed as parameters were not all connected to the same board.

**Solution:**

Modify the GPL code or the Virtual-Physical configuration as required.

**6.11.37 4378 Instruction not enabled (Function: FunctionName line LineNumber)****Cause:**

An attempt to use an instruction whose execution was not enabled. Probably, the hardware key is not correctly inserted or is missing.

**Solution:**

Insert the hardware key correctly. If the problem persists, contact the manufacturer.

**6.11.38 4379 Instruction can't be used in function called by events (Function: FunctionName line: LineNumber)****Cause:**

An attempt to use an illegal instruction in a function launched by interrupt. The functions launched by interrupt are passed as parameters to ONERRSYS, ONINPUT and ONFLAG instructions.

**Solution:**

Modify GPL code. Consult the list of instructions which can not be used with interrupt

**6.11.39 4380 Too many writing request into backup memory area (Function: FunctionName line: LineNumber)****Cause:**

Too many write operations were performed on the buffered memory at the same time (buffered memory is characterised by relatively slow access).

**Solution:**

Verify the instructions that perform write operations on the variables allocated in the buffered memory: counters, timers, matrixes and variables declared as "non volatile".

**6.11.40 4381 Can't use a serial channel not yet open (Function: FunctionName line: LineNumber)****Cause:**

An attempt to execute an instruction that operates on the serial port, before executing the COMOPEN instruction for this port.

**Solution:**

Modify GPL code.

**6.11.41 4382 Can't open a serial channel already open (Function: FunctionName line: LineNumber)****Cause:**

A COMOPEN instruction was executed on a serial port that has already been opened with the same instruction.

**Solution:**

Modify GPL code.

**6.11.42 4383 Too many auxiliary processes open (Function: FunctionName line: LineNumber)****Cause:**

An attempt to open more than 4 auxiliary processes at the same time.

**Solution:**

Modify GPL code.

#### **6.11.43 4384 Auxiliary process not in execution (Function: FunctionName line: LineNumber)**

**Causa:**

An attempt to access an auxiliary process which is not in execution.

**Solution:**

Modify GPL code.

#### **6.11.44 4385 Attempt to open an auxiliary process from another task (Function: FunctionName line: LineNumber)**

**Cause:**

An attempt to open an auxiliary process from a different task from the one that started execution. Auxiliary tasks can only be used by the tasks that started their execution.

**Solution:**

Modify GPL code.

#### **6.11.45 4386 Attempt to use a CanBUS communication port not yet opened (Function: FunctionName line: LineNumber)**

**Cause:**

An attempt to execute an instruction that operates on a CanBUS communication port, before executing the CANOPENDRIVER instruction on the port.

**Solution:**

Modify GPL code.

#### **6.11.46 4388 Attempt to close a CanBUS communication port not yet opened (Function: FunctionName line: LineNumber)**

**Cause:**

An attempt to close a CanBUS communication port, without having previously executed the CANOPENDRIVER instruction for this port.

**Solution:**

Modify GPL code.

#### **6.11.47 4387 Error opening CanBUS communication (Function: FunctionName line: LineNumber)**

**Cause:**

The CanBUS card initialization was not completed successfully. This could be due to an incorrect card configuration or to hardware conflicts with other components in the system.

**Solution:**

Verify the correct configuration of the CanBUS card. Check that there are no hardware conflicts. If the problem persists, contact T.P.A. S.p.A.

#### **6.11.48 4389 Attempt to open a CanBUS communication already opened (Function: FunctionName line: LineNumber)**

**Cause:**

An attempt to open a CanBUS communication port which had already been opened with the CANOPENDRIVER instruction.

**Solution:**

Modify GPL code.

#### **6.11.49 4390 CanBUS communication error (Function: FunctionName line: LineNumber)**

**Cause:**

An error occurred while using the GPL CANGETOBJECT or CANSETOBJECT functions. This could be due to the incorrect configuration of the CanBUS devices, to the use of incorrect parameters or to cabling problems. The parameters and configuration depend on the specific CanBUS device used, consult the technical documentation provided by the manufacturer.

**Solution:**

Check that the parameters used to access the devices are correct. Verify the devices' configuration and make sure that the devices' cabling is correct.

#### **6.11.50 4391 Error activating SYSOK (Function: FunctionName line: LineNumber)**

**Cause:**

The SYSOK signal activation was not successfully concluded. This is often due to a malfunctioning Greenbus transmitter on the axis card.

**Solution:**

Qualified technicians can perform a Hardware test on the i296 microcontroller Dual Port Memory. If the problem persists, please contact the constructor.

#### **6.11.51 4392 Synchronized movement channel not opened (Function: FunctionName line: LineNumber)**

**Cause:**

A synchronized movement instruction has been executed without having previously opened the corresponding channel using the command SYNCROOPEN.

**Solution:**

Correct the GPL code. Please, contact the machine constructor.

#### **6.11.52 4393 No lines to process (Function: FunctionName line: LineNumber)**

**Cause:**

The processing of a synchronized movement profile has been activated without the crossing points being previously assigned using the command SYNCROMOVE.

**Solution:**

Correct the GPL code. Please, contact the machine constructor.

#### **6.11.53 4394 Too many cycle errors (Function: FunctionName line: LineNumber)**

**Cause:**

There are more than 2000 cycle errors active.

**Solution:**

Correct GPL code by limiting the number of warning signals.

#### **6.11.54 4395 Too many messages (Function: FunctionName line: LineNumber)**

**Cause:**

There are ore than 2000 messages active.

**Solution:**

Correct GPL code by limiting the number of warning signals.



### 6.11.55 4397 Stack overflow on the function FunctionName (Function: FunctionName line: LineNumber)

**Cause:**

A GPL function stack exceeded the maximum limit of 2Kbyte.

**Solution:**

Compile the GPL code again and check in the compiler report the estimated stack space of the function that generated the system error. Then reduce the number of local variables and of parameters passed to the functions (replacing them, for example with global variables). Reduce the number of CALLs.

### 6.11.56 4398 Stack underflow on the function FunctionName (Function: FunctionName line: LineNumber)

**Cause:**

It can only occur in the case of a serious Firmware error, such as the incorrect management of function parameters or local variables.

**Solution:**

Contact T.P.A. S.p.A.

### 6.11.57 4399 Parameter out of range (Function: FunctionName line: LineNumber)

**Cause:**

A GPL variable or a device was assigned a value outside the allowed range.

**Solution:**

Correct and compile the GPL code again.

### 6.11.58 4865 The definition of the machine for the interpolation (G216 or G217) is missing

**Cause**

An attempt to move the axes with an ISO interpolation or the configuration indices have been set without defining in advance the configuration matrices and the axes that form the machine.

**Solution:**

Correct and compile the GPL code again, using the instructions ISOG216 .

### 6.11.59 4866 The definition of the indices of the selected machine configuration (M6) is missing

**Cause**

An attempt to move the axes with an ISO interpolation without defining in advance the indices of the machine's configuration matrices.

**Solution:**

Correct and compile the GPL code again, using the instruction ISOM6.

## 6.12 Errors generated by CNCTPA communication driver

### 6.12.1 16385 Disconnected module

**Cause:**

The connection between the Supervisor PC and a module was interrupted.

The possible causes are the following:

- power failure of the remote module
- Ethernet cable disconnection, even if temporary, due to a false contact in the connectors or to damaged cables.
- power failure or malfunctioning of the Ethernet hub (if present)
- interruption of the remote module firmware due to damaged configuration files.

- remote module CPU reset due to overheating or to EM disturbance.

**Solution:**

Verify that the module is switched on. Verify Ethernet cables and connectors. Update the firmware in the remote module. Check that this module has not overheated because of insufficient ventilation and that it is not subject to EM disturbance. If the problem persists, please contact T.P.A. S.p.A.

### 6.12.2 16386 Connected module

**Cause:**

A remote module was connected to the Supervisor PC after Albatros' initialisation phase. Albatros tries to connect all the modules indicated in the System Configuration during booting, which lasts approximately 4 seconds. Any module connected later generates a system error.

### 6.12.3 16387 Reconnected module

**Cause:**

A remote module was reconnected to the Supervisor PC after being disconnected. This error always follows error 16385: "Disconnected module".

### 6.12.4 16388 Initialized module

**Cause:**

A remote module was reinitialized during normal functioning. This implies that the module was disconnected and reconnected to the Supervisor PC beforehand. Therefore this error always follows error 16385: "Disconnected module".

It indicates the module reset due, for example, to power failure.

### 6.12.5 16389 Module interrupted connection

**Cause:**

A remote module has closed the connection with Albatros. This may happen when the module does not receive any command or query from the Supervisor PC for a long time. This error shows a problem (overload or deadlock) on the Supervisor PC.

**Solution:**

Check the Supervisor PC for programs that may cause overloads or deadlocks. Disable the screen saver on the Supervisor PC. If the problem persists, contact the machine constructor.

### 6.12.6 16641 AlbRtx doesn't answer to the commands

**Cause:**

An error arose during system initialization. Specifically, firmware does not respond as expected. This fault might be caused by a damaged firmware file.

**Solution:**

Try to reset system and if necessary install Albatros again. If the problem persists, contact T.P.A. S.p.A.

### 6.12.7 16642 AlbNet doesn't answer to the commands

**Cause:**

An error arose during system initialization. Specifically, communication software with remote modules does not respond as expected. This fault might be caused by a damaged software file.

**Solution:**

Try to reset system and if necessary install Albatros again. If the problem persists, please contact T.P.A. S.p.A.

---

### 6.12.8 16643 Operating System doesn't allow use of RTX

**Cause:**

The Operating System installed on the PC does not permit the use of RTX and consequently doesn't allow correct operation of versions of Albatros requiring its presence.

**Solution:**

Update the PC Operating System. Check minimum system requirements on the "Installation Manual of Albatros".

### 6.12.9 16644 Operating System doesn't allow use of AlbNet

**Cause:**

The Operating System installed on the PC does not allow correct operation of current version of Albatros.

**Solution:**

Update the PC Operating System. Check minimum system requirements on the "Installation Manual of Albatros".

### 6.12.10 16645 Error sending firmware code ...

**Cause:**

An error arose during system initialization. Specifically, transmission of a firmware file to a module failed.

**Solution:**

Try to reset system. If the problem persists, contact T.P.A. S.p.A.

### 6.12.11 16646 Could not restart firmware code

**Cause:**

An error arose during system initialization. Specifically, firmware failed restarting after a previous stop.

**Solution:**

Try to reset system. If the problem persists, contact T.P.A. S.p.A.

### 6.12.12 16647 Error while sending CanBUS hardware configuration

**Cause:**

An error was generated during the transmission to CAN master card of devices configuration. Error occurs when file couldn't be registered into remote module or the download of file in CAN card flash memory failed. Configuration file is a binary file with name is CANBUS followed by card number (from 0 to 3) and with extension DBM and it is registered into module CONFIG folder. It exists a CANBUSn.DBM for every card present in the system.

**Solution:**

Check that file is complete, that it has a size not higher than a little number of Kbs, that card is running. If the problem persists, contact T.P.A. S.p.A.

### 6.12.13 16897 RTX not installed

**Cause:**

The installed version of Albatros requires RTX installed on the PC; however, this has not been detected.

**Solution:**

Install RTX or install it again, if already loaded. Consult "Installation Manual of Albatros".

### 6.12.14 16898 User has no Administrator rights

**Cause:**

Albatros was started up by a user without Administrator rights on the PC. Administrator rights are required for correct operation of Albatros.

**Solution:**

Close current working session and access system as "Administrator" or as other user with Administrator rights.

### 6.12.15 16899 Wrong dimension of module RAM

**Cause:**

RAM dimension detected on remote module is incongruent with expected dimension. This fault is normally caused by a hardware failure.

**Solution:**

If the problem persists, contact T.P.A. S.p.A.

### 6.12.16 16900 Incorrect module IP address

**Cause:**

A remote module has been detected whose IP address does not belong to the supervisor PC subnet. Albatros cannot communicate correctly with the module.

**Solution:**

Check settings of AlbdHCP service and of LAN board on the supervisor PC. Consult "Installation Manual of Albatros".

### 6.12.17 16901 Module is already connected to another equipment

**Cause:**

A remote module appears to be connected to a different supervisor PC. This may be caused by presence on the network of another PC with Albatros running and using the same module. It may also be caused by a failure of the communication software on the module.

**Solution:**

Check that no other supervisor PC is using the remote module. Reset the module. If the problem persists, please contact T.P.A. S.p.A.

### 6.12.18 16902 The module is not configured

**Cause:**

A module appears not to be configured in "System Configuration".

**Solution:**

Configure the module.

### 6.12.19 16903 Firewall settings prevent communication

**Cause:**

A firewall blocking communication between Albatros and remote modules has been detected.

**Note:** Albatros can identify Windows Xp firewall only and not other firewalls as those included in some antivirus software packages.

**Solution:**

Modify firewall settings or disable it.

### 6.12.20 16904 Network card not present or disabled

**Cause:**

No network card available for connection to remote modules has been found.

**Note:** the detection of a network card does not grant proper settings and connection.

**Solution:**

Check the network card and its configuration. If the problem persists, contact the machine constructor

### 6.12.21 16905 Main firmware code missing

**Cause:**

Albatros can't find a firmware file on the PC hard disk. The problem may be caused by an accidental file deletion or a incorrect update.

**Solution:**

Check that files in the FW subfolder of Albatros setup are present and have the right version number. Contact the machine manufacturer.

### 6.12.22 16906 RTX version incompatible with main firmware code

**Cause:**

RTX version is not compatible with the installed firmware.

**Solution:**

Install the right RTX version or update the firmware. Contact the machine constructor.

### 6.12.23 16907 Operating system version incompatible with the Main code of the firmware

**Cause:**

Operating system version of the remote module is not compatible with the firmware installed.

**Solution:**

Install in the remote module the correct operating system version or update the firmware. Contact the machine constructor.

### 6.12.24 17153 PLUGTYPE: firmware code of GreenBus transmitter not found

**Cause:**

A firmware file could not be found in FW folder. Normally this depends on an accidental erasure or on an incomplete or damaged installation.

**Solution:**

Reinstall Albatros after executing a backup of the whole system. Contact the machine constructor.

### 6.12.25 17154 PLUGTYPE: firmware code of GreenBus transmitter damaged

**Cause:**

File containing firmware of GreenBus transmitter resides in FW folder but appears to be damaged or incomplete.

**Solution:**

Reinstall Albatros after executing a backup of the whole system. Contact the machine constructor.

### 6.12.26 17155 PLUGTYPE: error sending bootstrap code of GreenBus transmitter

**Cause:**

An error occurred during system initialization. Specifically, a firmware file failed being sent to a module.

**Solution:**

Try to reset system. If the problem persists, contact T.P.A. S.p.A.

**6.12.27 17156 PLUGTYPE: error sending main code to GreenBus transmitter**

**Cause:**

An error occurred during system initialization. Specifically, a firmware file failed being sent to a module.

**Solution:**

Try to reset system. If the problem persists, contact T.P.A. S.p.A.

**6.12.28 17157 PLUGTYPE: bootstrap code not found**

**Cause:**

A firmware file could not be found in FW folder. Normally this depends on an accidental erasure or on an incomplete or damaged installation.

**Solution:**

Install Albatros again after executing a backup of the whole system. Contact the machine constructor.

**6.12.29 17158 PLUGTYPE: main code not found**

**Cause:**

A firmware file could not be found in FW folder. Normally this depends on an accidental erasure or on an incomplete or damaged installation.

**Solution:**

Reinstall Albatros after executing a backup of the whole system. Contact the machine constructor.

**6.12.30 17159 PLUGTYPE: error sending bootstrap code**

**Cause:**

An error occurred during system initialization. Specifically, a firmware file failed being sent to a module.

**Solution:**

Try to reset system. If the problem persists, contact T.P.A. S.p.A.

**6.12.31 17160 PLUGTYPE: error sending main code**

**Cause:**

An error occurred during system initialization. Specifically, a firmware file failed being sent to a module.

**Solution:**

Try to reset system. If the problem persists, contact T.P.A. S.p.A.

**6.12.32 17409 Could not send auxiliary executable ...**

**Cause:**

This error may occur while updating firmware on a remote module. It may be caused by a momentary network failure but also by a damaged firmware on the module. This error message may include an error code.

**Solution:**

Try to switch off and switch back on the remote module and repeat the update procedure. If the problem persists, contact T.P.A. S.p.A.

### 6.12.33 17410 Could not run auxiliary executable ...

**Cause:**

An error occurred during system initialization. Specifically, an auxiliary program could not start execution. The error message also reports the auxiliary program name and possibly an error code.

**Solution:**

Try to reset system. If the problem persists, contact T.P.A. S.p.A.

### 6.12.34 17665 Communication library not found ...

**Cause:**

A Albatros system library has not been found. Normally this is caused by an accidental erasure of the file, or by an incomplete or damaged installation. The error message also reports name of the missing library and possibly an error code.

**Solution:**

Install Albatros again after executing a backup of the whole system. Contact the machine constructor.

### 6.12.35 17666 Error using communication library ...

**Cause:**

A system library returned an unexpected error code. Normally this happens when the current library version is not aligned with the rest of the system.

**Solution:**

Contact T.P.A. S.p.A.

### 6.12.36 17667 DLLNAME: firmware code could not start running

**Cause:**

An error occurred during system initialization. Specifically, firmware code could not start. "*DLLNAME*" corresponds to the software component that caused the error.

**Solution:**

Try to reset system. If the problem persists, Contact T.P.A. S.p.A.

### 6.12.37 17668 DLLNAME: could not get pointer to shared RAM

**Cause:**

An error occurred during system initialization. Specifically, the communication channel with firmware could not be opened. "*DLLNAME*" corresponds to the software component that caused the error.

**Solution:**

Try to reset system. If the problem persists, Contact T.P.A. S.p.A.

### 6.12.38 17669 DLLNAME: key 'Bin=' missing in TPA.INI

**Cause:**

Configuration file of Albatros is incorrect. Specifically, key "Bin" is missing, which identifies folder where system components are stored. This error may also be caused by an accidental erasure. "*DLLNAME*" corresponds to the software component that caused the error.

**Solution:**

Check that file "TPA.INI" exists and contains a valid "Bin" key. Contact the machine constructor.

### 6.12.39 17921 Could not send NODETPA ...

**Cause:**

This error may occur while updating firmware on a remote module. It may be caused by a momentary network failure but also by a damaged firmware on the module. This error message may include an error code.

**Solution:**

Try to switch off and on the remote module and repeat the update procedure. If the problem persists, contact T.P.A. S.p.A.

### **6.12.40 17922 NODETPA did not restart ...**

**Cause:**

This error may occur while updating firmware on a remote module. It may be caused by a momentary failure but also by a damaged firmware on the module. This error message may include an error code.

**Solution:**

Try to reset Clipper module and repeat the update procedure. If the problem persists, contact T.P.A. S.p.A.

### **6.12.41 17923 NODETPA not running ...**

**Cause:**

A remote module has been detected on the network, whose communication software is not running. Normally this is caused by a failure of communication software. The error message may include an error code.

**Solution:**

Try to switch off and on the remote the module. If the problem persists, contact T.P.A. S.p.A.

### **6.12.42 18177 NodeTpa tried to access to an invalid address**

**Cause:**

The remote module communication software raised an error. The error message may include an error code.

**Solution:**

Try to switch off and on the module. If the problem persists, contact T.P.A. S.p.A.



## 7 System Configuration

### 7.1 Introduction

In the chapter concerning the composition of the system, we have already seen how the Albatros system consists of one or more modules forming a plant and how each one of these is organised in a hierarchical structure.

To configure the machine from the point of view of Albatros it is necessary to follow a sequence of operations which enable to configure the various logic levels and the underlying hardware. The general order to be followed when configuring a system is:

- Module Configuration
- Definition of Groups and Subgroups
- Devices Configuration
- Machine Configuration
- System Configuration
- Hardware Configuration
- Virtual physical Configuration

Basically Module, Group and Machine Configuration determine the logic structure of the machine, while the System, Hardware and Physical Virtual Configuration determine the physical structure. We will analyze each one of these points in detail in the following paragraphs.

### 7.2 Devices Configuration

#### 7.2.1 Introduction

In the chapter concerning the composition of the Albatros system, we described the various types of devices which can appear in a module. Now we will describe the devices from the point of view of their configuration.

Each type of device can be configured a maximum number of times, as specified in the following list:

| Type of device | Max. number |
|----------------|-------------|
| Analog input   | 128         |
| Analog output  | 128         |
| Digital input  | 4096        |
| Digital output | 4096        |
| Output Nibble  | 256         |
| Input Nibble   | 256         |
| Input port     | 512         |
| Output port    | 512         |
| Axis           | 240         |
| Timer          | 128         |
| Counter        | 128         |
| Flag Bit       | 1024        |
| Flag Switch    | 256         |
| Flag Port      | 256         |
| Function       | 4096        |

The data to be specified during configuration depends on the device, however, except for axis devices, it is almost always the same. We will now see the configuration of certain devices.

**IMPORTANT:**

To a card **Can** can be associated only devices of type: digital input, digital output, input port, output port.

#### 7.2.2 Generic Device

Most devices require the same configuration parameters. Below we have illustrated the configuration of a Digital Input, however the same considerations apply to:

- Flag bit
- Flag switch
- Analog output
- Input Port

- Flag Port
- Timer
- Counters
- Input Nibble
- Output Nibble
- Function

**General Input configuration window**

To configure any device among those listed above, the following settings must be specified:

- **Name:** name of the device, a maximum of 40 characters.
- **Comment:** a brief description of the device, it can be translated into various languages, no spaces.
- **Logical:** assigned automatically by the system.
- **Read Accesses:** specifying the minimum access level required for the device to be visualised in the Diagnostic windows or in the Synoptic Views.
- **Write accesses:** specifying the minimum access level required to modify the state of the device.
- **Public:** specifying if the state of the device can be read or modified by a GPL code not belonging to the group of the device.

### 7.2.3 Digital output

The digital output has one parameter that standard devices do not have: the *One shot multivibrator*

Digital output configuration window

**Digital output configuration window**

To configure a digital output, the following settings must be specified:

- **Name:** name of the device, a maximum of 40 characters.
- **Comment:** a brief description of the device, it can be translated into various languages, no spaces.
- **Logical:** assigned automatically by the system.
- **One shot multivibrator:** if selected, it configures the output as one shot multivibrator, which means that when the output is set to ON it switches automatically back to OFF 200 ms later.
- **Read Accesses:** specifying the minimum access level required for the device to be visualised in the Diagnostic windows or in the Synoptic Views
- **Write accesses:** specifying the minimum access level required to modify the state of the device.
- **Public:** specifying whether the state of the device can be read or modified by a GPL code not belonging to the group of the device.

## 7.2.4 Analog input

The analog input has one parameter that standard devices do not have: *the type of power in input.*

The screenshot shows a dialog box titled "Analog input". It contains the following fields and options:

- Analog input section:**
  - Name: [Empty text box]
  - Comment: [Empty text box]
  - Logical: [Text box containing "2"]
- Type section:**
  - +10 / -10 Volt
  - 0 / +10 Volt
- Public:**
- Read Accesses:**
  - User
  - Service
  - Manufacturer
  - Tpa
- Write accesses:**
  - User
  - Service
  - Manufacturer
  - Tpa
- Buttons:** OK and Cancel

**Analog input configuration window**

To configure an Analog input the following settings must be specified:

- **Name:** name of the device, a maximum of 40 characters.
- **Comment:** a brief description of the device, it can be translated into various languages, no spaces.
- **Logical:** assigned automatically by the system.
- **Type:** to select the power interval read in input.
- **Read Accesses:** specifying the minimum access level required for the device to be visualised in the Diagnostic windows or in the Synoptic Views
- **Write accesses:** specifying the minimum access level required to modify the state of the device.
- **Public:** specifying if the state of the device can be read or modified by a GPL code not belonging to the group of the device.

## 7.2.5 Axis


### Base Data

The base data to be specified is:

- **Name:** name of the device, a maximum of 40 characters.
- **Description:** a brief description of the device, which can be translated into various languages, no spaces.
- **Resolution:** resolution of the encoder, depending on the characteristics of the encoder and on the specified unit of measure. Remember that Albatros axis cards count as pulses the rising edges and the falling edges of both encoder phases (a 2500 pulses/revolution encoder will be detected as a 10000 pulses /revolution encoder).
- **Axis Typology:** type of axis. The types are: **Analog** (analogically controlled), **Stepping motor**, **Digital**, **Count** (only encoder reading), **Frequency/Direction** (4° AlbSLM card connector), **Virtual**.
- **Unit of Measure:** the unit of measure used to indicate the position of the axes. As all the derived dimensions depend on it, we advise to set this parameter before any other.
- **Encoder Phases Rev:** it allows you to correct via software a possible cable inversion of the encoder phases.
- **Reference Reverse:** it allows you to reverse the speed reference of the axis. If used with the encoder phases reverse it allows you to reverse the direction of the axis (if cabling is correct).
- **Zero pulse enable:** only available for counting axes, it automatically resets the position to zero when the encoder pulse is detected.

### Movement parameters

Parameters used for axis point to point movement.



- **Max Speed:** max speed of the axis.
- **Acceleration:** time of acceleration ramp.
- **Deceleration:** time of deceleration ramp.
- **Minimum Speed:** speed reached by the motor in a single step; it can only be set on stepping motor axes.
- **Slope Typology:** ramp typology of acceleration and deceleration. Not available for stepping motors.
- **Proportional:** proportional coefficient of the position loop PID controller.
- **Integrative:** integration coefficient of the position loop PID controller.
- **Derivative:** derivation coefficient of the position loop PID controller.
- **Feed Forward:** percentage of feed forward. It allows you to reduce the loop error at equal speed.
- **Feed Forward Accel.:** percentage of feed forward acceleration. It allows you to eliminate the remaining loop error (not eliminated by the feed forward) during axis acceleration and deceleration phases.
- **Integrative Samples:** Sets the number of samples of loop error, used to calculate the integral component. Valid values are in the range 1 to 200. The default value is 50. See gpl SETINTEGTIME instruction.

### Interpolation parameters

Parameters used for axis interpolation movement.

The screenshot shows the 'New axis' dialog box with the 'Interpolation Parameters' tab selected. The 'Speeds and accelerations' section contains three input fields: 'Max Speed' [m/m] with a value of 0, 'Acceleration' [ms] with a value of 0, and 'Deceleration' [ms] with a value of 0. The 'Working Constants' section contains five input fields: 'Proportional' (0), 'Integrative' (0), 'Derivative' (0), 'Feed Forward' (0), and 'Feed Forward Accel.' (0). The 'Slope Typology' section has three radio buttons: 'Linear' (selected), 'S-shaped', and 'Double S'. At the bottom of the dialog are four buttons: 'OK', 'Cancel', 'Apply', and 'Help'.

Except for minimum speed, they have the same meaning as the parameters described in the Moving Parameters. However these are used for interpolation movements.

Note: acceleration and deceleration values, set in the interpolation parameters, cannot be lower than the corresponding values in the movement parameters.

## Other parameters

- **Manual Speed:** specifying the maximum configuration speed which can be used in manual movements. It will never exceed the maximum set speed.
- **Dynamic Servoerror:** Valid values are 0 (= normal) and 1 (= dynamic). The default value is 0. See gpl SETMAXERTYPE instruction.
- **Wait axis still:** enables or disables the overshoot recovery function. It sets a pause of 50 ms at the end of each movement.
- **Axis moving timeout:** Valid values are in the range 0 to 1024. See gpl ENABLESTARTCONTROL instruction.
- **Incorrect encoder connection limit:** The set values are expressed in the unit of measure that axis resolution is expressed in. The settable values must be in the range 128/axis resolution to 16384/axis resolution. The default setting is calculated based on a number of steps equivalent to 1024, i.e. 1024/axis resolution.
- **Positive Limit for Servoerror:** maximum value of the loop error for loop correction in positive direction.
- **Negative Limit for Servoerror:** maximum value of the loop error for loop correction in negative direction.
- **Positive Axis Limit:** maximum value of axis running in positive direction.
- **Negative Axis Limit:** maximum value of axis running in negative direction.
- **Positive quiescent threshold:** tolerance on arrival position in positive direction.
- **Negative quiescent threshold:** tolerance on arrival position in negative direction.




## Reference parameters

The screenshot shows the 'New axis' dialog box with the 'Reference Parameters' tab selected. The dialog contains the following fields and values:

| Parameter              | Unit | Value                               |
|------------------------|------|-------------------------------------|
| Reference              | [V]  | 9.0                                 |
| Automatic Adjust       |      | <input checked="" type="checkbox"/> |
| Initial Offset         | [V]  | 0                                   |
| Notch Filter frequency | [Hz] | 0                                   |
| Minimum Voltage        | [V]  | Negative: 0, Positive: 0            |
| Threshold              | [V]  | Negative: 0, Positive: 0            |

- **Reference:** value of the reference power corresponding to maximum speed
- **Automatic Adjust:** enables or disables calculation of automatic offset recovery. It's usually enabled.
- **Initial Offset:** Value to which initial reference offset is set. Value must be in the range -10 to 10. Default value is 0.
- **Notch filter frequency:** Frequency value to be filtered. Value must be in the range 0 to 500.
- **Minimum voltage:** Sets the minimum voltage parameters for the axis indicated. The negative value must be in the range -10 to 0, the positive value in the range 0 to +10. See SETDEADBAND instruction.
- **Threshold:** Sets the threshold values. They are always less than or equal to the respective minimum voltage values, hence the negative threshold value must be between 0 and the negative minimum voltage value. The maximum threshold value must be between 0 and the positive minimum voltage value.


## Access levels



- **Read Accesses:** specifying the minimum access level required for the axis to be visualised in the Diagnostic windows or in the Synoptic Views.
- **Write accesses:** specifying the minimum access level required to modify the state of the axis.
- **Public:** specifying whether the state of the axis can be read or modified by a GPL code not belonging to the group of the axis.

## Axes chaining


Axes chaining parameters. These are the PID controller coefficients which correct the loop error difference between the master axis and the slave axes.



- **Proportional:** proportional coefficient
- **Integrative:** integration coefficient
- **Derivative:** derivation coefficient

### Screw linearity correction

Setting the screw linearity correction of the axis. The correctors allow axis positioning errors to be compensated where these are due to mechanical imprecision of the axis itself (auto-correctors) as well as errors due to the effect deriving from the other axes of the machine (crossed correctors) typically related to bending in the structure. The correctors are not automatically enabled but must be enabled in the editing window for correction values ( **[Edit...]** button) and activated with the GPL code using the command `ENABLECORRECTION`.




- **Correction interval:** this allows the distance between one correction and the next to be set. The measurement number is given by the length of the axis divided by the length of the correction interval.
- **Corrector file name:** this allows the name of the file in which the correction values are saved to be set. This will be an ASCII file in which the values are separated by the character ";". This allows them to be edited with a standard text editor. The file extension is not specified, the extension ".csv" (comma separated values) is automatically assigned.
- **Correction data:** allows the specification of the list of the axes to be included in the calculation of the correction of the current axis. The current axis is always included in the list, this means that the auto-corrector is always present. Up to another 5 axes can be specified. To add an axis select it in the list on the left and press the [**>>Add**] button. To remove an axis select it in the list on the right and press the [**Remove <<**] button. To specify correction values select an axis from the list on the right and press the [**Edit...**] button. A window is opened with a table in which to insert the correction values.

**NOTE:** There is a limit of **235** screw linearity corrections managed by the system for each axis. Consequently, the length of the measuring interval must be at least the 235th part of the length of the axis. For example, if an axis is 2500 mm long, the correction interval must be set at 10.63 mm or more. There is also a limit to the maximum value of an individual correction: this must be lower than 1024 encoder steps, for example for an axis with a resolution of 256 steps/mm the maximum correction is  $\pm 4$  mm.

## 7.3 Logical Configuration

### 7.3.1 Plant configuration

To define a new machine or modify an existing one, access the Module Configuration screen page. Notice that, in this case, by Module Configuration we intend the configuration of the modules composing the plant, as confirmed by the heading of the configuration window shown in the following image: "Plant".



**Plant configuration window**

The Configuration environment can only be opened (from the manufacturer level or a higher level) when all the other work windows (synoptic, diagnostic, etc.) are closed, and it is done with the following command:

#### **Access to Configuration**

Select the heading **Open Configuration** from the **File** menu.

If no modules of the plant have been configured, Module Configuration is opened automatically, otherwise Machine Configuration will be opened. In this case, to access Module Configuration:

Select the heading **Module Configuration** from the **Edit** menu.

The window shown in fig. 8.1 will appear.

To add a module to the plant simply press **[New]**. **[Modify]** allows you to modify the data of an existing module, **[Delete]** to remove a module and **[Close]** to exit plant configuration.

When the **[New]** button is pressed, the window shown in the following figure is displayed.

**Module configuration window**

The data that identifies the machine, to be specified, is:

- the number of the module: a progressive integer number which, if not specified, is assigned by the system
- a brief description

It also contains some data concerning the underlying Hardware. The same window can be opened from the branch of the Configuration Module for the groups and from the branch of the Hardware Configuration Module.

### 7.3.2 Groups Configuration

When the machine is designed from scratch it is necessary to define all the components and to write all the control cycles. However, we often develop projects for finished machines which have to be conveniently modified.

Because in the Albatros environment machines are organised following a hierarchic model (Machine, Group, Subgroup, Device), it is possible to create a file of loosely configured groups according to the most frequently used components. In this case, the machine can be designed by taking the required groups from the files and modifying them where necessary.

Therefore, the groups file is a collection of "standard" groups which allows you to design on a modular basis and, above all, to re-use the configuration work already done.

#### **Creating a group**

To create a new group access the Groups Configuration screen page. All the groups, sub-groups and devices come from the first branch of the tree, called Module. The Module branch cannot be modified. If you press the [ENTER] key or the [Modify] button, a dialog box opens to modify the module data.

Select the heading **Groups** from the **Edit** menu

From here it is possible to create new groups, to modify or delete existing ones and to copy a group giving the copy a new name.

#### List of the commands to create, modify, delete groups, sub-groups and devices

| Command                                     | Action                                 |
|---|--|
| Creating a new group, a sub-group, a device | [CTRL+ENTER], Button [New], Edit->New  |
| Modifying a group, a sub-group, a device    | [ENTER], Button [Modify], Edit->Modify |
| Deleting a group, a sub-group, a device     | [DEL], Button [Delete], Edit->Delete   |

When you create a new group, the window below appears where following data must be set:

- the name of the group;
  - a comment
- (both can be translated in the languages used by Albatros).

**Group configuration window**

It is also possible to indicate the group as **Intergroup**. This setting was used in previous versions of Albatros to allow the GPL code of other groups to access the devices and functions of this group. In this version the same result can be obtained by setting the devices as public. However at least one group must be set as Intergroup as this setting is used by Albatros to identify the "main" group of the machine. This is the group whose main function (the one with the same name as the group) is launched automatically when the machine is booted. The function of this mechanism is to start the machine and launch the tasks that verify that everything is functioning correctly, before passing the control to the user.

#### Adding devices to a group


To create a subgroup of the group, you must be positioned on the group. The window below opens.

**Subgroup configuration window**

If we do not intend to create any subgroups, select the *Devices List*, as in the figure below and press **[OK]**. The name of the subgroup will be given automatically.

It is now possible to insert the single devices in the group. The process is similar to that used to create subgroups.

In this case a window containing the list of available devices will appear (see figure below).




**Devices selection window**

Select the required device and press **[OK]** for confirmation.

Another window will appear, to enable us to enter a name, a comment and other data which varies according to the selected device. A detailed description of the devices and their settings will follow in the chapter Devices Configuration.

### ***Copying a device***

The device copy function allows you to make a copy of any device. First, select the device and then press **[Copy]**. To insert the device in the list press **[Paste]** and enter the new name in the dialog window.




**Device copy window**

### ***Copying a group or subgroup***



The group copy function allows you to copy a group with all the subgroups and devices it contains. Moreover, the corresponding group synoptic (having the same name as the group), if existent, is also copied.

This function allows you to create rapidly groups which have a similar structure to that of an existing group, without having to re-create all the devices one at a time. To copy a group, select the required group, press **[Copy]** and enter the new name of the group in the dialog window.




**Group copy window**

### 7.3.3 Machine configuration

Once all the groups and all the necessary devices within the groups have been configured, the Machine Configuration consists simply in selecting the groups which really exist .


To access the Machine Configuration:

Select the heading **Machine** from the **Edit** menu.  
The window shown in the following image will appear.



**Machine Configuration**

To insert a new group press **[New group]**. A window containing the list of all the groups contained in the file will appear.



**Machine configuration: group selection window**

At this stage, select the chosen group and **drag it with the mouse** to the Machine Configuration window. Notice that this is the only possible way of performing this operation. It is also possible to remove an existing group or to search starting from the name of the group.


The machine can have only one intergroup. If more than one group was indicated as intergroup in the Group file, only one will have to be selected.

If necessary the configuration of certain devices may be modified, especially the axes configuration. In fact, it is possible to access the parameters of the devices through the machine configuration too, although most parameters can not be modified from this area. Remember also that any modification carried out in Machine configuration is not extended to the corresponding device in the group file.

## 7.4 Physical Configuration

### 7.4.1 System Configuration


The system configuration allows you to connect the physical resources (control units) to the modules defined in the logic configuration. This is possible into the System Configuration dialog box. The **modules** list of the plant is shown and to each of these a **Network Node**.



System Configuration

- **Local node** "Local" systems in which the HW handling the control is mounted directly on the user's system interface, that is the PC.
- **Name of a network node:** "Remote" systems in which the HW handling the control is connected to the PC through a serial line or network.
- **Not configured:** no configuration. This is the default at the beginning. If this choice remains, as a result it will be possible in the dialog box **Network Nodes Connections** to associate a remote module.

Up to 16 modules can be configured and one only can be configured as local node.

To assign a module, select the button **[Edit]** or double-click with the mouse on the network node to modify. Opening the pull-down menu, the list of the available remote modules is displayed, and it is also possible to use a local node or to set a module as not configured. To confirm the selection, select the button .

**N.B:** The profile machining of Albatros is protected by a USB hardware key, configured by T.P.A. S.p.A.

## 7.4.2 Hardware Configuration

Hardware configuration consists in deciding what kind of board, plug or I/O remote units make up the system.

The card occupying at the first position is called Master board.

Albatros checks if the board of the hardware configuration is correctly inserted. The operator is informed of incongruences or of errors in inserting.

In this system boards can be configured on Can, POWERLINK II and EtherCAT-Buses.

In this case links between physical and logical devices are defined in an external file, whose name CANBUS.DEF is fixed for the Can-Bus, EPLBUS.DEF for PowerLinkII and ECATBUS.DEF for EtherCAT. Clipper NT Embedded remote modules do not manage these field buses.

The TRS-AX, TRS-IO and TRS-16 remote modules can be connected only to TMSbus, TMSbus+ and TMSCombo+ boards.

No more than 4 TRS-AX remote modules can be connected to each TMSbus and TMSbus+ board.

Kinds of configurable cards:

- |                 |            |
|-----------------|------------|
| • TMSbus boards | max. two   |
| • TMSbus+       | max. four  |
| • TMSCombo+     | max. four  |
| • DualMech      | max. four  |
| • DualMech Mono | max. four  |
| • TMSCan        | max. two   |
| • TMSCan+       | max. four  |
| • AlbNT         | max. four  |
| • AlbSLM board  | max. four  |
| • AlbMech       | fino a due |
| • AlbIO32       | max. two   |
| • AlbNTPLC      | one only   |
| • CN2004        | one only   |

These are the I/O remote modules that can be configured on GreenBus (v 3.0):

- Albre8 8 digital inputs and 8 digital outputs
- Albre16 16 channels which can be configured via software as digital input or output.
- Albre24 24 digital inputs and 24 digital outputs
- Albre48 48 digital inputs and 48 digital outputs
- Albrem 16 digital inputs and 16 digital output, 4 analog inputs and 4 analog outputs
- AlbSTEP 8 digital inputs and 6 digital outputs, one stepping motor
- AlbEV 20 or 24 electrovalves (D-sub 25 pin connector)
- AlbAPP keypad for manual movements and/or teach-in
- Albrea 4 analog input and 4 analog output

The configurable types of remote module on GreenBus /v.4.0) are as follows:

- TRS-AX 4 analog or step-by-step axes
- TRS-EV- 24 electrovalves (D-sub 25 pin connector)  
24
- TRS-16 16 channels which can be configured via software as digital input or output.
- TRS-IO 16 channels which can be configured via software as digital input or output. This can be expanded through TRS-IO-E and TRS-AN-E (max. 5 items) and TRS-AC-E modules.
- TRS-IO-E 16 channels which can be configured as digital input or output; they can only be used as expansion of a TRS-IO module.
- TRS-AN-E 1 analog input and 1 analog output that can be only used as an expansion of a TRS-IO module
- TRS-AC-E 1 counting axes and 2 digital inputs, configurable as zero position reference and fast input. In the table below the maximum number of TRS-AC-E, configurable in a TRS-IO  
Number of TRS-IO-E and TRS- TRS-AC-E number expansion  
AN-E expansions

The types of remote module that can be configured on EtherCAT are as follows:

- TRS-CAT 16 channels that can be configured via software as a digital input or output. This can be expanded through TRS-IO-E and TRS-AN-E and TRS-AC-E modules.
- STAR-CAT transforms a EtherCAT network topology into a star topology by means of an input channel and up to 3 different output channels.

The table below shows the maximum number of expansions, that can be configured in a TRS-CAT.

| Number of TRS-IO-E and TRS-AN-E expansions | TRS-AC-E expansion |
|--|--------------------|
| 7  | 0                  |
| 5  | 1                  |
| 3  | 2                  |
| 1  | 3                  |


### Describing the hardware configuration window

The hardware configuration window opens if you select in the menu **Edit->Hardware**.

To insert a board or a module of remote I/O, press **[New]**. In this way a window appear to select the board or the module of remote I/O and the position where it should be inserted.

In general, no more of 4 boards for each module and no more of 32 modules of remote I/O for each board can be configured. Hence, for each module you can configure up to 128 I/O modules. Regarding the TRS-AX remote modules a more precise clarification should be made; in fact, if the number of the inserted TRS-AX modules rises, the number of TRS-16 and TRS-IO, which can be used, decreases. To calculate the maximum number of TRS-16 and TRS-IO remotes, which can be inserted, you need to apply the following formula: number of other remotes = 32-(number of TRS-AX\*4). For instance, if 3 TRS-AX are connected to a TMSbus, applying the formula we get: number of other remotes=32-(3\*4), then no more than TRS-16 and/or TRS-IO 20 remote modules can be inserted.

The position of the remote in the list should be chosen according to the address set through a switch on the remote module. Please, make reference to the hardware documentation of the single remote.



**Hardware Configuration**

According to the selected board, it could be necessary to set the kind of axes managed. This is invalid for AlbSLM boards, AlbESIm expansions and remote TRS-AX, CN2004 board.

What kinds of axes can be associated to the various hardwares are described as follows:

- AlbNT board                    analog axes and counting axes
- AlbENT expansion            analog axes and counting axes
- AlbSLM board                digital axes, frequency/direction axes (IV axis only, if configured as Frequency/Directon type, counting axes (Aux connectors only)
- AlbESIm expansion         digital axes, frequency/direction axes (IV axis only, if configured as Frequency/Directon type, counting axes (Aux connectors only)
- AlbMech board                digital axes
- DualMech board                digital axes
- DualMech Mono board        digital axes
- TRS-AX axes                 analog axes (if configured as analog type), counting axes (if configured as analog type), step-by-step axes (if configured as Step-by-Step type)
- remote AlbStep                step-by-step axes
- TRS-AC-E expansion         counting axes

In the Mechatrolink II the number of the axes that can be configured changes according to the set value of the control frequency of the axes:

| Board         | Axis frequency control (Hz) | Maximum number of servo drives |
|---------------|-----------------------------|--------------------------------|
| AlbMech       | 1000                        | 8                              |
| AlbMech       | <=500                       | 16                             |
| DualMech Mono | 1000                        | 8                              |
| DualMech Mono | 500                         | 20                             |
| DualMech Mono | 250                         | 30                             |
| DualMech      | 1000                        | 16                             |
| DualMech      | 500                         | 40                             |
| DualMech      | 250                         | 60                             |

The column **Settings and descriptions** shows or assigns some informations concerning the board or the remote module set.

Using **[Move]** you can move a board from a slot to another or a remote module from the bus of a board to the bus of another board. Through this operation any possible connections concerning the remote and available in the Virtual-Physical configuration are maintained. If the board to be moved contains some nodes configured on an external bus, this board cannot be moved. The same command can be selected from the **Edit->Move** command.

A remote module can also be disabled. Disabling has the effect of keeping the connections in the Virtual-Physical configuration whilst the remote module and the devices connected to it are totally disregarded by the system. Therefore, no error is generated if the module is not detected during initialisation and no error is generated when a GPL instruction is executed on a device associated with the module.

Consequently, this feature must be used with a special care. To disable a remote module, use the **[Disable]** button; to enable a remote module again, use the **[Enable]** button. The same command can be selected from the **Edit->Disabled** command.

### How to write CANBUS.DEF. file

Albatros can manage bus devices on CAN field bus through Tpa boards equipped with a CAN Bus connector or through generic boards for CANbus control. Connections between physical and logical devices on CANbus are defined in the CANBUS.DEF file, stored in the configuration folder of the corresponding module(\MODn\CONFIG). The formalism used is in accordance with the standard IEC1131.

Following description must exclusively be used with **TMSbus, TMSbus+ and TMSCan+ and TMSCan** boards. The main elements to define the CAN hardware are as follows:

CANBUS.DEF file is a text format file that describes the connections between logical devices and physical devices on Powerlink. For every module a EPLBUS.DEF file must be written and memorized into the configuration folder of corresponding module. (\MODn\CONFIG). Inside the file the part describing Powerlink hardware should come before the description of the logical-physical connections. The main elements to define the Powerlink hardware are follows:

- **(\*...\*)** beginning and ending of a comment. Comments can be written on more than one text line. You can enter a comment inside another. This is useful when you want to comment a block of definitions whose rows are commented. For example
 

```
.....
CN(3) ID=17 IO RPDO=4 TPDO=8; (*one only RPDO and one only TPDO*)
(*
CN(4) ID=21 IO RPDO=2+2+3 TPDO=8; (*(two RPDO1 of 2 bytes ...*)
CN(5) ID=22 IO RPDO=1+4 TPDO=8+8; (*two RPDOs and two TPDOs *)
*)
```
- **MN (number) attributes** beginning of the description block of a MN (managing node), that is master board of the *CanAddress*. Instead of a number you can use an alphanumeric identifier that will be used later on to identify MN in the description bloc of the logic-physical connections. In this case the attribute **ID** is obligatory. The number in brackets is the index, that will be used for the composition of the Can address. MN is configured by means of the following attributes:
  - ID=index number** of the board in the Albatros hardware configuration (from 1 onwards); if absent, MN(number) is used.
  - TIME=number** of sampling rate in msec. It cannot exceed 60000 (60 seconds)
  - BAUDRATE=number** of CAN communication rate in kilobits per second (can be 1000, 500, 250, 125, 100)
  - TIMEPDO=time** in msec. It shows the time devoted to the synchronous communication of the PDOs. The value set cannot exceed the TIME value (it not an obligatory value).
  - Service name=YES (to enable the service), NO (to disable the service).** It sets the CAN service or protocol, that can be enabled or disabled. Service list:

| Service name   | Description  |
|----------------|--|
| SERVICE-EMCY   | enables or disables the EMCY service   |
| SERVICE-NMT    | enables or disables the NMT service. If there are TMSCan and TMSCan+ boards, this service is always enabled. |
| SERVICE-CTRL   | enables or disables the NoteGuarding and/or HeartBeat protocol check   |
| SERVICE-SYNC   | enables or disables the SYNC service   |
| SERVICE-SDO    | enables or disables the SDO service  |
| SERVICE-PDO    | enables or disables the PDO service  |
| SERVICE-NGUARD | enables or disables the NGUARD service   |
| SERVICE-RCOVER | enables or disables the RCOVER service: this service cannot be used, if there are TMSCan                     |

|               |   |
|---------------|---|
|               | and TMSCan+ boards.   |
| SERVICE-HBEAT | enables or disables the Heartbeat service for the nodes. This service cannot be used, if there are TMSbus and TMSBus+ boards. |

Example: SERVICE-EMCY=YES (enabling the EMCY service). SERVICE-EMCY=NO (disabling the EMCY service).

**TIMEAFTERRESET=time** in msec. It shows the waiting time during the initial phase after a software reset of the nodes in the network. It cannot exceed 60000 (60 seconds).

**LIFETIMEFACTOR=number**. This is the number of CAN cycles without answer to the Node Guarding call before the generation of Disconnected node error. It cannot exceed 100 or be less than 1. (Default value: 3)

- **CN (number) attribute**

beginning of description block of a CN (Controlled Node). The number in brackets is the index, that will be used for the composition of the *CanAddress*. Instead of a number you can use an alphanumeric identifier that will be used later on to identify CN in the description block of the logic-physical connections. In this case the attribute **ID** is obligatory. CN will be considered as a part of the CAN subnet of the previous MN description block. A CN is configured by means of the following attributes:

**IO** indicates that it implements the DS401 (I/O) specification

**SERVO** reserved

**DISABLED**: disables CN. This word can be entered in any part of the definition, after CN() at the beginning and before ';' at the end.

**ID=number** is the CN number (from 1 onward); if this field does not exist, CN(number) is used.

**RDPO=list**: sequence of values (max. 8 for TMSBus and TMSBus+ boards, max. 4 for TMSCan and TMSCan+boards), separated by the character '+'; each value identifies the dimension of a receiving or transmitting PDO (for TPDO) of CN (1÷8).M

With TmsBus and TMSBus+ boards for each PDO the COB-ID can be defined, enclosed within round brackets (Ex.: "RPDO=2+4+4+2+1(101)+4(102)").

With TMSCan and TMSCan+ it is also possible to configure asynchronous PDOs, i.e. PDOs that are not updated at each cycle, but only on specific request. We define an asynchronous PDO by adding ASYNC. Asynchronous PDOs should be sent in the GPL code by means the SENDPDO instructions.

**TPDO= list**: list of sequence of values (max. 8 TMSBus and TMSBus+ boards, max. 3 for TMSCan and TMSCan+ boards), separated by the character '+'; each value identifies the dimension of a receiving or transmitting PDO (for TPDO) of CN (1÷8). With TMSBus and TMSBus+ boards it is possible for each PDO to define the COB-ID, enclosed within round brackets (Ex.: "RPDO=2+4+4+2+1(101)+4(102)").

With TMSCan and TMSCan+ it is possible to configure asynchronous PDOs, i.e. PDOs that are not updated at each cycle. We define an asynchronous PDO by adding ASYNC. Asynchronous PDOs should be received in the GPL code by means the RECEIVEPDO instructions.

**AUTOOP**: this device allows the automatic passage to the Operational status after a reconnection (optional).

- ; ending a MN or CN description block

Following description, concerning the logical-physical connections, must be used for all the boards on CANBus

- **(\*...\*)** beginning and ending of a comment. Comments can be written on more than one text line. You can enter a comment inside another. This is useful when you want to comment a block of definitions whose rows are commented.
- **VAR** beginning of block of connections description
- **DeviceName** complete logical device name. It can be written with the form "Group.Subgroup.Device" or "Group.Device"
- **AS** keyword that separates **DeviceName** from **CanAddress**
- **CanAddress** physical address on CANBus. The formalism for the description is:  
(for Tpa boards with CAN control)
  - %** is the first obligatory character.
  - I** or **Q** is the second character. **I** indicates an input device, **Q** indicates an output device
  - X** or **B** is the third character. **X** indicates that the following value must interpreted as bit, **B** indicates that the following value must be interpreted as byte. If omitted, the next value is interpreted as bit. Next characters are a sequence of numbers indicating the address. If in the system is configurated more than one Can board then it's possible to distinguish the board number by putting before the address the

- **CanAddress** (for TMSbus boards)
    - number of the board followed by a point. The address can be expressed in base 2, 8, or 16 according to the formalism IEC.
    - shows the address at the beginning, how many bits in dualport and of which board are available. The formalism for the description is:
      - %** is the first obligatory character.
      - I** or **Q** is the second character, **I** showing an input device, **Q** shows an output device
      - X** or **B** is the third character. **X** shows that the next number must be interpreted as a bit, **B** shows that the next number must be interpreted as a byte. If omitted, the next value is interpreted as a bit.
      - The next characters are a sequence of numbers indicating the address. They are separated by a dot. The first number refers to the master board (TMSBus) of the bus, the second one to the node, the third optional one is an offset within the node (this number is a progressive one depending on the Albatros device type. This offset can also be expressed in base 2, 8 or 16 according to the IEC formalism.
      - If the offset is not available, we consider 0.
  - ; completes the description of a connection
  - **END\_VAR** ending of block of connections description
- Whatever is found after the keyword END\_VAR of block end is ignored.  
 Whatever is out of the blocks is ignored.  
 The correctness of file whether from the point of view of the syntax, or from the point of view of the contents is verified during Albatros starting. In case of errors notice, is visualized an error message. The description of all errors is in file ERRCAN.TXT memorized into the folder defined in Tpa.ini at option DirReport.

**Example of definition of CAN Hardware on Tpa board:**

```

MN(1)          TIME=10 BAUDRATE=1000;
CN(3)          ID=17 IO RPDO=4 TPDO=8;    (* one only RPDO and one only TPDO *)
CN(4)          ID=21 IO RPDO=2+2+3      (* two RPDO1 with 2 bytes and a RPDO3 with 3
          TPDO=8;                          bytes *)
CN(5)          ID=22 IO RPDO=1+4 TPDO=8 (* two RPDO and two TPDO *)
          +8;

```

VAR

```

Main.EV1       AS %QX1.30.10;
Main.EV2       AS %Q1.3.11;
Main.Assi.InpPort AS %B1.5.12;
Emerg.InputW   AS %IX2.5.13;          (*board 2 *)

```

END\_VAR

**Example of definition of CAN Hardware on generic boards:**

VAR

```

Main.EV1       AS %QX10;                (* output device 10 board 1*)
Main.EV2       AS %Q11;                 (* output device bit 11 board 1*)
Main.Assi.InpPort AS %B12;              (* input device byte 12 board 1*)
Emerg.InputW   AS %IX2.13;              (* input device bit 13 board 2*)

```

END\_VAR

**How to write CANBUS.DEF file for S-CAN devices per dispositivi S-CAN**

The description of the S-CAN hardware configuration is defined in the CANBUS.DEF text file, stored in the configuration folder of the corresponding module. (\MODn\CONFIG). The formalism used is in accordance with the standard IEC1131.

Following description must be exclusively used with **TMSbus**, **TMSbus+** boards. The main elements to define the S-CAN hardware are as follows:

- **(\*...\*)** Beginning and end of a comment. Comments can be written on more than one text line.  
 You can enter a comment inside another. This is useful when you want to comment a block of definitions whose rows are commented. For example  
 .....  
 CN(3) SERVO RPDO=8 TPDO=8; (\*servo\*)



- (\*
- CN(4) SERVO RPDO=8 TPDO=8; (\*servo ...\*)
- CN(5) SERVO RPDO=8 TPDO=8; (\*servo...\*)
- \*)
- **MN(number) attributes**

beginning of the description block of a MN (managing node), that is master board of the S-CAN communication. The number in brackets is the index that will be used for the composition of *CanAddress*. Instead of a number you can use an alphanumeric identifier that will be used later on to identify MN in the description bloc of the logic-physical connections. In this case the attribute **ID** is obligatory. A MN is configured by means of the following attributes:

**S-CAN** shows the type of CAN protocol. It is obligatory.

**ID=index number** of the board in Albatros hardware configuration (from 1 onwards); if not present, MN(*number*) is used

**TIME=number** sampling time in msec (accepted values 2,4 and 6 only).

**BAUDRATE=number** CAN communication speed in kilobits/second (it can be 1000, 500, 250, 125, 100)

**TIMEAFTERRESET=time** in msec. It shows the waiting time during the initial phase after a software reset of the nodes in the network. It cannot exceed 60000 (60 seconds).

**LIFETIMEFACTOR=number**. This is the number of CAN cycles without answer to the Node Guarding call before the generation of Disconnected node error. It cannot exceed 100 or be less than 1. (Default value: 3)
  - **CN(number) attributes**

beginning of description block of a CN (Controlled Node). The number in brackets is the index that will be used for the composition of *CanAddress*. Instead of a number you can use an alphanumeric identifier that will be used later on to identify CN in the description block of the logic-physical connections. In this case the attribute **ID** is obligatory. CN will be considered as a part of the S-CAN subnet of the previous MN description block. A CN is configured by means of the following attributes:

**SERVO** shows that it is a servo drive. It is obligatory.

**DISABLED**: disables CN. This word can be entered in any part of the definition, after CN() at the beginning and before ';' at the end.

**ID=number** is the CN number (from 1 onward); if there is not this field, CN(*number*) is used

**RDPO= sequence list** of values (max. 8) separated by the '+' character, each one identifying the dimension of a CN reception PDO (1÷8). ). For each PDO the COB-ID can be defined, enclosed within round brackets (Ex.: "RPDO=2+4+4+2+1(101)+4(102)").

**TPDO=sequence list** of values (max. 8) separated by the '+' character, each one identifying the dimension of a CN reception PDO (1÷8). ). For each PDO the COB-ID can be defined, enclosed within round brackets.
  - ;

ending a MN or CN description block

Following description defines the logical-physical connections

- **(\*...\*)**

Beginning and end of a comment. Comments can be written on more than one text line. You can enter a comment inside another. This is useful when you want to comment a block of definitions whose rows are commented.
- **VAR**

beginning of block of connections description
- **DeviceName**

complete name of the logical device. It can be written under the "Group.Subgroup.Device" or "Group.Device" form.
- **AS**

Keyword separating **DeviceName** from **CanAddress**
- **CanAddress**

shows the address at the beginning, how many bits in dualport and of which board are available. The formalism for the description is:

**%** is the first character, it is obligatory.

**I** or **Q** is the second character. **I** shows an input device, **Q** shows an output device

**X** or **B** or **L** is the third character. **X** shows that the following value has to be interpreted as bit (digital inputs and outputs), **B** shows that the next value has to be interpreted as byte, **L** shows that the next value has to be interpreted as 8 bytes (axes). If omitted, the next value is interpreted as bit.

The following characters are a set of figures, separated by a point '.', identifying the address The first number refers to the MN (TMSbus) of the bus, the second one to the CN, the third one, optional, is an "offset" inside the CN (such a number is a progressive one linked to the Albatros device typology); the offset can also be expressed with base 2, 8, or 16 according to the IEC formalism.

If the offset is not available, we consider 0. In the S-CAN drive the offset can be used to send some commands to the drive by means of analog outputs. The following table provides the commands that can be sent and the offset address. The first three are digital outputs and the last one is a output port.

| Command | Offset | Example |
|---------|--------|---------|
|---------|--------|---------|

|                      |   |                          |
|----------------------|---|--------------------------|
| Servo on             | 0 | Ax.ServoOnX AS %QX1.1.0; |
| Enabling movement    | 1 | Ax.EnableX AS %QX1.1.1;  |
| Stop in the ramp     | 2 | Ax.StopX AS %QX1.1.2;    |
| Reset alarms         | 3 | Ax.ResAlmX AS %QX1.1.3;  |
| Sending couple value | 8 | Ax.TorqueX AS %QB1.1.8;  |

- ; completes the description of a connection
- **END\_VAR** end of the description block of the connections

Whatever is found after the keyword END\_VAR of block end is ignored.

At Albatros startup the program checks if the file is correct from both the points of view of the syntax and of the content. If errors are detected, an error message is displayed. Each error description is provided in the file ERRCAN.TXT stored into the folder defined in Tpa.ini under DirReport.

#### **Example of definition of S-CAN Hardware on TMSbus board:**

```
MN(1)          S-CAN TIME=2 BAUDRATE=1000;
CN(1)          SERVO RPDO=8 TPDO=8;
CN(2)          SERVO RPDO=8 TPDO=8;
```

```
VAR
  Ax.X          AS %IL1.1
  Ax.Y          AS %IL1.2
END_VAR
```

### **Characteristics of the EtherCat Management in Albatros**

The communication mode is always DC-Synchronous. The first node of the network provides the clock, so it is essential to make sure that that node provides a precise and stable clock, as it is provided for example by TRS-CAT. It is not possible to use other modes, such as, for example, Free-Run. Managed protocols are: CoE (CAN application protocol over EtherCAT) and EoE (Ethernet over EtherCAT). Inside CoE, the device profiles DS401 and DS402 are managed by the default operating mode of the axis control *cyclic synchronous speed mode*.

The maximum number of EtherCat nodes is 200.

### **Foreword**

To each physical EtherCAT device an ESI file (EtherCAT Slave Information) is associated, describing the characteristics and the functionalities of the device. This file is in XML format. For each device one only ESI file must exist. Generally, the ESI files can be downloaded from the manufacturer's Internet site. Albatros searches for these files in the folder defined in Tpa.ini in the section [tpa] under DirESIFiles. Default option is the subfolder ETHERCAT of SYSTEM. "\EtherCAT" di SYSTEM.

From the ESI Albatros files it obtains the information on the device, by analysing all the elements "/ Devices/Device/Type". Each device is identified by a Vendor ID, a Product ID and by a Revision Number. If more than a device with the same name is available, the same Vendor ID and the same Product ID, that with the greatest Revision Number is considered.

Always from the ESI files the information on the expansions (also called modules) of the devices are obtained. Albatros finds the information on the types of expansions by searching in the ESI file of the device the elements "Modules/Module".

### **ECATBUS.DEF file**

ECATBUS.DEF file is a text format file that describes the hardware configuration and the connections between logical devices and physical devices on EtherCAT. In each module using this bus a ECATBUS.DEF file must be written and stored in the configuration folder of the corresponding module (\MOD.n\CONFIG).

The file is divided into two sections, the first is the one that describes the hardware EtherCAT, and is equivalent to the Hardware Configuration of Albatros. In this section the physical devices are listed, that is the nodes of the EtherCAT network and their settings. The second section corresponds to the Virtual-Physical Configuration; in this section the couplings between logical devices and single inputs and physical outputs of the different EtherCAT nodes are listed. This section of the files is enclosed between

VAR and END\_VAR key words.

Each single definition available in the file in the hardware configuration section or in that of the Virtual-Physical can be described on more rows and must be finished by the `;` character. To enter some comments (or bypass part of virtual-physical and hardware configuration) you enter the characters `(\*` at the beginning of the comment text and the `\*)` characters at the end. The comments can be on multiple lines of text. You can also enter a comment inside another one. This is useful when you want to comment a block of definitions whose rows are commented.

Example:

```
(* Beginning of the EtherCAT configuration of the module *)
(*
  Here you must enter the definitions concerning EtherCAT hardware
*)
VAR
(*
  Here you must enter the virtual-physical associations among Albatros and I/O EtherCAT logical
  devices.
  (* This is a comment inside another comment*)
*)
END_VAR
```

### EtherCAT Hardware configuration

The hardware is configured by describing the master boards and, for each board, the list of physical devices connected to that card on the bus. The physical devices are also called "nodes" of the field bus. For EtherCAT the master board is not a specific board of bus control, but a network connection of the module is used. As for the local modules the network connection must be one of those managed by RTX, while for the remote modules a specific network connection of the module is used among those managed by Windows CE 6.0. For each local or remote module, you can configure one master only.

The master board is identified in the ECATBUS.DEF master file as MN, i.e. Managing Node, while each hardware device or node, is identified as CN, i.e. Controlled Node.

The syntax to describe the master (MN) is the following (please, note that the definition is finished by the `;` character):

```
MN(index)          (* index is the number to use for the virtual-physical* connections)
  ID=address        (* board number, from 1 on; optional *)
  NAME=interface_name (* name of the network interface*)
;
```

Where:

|                |   |
|----------------|---|
| index          | can be a number, from 1 onwards or an alphanumeric identifier. It will be used in the virtual-physical section (i.e. between VAR and END_VAR) to show the master board in the EtherCAT network of which the node to be associated to the logical device is placed. If you use an alphanumeric identifier, in the definition of MN() you must also specify the ID=address. |
| address        | Board number associated to the EtherCAT bus managed by this MN(). It must be a number from 1 onwards, if the index field is not used. If the index is an alphanumeric identifier, then the address must be defined in an explicit way.  |
| interface_name | this is the name of the interface acting as EtherCAT master. For the local modules the default value is "rtn0", that is the name of the section describing the network interface inside the ini file of RTX di IntervalZero. The default name of CN2008 remote module is "RTCENIC1", the default name of CN2128 remote module is "E1Q51CE61".                             |

Example: **MN(1)** . Full example in the paragraph "**Example of EtherCAT hardware configuration**".

The syntax to describe the node (CN) is the following (also in this case the definition is finished by this

character `;`):

```
CN(index)          (* index is the number to use for the virtual-physical*)
ID=address         (* address of the node, from 1 on *)
TYPE=device_name  (* name of hardware device *)
RxPDO=pdo_sequen (* description of a PDO that the node receive; optional *)
ce
TxPDO=pdo_sequenc(* description of a PDO that the node sends; optional *)
e
OPMODE=axis_mode (* servo nodes, operating mode of axis control; optional *)
DISABLED          (* disables the node; optional *)
IO               (* considers the node as of I/O even if it is a servo; optional *)
;
```

Where:

**index** can be a number, from 1 onwards or an alphanumeric identifier. It will be used in the virtual-physical section (i.e. between VAR and END\_VAR) to show the node to be associated with the logical device. If you use an alphanumeric identifier, in the definition of CN() you must specify also the ID=address.

Examples:

```
CN(100) ID=+ TYPE=TRS-CAT:AN-E:IO-E;
CN(200) ID=+ TYPE=STAR-CAT;
CN(101) ID=+ TYPE=TRS-CAT;
CN(LTi_1) ID=+ TYPE=3-Axis-module;
```

Full example in the paragraph "**Example of EtherCAT hardware configuration**".

**address** Node number of the EtherCAT bus. It must be a number from 1 onwards and if it is not indicated, the index field is used. If the index is an alphanumeric identifier, then the address must be defined in an explicit way.

**device\_name** Name of the device that is searched in the file ESI. This name can be indicated in several ways. It is worth using (1) the name that is in the tag Device\Type (even only a part of the name), but (2) it is accepted also that in the tag \Device\Name, or (3) you can write Product ID and the Vendor ID separated by a point (`. `). Examples:

Examples:

```
TYPE=3-Axis-module
TYPE=i700 (Double
```

Full example in the paragraph "**Example of EtherCAT hardware configuration**".

The devices can also have some expansions (called also modules) are they also must be indicated, by making the name of the device follow the list of the expansions, separated by the ':' character. ':' the mandatory modules ("mandatory") are automatically added and must not be indicated. if the device or the expansion name contain some space characters ( ` ` ), these can be replaced by underscores ( `\_ `).

It is not necessary to write all the components of the device and the expansion name, but it is sufficient to write those necessary for the univocal identification of the device and the expansion among all the ESI files.

Example:

```
TYPE=i700 (Double
```

. Full example in the paragraph "**Example of EtherCAT hardware configuration**".

**pdo\_sequence** A PDO (Process Data Object) is a communication object defined by the communication parameter and by the mapped PDO objects (max.8). PDOs are transmitted in the form "without confirmation". (see paragraph Description of a PDO).

**axis\_mode** defines the operating mode to be used for the nodes of drive type, i.e. for the nodes adhering to DS402 (object 6060<sub>16</sub>). The mode is one of the following:

|               |                             |
|---------------|-----------------------------|
| HOMING        | Homing                      |
| VELOCITY      | Velocity                    |
| PROF-POSITION | Profile position            |
| PROF-VELOCITY | Profile velocity            |
| PROF-TORQUE   | Profile torque              |
| INTERPOLATED  | Interpolated position       |
| SYNC-POSITION | Cyclic synchronous position |
| SYNC-VELOCITY | Cyclic synchronous velocity |
| SYNC-TORQUE   | Cyclic synchronous torque   |

If it is not set, SYNC-VELOCITY will be used. At the moment, this is the only mode supported in a native way by the numeric control.

It is possible to add some attributes to the node definition:

**DISABLED** This attribute indicates that the node is not present on the bus. Its configuration is examined, but it is not sent to the numeric control by Albatros. The same result could be obtained by commenting the whole definition of CN(), but some errors could be reported by analysing the EtherCAT virtual-physical configuration. The use of this attribute makes possible for the the logical devices associated with the node to be considered as not connected. Additionally, in the Albatros hardware configuration window this node is available and marked as disabled.

Example:

**CN(44) ID=+ TYPE=SGDV-E1 DISABLED**

Full example in the paragraph "**Example of EtherCAT hardware configuration**".

**IO** It is sometimes useful to force the numeric control to consider a particular node of axes as if it were an I/O node. This attribute applies to nodes only that support DS402 (servodrives).

In the configuration file, the definition of the several CN () must follow the definition of the MN(), like in a tree structure, in which each leaf is fastened to a branch.

## Description of a PDO

You can define up to eight PDOs sent by the node (TxPDO) and up to eight PDOs received by the node (RxPDO). Each RxPDO describes one only PDO that the node receives from the master, therefore digital and analog outputs for I/O nodes or target velocity and controlword for axis nodes. Each TxPDO describes one only PDO that the node sends to the master, therefore digital and analog inputs for I/O nodes or current position and statusword for axis nodes.

For the list and the description of the PDOs and of the objects that can be mapped on a PDO please, make reference to the documentation of the specific EtherCAT device and to its ESI file.

In the description of PDOs you can use the formalism IEC1131-3 to indicate the numbers, i.e. the sequence of figures representing the number with base 10. However, if it starts by "16#" so the number is considered to be base 16 and also the characters from A to F (case-insensitive) are considered. If it starts by "8#", it is considered to be base 8 and the allowed characters range from 0 to 7. If it starts by "2#", it is considered to be base 2, therefore only the figures 0 and 1 are allowed. In the figures you can enter the underscore '\_' character to improve the readability.

Example:

**TYPE=i700\_ (Double**

Full example in the paragraph "**Example of EtherCAT hardware configuration**".

There are three modes to describe the PDOs in a CN:

1. Do not set any PDO.  
 In this way the numeric control uses PDO configured by default in the device. This is the easiest mode and fits the majority of the CNs.  
 Example:  
`CN(100) ID=+ TYPE=TRS-CAT:AN-E:IO-E;` Full example in the paragraph **"Example of hardware EtherCAT configuration"**.
  
2. Set only the PDOs without providing any list of the objects.  
 To be used when a CN has several alternatives and not programmable PDOs. To use it, write TxPDO or RxPDO to set the direction of the data, followed by the '=' character and then by the number of the communication object (PDO number), without spaces in the middle.  
 Example:  
`CN(EL3102_1) ID=+ TYPE=EL3102 TxPDO=16#1A10;` Full example in the paragraph **"Example of hardware EtherCAT configuration"**.
  
3. Describe the PDO in a complete way, setting the communication object and the list of the objects to map.  
 This mode is the one that provides the best control over the information sent and received by the CN. To use this mode, describe the PDO like for the previous mode, then add the ':' character and the list of the object to map, joined together by the '+' character.  
 Example  
`RXPDO=16#1600:16#6040+16#60FF+16#6060`  
`RXPDO=16#1610:16#6840+16#68FF+16#6860`  
`RXPDO=16#1620:16#7040+16#70FF+16#7060`  
 Full example in the paragraph **"Example of EtherCAT hardware configuration"**.

Each object is described by its index in the object dictionary of CN, optionally followed by a sub-index. If the sub-index is not available, it is considered as 0.

Example:  
`TXPDO=16#1A00:16#6041+16#6064+16#6061+16#2918.1+16#6077+16#606C`  
`TXPDO=16#1A10:16#6841+16#6864+16#6861+16#3118.1+16#6877+16#686C`  
`TXPDO=16#1A20:16#7041+16#7064+16#7061+16#3918.1+16#7077+16#706C;`  
 Full example in the paragraph **"Example of EtherCAT hardware configuration"**.

The dictionary object (object dictionary) is the core of every device. It enables the access to all the types of the device data, to the communication parameters, to the configuration and data processing parameters.

Attention: not all the object of the object dictionary can be mapped in a PDO.

Examples of description of objects in the configuration file:

- 16#7060 (\* index with base 10: 28768; sub-index: 0 \*)
- 16#2918.1 (\* index with base 10: 10520; sub-index: 1 \*)

As for the CNs of servodrives there is a PDO for each drive, so that the nth TxPDO and the nth RxPDO of the CN make reference to the nth drive of the CN. The first two objects of each RxPDO and TxPDO have a preassigned significance and dimension, i.e.:

| Drive    | RxPDO                              |  | TxPDO                             |  |
|----------|------------------------------------|--|-----------------------------------|--|
|          | 1° object<br>16 bit<br>Controlword | 2° object<br>32 bit<br>Target velocity | 1° object<br>16 bit<br>Statusword | 2° object<br>32 bit<br>Actual position |
| 1° drive | 16#6040                            | 16#60FF                                | 16#6041                           | 16#6064                                |
| 2° drive | 16#6840                            | 16#68FF                                | 16#6841                           | 16#6864                                |

|           |   |
|-----------|---|
| nth drive | Add 16#800 to each object of the preceding drive. |
|-----------|---|

When you need to describe a PDO completely, you can use some automatic features that will simplify the description:

- If the PDO number is missing the first programmable PDO among those listed in the ESI file of the device is used;  
Example:  
RXPDO=:+16#6060  
TXPDO=:+16#6077;
- in the case of servodrives you can replace the list of Controlword e Target velocity with the character '+'; idem for Statusword and Actual position.  
Example:  
RXPDO=:+16#6060  
TXPDO=:+16#6077;

Full example in the paragraph "**Example of EtherCAT hardware configuration**".

Reading or writing objects can be added for a specific drive by adding the index (and any subindex) of each object in the PDO of the drive.

Example:

RXPDO=:+16#6060

Full example in the paragraph "**Example of EtherCAT hardware configuration**".

Then, these values can be read by GPL through the GETAXIS instruction (see the related chapter). It also possible to trace the additional objects both from the calibration window and from the oscilloscope.

More generally, it is possible to access specific objects in reading and writing within PDO through the GETPDO and SETPDO instructions (see the related chapters)

Each object inserted in a PDO must be described also in the ESI file of the Ethercat device. If that is not the case, when Albatros reads the ECATBUS.DEF file reports as warning the use of an unknown object and presets the length of 32-bit object.

## Example of EtherCAT hardware configuration

MN(1) NAME=RTND0;

CN(100) ID=+ TYPE=TRS-CAT:AN-E:IO-E;

CN(200) ID=+ TYPE=STAR-CAT;

CN(101) ID=+ TYPE=TRS-CAT;

CN(LTi\_1) ID=+ TYPE=3-Axis-module;

CN(LTi\_3) ID=+ TYPE=3-Axis-module

RXPDO=16#1600:16#6040+16#60FF+16#6060

RXPDO=16#1610:16#6840+16#68FF+16#6860

RXPDO=16#1620:16#7040+16#70FF+16#7060

TXPDO=16#1A00:16#6041+16#6064+16#6061+16#2918.1+16#6077+16#606C

TXPDO=16#1A10:16#6841+16#6864+16#6861+16#3118.1+16#6877+16#686C

TXPDO=16#1A20:16#7041+16#7064+16#7061+16#3918.1+16#7077+16#706C;

CN(LTi\_4) ID=+ TYPE=1-Axis-module

RXPDO=:+

TXPDO=:+16#6077;

CN(10) ID=+ TYPE=i700\_(Double

RXPDO=16#1605:16#6040+16#60FF+16#6060

TXPDO=16#1A05:16#6041+16#6064+16#6061+16#6077+16#606C;

CN(11) ID=+ TYPE=i700\_(Double

RXPDO=:+16#6060

RXPDO=:+16#6860

TXPDO=:+16#6061+16#6077+16#606C

TXPDO=:+16#6861+16#6877+16#686C ;

```

CN(20) ID=+ TYPE=I/O-System:EPM-S202:EPM-S302;
CN(102) ID=+ TYPE=TRS-CAT:AN-E:IO-E;
CN(EK1100) ID=+ TYPE=EK1100;
CN(EL3102_1) ID=+ TYPE=EL3102 TXPDO=16#1A10;
CN(EL3102_2) ID=+ TYPE=EL3102 TXPDO=16#1A10;
CN(EL4031) ID=+ TYPE=EL4031;
CN(EK1100) ID=+ TYPE=EK1100;
CN(40) ID=+ TYPE=EL2809;
CN(41) ID=+ TYPE=EL1809;
CN(42) ID=+ TYPE=EK1122;
CN(43) ID=+ TYPE=L7NH
(* RXPDO=16#1600:16#6040+16#60FF+16#6060
RXPDO=16#1601:16#6040+16#60FF+16#6060
RXPDO=16#1602:16#6040+16#60FF+16#6060
RXPDO=16#1603:16#6040+16#60FF+16#6060 *)
(* TXPDO=16#1A00:16#6041+16#6064+16#6061+16#6077+16#606C
TXPDO=16#1A01:16#6041+16#6064+16#6061+16#6077+16#606C
TXPDO=16#1A02:16#6041+16#6064+16#6061+16#6077+16#606C
TXPDO=16#1A03:16#6041+16#6064+16#6061+16#6077+16#606C *);

CN(44) ID=+ TYPE=SGDV-E1 DISABLED
(* RXPDO=16#1600:16#6040+16#60FF+16#6060
RXPDO=16#1601:16#6040+16#60FF+16#6060
RXPDO=16#1602:16#6040+16#60FF+16#6060
RXPDO=16#1603:16#6040+16#60FF+16#6060 *)
(* TXPDO=16#1A00:16#6041+16#6064+16#6061+16#6077+16#606C
TXPDO=16#1A01:16#6041+16#6064+16#6061+16#6077+16#606C
TXPDO=16#1A02:16#6041+16#6064+16#6061+16#6077+16#606C
TXPDO=16#1A03:16#6041+16#6064+16#6061+16#6077+16#606C *);

VAR
(* There are no virtual-physical links*)
END_VAR

```

### Configuration of the virtual-physical EtherCAT links

The formalism used is in accordance with the standard IEC1131-3. All links between logical devices and EtherCAT addresses must be indicated within the block defined by VAR and END\_VAR. With EtherCAT address we are referring to the start position of a sequence of bits inside one of the PDOs of a CN. The length of a PDO is given by the addition of the lengths of the objects that the PDO transfers. The first PDO of a CN has offset 0, while the offset of the next ones corresponds to the addition of the length of the preceding PDOs.

The syntax for the description of a virtual-physical link is as follows (here also the link is finished by the ';' character):

```
device_name AS EtherCAT_address;
```

Where:

|                  |  |
|------------------|--|
| device_name      | Complete name of the logic device. It can be written under the "Group.Subgroup.Device" or "Group.Device" form.   |
| EtherCAT_address | Sequence of characters that identifies precisely an address within an EtherCAT node. The sequence is made in this way: <ul style="list-style-type: none"> <li>'%' first character, obligatory.</li> <li>'I' or 'Q' 'I' identifies the address as the address of an input (i.e., transmitted by the CN), 'Q' identifies it as of the address of an output (i.e., received by the CN)</li> <li>'X', 'B', 'W', 'L' number of bits associated to the data, received or sent: <ul style="list-style-type: none"> <li>'X' = 1 bit, per for the digital inputs and the outputs</li> <li>'B' = 8 bits, for input and output ports</li> <li>'W' = 16 bits, for analog inputs and outputs</li> </ul> </li> </ul> |



'L' = special character to connect logical axes  
If it is missing, you must consider X, i.e 1 bit.

|          |   |
|----------|---|
| MN_index | Number, from 1 on, or alphanumeric identifier showing the EtherCAT bus to which the node is connected   |
| '\'      | Separation character between MN_index and CN_index  |
| CN_index | Number, from 1 on, or alphanumeric identifier showing the node  |
| '\'      | Separation character between CN_index and offset  |
| offset   | Offset with respect to the beginning of the first PDO of the node. It ranges from 0 on and the unit of measure depends on the number of the bits associated to the data, therefore in an EtherCAT address like %QB1.1.3 the byte given begins at the bit 24 of the PDO. |

Like in the case of the description of the PDOs, also for the offset it is possible to use the formalism IEC1131-3 to set the numbers.

Example:

```
SERVERIP.Limit1 AS %IX1.100.16;
SERVERIP.Limit2 AS %IX1.100.17;
```

Full example in the paragraph **"Example virtual-physical links"** .

As for the servo drive nodes, the axes are considered as input and output devices and the offset of each axis is the index of the drive inside the node. Statusword and controlword can be connected to logic devices of digital input and output with displacement 16 from an axis to the next one. The significance of each bit of the controlword is set in the AXCONTRI instruction . For the statusword, the significance of each bit is described in the AXSTATUS instruction. We remind you that the offset of the first bit is 0 and not 1.

Example:

```
LTi.X.Ax AS %IL1.LTi_1.0;
LTi.X.STOP AS %QX1.LTi_1.2;
LTi.X.SVON AS %QX1.LTi_1.3;
LTi.X.RESET AS %QX1.LTi_1.7;
LTi.X.ALM AS %IX1.LTi_1.3;
LTi.X.WARN AS %IX1.LTi_1.7;
```

```
LTi.B.Ax AS %IL1.LTi_1.1;
LTi.B.STOP AS %QX1.LTi_1.18;
LTi.B.SVON AS %QX1.LTi_1.19;
LTi.B.RESET AS %QX1.LTi_1.23;
LTi.B.ALM AS %IX1.LTi_1.19;
LTi.B.WARN AS %IX1.LTi_1.23;
```

Full example in the paragraph **"Example virtual-physical links"** .

## Virtual-physical links in the TRS-CAT

The I/O TRS-CAT device is the equivalent EtherCAT device of the TRS-IO onGreenbus. To this device, that shows digital 16 I/O, you can add IO-E (16 digital I/O), AN-E (an analog input and an analog output), AC-E (encoder reading) expansions, that physically are the same used for the remote Greenbus TRS-IO.

In the basic module, TRS-CAT, the available outputs are 16 starting from the address 0. For the inputs, the first 16 bits have a diagnostic significance and after them 16 available inputs follow. The initial address of the available bits in an expansion is the addition of the bit of the preceding expansions and of the basic module.

## Map of the inputs

| Element  | Description of the bits set   | Space  |  |             |  |               |  |                                       |  |             |   |        |               |    |        |               |    |        |              |    |        |            |    |         |  |         |
|--|---|--|--|-------------|--|---------------|--|---------------------------------------|--|-------------|---|--------|---------------|----|--------|---------------|----|--------|--------------|----|--------|------------|----|---------|--|---------|
| base   | <table border="1"> <thead> <tr> <th>Offset</th> <th>Length</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>8 bits</td> <td>State of each expansion; it can be connected to a port of digital inputs</td> </tr> <tr> <td>8</td> <td>1 bits</td> <td>State BUS</td> </tr> <tr> <td>9</td> <td>1 bits</td> <td>State VOLTAGE</td> </tr> <tr> <td>10</td> <td>1 bits</td> <td>State CURRENT</td> </tr> <tr> <td>11</td> <td>1 bits</td> <td>State NEWMSG</td> </tr> <tr> <td>12</td> <td>4 bits</td> <td>(reserved)</td> </tr> <tr> <td>16</td> <td>16 bits</td> <td>Max 16 inputs, if the outputs are not used. The corresponding bits used as outputs cannot be used as inputs.</td> </tr> </tbody> </table> | Offset   | Length   | Description | 0                                      | 8 bits        | State of each expansion; it can be connected to a port of digital inputs | 8                                     | 1 bits   | State BUS   | 9 | 1 bits | State VOLTAGE | 10 | 1 bits | State CURRENT | 11 | 1 bits | State NEWMSG | 12 | 4 bits | (reserved) | 16 | 16 bits | Max 16 inputs, if the outputs are not used. The corresponding bits used as outputs cannot be used as inputs. | 32 bits |
|  | Offset  | Length   | Description  |             |  |               |  |                                       |  |             |   |        |               |    |        |               |    |        |              |    |        |            |    |         |  |         |
|  | 0   | 8 bits   | State of each expansion; it can be connected to a port of digital inputs |             |  |               |  |                                       |  |             |   |        |               |    |        |               |    |        |              |    |        |            |    |         |  |         |
|  | 8   | 1 bits   | State BUS  |             |  |               |  |                                       |  |             |   |        |               |    |        |               |    |        |              |    |        |            |    |         |  |         |
|  | 9   | 1 bits   | State VOLTAGE  |             |  |               |  |                                       |  |             |   |        |               |    |        |               |    |        |              |    |        |            |    |         |  |         |
|  | 10  | 1 bits   | State CURRENT  |             |  |               |  |                                       |  |             |   |        |               |    |        |               |    |        |              |    |        |            |    |         |  |         |
|  | 11  | 1 bits   | State NEWMSG   |             |  |               |  |                                       |  |             |   |        |               |    |        |               |    |        |              |    |        |            |    |         |  |         |
| 12   | 4 bits  | (reserved)   |  |             |  |               |  |                                       |  |             |   |        |               |    |        |               |    |        |              |    |        |            |    |         |  |         |
| 16   | 16 bits   | Max 16 inputs, if the outputs are not used. The corresponding bits used as outputs cannot be used as inputs. |  |             |  |               |  |                                       |  |             |   |        |               |    |        |               |    |        |              |    |        |            |    |         |  |         |
| IO-E   | Max 16 inputs, if the outputs are not used. The corresponding bits used as outputs cannot be used as inputs.  | 16 bits  |  |             |  |               |  |                                       |  |             |   |        |               |    |        |               |    |        |              |    |        |            |    |         |  |         |
| AN-E   | An analog input   | 16 bits  |  |             |  |               |  |                                       |  |             |   |        |               |    |        |               |    |        |              |    |        |            |    |         |  |         |
| AC-E   | An input encoder, that can be connected to a logic device of counting axis.   | 32 bits  |  |             |  |               |  |                                       |  |             |   |        |               |    |        |               |    |        |              |    |        |            |    |         |  |         |
|  | <table border="1"> <thead> <tr> <th>Offset</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>Number of the expansion from 1 onwards</td> <td>Input encoder</td> </tr> <tr> <td>16 + Space in bits of all the preceding inputs</td> <td>Phase C, i.e. zero position reference</td> </tr> <tr> <td>17 + Space in bits of all the preceding inputs</td> <td>Quick input</td> </tr> </tbody> </table>   |  | Offset   | Description | Number of the expansion from 1 onwards | Input encoder | 16 + Space in bits of all the preceding inputs                           | Phase C, i.e. zero position reference | 17 + Space in bits of all the preceding inputs | Quick input |   |        |               |    |        |               |    |        |              |    |        |            |    |         |  |         |
|  | Offset  |  | Description  |             |  |               |  |                                       |  |             |   |        |               |    |        |               |    |        |              |    |        |            |    |         |  |         |
|  | Number of the expansion from 1 onwards  |  | Input encoder  |             |  |               |  |                                       |  |             |   |        |               |    |        |               |    |        |              |    |        |            |    |         |  |         |
| 16 + Space in bits of all the preceding inputs | Phase C, i.e. zero position reference   |  |  |             |  |               |  |                                       |  |             |   |        |               |    |        |               |    |        |              |    |        |            |    |         |  |         |
| 17 + Space in bits of all the preceding inputs | Quick input   |  |  |             |  |               |  |                                       |  |             |   |        |               |    |        |               |    |        |              |    |        |            |    |         |  |         |

## Map of the outputs

| Element | Description of the bits set   | Space   |
|---------|---|---------|
| base    | Max 16 inputs, if the inputs are not used. The corresponding bits used as inputs cannot be used as outputs. | 16 bits |
| IO-E    | Max 16 inputs, if the inputs are not used. The corresponding bits used as inputs cannot be used as outputs. | 16 bits |
| AN-E    | An analog output  | 16 bits |
| AC-E    | Cannot be used  | 32 bits |

Example:

```
SERVERIP.Limit1 AS %IX1.100.16;
SERVERIP.Limit2 AS %IX1.100.17;
SERVERIP.CATIN AS %IB1.100.3;
```

Full example in the paragraph "**Example virtual-physical links**".

In the case of AC-E encoder counting modules, the value entered corresponds to the expansion number of the TRS-CAT.

### Example of virtual-physical link

(\* The initial part of the file is that indicated in the previous example\*)

(\*

-----  
 Virtual-Physical Link

\*)

VAR

(\* TRS-CAT \*)

```
SERVERIP.Limit1 AS %IX1.100.16;
SERVERIP.Limit2 AS %IX1.100.17;
SERVERIP.CATIN AS %IB1.100.3;
```

(\* SERVO LTi\_1 \*)

```
LTi.X.Ax AS %IL1.LTi_1.0;
LTi.X.STOP AS %QX1.LTi_1.2;
LTi.X.SVON AS %QX1.LTi_1.3;
LTi.X.RESET AS %QX1.LTi_1.7;
LTi.X.ALM AS %IX1.LTi_1.3;
LTi.X.WARN AS %IX1.LTi_1.7;
```

```
LTi.B.Ax AS %IL1.LTi_1.1;
LTi.B.STOP AS %QX1.LTi_1.18;
LTi.B.SVON AS %QX1.LTi_1.19;
LTi.B.RESET AS %QX1.LTi_1.23;
LTi.B.ALM AS %IX1.LTi_1.19;
LTi.B.WARN AS %IX1.LTi_1.23;
```

```
LTi.Z.Ax AS %IL1.LTi_1.2;
LTi.Z.STOP AS %QX1.LTi_1.34;
LTi.Z.SVON AS %QX1.LTi_1.35;
LTi.Z.RESET AS %QX1.LTi_1.39;
LTi.Z.ALM AS %IX1.LTi_1.35;
LTi.Z.WARN AS %IX1.LTi_1.39;
```

(\* SERVO LTi\_3 \*)

```
LTi.Y.Ax AS %IL1.LTi_3.0;
LTi.Y.STOP AS %QX1.LTi_3.2;
LTi.Y.SVON AS %QX1.LTi_3.3;
LTi.Y.RESET AS %QX1.LTi_3.7;
LTi.Y.ALM AS %IX1.LTi_3.3;
LTi.Y.WARN AS %IX1.LTi_3.7;
```

(\*

(\* SERVO LTi\_4 \*)

```
LTi.X.Ax AS %IL1.LTi_4.0;
LTi.X.STOP AS %QX1.LTi_4.2;
LTi.X.SVON AS %QX1.LTi_4.3;
LTi.X.RESET AS %QX1.LTi_4.7;
LTi.X.ALM AS %IX1.LTi_4.3;
LTi.X.WARN AS %IX1.LTi_4.7;
```

\*)

END\_VAR

## How to write EPLBUS.def file

CANBUS.DEF file is a text format file that describes the hardware configuration and the connections between logical devices and physical devices on POWERLINK. For every module a EPLBUS.DEF file must be written and saved into the configuration folder of corresponding module. (\MODn\CONFIG). Inside the

file the part describing POWERLINK hardware should come before the description of the logical-physical connections. The main elements to define the hardware configuration are as follows:

- **(\*...\*)** beginning and ending of a comment. Comments can be written on more than one text line. You can enter a comment inside another. This is useful when you want to comment a block of definitions whose rows are commented. For example
 

```
.....
CN(1) SERVO; (*NODE 1*)
(*
CN(2) SERVO; (*NODE 2*)
CN(3) IO ; (*NODE 3*)
*)
```
- **MN (number) of attributes** beginning of description's block of a Managing Node (MN). **Number** represents the index used to the EplAddress arrangement. Instead of a number you can use an alphanumeric identifier that will be used later on to identify MN in the description block of the logic-physical connections. In this case the attribute **ID** is obligatory. A MN is configured by means of the following attributes:
  - MASTER: MN gives the signal of synchronism to the others
  - ID=number: reference to the MN board position in the PC bus.
  - TIME=number: sampling time in msec (it can be 1,2,4,8)
- **CN (number of attributes)** beginning of description block of a Controlled Node (CN). **Number** represents the index used for the EplAddress composition. Instead of a number you can use an alphanumeric identifier that will be used later on to identify CN in the description block of the logic-physical connections. In this case the attribute **ID** is obligatory. A CN is considered a part of the POWERLINK subnetwork of the preceding MN description block. A CN is configured by means of the following attributes:
  - SERVO: implements the DS402 specification (servodrives)
  - DISABLED**: disables CN. This word can be entered in any part of the definition, after CN() at the beginning and before ';' at the end
  - IO: implements the DS401 (I/O) specification
  - ENCODER: implements the DS406 specification (encoder)
  - ID=number: CN number. If this attribute is not defined, CN (number) is used
  - MPX=mult+slot: if defined, CN is used in multiplexing. **Mult** represents the sampling time multiplier. Following values can be defined: **0**=CN is queried in the asynchronous phase (not realtime); **1**=CN is queried every cycle; from **2 to 16**= CN is queried in multiplexing. **Slot** represents in which slot of time CN will be queried. The range of possible values is between 1 and the value assigned to **mult**.
  - RPDO=number: Process Data Object dimension of CN's reception. Value should be between 1 and 1490
  - TPDO=number: Process Data Object dimension of CN's transmission. Value should be between 1 and 1490
- **;** ending the description of a MN or CN description block

Below the description of the main elements to define the logical-physical connections:

The formalism used is in accordance with the standard IEC1131. The described data should be located inside the block defined by VAR END\_VAR.

- **(\*...\*)** beginning and ending of a comment. Comments can be written on more than one text line. You can enter a comment inside another. This is useful when you want to comment a block of definitions whose rows are commented.
  - **VAR** beginning of block of connections' description.
  - **DeviceName** full name of the logical device. It can be written in the form "Group.Subgroup.Device" or "Group.Device"
  - **AS** keyword separating **DeviceName** from **EplAddress**
  - **EplAddress** shows the hardware address, how many bit employs and which CN is referred to. Its describing formalism is :
    - %** is the first compulsory character
    - I** or **Q** is the second character. **I** shows an input device, **Q** shows an output device
    - X** or **B** or **W** or **L** is the third character. **X** shows the the next value has to be interpreted as a bit and it has to be used in the definition of digital inputs and outputs. **B** shows that the next value should be interpreted as a byte and it has to be used in the definition of digital input and outputs ports.
    - W** shows that the next value should be interpreted as a word and it has to be used in the definition of digital input and outputs ports. **D** shows that the next value should to be interpreted as 32 bit and it has to be used in the definition of analog input and outputs ports. **L** shows the the next value should be interpreted as 8 byte and it has to be used in the axes definition. If omitted, the next value is interpreted as a bit.
- The following characters are a sequence of figures, divided by a point '.', showing the address. The first number refers to MN, the second one to CN, the third, optional, is an offset inside CN. This offset can also be expressed on 2, 8 or 16 according to the IEC formalism. If the offset is omitted, a value equal to 0 is considered.

- ; ending the connection's description
- **END\_VAR** ending of block of connections description

Whatever is found after the keyword END\_VAR of end block is ignored. Correctness of the file from both points of view of syntax and content is verified at the startup of Albatros. If an error is found, an error message is displayed. All the errors described are in the file ERREPL.TXT saved in the folder provided in Tpa.ini under DirReport.

**Example:**

```
MN (1) ID=142332 TIME=1 MASTER;
```

|        |        |         |         |        |         |
|--------|--------|---------|---------|--------|---------|
| CN (1) |        | SERVO   | MPX=1   | RPDO=4 | TPDO=8; |
| CN (2) |        | SERVO   | MPX=1   | RPDO=4 | TPDO=8; |
| CN (3) | ID=17  | IO      | MPX=2   | RPDO=4 | TPDO=8; |
| CN (4) | ID=21  | IO      | MPX=4+1 | RPDO=4 | TPDO=8; |
| CN (5) | ID=22  | IO      | MPX=4+2 | RPDO=4 | TPDO=8; |
| CN (6) | ID=108 | ENCODER | MPX=0   | RPDO=4 | TPDO=8; |

VAR

|                   |               |
|-------------------|---------------|
| Main.EV1          | AS %QX1.3.10; |
| Main.EV2          | AS %Q1.3.11;  |
| Main.Axes.InpPort | AS %IB1.5.12; |
| Emerg.InputW      | AS %IX1.5.13; |
| Axes.AxisX        | AS %IL1.1;    |
| Axes.AxisY        | AS %IL1.2;    |

END\_VAR


### 7.4.3 Virtual physical Configuration

Virtual physical Configuration is the last configuration step and consists in connecting the logic devices to the hardware components.

For each axes of a Mechatrolink II board 6 inputs and 1 digital output can be configured in virtual-physical. For a detailed description, please, read chapter **GPL Language->Instruction->Mechatrolink II->MECGETSTATUS**.

If Ether-CAT bus is available in a module, you can anyway configure some boards for the Mechatrolink II bus, but with some restrictions: with 1 ms realtime you cannot connect more than 6 Mechatrolink II axes (each bus); with 2 ms realtime, the restriction rises to 16 axes.

Opening the Virtual physical Configuration two windows are displayed: the Machine Configuration window (virtual) on the left, and the Hardware Configuration window (physical) on the right. Both show a graphic representation of all the elements composing the system in a tree structure.



### Virtual-Physical Configuration

The existing virtual-physical connections are highlighted in the "Machine Configuration", by the Name of the device (in red), while in the "Hardware Configuration" window they are highlighted by the name of the type of signal, which follows the number of the terminal, also in red.

If in the system some devices are configured on CAN, POWERLINK and EtherCAT buses, they are displayed in fuchsia and they cannot be modified. All this because bringing together the logical device and the physical device must be defined in the external .DEF files.

The devices or the terminals still to be connected are marked in black.

The signals indicating the axes, in the "Hardware Configuration" window, are all preceded by a rectangle whose colour corresponds to the colour of the sheathing of the wire inside the connection cable.

It is possible to highlight a connection by selecting a logic device (or a hardware component) and pressing the space bar: the connection is shown as a red line between the device and the hardware component. It is also possible to keep the connection visible at all times by pressing **[Alt+Enter]**.

To show which logic device is connected to the hardware component, select the hardware component and double click on it with the mouse.

To select the logical device and the physical device to connect various procedures are possible:

#### First procedure

- Display on the screen, through the "Hardware Configuration" window, the physical terminal to which the device has to be connected.
- Select, or point, the logical device required in the "Machine Configuration" window.

#### Second procedure

- Select, or point, the chosen virtual device in the "Machine Configuration" window.
- Select the command from **Edit->Find the suitable physical device** menu or **[CTRL+space]** key combination. Albatros displays automatically in the "Hardware Configuration" window the first

physical unengaged device to which the logical device can be connected.

#### Third possible procedure

- Select, or point, a virtual device in the "Machine Configuration" window.
- Select the command from the menu **Edit->Find next unlinked device** or the shortcut key **[CTRL+NumPad+]** or the command **Edit->Find previous unlinked device** or **[CTRL+NumPad-]** keyboard shortcut.

To connect the two selected devices:

- Click on the logical device to connect with the left hand button of the mouse, and keeping it pressed, drag it towards the selected terminal. A red line will appear to indicate connection in progress. When you have reached the terminal line, release the button to terminate the operation or
- select the command **Link!** from the menu **Edit** or the keyboard shortcuts **[CTRL+L]**.

To remove a connection, select the device or the affected component and press the button **[Remove]** or the button **[Delete]** on the keyboard.

### 7.4.4 Cabling maps

When the virtual devices and the corresponding physical devices have been connected, it is possible to print maps or lists of the virtual-physical connections.

To perform this operation it is necessary to have installed MS-Word (version 6 or later) on the system, as Albatros uses its functions to format the maps.

The system must also have been configured correctly, which means that the system must have the model files used for map compiling. These are a series of files with a ".doc" extension which normally lie in the System folder or in another installing folder (often the "Map" file). The important is that the folder where these files lie corresponds to the one specified in the **TPA.INI** file, key: "DirMaps". For example:

```
[TPA]
DirMaps=C:\Albatros\Maps
```

To print the cabling maps, select any hardware component in the right hand window of the Virtual-Physical configuration or in the window of the Hardware configuration.

Press the Print icon in the Status Bar, or select the heading **Print** from the **File** menu; the usual print options window will appear. When the printer is set to your satisfaction, confirm by pressing **[OK]** and another window will show the list of hardware components present in configuration. Select from this window all the components to be included in the cabling map. To select more than one component, select the components with the mouse while keeping the "Ctrl" key pressed. Click on **[OK]** and the cabling maps will be printed. If the **Print on paper** option is deselected, the maps will be saved as MS- Word documents in the file of the current module (Mod.0, etc).

Because of the large number of pages which are often necessary for printing, we suggest printing a proof sheet, with only one hardware component, to check that everything is working. If a list of logic devices is printed instead of the map, probably no component (for example an axis card or remote) was selected in the hardware window. When a component is selected, its name appears highlighted in blue.

### 7.4.5 List of navigation keys to navigate through a tree structure

| Key         | Description  |
|-------------|--|
| Up Arrow    | moves the selection to the immediately previous row or to the following one                                    |
| Down Arrow  |  |
| Right arrow | expands the selected branch to an extra level and, if already expanded, moves the selection on the next branch |
| Left arrow  | collapses the selected branch and, if already collapsed, transfers the selection on the previous branch        |
| +           | expands the selected branch to one level   |
| -           | collapses the selected branch  |
| *           | expands all the levels of the selected branch  |






## 8 Development tools

### 8.1 Editor GPL

#### 8.1.1 GPL Editor functions

GPL editor is the instrument that allows you to create and modify the files in the Albatros GPL code. This function can only be activated as from the manufacturer password level. Each functions file contains information which can be displayed in the **File->Information** menu.

The functions are the ones typically used in a text editor, so we find commands such as **Copy, Paste, Find, Replace** etc. All these commands can be selected from the menu **Edit**.

|                                 |   |
|---------------------------------|---|
| <b>Undo</b>                     | if possible, erases the last operation performed. The situation is reverted to the older state, before the last operation performed.  |
| <b>Redo</b>                     | The situation is reverted to the older state preceding the last Undo command.   |
| <b>Cut</b>                      | Text or selected data are removed and copied in a temporary memory to enable their possible insertion with the command <i>Paste</i>   |
| <b>Copy</b>                     | Text or selected item is copied in a temporary memory to be inserted again with the command. <i>Paste</i> .   |
| <b>Paste</b>                    | Temporary memory content is inserted using different criteria according to the active function.   |
| <b>Delete</b>                   | Text or rows or the selected item are deleted. Deleted data can be recovered by acting immediately upon the command <i>Delete</i>   |
| <b>Select All</b>               | allows the whole text of the active file to be selected. To the selected rows Copy, Cut, Paste commands can be applied.   |
| <b>Find...</b>                  | searches a text in the current document. You can set some criteria to use under research such as search direction and case-sensitive distinction.   |
| <b>Find next</b>                | permits the repetition of a previous search, enabling the change of the research criteria, set by with the command Find.  |
| <b>Replace</b>                  | allows you to search a text of the current document and to replace it with another text.  |
| <b>Insert device</b>            | inserts a device by selecting it from the list of the devices. This function is particularly useful when you work with a large number of devices whose name can be difficult to remember. Only the devices of the current module that can be recalled and all the public devices of the other modules are displayed.  |
| <b>Insert function</b>          | inserts an empty function including some comments to use as a guide in Edit. It inserts a function or a part of a function starting from the position of the cursor. The function is read by a prototype file, written from the machine constructor. More prototype files can be written. A prototype file is a text file, whose name must start with the GPL prefix and TXT extension. It must be stored in the directory, where the libraries are normally stored (usually system \lib). If more prototype files are defined, selecting a command, a dialog box is opened, in which the list of the prototype names is displayed without prefix and without extension. Prototype files can contain, for instance, const definitions commonly used, handling functions of system errors, generic functions, codes implementing algorithms for various usages, and so on. They also content some comments. A prototype file can be created by saving the selected text in the file of GPL functions. This command is available only as keyboard accelerator <b>[Ctrl+Shift+C]</b> . A dialog box opens to insert the name that has be given to the code fragment. |
| <b>Insert message...</b>        | inserts in the GPL text the numeric code associated to the chosen message. Enables some new messages to be entered in the language files.   |
| <b>Enable/Disable new page</b>  | inserts or removes a page break  . Page break can be used as a bookmark to spring to remarkable positions inside the function file.  |
| <b>Enable page break after</b>  | moves edit cursor to the row of the next page break with respect to its position  |
| <b>Enable page break before</b> | moves edit cursor to the row of the previous page break with respect to its position  |

```

Machine 1: Editing MAIN
Function AbsMovement
  param axisname as axis
  param speed as float
  param position as double

  iftarget axisname goto move
  ifstill axisname goto move
  fret
  move:
  setvel axisname, speed
  movabs axisname, position
  waitstill axisname
  fret

Function IncMovement
  param axisname as axis
  param speed as float
  param position as double

  iftarget axisname goto move
  ifstill axisname goto move
  fret
  move:
  setvel axisname, speed
  movinc axisname, position

```

GPL Editor

Syntax corrections are carried out in the archiving phase, when the text is also compiled. However, the programmer can easily make a preliminary inspection, as the text is displayed in different colours according to what it represents. For example, instructions are in blue, comments in green and labels in red.

The value of tabulations for the initial position of the GPL code, the initial position of the first subject of instructions and the initial position of the comment, can be modified using the **Options->Tabulations...** menu.

Tab value can be modified from menu **Options->Tabulations...** Two types of tabulations can be defined:

- absolute tabulations: they set the initial position for the instructions of GPL code the initial position of the first argument of the instructions and the initial position for the comment.
- relative tab (spaces): it sets how many spaces is a tab

Tabulations also help to make the lay out of the GPL code more immediately comprehensible.

Each instruction or keyword is linked to the online help for further support when editing a function. To recall the help simply place the cursor on the instruction and press **[F1]**.

Each line of text can contain only one instruction. To continue the instruction in the following row press the character '\_' (preceded by a space) as the last one of the row. This allows you to insert comments in the middle of an instruction:

```

Message
  1000 ;code of the message that will be displayed  _
  3    ;synoptic cell in which it will be displayed [Enter]

```

## 8.1.2 Available keyboard shortcut list

|   |  |
|---|--|
| <p>☐ <b>Clearing a text</b></p> <p><b>Key</b><br/>           Backspace<br/>           Ctrl+Backspace<br/>           Del<br/>           Ctrl+T<br/>           Ctrl+Del</p>   | <p><b>Description</b><br/>           erases a character on the left or the selected text<br/>           erases the word on the left<br/>           erases a character on the right or the selected text<br/>           erases the words or the spaces on the right<br/>           erases the word on the right and all the following spaces until the beginning of a new word</p>  |
| <p>☐ <b>Comment of more text rows</b></p> <p><b>Key</b><br/>           Ctrl+';'. In the Italian keyboards [Shift] key must be pressed as well</p>   | <p><b>Description</b><br/>           this adds or removes the comment characters to the selected rows.</p>   |
| <p>☐ <b>Cursor positioning</b></p> <p><b>Key</b><br/>           Up arrow<br/>           Down arrow<br/>           Right arrow<br/>           Left arrow<br/>           Home</p> <p>End:<br/>           Ctrl+Home<br/>           Ctrl+End<br/>           Ctrl+Left Arrow<br/>           Ctrl+Right Arrow<br/>           Ctrl+Enter</p> | <p><b>Description</b><br/>           moves the cursor to the selected direction</p> <p>moves the cursor to the beginning of the row to the beginning of the row and to the first character of the row alternately<br/>           moves the cursor to the end of the row<br/>           moves the cursor to the beginning of the document<br/>           moves the cursor to the end of the document<br/>           moves the cursor by one word on the left<br/>           moves the cursor by one word on the right<br/>           moves the cursor on the first character of the following row</p>   |
| <p>☐ <b>Select</b></p> <p><b>Key</b><br/>           Shift+Home<br/>           Ctrl+Shift+Home</p> <p>Ctrl+Shift+End<br/>           Ctrl+Shift+Left Arrow<br/>           Ctrl+Shift+Right Arrow<br/>           Shift+Page Up<br/>           Shift+Page Down<br/>           Ctrl+W<br/>           Ctrl+A</p>                            | <p><b>Description</b><br/>           selects from the cursor position until the beginning of the row<br/>           selects from the cursor position until the beginning of the document<br/>           selects from the cursor position until the end of the document<br/>           selects the word or the the spaces on the left of the cursor<br/>           selects the word or the the spaces on the right of the cursor<br/>           selects a page up from the current position of the cursor<br/>           selects a page down from the current position of the cursor<br/>           selects the word where the cursor is placed<br/>           selects the whole document</p> |
| <p>☐ <b>Rectangular selection</b></p> <p><b>Key</b><br/>           Alt+<br/>           Shift+Up Arrow<br/>           Shift+Down Arrow<br/>           Shift+Left Arrow<br/>           Shift+Right Arrow</p>  | <p><b>Description</b><br/>           selects a rectangular code group</p>  |
| <p>☐ <b>Tabulations</b></p> <p><b>Key</b><br/>           Tab</p> <p>Shift+Tab</p>   | <p><b>Description</b><br/>           in case of unavailable selected text, it inserts spaces between characters, as defined in <b>Options-&gt;Tabulations</b>. If many rows have been selected, <i>Tab</i> inserts on the right the spacing set for the relative tabulation.<br/>           In case of unavailable selected text, <i>Shift+Tab</i> moves the cursor on the left side or the spacing defined <b>Options-&gt;Tabulations</b>. If one or more rows have been selected, they are moved to the left side of the spacing set for the relative tabulation.</p>  |

### ☐ Copy and Paste

#### Key

Ctrl+C

Ctrl+Ins

Ctrl+X

Shift+Del

Ctrl+V

Shift+Ins

Ctrl+Y

Drag'n'drop (with the mouse)

Ctrl+Drag'n'drop (with the mouse)

#### Description

copy the selected text into the Clipboard

deletes the selected text and copy it into the Clipboard

inserts the content of Clipboard from the cursor position

eliminates the row where the cursor is placed and copies its content into the Clipboard

the selected text is dragged and moved to the new position after its release

the selected text is dragged and copied to the new position after its release

### ☐ Cancel / Restore

#### Key

Ctrl+Z

Alt+BackSpace

Ctrl+Shift+Z

#### Description

cancels the last typing

restores the last typing

### ☐ Search and Replace

#### Key

Ctrl+F3

Ctrl+Shift+F3

F3

Shift+F3

Alt+F3

#### Description

searches down into the whole document for the word which the cursor is placed on.

searches up into the whole document for the word, which the cursor is placed on.

searches for the following occurrence. The dialog box **Find** should be closed.searches for the previous occurrence. The dialog box **Find** should be closed.opens the dialog box **Find** and as a text to be searched sets the word, which the cursor is placed on.

### ☐ Displaying compilation errors

#### Key

Double-click on the error

F4

Shift+F4

#### Description

places the cursor on the row of the GPL function where the error described occurred

places the cursor on the row of the GPL function where occurred the error, that follows the last selected error.

places the cursor on the row of the GPL function where occurred the error, that precedes the last selected error..

### ☐ Creating a prototype file

#### Key

Ctrl+Shift+C

Folding control

#### Key

Ctrl+M

#### Description

saves the text selected in the file of GPL functions. A dialog box opens to insert the name that has to be given to the code.

#### Description


expands or collapses the selected folding.

## 8.1.3 Insert Message

Albatros uses two kinds of messages: module messages and group messages. The command can be selected from the menu **Edit->Insert Message**.

Group messages are inserted directly in editor when writing the GPL code, by using the DEFMSG instruction. These messages can be displayed and used only inside the group in which they are defined, so that the same message definition can be used in various groups, without creating superimposition.

Module messages, unlike group messages, can be used by any group. They can be inserted through the dialog window that allows both recalling any existing message from the language file and introducing new messages.



**Message management window**

Using this procedure avoids having to pass to Winmess.exe and worrying about opening the right file. The message will be inserted in the current language although, later, it will have to be translated in the other languages (this time using Winmess.exe).

All the messages in the language file are listed under the heading **Description**. To insert a message in the function, choose the required text and select the **[Modify text]** button.

To modify an existing message **[Modify]** or create a new one **[New]**, first type in the modification or the new text and then press the corresponding button.

### 8.1.4 Cryptography


In Albatros it is possible to use encryption so that the source text of functions cannot be displayed.

Cryptography is enabled by selecting Tele+=0 or 1 in TPA.INI. The default value is 0. In this case, when Albatros saves a functions file, the save mode does not change.

When a functions file is saved and cryptography is enabled, the following message will be displayed: "Do you want to encrypt the file?". If you choose no, the file will be saved as plaintext. A previously saved, plaintext file can subsequently be encrypted, while an encrypted file will not change, and will be saved in the same way by default.

When a functions file is saved for the first time, with cryptography enabled, and a daily Manufacturer password is used, the file will not be encrypted, but only saved as plaintext. Subsequently, the encrypted functions file may only be displayed or edited in Albatros by the user who previously saved it. The owner of an encrypted functions file cannot change!

The external file SBIANCA.EXE must be used to decipher the file. This is located in the Bin folder of Albatros. When the programme is run, the following window is displayed:



In this window, files to decrypt can be selected. The Status and Credentials are displayed for each file. The status may be "Plaintext" or "Encrypted". "Credentials" gives information about file visibility. "Freely readable" means the file can be displayed from the current password level. Blocked means the file cannot be displayed. Select the files, then click on "Decrypt!" to decipher them.

## 8.2 Libraries


### 8.2.1 Create and modify

A library is a collection of GPL functions which can be called within the custom GPL code without being limited to a particular configuration. Libraries are very useful, as they can be easily copied from one machine to another, which avoids having to rewrite common code when implementing new machines. For example, we could create a mathematical and geometrical functions library.

Library files are archived in the system\lib folder. They are compiled by executing one of the following commands: **CNC->Initializing, File->Compile All, Save** library file or global variables file.


If in the GPL code a machine is given a function or variable name which already exists in a library, in the compiling phase the machine will always have the priority. If the same name is used in two different libraries, when writing the GPL code, we suggest using the following full syntax to identify the required one: **namelibrary.namefunction**. For example, if the LengthSegment function appears both in the LIBGEO library and the LIBMAT library, and we want to identify the function belonging to the LIBGEO library, we write:

LIBGEO.LengthSegment.



**GPL library management window**

All the operations concerning the library are managed through the dialog window above. It is possible to create new libraries **[New]**. The name given to the library will be added to the list of libraries installed. Moreover it is also possible to import already existing libraries and to transform files of groups into a new library; this is done by recalling them through the dialog window opened by pressing **[Import..]**. The same operation is used to recover libraries which had previously been eliminated with the **[Erase]** command.




**New library**

To modify the code of a library, select the **[Edit]** button. The library is opened by GPL editor. When writing the library functions remember these basic rules:

- it is not possible to access devices, functions, and variables belonging to the configuration in which the function is being written.
- it is possible to call public functions and variables from other libraries.
- the functions declared inside a library are defined as private by default. To make it possible for other function files to recall them, they have to be declared as PUBLIC.

Library modification is subject to access level limitations of the person using Albatros. It is possible to assign or modify library access authorisations by selecting the **[Properties]** button.



Library properties

Any global variables declared in a library are displayed in a section of Diagnostic. The display of library elements depends on the access rights of the person using Albatros.

## 8.3 Debug

### 8.3.1 The debugger

The debugger is a function of Albatros which allows you to follow the sequence of instructions of a GPL task step by step, thus allowing you to identify and correct any logic errors and anomalous behaviour of the code.

This function can only be activated from the manufacturer level or a higher password level. The debugger allows the user, for example:

- to assign breakpoints
- to interrupt the execution of a task and display the value of a variable
- to supervise the execution sequence of a function
- to check the value adopted by a local variable
- to check that, in the case of an instruction, the right branch was chosen

The commands required in debug mode can be selected from the **Debug** menu. The main ones are:

**Go** resumes the execution of a blocked task. The task will continue until the end, it will not be stopped again or an interruption point will not be.

**Restart** restarts the debug of the current task

**Break now** stops the execution of the task which is being debugged. The cursor is placed at the row, where the instruction has been broken. Once the task has been stopped, its execution can be piloted and the status of the local variables can be checked.

**Step into** steps into a single GPL instruction The task should have been previously broken.

**Step out** carries out all the instructions until the first instruction after the current one

**Step over** carries a single GPL instruction out or, if the instruction is a function call, it carries the whole instruction out

**Step to Cursor** carries out the instructions until the cursor position

**End** debug usage. The function file that was being debugged is opened in Edit mode.

To access the debugger, display the list of tasks in execution (from the menu **Debug->Task in execution** or the list of All tasks (from the menu **Debug->All tasks**) and then select the task to be debugged.

Before executing the debug make sure there are no function compiling errors (for example: syntax errors and undeclared variables) and that the module to be debugged has been started correctly.



The debug window is similar to the GPL editor window, however it does not allow you to modify the code. The background of the window is grey and the line in execution is highlighted in yellow.

```

Machine 1: Debugging ASSI.SetpointX [running]
fret
Function SetpointAssi public
  setflag   main.Setp
  starttask SetpointX
  starttask SetpointY
  setquote  B, 0.0
  setquote  C, 0.0
  waittask  SetpointX
  waittask  SetpointY
  resetflag main.SETP
fret
Function SetpointX autorun
  reslimpos x
  reslimneg x
  ifinput   SetP_X ON goto jump
  setvel    x, 5
  movinc    x, 400
  waitinput setp_x, ON
  endmov    x
  waitstill x
jump:
  setvel    x, 0.1
  movinc    x, -100.0


```

Debugger window

**Notice:** It is not possible to debug simultaneously more than one task belonging to the same module.

### 8.3.2 Task in execution

The command can be selected from the menu **Debug->Task in execution**. It displays the list of tasks in execution associated to a machine or module. It is possible to execute the debug or interrupt execution of a task by selecting the task and clicking on the **[Debug]** or **[End]** button, accordingly.




**List of active tasks**

### 8.3.3 All tasks

It displays in a dialog window the list of all the tasks defined in the GPL code. These are represented graphically as a tree structure, as shown in the figure below. When we select a function, the file in which it is defined is opened and the cursor is positioned on the first instruction of the function. This allows you to set Breakpoints even before starting execution.

It is important to select the function from the task branch we want it to be called from.




List of tasks

Below we describe the meaning of the symbols used in the composition of the task execution tree. An interesting symbol is the one indicating the recursive function, that indicates a function which includes a recall to the function from which it is called.

| Symbol | Description  |
|--------|--|
|        | task of the Intergroup's main function                             |
|        | autorun task   |
|        | generic task   |
|        | real-time task   |
|        | group function   |
|        | group function executed by instructions such as ONINPUT, ONFLAG    |
|        | library function   |
|        | library function executed by instructions such as ONINPUT, ONFLAG. |
|        | recursive function   |

### 8.3.4 Show call stack

During debug it is possible to display the list of functions which have been called but still haven't returned (that is, all the functions in which the FRET instruction has not yet been executed). A dialog window appears, listing all the function calls leading to the current instruction. The function executed last is at the top of the list.



**List of all function calls**

To observe the behaviour of a function call:


- move the cursor to the desired position in the function
- select **Debug->Step to cursor** to take program execution to the desired position
- select **Debug->Show Call stack**, or the shortcut button **[CTRL+K]**.
- the name of a function can be selected from the Call stack dialog window. The cursor will then go to the first instruction of the chosen function.

### 8.3.5 Breakpoints

A breakpoint allows you to examine all the details of an instruction execution sequence, to examine or modify variables and devices, to examine the list of function calls etc.

Task execution is interrupted when the instruction containing the breakpoint is reached.

Breakpoints can be set both before executing a certain task and during execution (from the menu **Debug->Breakpoints**). It is also possible to delete the breakpoints when they are no longer necessary.



**List of breakpoints**


In certain situations, despite having inserted breakpoints the task is not interrupted, because execution never reaches the breakpoint. In this case the task can be interrupted by using the command: **Debug->Break now**. The cursor will be positioned on the GPL instruction which was about to be executed when the task was interrupted.

### 8.3.6 Variable content

This command can be selected from the menu **Debug->Content of variable**.

After interrupting task execution the following can be displayed:

- the value of the local variables declared in the function where the task has been interrupted
- global variables
- the value assumed by an expression
- the state of devices and device parameters



**Display/Change content of a variable**

If the variable (or device) is not read-only, its content can be modified: obviously any modifications will affect the execution of the next task.

Changing the value of a variable or device allows you to test execution in different conditions from usual, to correct errors and carry on with the execution of the next instructions.

It is possible to display the content of a variable, of a device or of a constant also by moving the mouse on the variable, on the name of the device or on the constant. A tooltip is displayed, where the type, the name and the value of the data is shown. If you select an expression, its result is displayed. If the mouse pointer is inside the selection, the whole selection is used, otherwise only the word where the mouse pointer is placed. If the mouse pointer is not inside a word, the whole argument is used.

E.g., to see the value of the `Mx[3][column]`, if the mouse pointer is on "3", 3 is displayed in the tooltip; if the mouse pointer is on "column", the value of the column is displayed; if it is on "matrix" nothing is displayed; if it is on a square bracket, the value of `Mx Mx[3][column]` is displayed.

### 8.3.7 Available keyboard shortcut list

To activate the commands of **Debug**, the options can be selected the menu **Debug** or typed directly on the keyboard.

The keyboard shortcuts are as follows:


| Key           | Description   |
|---------------|---|
| Ctrl+F5       | opens the dialog window showing the list of the tasks in execution  |
| Ctrl+Shift+F5 | opens the dialog window showing the list of all the tasks   |
| Ctrl+B        | opens the dialog window to insert or cancel the breakpoints   |
| Ctrl+F9       | inserts or eliminates the breakpoints on the row where the cursor is placed   |
| Ctrl+K        | opens the dialog box to display the list of the functions called, but not yet returned  |
| Shift+F9      | opens a dialog window to display the content of a variable  |
| F8            | executes the instruction If this is a function, it enters the function  |
| Shift+F7      | executes all the instructions of the function   |
| F10           | executes the instruction If this is a function, it executes it without entering   |
| F7            | executes all the instructions until the instruction where the cursor is placed. The cursor should be placed on an instruction within a function |
| Alt+Interr    | interrupts the execution of the code at the last executed instruction   |
| F5            | resume the code execution after an interruption   |
| Shift+F5      | ends the current task and executes it again   |
| Alt+F5        | ends the debug  |

## 8.4 Control initialization

### 8.4.1 Network Connections

The profile machining of Albatros is protected by a USB hardware key, configured by T.P.A. S.p.A. This command can be selected from the menu **Cnc->Network Connections**. It displays the state of the remote modules connected to the system. If a module is not connected, the symbol with which it is indicated is marked with a red cross.


Each module has two fields. The first one is the name of the associated module and the second one is the name of the network station. Usually the name of the network station begins with the fixed characters "TPANT" or "TPACE" followed by the serial number of the remote module.




**Remote modules connection**

#### Assigning a network node to a logical module

To assign a network node to a module, position the mouse pointer on the text "Not configured" or click on the button **[Edit]**. A few seconds later a window containing the list of available remote modules in the network will appear (each remote module must be switched on and it must have received an IP address correctly)



**Assigning a remote module**

Now, select the network node you want to connect to the logical module and confirm your choice by pressing the  button.

Notice that this operation can be carried out at a "Service" password level, without having to access Albatros's System configuration for which a "Manufacturer" password level is required. However, the module must be configured as "remote ALBRTX" in System configuration, beforehand.

## 8.4.2 Hardware Diagnostic

This command can be selected from the menu **Cnc->Hardware Diagnostic**.

Hardware Diagnostic displays the list and the state of configured modules, of axis cards and of the remotes belonging to them, as defined in hardware configuration. If the symbol of a card or of a remote is marked with a red X, it can either mean that this item was not found among the hardware in the control panel or that it was not possible to initialize it correctly.


If an item is marked with a yellow question mark, it means the system has detected a card or remote, but it does not match the type defined in configuration.

## 8.5 Test

### 8.5.1 Print global on disk

This command can be selected from the menu. It saves the content of a global variable on disk as a formatted text file. The file's name is *variablename.txt* and the file is saved in the *Report* folder.

This operation can only be performed if the read access level of the global variable is compatible with the current access level.




Saving a global variable

### 8.5.2 Start single function

This command can be selected from the menu **Test->Start function**.

It executes a function independently of the rest of the system, creating a new task. The task begins its execution from the selected function, from which it will take its name.

Only the functions without input parameters and whose read access level is compatible with the current access level can be executed. If the executed function is the main function of the inter-group, all the autorun tasks will also be executed after.



Selecting a function to be executed manually

### 8.5.3 Message Import and Export

Group messages, assigned by means of the GPL DEFMSG instruction, can be stored in a text file to be modified and later re-introduced into the GPL code. This function is useful, for example, when you need to translate messages or create an archive of used DEFMSG instructions.

To import or export group messages, all the GPL code must be compiled without mistakes. Otherwise, the user would be prompted with a message saying "Not all the GPL code is compiled".

Group messages belonging to encrypted files cannot be exported or imported (See Chapter **Development tools->Editor GPL->Cryptography**). Therefore, the user is not authorised to decipher (or decrypt) these group messages into plain text.

#### Export Group Messages

This command can be selected from the menu **Test->Export group messages**.

A dialog box prompts you to enter the name of the text file where to store group messages. The default name is MSGEXP.TXT and it is saved in the folder defined in tpa.ini at the *dirReport* item.

#### Import Group Messages

This command can be selected from the menu **Test->Import group messages**.

A dialog box prompts the name of the text file from which you can retrieve group messages to be introduced into the GPL code. The default name is MSGEXP.TXT. It is saved in the folder defined in tpa.ini at the *dirReport* item. Only the messages which have already been defined in the GPL code can be imported. The GPL text cannot be modified if there is at least one DEFMSG instruction following an IFDEF instruction.

While importing group messages, errors can be detected when:

- among the texts of a particular group message, the language identifier code is present more than once
- a text is empty (that is: "")
- the name of a group or a library is defined more than once.

At the end of the import process all modules, containing modified groups or libraries, are compiled.

#### File Format

The file is in text format. The keywords are GROUP, LIBRARY, AUXLANG and each language is identified by the relevant three-letter name.

Here is an example of how the file can be written:

```
;Complete list of messages
```

```
GROUP Main:           ;Main group of any module
```



```

MSG_BASE      ITA "Italian translation"
              DEU "German translation"
              ENG "English translation"
              ESP "Spanish translation"
              FRA "French translation"

GROUP 1.Main: ;Main group of module 1
MSGERR "Error of the only Main group of module 1"
LIBRARY Calculations:
TOOCOMPLEX   ITA "Troppo complesso" ENG "Too complex"
ERROR        ITA "Errore generico"  ENG "Generic error"
BADARG       ITA "Argomento errato"  ENG "Bad argument"

```

**GROUP:** it assigns the name of the group to which messages belong ("GROUP Main:"). If groups with the same name already exist in different modules, messages are imported in all groups. If you like that a few messages are imported only in one group of a given module, you need to put the module number and a "." (point) before the group name ("GROUP 1.Main:").


- **LIBRARY:** it assigns the name of the library to which messages belong ("LIBRARY Calculations:").
- **DEFMSG Description:** it assigns the DEFMSG parameters: label (mnemonic name of the message to be displayed), language prefix (language in which the message is written: one of the 5 basic languages), message string (message to be displayed. It should be placed between quotation marks (""))
- **AUXLANG:** it assigns the name of the additional language used, while importing a group message, to enter an "additional" message into the GPL code, when the desired language is not included in the five main languages. It should be specified before the first GROUP or LIBRARY. ("AUXLANG: SQI")

## 8.6 Tools

### 8.6.1 Customise...

This command can be selected from the menu **Tools->Customise**.

It allows you to set a maximum of 10 programs whose execution can be started by Albatros's **Tools** menu.



**Configuration of the Tools menu**

**Menu Structure:**

lists the programs displayed in the **Tools** menu.

**Command:**

name of the program to be executed. The folder in which the program is stored may also be indicated, especially if it is not the same folder from which Albatros is executed or from the folders whose operating system looks for the executable files (variable of PATH windows environment).

**Text in Menu:**

the name appearing in the **Tools** menu to identify the executable program.

**Arguments:**


any combination of command line arguments needed by the program for correct execution. It is possible to insert dynamic subjects. For example by using the string \$TER during ViewRER execution report file of current month open.

Here is subjects list:

- \$File** Complete Path name of current file.
- \$FileName** File name and extension of current file.
- \$FileDir** Disc and folder of current file.
- \$Ter** Complete Path name of report file of errors of current month.
- \$DirModule** Disc and folder containing MODx of current file.
- \$Module** Module number of current file.
- \$Bin** Disc and folder containing Albatros executables.
- \$TpaIni** Complete Path name of initialization file TPA.INI
- \$ReqDirModule** Path (disk and folders) of Albatros module. If several modules are configured, the module dialog box opens. Example:  
\$ReqDirModule\config\canbus.def corresponds to the path  
c:\albatros\bin\mod.1\config\canbus.def if the second module is selected.
- \$ReqModule** Albatros module number If several modules are configured, the dialog box of the module number opens.

**Ask for Arguments:** if selected, whenever program execution is requested, a dialog window appears to

allow you to introduce different arguments from the ones set in the Arguments field. These can vary according to the launch mode of the program.



**It specifies the program-start arguments**

**Enable level:** it sets the display level of the program in the **Tools** menu. Albatros's test programs and data modification programs are normally given a manufacturer level. Machining editing programs are assigned a user level.

Certain fields can be edited using the **[Add]** button. This opens the **Add Tool** dialog window for the selection of the program to be executed. The allowed executable files are the following: .EXE, .COM, .PIF, .BAT.

When the dialog window is closed, after confirming the data, the program is inserted in the **Menu Structure** window and the name of the program and its folder, in the **Command** row.

The other buttons provided are **[Delete]**, **[Move Up]**, **[Move down]** which are used respectively to delete a program and order the list of programs.

## 8.7 Browser

### 8.7.1 The browser

Albatros's browser function uses the information generated by the compiler to create a database for the rapid search of symbols defined in the functions.

This function can only be activated at manufacturer or higher access levels. To select the commands, use the **Debug** menu.

The browser enables to:

- position the cursor in the line where a function, or a module, group or library variable or a module or group constant is first defined (from the menu **Debug->Go to definition**)
- position the cursor in the lines where a function, a device, a module or group variable or a GPL instruction (except for FCALL and FRET instructions) is mentioned. (from the menu **Debug->Go to reference**, to display the previous reference or the next one select from the menu respectively the options **Debug->Previous** o **Debug->Next**)


Group variables can only be managed from the edit window of the group they belong to.

To update the browser when switching to a new version, it is advisable to save the global variables first, and then execute the command **File->Compile All**.

When editing the functions, the link between text and symbols is lost. The link is reestablished in the filing stage.

### 8.7.2 Identifier Search

This command can be selected from the menu **Debug->Source browser**. The identifier search opens a dialog window that allows you to insert the name of the symbol to be found in the GPL code. According to the selected **Type of search**, this function will find either the definition or the first reference to the symbol.




**Identifier search window**

The inserted name can have the following characteristics:

- if it contains no "." (period) character: the name is searched for in all the function files.
- if it contains only one "." (period) character: the name preceding the period is identified as the name of the group, and the symbol will only be looked for in that group. For example, if a VisError function has been defined both in the MAIN group and in the AXES group, when a search is called for AXES.VisError, the cursor will go to the first row of the VisError function in the AXES group.
- if it contains two "." (period) characters: the name preceding the first period is identified as the name of the group and the one preceding the second period is identified as the name of the subgroup. The symbol will only be searched for in that subgroup.
- if it ends with an "\*" (asterisk) character the search will include all the symbols beginning with the characters preceding the asterisk.

In case of ambiguity in the search for a symbol, a dialog window is opened displaying all the symbols with the requested name. From this window it is possible to select the required symbol.



**Identifier selection window**













Below is a description of the special symbols used in the list for the identifier selection.

**Symbol**



**Description**

GPL instruction  
 module or group or library constant  
 module or group variable

|   |                  |
|---|------------------|
|  | library variable |
|  | library vector   |
|  | library matrix   |
|  | library function |
|  | group message    |
|  | label            |
|  | local variable   |
|  | local vector     |
|  | local matrix     |
|  | single parameter |
|  | array parameter  |
|  | matrix parameter |

### 8.7.3 Available keyboard shortcut list

To enable the Browser commands, select the menu items **Debug** or type directly on the keyboard. The keyboard shortcuts are as follows:

| Key                     | Description  |
|-------------------------|--|
| F2                      | positions the cursor on the line where the selected symbol is defined. If the browser data-base contains several symbols with the requested name, a dialog window opens to allow the user to select the required symbol. |
| Shift+F2                | positions the cursor on the first reference to the selected symbol. In case of ambiguity a dialog window opens to allow the user to select the required symbol.  |
| Ctrl+F2                 | opens a dialog window for the selection of the required symbol.  |
| Ctrl+'+' or Ctrl+PgUp   | positions the cursor on the following reference (use the "+" on the numeric pad)   |
| Ctrl+'-' or Ctrl+PgDown | positions the cursor on the previous reference (use the "-" on the numeric pad)  |



## 9 GPL Language

### 9.1 Basic Feature

#### 9.1.1 Conventions and terminology

##### Basic terms

|                            |  |
|----------------------------|--|
| ARGUMENT                   | One of the arguments of the instructions; it can be defined as <i>constant</i> , <i>variable</i> , or <i>parameter</i> , depending on the kind of instruction; if between square brackets ([ ]) it means that it may be omitted, implying that the instruction can be executed in a different way. |
| KEYWORD                    | An argument to be chosen among the arguments with a predetermined value, normally written in capital letters; the list of keywords is provided in a specific help page.  |
| PARAMETER                  | The argument of an instruction which is not defined within the instruction, but is passed to the function, precisely as a parameter, when the function is executed; in certain cases it is also called <i>parameterised argument</i> .   |
| CONSTANT                   | A fixed argument defined by means of the CONST metacontrol or an argument which is rigidly fixed within the instruction.   |
| VARIABLE                   | An argument defined as machine or group global variable or defined by a LOCAL instruction, which can be organised as simple variable, vector or matrix. See variables.   |
| CONFIGURATION<br>PARAMETER | An argument defined in configuration, such as the parameters of an axis, for example.  |

##### Most frequent arguments in instruction descriptions

The list below contains the terms relating to arguments which are frequently used in GPL instruction syntax. Each one is followed by a brief description. In cases in which an argument can assume a different value from the one described below, its description continues in the *arguments* section of the instruction's help page.

|                       |   |
|-----------------------|---|
| <b>inputname</b>      | name of digital input device  |
| <b>outputname</b>     | name of digital output device   |
| <b>flagname</b>       | name of flag switch or flag bit device  |
| <b>portname</b>       | name of input port, output port or flag port device   |
| <b>timename</b>       | name of timer device  |
| <b>countername</b>    | name of counter device  |
| <b>functionname</b>   | name of a function (also valid as device parameter in the case of ERRSYS.)  |
| <b>subprogramname</b> | name of a subprogram, it is the equivalent of <i>label</i> , to which we refer to for explanations; to call a subprogram use the instruction "CALL subprogramname". |
| <b>axis</b>           | name of an axis   |
| <b>constant</b>       | a character, an integer or double number, or a keyword  |
| <b>value</b>          | constant or variable (the <i>type</i> depends on the instruction)   |
| <b>variable</b>       | name of: variable, vector element or matrix element   |
| <b>variabledevice</b> | name of <i>device parameter</i>   |
| <b>matrix</b>         | name of a matrix  |
| <b>vector</b>         | name of a vector  |
| <b>label</b>          | name of the jump label or name of a subprogram.   |
| <b>state</b>          | logic state, options: ON or OFF, or 1 or 0  |
| <b>timeout</b>        | amount of time within which something has to happen, or a delay time (constant or variable)   |
| <b>position</b>       | coordinates of the position (double constant or double variable)  |
| <b>radius</b>         | value of the radius (double constant or double variable)  |

|                         |   |
|-------------------------|---|
| <b>angle</b>            | value of the angle (double constant or double variable)   |
| <b>numrev</b>           | number of revolutions (double constant or double variable)  |
| <b>speed</b>            | value of speed (float constant or float variable)   |
| <b>direction</b>        | clock or anti clockwise rotation (variable or constant: CW o CCW)   |
| <b>operand</b>          | (constant o variable o devicename)  |
| <b>result</b>           | result of the operation (variable or devicename)  |
| <b>devicename</b>       | name of any type of device (or device parameter)  |
| <b>constantstr</b>      | sequence of characters in inverted commas (ex. "string")  |
| <b>variablestr</b>      | the name of a character vector, namely a string   |
| <b>operator</b>         | comparison operators:<br>> (greater than)<br>= (equal to)<br>< (less than)<br><br>they can also be used in combination, for ex. >= (meaning: greater or equal to) |
| <b>type</b>             | type of constant or variable:<br>"char" (8 bit), "integer" (32 bit), "float" (32 bit), "double" (64 bit), "string"  |
| <b>device parameter</b> | is a variable that stands for a device. The devices are defined in Configuration.   |

## Main terms used for axes

|   |  |
|---|--|
| <b>theoretical position (or target)</b> | Current "theoretical" position set, second by second, by the numerical control on the basis of the algorithm of speed profile generation.  |
| <b>real position</b>                    | Real position of the axis as detected by the position transducer. The difference between the real position and the theoretical position is known as "tracking error" or "loop error".  |
| <b>final position</b>                   | It corresponds to the programmed arrival position of a movement. The calculation algorithm of the speed profile enables the theoretical position to reach exactly the final value.   |
| <b>arrival position window</b>          | Programmable interval whose central point corresponds to the final theoretical position: when the real position enters this area, the movement is considered concluded.  |
| <b>arrival position big window</b>      | Position arrival window multiplied by a factor to be set by means of the instruction SETBIGWINFACTOR.  |
| <b>loop error</b>                       | The difference, second after second, between the theoretical position and the real position of an axis: it is usually proportional to translation speed and inversely proportional to the "proportional loop gain".                                    |
| <b>proportional [loop] gain</b>         | Axis regulation parameter, programmable: it determines the ratio between current speed and relative loop error.  |
| <b>feed forward</b>                     | Axis regulation parameter, programmable: it determines a direct contribution (proportional to programmed speed) injected on the drive speed control. It allows you to reduce, at equal speed and equal proportional gain, the value of the loop error. |
| <b>feed rate override</b>               | Percentage of programmed speed. This parameter allows you to reduce execution speed, compared to programmed speed, by a percentage ranging between 0% and 100%.  |
| <b>tolerance</b>                        | Move value according to which the axis moves away from the original trajectory in a multi-axis interpolation between two consecutive blocs of displacement.  |
| <b>backlash</b>                         | Space between the cogs of a couple of gears.   |



## 9.1.2 Introduction to GPL language

GPL language (General Purpose Language) is the language used to create functions in the Albatros system.

Although its structure, for some aspects, is similar to BASIC, it is characterised by a large number of device control instructions.

The language is composed of more than 200 instructions, called *instruction*, which have been divided into groups of instructions with similar functions, for your convenience.

Moreover, the language is multitasking, allowing the execution of various tasks at the same time.

### **Typical Syntax of GPL instructions**

GPL instructions all have a similar structure, corresponding to the following pattern:

**instructionname** parameter-1, parameter-2, ..... parameter-N

The number of parameters depends on the instruction and the context in which it is used, the absolute maximum parameters number for a function or an instruction is 120. In certain cases the instruction may not contain any parameters at all.

The smallest block of GPL code is the function.

### **Dividing the code into groups**

The GPL code is subdivided into blocks that reflect the logic subdivision of the machine into groups. This means that each group has a corresponding file containing its code. To these files, containing the code of the groups present in the machine, we must add the file containing the global variables and constants which are visible from any group's GPL code and the libraries. These contain code not related to machine configuration hence easily portable to other machines.

## 9.1.3 Variables

Variables are information containers which in the GPL language are used to store all the values necessary for program functioning.

Variables are characterised by a "type" that indicates the kind of information they contain. Moreover each variable has a specific visibility which determines which code groups or subgroups can operate (read or write) on it.

### **Type of data**

#### **SIMPLE OR SCALAR DATA**

GPL supports both simple and aggregate data. The types of simple data are similar to the ones used in most programming languages:

#### **Char**

Is an integer with sign ranging between [-128 ; +127] and its length is 1 byte.

To declare a Char variable, the following syntax is used:

VariableName as char

#### **Integer**

Is an integer with sign ranging between [-2147483647 ; +2147483647] and its length is 4 byte (it corresponds to the long type in C).

To declare an Integer variable, the following syntax is used:

VariableName as integer

#### **Float**

Is a floating point number ranging between [-3,402823 E+38 ; -1,401298 E-45] and [+1,401298 E-45 ; +3,402823 E+38], its length is 4 byte (it is usually used to indicate speed).

To declare a Float variable, the following syntax is used:

VariableName as float

### Double

Is a floating point number ranging between [-1,79769313486231 E+308 ; -4,94065645841247 E-324] and [4,94065645841247 E-324 ; 1,79769313486231 E+308], its length is 8 byte (it is usually used to indicate positions)

To declare a Double variable, the following syntax is used:

VariableName as double

These types of data can be used together in one expression. The GPL converts them automatically without giving any warning messages. For this reason, when using different types of data in the same expression, it is advisable to check that no information has gone lost.

In certain situations conversion is not allowed. In this case the compiler usually sends an alert message or a system error occurs.

## AGGREGATE DATA

### Array

It is a group of simple variables, all of the same type, obtained by associating an index to the name of the variable. The index must be enclosed in square brackets. If the array is called, for example, "parameters", the first item of the group will be called "parameters[1]", the second "parameters[2]", and so on.

The array has a fixed number of items which must be determined in the declaration. A typical array declaration uses the following syntax:

parameters[10] as integer

Where *parameters[10]* indicates that the name of the array is "parameters" and that it's composed by 10 items; *as integer* indicates the type of simple data used for the array's individual elements, which in this case is an integer.

The arrays can be made up of simple data or strings.

An array can have a maximum of 262144 elements.

Vectors can be directly initialized in the GPL code, at the time of their declaration. GPL syntax can be:

```
[READONLY] vector[numberofrows] as integer = 1,2,3,4
```

```
[READONLY] vector[numberofrows] as string = "one","two","three","four"
```

### Matrixes

Matrixes are bidimensional arrays, that is, variables with two indexes. A matrix can be visualized as a table divided into rows and columns. To indicate a cell on the table, we can indicate in which row and which column it is. The first index indicates the number of the row and the second the number of the column.

Unlike arrays, matrixes can contain different types of data, but with the following restriction: we may use a different type of simple data for each column but it is not possible to vary within the column.

For example we can define a matrix in which the first column is integer type and the second is float type. However we can not have a matrix where the first row is occupied by an integer and a float and the second by a char and a double. In the rows, the elements must all be composed by the same type of data.

The declaration of a matrix can be written using the following syntax:

offset[10] as double double double

dim\_part[50] as float:length float:width float:thickness

In the second type of declaration a label or symbolic name is given to each column. The symbolic names of the columns are very useful when working with large matrixes, as in this kind of situation it is difficult to remember the values memorised inside each column of the matrix. The symbolic name allows us to identify immediately the type of data we are working with. For ex. "Offset[1][3]" is not as clear as "Offset[1].axis\_X".

Matrixes can only contain simple data. For example, it is not possible to create matrixes containing strings. The maximum number of rows in a matrix is 262144.

Matrices can be directly initialized in the GPL code, at the time of their declaration. GPL syntax can be:

```
[READONLY] matrixname[numberofrows] as double double integer double = _
```

```
1.1, 2.2, 3, 0.1 _
```

```
1.2, 3.4, 5, 0.1 _
```

2.1, 5.6, 6, 0.1

**Strings**

Strings are groups of characters, that is char data. However, because they represent legible text, they are treated in a special way.

A string is very similar to a char array. The main difference is given by the presence of a terminating character, which is automatically added at the end of the string. The GPL also provides some macros which allow you to manipulate the strings.

Usually strings are used to write messages, which the user can read on the screen or in a report file. To declare a String variable, the following syntax is usually used:

VariableName as String

To declare a String variable, the following syntaxes may be used:

VariableName as String

VariableName[20] as String

In the first declaration the string assumes a default size of 256 characters. In the second case a maximum string size is defined.

**Data conversion**

In all mathematical expressions, but EXPR instruction, the types of data of the operands are converted according to the type of data of the result variable and then the operation is executed. It is important to pay attention to the declaration of types of data, because they can influence the result. Following table is an example of how the results based on the type of data given may change:

|     |                    |                   |                 |
|-----|--------------------|-------------------|-----------------|
| DIV | Operand 1(Integer) | Operand 2(Double) | Result (char)   |
|     | 3                  | 5.0               | 0               |
|     | 5                  | 1.9               | 5               |
|     | 1200               | 107.2             | Undefined       |
|     | 1200               | 250.0             | Undefined       |
| DIV | Operand 1(Double)  | Operand 2(Double) | Result (Double) |
|     | 3                  | 5.0               | 0.6             |
|     | 5                  | 1.9               | 2.631           |
|     | 1200               | 107.2             | 11.194          |
|     | 1200               | 250.0             | 4.8             |

In the EXPR instruction, if the operands are not of the same type, an automatic conversion is carried out and the type of the result of the operation is the same as the greater one of the two results, according the following rule:

- char < integer
- float < double
- char or integer < float or double.
- 

After resolving the expression, the result is converted according to the type of the result variable.

|             |                          |                             |                            |                         |
|-------------|--------------------------|-----------------------------|----------------------------|-------------------------|
| <b>EXPR</b> | <b>Operand 1(Double)</b> | <b>+ Operand 2(Integer)</b> | <b>/ Operand 3(Float)</b>  | <b>Result (Integer)</b> |
|             | 900.0                    | + 100                       | / 400.0                    | 900                     |
| <b>EXPR</b> | <b>Operand 1(Double)</b> | <b>+ Operand 2(Integer)</b> | <b>/ Operand 3 (Float)</b> | <b>Result (Double)</b>  |
|             | 900.0                    | + 100                       | / 400.0                    | 900.25                  |

## Declaration and Visibility of the variables

Variables and constants can only be declared in specific parts of the GPL code.

We can classify as variables:

- Module globals
- Group globals
- Locals (variables only)
- Library globals

A maximum of 2048 variables (module and group) can be declared.

It is possible to define some *modifiers* that assign additional characteristics to the variables.

### Module global variables

Module global variables are grouped in a special file which is accessed by selecting the heading

**Menu->File->Open Global Variables.**

The declaration is performed, as shown in previous paragraphs, by specifying the name of the variable, followed by the keyword "AS", followed by the type of data (or types of data in the case of matrixes).

These variables are visible directly from the code of all the groups.

### Group global variables

Group global variables are defined at the beginning of the group code. They must be declared before the GPL functions.

These variables are directly visible from the integer code inside the group. Moreover it is possible to extend the visibility of these variables outside the group by declaring them as "Public" variables.

Public variables are not directly accessible from outside the group. To access them, we have to use their name preceded by the name of the group they belong to. For example, if we want to modify the "offset" public variable, belonging to the "axes" group, from the code of the "main" group, we will write "SETVAL 10 axes.offset".

To declare a group global variable, the same syntax used for module global variables is used. The main difference lies in the definition of public variables. To define one or more public or private variables use the labels "Public" and "Private". For example:

```
Public:
  offset as double
  speed as float
Private:
  tool as integer
```

### Local Variables

Local variables are declared in the body of a function. They must be declared before any other instruction, except for the declaration of the function's parameters.

Local variables are only accessible from inside the function.

These variables are created with a 0 value (the necessary memory is allotted) only at the beginning of function execution and are destroyed (the memory is released) at the end of execution. Global variables, on the other hand, are created when the module is initialized and are always visible in "Diagnostic".

The declaration of a local variable uses the syntax we have already seen, but is preceded by the keyword "LOCAL".

For example:

```
Function processing
local position_centre_ as double
movabs X,position_centre
fret
```

### Library global variables

Library global variables are declared in GPL code libraries. They are similar to group global variables.

## Modifiers

### Modifiers: READONLY

Module and group global variables can be declared as READONLY.

A readonly variable is a variable whose value can not be modified by the GPL code, although it can

be modified from "outside", that is by Albatros's technological parameters file. The technological parameters file is a database which stores the values that characterize the machine but could vary in the long term if the machine were modified or in case of extraordinary maintenance. This data is normally inserted in a GPL matrix during control initialization.

An example of this type of information are the machining area offsets or the dimensions and technological parameters of the tools.

By declaring these variables as readonly we avoid accidental modifications of the information which shouldn't vary during normal machine functioning.

The maximum size of a readonly variable is 128 Kbyte.

To declare a readonly variable, the following syntax is used:

`readonly VariableName as type`

**Modifiers: NONVOLATILE**

Variables declared as NONVOLATILE class are memorized on the non volatile RAM (provided with batteries) instead of the normal RAM. Consequently the values stored in these variables are not lost when the numerical control is switched off.

For the declaration of a nonvolatile variable, the following syntax is used:

`nonvolatile VariableName as type`

For example:

`nonvolatile OffsetArea[2] as double:offsetX double:offsetY double:offsetZ`

Only group and machine global variables can be classified as "nonvolatile".

The maximum size of variables memorized on nonvolatile RAM is 15100 byte. The maximum size of a single non volatile matrix is 1024 byte.

**Assigning a RANGE**

When formulating a declaration it is possible to assign a range of values to the variable. However, at the moment, there is no control of limits observance in execution phase, except for a compiler control in the case of constant values (for ex. to initialize the variable).

Consequently, the main advantage is constituted by a sort of code auto documentation.

For the definition of ranges, the following syntax is used:

`VariableName Range:minval..maxval AS type`

For example:

`ToolNumber Range:1..100 as integer`

**Writing and Reading Rights**

Writing and reading rights allow you to specify the minimum access level to the system, necessary to display (read right) and modify (write right) its value.

The syntax used is:

`VariableName Read=S Write=M AS type`

The keywords used to specify the rights are:

- READ reading
- WRITE writing

The values which can be assigned are:

- U or USER user
- S or SERVICE service
- M or MANUFACTURER manufacturer
- T or TPA tpa

The values' defaults are:

- READ reading for service (S or SERVICE)

- WRITE writing for manufacturer (M or MANUFACTURER) and tpa (T or TPA )

## Constants

### Constants

GPL uses four types of constants:

- Integer
- Double
- Char
- String

Char constants are declared by using inverted commas, as below:

```
Const COD = 'A'
```

String constants are declared by using inverted commas, as below:

```
Const MSG = "Start processing"
```

For Integer constants and Double constants the following syntax is used:

```
Const PI = 3.14
Const MSGBOX = 12
```

For Integer constants a binary and hexadecimal notation is allowed:

```
Const MASK = $11001001b ; binary
Const MASK = $F5h ; hexadecimal
```

Also group and library constants can be public or private. The syntax is similar to variables' one.

Example:

```
Public:
Const PI = 3.14
Const MSGBOX = 12
Private:
Const MASK = $11001001b
```

**NOTE:** Float constants do not exist. Decimal numbers must necessarily be declared as Double. In certain cases this might cause alert messages from the compiler (when optimized GPL macros are used for Float types).

The constants can be defined as the result of calculation expressions, with the following syntax:

```
Const a = 10
Const b = 20
Const c = a + b
```

Permitted operators are the same as those used in the EXPR instruction.

### 9.1.4 Predefined constants

The GPL language has some predefined constants, which can be used directly without having to define them.

The predefined constants and their respective values are:

|                 |           |
|-----------------|-----------|
| <b>ON</b>       | <b>1</b>  |
| <b>OFF</b>      | <b>0</b>  |
| <b>UP</b>       | <b>+1</b> |
| <b>DOWN</b>     | <b>-1</b> |
| <b>POSITIVE</b> | <b>+1</b> |
| <b>NEGATIVE</b> | <b>-1</b> |
| <b>CW</b>       | <b>1</b>  |
| <b>CCW</b>      | <b>0</b>  |

|            |   |
|------------|---|
| TRUE       | 1 |
| FALSE      | 0 |
| NOWAIT     | 0 |
| WAIT       | 1 |
| WAITACK    | 2 |
| STORE      | 1 |
| NOSTORE    | 0 |
| NOPLACE    | 0 |
| COM1       | 0 |
| COM2       | 1 |
| COM3       | 2 |
| COM4       | 3 |
| COM5       | 4 |
| COM6       | 5 |
| COM7       | 6 |
| COM8       | 7 |
| NOPARITY   | 0 |
| ODDPARITY  | 1 |
| EVENPARITY | 2 |

### 9.1.5 Keywords

Keywords are identifiers with a specific function and can not be used in any other way.

Available keywords are:

- All the names of GPL instructions** See the "Instructions" part of the manual for the description of all GPL instructions
- All kinds of data** See Variables
- Device parameters** See Device parameters
- EXIST** Used in IFDEF instructions to verify the existence of a group. See IFDEF instruction
- NOTEXIST** Used in IFDEF instructions to verify the non existence of a group. See IFDEF instruction
- LINKED** used in the IFDEF instruction to enable the compilation of code blocks, if the device is connected in virtual-physical. See IFDEF instruction.
- UNLINKED** used in the IFDEF instruction to enable the compilation of block codes, if the device is not connected in virtual-physical See IFDEF instruction.
- \_ID\_MODULE** Used in the IFDEF instruction to verify the current module number. See the instruction IFDEF
- \_REMOTE\_MODULE** Used in the IFDEF instruction to verify if the connected module is a remote module (value=1). See instruction IFDEF
- \_VER\_MAJOR** Used in IFDEF instruction to verify the main version number of Albatros. See instruction IFDEF
- \_VER\_MINOR** Used in the IFDEF instruction to verify the secondary version number of Albatros. See instruction IFDEF
- \_VER\_REVISION** Used in the IFDEF instruction to verify the revision number of Albatros. See instruction IFDEF
- \_VER\_SP** Used in the IFDEF instruction to verify the service pack of Albatros .See instruction IFDEF

|                     |  |
|---------------------|--|
| <b>_VER_FULL</b>    | Used in the IFDEF instruction to verify the service pack of Albatros. See instruction IFDEF                                    |
| <b>FUNCTION</b>     | Declaration of a function. See Functions   |
| <b>AS</b>           | Used for variable declarations. See Variables  |
| <b>PUBLIC</b>       | An attribute of functions. See Functions   |
| <b>AUTORUN</b>      | An attribute of functions. It indicates that the function runs automatically. See Functions                                    |
| <b>R= o READ</b>    | An attribute of functions or variables. It indicates the read access level. See Functions, Variables and Access rights         |
| <b>W=o WRITE</b>    | An attribute of functions or variables. It indicates the write access level. See Functions, Variables and Access rights        |
| <b>CONST</b>        | It allows you to assign a significant name, called symbolic constant, instead of a number, character or string. See Variables  |
| <b>READONLY</b>     | An attribute of global variables. See Variables  |
| <b>NONVOLATILE</b>  | An attribute of global variables. See Variables  |
| <b>PRIVATE</b>      | An attribute of functions. See Functions   |
| <b>RANGE</b>        | Used for the definition of an interval of values for variables. See Variables  |
| <b>USER</b>         | An attribute of functions or variables. It indicates the type of access. In this case user. See Functions or Variables         |
| <b>SERVICE</b>      | An attribute of functions or variables. It indicates the type of access. In this case service. See Functions or Variables      |
| <b>MANUFACTURER</b> | An attribute of functions or variables. It indicates the type of access. In this case manufacturer. See Functions or Variables |
| <b>TPA</b>          | An attribute of functions or variables. It indicates the type of access. In this case TPA. See Functions or Variables          |

### 9.1.6 Functions

Functions are the smallest block of GPL code. GPL instructions can not be inserted in a file in sequence, they have to be grouped in functions.

As far as the compiler is concerned, a function is any block of GPL code beginning with a line whose first word is FUNCTION. However, there is no keyword indicating the end of the text of a function: the function ends with the line preceding the beginning of another function or with the end of the file containing the functions.

The syntax used to define a function is:

```
FUNCTION  FunctionName Attributes  
           Parameters  
           Local Variables  
           List of GPL instructions
```

A function is also a special type of Albatros device. As a device, it is characterised by a series of properties common to all devices: a univocal name (untranslatable), a descriptive name (which can be



translated, although it can not be set in GPL text), a logic address, a visibility indicator (whether the device is public or not), an access rights for reading and an access level for writing (see next paragraph).

**Access rights**

Because functions are a special kind of device, they are subject to access rights like all other devices. Access rights allow you to specify the minimum access level to the system necessary to allow visibility (read right) and execution (write right).

The syntax used is the following:

```
Function      FunctionName  READ=S WRITE=M
```

The rights are identified by the keywords READ (reading) and WRITE (execution) Assignable values, corresponding to the various access levels, are:

- U or USER            user
- S or SERVICE        service
- M or MANUFACTURER    manufacturer
- T or TPA             tpa

The values' defaults are:

- READ    reading for service (S or SERVICE)
- WRITE    writing for manufacturer (M or MANUFACTURER) and tpa (T or TPA )

**Autorun Functions**

Autorun functions are executed automatically when the machine is booted. Autorun functions have a characteristic: they are restarted automatically after being closed down because of a system error.

The syntax used is the following:

```
Function      FunctionName  autorun
```

So it is sufficient to add the modifier "autorun" to the declaration of the function.

**Public Functions**

Normally a function can only be executed (called) by the code inside the group file. To make it possible for a function to be executed by the GPL code of a different group, it must be defined as **public**. The syntax used to define a public function is the following:

```
Function      FunctionName  public
```

So it is sufficient to add the modifier "public" to the declaration of the function. Functions belonging to the intergroup are an exception, as they are always **public**.

**Subgroup Functions**

A function can be connected to a subgroup simply by putting the name of the subgroup in front of the name of the function. The subgroup and the function's name must be separated by a full stop ".". For example the following function belongs to "X" subgroup of the "Axes" group.

```
Function      X.homing
local         vel as float
movabs X,100
waitstill X
Fret
```

**Asynchronous Functions**

Asynchronous functions are automatically called by the numerical control when the event connected to the function takes place.

Three types of events are possible:

- Change of state of a digital input: instruction ONINPUT
- Change of state of a flag bit or flag switch: instruction ONFLAG
- System error: instruction ONERRSYS

When the event takes place, the function is called (not as autonomous task but in the context of the task in which the corresponding ON... instruction was executed) as implicit FCALL, as soon as the current instruction has terminated execution.

Typically, asynchronous functions are used to resolve emergency situations, and they must be extremely

fast. For this reason, these functions can't use just any GPL instruction; they use a subgroup which guarantees short execution times.

### **Functions with input parameters (parametric)**

A function can have some parameters declared in input, without ever returning any values. These parameters can be considered as special local variables whose value is initialized externally the moment the function is executed. The parameters are indicated with the keyword PARAM and use the same syntax used for local parameters. The parameters must be listed in the first lines of the body of the function, before any other instruction and before the local variables.

There are two ways the parameters can be passed:

- **by value:** all simple data types are passed by value, that is CHAR, INTEGER, FLOAT and DOUBLE. Passing by reference means that a copy of the original value is created. Changes made to the parameter only have an effect in the context of the function.
- **by reference:** aggregate data types are passed by reference, that is ARRAY, MATRIXES and STRINGS. Passing by reference means using the source variable; consequently the changes made to the parameter have an effect in the context of the calling function. This characteristic can be exploited to send return values back to the calling function.

Typically a function is sent in execution with the instruction FCALL. If the concerned function is a parametric function, the list of values to be given to the parameters must be specified after the name. In the following example we find a parametric function executing a perforation operation. The coordinates of the centre of the hole and feed speed of the Z-axis are passed to the function as parameters.

```
Function Perforation
  Param Qx as Double      ; position X of the centre of the hole
  Param Qy as Double
  Param vel as Float      ; feed speed

  Movabs      X, Qx, Y, Qy
  Waitstill   X,Y
  ....
  Fret
```

This function call, for example to make a hole in the position (12.5 , 25.7), with a feed speed of 3m per minute, could be written in the following way:

```
Fcall  Perforation 12.5, 25.7, 3.0
```

The parameters passed to the function must match in name and type, those declared in the call function. The execution of the call function restarts at the end of the called function.

It is also possible to declare a device as a function parameter. This enables to write general use functions, such as a homing function, to be used with all the axes in the machine:

```
Function HOMING PUBLIC
  param  axis as Axis
  movabs axis,100
  Fret

Function MAIN
  ....
  Axes.Homing x
  Fret
```

The homing function belongs to the Axes group and is declared PUBLIC to allow it to be seen by the functions declared in other groups. The Main function calls the axes group homing function, specifying the axis which has to be moved as an input parameter.

## **9.1.7 Device parameters**

Device type parameters are special variables which allow you to call a machine device. This kind of data can be used **exclusively** in the declaration of function parameters. So it is not possible to declare variables of this type. The definition of names and other characteristics of the devices pertain to System Configuration. The following table contains the type of Device and the relative keywords to be used for the declaration of the parameters.

| <b>Type</b>    | <b>Keyword</b>               |
|----------------|------------------------------|
| Digital input  | INPUTDIG                     |
| Digital output | OUTPUTDIG                    |
| Analog input   | INPUTANALOG                  |
| Analog output  | OUTPUTANALOG                 |
| Axis           | AXIS                         |
| Timer          | TIMER                        |
| Counter        | COUNTER                      |
| Flag bit       | FLAGBIT                      |
| Flag switch    | FLAGSWITCH                   |
| Flag port      | FLAGPORT                     |
| Input port     | INPUTPORT                    |
| Output port    | OUTPUTPORT                   |
| Input Nibble   | INPUTNIBBLE                  |
| Output Nibble  | OUTPUTNIBBLE                 |
| Function       | FUNCTION (only for ONERRSYS) |
| Generic device | DEVICE (only for ONERRSYS)   |

Example of axis parameter declaration and use:

```

Function test
  Param axis as axis

  MovAbs axis,100
  WaitStill axis

Fret
    
```

### 9.1.8 Multitasking

As the system is multitasking, it is possible to have more than one GPL task in progress at the same time, and by task we intend the handling process of a logic entity (usually a group).

There are two types of task available: normal tasks and the most recent "Real-time Tasks".

#### Normal tasks

Multitasking is based on a cooperative algorithm based on priorities. This guarantees that all the tasks are executed cyclically, varying their priority. The scheduling algorithm ensures that one instruction is executed for each active task (running state). Every task has a priority set using the instruction SETPRIORITYLEVEL assigned to it. The priority is identified by a whole number between 0 (highest priority and 255 (lowest priority). For tasks with a priority of 0 (zero) an instruction is carried out every scheduling cycle, for tasks with a priority of 1 an instruction is executed every two scheduling cycles and so on up to tasks with a priority of 255 for an instruction is carried out every 256 scheduling cycles.

The execution of normal tasks is asynchronous with respect to the frequency of refresh of the axes. This means that there is no guarantee that a GPL function will be completed in the time span between two updates of the state of the axes.

A task is identified by the name of the GPL function from which its execution starts.

The execution of a task can begin:

- automatically with the initialisation of the system: main intergroup function and autorun functions.
- following the execution of a STARTTASK execution.
- Following the triggering of Albatros in manual mode using the graphics interface.

Each task is characterised by an internal state:

|                |   |
|----------------|---|
| <b>RUNNING</b> | The task is running                           |
| <b>HOLD</b>    | The task is suspended                         |
| <b>BREAK</b>   | The task has been interrupted by the debugger |

Tasks are organised hierarchically in a tree structure. Each task is created by another, which means that if the mother task finishes, all the child tasks will also be terminated. The maximum number of tasks in execution at the same time is 500.

It must be considered that an high number of running tasks implies a decrease in speed, at which every single task is performed.

If the application to be made is supposed to imply the use of a number of tasks higher than 200, the operator should use a proper hardware such as **Cn2128**.

### **Real-Time Tasks**

Real-time tasks differ from the foregoing in that they are not subject to a scheduling procedure nor are they arranged by priority, but are executed completely with each update of the state of the axes (axes real-time).

It is absolutely necessary for the execution of these tasks to end by a set time because the execution of the GPL tasks described earlier remains on hold while the real-time tasks are being run.

The system runs checks on the execution time of real-time tasks and should these exceed the maximum time allowed the system generates an error.

It is therefore not advisable to create infinite cycles (e.g. using GOTO instructions) within these tasks; cycles, moreover, are not necessary given that the execution of the code starts again from the beginning with each axes real-time task.

In order to avoid excessively long execution times real-time task use is limited to some GPL instructions. The instructions whose use is not allowed are those that cannot be used on interrupt.

We advise using real-time tasks only for those activities that must of necessity be carried out synchronously with the update of the axis positions. For most control activities it is better to use normal tasks.

Real-time tasks are sent with the instruction STARTREALTIMETASK and can be interrupted with the instruction ENDREALTIMETASK. Up to 256 real-time tasks can be activated at the same time. The tree structure is no longer applicable, so if the task creating a real-time task ends, the real-time task will still run.

The local variables declared in the realtime task are initialized only by the start of the task and then they maintain the value of the last run.

Real-time tasks are not characterized by states typical of normal tasks. A real-time task can be debugged, but when this happens the system automatically declasses the task to a "normal task" for the duration of the debug.

If a system error is detected in a real-time task, the task is declassified to a "normal task" and it is put on HOLD to allow it to be analysed with the debugger.

## **9.1.9 Communication**

Communications between the GPL and the outside world occur in three different ways:

- SEND / RECEIVE
- Serial communication
- IPC

### **Send / Receive**

The instructions SEND and RECEIVE implement a message-orientated communication mechanism. The communication may occur within the same module (of little advantage), between different modules of a line or between the modules and the supervisor Albatros or with OLE applications.

The way it works is similar to e-mails; for every message there is an addressee, an identifier of the information sent (or requested), the information itself plus the service information. Albatros performs the collect and sorting function of the information and in some cases directly supplies the information requested.

This mode of communication is normally used to send working programmes between the supervisor and the control units, to synchronize the activity of the machines of a line and to interface with external applications (OLE server).

### **Serial communication**

The GPL language supplies some instructions, for example, COMREAD and COMWRITE, that make it possible to send and receive data via the serial ports of the numerical control. It is thus possible to interface the control with external devices like inverters, terminals or PLCs. When correctly used these instructions make it possible to implement serial communication protocols like MODBUS-RTU etc.

### **IPC**

IPC or Inter Process Communication is a communication mode between processes. In particular, this mode allows an area of memory to be defined which is shared by two or more processes and can be

used for data exchange. Compared with other methods of communication, for example OLE, IPC is less sophisticated as there is no check on the data transmitted but it is substantially quicker.

Typically it is used when big quantities of data have to be transmitted or in general when the performances supplied by the OLE interface Albatros are not adequate.

On the GPL side IPC communication is implemented using the instructions SENDIPC, WAITIPC and TESTIPC. The external processes, however, may refer to the APIs supplied by RTX (an application written in C or C++) or to the COM component **gplipc2.dll** supplied by TPA S.p.A. which simplifies use (in particular for MS Visual Basic applications).

In addition, IPC makes it possible to communicate with other real-time processes (developed with RTX) and thus to integrate Albatros with hardware produced by third parties in the system.

For further information contact T.P.A. S.p.A.

### 9.1.10 Variables used in programming

Most instructions have been written so as to allow operating with various types of variables (CHAR, INTEGER, FLOAT, DOUBLE). However, each instruction has been optimised for a specific variable; for the best performance during GPL code execution, we advise using the type of variable suggested in the description of each instruction. In general, we suggest following the table below, which associates the main quantities used in programming to the relative optimal types:

| <i>quantity</i>             | <i>type</i>    |
|-----------------------------|----------------|
| position                    | <i>double</i>  |
| speed                       | <i>float</i>   |
| time                        | <i>double</i>  |
| counter                     | <i>integer</i> |
| value port / flag port      | <i>integer</i> |
| value nibble / BCD          | <i>integer</i> |
| timeout                     | <i>double</i>  |
| analog input / output       | <i>float</i>   |
| director cosines            | <i>double</i>  |
| string control character    | <i>char</i>    |
| acceleration / deceleration | <i>integer</i> |

### 9.1.11 Axes

The term "axis" normally indicates an electromechanical system whose function is the controlled movement of a part of a tool machine.

Describing this system from the point of view of its components, we can subdivide them according to their technological characteristics.

The mechanical components are:

- frame
- guides
- bearings
- screws + ball screws

whose function is to contrast the forces involved, reduce friction, turn rotational motion into translation motion, etc.


The electric and electronic components are:

- motor
- end run switches
- encoder
- tachimetric dynamo

whose function is to provide the necessary power for movement and detect the state of the system.

These elements are connected so as to allow controlled execution of movements.

Diagram of a retroactive control




The function of the numerical control is to control the position and the movement of the axes.

Axis movement can be broken up into 5 phases:

- Acceleration**    initial phase during which the speed of the axis is gradually increased, until it reaches programmed speed.
- Regime**            intermediate phase during which the axis moves at constant speed (this phase may be omitted if the space to be covered is smaller than the space covered in acceleration and deceleration phases).
- Deceleration**    phase during which the axis reduces its speed back to 0
- Window**            pause, while the loop error is reduced to the value indicated in configuration as "arrival position window"
- Position**            end of movement

At the end of the movement the axis will have to be positioned within an interval called "arrival position window" (that determines tolerance for axis positioning). If this is not done within 5 seconds of expected end of movement, the system generates a "movement not concluded" system error.



For each movement the numerical control calculates a speed profile like the one shown in the figure above. It then calculates the target positions by subdividing the speed profile in time intervals equivalent to axis refreshment time and calculating the area of each part. The area corresponds to the position increase which the axis has to reach in that space of time to comply with the above mentioned speed profile.

Axis control is implemented by means of a PID controller that "closes the position loop", meaning that, when the machine starts, it provides a speed reference calculated on the basis of the position that has to be reached (target position) and the real position read by the encoder. The difference between the real position and the target position is called **Loop Error**.




Diagram of Albatros axis control

### 9.1.12 Message handling in different languages

As said in the chapter describing the Composition of the System, Albatros supports the display of text messages in various languages.

This support is provided by a program independent of Albatros that manages the message files: Winmess.exe. Manufacturer is the minimum access level required to modify the language of the messages. Winmess reads the content of the language file and provides Albatros with the translation of the message in the selected language. It also handles language changes and memorizes the language selected by the user.

#### Text associated to Cycle Errors and Messages

Messages and Cycle errors are a special kind of text generated by the GPL code which are displayed by Albatros.

These are normally defined by the person who develops the GPS when writing the code itself. To simplify the programmer's work, the GPL editor allows you to insert the text of a message directly from Albatros, without having to use Winmess.

A second option for message handling in various languages is using the GPL DEFMSG instruction.

### 9.1.13 System Error Management

Whenever a system error occurs (See Chapter **System Errors->Introduction to System Errors**) the normal control behaviour is that of ending all tasks: the system error management allows you to avoid ending the tasks for which this function was enabled.

System errors generated by faults, stack underflow and stack overflow are directly managed by the relevant control without recalling the function of system error management: the task is placed in HOLD status.

#### Error Management Function

Within the GPL code, one or more functions should be defined to examine the system error and consequently to establish the most suitable actions to set the machine in safety conditions. The function to recall is passed as a parameter to the GPL ONERRSYS instructions. (See Chapter **GPL Language->Instructions->Flux management->ONERRSYS**).

Whenever a system error occurs, the task which generated this error is placed in HOLD status. In case the autorun tasks generate system errors, they are relaunched only if the system error is not a FAULT. If the system error is generated without task number, the current task is placed in HOLD status.

## 9.1.14 Special functions

### Axis movement customization

Albatros system graphical interface allows you to perform manual axis movements and provides a graphical tool for axis calibration.

Manual axis movement is performed by the manual movement control board, calibration may be performed by the calibration control board. Both can be accessed by the Diagnostic window and synoptic views.

In both cases axis movement is controlled by a set of GPL functions whose execution is hidden to the user.

The system has a predefined set of these functions which are adequate in most cases. Anyway in some cases may be necessary to customize the functions, for instance to define axes movement restrictions depending on to machine status or to manage auxiliary devices as drive brakes.

Customisation is performed by creation of two GPL function for each axis: one for the manual movements and one for the calibration. These functions are optional, if the system finds them uses them, otherwise standard ones are used. Furthermore a partial customization of the movement functions is possible.

### Manual axis movement

The customized *manual movement* functions must respect the following rules:

- The function must belong to the same subgroup of the referred axis.
- Function name must be **MoveAx#axis\_name** where axis\_name will be changed to the axis name as defined in Configuration. For instance X axis function name will be: MoveAx#X .
- The function must provide the following parameters:
  1. **Required action.** May be an absolute position movement, an incremental movement, a stop etc. Actions are identified by an integer number, the GPL compiler provides a predefined constant for each action:
 

|              |  |
|--------------|--|
| _MOVAXABS    | absolute position movement                                     |
| _MOVAXINC    | incremental movement   |
| _MOVAXSET    | position setting   |
| _MOVAXFREE   | free status setting  |
| _MOVAXNORMAL | normal status setting  |
| _MOVAXEND    | axis status reset after a movement (not used to stop the axis) |
  2. **Result.** Needed by the system to know whether the required action may be performed by the customized function. If the required action is not supported, the corresponding standard function is used. So this is a return value that the customized function has to set, therefore it is defined as a "by reference" parameter (one element array).
  3. **Speed.** Meaningful only when the required action is a movement, it is the required movement speed.
  4. **Position.** Meaningful only for movement and position setting actions.

Custom axis movement function example:

```
Function MoveAx#X
  param action as integer
  param result[1] as integer
  param speed as float
  param position as double

  setval      1,result[1]

  select action
  case _MOVAXEND
    fcall EndMovement
```



```

case _MOVAXABS
    fcall AbsMovement X, speed, position
case _MOVAXINC
    fcall IncMovement X, speed, position
case _MOVAXSET
    fcall PositionSet X, position
case _MOVAXFREE
    fcall FreeAxis
case _MOVAXNORMAL
    fcall NormalAxis
case else
    call Unknown
endselect

fret

Unknown:
    setval    0, result[1]
    ret

```

The EndMovement, AbsMovement, etc. functions (the names are not compulsory) should implement the customized management of the required actions. To ease the programmer's job standard movement functions are provided as a guide to develop customized ones.

### Calibration

The customized *calibration* functions must respect the following rules:

- The function must belong to the same subgroup of the referred axis.
- Function name must be **CalibAx#axis\_name** where axis\_name will be changed to the axis name as defined in Configuration. For instance X axis function name will be: CalibAx#X
- The function must provide the following parameters:
  1. **Required action.** May be a point-to-point movement or an interpolated movement.
  2. **Result.** Needed by the system to know whether the required action may be performed by the customized function. If the required action is not supported, the corresponding standard function is used.
  3. **Speed.** Calibration movement speed
  4. **Positive position.** Positive calibration movement position.
  5. **Negative position.** Negative calibration movement position.
  6. **Wait time.** Wait time between subsequent movements.

NOTE: please keep in mind that in some cases actions performed on the calibration control board cause the execution of the axis movement function. For instance at the end of a calibration movement (when the stop button is pressed) an axis status reset is performed calling the customized axis movement function with the "required action" parameter set to \_MOVAXEND. The same way when the axis position is modified in the calibration control board the axis movement function is called with the "required action" parameter set to \_MOVAXSET.

Custom axis calibration function example:

```

Function CalibAx#X
    param action as integer
    param result[1] as integer
    param speed as float
    param PosPosition as double
    param NegPosition as double
    param waitTime as float

    setval    1,result[1]

```

```

select action
case _CALAXPP
    fcall PPCalibration X, speed, PosPosition, NegPosition, _
        WaitTime
case _CALAXINT
    fcall IntCalibration X, speed, PosPosition, NegPosition, _
        WaitTime
case else
    call Unknown
endselect

fret

Unknown:
setval      0, result[1]
ret

```

The PPCalibration, IntCalibration etc. functions (the names are not compulsory) should implement the customized management of the required actions. To ease the programmer's job calibration standard functions are provided as a guide to develop customized ones.

### ***Interaction with the window of Manual axis movement***

Functions for interaction with the window of manual axis movement should comply with the following specifications:

- The function should be in the same sub-group which belongs to the reference axis
- The function name should be **MoveAx#axis\_name>Action** where name\_axis should be replaced with the axis name defined in the configuration and Action can assume one of the following definitions:

|          |  |
|----------|--|
| OPEN     | indicates that the user has just opened the movement axis window             |
| CLOSE    | indicates that the user is going to close the movement axis window           |
| ACTIVE   | shows that the movement axis window is active                                |
| INACTIVE | shows that the movement axis window is not active                            |
| JOG      | indicates that a shifting movement managed in runtime by the operator is set |
| STEP     | indicates that a shifting movement with an predefined pitch is set           |
| ABSOLUTE | indicates that a shifting movement with a determined position is set.        |

For instance, if the axis handling window for X-axes has been opened, the function named MoveAx#X#Open will be called.

### ***Modifying the Window of Manual axis movement***

It is possible to add up to 4 buttons to the axis movement window. Some GPL functions with fixed name MoveAx#NameaAsse#BUTTONtext should be defined in the same sub-group where the concerned axis is defined. NameAxis represents the concerned axis name and test represents the test, that will be displayed on the button. The test can contain the character '&' to introduce a keyboard accelerator. If the test begins with a number between 1 and 4, this number is considered as the position where the button will be inserted in the axis movement window. The button test can be translated, if a DEFMSG with MOVEAX#BUTTONtest as identifier is introduced into the group where the axis is. Pressing the customized button includes the execution of the associated GPL function. Any exiting function delay or any check of function's run start are not executed.

### **Standard calibration and movement functions**

Those shown below are standard functions used by manual movement and calibration control boards. The functions change depending on axis type: encoder reading, stepper, etc. The following functions may be customized.

### **Standard manual movement functions**

#### ***Absolute position movement***

```
; for stepper motor axes
```

```

Function AbsMovement
  param axisname as axis
  param speed as float
  param position as double

  ifstill      axisname goto move
  fret

move:
  setvel      axisname, speed
  movabs     axisname, position
  waitstill   axisname
  fret

```

```

; for all other kind of axis
Function AbsMovement
  param axisname as axis
  param speed as float
  param position as double

  iftarget    axisname goto move
  ifstill     axisname goto move
  fret

move:
  setvel      axisname, speed
  movabs     axisname, position
  waitstill   axisname
  fret

```

**Incremental movement**

```

; for stepper motor axes
Function IncMovement
  param axisname as axis
  param speed as float
  param position as double

  ifstill      axisname goto move
  fret

move:
  setvel      axisname, speed
  movinc     axisname, position
  waitstill   axisname
  fret

```

```

; for all other kind of axis
Function IncMovement
  param axisname as axis
  param speed as float
  param position as double

  iftarget    axisname goto move
  ifstill     axisname goto move
  fret

move:
  setvel      axisname, speed
  movinc     axisname, position
  waitstill   axisname
  fret

```

**Position setting**

```
; for encoder reading axes
```

```
Function PositionSet
```

```
  param axisname as axis
```

```
  param position as double
```

```
  setquote      axisname, position
```

```
  fret
```

```
; for stepper motor axes
```

```
Function PositionSet
```

```
  param axisname as axis
```

```
  param position as double
```

```
  ifstill      axisname goto set
```

```
  fret
```

```
set:
```

```
  setquote      axisname, position
```

```
  fret
```

```
; for all other kind of axis
```

```
Function PositionSet
```

```
  param axisname as axis
```

```
  param position as double
```

```
  iftarget     axisname goto set
```

```
  ifstill     axisname goto set
```

```
  fret
```

```
set:
```

```
  setquote     axisname, position
```

```
  fret
```

**Free status setting**

```
Function FreeAxis
```

```
  param axisname as axis
```

```
  free      axisname
```

```
  fret
```

**Normal status setting**

```
Function NormalAxis
```

```
  param axisname as axis
```

```
  normal      axisname
```

```
  fret
```

**Calibration standard functions****Point-to-point movements calibration**

```
; for stepper motor axes
```

```
Function PPCalibration
```

```
  param axisname as axis
```

```
  param speed as float
```

```

    param PosPosition as double
    param NegPosition as double
    param WaitTime as float

    setvel      axisname, speed
loop:
    movabs     axisname, PosPosition
    waitstill  axisname
    delay     WaitTime
    movabs     axisname, NegPosition
    waitstill  axisname
    delay     WaitTime
    goto      loop
    fret

; for all other kind of axis
Function PPCalibration
    param axisname as axis
    param speed as float
    param PosPosition as double
    param NegPosition as double
    param WaitTime as float

    setvel      axisname, speed
loop:
    movabs     axisname, PosPosition
    waitstill  axisname
    ifquotet   axisname,<>,PosPosition goto exit
    delay     WaitTime
    movabs     axisname, NegPosition
    waitstill  axisname
    ifquotet   axisname,<>,NegPosition goto exit
    delay     WaitTime
    goto      loop
exit:
    fret

```

### ***Interpolated movements calibration***

```

Function IntCalibration
    param axisname as axis
    param speed as float
    param PosPosition as double
    param NegPosition as double
    param WaitTime as float

    setveli    axisname, speed
loop:
    linearabs  axisname, PosPosition
    waitstill  axisname
    ifquotet   axisname,<>,PosPosition goto exit
    delay     WaitTime
    linearabs  axisname, NegPosition
    waitstill  axisname
    ifquotet   axisname,<>,NegPosition goto exit
    delay     WaitTime
    goto      loop

```

exit:  
fret

### Function OnUIEnd

The function "OnUIEnd#" is performed, if available, by Albatros before ending all the tasks in a module. The function must be defined in the file of intergroup functions. Maximum execution time of the function "OnUIEnd#" is 2 seconds, then Albatros will terminate all the tasks.

### Function OnUIPlugged#

The OnUIPlugged# function is executed, when you need to know, for instance, if Albatros, after switching on the plant, is informed of the remote module. This function must be defined within the intergroup.

### Function OnUIUnplugged#

Function "OnUIUnplugged#" is executed before ending the execution of Albatros (and so before Albatros disconnects from a module). This function must be defined within the intergroup. Albatros executes this function within max. 2 seconds.

During this time

- Cycle errors
- System errors
- Messages are read.

At the end of the execution, Albatros closes.

## 9.2 Instructions

### 9.2.1 Conventions

The following pages have been organized as files and contain, for each instruction:

- the *Syntax*
- a description of the *arguments*: type of data and admitted values
- a *Description* of functioning
- *Notes*
- *Examples*

All the instructions of the same type have been grouped together, to simplify learning and consultation.

### 9.2.2 Types of instructions in the GPL language

The language is composed of instructions that can be grouped as follows:

#### Instructions for Input/Output management

|                |  |
|----------------|--|
| GETFEED        | reads the override feed rate                       |
| GETVF          | reads the voltage/frequency converter              |
| INPANALOG      | reads an analog input                              |
| INPBCD         | reads a series of digital nibbles in BCD format    |
| INPFLAGPORT    | reads a flag port                                  |
| INPPORT        | reads a digital port                               |
| MULTIINPPORT   | reads up to 4 output ports                         |
| MULTIOUTPORT   | sets up to 4 output ports                          |
| MULTISETFLAG   | sets several flags on 1                            |
| MULTISETOUT    | sets several outputs on 1                          |
| MULTIRESETFLAG | sets several flags on 0                            |
| MULTIRESETOUT  | set several outputs on 0                           |
| MULTIWAITFLAG  | waits for the state of a flag bit or flag switch   |
| MULTIWAITINPUT | waits for the state of various inputs              |
| OUTANALOG      | modifies an analog output                          |
| OUTBCD         | modifies a series of digital nibbles in BCD format |

|                  |  |
|------------------|--|
| OUTFLAGPORT      | modifies a flag port                             |
| OUTPORT          | modifies a digital port                          |
| RESETFLAG        | sets a flag on 0                                 |
| RESETOUT         | sets an output on 0                              |
| SETFLAG          | sets a flag on 1                                 |
| SETOUT           | sets an output on 1                              |
| WAITFLAG         | waits for the state of a flag bit or flag switch |
| WAITINPUT        | waits for the state of an input                  |
| WAITPERSISTINPUT | waits for a persistent state of an input         |

## Instructions for Axes management

|                    |  |
|--------------------|--|
| CHAIN              | chains an axis to another  |
| CIRCABS            | absolute circular interpolation  |
| CIRCINC            | incremental circular interpolation   |
| CIRCLE             | makes a circle   |
| COORDIN            | coordinated axis movement  |
| DISABLECORRECTION  | disables the linear correction for the specified axis  |
| EMERGENCYSTOP      | forces an emergency stop of the axes   |
| ENABLECORRECTION   | enables the linear correction for the specified axis   |
| ENDMOV             | end of axis movement   |
| FASTREAD           | fast axis position read  |
| FREE               | sets the axis in free  |
| HELICABS           | absolute helicoidal interpolation  |
| HELICINC           | incremental helicoidal interpolation   |
| JERKCONTROL        | enables or disables interpolation movement control   |
| JERKSMOOTH         | links with acceleration and speed continuity, the speed profiles of the axis while contouring. |
| LINEARABS          | absolute linear interpolation  |
| LINEARINC          | incremental linear interpolation   |
| MOVABS             | absolute movement of axes  |
| MOVINC             | incremental movement of axes   |
| MULTIABS           | absolute multi-axis linear interpolation   |
| MULTIINC           | incremental multi-axis linear interpolation  |
| NORMAL             | disables axis free   |
| RESRIFLOC          | resets initial reference   |
| SETINDEXINTERP     | associates a variable for the counting of executed interpolation                               |
| SETLABELINTERP     | associates a variable for the identification of a displacement block                           |
| SETPFLY            | fly homing   |
| SETPFLYCHAINSTRAT  | enables control of slave axes behaviour for a master setpfly instruction                       |
| SETPZERO           | homing on zero   |
| SETPZEROCHAINSTRAT | enables control of slave axes behaviour for a master setpfly instruction                       |
| SETQUOTECHAINSTRAT | enables control of slave axis behaviour for a setquote instruction on the master               |
| SETRIFLOC          | set spacial reference points   |
| SETTOLERANCE       | sets the tolerance values for the linear interpolation   |
| START              | restarts axis movement   |
| STARTINTERP        | forces start of an interpolation   |
| STOP               | interrupts axis movement   |
| SWITCHENC          | allows replacing the encoder of an axis with that of another axis                              |
| SYNCRROOPEN        | opens a synchronized movement channel  |
| SYNCRROCLOSE       | closes the synchronized movement channel   |
| SYNCRROMOVE        | assigns a synchronized movement point  |
| SYNCRROSETACC      | sets the acceleration for synchronized movements   |
| SYNCRROSETDEC      | sets the acceleration for synchronized movements   |
| SYNCRROSETVEL      | sets the acceleration for synchronized movements   |
| SYNCRROSETFEED     | sets the axes speed for a synchronized movement  |
| SYNCRROSTARTMOVE   | starts processing a synchronized movement  |

## Instructions for the management of Timers and Counters

|            |                      |
|------------|----------------------|
| DECOUNTER  | decrements a counter |
| HOLDTIMER  | locks a timer        |
| INCOUNTER  | increments a counter |
| SETCOUNTER | sets a counter       |
| SETTIMER   | sets a timer         |
| STARTTIMER | starts the timer     |

## Instructions for Communications' management

|                  |   |
|------------------|---|
| CLEARRECEIVE     | empties the list of RECEIVE to satisfy    |
| COMCLEARRXBUFFER | empties inbox buffer of a serial port     |
| COMCLOSE         | closes a serial port                      |
| COMGETERROR      | reads the error code                      |
| COMGETRXCOUNT    | reads the number of bytes in inbox buffer |
| COMOPEN          | opens a serial port                       |
| COMREAD          | reads from the serial port                |
| COMREADSTRING    | reads a string from the serial port       |
| COMWRITE         | writes on the serial port                 |
| COMWRITESTRING   | writes a string on the serial port        |
| RECEIVE          | external data reception                   |
| SEND             | sends data from outside                   |
| WAITRECEIVE      | external data reception with standby      |

## Instructions for Mathematical management

|          |                                   |
|----------|-----------------------------------|
| ABS      | absolute value                    |
| ADD      | sum                               |
| AND      | AND binary                        |
| ARCCOS   | arc cosine                        |
| ARCSIN   | arc cosine                        |
| ARCTAN   | arc tangent                       |
| COS      | cosine                            |
| DIV      | division                          |
| EXP      | exponential                       |
| EXPR     | resolves mathematical expressions |
| LOG      | natural logarithm                 |
| LOGDEC   | base 10 logarithm                 |
| MOD      | module                            |
| MUL      | multiplication                    |
| NOT      | binary NOT                        |
| OR       | binary OR                         |
| RANDOM   | generates a random number         |
| RESETBIT | sets a bit on 0                   |
| ROUND    | rounds                            |
| SETBIT   | sets a bit on 0                   |
| SHIFTL   | rotates the bits to left          |
| SHIFTR   | rotates the bits to right         |
| SIN      | sine                              |
| SQR      | square root                       |
| SUB      | subtraction                       |
| TAN      | tangent                           |
| TRUNC    | truncation                        |
| TYPEOF   | type of the argument              |
| XOR      | binary XOR                        |

## Instructions for Multitask management



|                   |  |
|-------------------|--|
| ENDMAIL           | reports the end of the execution of a task                                       |
| ENDREALTIMETASK   | terminates a realtime task   |
| ENDTASK           | terminates a task  |
| GETPRIORITYLEVEL  | reads the priority level of the current task                                     |
| GETREALTIME       | returns time lapsed since the beginning of axis realtime                         |
| GETREALTIMECOUNT  | returns the number of RealTime lapsed  |
| HOLDTASK          | interrupts the execution of a task   |
| RESUMETASK        | resumes the execution of a task  |
| SENDIPC           | sends an IPC information   |
| SENDMAIL          | sends a command to the 'mail' mailbox  |
| SETPRIORITYLEVEL  | sets the priority level of the current task                                      |
| STARTREALTIMETASK | starts a realtime task   |
| STARTTASK         | starts the execution of a task   |
| STOPTASK          | stops the execution of a task and interrupts the movement of the associated axes |
| WAITIPC           | waits for an IPC information   |
| WAITMAIL          | receives a command from the 'mail' mailbox                                       |
| WAITTASK          | waits for a task to terminate  |

## Instructions for Matrix management

|          |  |
|----------|--|
| CLEAR    | sets variable, vector and matrix to zero                               |
| FIND     | searches for an element  |
| FINDB    | searches for an element in a vector or in a matrix increasingly ranged |
| LASTELEM | last element of a vector or of a matrix                                |
| LOCAL    | declaration of a local variable, vector, local matrix                  |
| MOVEMAT  | copies the row of a matrix in another                                  |
| PARAM    | declaration of a function parameter                                    |
| SETVAL   | changes a variable   |
| SORT     | sorts vector or matrix   |

## Instructions for Flux management

|             |   |
|-------------|---|
| CALL        | calls a subprogram  |
| DELONFLAG   | disables the emergency management on flag bit or flag switch  |
| DELONINPUT  | disables the emergency management on digital input            |
| ENDREP      | end of the block repetition with REPEAT                       |
| FCALL       | calls a function  |
| FOR         | extension of REPEAT   |
| FRET        | return from call to function                                  |
| GOTO        | jumps to a label  |
| IF          | test on a variable  |
| IFACC       | tests, if the axis is accelerating                            |
| IFAND       | test on AND operation   |
| IFBIT       | test on bits  |
| IFBLACKBOX  | tests if the record of the logical device activity is active. |
| IFCHANGEVEL | tests, if the axis is changing speed                          |
| IFCOUNTER   | test on a counter   |
| IFDEC       | tests if the axis is decelerating                             |
| IFDIR       | test on axis direction  |
| IFERRAN     | test on loop error  |
| IFERROR     | test on active cycle error                                    |
| IFFLAG      | test on a flag  |
| IFINPUT     | test on an input  |
| IFMESSAGE   | test on the active message                                    |
| IFOR        | test on OR operation  |
| IFOUTPUT    | test on an output   |
| IFQUOTER    | test on real position   |
| IFQUOTET    | test on real position   |
| IFRECEIVED  | test on data reception  |
| IFREG       | tests if the axis is in steady-state conditions               |
| IFSAME      | verifies that both arguments refer to the same data           |
| IFSTILL     | tests if the axis is still                                    |
| IFSTR       | test on a string  |

|            |   |
|------------|---|
| IFTARGET   | tests if the axis has reached the target  |
| IFTASKHOLD | tests if the parallel function is interrupted   |
| IFTASKRUN  | tests if the parallel function is running   |
| IFTIMER    | test on a timer   |
| IFVALUE    | test on a variable  |
| IFVEL      | test on axis speed  |
| IFWIN      | tests if the axis is in the window  |
| IFXOR      | test on XOR operation   |
| NEXT       | end of block repetition with FOR  |
| ONERRSYS   | sets the call to a function on a system error   |
| ONFLAG     | emergency in flag bit or flag switch  |
| ONINPUT    | emergency in digital input  |
| REPEAT     | repetition of an instruction block  |
| RET        | return from subprogram  |
| SELECT     | multiple selection with jump  |
| TESTIPC    | verifies the presence of an IPC information   |
| TESTMAIL   | test and reception of a command   |
| WAITACC    | waits for axis acceleration   |
| WAITCOLL   | waits for the axis to exceed a position from which it should start checking the presence of a collision |
| WAITDEC    | waits for axis deceleration   |
| WAITREG    | waits for the axis to be in steady-state conditions   |
| WAITSTILL  | waits for the final position to equal the target position   |
| WAITTARGET | waits for the axis to reach the target  |
| WAITWIN    | waits for the axis to be in the window  |

## Instructions for String management

|             |   |
|-------------|---|
| ADDSTRING   | chains two strings                            |
| CONTROLCHAR | sets a control character in a string variable |
| LEFT        | extracts the first characters                 |
| LEN         | reads the length of a string                  |
| MID         | extracts some characters                      |
| RIGHT       | extracts the last characters                  |
| SEARCH      | searches for a string                         |
| SETSTRING   | modifies a string variable                    |
| STR         | converts from number to a string              |
| VAL         | converts from string to number                |

## Instructions for axis Parameter management

|                    |   |
|--------------------|---|
| DYNLIMIT           | enables or disables dynamically the test on axis limit exceeding.                               |
| ENABLESTARTCONTROL | enables and sets the timeout to control the non-start up or the sudden stop of the axis         |
| DEVICEID           | writes the logical address associated to a device   |
| GETAXIS            | reads one or more data of an axis   |
| LOOKAHEAD          | sets the interpolation lookahead  |
| NOTCHFILTER        | sets the notch filter cut-off frequency for the specified axis                                  |
| RATIO              | sets the chaining ratio of a slave axis with respect to its own master                          |
| RESLIMNEG          | disables the negative limit of the axis   |
| RESLIMPOS          | disables the positive limit of the axis   |
| SETACC             | sets acceleration   |
| SETACCI            | sets the acceleration for interpolation   |
| SETACCLIMIT        | enables and disables the automatic calculation of the interpolation steady state speed          |
| SETACCSTRATEGY     | sets the type of acceleration   |
| SETADJUST          | sets the adjust of an axis  |
| SETAXPARTYPE       | changes the axis parameter set currently in use   |
| SETBACKLASH        | decreases or deletes the effects of the mechanical backlash on the axis trajectory              |
| SETBIGWINFACTOR    | modifies the multiplication factor for the calculation of the big window on the requested axis. |

|                 |  |
|-----------------|--|
| SETCONTORNATURE | sets the contouring angle  |
| SETDEC          | sets the deceleration  |
| SETDECI         | sets the deceleration for the interpolation  |
| SETDEADBAND     | sets the minimum voltage for the affected axis   |
| SETDERIV        | sets the coefficient of derived action   |
| SETDERIVI       | sets the coefficient of interpolation derived action   |
| SETDYNRATIO     | changes dynamically the chaining ratio during the movement of the master axis.   |
| SETFEED         | sets the point-to-point feed rate  |
| SETFEEDCOORD    | sets the percentage value of the highest instantaneous variation of the axis feed rate.  |
| SETFEEDF        | sets the feed forward  |
| SETFEEDFA       | sets the acceleration feed forward   |
| SETFEEDFAI      | sets acceleration feed forward in interpolation  |
| SETFEEDI        | sets feed forward in interpolation   |
| SETFEEDFI       | sets the feed forward in interpolation   |
| SETINDEXEN      | enables or disables on the axis the reset of the position that corresponds to the zero position reference                      |
| SETINTEG        | sets the coefficient of integral action  |
| SETINTEGI       | sets coefficient of interpolation integral action  |
| SETINTEGTIME    | it sets the number of loop error samples used to calculate the integral component  |
| SETIRMPP        | sets the speed of start ramp   |
| SETLIMNEG       | sets the negative limit of the axis  |
| SETLIMPOS       | disables the positive limit of the axis  |
| SETMAXER        | sets the highest tolerated tracking value  |
| SETMAXERNEG     | sets highest tolerated tracking value (negative direction)   |
| SETMAXERPOS     | sets highest tolerated tracking value (positive direction)   |
| SETMULTIFEED    | sets the percentage value of feed rate override of the affected axes   |
| SETOFFSET       | enables a position offset  |
| SETPHASESINV    | enables or disables on the affected axis the phase inversion   |
| SETPROP         | sets the coefficient of proportional action  |
| SETPROPI        | sets coefficient of interpolation proportional action  |
| SETQUOTE        | sets the position  |
| SETREFINV       | enables or disables on the affected axis the inversion of speed reference  |
| SETRESOLUTION   | changes the resolution if an axis  |
| SETSLOWPARAM    | changes the parameters to calculate the slowdown speed in the event that the slowdown functionality while contouring is active |
| SETVEL          | sets the speed   |
| SETVELI         | sets the interpolation speed   |
| SETVELILIMIT    | sets the individual components of the affected axis speed  |

## Various instructions

|                      |  |
|----------------------|--|
| CLEARERRORS          | deletes all the module cycle errors  |
| CLEARMESSAGES        | deletes all messages of the module   |
| DEFMSG               | defines a group message  |
| DELAY                | locks the current function for a period of time                                |
| DELERROR             | deletes ma previous cycle error  |
| DELMESSAGE           | deletes a previous message   |
| ERROR                | sends a cycle error to the PC  |
| IFDEF/ELSEDEF/ENDDEF | test for the conditional compilation   |
| MESSAGE              | sends a message to the PC  |
| SYSFAULT             | disables SYSOK signal  |
| SYSOK                | enables SYSOK signal   |
| WATCHDOG             | enables, updates, disables the whatchdog from GPL on the TMSWD hardware module |

## Instructions for SLM management

|                  |   |
|------------------|---|
| SLMCOMMAND       | executes a SLM command                      |
| SLMEEPROMDISABLE | execute an EEPROM writing disabling command |
| SLMEEPROMENABLE  | executes an EEPROM wiring enabling command  |
| SLMGETEEPROM     | reads an EEPROM memory location             |
| SLMGETPARAM      | reads a SLM parameter                       |
| SLMGETREGISTER   | reads a SLM register                        |
| SLMGETSTATUS     | reads a drive quantity                      |
| SLMSETEEPROM     | writes an EEPROM memory location            |
| SLMSETPARAM      | sets a SIM parameter                        |
| SLMSETREGISTER   | sets a SLM register                         |

## Instructions for CANopen management

|                |  |
|----------------|--|
| CANOPENDRIVER  | opens a CANopen communication canal  |
| CANCLOSEDRIVER | closes a CANopen communication channel   |
| CANRESETBOARD  | resets a CANopen board   |
| CANSETOBJECT   | writes a CANopen object  |
| CANGETOBJECT   | reads a CANopen object   |
| GETCNSTATE     | returns the NMT protocol state for the node of a CANopen board.                  |
| GETSDOERROR    | returns the last error occurred  |
| GETMNSTATE     | returns the status of the NMT protocol for the master node of the CANopen board. |
| SENDPDO        | writes the content of an asynchronous PDO  |
| SETNMTSTATE    | sets the status of the NMT protocol for the node of the CANopen board.           |
| RECEIVEPDO     | reads the content of an asynchronous PDO   |

## Instructions for Mechatrolink II management

|              |   |
|--------------|---|
| MECCOMMAND   | sends a command to the axis drive             |
| MECGETPARAM  | reads a parameter of the indicated axis       |
| MECSETPARAM  | writes a parameter in the indicated axis      |
| MECGETSTATUS | reads the values of STATUS, ALARAM and IO_MON |

## Instructions for Simulation

|                    |                                   |
|--------------------|-----------------------------------|
| ENABLE             | enables one or more axes          |
| ENABLEFORCEDINPUT  | enables the inputs to be forced   |
| DISABLE            | disables one or more axes         |
| DISABLEFORCEDINPUT | disables the inputs to be forced  |
| SETFORCEDINPUT     | forces an input to ON             |
| RESETFORCEDINPUT   | forces an input to OFF            |
| SETFORCEDBCD       | forces a nibble set in BCD format |
| SETFORCEDPORT      | forces an input port              |
| SETFORCEDANALOG    | forces an analog input            |

## Instruction for the "Blackbox" functionalities

|               |                                     |
|---------------|-------------------------------------|
| ENDBLACKBOX   | ends the record functionality       |
| PAUSEBLACKBOX | interrupts the record functionality |
| STARTBLACKBOX | starts the record functionality     |

## Instructions for Powerlink II and EtherCAT management

|           |                              |
|-----------|------------------------------|
| AXCONTROL | sets a value for ControlWord |
|-----------|------------------------------|

|                 |   |
|-----------------|---|
| ACTIVATEMODE    | sets an operating mode                      |
| AXSTATUS        | returns the value in the StatusWord         |
| CNBYDEVICE      | returns the EPL coordinates of a device     |
| <b>GETPDO</b>   | returns an object inside a PDO Ethercat     |
| HOMING          | searches the "zero position"                |
| READDICTIONARY  | reads the content of a dictionary object    |
| SETPDO          | sets an object inside a PDO Ethercat        |
| WRITEDICTIONARY | writes the content of the dictionary object |

## Instructions for ISO control

|               |  |
|---------------|--|
| ISOG0         | sets the rapid movement  |
| ISOG1         | sets the interpolated movement   |
| ISOG9         | sets the forced stop of the movement   |
| ISOG90        | sets the interpretation of the positions as absolute positions                         |
| ISOG91        | sets the interpretation of the positions as relative positions                         |
| ISOG93        | sets the interpretation as inverse of the time   |
| ISOG94        | sets the interpretation of the speed as unit of measure per minute                     |
| ISOG216       | defines the matrices for machine parametrisation                                       |
| ISOG217       | describes the physical axes and the virtual axes, which make up the machine            |
| ISOM2         | frees the axes free from ISO movement  |
| ISOM6         | selects the indices of parametrisation matrices  |
| ISOSETPARAM   | sets some parameters that characterize the fluidity of the ISO interpolation movement. |
| KINEMATICEXPR | sets the single expressions of inverse and direct kinematics                           |

### 9.2.3 Input/Output

#### GETFEED

##### Syntax

**GETFEED**                                 **variable**

##### Arguments

**variable**   feed rate

##### Description

It copies the value of the feed rate read from the remote I/O card, in the specified **variable**. Feedrate value is included between 0 and 100 and it is a percentage value.

It operates on an analog input which is not visible in configuration.

On a Albnt board this is the connector of the 4th axis (red) which, when the card has been appropriately configured, acts as an analog input (grey/greywhite wires).

For Cn2004 board the feed rate is managed by configuring the first analogical input AIN1. For all the other T.P.A boards controlling the feed rate a dedicated connector is available.

#### GETVF

##### Syntax

**GETVF**   **variable**

##### Arguments

**variable**   integer variable

##### Description

It reads the voltage/frequency converter value normally used to manage the feed rate override and puts the result in the specified **variable**. The read value interval ranges from 0 to 16000, which corresponds to an input voltage of 0 - 8 volts. For example the value 8000 corresponds to 4 volts.

## INPANALOG

### Syntax

**INPANALOG** **inpanalogname, variable**

### Arguments

**inpanalogname** name of analog input device  
**variable** variable

### Description

It copies the value of the analog input specified by **inpanalogname** in the specified **variable**.

## INPBCD

### Syntax

**INPBCD** **digitname1 [,digitname2, ... ], variable**

### Arguments

**digitname1** name of nibble device  
**variable** variable

### Description

It reads the input nibbles specified by the **digitname** arguments (from **1** to **4 max**). It reads each nibble as a number, where argument **digitname1** has the highest weight, and it sets the value of the number in the **variable**.

In practice it is used to read decimal numbers from physical devices which indicate them as groups of 4 inputs (nibble). The inputs of each nibble correspond to the bits necessary to represent the decimal number in the binary system.

## INPFLAGPORT

### Syntax

**INPFLAGPORT** **flagportname, variable**

### Arguments

**flagportname** name of flag port device  
**variable** variable

### Description

It copies the state of the flag port specified by **flagportname** in the specified **variable**.

The flag port is detected as a bit mask. A bit is associated to each flag of the port. If a flag is "ON", the corresponding bit is set on 1.

## INPPORT

### Syntax

**INPPORT** **portname, variable**

### Arguments

**portname** name of input port device  
**variable** integer or char variable

### Description

It copies the state of the **portname** input port in the specified **variable**.

The input port is detected as a bit mask. If the input of the port is "ON" the corresponding bit is set on 1.

## MULTIINPPORT

### Syntax

**MULTIINPPORT** **port1[,...,port4],variable**

### Arguments

**port1** provides the bits from 0 to 7  
**port2** provides the bits from 8 to 15  
**port3** provides the bits from 16 to 23  
**port4** provides the bits from 24 to 31  
**variable** integer variable receiving the input ports

**Description**

It reads no more than 4 output ports at the same time and writes them into a **variable**. Ports are read atomically. This procedure guarantees that the ports are read within the same real-time. Port1 corresponds to the lower byte, port4 corresponds to the greater byte.



**MULTIOUTPUT**

**Syntax**


**MULTIOUTPUT** value, portname1[,...,portname4]

**Arguments**

**value** number or integer value to be written in the output ports  
**portname1** receives the bits from 0 to 7  
**portname2** receives the bits from 8 to 15  
**portname3** receives the bits from 16 to 23  
**portname4** receives the bits from 24 to 31

**Description**

It writes the **value** into four output ports at the same time. Ports are read atomically. This procedure guarantees that the ports are written within the same real-time. If **portname2**, **portname3**, **portname4** are not specified, the value of the byte is 0.



**MULTIRESETFLAG**

**Syntax**

**MULTIRESETFLAG** mask, flagname1[, ..., flagname32]

**Arguments**

**mask** mask of involved flags - constant or variable  
**flagname1** name of flag device

**Description**

It disables, that is, it switches to "OFF", all the **flagnames** (1÷32), whose bit is set on 1 in the argument **mask**. The **mask** 0 bit (lowest weight) corresponds to **flagname1**.

**MULTIRESETOUT**

**Syntax**

**MULTIRESETOUT** mask, outputname1[, ..., outputname32]

**Arguments**

**mask** mask of involved outputs - constant or variable  
**outputname1** name of output device

**Description**

It disables all the **outputnames** (1÷32), whose bit in the argument **mask** is set on 1. The **mask** 0 bit (lowest weight) corresponds to **outputname1**.

## MULTISETFLAG

### Syntax

**MULTISETFLAG**                    **mask, flagname1[, ..., flagname32]**

### Arguments

**mask**                                  mask of involved flags - constant or variable  
**flagname1**                            name of flag device

### Description

It enables, that is, it switches to "ON", all the **flagnames** (1÷32), whose bit in the argument **mask** is set on 1. The **mask** 0 bit (lowest weight) corresponds to **flagname1**.

## MULTISETOUT

### Syntax

**MULTISETOUT**                    **mask, outputname1[, ..., outputname32]**

### Arguments

**mask**                                  mask of involved outputs - constant or variable  
**outputname1**                        name of output device

### Description

It enables all the **outputname** outputs (1÷32), whose bit in the argument **mask** is set on 1. The 0 bit of **mask** (lowest weight) corresponds to **outputname1**. If the output is a monostable output it is disabled automatically after 200 milliseconds.

## MULTIWAITFLAG

### Syntax

**MULTIWAITFLAG**                **mask, flag1[, ..., flag32], state [, timeout [, GOTO label]]**  
**MULTIWAITFLAG**                **mask, flag1[, ..., flag32], state [, timeout [, CALL**  
   **subprogramname]]**  
**MULTIWAITFLAG**                **mask, flag1[, ..., flag32], state [, timeout [, functionname]]**

### Arguments

**mask**                                  constant or variable. Mask of involved flags  
**flag1[,...flag32]**                name of flag device  
**state**                                predefined constant. Acceptable values are:  
   **ON** flag state: enabled  
   **OFF** flag state: disabled  
**timeout**                             constant or variable. Maximum wait time.  
**label**                                jump to label (GOTO)  
**subprogramname**                subprogram label (CALL)  
**ame**  
**functionname**                    name of function

### Description

It waits for the specified flags, from **flag1...flag32** to be in the state indicated by the **state** parameter (ON/OFF).

It checks all the flags whose bit in the argument **mask** is enabled (ON). The 0 bit of the argument **mask** (lowest weight) corresponds to the bit defined by **flag1**, the 1 bit corresponds to the bit defined by **flag2** and so on, up to the bit defined by **flag32**.

The **timeout** parameter allows you to set a different timeout from default timeout which waits one second.

When **label**, **subprogramname** or **functionname** are present, at the end of timeout the program jumps to **label** or calls **subprogramname** or **functionname**.



## MULTIWAITINPUT

### Syntax

```

MULTIWAITINPUT      mask, input1[, ..., input32], state [, timeout [, GOTO label]]
MULTIWAITINPUT      mask, input1[, ..., input32], state [, timeout [, CALL
                     subprogramname]]
MULTIWAITINPUT      mask, input1[, ..., input32], state [, timeout [, functionname]]
    
```

### Arguments

|                          |   |
|--------------------------|---|
| <b>mask</b>              | constant or variable. Mask of involved inputs   |
| <b>flag1[,...flag32]</b> | name of input   |
| <b>state</b>             | predefined constant. Acceptable values are:<br><b>ON</b> flag state: enabled<br><b>OFF</b> flag state: disabled |
| <b>timeout</b>           | constant or variable. Maximum wait time.  |
| <b>label</b>             | jump to label (GOTO)  |
| <b>subprogramname</b>    | subprogram label (CALL)   |
| <b>functionname</b>      | name of function  |

### Description

It waits for the specified inputs, from **input1...input 32** to be in the state indicated by the **state** parameter (ON/OFF).  
 It verifies all the inputs whose bit in the argument **mask** is enabled (ON). The 0 bit of the argument **mask** (lowest weight) corresponds to the bit defined by **input1**, the 1 bit corresponds to the bit defined by **input2** and so on, up to the bit defined by **flag32**.  
 If no optional arguments are specified, a second after the beginning of instruction execution (default time), the following parametrised message appears: "Wait inputn ON/OFF". The name of the indicated input corresponds to the first enabled input which still has not satisfied the state. If the **timeout** parameter is included, the above mentioned message will appear when the set timeout expires. If the requested condition takes place, when timeout has expired, a parametrised message will appear automatically to delete the previous one.  
 When **label**, **subprogramname** or **functionname** are present, at the end of timeout the program jumps to **label** or calls **subprogramname** or **functionname**

## OUTANALOG

### Syntax

```

OUTANALOG          outanalogname, value
    
```

### Arguments

|                      |                                      |
|----------------------|--------------------------------------|
| <b>outanalogname</b> | name of analog output device or axis |
| <b>value</b>         | constant or variable                 |

### Description

It sets the analog output or the axis indicated by **outanalogname** to the voltage specified by **value**.

## OUTBCD

### Syntax

```

OUTBCD             digitname1 [,digitname2, ... ], variable
    
```

### Arguments

|                  |                       |
|------------------|-----------------------|
| <b>digitname</b> | name of nibble device |
| <b>variable</b>  | constant or variable  |

### Description

In computing and electronic systems, binary-coded decimal (BCD) is a class of binary encodings of decimal numbers, where each decimal digit is represented by a binary code of four bits, whose value ranges from 0 (0000) to 9 (1001).

This instruction converts the decimal value contained in the **variable** to a sequence of numbers. Each digit is converted to the binary system and the bit mask thus obtained is set in the corresponding nibble. The digit with the highest weight is associated to the first nibble (**digitname1**).

**Example**

```
OUTBCD          nib1,nib2,nib3 234

; 4 in binary is 0100 and lights the third led of the nibble3
; 3 in binary is 0011 and lights the first and the second led of the
nibble2
; 2 in binary is 0010 and lights the second led of the nibble1
```

**OUTFLAGPORT****Syntax**

```
OUTFLAGPORT          flagportname, value
```

**Arguments**

|                     |                              |
|---------------------|------------------------------|
| <b>flagportname</b> | name of the flag port device |
| <b>value</b>        | constant or variable         |

**Description**

It copies the **value** in the flag port specified by **flagportname**. The **value** parameter is detected as a bit mask. Each bit is associated to a port flag. If the bit is set on 1 the flag is "ON".

**OUTPUT****Syntax**

```
OUTPUT          portname, value
```

**Arguments**

|                 |                                       |
|-----------------|---------------------------------------|
| <b>portname</b> | name of output port device            |
| <b>value</b>    | constant or variable, integer or char |

**Description**

It copies the **value** in the **portname** output port. The output port is detected as a bit mask. If the bit is set on 1 the corresponding output is on "ON".

**RESETFLAG****Syntax**

```
RESETFLAG          flagname
```

**Arguments**

|                 |                     |
|-----------------|---------------------|
| <b>flagname</b> | name of flag device |
|-----------------|---------------------|

**Description**

It disables (switches to OFF) the **flagname** flag.

**RESETOUT****Syntax**

```
RESETOUT          nameoutput
```

**Arguments**

|                   |                               |
|-------------------|-------------------------------|
| <b>nameoutput</b> | name of digital output device |
|-------------------|-------------------------------|

**Description**

It disables (switches to OFF) the **nameoutput** output.

**SETFLAG****Syntax**

```
SETFLAG          flagname
```

**Arguments**

**flagname** name of flag device

**Description**

It enables (switches to ON) the **flagname** flag.

**SETOUT**

**Syntax**

**SETOUT** **nameoutput**

**Arguments**

**nameoutput** name of digital output device

**Description**

It enables (switches to ON) the **nameoutput** output.  
 If the output is configured as monostable it is automatically disabled after a 200 millisecond timeout.

**WAITFLAG**

**Syntax**

**WAITFLAG** **flagname, state [, timeout [, GOTO label]]**  
**WAITFLAG** **flagname, state [, timeout [, CALL subprogramname]]**  
**WAITFLAG** **flagname, state [, timeout [, functionname]]**

**Arguments**

**flagname** name of flag device  
**state** predefined constant. Acceptable values are:  
**ON** flag state: enabled  
**OFF** flag state: disabled  
**timeout** constant or variable. Maximum wait time.  
**label** jump label (GOTO)  
**subprogramname** subprogram label (CALL)  
**functionname** name of function

**Description**

It waits for the flag **flagname** to be in the state indicated by the parameter **state** (ON/OFF).  
 If the only optional argument present is **timeout**, the cycle error "**flagname** flag awaiting **state**" is generated at end of timeout.  
 If the condition is satisfied after timeout expiry, the cycle error previously sent out for that task is automatically cancelled.  
 When **label**, **subprogramname** or **functionname** are present, at the end of timeout the program jumps to **label** or calls **subprogramname** or **functionname** without generating any automatic display.

**Note**

To avoid waiting for flags during work cycles, we suggest setting a timeout.

**WAITINPUT**

**Syntax**

**WAITINPUT** **nameinput, state [, timeout [, GOTO label]]**  
**WAITINPUT** **nameinput, state [, timeout [, CALL subprogramname]]**  
**WAITINPUT** **nameinput, state [, timeout [, functionname]]**

**Arguments**

**nameinput** name of input  
**state** predefined constant. Acceptable values are:  
**ON** flag state: enabled  
**OFF** flag state: disabled  
**timeout** constant or variable. Maximum wait time.  
**label** jump label (GOTO)  
**subprogramname** subprogram label (CALL)  
**functionname** name of function

**Description**

It waits for the **nameinput** input to be in the state indicated by the parameter **state** (ON/OFF). If no optional arguments are specified, the cycle error "**Nameinput** digital input awaiting **state**" is generated automatically 20 seconds after the beginning of instruction execution. If the only optional argument present is **timeout**, the above mentioned message is generated at the end of timeout. If the condition is satisfied after **timeout** expiry, the cycle error previously sent out for that task is automatically cancelled.

If **label**, **subprogramname** or **functionname** are present, when timeout expires the program jumps to **label** or calls **subprogramname** or **functionname** without generating any automatic display.

**Note**

To avoid having to wait for input signals during a work cycles, we suggest setting a shorter timeout than default time (20 seconds).

**Example**

Routine of Axis Homing

**WAITPERSISTINPUT****Syntax**

```

WAITPERSISTINPUT      nameinput, state, timepersist [, timeout [, GOTO label]]
WAITPERSISTINPUT      nameinput, state, timepersist [, timeout [, CALL
subprogramname]]
WAITPERSISTINPUT      nameinput, state, timepersist [, timeout [, functionname]]

```

**Arguments**

|                       |   |
|-----------------------|---|
| <b>nameinput</b>      | name of digital input device  |
| <b>state</b>          | predefined constant. Acceptable values are:<br><b>ON</b> flag state: enabled<br><b>OFF</b> flag state: disabled |
| <b>timepersist</b>    | constant or variable  |
| <b>timeout</b>        | constant or variable. Maximum wait time.  |
| <b>label</b>          | jump label (GOTO)   |
| <b>subprogramname</b> | subprogram label (CALL)   |
| <b>functionname</b>   | name of function  |

**Description**

It waits for the **nameinput** input to reach the state indicated by the parameter **state** (ON/OFF) and to remain in that state for the time specified in **timepersist** (unit of measure: seconds).

If no optional arguments are specified, the cycle error "**Nameinput** digital input awaiting **state**" is generated automatically 20 seconds after the beginning of instruction execution.

If the only optional argument present is **timeout**, the above mentioned message is generated at the end of timeout.

If the condition is satisfied after **timeout** expiry, the cycle error previously sent out for that task is automatically cancelled.

When **label**, **subprogramname** or **functionname** are present, at the end of timeout the program jumps to **label** or calls **subprogramname** or **functionname** without generating any automatic display.

**Note**

To avoid having to wait for input signals during work cycles, we suggest setting a shorter timeout than default time (20 seconds).

**9.2.4 Axes****CHAIN****Syntax**

```
CHAIN      master_axis, slave_axis1 [, ...slave_axis5]
```

**Arguments**

|                                  |   |
|----------------------------------|---|
| <b>master_axis</b>               | name of axis device functioning as master |
| <b>slave_axis1...slave_axis5</b> | name of axis device functioning as slave  |

**Description**

After executing this instruction, the **slave\_axes** (1÷5) will execute will execute movements linked to those of the master axis by the chaining ratio set with the **RATIO** instruction. Both point-to-point and interpolated movements will be chained.

**Slave\_axis1** is not an optional parameter, it must always be defined.

If a slave axis is to be chained, it can not be engaged in an interpolation and can not be master of other slaves.

In his turn, the master axis cannot be the slave of other axes.

Chaining can be carried out both with positioned axes and moving axes.

To disable axes chaining it is sufficient to execute the instruction **NORMAL** on the master axis. This last operation can be carried out both with axes in position and with axes in motion. When the chain is disabled while the axes are in motion, the slave gradually decelerates and stops.

A maximum of 8 master axes can be simultaneously defined.

The instruction can be performed also with step-by-step axes (stepper), as long as they can be controlled through **TRS\_AX**.

In addition, all the axes must have a real and not simulated encoder, otherwise the system error no. "4101 - Inconsistent axis AxisName management" is generated".

See also **RATIO**.

**Example**

```
CHAIN      X, Y      ; Y axis is chained to X
MOVINC    X, 100    ; X axis moves. Y axis replicate
           X         ; X axis movement
```

**CIRCABS**

**Syntax**

```
CIRCABS    [label],axis1, position1, axis2, position2, direction, ±radius [,
           angle]
```

**Arguments**

|                            |   |
|----------------------------|---|
| <b>label</b>               | constant or variable integer. Label identifying a displacement bloc   |
| <b>axis1, axis2</b>        | name of axis devices  |
| <b>positon1, position2</b> | constant or variable. It indicates the absolute move position   |
| <b>direction</b>           | integer variable. It specifies the kind of rotation. Acceptable values are:<br><b>CW</b> clockwise<br><b>CCW</b> anti clockwise |
| <b>radius</b>              | constant or variable. It indicates the value of the radius of the circle.   |
| <b>angle</b>               | constant or variable. It indicates the angle of the starting point  |

**Description**

2 axes circular interpolation with *absolute transfer* based on programmed positions: position1, position2.

The arch is determined by the starting point (current point), the final point, the value of the **radius** and the **direction**.

The sign applied to the **radius** allows you to select the minor arch (+radius) or the major arch (-radius).


In the rare case in which the starting position of axis1 coincides with **position1** final position and the starting position of axis2 coincides with the **position2** final position a complete circle is drawn. In this case it is necessary ti indicate the argument **angle**, having the same meaning as the instruction **CIRCLE** (to be referred to).

The angle parameter is necessary to determine precisely the centre of the circle, with the same meaning as the instruction **CIRCLE**. It is only used when, before instruction execution, **position1** and **position2** coincide with the current position of the axes.

The optional parameter **label** is used in association with the instruction **SETLABELINTERP** to indentify univocally the displacement bloc

Step-by-step axes can only be used in this instruction, if they are controlled by a **TRS-AX** remote.

In this case it must be taken into account that the word interpolation refers to a coordinated movement of more axes affected by discrete error due to axis piloting method.



## CIRCINC

### Syntax

**CIRCINC**

**[label],axis1, position1, axis2, position2, direction, ±radius [, angle]**

### Arguments

|                             |   |
|-----------------------------|---|
| <b>label</b>                | constant or variable integer. Label identifying a displacement bloc   |
| <b>axis1, axis2</b>         | name of axis devices  |
| <b>position1, position2</b> | constant or variable. It indicates the incremental move position  |
| <b>direction</b>            | integer variable. It specifies the kind of rotation. Acceptable values are:<br><b>CW</b> clockwise<br><b>CCW</b> anti clockwise |
| <b>radius</b>               | constant or variable. It indicates the value of the radius of the circle  |
| <b>angle</b>                | constant or variable. It indicates the angle of the starting point  |

### Description

2 axes circular interpolation with *incremental transfer* based on programmed positions **position1** and **position2**.


The arch is determined by the starting point (current point), the final point, the value of the **radius** and the **direction**.

The sign applied to the **radius** allows you to select the minor arch (+radius) or the major arch (-radius).

In the rare case in which position1 = position2 = 0, a complete circle is drawn. In this case it is necessary to indicate the argument **angle**, with the same meaning as the instruction CIRCLE (to be referred to).

The angle parameter is necessary to determine precisely the centre of the circle, with the same meaning as the instruction CIRCLE. The optional parameter **label** is used in association with the instruction SETLABELINTERP to identify univocally the displacement bloc.

Step-by-step axes can only be used in this instruction, if they are controlled by a TRS-AX remote. In this case it must be taken into account that the word interpolation refers to a coordinated movement of more axes affected by discrete error due to axis piloting method.



## CIRCLE

### Syntax

**CIRCLE**

**[label],axis1, axis2, direction, radius, angle**

### Arguments

**label** constant or variable integer. Label identifying a displacement bloc  
**axis1, axis2** name of axis devices  
**direction** integer variable. It specifies the kind of rotation. Acceptable values are:  
**CW** clockwise  
**CCW** anti clockwise  
**radius** constant or variable. It indicates the value of the radius of the circle.  
**angle** constant or variable. It indicates the angle of the starting point.

### Description


Complete circular interpolation.

It generates a circle with **axis1** and **axis2**, in the indicated direction, with the indicated **radius** and according to the set starting **angle**.

The **radius** can only have positive values.

The **angle** must be given according to the trigonometric convention, positive, clockwise, starting from the X axis. The position of the centre **Co** of the circle is determined by specifying the angle formed by the radius passing from the programmed initial point **P** (current point) and the horizontal direction **X+**. The optional parameter **label** is used in association with the instruction SETLABELINTERP to identify univocally the displacement bloc.

Step-by-step axes can only be used in this instruction, if they are controlled by a TRS-AX remote. In this case it must be taken into account that the word interpolation refers to a coordinated movement of more axes affected by discrete error due to axis piloting method.



## COORDIN

### Syntax

**COORDIN**

**matrix, value deltaT, direction, begin, end, mask, axis1, n°\_column\_axis1**  
**[, (axis2, n°\_column\_axis2) ÷ (axis32, n°\_column\_axis32)]**

### Arguments

**matrix** data matrix  
**value deltaT** constant or variable. Time basis  
**direction** predefined constant. Direction of data reading in matrix  
**UP** from the last row, upwards  
**DOWN** from the first row downwards  
**begin** global integer variable. The number of the first row  
**end** global integer variable. The number of the last row

|  |   |
|--|---|
| <b>mask</b>                              | axis mask to be enabled                   |
| <b>axis1 [...axis32]</b>                 | name of axis devices                      |
| <b>n°</b>                                | number of matrix column referring to axis |
| <b>_column_axis1[...n_column_axis32]</b> |   |

### Description

This instruction allows you to carry out synchronised movements of axes **axis1**, **axis2**, etc. by means of incremental transfers (microvectors) defined by a data **matrix**. The parameters **axis1** and **n\_column\_axis1** must always be defined. The values contained in the **matrix** indicate the absolute positions reached by the various axes one at a time.

Relative incremental transfers (interval between the position of row (n) and row (n-1)) are executed in a lapse of time equivalent to a **multiple** of the time basis (1 ms = Real Time of axes refresh) specified by the argument **value Δt**, which must consequently be expressed by an integer number. When the value of this time has been defined, the distance covered at each movement by each axis determines its speed. This instruction allows you to coordinate the movement of a maximum of 32 axes, along any curved line in space, as generated by SPLINE techniques.

It is not necessary to wait until the instruction is completed; it does not need the STARTINTERP instruction to start. However, a WAITSTILL instruction should be brought to its end, in order to wait for the correct arrival phase of the axes. Possible changes of the feedrate override should be made by means of the SETFEEDI instruction and worked through the SETFEEDCOORD instruction. The parameter **direction** allows you to determine the direction of the matrix, allowing you to execute the trajectory in both directions.

The columns of the matrix to be scanned can be float or double but not both at the same time.

In addition to the movement of axes along a finite path (defined by the number of matrix rows), infinite movement can be selected using:

- one matrix of a single row. With this operating mode, the control always reads the only row of the matrix and applies the coordinates in the row to the axes. To move the axes, the matrix row should be changed, preferably using a real-time task which guarantees coordinates updating is synchronised with the axes refresh frequency. With this operating mode, the control always reads the only row of the matrix and applies the coordinates in the row to the axes. To move the axes, the matrix row should be changed, preferably using a real-time task which guarantees coordinates updating is synchronised with the axes refresh frequency;
- a matrix of more rows. It is possible to scan the matrix with cycles from the first to the last row indefinitely by setting the values **ini** = 1, **fin** = 0 and **direction** = UP. If a single multi-row matrix row must be executed, it is necessary to set parameters **ini**, **fin** and **direction** in the following way: **ini** = number of row that must be executed, **fin** = number of row preceding row that must be executed, **direction** = UP. In other case a system error is generated. Step-by-step axes can only be used in this instruction, if they are controlled by a TRS-AX remote.

## DISABLECORRECTION

### Syntax

**DISABLECORRECTION**      **axis** [, **axis1**, ..., **axis6**]

### Arguments

|                          |                     |
|--------------------------|---------------------|
| <b>axis</b>              | name of axis device |
| <b>axis1, ..., axis6</b> | name of axis device |

### Description

Disables the linear correction for the specified **axis**.

The first parameter is the axis whose correction is to be deactivated, if it is the only parameter specified all the corrections present in the configuration are deactivated. The following parameters allow the specification of which corrections are to be deactivated, if one of these coincides with the first parameter the auto-correction is deactivated.

For a more detailed description see ENABLECORRECTION.

### Example

```
; disables only the auto-correction for axis X
DISABLECORRECTION      X, X
```

```
; disables the crossed correction (towards X and Y) for axis Z,
; but not the auto-correction
DISABLECORRECTION      Z, X, Y
```



## EMERGENCYSTOP

### Syntax

**EMERGENCYSTOP**                    **axis, time**

### Arguments

**axis**                                    name of axis devices  
**time**                                    constant or integer variable. Ramp time (ms)

### Description

It stops the specified axis and any axes possibly involved with it in the interpolated movement. The movement is stopped by a deceleration ramp over the time indicated by the variable **[time]**. In the point-to-point movements if the time set is greater than the configured deceleration time, this latter is used.

In the interpolated movements, if the time set is greater than the maximum value of the deceleration times of all axes involved, the maximum time configured is used.

The movement can be resumed by a START instruction.

The instruction cannot be used if **[axis ]** is a slave axis.

The instruction can generate following system errors:

- "4101 - Inconsistent axis management" when **[axis]** is executing a synchronized movement or a multilinear interpolation or an ISO movement.
- "4105 - instruction not executable on axis" when **[axis]** is a counting axis.
- "4399 - parameter out of range" if the **[time]** indicated is equal or less than 0.

## ENDMOV

### Syntax

**ENDMOV**                                **axis [, position]**

### Arguments

**axis**                                    name of axis device  
**position**                                constant or variable.

### Description

It stops movement of the specified axis. The difference from the STOP instruction is that when movement is interrupted it can not be restarted by using the START instruction. If the parameter **position** is specified, you can set the position at which the axis will end its movement, otherwise the point at which the axis stops will depend on current speed and the last programmed deceleration. Where necessary, to reach the end-of-movement point, the controller reverses axis motion.

### Note

This parameter is used only if the movement concerns a point-to point movement. In case of interpolated movement, the movement of the axis stops without considering the **position** value.

### Example

```
; stops current movement, taking axis to 0.0 position
ENDMOV X, 0.0
```

## ENABLECORRECTION

### Syntax

**ENABLECORRECTION**                **axis [, axis1, ..., axis6]**

### Arguments

**axis**                                    name of axis device  
**axis1, ..., axis6**                    name of axis device

### Description

Enables the linear correction for the specified **axis**. The correction consists of the auto-correction and the crossed correction. The auto-correction is a correction of the real position of an axis in relation to its own position, a crossed correction is a correction of the real position of an axis in relation to the position of other axes. Up to five crossed correctors can be defined.

The first parameter is the axis whose correction is to be deactivated, if it is the only parameter specified all the corrections present in the configuration are activated.

The following parameters allow the specification of which corrections are to be activated, if one of

these coincides with the first parameter the auto-correction is activated.  
See also DISABLECORRECTION.

**NOTE:** For the instruction to have effect the correction must also be enabled in the configuration.

#### Example

```
; enables all the corrections contained in the configuration for axis X
ENABLECORRECTION      X

; enables only the auto-correction for axis X
ENABLECORRECTION      X, X

; enables the auto-correction and
; the crossed correction (towards X and Y) for axis Z
ENABLECORRECTION      Z, X, Y, Z
```

## FASTREAD

### Syntax

```
FASTREAD                axis1, state, variable1 [,axis2, variable2],[..., axis8,
                        variable8]
```

### Arguments

|  |  |
|--|--|
| <b>axis1...[...axis8]</b>              | name of axis devices. Axis1 is the master axis   |
| <b>state</b>                           | predefined constant. It can assume the following values:<br><b>ON</b> rising edge<br><b>OFF</b> falling edge |
| <b>variable1...<br/>[...variable8]</b> | variable or double matrix/vector element. Memorised position   |

### Description

The positions of the indicated **axes** are read and saved in the **variables** the instant the rapid input of **axis1** (Master axis) switches to the set state.

If the indicated axes are analog, they must be part of the same board (8 for ALBN and 4 for TRS-AX).  
If the indicated axes are digital, the rapid input signal is located directly on the drive; therefore, in case of multiple fastread, the signal should be connected in parallel on various devices.

If the indicated axes are configured on EtherCAT bus, they must be part of the same drive.

The instruction ends when the input switches to the indicated **state (ON/OFF)**.

If a STOP instruction is executed before switching to rapid input, these instructions remain active and restart after the START instruction.

More than one fast reading can be activated at the same time on the same axis board.

During the execution of the instruction it is not possible to execute the instructions SETPZERO and SETPFLY at the same time on the same axis, if it is connected to boards with Mechatrolink II bus.

### Note

The rapid input for the axes being part of an ALBNT board stands on the **axis1** connector and doesn't need to be configured in virtual-physical

The rapid input for digital axes on board with Mechatrolink II bus stands on **EXTI2 input** and doesn't need to be configured in virtual-physical. The rapid inputs of digital Mechatrolink II axes need to be "short circuited", because the axis coordinate should stored only with reference to its own rapid axis.

## FREE

### Syntax

```
FREE                    axis [, voltage]
```

### Arguments

|                |   |
|----------------|---|
| <b>axis</b>    | name of axis device                                 |
| <b>voltage</b> | constant float or variable float. Reference voltage |

### Description

It sets the **axis** in "open loop" (Free) mode, disabling the *position control*. If the voltage parameter is specified, the axis reference voltage is set on the specified value.

This instruction can be used in the case of measuring axes, for position detection, or for axes whose movement can be forced by external mechanical instruments which could alter their position. During functioning the position of the axis is regularly detected and updated, allowing to position the axis definitively after enabling position control (instruction NORMAL).

## HELICABS

### Syntax

**HELICABS** [label],axis1, position1, axis2, position2, axis3, position3, direction, ±radius [,angle [, numrev [, axis4, position4 [, ..., axis6, position6]]]]

### Arguments

|  |   |
|--|---|
| <b>label</b>                               | constant or variable integer. Label identifying a displacement bloc |
| <b>axis1...axis3[...axis6]</b>             | name of axis devices  |
| <b>position1...position3[...position6]</b> | constant or variable. Absolute move position                        |
| <b>direction</b>                           | integer variable. Kind of rotation clockwise/anticlockwise (CW/CCW) |
| <b>radius</b>                              | constant or variable. Radius of the helix                           |
| <b>angle</b>                               | constant or variable. Angle of starting point                       |
| <b>numrev</b>                              | constant or variable. Number of revolutions                         |

### Description

Helicoidal interpolation with absolute move equal to programmed positions **position1**, **position2** and **position3**. The movement consists in a circular interpolation associated to axes **axis1** and **axis2** (using the same syntax rules as CIRCABS /CIRCINC, relative to the arguments **direction**, **±radius** and **angle**), and an associated linear of axis3 (and possibly **axis4**, **axis5** and **axis6**). The helicoidal movement can be developed in a series of revolutions, as indicated by the argument **numrev**. The position of the axis with linear movement (as the possible positions of **axis4**, **axis5** and **axis6**) refers to the total move (not to move/revolution). The optional parameter **label** is used in association with the instruction SETLABELINTERP to identify univocally the displacement bloc. Step-by-step axes can only be used in this instruction, if they are controlled by a TRS-AX remote. In this case it must be taken into account that the word interpolation refers to a coordinated movement of more axes affected by discrete error due to axis piloting method.

### Note

1. Contornature condition is evaluated only on the three first axes making up the reference system. Adding and possibly modifying a further one, you obtain an incorrect management of the speed profile. To obtain a correct movement, an instruction WAITSTILL between an instruction HELICABS and the other should be interposed.
2. If a reference local system is set using the instruction SETRIFLOC the three axes definit the new reference system should be always be indicated among the parameters of the instruction HELICABS, even if they do not displace anything.

## HELICINC

### Syntax

**HELICINC** [label],axis1, position1, axis2, position2, axis3, position3, direction, ± radius [,angle [, numrev [, axis4, position4 [, ..., axis6, position6]]]]

### Arguments

|  |   |
|--|---|
| <b>label</b>                               | constant or variable integer. Label identifying a displacement bloc |
| <b>axis1...axis3[...axis6]</b>             | name of axis devices  |
| <b>position1...position3[...position6]</b> | constant or variable. Incremental move position                     |
| <b>direction</b>                           | integer variable. Type of rotation clockwise/anticlockwise (CW/CCW) |
| <b>radius</b>                              | constant or variable. Radius of the helix                           |
| <b>angle</b>                               | constant or variable. Angle of starting point                       |
| <b>numrev</b>                              | constant or variable. Number of revolutions                         |

### Description

Helicoidal interpolation with incremental move equal to programmed positions **position1**, **position2** and **position3**. The movement consists in a circular interpolation involving axes **axis1** and **axis2** (using the same syntax rules as CIRCABS /CIRCINC, relative to arguments **direction**, **±radius** and **angle**), and a

linear interpolation involving **axis3** (and possibly **axis4**, **axis5** and **axis6**).

The helicoidal movement can be developed in a series of revolutions as indicated by the argument **numrev**.

The position of the axis with linear movement (as the possible positions of **axis4**, **axis5** and **axis6**) refers to the total move (not to move/revolution). The optional parameter **label** is used in association with the instruction SETLABELINTERP to identify univocally the displacement bloc.

Step-by-step axes can only be used in this instruction, if they are controlled by a TRS-AX remote. In this case it must be taken into account that the word interpolation refers to a coordinated movement of more axes affected by discrete error due to axis piloting method.

#### Note

1. Contornature condition is evaluated only on the three first axes making up the reference system. Adding and possibly modifying a further one, you obtain an incorrect management of the speed profile. To obtain a correct movement, an instruction WAITSTILL between an instruction HELICINC and the other should be interposed.
2. If a reference local system is set using the instruction SETRIFLOC the three axes that define the new reference system should be always be indicated among the parameters of the instruction HELICINC, even if they do not displace anything.

## JERKCONTROL

### Syntax

**JERKCONTROL**                      **axis, state**

### Arguments

|              |  |
|--------------|--|
| <b>axis</b>  | name of axis devices   |
| <b>state</b> | predefined constant. It can assume the following values:<br><b>ON</b> rising edge<br><b>OFF</b> falling edge |

### Description

According to whether the parameter **state** is set on ON or OFF, it enables or disables the jerk control on **axis** interpolation and point-to-point movements. The jerk control is enabled only with axes that have configured one acceleration ramp and Esse deceleration. If the axis has configured one Linear ramp the jerk is not checked.

## JERKSMOOTH

### Syntax

**JERKSMOOTH**                      **axis, value**

### Arguments

|              |                               |
|--------------|-------------------------------|
| <b>axis</b>  | name of devices of axis type. |
| <b>value</b> | constant or variable float.   |

### Description

In any classic interpolated movements, the axes can move while contouring, that is without stopping between a bloc and the next one. This occurs, if discontinuous function of tangency in the blocs is lower than the value "Maximum contouring angle", set in the module configuration (default value is 15), or lower than the value set through the instruction SETCONTORNATURE. In the opposite case, the axes are stopped in the edge point with controlled deceleration and let start again along the new bloc with controlled accelerations and speed rates. However, stop and restart reduce the machine movement performances. When the contouring angle takes on consistent values such as, e.g., a discontinuous function of tangency value higher than 1 degree, remarkable jumps of speed for the axes involved in contouring are determined, with infinite acceleration values and discontinuous functions in the speed rate profile, consequently. According to a value established by the user, the instruction JERKSMOOTH allows to link smoothly, that is with acceleration and speed continuity, the speed profiles of the axis while contouring. It should be noted that this smooth link inserts little variation in the performed trajectory compared to the performed one, because around the contouring point the axes show a speed rate profile different from the theoretical one.

The variable **value** expressed through a percentage value between 0 and 100, defines how much the speed rates profiles should be smoothly linked. A value equal to 0 maintains a theoretical profile by creating some discontinuities in the accelerations and in the speed rates profiles. A value equal to 100 obtains smooth linked profiles, a better performance, but also the high deviation from the theoretical trajectory, proportionate to the speed rate along the trajectory.

**Note**

The instruction is only applied in the movements with classic interpolation (instructions LINEARABS, LINEARINC, CIRCABS, CIRCINC, HELICABS, HELICINC). It cannot be applied in movements of multiaxis interpolation (instruction MULTIABS and MULTIINC).

**LINEARABS**

**Syntax**

**LINEARABS** [label],axis1, position1, [axis2, position2 [, axis3, position3 [, ..., axis6, position6]]]

**Arguments**

|  |   |
|--|---|
| <b>label</b>                                 | constant or variable integer. Label identifying a displacement bloc |
| <b>axis1[...axis2[...axis6]]</b>             | name of axis devices  |
| <b>position1[...position2[...position6]]</b> | constant or variable. Absolute move position                        |

**Description**

Linear interpolation, with absolute move, in positions specified by position1, position2, etc. The optional parameter label is used in association with the instruction SETLABELINTERP to identify univocally the displacement bloc.

Step-by-step axes can only be used in this instruction, if they are controlled by a TRS-AX remote. In this case it must be taken into account that the word interpolation refers to a coordinated movement of more axes affected by discrete error due to axis piloting method.

**Note**

1. Contornature condition is evaluated only on the three first axes making up the reference system. Adding and possibly modifying a further one, you obtain an incorrect management of the speed profile. To obtain a correct movement, an instruction[\*\*\*\*]WAITSTILL between an instruction LINEARABS and the other should be interposed.
2. If a reference local system is set using the instruction SETRIFLOC, the three axes that define the new reference system should be always be indicated among the first three parameters of the instruction LINEARABS, even if they do not displace anything.

**LINEARINC**

**Syntax**

**LINEARINC** [label],axis1, position1, [axis2, position2 [, axis3, position3 [, ..., axis6, position6]]]

**Arguments**

|  |   |
|--|---|
| <b>label</b>                                 | constant or variable integer. Label identifying a displacement bloc |
| <b>axis1[...axis2[...axis6]]</b>             | name of axis devices  |
| <b>position1[...position2[...position6]]</b> | constant or variable. Incremental move position                     |

**Description**

Linear interpolation, with *incremental move*, in positions specified by **position1, position2**, etc. The optional parameter **label** is used in association with the instruction SETLABELINTERP to identify univocally the displacement bloc.

Step-by-step axes can only be used in this instruction, if they are controlled by a TRS-AX remote. In this case it must be taken into account that the word interpolation refers to a coordinated movement of more axes affected by discrete error due to axis piloting method.

**Note**

1. Contornature condition is evaluated only on the three first axes making up the reference system. Adding and possibly modifying a further one, you obtain an incorrect management of the speed profile. To obtain a correct movement, an instruction WAITSTILL between an instruction LINEARABS and the other should be interposed.
2. If a reference local system is set using the instruction SETRIFLOC, the three axes that define the new reference system should be always be indicated among the parameters of the instruction LINEARINC, even if they do not displace anything.

## MOVABS

### Syntax

**MOVABS**                                    **axis1, value1 [, axis2, value2 [, ..., axis6, value6]]**

### Arguments

**axis1...[...axis6]**                    name of axis devices  
**value1...[...value6]**                constant or variable. Value of absolute move

### Description

It instructs the specified axes to execute an *absolute move* according to values specified in **value1 [,...value6]**.

To execute the move the axis must not be engaged in an interpolated move and it must be in position or in window. The movement of the axis begins as soon as the instruction is executed. If more than one point-to-point movement instruction is performed in the same task, they are chained. If a second task tries to carry out point-to-point instructions on an axis that is already engaged in a move, this task will wait for the move commanded by the first task to end.

It is also possible to change the velocity of a point-to-point movement and the following move using the instruction SETVEL. The two movements will be linked by a speed ramp without stopping the axes.

If the instruction SETVEL is not used, the highest possible velocity is represented by the value of the manual speed configured.

A point-to-point movement can be halted with the instruction STOP and subsequently restarted with the instruction START. During the interruption of the movement the axis remains in a normal running state even though physically it is not moving.

A move can be aborted with the instruction ENDMOV. In this case it cannot be restarted.

**NOTE:** Previously point-to-point movements:

- allowed no speed variation unless the axis was motionless. The current behaviour is similar to that of interpolated movements.
- when interrupted by a STOP the corresponding axis assumed the state "in position".

2) We suggest the reader to use linear interpolation instructions instead of point-to-point movement instructions, when the number of moving blocks exceeds 32 and the blocks are made by micro-segments. For further details references shall be made to the document ""Limiti Firmware Movimento Punto Punto.doc" available from T.p.A. S.p.A.

### Example

Homing Routine on Interrupt

### Example 2

```
; speed change
Function SpeedChange
    setvel      X, 20
    setvel      X, 20
    movabs     X, 100, Y, 200
    movabs     X, 150, Y, 180
    setvel      X, 5
    movabs     X, 80, Y, 100
    waitstill  X, Y
fret
```

## MOVINC

### Syntax

**MOVINC**                                    **axis1, value1 [, axis2, value2 [, ..., axis6, value6]]**

### Arguments

**axis1...[...axis6]**                    name of axis devices  
**value1...[...value6]**                constant or variable. Value of incremental move

### Description

It instructs each axis to execute an *incremental move* on the basis of the corresponding **value**.

To execute the move the axis must not be engaged in an interpolated move and it must be in

position or within tolerance. The movement of the axis begins as soon as the instruction is executed. If more than one point-to-point movement instructions on the same task is executed, they are chained. If a second task tries to carry out point-to-point instructions on an axis that is already engaged in a move, this task will wait for the move commanded by the first task to end.

It is also possible to change the speed of a point-to-point movement and the following move using the instruction SETVEL. The two movements will be linked by a speed ramp without stopping the axes.

If the instruction SETVEL is not used, the highest possible speed is represented by the value of the manual speed configured.

A point-to-point movement can be halted with the instruction STOP and subsequently restarted with the instruction START. During the interruption of the movement the axis remains in a normal running state even though physically it is not moving.

A move can be aborted with the instruction ENDMOV. In this case it cannot be restarted.

**NOTE:** Previously point-to-point movements:

- allowed no speed variation unless the axis was motionless. The current behaviour is similar to that of interpolated movements.
- when interrupted by a STOP the corresponding axis assumed the state "in position".

2) We suggest the reader to use linear interpolation instructions instead of point-to-point movement instructions, when the number of moving blocks exceeds 32 and the blocks are made by micro-segments. For further details, references shall be made to the document "Limiti Firmware Movimento Punto Punto.doc" available from T.p.A. S.p.A.

### Example

Homing Routine of an axis

### Example 2

```

; speed change
Function SpeedChange
    setvel      X, 20
    setvel      X, 20
    movinc      X, 100, Y, 200
    movinc      X, 150, Y, 180
    setvel      X, 5
    movinc      X, 80, Y, 100
    waitstill   X, Y
fret
    
```

## MULTIABS

### Syntax

**MULTIABS** [label],axis1, value1, [axis2, value2 [, axis3, value3 [..., axis16, value 16]]]

### Arguments

|                                |  |
|--------------------------------|--|
| <b>label</b>                   | constant or variable integer. Label identifying a displacement bloc          |
| <b>axis1 ... axis16]</b>       | name of axis devices   |
| <b>value1... [... value16]</b> | constant or variable. Value of theoretical position of displacement bloc end |

### Description

Absolute multi-linear interpolation up to 16 axes. This interpolation movement enables to advance the speed profiles, properly setting their respective tolerances on the axes by means of the instruction SETTOLERANCE (axes tolerance refers to a portion of path, where a constant interpolation ratio could not possibly exist). Axes addition order into the MULTIABS instruction **should** always be the same and **all** the axes involved in the movement should be present. The move blocs are queued in the normal lookahead and the movement is partially joined to the execution of an instruction WAITSTILL, STARTINTERP or to the filling of the same lookahead. From the axes involved in the move one can be used as a collider by means of the WAITCOLL instruction. The optional parameter **label** is used in association with the instruction SETLABELINTERP to identify univocally the displacement bloc.

Step-by-step axes can only be used in this instruction, if they are controlled by a TRS-AX remote. In this case it must be taken into account that the word interpolation refers to a coordinated movement of more axes affected by discrete error due to axis piloting method.

**Note**

With this kind of interpolation, virtual reference systems (SETRIFLOC and RESRIFLOC instructions) cannot be used. It is possible to perform some movements with chained axes (in CHAIN). The axes involved in the multi-axis interpolated movement should be declared master of other axes not involved in the movement. Furthermore, FeedRateOverride can be applied.

**Example**

```

SETQUOTE      x, 0
SETQUOTE      y, 0
SETQUOTE      z, 0

;first bloc
setveli       x, velx1
setveli       y, vely1
setveli       z, velz1
multiabs      x, positionx1, y,positiony1, z,position1

;second bloc
settolerance  x, tollx2, y,tolly2, z,tollz2
setveli       x, velx2
setveli       y, vely2
setveli       z, velz2
multiabs      x, positionx2, y,positiony2, z,positionz2

;third bloc
settolerance  x, tollx3, y,tolly3, z,tollz3
setveli       x, velx3
setveli       y, vely3
setveli       z, velz3
multiabs      x, positionx3, y,positiony3, z,positionz3

; fourth bloc
settolerance  x, tollx4, y,tolly4, z,tollz4
setveli       x, velx4
setveli       y, vely4
setveli       z, velz4
multiabs      x, positionx4, y,positiony4, z,positionz4
waitstill     x, y,z

```

**MULTINC****Syntax**

**MULTIINC** [label],axis1, value1, [axis2, value2 [, axis3, value3 [,..., axis16, value 16]

**Arguments**

|                                |   |
|--------------------------------|---|
| <b>label</b>                   | constant or variable integer. Label identifying a displacement bloc                   |
| <b>axis1 ... axis16]</b>       | name of axis devices  |
| <b>value1... [... value16]</b> | constant or variable. Value of theoretical position increase of displacement bloc end |

**Description**

Incremental multi-linear interpolation up to 16 axes. This interpolation movement enables to advance the speed profiles, properly setting their respective tolerances on the axes by means of the instruction SETTOLERANCE (axes tolerance refers to a portion of path, where a constant interpolation ratio could not possibly exist). Command of axes addition into the MULTINC instruction **should** always be the same and **all** the axes involved in the movement should be present. The movement blocs are queued in the normal lookahead and the movement is partially joined to the execution of an WAITSTILL, STARTINTERP instruction or to the filling of the same lookahead. From the axes involved in the movement one can be used as a collider by means of the WAITCOLL instruction. The optional parameter **label** is used in association with the instruction SETLABELINTERP to identify univocally the displacement bloc.



Step-by-step axes can only be used in this instruction, if they are controlled by a TRS-AX remote. In this case it must be taken into account that the word interpolation refers to a coordinated movement of more axes affected by discrete error due to axis piloting method.

**Note**

With this kind of interpolation, virtual reference systems (SETRIFLOC and RESRIFLOC instructions) cannot be used. It is possible to perform some movements with chained axes (in CHAIN). The axes involved in the multiaxis interpolated movement should be declared master of other axes not involved in the movement. Furthermore, FeedRateOvveride can be applied.

**NORMAL**

**Syntax**

**NORMAL axis**

**Arguments**

**axis** name of axis device

**Description**

It enables the *position control* on the **axis** and disables the *axes chain*.  
 When the system is switched on, all the configured axes set in free state and switch to normal state when this instruction is executed or when the first movement takes place.  
 However it is advisable to execute this instruction before carrying out axis reset procedure, to restore any existing emergency conditions.

**RESRIFLOC**

**Syntax**

**RESRIFLOC axis1, axis2, axis3**

**Arguments**

**axis1...axis3** name of devices. Type of axis

**Description**

It resets the absolute reference system for axes X Y Z (**axis1, axis2, axis3**).  
 It is normally used after setting a rototranslation reference system with a SETRIFLOC instruction.

**SETINDEXINTERP**

**Syntax**

**SETINDEXINTERP axis, varname**

**Arguments**

**axis** name of axis device  
**varname** name of global integer variable

**Description**

It defines an index which counts the number of interpolation blocks executed by an axis.  
 During interpolation movements, the variable **varname** increases by 1 at each block change.

**Note**

The variable used as index must be a group global variable or a machine global.

**SETLABELINTERP**

**Syntax**

**SETLABELINTERP axis, value**

**Arguments**

**axis** name of device of type axis  
**value** global variable of type integer

**Description**

In the variable **value** during a movement in interpolation, every time that the bloc is changed, the label value of the new bloc is assigned. The label is defined in the instructions of interpolated movement.

#### Note

The variable **value** should be a global group variable or a machine global.

## SETPFLY

### Syntax

**SETPFLY axis, state, speed, position,[error]**

### Arguments

|                 |   |
|-----------------|---|
| <b>axis</b>     | name of axis device   |
| <b>state</b>    | predefined constant. It indicates the state of the micro to be tested.<br>Acceptable values are:<br><b>ON</b><br><b>OFF</b> |
| <b>speed</b>    | float constant or variable  |
| <b>position</b> | constant or variable  |
| <b>error</b>    | integer variable. Error code  |

### Description

It allows you to reset the **axis** position "on the fly". The resetting is piloted by a switch connected to the rapid input of the axis connector (on boards with Mechatrolink II bus reference is made to EXTI1).

During **axis** movement, it waits for the corresponding home micro to switch to the indicated **state**. When this transition is intercepted, the real position of the axis is reset on zero, without interrupting movement, and target **position** and **speed** are automatically and dynamically redefined. If the set position is reached without detecting an input change and the parameter **error** has not been set, a system error is generated. If an **error** parameter has been set, this will contain the numeric code for the corresponding system error.

In this case the homing has not been executed and it is necessary to execute the SETQUOTE instruction to reset the micro search.

To interrupt the "on the fly" homing execution, execute a NORMAL on the axis or simply end the task that requested the homing.

During the execution of the instruction it is not possible to execute the instructions SETPZERO and FASTREAD at the same time on the same axis, if it is connected to boards with Mechatrolink II bus.

### Example

Homing Routine on Interrupt

## SETPFLYCHAINSTRAT

### Syntax

**SETPFLYCHAINSTRAT axis, type**

### Arguments

|             |  |
|-------------|--|
| <b>axis</b> | name of axis device  |
| <b>type</b> | Integer constant. Permitted values:<br>0 = only the master axis zeroes the coordinate. The slave axis keeps the previous coordinate<br>not equal to 0 = both master and slave axes synchronously zero the coordinate |

### Description

This instruction enables to set, how the indicated slave axes will behave for a master setpfly instruction.

The instruction has to be executed indicating the slave axis. If the variable **Type** is omitted, a default value equal to 0 is set.

## SETPZERO

### Syntax

**SETPZERO**                      **axis, position [,error]**

### Arguments

**axis**                              name of axis device  
**position**                         constant or variable. It is an incremental position  
**error**                               integer variable. Error code

### Description

It starts an incremental movement of the **axis** in the specified **position** and waits for the encoder zero pulse to be detected (before reaching the specified position).  
 As soon as the pulse is detected the real position is set on zero and the axis is stopped.  
 If the set position is reached without detecting the Zero pulse and the parameter **error** has not been set, a system error is generated. If an **error** parameter has been set, this will contain the numeric code for the corresponding system error. In this case the set point has not been executed and the SETQUOTE instruction must be executed to reset the pulse search.  
 The incremental position can reach a maximum of 50,000 encoder impulses.  
 The instruction is not applicable to digital axes on ALBSLM.  
 The movement of the axes, generated by this instruction, can be interrupted with a STOP and restarted by a START.  
 If the instruction is executed with S-CAN axes and with EtherCAT axes, a FREE instruction must be executed first.

During the execution of the instruction it is not possible to execute the instructions SETPZERO and FASTREAD at the same time on the same axis, if it is connected to boards with Mechatrolink II bus.

### Example

```
Function TestSetpZero
  free      X
  setpzero  x,100
fret
```

## SETQUOTECHAINSTRAT

### Syntax

**SETQUOTECHAINSTRAT**      **axis, [value]**

### Arguments

**axis**                              name of axis device  
**value**                             integer variable. Permitted values:  
 0= only the master axis zeroes the new coordinate, the slave axis keeps the previous coordinate  
 not equal to 0= the coordinates of the slave axes are synchronously initialized with the master axis coordinates

### Description

This instruction enables to set how the indicated slave axis will behave for a master SETQUOTE instruction.  
 The instruction has to be executed on the slave axis.  
 If the variable **value** is omitted, a default value equal to 0 is set.

## SETPZEROCHAINSTRAT

### Syntax

**SETPZEROCHAINSTRAT**      **axis, [value]**

### Arguments

**axis**                              name of axis device  
**value**                             integer variable. Permitted values:  
 0= only the master axis zeroes the coordinate, the slave axis keeps the previous coordinate  
 not equal to 0= both master and slave axes synchronously zero the coordinate

### Description

This instruction enables to set how the indicated slave axis will behave for a master SETPZERO instruction  
The instruction has to be executed on the slave axis.  
If the variable **value** is omitted, a default value equal to 0 is set.

## SETQUOTE

### Syntax

**SETQUOTE** **axis, position**

### Arguments

**axis** name of axis device  
**position** constant or variable

### Description

This instruction forces, at the same time, the theoretical and the real position of an axis to the value specified in **position**. If the axis is moving, this instruction causes the axis to stop abruptly as it is suddenly set in position (real quote coincides with target quote). For this reason we do not recommend using this instruction on moving axes if not at a very reduced speed.

### Example

Axis Homing routine

## SETRIFLOC

### Syntax

**SETRIFLOC** **position1\_ax1, position2\_ax1, position3\_ax1,  
position1\_ax2, position2\_ax2, position3\_ax2,  
position1\_ax3, position2\_ax3, position3\_ax3,  
axis1, axis2, axis3**

### Arguments

**position1\_ax1...position3\_ax3** director cosine of the three axes  
**axis1...axis3** name of devices. Axes

### Description

It allows you to activate an X' Y' Z' Cartesian reference system with a rototranslation with respect to the X Y Z absolute reference system of the machine, represented by the physical axes **axis1**, **axis2** and **axis3**.

The nine arguments indicate the Director Cosines of the three local axes in reference to the absolute axes

|                |               |                |
|----------------|---------------|----------------|
| $\cos\alpha_1$ | $\cos\beta_1$ | $\cos\gamma_1$ |
| $\cos\alpha_2$ | $\cos\beta_2$ | $\cos\gamma_2$ |
| $\cos\alpha_3$ | $\cos\beta_3$ | $\cos\gamma_3$ |

which compose the transformation matrix of the coordinates.

The origin of the new reference system is set in the current point.

All the interpolation movement instructions, involving axes X, Y and Z, refer to this reference system, until the RESRIFLOC instruction is executed.

## SETTOLERANCE

### Syntax

**SETTOLERANCE** **axis1, value1, [axis2, value2 [, axis3, value3 [, ..., axis16,  
value 16]]]**


### Arguments

**axis1...axis16** name of axis devices  
**value1...[...value16]** constant or variable. Maximum tolerance value that can be applied to the axis.


### Description

For each defined **axis** it sets the tolerance **value** to apply on the multi-axis interpolation motion. Tolerance value is the displacement value according to which the axis moves away from the original trajectory in a multi-axis interpolation.

Tolerance has to be set for each **axis** involved in the interpolation and the system will advance the speed rate profiles and respect the tolerances on all the axes without exceeding the ramp space, that represents the upper limit to anticipate the profiles. A missing assignment of tolerance before a multi-axis instruction means that the last tolerance will be applied on the axis itself. If a tolerance value has never been assigned before, the same is considered with null tolerance. In this case each multi-axis motion, involving that axis, does not set any ramp in advance.



A classic multi-axis trajectory is shown above and is made of two moving blocks, where the first one consists in a displacement of 100 of the X-axis, while the second one consists in an Y-axis motion of 300 and in an X-axis motion of 100. The red line marks the trajectory in case of null tolerance, the blue one instead is the trajectory in case of maximum tolerance axis. The tolerance can also be seen as the area subtended by the speed rate profile during the time of advance, as below.



## START

### Syntax

**START**                                    **axis**

### Arguments

**axis**                                    name of axis device

### Description

It restarts **axis** movement after a **stop**.

## STARTINTERP

### Syntax

**STARTINTERP**                            **axis**

### Arguments

**axis**                                    name of axis device

### Description

It starts an interpolation whose channel is identified by **axis**. Normally the movement of axes associated to an interpolation channel begins when the interpolation buffer is completely full (512 instructions) or when a WAITSTILL instruction is given, to stop movement. This allows the algorithm of the interpolator to determine optimal speed profiles, as it is provided with information concerning a large number of (or all) stages of interpolation movement.

The STARTINTERP instruction allows you to force axis movement even if the above described conditions are not fulfilled.

## STOP

**Syntax**  
**STOP**

**axis**

**Arguments**

**axis** name of axis device

**Description**

It interrupts **axis** movement. The axis executes a deceleration ramp whose length depends on current speed and configuration parameters.

**Example**

Homing Routine of an axis

## SWITCHENC

**Syntax**

**SWITCHENC** **axis1, [axis2, [direction, coordinate]]**

**Arguments**

**axis1** name of the device of axis type  
**axis2** name of the device of axis type indicates counting axis  
**direction** predefined constant.  
**UP**=encoder exchange, when the coordinate in positive direction is exceeded  
**DOWN**=encoder exchange, when the coordinate in negative direction is exceeded  
**coordinate** constant or double variable

**Description**

Allows you to replace the encoder of **axis 1** with the encoder of **axis2**. The encoder is exchanged when the quote indicated is exceeded in positive (UP) or in negative (DOWN) **direction**. If the parameters **direction** and **coordinate** are left out, the encoder exchange is immediately executed, regardless of the axis position.

If only axis1 is **declared**, the functioning with a single encoder is restored.

**Axis1** cannot be of step-by-step, counting and virtual type, **Axis2** can be a counting axis only. Further, both **axis1** and **axis2** cannot be involved in movements in chain as slave axis

The instruction generates the system error 4101 - Inconsistent axis AxisName management", when **axis1** or **axis2** are declared as slave in a movement in chain and the system error 4105 Instruction not executable on axis AxisName, when the declared axis type does not belong to the possible ones.

## SYNCRROOPEN

**Syntax**

**SYNCRROOPEN** **channel, deltaT, matrix, var, [smoothing]**

**Arguments**

**channel** variable or constant integer. Number of channel to open  
**deltaT** time interval  
**matrix** matrix in which the positions are saved  
**var** number of lines generated  
**smoothing** optional, admissible values: **ON** and **OFF**. Enables the profile smoothing function

**Description**

Opens a synchronized movement channel. With this type of movement a points profile is generated that is then executed using the instruction COORDIN. The profile is generated starting from a series of "crossing points" through which the axes must move all at the same moment. The crossing points are assigned using the instruction SYNCROMOVE.

The parameter **deltaT** assigns frequency with which the points of the profile joining the various crossing points are generated.

The parameter **matrix** specifies the GPL matrix in which the profile of points is saved. The matrix

must be composed of a double (or float) column for each axis involved in the movement, plus an integer column (the last). The double column is used to save the positions of the profile points, while the integer column is used to save an index which corresponds to the crossing point to which the current stroke of the profile must be brought. This index is useful for synchronizing the movement of the axes with other activities (e.g. activating an output).

The parameter **var** is a variable in which the number of points generated is saved; it is used by the instruction COORDIN to know what the last useful line of the GPL matrix is in which the profile is saved.

The parameter **smoothing** allows the activation of a function that avoids discontinuities in the speed of the axes, thus making the movement more fluid.

Within a profile the speed and the acceleration of the individual axes involved can be varied and the speed of the axes can be scaled down, see SYNCROSETACC, SYNCROSETDEC, SYNCROSETFEED. Once all the crossing points are assigned the profile can be generated using the instruction SYNCROSTARTMOVE.

When the generation of the profile is over the synchronized movement channel is closed with the instruction SYNCROCLOSE.

Up to 4 synchronized movement channels can be opened at the same time. The channel enumeration starts from 1.

### Example

Synchronized movements

## SYNCROCLOSE

### Syntax

**SYNCROCLOSE**                      **channel**

### Arguments

**channel**                                      variable or constant integer. Number of channel to close

### Description

Closes a synchronized movement channel. See SYNCROOPEN.

### Example

Synchronized movements

## SYNCROMOVE

### Syntax

**SYNCROMOVE**                      **channel, axis1, position1, [ axis2, position2, [ ... axis32, position32]]**

### Arguments

**channel**                                      variable or constant integer. Number of synchronized movement channel  
**axis1**    first axis  
**position 1**                                      position of first axis  
**axis32**    thirty second axis  
**position32**                                      position of thirty second axis

### Description

This assigns a crossing point for the axes and the movement channel specified. The crossing points are inserted in a internal table that is processed when the instruction SYNCROSTARTMOVE is executed.

The instruction allows up to thirty two axes to be moved.

Step-by-step axes can be used in this instruction, only if controlled by a TRS-AX remote. In this case it must be taken into account that the word interpolation refers to a coordinated movement of more axes affected by discrete error due to axis piloting method.

The instruction **SYNCROMOVE** must be preceded by the instruction to open the synchronized movement channel: SYNCROOPEN.

### Example

Synchronized movements



## SYNCROSETACC

### Syntax

**SYNCROSETACC**                    **channel, axis, accPos, accNeg**

### Arguments

|                |  |
|----------------|--|
| <b>channel</b> | variable or constant integer. Number of channel                  |
| <b>axis</b>    | axis device  |
| <b>accPos</b>  | variable or constant integer. Acceleration in positive direction |
| <b>accNeg</b>  | variable or constant integer. Acceleration in negative direction |

### Description

Sets the duration of the acceleration ramps of an axis during a synchronized movement. The acceleration of a movement can be defined in a positive and in a negative direction. See SYNCROOPEN.

### Example

Synchronized movements

## SYNCROSETDEC

### Syntax

**SYNCROSETDEC**                    **channel, axis, decPos, decNeg**

### Arguments

|                |  |
|----------------|--|
| <b>channel</b> | variable or constant integer. Number of channel                  |
| <b>axis</b>    | axis device  |
| <b>decPos</b>  | variable or constant integer. Deceleration in positive direction |
| <b>decNeg</b>  | variable or constant integer. Deceleration in negative direction |

### Description

Sets the duration of the deceleration ramp of an axis during a synchronized movement. The deceleration of a movement can be defined in a positive and in a negative direction. See SYNCROOPEN.

### Example

Synchronized movements

## SYNCROSETVEL

### Syntax

**SYNCROSETVEL**                    **channel, axis, velPos, velNeg**

### Arguments

|                |  |
|----------------|--|
| <b>channel</b> | variable or constant integer. Number of channel          |
| <b>axis</b>    | axis device  |
| <b>velPos</b>  | variable or constant double. Speed in positive direction |
| <b>velNeg</b>  | variable or constant double. Speed in negative direction |

### Description

Sets the speed of an axis during a synchronized movement. The speed of a movement can be defined in a positive and in a negative direction. See SYNCROOPEN.

### Example

Synchronized movements

## SYNCROSETFEED

### Syntax

**SYNCROSETFEED**                    **channel, axis, feed**

### Arguments

|                |   |
|----------------|---|
| <b>channel</b> | variable or constant integer. Number of channel |
| <b>axis</b>    | axis device                                     |

**feed** variable or constant integer. Feed rate value

#### Description

Allows the scaling of the speed of all the axes associated with a synchronized movement channel. The parameter **feed** represents the percentage of the speed previously programmed to be applied to the following movements. Admissible values range from 0 to 100.

**NOTE:** This instruction has effect during the generation of the profile and not during its execution which is triggered by the instruction COORDIN. To scale the speed of the axes while they are in motion use the instruction SETFEED1.

#### Example

Synchronized movements

## SYNCRSTARTMOVE

#### Syntax

**SYNCRSTARTMOVE** **channel, [line]**

#### Arguments

**channel** variable or constant integer. Number of channel  
**line** initial process line

#### Description

Start the processing of the profile for the specified channel. The optional parameter **line** allows the specification of which will be the first line of the internal table in which the SYNCROMOVE instructions to include in the processing are queued; if this is omitted the processing starts from the first line. See SYNCROOPEN.

#### Example

Synchronized movements

## WAITCOLL

#### Syntax

**WAITCOLL** **axis, value, timeout, delta**

#### Arguments

**axis** name of the axis device  
**value** constant or variable. Absolute position value  
**timeout** constant or variable. It is the waiting time, when the axis is still  
**delta** constant or variable. it is the window value to obtain a still axis

#### Description

When the axis moves, the achievement of a programmed position can be prevented by an obstacle of mechanical nature, represented at times also by the same workpiece. In this case the system generates an error in the system "servoerror" or "movement not finished". This instruction defines a position value at which

- the system begins to verify the presence of a collision;
- the waiting time (**timeout**) before the **axis**, after the collision, is placed on "position";
- the **delta** that defines the tolerance on the axis positioning.

When the axis exceeds its position, which is defined in **value**, the system checks, whether the axis is still moving. Once the obstacle is intercepted, the critical situation is identified and, while ensuring the engine thrust, the loop error exceeding the limit is not checked anymore. The motion direction on which the collision occurred is verified, has the same direction of the last movement joined at the end. The timeout is expressed in seconds, the **delta** value should be greater than 0.001 mm and less than the difference between the programmed arrival position and the position **value**.

The instruction can be used with the multi-axis interpolator, since within such interpolator the temporary loss of the interpolation link.

The instruction can be applied also to virtual axes and to Master axes of a movement in chain.

An error system is generated when:

- the axis is executing a classic interpolated movement (see instructions LINNEARBS, LINEARINC,, CIRCABS, CIRCINC, HELICABS, HELICINC) or in coordinated motion
- the **axis** is a slave-axis

- the **axis** is a counting axis or a step-to-step axis
- the **value** set is higher than the end-movement position

**Example**

```

; sets the X axis position
SETQUOTE X, 0.0
; moves the x axis to the absolute position 1000
MOVABS X, 1000.0
; waits for the collision point, waits 2 seconds before setting
; the axis on "position", after
; intercepting a collision with a precision of 0.01 mm
WAITCOLL X, 980.0,2.0,0.01

```

**WAITDEC**

**Syntax**

**WAITDEC** **axis1 [, ..., axis6]**

**Arguments**

**axis1 [...,axis6]** name of axis device

**Description**

It waits for the deceleration state or one of the subsequent states of all the specified **axes** (1÷6). The task where the instruction is executed is put on wait status, until the axis reaches the acceleration, coordinate, wait on the higher threshold, wait on the lower threshold and axis quiescent waiting state.

Axis states are identified by an integer:

- acceleration = 1
- steady = 2
- deceleration = 3
- coordinate = 4
- wait on the higher threshold = 5
- axis quiescent waiting = 6
- wait on the lower threshold = 7

**WAITREG**

**Syntax**

**WAITREG** **axis1 [, ..., axis6]**

**Arguments**

**axis1 [...,axis6]** name of axis device

**Description**

It waits for the regime state or one of the subsequent states of all the specified **axes** (1÷6). Il task in cui viene eseguita l'istruzione viene messo in attesa fino a quando l'asse si trova negli stati di steady, deceleration, coordinate, wait on the higher threshold, wait on the lower threshold and axis quiescent waiting state.

Axis states are identified by an integer:

- acceleration = 1
- steady = 2
- deceleration = 3
- coordinate = 4
- wait on the higher threshold = 5
- axis quiescent waiting = 6
- wait on the lower threshold = 7

**WAITSTILL****Syntax****WAITSTILL**                      **axis1 [, ..., axis6]****Arguments****axis1 [...,axis6]**                      name of axis device**Description**It waits for all the specified **axes** (1÷6) to end movement (Position state).**Example**

Axis Homing routine

**WAITTARGET****Syntax****WAITTARGET**                      **axis1 [, ..., axis6]****Arguments****axis1 [...,axis6]**                      name of axis device**Description**It waits for the theoretical current position of all the specified **axes** (1÷6) to reach target position. The real quote will not match the theoretical position until the loop error is cleared.**WAITWIN****Syntax****WAITWIN**                              **axis1 [, ..., axis6]****Arguments****axis1 [...,axis6]**                      name of axis device**Description**It waits for the threshold state or one of the subsequent states of all the specified **axes** (1÷6). The task where the instruction is executed is put on wait status, until the axis reaches the wait on the higher threshold, wait on the lower threshold and axis quiescent waiting state.

Axis states are identified by an integer:

- acceleration = 1
- steady = 2
- deceleration = 3
- coordinate = 4
- wait on the higher threshold = 5
- axis quiescent waiting = 6
- wait on the lower threshold = 7

**WAITACC****Syntax****WAITACC**                              **axis [, ..., axis6]****Arguments****axis1 [...,axis6]**                      name of axis device**Description**It waits for the acceleration state or one of the subsequent states of all the indicated **axes** (1÷6). The task where the instruction is executed is put on wait status, until the axis reaches the acceleration state or one of the subsequent states.

Axis states are identified by an integer:

- acceleration = 1

- steady = 2
- deceleration = 3
- coordinate = 4
- wait on the higher threshold = 5
- axis quiescent waiting = 6
- wait on the lower threshold = 7

### Axis Parameter

### Reading/Writing

### DEVICEID

#### Syntax

**DEVICEID**                                  **device, variable**

#### Arguments

**device**                                  name of the device or the device parameter  
**variable**                                integer variable receiving the logical address

#### Description

It writes in **variable** the logical address associated to any kind of device.  
This instruction may enable an univocal "key" associated to the device, as an index or a search key in data structures.

### GETAXIS

#### Syntax

**GETAXIS**                                    **axis, dataname, varname**  
**GETAXIS**                                    **axis, dataname1, dataname2, [...,dataname20,] matrix[row]**

#### Arguments

**axis**    name of axis device  
**dataname**                                    predefined constant (See list below). Axis parameter(1÷20)  
**varname**                                    variable or name of device  
**row**    constant or integer variable. Row number of the matrix  
**matrix**                                        name of matrix

#### Description

In the first version the instruction reads one datum (**dataname**) of an axis and saves it in a variable.  
In the second version, the instruction reads various data of an axis at the same time (from 1 to 20) and saves it, in the same order as it was requested, in the elements of the specified matrix row. In this case the number of columns of the matrix must correspond to the number of requested data. The list reported below includes all the predefined constants that can be assigned to the parameter **dataname**.  
The first column is the name of the constant.  
The second describes the quantity of the axis read by the instruction.  
The third is the format of the datum returned to the variable **varname** or the **matrix[row]**, where:

- **d** means **double**,
- **f** means **float**,
- **i** means **integer**
- **b** means **char**.

If the declaration of the variable, where the data will be memorised, is different from the value returned by the instruction, the compiler changes the datum (cast) to the type requested by the user. Sometimes this implies losing a certain amount of data. For example a double value equal to 12,345, changed into an integer, becomes 12. For this reason we recommend keeping to the requested types when declaring **varname** and **matrix[row]** variables.  
The last column describes either the return value or the measuring unit of the relative parameter. Constants beginning with "\_CFG" allow to configuration values, that is the values set when the machine is started.

| constant | description   | type | return value        |
|----------|---------------|------|---------------------|
| _CFGTYPE | Axis typology | i    | 1=analog,3=stepping |

| <b>costant</b> | <b>description</b>   | <b>type</b> | <b>return value</b>  |
|----------------|--|-------------|--|
| _CFGUM         | unit of measure  | i           | motor,4=digital,5=count,<br>6=frequency/<br>direction,7=virtual<br>0=millimetres,1=inches,2<br>=degrees,3=revol. |
| _CFGRIS        | resolution   | d           | impulses per _UM   |
| _CFGVMAX       | maximum speed  | f           | m/1' or inch/1' or<br>degrees/1' or rotations/1'   |
| _CFGVMAXD      | maximum speed in<br>manual mode                                      | f           | m/1' or inch/1' or<br>degrees/1' or rotations/1'   |
| _CFGVMAXI      | maximum interpolation<br>speed                                       | f           | m/1' or inch/1' or<br>degrees/1' or rotations/1'   |
| _CFGPHINV      | encoder phase inversion  | b           | 0=no inversion,<br>1=inversion   |
| _CFGRFINV      | reference inversion  | b           | 0=no inversion,<br>1=inversion   |
| _CFGZIND       | enable on-index position<br>reset                                    | b           | 0=disabled, 1=enabled  |
| _CFGTRPP       | type of acceleration/<br>deceleration ramp in<br>point-to-point mode | b           | 0=linear, 1= 'S' shaped ,<br>2= double 'S' shaped  |
| _CFGKFFA       | acceleration feed<br>forward   | f           |  |
| _CFGKFFAI      | interpolation acceleration<br>feed forward                           | f           |  |
| _CFGSRPP       | step by step ramp start<br>speed                                     | f           | m/1' o inch/1' o gradi/1'<br>o giri/1'   |
| _CFGACC        | acceleration time from 0<br>to _CFGVMAX                              | i           | msec   |
| _CFGDEC        | deceleration time from<br>_CFGVMAX                                   | i           | msec   |
| _CFGACCI       | acceleration time from 0<br>to _CFGVMAXI                             | i           | msec   |
| _CFGDECI       | deceleration time from<br>_CFGVMAX to 0                              | i           | msec   |
| _CFGQLP        | positive axis limit  | d           | position   |
| _CFGQLN        | negative axis limit  | d           | position   |
| _CFGKP         | proportional coefficient   | f           |  |
| _CFGKI         | integral coefficient   | f           |  |
| _CFGKD         | derivative coefficient   | f           |  |
| _CFGKFF        | feed forward   | f           | percentage   |
| _CFGKPS        | slave axis proportional<br>coefficient                               | f           |  |
| _CFGKIS        | slave axis integral<br>coefficient                                   | f           |  |
| _CFGKDS        | slave axis derivative<br>coefficient                                 | f           |  |
| _CFGQEAP       | positive loop error  | d           | position   |
| _CFGQEAN       | negative loop error  | d           | position   |
| _CFGKPI        | interpolation proportional<br>coefficient                            | f           |  |
| _CFGKII        | interpolation integral<br>coefficient                                | f           |  |
| _CFGKDI        | interpolation derivative<br>coefficient                              | f           |  |
| _CFGTMINP      | minimum positive<br>voltage  | f           | volt   |
| _CFGTMINN      | minimum negative<br>voltage  | f           | volt   |
| _CFGSTMINP     | positive threshold<br>voltage  | f           | volt   |
| _CFGSTMINN     | negative threshold<br>voltage  | f           | volt   |
| _CFGESC        | axis moving timeout  | i           | msec   |

| <b>costant</b> | <b>description</b>  | <b>type</b> | <b>return value</b>                           |
|----------------|---|-------------|---|
| _CFGDSE        | enable dynamic servoerror   | b           | 0=disabled, 1=enabled                         |
| _CFGAEAN       | enable automatic adjust   | b           | 0=disabled, 1=enabled                         |
| _CFGOFFSET     | adjust voltage - initial offset   | f           | volt  |
| _CFGCEE        | incorrect encoder connection position                                       | d           | position                                      |
| _CFGNOTCH      | notch filter frequency  | i           | Hz  |
| _CFGBUFI       | integrative calculation dimension buffer                                    | i           | [1, 200]                                      |
| _CFGQAP        | positive quiescent threshold  | d           |   |
| _CFGQAN        | negative quiescent threshold  | d           |   |
| _CFGTRI        | type of acceleration/ deceleration ramp in interpolation mode               | f           | 0=linear, 1= 'S' shaped ,2= double 'S' shaped |
| _CFGKFFI       | interpolation feed forward  | f           | percentage                                    |
| _CFGAAF        | wait axis still   | b           | 0=disabled, 1=enabled                         |
| _CFGENCTYPE    | type of encoder   | i           | 0=simulated or absent, 1=real                 |
| _SRPP          | step by step ramp start speed   | f           | m/1' or inch/1' or degrees/1' or rotations/1' |
| _ACC           | acceleration time from 0 to _VMAX   | i           | msec  |
| _DEC           | deceleration time from _VMAX to 0   | i           | msec  |
| _ACCI          | acceleration time from 0 to _VMAXIn   | i           | msec  |
| _DECI          | interpolation mode deceleration time from _VMAXI to 0 in interpolation mode | i           | msec  |
| _QLP           | positive axis limit   | d           | position                                      |
| _QLN           | negative axis limit   | d           | position                                      |
| _KP            | proportional coefficient  | f           |   |
| _KI            | integral coefficient  | f           |   |
| _KD            | derivative coefficient  | f           |   |
| _KFF           | feed forward  | f           | percentage                                    |
| _KPS           | slave axis proportional coefficient   | f           |   |
| _KIS           | slave axis integral coefficient   | f           |   |
| _KDS           | slave axis derivative coefficient   | f           |   |
| _QEAP          | positive loop error   | d           | position                                      |
| _QEAN          | negative loop error   | d           | position                                      |
| _VEL           | point- to-point speed   | f           | m/1' or inch/1' or degrees/1' or rotations/1' |
| _VELI          | interpolation speed   | f           | m/1' or inch/1' or degrees/1' or rotations/1' |
| _MODE          | axis functioning mode   | b           | 1=normal, 2=free, 8=interpol., 10=coord.      |
| _PHINV         | encoder phase inversion   | b           | 0=no inversion, 1=inversion                   |
| _RFINV         | reference inversion   | b           | 0=no inversion, 1=inversion                   |
| _ZIND          | enable on-index position reset  | b           | 0=disabled, 1=enabled                         |
| _KPI           | interpolation proportional coefficient                                      | f           |   |
| _KII           | interpolation integral coefficient  | f           |   |

| <b>costant</b> | <b>description</b>                       | <b>type</b> | <b>return value</b>  |
|----------------|--|-------------|--|
| _KDI           | interpolation derivative coefficient     | f           |  |
| _KFFI          | interpolation feed forward               | f           | percentage   |
| _KFFA          | acceleration feed forward                | f           | percentage   |
| _KFFAI         | interpolation acceleration feed forward  | f           | percentage   |
| _ESC           | axis moving timeout                      | i           | msec   |
| _CEE           | incorrect encoder connection position    | d           | position   |
| _NOTCH         | notch filter frequency                   | i           | Hz   |
| _BUFI          | integrative calculation dimension buffer | i           | [1,200]  |
| _QAP           | positive quiescent threshold             | d           |  |
| _QAN           | negative quiescent threshold             | d           |  |
| _QEAPINV       | positive loop error limit in inversion   | d           |  |
| _QEANINV       | negative loop error limit in inversion   | d           |  |
| _OFSCoord      | offset position coordinated move         | d           |  |
| _MS            | axis typology master or slave            | b           | 0=not in chain,4=master,5=slave  |
| _QENC          | encoder position                         | d           | position   |
| _QR            | real position                            | d           | position   |
| _RIS           | resolution used by the axis              | d           |  |
| _ST            | axis state                               | b           | 1=accel., 2=regime, 3=decel.,4=position, 5=wait big win.,6=wait axis stop,7=wait small win, 8=start  |
| _QT            | theoretical position                     | d           | position   |
| _EA            | loop error                               | d           | position   |
| _FF            | feed forward                             | i           |  |
| _VC            | current speed                            | f           |  |
| _P             | proportional correction                  | i           |  |
| _I             | integral correction                      | i           |  |
| _D             | derivative correction                    | i           |  |
| _FLGS          | axis flags                               | b           |  |
| _VCR           | real speed                               | f           |  |
| _ADJUST        | axis compensation offset                 | i           | whole number showing the tension to be transmitted to the drive, as seen from the side of the DAC axis card. The full scale of the drive is 10 Volt and that of the DAC is 32767.      |
| _DAC           | DAC value                                | i           | whole number representing the tension to be transmitted to the drive, as seen from the side of the DAC axis card. The full scale of the drive is 10 Volt and that of the DAC is 32767. |
| _ACCINST       | instantaneous acceleration value         | f           |  |
| _FFA           | acceleration feed forward                | i           |  |



| <b>constant</b> | <b>description</b>  | <b>type</b> | <b>return value</b>   |
|-----------------|---|-------------|---|
| _GONETIME       | elapsed time from the beginning of the movement   | f           | sec (0 for slave axis and step-by-step axis)  |
| _RESTIME        | time left until the end of the movement. The values are related to the allocated movement in the buffer when requested.   | f           | sec (0 for slave axis, coordinated moving axes and step-by step axis)   |
| _GONESPACE      | space from the beginning of the movement. The values are related to the allocated movement in the buffer when requested.  | f           | percentage (100 for slave axis, interpolated moving axes and step-by-step axis)   |
| _RESSPACE       | space left until the end of the movement. The values are related to the allocated movement in the buffer when requested.  | f           | percentage (100 for slave axis, interpolated moving axes and step-by-step axis)   |
| _AXESJERK       | enabling the jerk control on the axis   | b           | 1=enabled control, 0=control not enabled  |
| _MOVEJERK       | enabling the jerk control on the movement on which the axis is engaged  | b           | 1=enabled control, 0=control not enabled  |
| _MOVETYPE       | axis motion on which the axis is engaged.   | b           | 1=classical interpolated movement, 2=interpolated multi-axis motion, 3= coordinated movement, 4= movement point-to-point, 5=movement in chain (slave axes only) |
| _PARTYPESET     | type of parameter axes in use during the movement   | i           | 1=interpolation, 0=point-to-point   |
| _AXINRIFLOC     | current axe in a local reference system   | i           | 1=yes, 0=no   |
| _QTARGETTOOL    | target position of the axis. In case of ISO interpolation target position of the coordinate of the tool point of the axis | d           |   |
| _QREALTOOL      | real position of the axis. In case of ISO interpolation real position of the coordinate of the tool point of the axis     | d           |   |
| _BACKLASH       | value of the mechanical clearance defined for the axis  | d           |   |
| _DISABLED       | disabling an axis   | b           | 1=disabled axis, 0=enabled axis   |
| _DYNLIMIT       | enabling dynamic numeric control of axis limits   | b           | 1=enabled control, 0=disabled control   |
| _AXESFEED       | override feedrate value currently applied to the axis   | f           |   |
| _CORRLIN        | kind of linearity correction in use   | i           | 0=no correction in use, 1=self correction, 2=crossed correction,  |

| constant    | description   | type | return value   |
|-------------|---|------|--|
| _VELISO     | the tool point speed during the ISO - movement  | f    | 3=self correction with crossed correction  |
| _ISOSTOPS   | number of the forced stops of the interpolated movement due to borderline situations of the lookahead | i    |  |
| _CURRATIO   | value of the chaining ratio currently used  | d    |  |
| _DYNRATIO   | returns, if a dynamic change of the chaining ration is in execution                                   | i    | 0=no, 1 = yes  |
| _RESBLOCK   | number of total queued displacement blocs in the movement (current value)                             | i    |  |
| _EXECBLOCK  | number of the displacement blocs still to be performed  | i    |  |
| _TOTALBLOCK | number of performed displacement blocs  | i    |  |
| _SWITCHENC  | monitors if the encoders are being exchanged  | i    | -1=the axis does not use the SWITCHENC instruction, 0= a SWITCHENC instruction has been executed, but the axis is using its encoder, 1= a SWITCHENC instruction has been executed and the axis is using the encoder of the counting axis |
| _QOFSENC    | encoder offset value  | d    |  |

## Point-to-point Movement

### SETACC

#### Syntax

**SETACC**                                    **axis, [value]**

#### Arguments

**axis**                                        name of axis device  
**value**                                        constant or variable. Acceleration time

#### Description

It assigns to the **axis** the acceleration time indicated by **value**. Acceleration time is expressed in milliseconds.

If **value** is omitted, it assigns the configuration parameter. If the instruction is placed between two instructions MOVABS or MOVINC, the first movement instruction (with stop of the movement) is executed, using the acceleration and deceleration parameters previously set. The second instruction is executed, when the new parameter of acceleration are applied. SETACC instruction has an effect only on the movements coming after its execution.

If the specified **value** is smaller than the configuration parameter then the latter is taken.

See also SETDEC, SETACCI and SETDECI.



**Note**

If the instruction is applied to an engine with SLM command and plate speed higher than 3750 RPM, the maximum feed forward adjustable value is 50. This is because the engine with Commands SLM performs a scaling on internal reference speed sent by the control.

**SETFEEDFA****Syntax**

**SETFEEDFA**                      **axis [, value]**

**Arguments**

**axis**                              name of axis device  
**value**                              constant or variable. Feed forward percentage

**Description**

It assigns to the **axis** the acceleration *feed forward percentage* **value** for point-to-point movements. If **value** is omitted, the configuration feed forward coefficient is used. If the instruction is applied to a step-by-step motor a system error is generated. The same happens if the **value** variable is set on a value which is not included between 0 and 100. See also instructions SETFEEDF,SETFEEDFI,SETFEEDFAI.

**Note**

If the instruction is applied to an engine with SLM command and plate speed higher than 3750 RPM, the maximum feed forward adjustable value is 50. This is because the engine with Commands SLM performs a scaling on internal reference speed sent by the control.

**SETINTEG****Syntax**

**SETINTEG**                      **axis [, value]**

**Arguments**

**axis**                              name of axis device  
**value**                              constant or variable. Integral action coefficient. Char and integer variables are not allowed.

**Description**

It assigns the **value** *integral action coefficient* to the **axis**. If **value** is omitted, the configuration integral action coefficient is used. The instruction can not be applied to step-by-step motors. See also instruction SETINTEGI.

**SETMULTIFEED****Syntax**

**SETMULTIFEED**                      **axis1, value1, axis2, value2 [, axis3, value3 [, ..., axis16, value 16]]]**

**Arguments**

**axis1...axis16**                      name of devices of type axis  
**value1...[...value16]**              constant or variable. It represents the feed rate override percentage

**Description**

It modifies the **feed rate** override percentage value of the indicated **axes** indicated as far as the *point- to-point movements* are concerned. For each axis a different value can be set.



## SETACCI

### Syntax

**SETACCI**                                    **axis1 [, ..., axis6] [, value]**

### Arguments

**axis1,[...axis6]**                    name of axis device  
**value**                                    constant or variable. Acceleration time

### Description

It assigns to axes **axis1** and **axis2** the interpolation movement acceleration time indicated by **value**. Time is expressed in milliseconds. If **value** is omitted, the configuration parameter is taken instead.

See also SETACC, SETDEC and SETDECI.

## SETACCLIMIT

### Syntax

**SETACCLIMIT**                                **axis,[value]**

### Arguments

**axis**                                        name of axis device  
**value**                                        operating time constant

### Description

It enables and disables the automatic calculation of interpolation regime speed according to the acceleration tolerated by the axes. The **value** parameter is a time constant used to define the speed limit tolerated by the **axis**, in milliseconds. This parameter is optional. If omitted, the macro will disable the automatic calculation. A standard value for this parameter is 30 milliseconds. If this time is further reduced, the profile will slow down making movement more gentle. By increasing this time, the opposite effect is obtained. This instruction can't be applied to helical interpolations.

## SETACCSTRATEGY

### Syntax

**SETACCSTRATEGY**                            **axis, [value]**

### Arguments

**axis**                                        name of axis device  
**[value]**                                        acceleration strategy

### Description

Allows the selection of the type of acceleration wanted for the following interpolation movements. The instruction is executed for all the axes involved in the interpolation.

There are two admissible values for the parameter **value**: 0 and 1. If the value 0 is passed, the usual acceleration strategy is adopted (the least of the axes involved in the interpolation is chosen as profile acceleration). If the value is equal to 1 the highest acceleration that the individual axes can support is taken (considering the individual components). In this latter case, only the linear interpolation strokes will be considered and the algorithm will work only so long as the acceleration and deceleration ramps are contained in the same interpolation stroke.

## SETAXPARTYPE

### Syntax

**SETAXPARTYPE**                                **axis, [value]**

### Arguments

**axis**                                        name of the axis device  
**[value]**                                        variable or integer constant.

### Description

When a multilinear interpolation is performed, this instruction allows you to change the axis parameter set in use, changing from the typical parameters of the interpolation (**value =1**) to those used for the

point-to-point movement (**value** = 0). If the variable **value** is omitted, the resolution value used is the interpolation one.  
 The parameter set change can only be made if the axis is still in POSITION state, otherwise the instruction generates the system error no. 4101 "Inconsistent axis *AxisName* management".

## SETCONTORNATURE

**Syntax**  
**SETCONTORNATURE**                    **[value1[,value2]]**

**Arguments**  
**value1**                                    constant or variable. Maximum contouring angle  
**value2**                                    constant or variable. Maximum slowdown angle

**Description**  
 Sets the minimum angle between the tangents of two trajectories carried out in interpolation. If the angle is exceeded, the machine will not carry out the contouring, that is, the axes will stop at the end of the first trajectory and then restart along the second one. For this reason a *maximum contouring angle* is defined as **value1** and represents the maximum angle between two displacement lines, below which the movement does not stop. If the angle between two displacement blocks is greater than the maximum contouring angle, the movement stops. To avoid the stop, a maximum deceleration angle (**value2**) can be set. If the angle between two displacement blocks is included between the *maximum contouring angle* and the *maximum deceleration angle*, the movement does not stop, but only slows down. Thus, the *maximum deceleration angle* represents the angle over which the movement must be compulsorily stopped. For angles less than the maximum contouring angle the movement **does not slow down**, for angles between the maximum contouring angle and the maximum deceleration angle the movement **stops**.

**Value1** and **value2** are optional parameters; if both are not set, 15 degrees are taken on as a default value. If only the first parameter is set, *maximum deceleration angle* is equal to the *maximum contouring angle*. Deceleration feature is disabled when the *maximum deceleration angle* is less or equal to the *maximum contouring angle*. The maximum deceleration angle is equal to 180 degrees. If an greater value is set, the generates the following error no. 4399 "Parameter out of range".  
 Deceleration feature is enabled only if the instruction JERKSMOOTH is active; however, the contouring is always active.

**Nota**  
 L'uso di questa istruzione è associato all'uso delle istruzioni JERKSMOOTH e SETSLOWPARAM e it is only applied in the movements with classic interpolation (LINEARABS, LINEARINC, CIRCABS, CIRCINC, HELICABS, HELICINC instructions).

## SETDECI

**Syntax**  
**SETDECI**                                    **axis1 [, ..., axis6] [, value]**

**Arguments**  
**axis1,[...axis6]**                        name of axis device  
**value**                                        constant or variable. Deceleration time

**Description**  
 It assigns to axes **axis1** and **axis2** the interpolation movement deceleration time indicated by **value**. Time is expressed in milliseconds. If **value** is omitted, the configuration parameter is taken instead.

See also SETACC, SETDEC, and SETACCI.

## SETDERIVI

**Syntax**  
**SETDERIVI**                                    **axis [, value]**

**Arguments**  
**axis**                                        name of axis device  
**value**                                        constant or variable. Derivative action coefficient. Char and integer variables are not allowed

**Description**

It assigns to the **axis** the **value** *derivative action coefficient* during axis interpolation movement. If **value** is omitted, the configuration derivative action coefficient is used. The instruction can not be applied to a step-by-step motor. See also instruction SETDERIV.

**SETFEEDFAI****Syntax**

**SETFEEDFAI**                      **axis [, value]**

**Arguments**

**axis**                                      name of axis device  
**value**                                      constant or variable. Feed forward percentage

**Description**

It assigns to the **axis** the *acceleration feed forward percentage* **value** for interpolation movements. If **value** is omitted, the configuration feed forward coefficient is used. If the instruction is applied to a step-by-step motor a system error is generated. The same happens if the **value** variable is set on a value which is not included between 0 and 100. See also instructions SETFEEDF,SETFEEDFI,SETFEEDFA.

**Note**

If the instruction is applied to an engine with SLM command and plate speed higher than 3750 RPM, the maximum feed forward adjustable value is 50. This is because the engine with Commands SLM performs a scaling on internal reference speed sent by the control.

**SETFEEDI****Syntax**

**SETFEEDI**                              **axis, value**

**Arguments**

**axis**                                      name of axis device  
**value**                                      constant or variable. It represents the feed rate override percentage

**Description**

It modifies the percentual **value** of **axis** feed rate override in relation to interpolation movements. See also instruction SETFEED.

**SETFEEDFI****Syntax**

**SETFEEDFI**                              **axis [, value]**

**Arguments**

**axis**                                      name of axis device  
**value**                                      constant or variable. Feed forward percentage

**Description**

It assigns to the **axis** the feed forward percentage **value** for interpolation movements. If the argument **value** is omitted, the system takes the feed forward percentage set in the configuration parameters of the concerned axis device. The instruction can not be applied to step-by-step motors. The **value** variable admits values included between 0 and 100. See also instructions SETFEEDF,SETFEEDFA,SETFEEDFAI.

**Note**

If the instruction is applied to an engine with SLM command and plate speed higher than 3750 RPM, the maximum feed forward adjustable value is 50. This is because the engine with Commands SLM performs a scaling on internal reference speed sent by the control.



## SETINTEGI

### Syntax

**SETINTEGI**                      **axis [, value]**

### Arguments

|              |  |
|--------------|--|
| <b>axis</b>  | name of axis device  |
| <b>value</b> | constant or variable. Integral action coefficient. Char and integer variables are not allowed. |

### Description

It assigns to the **axis** the *integral action coefficient* **value** used during axis interpolation movements.

If **value** is omitted, the configuration integral action coefficient is used.  
 The instruction can not be applied to step-by-step motors.  
 See also instruction SETINTEG.

## SETPROPI

### Syntax

**SETPROPI**                      **axis [, value]**

### Arguments

|              |   |
|--------------|---|
| <b>axis</b>  | name of axis device   |
| <b>value</b> | constant or variable. Proportional action coefficient. Chars and integers are not allowed |

### Description

It assigns to the **axis** the *proportional action coefficient* **value** used during axis interpolation movements.  
 If **value** is omitted, the configuration proportional action coefficient is used.  
 The instruction can not be applied to step-by-step motors.  
 See also instruction SETPROP.

## SETSLOWPARAM

### Syntax

**SETSLOWPARAM**                      **axis [,value1,value2]**

### Arguments

|               |   |
|---------------|---|
| <b>axis</b>   | name of device of axis type                             |
| <b>value1</b> | constant or variable double. General reduction factor   |
| <b>value2</b> | constant or variable double. Inversion reduction factor |

### Description

This instruction modifies the parameters needed to calculate the deceleration, where deceleration features are active while contouring (see instruction SETCONTORNATURE).  
 Deceleration speed is initially calculated for each axis in a technical way. In case of motion reversal, it can be reduced using **value2**. Later, among all the calculated speed rates, the minimum speed rate is taken into account, in order to comply with the dynamic of the more limiting axis. Finally, a further reduction of the deceleration speed of a factor which depends on **value1**, is possible.

If **value1** or **value2** are omitted, values by default are taken on, so that both the parameters do not take effect. The **value1** parameter represents the reduction percentage value of the theoretical speed slowdown. The applied slowdown speed is equal to  $(100 - \text{value1}) \cdot ((100 - \text{valore1}) / 100) \cdot \text{theoretical speed}$ . Maximum reduction value is equal to 100. In this case the resulting speed corresponds to 1% of the theoretical speed. Vice versa, when the value is 0 or it is omitted, the default value, that is, the entire theoretical speed, is taken into account.  
 The parameter **value2** represents the percentage of reduction, between 1 and 10 times, of the theoretic slowdown, should an axis reverse its motion. In particular, when **value2** is 100, the speed rate drops by 10 times. Vice versa, when it is equal to zero or it is omitted, the speed rate does not drop.

The instruction generates the system error 4399 "Parameter out of range", when the value set is less than 0 or greater than 100. It is important to remember that if the parameter **value1** is omitted, also the **value2** parameter must be omitted.

#### Note

This instruction requires the instructions JERKSMOOTH and SETCONTORNATURE and is only effective with classical interpolation (instructions LINEARABS, LINEARINC, CIRCABS, CIRCINC, HELICABS, HELICINC).

## SETVELI

#### Syntax

**SETVELI**                                    **axis1 [, ..., axis6] [, speed]**

#### Arguments

**axis1 [...axis6]**                        name of axis device to be interpolated  
**speed**                                        float constant or float variable

#### Description

It sets the highest **speed** of **axis1** and **axis2**, for interpolation movements. Speed is expressed in the axis measuring unit, specified in the configuration parameter. If the **speed** argument is omitted, maximum configuration speed is taken. Step-by-step axes can be used in this instruction only if they are controlled by a TRS-AX remote. See instruction SETVEL.

## SETVELILIMIT

#### Syntax

**SETVELILIMIT**                            **axis, speed**

#### Arguments

**axis**    name of axis device  
**speed**                                        float constant or float variable

#### Description

It sets the single **speed** components of the **indicated axis**, for interpolated movements. The speed is expressed in the UOM of the axis.

## Coordinated Movement

### SETFEEDCOORD

#### Syntax

**SETFEEDCOORD**                        **axis, value1, value2**

#### Arguments

**axis**    name of the device of axis type  
**value1**                                        constant or variable double. It represents the maximal percentage of feed rate override.  
**value2**                                        constant or variable integer. It represents the number of real time where the feed rates variation has to be applied.

#### Description

This modifies **value1** percentage of the **axis** feed rate's maximal instantaneous variation. Feed rate is not changed anymore in the time, expressed as a real time and defined into the **value 2** variable. In other words, after applying a variation of feedrate override of **value1**, as highest value, by a Real Times number of **value2**, any new feedrate variation cannot be applied. The combination of these two parameters defines a sort of acceleration/deceleration, that the axis can sustain. By modulating these two parameters, we can obtain some "step ramps" of the ramp required.

#### Note

For each axis involved in the coordinate move feedrate value and time should be set, otherwise the default values **value 1**=100 and **value2**=1 are taken. During the execution of the coordinated move (instruction COORDIN), the system calculates again the parameters **value1** and **value2** to apply to

the move according to all the involved axes' parameters. The motionless axes are excluded from the control. Both parameters are calculated as follows:  
**value1**: minimum value set on the moving axis;  
**value2**: value obtained dividing value1 by the lowest ratio **value1/value2**.

**Exemple**

;Function CoordinatedMove

```

Setquote X,0
Setquote Y,0
Setquote Z,0

setFeedCoord X, 20, 80
setFeedCoord Y, 10, 1
setFeedCoord Z, 3, 3

coordin matrix, deltaT, UP, rigaInit, rigaEnd,mask, _
          X,columnX, Y,columnY, Z,columnZ
waitstill x,y,z


```

fret

Suppose that in a specific passage of the coordinated move the z-axis does not move. Set parameters result to be

**Max\_Variation** = 10  
**Delta\_T** = 10 / 0.25 = 40

Therefore we have to following trace of oscilloscope, where the speed rate profile of the X-axis is marked in green and that of the Y-axis is marked in yellow.



## SETOFFSET

### Syntax

**SETOFFSET**                      **axis, position**

### Arguments

**axis**                              name of axis device  
**position**                         constant or variable. Offset for coordinated movements

### Description

It allows you to apply an offset to the position of a coordinated movement. The offset specified by the position parameter will be used in later coordinated movements, adding the indicated position to all the positions in the table. See also instruction COORDIN.

## Chained Movement

## RATIO

### Sintassi

**RATIO**                              **axis, [value]**

### Argomenti

**axis**                              name of axis device  
**value**                              constant or variable. Reduction ratio.

### Descrizione

Sets the chaining ratio of a slave axis with respect to its master. Slave axis movements will be scaled with respect to master movements by the set chaining ratio. If the **value** parameter is omitted, the ratio is reset to 1.0 (identical movements). Instruction generates system error if executed when the axis is not in slave state and the corresponding master axis is not in position state. See CHAIN instruction.

### Esempio

```
CHAIN                      X, Y
RATIO                      Y, 0.5                      ; reduction ratio 1/2

MOVABS                    X, 100                      ; Y axis will move to position 50
WAITSTILL                X
```

## SETDYNRATIO

### Syntax

**SETDYNRATIO**                      **axis, value**

### Arguments

**axis**                              name of the axis device  
**value**                              constant or double variable

### Description

This instruction allows the chaining ratio to be changed in a dynamic way during the movement of the master axis. It is possible to apply the new value of the chaining ratio, even though the previous variation has not ended. The declared **axis** must be a slave axis.

If the instruction is executed with master axis at the state POSITION, the new value of the chaining ratio **value** is instantaneously applied.

The variation of the chaining ratio occurs by means of a linear acceleration (or deceleration) ramp. The acceleration value employed is given by the acceleration of the Master-axis currently used for the point-to-point movement. This means that it is also possible to modify this ramp by setting a new acceleration value using the instruction SETACC.

This instruction can generate following system error:

- "4101: Inconsistent axis AxisName management", in the event that the **axis** declared is not a slave axis.

## Generic Parameters

### DYNLIMIT

#### Syntax

**DYNLIMIT** axis, state

#### Arguments

**axis** name of axis device  
**state** predefined constant Permitted values:  
**ON** enabling dynamic controls of the axis limits  
**OFF** disabling dynamic controls of the axis limits

#### Description

It enables or disables the dynamic test of exceeded axis limit. What distinguishes the dynamic test of exceeded axis limit from the static test of exceeded axis limit is that the first one verifies at each real time that the axis exceeds its limits, according to its current speed rate and to its maximum deceleration. The test of static type, instead, verifies instant by instant that the current arrival position of each axis is located within the positive or negative set axis limits. Furthermore, before the beginning of the move, the test of static type verifies if the positions given by the movement instructions exceed the set limits. Before a DYNLIMIT instruction SETLIMPOS and SETLINMNEG instructions must be set, in order to define the new limits.

#### Example


Check of the axes limits according to both typologies of static and dynamic test, with axes on the same movement directrix.

#### Static test.

In a generic movement the **Axis X1** cannot exceed the initial positive limit given by the **Axis X2** position. Axes limit check generates a system error no. 4108 " Axis X1: final position exceeding the software limit".

#### Dynamic test

It verifies in a generic movement that the instantaneous **X1 position** is located, with a proper sign and according to the movement direction of the axis, within the axis limits decreased of the minimum stop space of the same axis. The minimum stop space is calculated according to the instantaneous speed rate and to the deceleration set into the configuration of the point-to-point movement. Furthermore, this test does not verify before the beginning of the movement, if the positions given by the movement instructions exceed the set limits.



### ENABLESTARTCONTROL

#### Syntax

**ENABLESTARTCONTROL** axis, [timeout]

#### Arguments

**axis** name of axis device  
**timeout** variable. Wait timeout

#### Description

This instruction allows for **timeout** to be enabled and selected to control the non-start up or sudden stop of the axis.  
If the axis does not move by at least 2 steps in 200 RealTime when movement is executed, a system error is generated.  
If the **timeout** parameter is set to zero, the control is disabled. The instruction is not enabled if the theoretical speed is slower than two steps in 200 RealTime or if the movement ends in less than 200 RealTime.

#### Example

```
; axes starting timeout equal to 10 ms  
ENABLESTARTCONTROL x, 10
```

## NOTCHFILTER

**Sintassi**  
**NOTCHFILTER** **axis, [value]**

**Argomenti**  
**axis** name of axis device  
**value** constant or variable. Frequency value [Hz]. Valid values are in the range **0** to **500**.

#### Descrizione

Sets the notch filter's cut-off frequency for the axis specified. If **value** equals 0, the filter is disabled. If the **value** parameter is omitted, the value set in configuration will be used.

#### Esempio

```
; frequency cut-off 97 Hz  
NOTCHFILTER x, 97
```

## RESLIMNEG

**Syntax**  
**RESLIMNEG** **axis**

**Arguments**  
**axis** name of axis device

#### Description

It disables the test on the negative limit of the indicated **axis**.  
These instructions are usually used in homing routines to search for home switches, allowing the axes to exceed the set configuration values.  
See also instructions SETLIMNEG, SETLIMPOS, RESLIMPOS.

#### Example

Axis Homing routine

## RESLIMPOS

**Syntax**  
**RESLIMPOS** **axis**

**Arguments**  
**axis** name of axis device

#### Description

It disables the test on the positive limit of the indicated **axis**.




```
SETQUOTE      y, 0
SETVELI       X, 1.0
CIRCLE        X,Y,cw,100,90
WAITSTILL    X,Y
```

```
; Function whose backlash recovery is enabled
; (black line in the drawing)
```


```
SETQUOTE      X, 0
SETQUOTE      y, 0
SETVELI       X, 1.0
SETBACKLASH   X, 1.9
SETBACKLASH   y, 1.8
CIRCLE        X,Y,cw,100,90
WAITSTILL    X,Y
```

Carrying out the two functions generates two different traces.  
The first figure shows the interpolation on two axes, that present a backlash in the mated engine-reduction gear.



The second figure represents the same interpolation, but containing the instruction of backlash recovery.





## SETBIGWINFACTOR

**Syntax**  
**SETBIGWINFACTOR**      **axis, value**

### Arguments

|              |  |
|--------------|--|
| <b>axis</b>  | name of axis device  |
| <b>value</b> | double constant or variable. Multiplication factor for the calculation of the big window |

### Description

This instruction allows you to modify the multiplication factor for the calculation of the big window on **the axis** requested. To calculate the big window, we need to multiply the variable **value** by the parameter defined in the axes configuration of the position arrival window. The **value** that can be set should be included between 1 and 257 first and final value excluded. Default value is 4.0.

## SETDEADBAND

**Syntax**  
**SETDEADBAND**      **Asse,VMinPos,VMinNeg,VThrePos,VThreNeg**

### Arguments

|                 |   |
|-----------------|---|
| <b>axis</b>     | name of axis device   |
| <b>VMinPos</b>  | float variable or constant. Minimum positive voltage [Volt] |
| <b>VMinNeg</b>  | float variable or constant. Minimum negative voltage [Volt] |
| <b>VThrePos</b> | float variable or constant. Positive threshold [Volt]       |
| <b>VThreNeg</b> | float variable or constant. Negative threshold [Volt]       |

### Description

It sets the minimum voltage for the indicated axis. The minimum (positive/negative) voltage values are added to the theoretical reference voltage (positive/negative) , if this exceeds the (positive/negative) threshold value selected. If the theoretical reference voltage falls within threshold values, the actual reference voltage is forced to zero. Minimum voltage management can be disabled, setting all values to zero. The threshold values must always be below or equal to relative minimum voltage values.

When the system starts up, minimum voltage management is disabled.

## SETENCLIMIT

### Syntax

**SETENCLIMIT**                      **axis [, value]**

### Arguments

**axis**                                  name of axis device  
**value**                                  double constant or variable

### Description

It changes the incorrect encoder connection limit. This parameter is expressed in the axis UOM. Permitted values must fall within a range equal to 128 – 16384 encoder steps. If the parameter is omitted, the default value equal to 1024 steps is restored. For example, permitted values for an axis with a 1000 impulse/mm resolution will range from 0.128 to 16.384 mm.

If the **value** parameter is set to zero, the control of the incorrect encoder connection limit is disabled.

### Example

```
; set a incorrect encoder connection limit equal to 3.5  
SETENCLIMIT X, 3.5
```

## SETINDEXEN

### Syntax

**SETINDEXEN**                      **axis, state**

### Arguments

**axis**                                  name of axis device  
**state**                                  default constant. Permitted values:  
**ON** zero pulse state enabled  
**OFF** zero phases pulse disabled

### Description

It enables or disables coordinate zeroing on the indicated **axis** at the zero pulse. To execute this instruction, the axis must be a metering-type axis.

## SETINTEGTIME

### Syntax

**SETINTEGTIME**                      **axis [, value]**

### Arguments

**axis**                                  name of axis device  
**value**                                  integer constant or variable

### Description

It sets the number of link error samples used to calculate the integral component. Values are valid from 1 to 200. This parameter may be changed suddenly, but this may generate steps on the axis speed reference. It is advisable to change this parameter when the axes are stationary and disabled, or preferably free.

## SETIRMPP

### Syntax

**SETIRMPP**                              **axis, speed**

### Arguments

**axis**                                  name of axis device

**speed** float constant or float variable. Ramp start speed

**Description**

It assigns the *ramp start* **speed** value to the **axis**. It is the minimum speed of a step-by-step motor.  
This instruction is used for axes moved by step-by-step motors.

**SETLIMNEG**

**Syntax**

**SETLIMNEG** **axis [, position]**

**Arguments**

**axis** name of axis device  
**position** constant or variable. Negative limit

**Description**

It sets the **axis** negative limit **position**.  
If **position** is omitted, the configuration negative limit is set.  
These instructions are usually used in homing routines to look for home switches, allowing the axes to exceed set configuration values.  
See also instructions RESLIMNEG, SETLIMPOS, RESLIMPOS.

**Example**

Axis Homing routine

**SETLIMPOS**

**Syntax**

**SETLIMPOS** **axis [, position]**

**Arguments**

**axis** name of axis device  
**position** constant or variable. Positive limit

**Description**

It sets the positive limit **position** for the **axis**.  
If **position** is omitted, the configuration positive limit is set.  
These instructions are usually used in homing routines to look for home switches, allowing the axes to exceed set configuration values.  
See also instructions RESLIMNEG, RESLIMPOS, SETLIMNEG.

**Example**

Axis Homing routine

**SETMAXER**

**Syntax**

**SETMAXER** **axis, value [, direction]**

**Arguments**

**axis** name of axis device  
**value** constant or variable. Maximum loop error  
**direction** predefined constant. Axis direction  
Possible values are:  
**POSITIVE**  
**NEGATIVE**

**Description**

It assigns to the **axis** the maximum chase **value** admitted by control, in the indicated direction, before generating a "servoerror".  
If **direction** is omitted, the maximum tracking value is set for both directions.

**SETMAXERNEG****Syntax**


**SETMAXERNEG**                      **axis, backlog , advance**

**Arguments**

**axis**                                      name of axis device  
**backlog**                                  constant or variable. Maximum backlog error  
**advance**                                  constant or variable. Maximum advance error

**Description**

Sets the **axis** maximum values for backlog and advance loop errors allowed by control, in negative direction, before generating "servo error". Loop error is computed as the difference between theoretical coordinate (where the axis should be positioned) and real coordinate. When the axis moves in negative direction, a negative value of loop error indicates that the axis has a backlog, while a positive value of loop error indicates that the axis is in advance. If this instruction is not used, the maximum loop error values set in axis configuration will be assumed as default by the numerical control; in this case, the maximum advance error will be equal to 1/4 of the maximum backlog error.

**Example**

```
;Maximum axis delay is 10mm, maximum advance 5mm
SETMAXERNEG      Axes.X, 10, 5
```

**SETMAXERPOS****Syntax**


**SETMAXERPOS**                      **axis, backlog , advance**

**Arguments**

**axis**                                      name of axis device  
**backlog**                                  constant or variable. Maximum backlog error  
**advance**                                  constant or variable. Maximum advance error

**Description**

Sets the **axis** maximum values for backlog and advance loop errors allowed by control, in positive direction, before generating "servo error". Loop error is computed as the difference between theoretical coordinate (where the axis should be positioned) and real coordinate. When the axis moves in positive direction, a positive value of loop error indicates that the axis has a backlog, while a negative value of loop error indicates that the axis is in advance. If this instruction is not used, the maximum loop error values set in axis configuration will be assumed as default by the numerical control; in this case, the maximum advance error will be equal to 1/4 of the maximum backlog error.

**Example**

```
;Maximum axis delay is 10mm, maximum advance 5mm
SETMAXERPOS      Axes.X, 10, 5
```

## SETPHASESINV

### Syntax

**SETPHASESINV**                      **axis, state**

### Arguments

|              |   |
|--------------|---|
| <b>axis</b>  | name of axis device   |
| <b>state</b> | default constant. Permitted values:<br><b>ON</b> phases inversion stage enabled<br><b>OFF</b> phases inversion state disabled |

### Description

It enables or disables phases inversion on the indicated **axis**, allowing any encoder phase wiring inversion to be offset using software. If used with the reference inversion, the axis direction can be inverted (if wiring is correct).  
To execute this instruction, the axis must be in a FREE state.

## SETMAXERTYPE

### Syntax

**SETMAXERTYPE**                      **axis, type**

### Arguments

|             |  |
|-------------|--|
| <b>axis</b> | name of axis device  |
| <b>type</b> | integer constant. Permitted values:<br>0 = sets servoerror to threshold value (default value)<br>1 = sets dynamic servoerror |

### Description


This instruction allows the **type** of servoerror test to be set. Conventional servoerror management sets a pair of limits (positive and negative), which are constant as axis speed changes. This type of management sizes the limits depending on the axis's maximum speed, i.e. it sets a limit so that the error in normal operating conditions is not set off. However at low speeds, the link error generally has far lower values than the set limit, and this delays error condition identification.

Window management of the servoerror is based on calculating the theoretical link error. The positive and negative servoerror limits are calculated as a function of this, adding and subtracting a threshold value from them. If the actual link error exceeds this threshold, a servoerror is generated.


### Nota

If you set the test on dynamic servoerror it is generally necessary to amend the limit values of positive servoerror and negative servoerror limit set in axis configuration for the servoerror threshold. This is because the above values are used as initial values for the calculation of the loop-error.

"Classic" ServoError limit":



"Window" ServoError limit":



### SETREFINV

**Syntax**

**SETREFINV**                      **axis, state**

**Arguments**

- axis**                      name of axis device
- state**                    default constant. Permitted values:  
**ON** reference inversion state enabled  
**OFF** reference inversion state disabled

**Description**

It enables or disables reference inversion on the indicated **axis**. If used with phases inversion, the axis direction can be inverted (if wiring is correct).  
 To execute this instruction, the axis must be in a FREE state.  
 See also SETPHASESINV.

### SETRESOLUTION

**Syntax**

**SETRESOLUTION**                      **axis [, value]**

**Arguments**

- axis**                      device name of axis type

**value** constant or double variable

**Description**

changes the resolution of the specified axis. If **value** is left out, the resolution value, that was set in the configuration, is used. Resolution value can only be edited if the axis is stationary (axis state=coordinate), otherwise the system error no. 4101 "Inconsistent axis management" is generated.

## 9.2.5 Counter

### DECOUNTER

**Syntax**

**DECOUNTER** **countername** [, **value**]

**Arguments**

**countername** name of counter device  
**value** constant or variable or counter device

**Description**

It decreases the counter **countername** by the specified **value**. If no **value** is set, it assumes value 1. See also instructions SETCOUNTER and INCOUNTER.

### INCOUNTER

**Syntax**

**INCOUNTER** **countername** [, **value**]

**Arguments**

**countername** name of counter device  
**value** constant or variable or counter device

**Description**

It increases the counter **counter name** by the specified **value**. If no **value** is set, it assumes value 1. See also instructions SETCOUNTER and DECOUNTER.

### SETCOUNTER

**Syntax**

**SETCOUNTER** **countername, value**

**Arguments**

**countername** name of counter device  
**value** constant or variable or counter device

**Description**

It sets the counter **countername** to the specified **value**. See also INCOUNTER and DECOUNTER.

## 9.2.6 Timer

### HOLDTIMER

**Syntax**

**HOLDTIMER** **timename**

**Arguments**

**timename** name of timer device

**Description**

It blocks the updating of the timer **timename**. See also STARTTIMER and SETTIMER.

## SETTIMER

### Syntax

**SETTIMER**                      **timename, time**

### Arguments

**timename**                      name of timer device  
**time**                              constant or variable or timer device

### Description

It sets the **timename** to the specified **time** (in seconds).  
 Only positive values (higher than 0) are admitted. Maximum precision of timers is 4 ms.  
 See also STARTTIMER and HOLDTIMER.

### Example

```
;The Function sets a timer
SETTIMER            Timeout,20        ; Set timer Timeout to value: 20 seconds
STARTTIMER        Timeout,DOWN ; Timer starts in decrease mode. When it
                                                 ; reaches 0 it stops
```

## STARTTIMER

### Syntax

**STARTTIMER**                      **timename [, direction]**

### Arguments

**timename**                      name of timer device  
**direction**                      predefined constant. Possible values are:  
**UP**    crescent  
**DOWN**    decrescent

### Description

It starts the **timename** timer on the mode specified by **direction**, if specified.  
 If **direction** is omitted, it is automatically set on **DOWN** mode.  
 When a timer (started in decrescent mode) reaches zero it automatically stops.  
 See also HOLDTIMER and SETTIMER.

## 9.2.7 Variables, Vectors and Matrixes

### CLEAR

#### Syntax

**CLEAR**                              **varname or vector or matrix[rowmatrix]**

#### Arguments

**varname**                              name of variable  
**vector**                                name of vector  
**matrix**                                name of matrix  
**matrixrow**                            constant or variable or counter. Matrix row

#### Description

It clears to 0 the part of memory reserved for variables (**varname**), vectors (**vector**), matrixes (**matrix**) or the elements of a matrix row.

### FIND

#### Syntax

**FIND**                                **matrix, column, min\_limit, max\_limit, value, variable**  
**FIND**                                **vector, min\_limit, max\_limit, value, variable**

#### Arguments

**matrix**                                name of the matrix. The matrix in which to search.  
**vector**                                name of the vector. The vector in which to search.



|                  |   |
|------------------|---|
| <b>column</b>    | constant or integer variable or counternumber. Number of the matrix column in which to search |
| <b>min_limit</b> | constant or variable. Minimum index of the vector or matrix from which search starts          |
| <b>max_limit</b> | constant or variable. Maximum index of the vector or matrix where the search ends             |
| <b>value</b>     | constant or variable. Value to be found   |
| <b>variable</b>  | variable. Result of the search  |

**Description**

It carries out a sequential search of a value inside a **vector** or the **column** of a **matrix** and puts the index of the element in the **variable** variable.  
 If the value is not found, the **variable** variable will assume value -1.

**FINDB**

**Syntax**

|              |  |
|--------------|--|
| <b>FINDB</b> | <b>matrix, column, min_limit, max_limit, value, variable</b> |
| <b>FINDB</b> | <b>vector, min_limit, max_limit, value, variable</b>         |

**Arguments**

|                  |   |
|------------------|---|
| <b>matrix</b>    | name of the matrix. The matrix in which to search.  |
| <b>vector</b>    | name of the vector. The vector in which to search.  |
| <b>column</b>    | constant or integer variable or counternumber. Number of the matrix column in which to search |
| <b>min_limit</b> | constant or variable. Minimum index of the vector or matrix from which search starts          |
| <b>max_limit</b> | constant or variable. Maximum index of the vector or matrix where the search ends             |
| <b>value</b>     | constant or variable. Value to be found   |
| <b>variable</b>  | variable. Result of the search  |

**Description**

It performs a rapid search for a value inside a **vector** or the **column** of the **matrix** and puts the index of the element in the **variable** variable. For the search to be successful, the **vector** or the **column** of the **matrix** must have been previously sorted with the SORT instruction according to an increasing order.  
 If the value is not found, **variable** will assume value -1.

**LASTELEM**

**Syntax**

|                 |                             |
|-----------------|-----------------------------|
| <b>LASTELEM</b> | <b>vector, vectelements</b> |
| <b>LASTELEM</b> | <b>matrix, matrows</b>      |

**Arguments**

|                     |  |
|---------------------|--|
| <b>matrix</b>       | name of matrix                             |
| <b>vector</b>       | name of vector                             |
| <b>vectelements</b> | variable. Number of elements of the vector |
| <b>matrows</b>      | variable. Number of rows of the matrix     |

**Description**

It writes the number of elements of the **vector** in the **vectelements** variable, or the number of rows of the **matrix** in the **matrows** variable.

**LOCAL**

**Syntax**

|              |  |
|--------------|--|
| <b>LOCAL</b> | <b>varname AS type</b>   |
| <b>LOCAL</b> | <b>vector[n° elements] AS type</b>   |
| <b>LOCAL</b> | <b>matrix[n° rows] AS type, type, type, etc.</b>                             |
| <b>LOCAL</b> | <b>matrix[n° rows] AS type:colname1, type: colname2, type:colname3, etc.</b> |

**Arguments**

|                            |  |
|----------------------------|--|
| <b>varname</b>             | name of variable   |
| <b>[n° elements]</b>       | variable or constant (obligatory argument). Number of elements of the vector |
| <b>[n° rows]</b>           | constant or variable (obligatory argument). Number of rows of the matrix     |
| <b>type</b>                | char, integer (32 bit), float (32 bit), double (64 bit), string, timer       |
| <b>colname1...colnameN</b> | name of column. Label.   |

**Description**

Declaration of a local variable. Only the PARAM instruction, which defines the parameters of the function, can appear before this instruction.  
For further information about local variables see Local variables.

**MOVEMAT****Syntax**

```
MOVEMAT   matsourcename, mataddrname

MOVEMAT   matsourcename[row source], mataddrname[row addr]

MOVEMAT   matsourcename[row source], mataddrname[row addr],num row
```

**Arguments**

|                      |  |
|----------------------|--|
| <b>matsourcename</b> | name of source matrix  |
| <b>row source</b>    | start rows number for the copy of the source matrix (obligatory argument)        |
| <b>mataddrname</b>   | name of addressee matrix   |
| <b>rowaddr</b>       | start rows number for the copy into the destination matrix (obligatory argument) |
| <b>numrow</b>        | rows number to copy  |

**Description**

It copies the content of the entire matrix **matsourcename** in the matrix **mataddrname** or one or more rows **num row** of the matrix row **matsourcename[rowsource]** in the matrix row **mataddrname[rowaddr]**. If the parameter **numrow** is not specified one only row is copied. The two matrixes must have the same type of structure (same number of columns and same type of data in each column) and when entire matrix is copied the same number of rows. It is possible to move rows of data within the same matrix.

**Example**

```
Movemat Mx1, Mx2           ; copies Mx1 matrix in Mx2

Movemat Mx1[10], Mx2[3]   ; copies row 10 of matrix Mx1 in row 3
                           ; of Mx2

Movemat Mx1[1], Mx1[7]   ; copies row 1 of matrix Mx1 in row 7
                           ; of Mx1

Movemat Mx1[2], Mx2[8],6  ; copies 6 rows starting from row 2
                           : of matrix Mx1
                           ; into matrix Mx2 starting from row 8

Movemat Mx1[2], Mx1[10],4 ; copies 4 rows starting from
                           ; row 2 of matrix Mx1 into the same
                           ; matrix Mx1 starting from row 10
```

**PARAM****Syntax**

|                |   |
|----------------|---|
| <b>[PARAM]</b> | <b>varname AS type</b>  |
| <b>[PARAM]</b> | <b>vector[n° elements] AS type</b>                                  |
| <b>[PARAM]</b> | <b>matrix[n° rows] AS type, type, type, etc.</b>                    |
| <b>[PARAM]</b> | <b>matrix[n° rows] AS type: alias, type:alias, type:alias, etc.</b> |

**Arguments**

|                      |   |
|----------------------|---|
| <b>varname</b>       | name of variable  |
| <b>[n° elements]</b> | constant (obligatory argument)                                  |
| <b>[n° rows]</b>     | constant (obligatory argument)                                  |
| <b>type</b>          | char, integer (32 bit), float (32 bit), double (64 bit), string |

**Description**

The parameters behave like the local variables (see LOCAL), but are activated by whoever calls the function. The syntax for parameter declarations is the same used for local variables. Parameters may be by value or by reference depending on their kind. See "Functions". They must be declared before any other instruction. For further information see Local variables.

**SETVAL**

**Syntax**

**SETVAL value, varname**

**Arguments**

|                |                                    |
|----------------|------------------------------------|
| <b>value</b>   | constant or variable or devicename |
| <b>varname</b> | variable or devicename             |

**Description**

It assigns the specified **value** to the **varname** variable or to the n-th vector or matrix element.

**SORT**

**Syntax**


**SORT matrix, column [, order], min\_limit, max\_limit**  
**SORT vector [,order], min\_limit, max\_limit**

**Arguments**

|                  |  |
|------------------|--|
| <b>matrix</b>    | name of the matrix.  |
| <b>vector</b>    | name of the vector.  |
| <b>column</b>    | constant or integer variable or countername. Matrix column number  |
| <b>order</b>     | predefined constant. It indicates order mode<br>Possible values are:<br><b>UP</b> increasing order<br><b>DOWN</b> decreasing order |
| <b>min_limit</b> | constant or variable. Minimum index of the vector or matrix from which sorting starts  |
| <b>max_limit</b> | constant or variable. Maximum index of the vector or matrix where sorting ends   |

**Description**

It sorts the values inside a **vector** or a **matrix**, according to the order specified in the **order** constant. In the case of a matrix, the order of the rows is dictated by the increasing (UP) or decreasing (DOWN) disposition of the values in the selected **column**. If the **order** argument is omitted, the UP mode is automatically selected.



## 9.2.8 Strings

### ADDSTRING

#### Syntax

**ADDSTRING**                                    **stringname1, stringname2, stringname3**

#### Arguments

|                    |  |
|--------------------|--|
| <b>stringname1</b> | string constant or string variable. Source string      |
| <b>stringname2</b> | string constant or string variable. String to be added |
| <b>stringname3</b> | string variable. Result string                         |

#### Description

Chain of two strings.

It adds the string identified by **stringname2** to the string identified by **stringname1** and puts the result in the string identified by **stringname3**.

The maximum dimension of a string is 255 characters+ the terminator, so that the result of the chaining of the first two strings can not exceed this limit.

#### Example

Operations on strings

### CONTROLCHAR

#### Syntax

**CONTROLCHAR**                                    **value, stringname**

#### Arguments

|                   |   |
|-------------------|---|
| <b>value</b>      | char or integer constant or char or integer variable. Value to be converted |
| <b>stringname</b> | string variable. Result string  |

#### Description

It converts the value identified by **value** in ASCII characters and puts the result in the **stringname** string (which corresponds to the first byte).

The former content of the string is lost. This instruction is useful if control or unprintable characters( such as the character NULL = 0x00) have to be inserted in a string.

It accepts strings of at least 2 characters: 1 character + the terminator. If the string is of only one array[1] as char character, the "Incorrect macro argument" system error is signalled

#### Example

Operations on strings

### LEFT

#### Syntax

**LEFT**    **sourcestringname, numcharacters, leftstringname**

#### Arguments

|                         |   |
|-------------------------|---|
| <b>sourcestringname</b> | string constant or string variable. Source string       |
| <b>numcharacters</b>    | constant or variable. Number of characters to be copied |
| <b>leftstringname</b>   | string variable. Destination string                     |

#### Description

It copies the first **numcharacters** of the **sourcestringname** in the **leftstringname**.

In practice, it fetches the left side of the source string. See also instructions MID and RIGHT.

#### Example

Operations on strings

## LEN

**Syntax**  
LEN

**stringname, variable**

**Arguments**

**stringname** string variable. String  
**variable** variable

**Description**

It calculates the number of characters contained in the **stringname** string (excluding the terminator) and puts the result in **variable**.

**Example**

Operations on strings

## MID

**Syntax**  
MID

**sourcestringname, firstchar [, numcharacters],  
rightstringname**

**Arguments**

**sourcestringname** string constant or string variable. Source string  
**numcharacters** constant or variable. Number of characters to be copied  
**rightstringname** string variable. Destination string  
**firstchar** constant or variable. Position of start copy character

**Description**

It extracts a number of characters identified by **numcharacters**, starting from **firstchar**, from the string identified by **sourcestringname**.  
The extracted substring is set in the string identified by **rightstringname**.  
If **numcharacters** is omitted, the **sourcestring** is copied from the **firstchar** position, to the end of it. In practice it fetches the middle part of the source string.  
See also instructions LEFT and RIGHT.

**Example**

Operations on strings

## RIGHT

**Syntax**  
RIGHT

**sourcestringname, numcharacters, rightstringname**

**Arguments**

**sourcestringname** string constant or string variable. Source string  
**numcharacters** constant or variable. Number of characters to be copied  
**rightstringname** string variable. Destination string

**Description**

It copies the last **numcharacters** of the **sourcestringname** string in the **rightstringname** string. In practice, it fetches the right side of the source string. See also instructions LEFT and MID

**Example**

Operations on strings

## SEARCH

**Syntax**  
SEARCH

**stringname, character, variable**

**Arguments**

**stringname** string variable.

**character** char constant or string constant or string variable. Character or string to be found  
**variable** variable

**Description**

It looks for the position of the ASCII character identified by **character** (which may also be a string) within the **stringname** string and puts the index of the result in **variable**.  
If **character** is not found, **variable** will contain the value -1.

**Example**

Operations on strings

**SETSTRING****Syntax**

**SETSTRING** "value", stringname

**Arguments**

**value** string constant or string variable (in inverted commas)  
**stringname** destination string

**Description**

It copies a string.  
It copies the ASCII characters contained in the string identified by "**value**" in the string identified by **stringname**.  
To insert unprintable characters in a string see instruction CONTROLCHAR.

**Example**

Operations on strings

**STR****Syntax**

**STR** value, stringname

**Arguments**

**value** constant or variable. Source value to be converted  
**stringname** string variable. Destination string

**Description**

It converts the **value** in ASCII characters and puts the result in the **stringname** string. It can be used to change an integer variable in a string. For example the number 10 becomes the string "10".

**Example**

Operations on strings

**VAL****Syntax**

**VAL** stringname, result

**Arguments**

**stringname** string variable. String to be converted  
**result** variable. Transformed string

**Description**

It transforms the content of the **stringname** string in a decimal number and puts the result in the **variable**.  
For example, the "123" string becomes 123..

**Example**

Operations on strings

## 9.2.9 Communications

### CLEARRECEIVE

**Syntax**

**CLEARRECEIVE**

**Arguments**

No argument

**Description**

It empties the list of executed but not satisfied RECEIVES.

### COMCLEARRXBUFFER

**Syntax**

**COMCLEARRXBUFFER**            **COMnumber**

**Arguments**

**COMnumber**                      predefined constant. Number of serial port. Possible values are: from **COM1** to **COM8**.

**Description**

The instruction empties the receive buffer of the serial **COMnumber**. Any data contained is deleted.

### COMCLOSE

**Syntax**

**COMCLOSE**                      **COMnumber**

**Arguments**

**COMnumber**                      predefined constant. Number of serial port. Possible values are: from **COM1** to **COM8**.

**Description**

It closes the **COMnumber** serial line opened by a **COMOPEN**. It is also necessary to close the serial line when a task that has opened a serial port is closed for any reason.

### COMGETERROR

**Syntax**

**COMGETERROR**                **COMnumber, variable**

**Arguments**

**COMnumber**                      predefined constant. Number of serial port. Possible values are: from **COM1** to **COM8**.

**variable**                         integer variable. The result of the last operation executed on the serial

**Description**

The instruction reads the return code of the last serial communication instruction called on the **COMnumber** port. Through this instruction it can learn whether a read or write task was successful and, if not, it can find the returned error code.

The error codes are listed below.

|                                      |    |
|--------------------------------------|----|
| Normal return                        | 0  |
| Transmission buffer full             | 2  |
| Device already open                  | 3  |
| Port not valid or not configured     | 6  |
| I/O port enabling failed             | 7  |
| Connection to interrupt not possible | 8  |
| Serial port (com) not yet open       | 9  |
| The serial device (com) is occupied  | 12 |
| Connection to RTX not possible       | 14 |

**COMGETRXCOUNT****Syntax****COMGETRXCOUNT**                    **COMnumber, numchar****Arguments**

**COMnumber**                    predefined constant. Number of serial port. Possible values are: from **COM1** to **COM8**.

**numchar**                    number of characters in buffer

**Description**

The instruction returns the number of characters present in the reception buffer. It allows you to know if the serial port has received any characters.

**COMOPEN****Syntax****COMOPEN**                    **COMnumber, baudrate, wordsize, stopbits, parity****Arguments**

**COMnumber**                    predefined constant. Number of serial port. Possible values are: from **COM1** to **COM8**.

**baudrate**                    communication baudrate. Possible values are: 2400, 4800, 9600, 19200, 38400, 57600, 115200

**wordsize**                    size of data words. Possible values are: 5, 6, 7, 8.

**stopbits**                    stop bits. Possible values are: 1, 2

**parity**                    predefined constant. Parity. Possible values are: **NOPARITY**, **ODDPARITY** and **EVENPARITY**

**Description**

It opens a serial line. This instruction is executed before any other instruction for serial line management. If any other instruction concerning the same serial line is executed before **COMOPEN**, a system error is generated. The transmitted parameters must be included among the above mentioned values.

The serial line communication channel is bound to the task which has executed the **COMOPEN** instruction. If task ends, the communication channel is automatically closed.

See also **COMCLOSE**, **COMREAD**, **COMWRITE**, **COMREADSTRING**, **COMWRITESTRING**.

**Note**

The number of the serial available lines depends on the hardware environment of the numeric control (see documentation). In the RTX environment only **COM1** and **COM2** are available.

**COMREAD****Syntax****COMREAD**                    **COMnumber, buffer, numchartoread, numcharread [,timeout]****Arguments**

**COMnumber**                    predefined constant. Number of serial port. Possible values are: from **COM1** to **COM8**.

**buffer**                    vector of char. The vector where the data is deposited.

**numchartoread**                    number of characters which should be read on the serial line

**numcharread**                    number of characters really read

**timeout**                    wait timeout (in seconds)

**Description**

The instruction reads certain characters of the **COMnumber** serial. The read characters are memorised in the variable **buffer**. This variable must be char vector type. The field **ToRead** indicates the number of characters that the instruction must read. If the serial reception buffer contains less characters and the **timeout** parameter is not specified, the instruction will end immediately, specifying the number of characters it has really read in the parameter **Read**. If the parameter **timeout** is specified, the instruction will have to wait a maximum of seconds indicated in the variable, for other characters to arrive. If **timeout** runs out, the instruction will exit, still specifying in **Read** the number of characters really copied in **buffer**.



## COMREADSTRING

### Syntax

**COMREADSTRING** **COMnumber, buffer, numcharread [,terminator [,timeout]]**

### Arguments

|                    |  |
|--------------------|--|
| <b>COMnumber</b>   | predefined constant. Number of serial port. Possible values are: from <b>COM1</b> to <b>COM8</b> . |
| <b>buffer</b>      | vector of char. The vector where the data is deposited.  |
| <b>numcharread</b> | number of characters really read   |
| <b>terminator</b>  | transmission termination character   |
| <b>timeout</b>     | wait timeout (in seconds)  |

### Description

The instruction reads certain characters of the **COMnumber** serial. Unlike the **COMREAD** it reads the serial until it finds the terminator character. The read characters are memorised in the variable **buffer**. This variable must be a char type vector. The **numcharread** field indicates the number of characters which the instruction has really read in the serial line and copied in the **buffer**. The parameter **terminator** indicates the character that will function as transmission terminator. In practice the instruction will have to read the characters of the serial until it reaches a character like the one specified in this parameter. This parameter is optional. If no other character is set, the terminator character is zero. The zero is not copied in the buffer as it is recognised as a parameter, while any other termination character specified in the instruction will be copied. The **timeout** is another parameter that indicates how many seconds the instruction will have to wait for more characters if it has emptied the reception buffer without finding any termination character. If the **timeout** parameter is not specified, the instruction will terminate as soon as the reception buffer has been emptied.

## COMWRITE

### Syntax

**COMWRITE** **COMnumber, buffer, towrite**

### Arguments

|                  |  |
|------------------|--|
| <b>COMnumber</b> | predefined constant. Number of serial port. Possible values are: from <b>COM1</b> to <b>COM8</b> . |
| <b>buffer</b>    | char vector. The vector containing the data to be written.   |
| <b>towrite</b>   | number of characters to be written   |

### Description

The instruction writes the characters present in the buffer variable in the **COMnumber** serial line. The **towrite** parameter specifies the number of characters to be written.

## COMWRITESTRING

### Syntax

**COMWRITESTRING** **COMnumber, buffer [,terminator]**

### Arguments

|                   |  |
|-------------------|--|
| <b>COMnumber</b>  | predefined constant. Number of serial port. Possible values are: from <b>COM1</b> to <b>COM8</b> . |
| <b>buffer</b>     | char vector. The vector containing the data to be written.   |
| <b>terminator</b> | transmission termination character   |

### Description

The instruction writes the characters contained in the buffer variable on the **COMnumber** serial line. Unlike the **COMWRITE** it writes on the serial until it finds the character **terminator**. The parameter **terminator** is optional. If it is not specified, the instruction will transmit until it finds a zero character. The zero is not transmitted, while any other specified control character is.

## RECEIVE

### Syntax

**RECEIVE** **[source, ] identifier, flags [, container]**

**Arguments**

|                   |  |
|-------------------|--|
| <b>source</b>     | string constant                                |
| <b>identifier</b> | string constant                                |
| <b>flags</b>      | integer constant                               |
| <b>container</b>  | name of device or variable (numeric or string) |

**Description**

This instruction is used, together with SEND, to exchange information between the modules of the plant and the supervisor PC. SEND is used to send information, RECEIVE to ask for information. Information can be requested from Albatros or an external program (Server OLE Automation). In the second case the request is still received by Albatros who will then send it to the external program.

The parameter **source** is a string that allows you to specify where the request for information is directed to. There are three classes of sources:

- sources beginning with the "@" character (see list further on). The source is really Albatros, or better, one of its functions.
- sources not beginning with the "@" character. They are considered as Server OLE, as soon as Albatros receives an information request addressed to them, it will try to send them in execution and then to pass on the information request received from the module.
- unspecified source (the parameter is actually optional). In this case the information is read in a table kept by Albatros. If the information is not included in the table the request remains open and will be satisfied as soon as the information is available (provided by another module or an external program).

The parameter **identifier** is the name of the requested information, and can not be omitted. It takes on different meanings according to the source:

- if Albatros is the source, the identifier will be a command related to the accessed function
- if a Server OLE is the source, it will be a property of the OLE object requested.
- if the source is not specified it will be the label that identifies the information in the Albatros table.

The **flags** parameter allows you to specify how the requested information is to be treated by Albatros. The acceptable values and their effects are the following:

| <b>value</b> | <b>command</b> | <b>description</b>   |
|--------------|----------------|--|
| \$0008H      | CancelAfter    | The information is deleted after being read.   |
| \$0800H      | UpdateFlags    | Modifies the state of the information (already read/to be read) without modifying the data |
| \$8000H      | Delete         | Deletes the information  |

The parameter **container** is the variable (or device) in which the requested information will be stored. This may be omitted, in which case the request is the notification of an event (it can be used to synchronise the execution of the GPL code on various modules).

List of **sources** managed by Albatros and their commands:

**"@List"**

Makes possible to control the commands Simulation and Setpoint

Following commands are allowed (Parameter **identifier**):

- Sim,0,container: requires the Simulation button state, that is written on the Simulazione flag switch. The return variable **container** has a 1 value, if any error did not occur, otherwise it has a value 0.
- Setp,0,container: requires Setpoint button state, that is written on CmdSetP flag switch. The return variable **container** has a 1 value, if any error did not occur, otherwise it has a 0 value.
- Esc,0, container: requires Setpoint button state, that is written on Escluso flag switch. The return variable **container** has a 1 value, if any error did not occur, otherwise it has a value 0.

**"@Environ"**

It allows you to receive information about the state of the system: user's access level, modules connected to the supervisor etc. The requested information is stored in the parameter **container**. The acceptable values for the parameter **identifier** and the relative answers are:

- "AccessLevel" access level to the system 0=user, 1=service, 2=builder, 3=tpa
- "MaskConfModules" mask of configured modules
- "MaskActiveModules" mask of connected modules
- "CurrentModule" module sending the request
- "*mod*:NamePC" name of PC corresponding to module "*mod*". ( *mod* must be between 0 and 15)
- "LocalDateTime" date and time of PC in YYYY/MM/DD HH:MM:SS format

The masks of the connected and configured modules are bit masks. The lowest weight bit is module 0. The bit of each module is 1 if the module is connected or configured. In case of "NamePC" the module number is not compulsory; if omitted, the number is assumed of the module which instanced the request.

### "@Syn"

Communication between GPL and the synoptic view display. It allows you to open and close the synoptic views with GPL control and request information from a synoptic cell.

The following commands are possible (parameter **identifier**):

- "Open:*filename*" opening of the synoptic *filename.syn*
- "Close:*filename*" closure of the synoptic *filename.syn*
- "*cellname*" cell from which the requested information is read

It is possible to get information about the axes move window according to the technical data, that has been defined also for the parameter **source** "@Devices", as below.

It is possible to get some information about the axes movement, according to the specifications defined also for the parameter **source** "@Devices", as below.

### "@FileName"

stores an association between a constant string and a file name, which can be made up with string variables. Since Albatros has received the communication of the association it replaces all the following file names with the name received by means of this instruction. The parameter **identifier** is the name of the file. The name of the file is a variable string. If in the parameter **identifier** the complete path in which to store the file is not specified, Albatros considers the one defined in tpa.ini into the section [tpa] at the item *dirreport*. The value of the parameter **identifier** is stored in tpa.ini in the section [GPLFileName] at the item Log, so that it can be used again also in the Albatros executions, that follow. To cancel the association you need to set an empty string as parameter **identifier**. The association, which is defined in this way, can be used for each module.

### "@FileDelete"

Delete a file. The **identifier** parameter is the name of the file which will be deleted (complete path). If in the parameter **identifier** the complete path in which to store the file is not specified, Albatros considers that defined in tpa.ini in the section [tpa] at the item *dirreport*. The file name can be defined according to the rules, that have been described in the parameter **source** @FileRead. The **container** parameter contains the value:

- 1 if the file has been deleted
- 0 if not

### "@FileRead"

It reads the file content. The parameter **identifier** is the name of the file that will be read (complete path). If in the parameter **identifier** the complete path in which to store the file is not specified, Albatros considers that defined in tpa.ini in the section [tpa] at the item *dirreport*. If the **identifier** starts and finishes with a %-symbol, the inside string is searched in tpa.ini into the section [tpa] and used as a file name. Inside the name can be inserted some symbols that will be substituted during the instruction execution:

- %n module number that execute RECEIVE instruction
- %h current time (format 00-23)
- %d current day (format 01-31)
- %m current month (format 01-12)
- %y current year (four numbers format)

If the parameter **container** is defined as a char variable, it will contain a byte read by the file, if it is defined as a string, it will contain an entire string of the file test, if defined as a file integer, it will contain the missing number of bytes to reach the end of the file (0= file end).

To place the pointer on the file at the beginning of the file itself, the parameter **container** should be omitted.

### "@FileExist"

It checks the existence of a file. The parameter **identifier** is the name of the file that will be read (complete path). If in the parameter **identifier** the complete path in which to store the file is not specified, Albatros considers that defined in tpa.ini in the section [tpa] at the item *dirreport*. The name of the file can be defined according to the rules that have been described in the parameter **source** @FileRead. The parameter **container** contains the value:

- different from 0, if the file exists
- 0, if the file does not exist

### "@Devices"

Request to open or close the Diagnostic window of the module sending the information. The identifier parameter can assume the following values:

- "Open"           open Diagnostic
- "Close"         close Diagnostic

The parameter **identifier**, when we need to interact with the move axis window, can assume the values, as follows:

- "MoveAX#nome\_asse#HasFocus" the parameter **container** contains 1, if the specified move axis window is active, otherwise it contains 0.
- "MoveAX#nome\_asse#Jog" the parameter **container** contains 1, if the move for displacements managed in runtime by the operator is set, otherwise it contains 0.
- "MoveAX#nome\_asse#Step" the parameter **container** contains 1, if the move with predefined steps is set, otherwise it contains 0.
- "MoveAX#nome\_asse#Absolute" the parameter **container** contains 1, if the move with defined position is set, otherwise it contains 0, where the axis name represents the name of the axis displayed in the window. E.g., if we need to verify, if the move axis window is active, the parameter **identifier** will be "@MoveAX#X#HasFocus". The name of the axis can be expressed in one of the following forms:
  1. Name\_Group. Name\_Subgroup. Name\_Axis or Name\_Group. Name\_Axis: the complete path of the axis is shown.
  2. Name\_Axis: to identify the correct axis checks are made according to the following order:
    - if the task from which it arrives the command is a function of subgroup, the axis is searched in that sub-group.
    - if the task from which it arrives the command is a function of the main subgroup, the axis is searched in all the group. If there is more than one axis with that name, the research fails.
    - if the previous checks failed, the axis is searched in all the groups in the module. If there is more than one axis with the name Name\_Axis, the research has not positive outcome.

#### "@Vars"

It requests the updating of a GPL global variable. It allows you to perform data refreshment of technological Parametric and tools. The parametric data is normally sent to the GPL during machine booting. The parameter **identifier** will indicate the name of the global variable (machine or group) whose update is requested. The parameter **container** will contain the value:

- 1 if the variable has been correctly updated
- 0 if not

#### "@Application"

Interaction with Albatros. It allows you to display the "message box" on the screen and close down Albatros. Possible values for the **identifier** parameter are:

- "       to close Albatros  
  Q  
  u  
  i  
  t  
  "
- "Is     verifies, if the exit from the Albatros is locked. The parameter **container** contains 1, Locke if the interface is locked, 0, if it is possible to exit Albatros.  
  d"
- "MsgB  reads the answer of a message box previously opened with a SEND  
  ox"

The parameter **container** makes it possible to know, in the case of a message box, which button has been pressed by the operator:

- 1 "OK" button
- 2 "Cancel" button
- 3 "Abort" button
- 4 "Retry" button
- 5 "Ignore" button
- 6 "Yes" button
- 7 "No" button

In the case of the "Quit" control, the parameter **container** will contain the value:

- 1 IF Albatros has been closed down correctly
- 0 if not

**"@Param"**

It allows you to know the progressive number of Partec.par and Partool.par parametric files storing. Requested information is stored into **container** parameter. Admitted values for the parameter **identifier** are:

- "partec" it requests the progressive of partec.par storing
- "partool" it requests the progressive of partool.par storing

**"@Ini"**

reads a key=value combination from the tpa.ini file. The parameter **identifier** is the name of the key to read in tpa.ini at section [Tpa]. To read from a specific section, the name of the section in square brackets ("[Section]Key") must be added to the name of the key.

**"@ShellExecute"**

asks the operating system to open a file using the program associated to the file extension. An executable program can be also launched. The parameter **identifier** is the name of the file to open or the name of the program to launch. The name of the file can be declared with a complete path; if not, it is charged in the current folder of Albatros. The name of the file is searched also among those, that are defined through "@FileName". The parameter **container** contains the value 0, if no errors occurred while opening the file; otherwise, it contains the code of the error.

**"@StartProg"**

execute the program defined in the parameter **identifier**. In is not possible to pass the arguments to the program to launch. The name of the program must contain the whole path; if not, it is charged in the current folder of Albatros. The name of the program is also searched also among those that are defined through "@FileName". The parameter **container** contains the value 0, if the program was successfully launched; otherwise, it contains the code of the error. If the program had already been launched, the code or the error is 1056.

**"@ProgRunning"**

verifies if the program, launched with "@StartProg" is still being executed. The name of the program is defined in the parameter **identifier**. The name of the program must contain the whole path; if not, it is charged in the current folder of Albatros. The name of the program is also searched also among those that are defined through "@FileName". The parameter **container** contains value 1, if the program is still being executed, if not it contains value 0.

**"@TermProg"**

ends the program defined in the parameter **identifier** and launched through "@StartProg". The name of the program must contain the whole path; if not, it is charged in the current folder of Albatros. The name of the program is searched also among those, that are defined through "@FileName". The parameter **container** contains the value 0, if the program was successfully launched; otherwise, it contains the code of the error. If the program had already been launched, the code or the error is 1056.

**"@DialogFile"**

opens the dialog box of File Open or File Save to allow you to choose a file name. To open the window of File Open set the parameter **identifier** = "Open", to open the window of File Save to set the parameter **identifier** = "Save". The name of the selected file is stored in the parameter **container**.

**Example**

```

;in GPL
RECEIVE "@Param", "partec", 0, prog
RECEIVE "@Param", "partool", 0, prog

;in GPL
;reads the Radix key value in the [Albatros] section from the
;tpa.ini file
RECEIVE "@INI", "[Albatros]Radix", 0, value

; opens the window of File Open and stores the name of file in the FileName
variable
RECEIVE "@DialogFile", "Open", 0, FileName

```

**SEND****Syntax**

**SEND** [addressee, ] identifier, flags [, information]

**Arguments**

|                    |  |
|--------------------|--|
| <b>addressee</b>   | string constant  |
| <b>identifier</b>  | string constant  |
| <b>flags</b>       | integer constant   |
| <b>information</b> | name of device or constant or variable (numeric or string) |

**Description**

This instruction is used, together with RECEIVE, to exchange information between the modules of the plant and the supervisor PC. SEND is used to send information, RECEIVE to ask for information. Information can be requested from Albatros or an external program (Server OLE Automation). In the second case the request is still received by Albatros who will then send it to the external program.

The parameter **addressee** is a string which allows you to specify who the information is sent to. There are three classes of addressees:

- addressees beginning with the "@" character (see list further on). The addressee is really Albatros, or better, one of its functions.
- addressees which do not begin with the "@" character. They are considered as Server OLE, and as soon as Albatros receives an information request addressed to them, it will try to send them in execution and then to pass on the information request received from the module.
- unspecified addressee (the parameter is actually optional). In this case the information is kept in a table by Albatros where it is available for anyone requesting it (another module or external program).

The parameter **identifier** is the name of the information, and can not be omitted. It takes on different meanings according to the addressee:

- if Albatros is the addressee, the identifier will be a command related to the accessed function
- if a Server OLE is the addressee, it will be a property of the OLE object requested.
- If the addressee is not specified it will be the label identifying the information contained in the Albatros table

The parameter **flags** allows you to specify how the requested information is to be treated by Albatros. The acceptable values and their effects are the following:

| <b>value</b> | <b>command</b> | <b>description</b>  |
|--------------|----------------|---|
| \$0001H      | Broadcast      | Normal request broadcast  |
| \$0008H      | CancelAfter    | The information is deleted after being read.                                      |
| \$0020H      | ReadOnly       | The information can only be deleted by the sender                                 |
| \$1000H      | UpdateFlags    | Modifies the state of the information (read / to read) without modifying the data |
| \$8000H      | Delete         | Deletes the information   |

The **information** parameter is the information sent. This can be omitted, in which case the empty information indicates the notification of an event (it can be used to synchronise the execution of the GPL code on a series of modules). All devices (except for the axes), simple GPL variables and strings are recognised as information parameters.

List of **addressees** managed by Albatros and their commands:

**"@List"**

makes possible to control the commands Simulation and Setpoint

Following commands are allowed (parameter **identifier**):

- Sim: notifies the change in state of the Simulating switch flag. According to the flag state, its identification button is visualized pressed or released in the toolbar (1=checked, 0=unchecked).
- Setp: notifies the change in state of the CmdSetp switch flag. According to the flag state, its identification button is visualized pressed or released in the toolbar (1=checked, 0=unchecked).
- Esc: notifies the change in state of the Excluded switch flag. According to the flag state, its identification button (same as the flag switch CmdSetp button) is visualized pressed or released in the toolbar (1=checked, 0=unchecked)
- End: ends the list execution. This command lowers the Start and Stop buttons and disallows

the Start and Stop options of the menu

- Hold: lowers the Stop button and enables the Stop option of the menu. It raises the Start button and disallows the Start option of the menu

**"@Syn"**

Communication between GPL and the synoptic view display. It allows you to open and close the synoptic views through GPL control and to send information to a synoptic cell.

The following commands are possible (parameter **identifier**):

- "Open:*filename*" opening of the synoptic *filename.syn*
- "Close:*filename*" closure of the synoptic *filename.syn*
- "Open" opening of a synoptic. The file name is read from variable **information**
- "Close" closure of a synoptic. The file name is read from variable **information**
- "*cellname*" cell in which the sent information is displayed

It is possible to interact with the axis move window according to the technical data, that has been defined also for the parameter **addressee** "@Devices", as below.

**"@File"**

Writing on a file. It allows you to create personalised log files to memorise the operations performed by a machine. The files are text files (ASCII). The **identifier** parameter is the name of the file which will be written on.

If in the parameter identifier the complete path, in which to store the file, is not specified, Albatros considers that defined in tpa.ini in the section [tpa] at the item *dirreport*.

If the identifier starts and finishes with the symbol % inside the string is cherched in tpa.ini in section [tpa] and used as file name. Inside the name can be inserted symbols that will be substituted during the instruction execution:

- %n module number that execute SEND instruction
- %h current time (00-23 format)
- %d current day (01-31 format)
- %m current month (01-12 format)
- %y current year (four numbers format)

See the example.

Writing operations are carried out in append mode (the data is added at the end of the file). Numeric data (automatically converted to ASCII) and strings can be sent in a file. It is possible to write date/time format strings using format characters %d for the date and %t for the time. For the time we use the format "HH:mm:ss" (that is: hours, minutes and seconds separated by ":") and for the date we use a format, that depends on each national settings. It is possible to use another format, if you set in tpa.ini in the section [Albatros] the option "LogNoLocale=1" (by default it is LogNoLocale=0, that is use of the current format). It is also possible to set the format to be used for the date and the time apart from the format set in Windows, defining always in tpa.ini in the section [Albatros] the options "LogDateFormat=" e "LogTimeFormat=" and assigning a string of characters according the table below. If these options are not available or are empty, we use the formats set by Windows.

**Time format**

|    |   |
|----|---|
| h  | Time in 12-hours format without leading zeros             |
| hh | Time in 12-hours format with leading zeros                |
| H  | Time in 24-hours format without leading zeros             |
| HH | Time in 24-hours format with leading zeros                |
| m  | minutes without leading zeros                             |
| mm | minutes with leading zeros                                |
| s  | seconds without leading zeros                             |
| ss | seconds with leading zeros                                |
| t  | one only character to show the time marker, e.g. A or P   |
| tt | several characters to show the time marker, e.g. AM or PM |

Notes "t" and "tt" format use the time marker shown in the control panel of the current user. It is not necessarily "AM" and "PM".

Example: if it is 11:29 in the afternoon and the string is made up in this way "hh':'mm':'ss tt", "11:29:40 PM" appears.

**Day format**

|      |   |
|------|---|
| d    | day of the month without leading zeros, represented by the digits         |
| dd   | day of the month with leading zeros, represented in digits                |
| ddd  | day of the week, represented in characters and shortened to three letters |
| dddd | day of the week, represented in characters with its full name             |
| M    | month without leading zeros, represented in digits                        |

|       |  |
|-------|--|
| MM    | month with leading zeros, represented in digits                          |
| MMM   | month, represented in characters and shortened to three letters          |
| MMMM  | month, represented in characters with its full name                      |
| y     | year with two digits without leading zeros for years less than 10        |
| yy    | year with two digits with leading zeros for years less than 10           |
| yyyy  | year represented by four or five digits according to the calendar in use |
| yyyyy | year represented by four or five digits according to the calendar in use |

Example: if it is Wednesday, 31 August, 1994 and its string is made up in this way "ddd',' MMM dd yy", "Wed, August 31 94" appears.

If the information is omitted a "return to beginning" is added to the file.

#### "@FileName"

stores an association between a constant string and a file name, which can be made up with string variables. Since Albatros has received the communication of the association it replaces all the following file names with the name received by means of this instruction. The parameter **identifier** is the name of the file, which will be written. The name of the file is a variable string. If in the parameter identifier the complete path in which to store the file is not specified, Albatros considers the one defined in tpa.ini into the section [tpa] at the item *dirreport*. The value of the parameter identifier is stored in tpa.ini in the section [GPLFileName] at the item Log, so that it can be used again also in the Albatros executions, that follow. To cancel the association you need to set an empty string as parameter identifier. The association, which is defined in this way, can be used for each module.

#### "@FileDelete"

deletes a file. The parameter **identifier** is the name of the file which will be deleted (complete path). If in the parameter identifier the complete path, in which to store the file, is not specified, Albatros considers that defined in tpa.ini in the section [tpa] at the item *dirreport* cannot be used. File name can be defined according to the rules described for the parameter **addressee** @File

#### "@FileRead"

places the pointer at the beginning of the file. The parameter **identifier** is the file name (complete path). If in the parameter identifier the complete path, in which to store the file, is not specified, Albatros considers that defined in tpa.ini in the section [tpa] at the item *dirreport*. File name can be defined according to the rules described for the parameter **addressee** @File.

#### "@Axis"

interacts with the axis manual movement window according to the technical data, that have been defined also for the parameter addressee "@Devices", as below. If a window that controls the movements of the indicated axis is already open, this command acts on this window, whether it is open in a synoptic data table or it is open in diagnostics. If the window is shut, the command tries to open it in Diagnostics or in one of the synoptic data tables already open and that contains that axis.

#### "@Devices"

requires to open or close the Diagnostic window of the module sending the information. Commands execution within the axis move window in diagnostic. The **identifier** parameter can assume the following values:

- "Open"           open Diagnostic
- "Close"         close Diagnostic

The parameter **identifier**, when we need to interact with the move axis window, can assume the values, as follows:

- "MoveAX#nome\_asse#Open"   opening of the axis move window
  - "MoveAX#nome\_asse#Close"   closing of the axis move window
  - "MoveAX#nome\_asse#Plus"    pushing the button of axis move (positive direction)
  - "MoveAX#nome\_asse#Minus"   pushing the button of axis move (negative direction)
  - "MoveAX#nome\_asse#Stop"    pushing the button of move stop
  - "MoveAX#nome\_asse#Jog"     setting the mode of move for displacements managed in runtime by the operator
  - "MoveAX#nome\_asse#Step"    setting the mode of move for displacements with predefined steps
  - "MoveAX#nome\_asse#Absolute" setting the mode of move with axis defined position where the axis name represents the axis name displayed in the window. E.g, if you need to open the X-axis move window, the parameter **identifier** is "@MoveAX#X#Open". The axis can be named as follows:
1. Name\_Group.Name\_Subgroup.Name\_Axis or Name\_Group .Name\_Axis: the complete axis path is given.



2. Name\_Axis: to identify the right axis, tasks are verified according the following order:
- If the task from which the command arrives is a function of subgroup, the axis is searched in that subgroup.
  - If the task from which the command arrives is a function of the main group, the axis is searched in all the group. If there is more than one axis with that name, the research fails.
  - If the previous checks failed, the axis is searched in all the groups of the module. If there is more than one axis with Name\_Axis, research has not positive outcome.

It is possible to prevent the user to act on the keys of axis move of all the axis movement windows of the module in diagnostic. For this purpose the parameter **identifier** should be set as follows:

- "MoveAX##UIENABLE" if the parameter **information** is set on 0, the axes move from Albatros is disabled; if it is set on 1e, the axes move is enabled from Albatros.

We suggest to disable axes move from Albatros, when the axes are moved from the machine's control panel.

### "@Vars"

requires to save the content of a GPL global variable in the store of the technological parameters or tools. The parameter **identifier** is the name of the global variable (of machine whether group or library) for which the update is required.

### "@Application"

Interaction with Albatros. It allows you to display "message boxes" on the screen and close down Albatros. Possible values for the **identifier** parameter are:

- "Quit" to close Albatros
- "Lock" prevents from closing Albatros from **File->Exit** or from keyboard shortcuts [ALT +F4] or from closing button.
- "Unlock" restores the possibility of closing Albatros
- "MsgBox:flags" to open a message box

The behaviour of the message boxes is controlled by the "flags" of the **identifier** string. This can be a combination of the following strings:

- "O" "OK" button
- "OC" "OK" and "Cancel" buttons
- "YN" "Yes" and "No" buttons
- "YNC" "Yes", "No" and "Cancel" buttons
- "RC" "Retry" and "Cancel" buttons
- "ARI" "Abort", "Retry" and "Ignore" buttons
- "S" Stop icon
- "?" Question mark icon
- "!" Exclamation mark icon
- "\*" information icon
- "1" the first button is for default
- "2" the second button is for default
- "3" the third button is for default

For example "MsgBox:YN2" identifies a message box with a question mark icon and two "Yes" and "No" buttons where the latter one is the default button.

The **information** parameter can be a string, containing the text to be displayed, or an integer number which is recognized as the code of a module message handled by Winmess.exe or a group message label defined by the DEFMSG instruction.

### "@Help"

opens a help file. It allows you to command the display of a help file by specifying the argument to be displayed. Possible values for the **identifier** parameter are:

- "Open:filename" to open a help file
- "Close:filename" to close a help file

The "filename" part of the string, specifies the name of the help file to be opened.

The parameter **information** can be a string or a number and assumes accordingly the meaning of key or context number (to identify the page or help argument to be displayed).

### "@Report"

adds messages to the Albatros report file (MONTH (n month).TER). The parameter **Identifier** is:

- "Add"

The parameter **Information** can be:

- a string variable or a string constant: the text, contained in the string, is saved in the report file
- an integer variable or an integer numeric value: the text, defined by the DEFMSG instruction, is saved
- defined by the DEFMSG instruction.

#### "@Ini"

writes a key=value combination from the tpa.ini file. The parameter **identifier** is the name of the key to add in tpa.ini at section [Tpa]. To write in a specific section, the name of the section in square brackets ("[Section]Key") must be added to the name of the key  
The parameter **information** can be a string or numeric variable, a string or a numeric constant.

#### "@ShellExecute"

asks the operating system to open a file using the program associated to the file extension. It is also possible to launch an executable program. The parameter **identifier** is the name of the file to open or the name of the program to launch. The name of the file can be declared with a complete path; if not, it is charged in the current folder of Albatros. The name of the file is also searched among those that are defined through "@FileName".

#### "@StartProg"

executes the program defined in the parameter **identifier**. It is not possible to pass any arguments to the program to launch. The name of the program must contain the whole path; if not, it is searched in the current folder of Albatros. The name of the program is searched also among those that are defined with "@FileName".

#### "@TermProg"

ends the program defined in the parameter **identifier** and launched through "@StartProg". The name of the program must contain the whole path; if not, it is charged in the current folder of Albatros. The name of the program is searched also among those that are defined through "@FileName".

#### "@DialogFile"

allows you to set some parameters related to the dialog box of File Open or File Save.

The values allowed for the parameter **identifier** are:

|                          |   |
|--------------------------|---|
| "Extension"              | if the user does not enter an extension, the extension defined in the <b>information</b> parameter is used (variable or string constant)  |
| "Filter"                 | sets the filter on the file types to be used. The <b>information</b> parameter can be a string variable or a string constant; in this case the text in the string, an integer variable or an integer numerical value is used as a filter and in this case the text defined in the DEFMSG instruction is used as a filter. |
| "Flags"                  | set the initialisation flags. For the list of the values to be set in the <b>information</b> field (variable or integer constant), please make reference to the official Microsoft documentation concerning the Flags member of the OPENFILENAME structure.   |
| "InitalDir"<br>constant) | set the initial folder, defined in the <b>information</b> field (variable or string   |
| "Title"                  | sets the box name. The <b>information</b> parameter can be a string variable or a string constant; in this case the text in the string, an integer variable or an integer numerical value is used as a filter and in this case the text defined in the DEFMSG instruction is used as a filter.                            |

```
; Example of send file instruction with name created during execution.
; Suppose that the date of instruction execution be 31-01-2000
```

```
; in GPL
    SEND "@File", "%Log%", 0, "Start execution"
    SEND "@File", "%Log%", 0                      ; add a "wordwrap"
; in tpa.ini at section [TPA]
Log=c:\Albatros\report\%y\Rep%m%d.txt
```

```
; The name of final file is:
c:\Albatros\report\2000\Rep0131.txt
```

```

; Example of send Vars instruction
; we define a Var_SendVars variable as double in the file of the global
; variables
; in the technological Parameters Var_SendVars is entered in the field
; Matrix Name
; in GPL
    SETVAL 100.0,Var_SendVars
; sends the 100.0 value to the parameter of the technological Parameters
; associated to the Var_SendVars variable
    SEND "@Vars", "Var_SendVars", 0

; Example of send INI instruction
; in tpa.ini the Radix key is entered in the [Albatros] section to set
; a numerical basis of decimal number view
    SEND "@INI", "[Albatros]Radix", 0;1

; Example of setting up an association between GPL constant string
; and name of a file.

; declaration of a string variable
nomefile as string
; composition of the file name
setstring C:\ALBATROS\MOD.0\CONFIG),filename
; association
    SEND "@File", "LOG",0,filename
; all the writing operations from now are
; performed in the file defined by the filename variable
    SEND "@File", "LOG",0, "writing in the LOG file"

```

**SENDIPC**

*Syntax*

```

SENDIPC          IPCname, wait [, varname1 [, varnameN, ...]]
SENDIPC          IPCname, wait , matrix[row]
SENDIPC          IPCname, wait , vector
SENDIPC          IPCname, wait , matrix

```

*Arguments*

|                              |  |
|------------------------------|--|
| <b>IPCname</b>               | string constant. Name of the IPC   |
| <b>wait</b>                  | predefined constant. Wait mode of command read<br>Possible values are:<br><b>WAIT</b> waits for the command to be read<br><b>NOWAIT</b> does not wait for the command to be read |
| <b>varname1[...varnameN]</b> | constant or variable. Names of variables 1÷N   |
| <b>matrix[row]</b>           | constant or integer variable. Matrix row number  |
| <b>vector</b>                | name of vector   |
| <b>matrix</b>                | name of matrix   |

*Description*

It sends an IPC command to the "**IPCname**" shared memory.  
 When the SENDIPC instruction is executed for the first time the shared memory is allocated; the memory's dimension is calculated on the basis of the size of sent data. The maximum shared memory dimension is 64 Kb. Up to 48 shared memories can be defined with 48 distinct names.  
 A semaphore is connected to the memory to allow synchronisation of the tasks accessing it. The task writing the data enables the semaphore when it finishes writing, the task reading the data disables it when it finishes reading.  
 If WAIT was indicated as **wait** parameter, the task sending the data will wait for them to be read (disabled semaphore) before continuing execution.  
 A SENDIPC without data simply synchronises the tasks. In this case no shared memory is allocated.

**IPC intermodule**

Two remote modules can exchange data through IPCs. These IPCs are called IPC intermodule. To define an IPC intermodule you need to write the **IPCname** according to the following formalism: Number of source module, "->", number of the recipient module, ":", and hereafter the other character of the IPC name.  
 For example, "0->1:Base Parameters".

See also WAITIPC and TESTIPC.

## WAITIPC

### Syntax

|         |  |
|---------|--|
| WAITIPC | IPCname [, varname1 [, varnameN, ...]] |
| WAITIPC | IPCname, matrix[row]                   |
| WAITIPC | IPCname, vector                        |
| WAITIPC | IPCname, matrix                        |

### Arguments

|                       |   |
|-----------------------|---|
| IPCname               | string constant. Name of IPC                    |
| varname1[...varnameN] | constant or variable. Names of variables 1÷N    |
| matrix[row]           | constant or integer variable. Matrix row number |
| vector                | name of vector                                  |
| matrix                | name of matrix                                  |

### Description

It receives an IPC command from the "**IPCname**" shared memory. When the SENDIPC instruction is executed for the first time the shared memory is allocated; the memory's dimension is calculated on the basis of the size of sent data. The maximum shared memory dimension is 64 Kb. Up to 48 shared memories can be defined with 48 distinct names. A semaphore is connected to the memory to allow you to synchronise the execution of the tasks accessing it. The task reading the data waits for the semaphore to be enabled by the task writing the data, it reads the data and then disables the semaphore.

A WAITIPC without data simply synchronises the tasks. In this case the shared memory is not allocated.

See also SENDIPC and TESTIPC.

## WAITRECEIVE

### Syntax

|             |  |
|-------------|--|
| WAITRECEIVE | [source, ] identifier, flags [, container] |
|-------------|--|

### Arguments

|            |  |
|------------|--|
| source     | string constant                                |
| identifier | string constant                                |
| flags      | integer constant                               |
| container  | name of device or variable (numeric or string) |

### Description

It waits for the requested information (specified by identifier) to arrive, before continuing execution of the GPL program. For use, consult documentation of the RECEIVE instruction.

## 9.2.10 Mathematics

### ABS

#### Syntax

|     |                 |
|-----|-----------------|
| ABS | operand, result |
|-----|-----------------|

#### Arguments

|         |  |
|---------|--|
| operand | constant or variable or name of device |
| result  | variable or name of device             |

#### Description

It extracts the absolute value of **operand** and puts in **result**. To convert data, according to the type of declared data, see chapter Data conversion.

#### Example

```
SETVAL    -10,op    ; sets -10 to the op variable
```





It performs a division between **operand1** and **operand2** and puts the result in **result**. The instruction can generate a system error when **operand2** equals 0. To convert data, according to the type of declared data, see chapter Data conversion.

**Example**

```
SETVAL 10,op1 ; sets 10 to the op1 variable
SETVAL 5,op2 ; sets 5 to the op2 variable
DIV op1,op2,var
;The value set in the var variable is 2
```

**EXP**

**Syntax**

```
EXP operand, result
```

**Arguments**

**operand** constant or variable or name of device  
**result** variable or name of device

**Description**

It calculates the exponential of **operand** and puts the value in **result**. To convert data, according to the type of declared data, see chapter Data conversion.

**Example**

```
SETVAL 2.302585093,op ;sets 2.302585093
;in the op variable
EXP op,var
;The value set in the var variable is 10
```

**EXPR**

**Syntax**

```
EXPR variable = expression
```

**Arguments**

**variable** name of device or variable  
**expression** group of operators

**Description**

This instruction allows you to resolve mathematical expressions. Factors may be constants, names of devices or variables. Its syntax provides that between each operator and each operand a spacing should be entered.

If the operands are not of the same type, an automatic conversion is carried out and the type of the result of the operation is the same as the greater one, according the following rule:

- char < integer
- float < double
- char or integer < float or double.

After resolving the **expression**, the result is converted to the **variable** type.

The following operators are permitted:

|        |                                 |
|--------|---------------------------------|
| ( )    | brackets                        |
| -      | sign change operator            |
| ABS    | absolute operand value          |
| ROUND  | unit round up/round down        |
| TRUNC  | value truncated to whole number |
| LOG    | natural logarithm               |
| LOGDEC | decimal base logarithm          |
| EXP    | exponential                     |
| SRQ    | square root operation           |

|        |   |
|--------|---|
| SIN    | sine operation. The operand is expressed in degrees, indicating the value to two decimal points if applicable (e.g.: 30° 15" = 30.25.)            |
| COS    | cosine function operation. The operand is expressed in degrees, indicating the value to two decimal points if applicable (e.g.: 30° 15" = 30.25.) |
| TAN    | tangent operation, expressed in degrees.  |
| ARCSIN | arc sine operation. The result is expressed in degrees, with the value in a -90°÷+90° range   |
| ARCCOS | arc cosine operation. The result is expressed in degrees, with the value in a 0°÷180° range   |
| ARCTAN | executes an arc tangent operation. See ARCTAN   |
| ^      | power operator  |

|   |                             |
|---|-----------------------------|
| * | multiplication              |
| / | division                    |
| % | division remainder (module) |
| + | addition                    |
| - | subtraction                 |

This instructions allows for GPL code writing to be simplified, when performing mathematical calculations; the single GPL instructions corresponding to the operators listed in the table are replaced. These instructions stay available for compatibility purposes.

**Example**

```

; calculation of the distance between two points
EXPR dist = SQR ( ( Xb - Xa ) ^ 2 + ( Yb - Ya ) ^ 2 )

```

**LOG**

**Syntax**  
LOG

**operand, result**

**Arguments**

**operand** constant or variable or name of device  
**result** variable or name of device

**Description**

It calculates the natural logarithm of **operand** and puts the result in **result**. To convert data, according to the type of declared data, see chapter Data conversion.

**Example**

```

SETVAL 10,op ; sets 10 to the op variable
LOG op,var
;The value set in the var variable is 2.302585093

```

**LOGDEC**

**Syntax**  
LOGDEC

**operand, result**

**Arguments**



**operand** constant or variable or name of device  
**result** variable or name of device

**Description**

It calculates the base 10 logarithm of **operand** and puts the value in **result**. To convert data, according to the type of declared data, see chapter Data conversion.

**Example**

```
SETVAL 10,op ; sets 10 to the op variable
LOGDEC op,var
;The value set in the var variable is 1
```

**MOD**

**Syntax**

**MOD operand1, operand2, result**

**Arguments**

**operand1** constant or integer variable or name of device  
**operand2** constant or integer variable or name of device  
**result** integer variable or name of device

**Description**

It performs a module operation between **operand1** and **operand2** and puts the result in **result**. The module is the remainder resulting from the division between the first and the second operand. The instruction can generate a system error when **operand2** equals 0. To convert data, according to the type of declared data, see chapter Data conversion.

**Example**

```
SETVAL 20,op1 ; sets 20 to the op1 variable
SETVAL 3,op2 ; sets 3 to the op2 variable
MOD op1,op2,var
;The value set in the var variable is 2
```

**MUL**

**Syntax**

**MUL operand1, operand2, result**

**Arguments**

**operand1** constant or variable or name of device  
**operand2** constant or variable or name of device  
**result** variable or name of device

**Description**

It performs a multiplication operation between **operand1** and **operand2** and puts the result in **result**. To convert data, according to the type of declared data, see chapter Conversion data.

**Example**

```
SETVAL 5,op1 ; sets 5 to the op1 variable
SETVAL 2,op2 ; sets 2 to the op2 variable
MUL op1,op2,var
;The value set in the var variable is 10
```

**NOT****Syntax****NOT** **operand****Arguments****operand** variable or name of device**Description**

It performs a binary NOT operation (*the single bits are inverted*) on the value expressed by **operand**. The result is stored in **operand**.

**Example**

```
SETVAL 5,var ; sets a value of 5 to "var"
NOT var

; The result is var = -6
; Binary notation: 5 = 0000 0101,
; Binary notation:10 = 0000 1010
; Hexadecimal notation 5 = 0000 0000 0000 0005
; Hexadecimal notation 10 = 0000 0000 0000 000A
; by executing a NOT on value 5 the result is 0xFFFF FFFF FFFF FFFA = -6
```

**OR****Syntax****OR** **operand1, operand2, result****Arguments**

**operand1** constant or variable or name of device  
**operand2** constant or variable or name of device  
**result** variable or name of device

**Description**

It carries out a binary OR operation (*between two bits, the result is 1 if at least one equals 1*) between **operand1** and **operand2** and puts the result in **result**. To convert data, according to the type of declared data, see chapter Data conversion.

**Example**

```
;The values set in the var variable is 7
;(Binary notation: 5 = 0101, 3 = 0011, 7 = 0111 )

OR 5,3,var
```

**RANDOM****Syntax****RANDOM** **min, max, result****Arguments**

**min** constant or variable  
**max** constant or variable  
**result** variable or name of device

**Description**

It send to result a pseudocausal number included between **min** and **max** (extremes included). By executing the instruction repeatedly you obtain a sequence of pseudocausal numbers. To convert data, according to the type of declared data, see chapter Data conversion.

**Example**

```
SETVAL 2,op1 ; sets 2 in the op1 variable
```

```
SETVAL 100,op2 ; sets 100 in the op2 variable
RANDOM op1,op2,var
```

```
;The value set in the var variable is a random number
;included between 2 and 100
```

## RESETBIT

### Syntax

```
RESETBIT mask, nbit
```

### Arguments

**mask** constant or integer variable or countername or portname. It indicates the value to be modified (max 32 bit)

**nbit** constant or integer variable or countername. Number of bit to be modified

### Description

It sets a single bit of the passed bit **mask**, specified by **nbit**, to 0. The argument **mask** must correspond to an integer value with a maximum of 32 bit. The number of bits, **nbit**, ranges between 1 and 32.

### Example

State of the port before executing the code



State of the port after executing the code



```
;-----
; Example to disable the line of a flag port:
;-----
```

```
SETVAL 2,nbit
RESETBIT FlagPort,nbit
```

```
; disables line 2 of the flag port
```

## ROUND

### Syntax

```
ROUND operand, result
```

### Arguments

**operand** constant or variable or name of device

**result** variable or name of device

### Description

It performs a rounding operation on the **operand** and puts the value in **result**. To convert data, according to the type of declared data, see chapter Conversion data.

### Example

```
SETVAL 5.7,op ;sets 5.7 in the op variable
ROUND op,var
```

```
;The value set in the var variable is 6
```

```
SETVAL 5.2,op ;sets 5.2 in the op variable
ROUND op,var
```

```
;The value set in the var variable is 5
```

## SETBIT

### Syntax

```
SETBIT mask, nbit
```

### Arguments

**mask** constant or integer variable or countername or portname. Value to be modified (max 32 bit)

**nbit** constant or integer variable or countername. Number of the bit to be modified (1÷32)

### Description

It sets a single bit of the passed bit **mask**, specified by **nbit**, to 1. The argument **mask** must correspond to an integer value with a maximum of 32 bit. The number of bits, **nbit**, ranges between 1 and 32.

### Example

State of the port before code execution



State of the port after code execution



```
-----
; Example to enable a line of the flag port:
-----
```

```
setVal      2,nbit
setbit      FlagPort,nbit
```

```
; it enables line 2 of the flag port
```

## SHIFTL

### Syntax

```
SHIFTL operand 1 [, operand2]
```

### Arguments

**operand1** variable (integer or char) or name of device


**operand2** variable (integer or char) or name of device

### Description

If **operand2** is not specified, this instruction performs a left hand shift operation of the bits that make up the **operand1**. If also the second operand is specified, a rotation is performed between **operand2**, used as 0-value or not equal to 0 and the bits of **operand1**. In this case, at the end of the operation, **operand2**, will contain the carry of the operation and the bit of lower weight of **operand1** will become 0 or 1 according to the initial value of **operand2**, (0 or not equal to zero).

### Example

*Rotation (left hand shift with carry)*



Example of left hand shift without carry



### SHIFTR

**Syntax**

**SHIFTR** **operand1** [, **operand2**]

**Arguments**


**operand1** variable (integer or char) or name of device  
**operand2** variable or name of device

**Description**

If **operand2** is not specified, this instruction performs a left - hand scrolling operation of the bits that make up the **operand1**. If also the second operand is specified, a rotation between **operand2**, used as 0-value or not equal to 0 and the bits of **operand1**, is performed. In this case, at the end of the operation **operand2** will contain the carry of the operation; the bit of lower weight of **operand1** will become 0 or 1 according to the initial value of **operand2** (0 or not equal to zero).

**Example**

Rotation (right-hand shift with carry)



Right hand shift (Right-hand shift without carry)



**SIN**

**Syntax**  
SIN

**operand, result**

**Arguments**

**operand**  
**result**

constant or variable or name of device  
variable or name of device

**Description**

It carries out a sinus operation on **operand** and puts the result in **result**.  
The argument **operand** is expressed in degrees with a possible centesimal fractionary part (ex.: 30° 15" = 30,25). To convert data, according to the type of declared data, see chapter Data conversion.

**Example**

```

SetVal    30,op      ;sets 30 in the op variable
Sin       op,var
;The value set in the var variable is 0.5
    
```

**SQR**

**Syntax**  
SQR

**operand, result**

**Arguments**

**operand**  
**result**

constant or variable or name of device  
variable or name of device

**Description**

It extracts the square root of **operand** and puts the value in **result**. Only positive values are admitted in the **operand** parameter. To convert data, according to the type of declared data, see chapter Data conversion.

**Example**

```
SetVal 81,op ;sets 81 in op variable
Sqr op,var

;The value set in the var variable is 9
```

**SUB**

**Syntax**

**SUB operand1, operand2, result**

**Arguments**

**operand1** constant or variable or name of device  
**operand2** constant or variable or name of device  
**results** variable or name of device

**Description**

It performs a subtraction operation between **operand1** and **operand2** and puts the result in **result**. To convert data, according to the type of declared data, see chapter Data conversion.

**Example**

```
SetVal 10,op1 ; sets 10 in the op1 variable
SetVal 4,op2 ; sets 4 in the op2 variable
Sub op1,op2,var

;The values et in the var variable is 6
```

**TAN**

**Syntax**

**TAN operand, result**

**Arguments**

**operand** constant or variable or name of device  
**result** variable or name of device

**Description**

It performs a tangent operation in **operand** and puts the result in **result**. The **operand** argument is expressed in degrees. To convert data, according to the type of declared data, see chapter Data conversion.

**Example**

```
SetVal 45,op ;sets 45 in the op variable
Tan op,var

;The value set in the var variable is 1
```

**TRUNC**

**Syntax**

**TRUNC operand, result**

**Arguments**

**operand** constant or variable or name of device  
**result** variable or name of device

**Description**

It truncates to integer the value of **operand** and puts the result in **result**. (the decimal part goes lost). To convert data, according to the type of declared data, see chapter Data conversion.

**Example**

```
SetVal      5.7,op      ;sets 5.7 to the op variable
Trunc      op,var
;The value set in the var variable is 5
```

**XOR****Syntax**

**XOR** **operand1, operand2, result**

**Arguments**

|                 |  |
|-----------------|--|
| <b>operand1</b> | constant or variable or name of device |
| <b>operand2</b> | constant or variable or name of device |
| <b>result</b>   | variable or name of device             |

**Description**

It performs a binary XOR operation (between two bits, the result is one if only one of the two equals one) between **operand1** and **operand2** and puts the result in **result**. To convert data, according to the type of declared data, see chapter Data conversion.

**Example**

```
Xor      5,3,var
;The value set in the var variable is 6
;(Binary notation: 5 = 0101, 3 = 0011, 6 = 0110)
```

## 9.2.11 Multitasking

**ENDMAIL****Syntax**

**ENDMAIL** **mail**

**Arguments**

**mail** constant or integer variable. Number of post box (1÷256)

**Description**

It indicates the end of execution of a command associated to a message taken from the **mail** post box.

The task that sent the message (using the SENDMAIL instruction) and was waiting for command execution (wait arguments WAITACK) can now carry on with its own execution. This instruction **is effective only when executed within task** that previously received the message (with the WAITMAIL or TESTMAIL instruction).

See also instructions SENDMAIL, WAITMAIL and TESTMAIL

**Example**

Axis movement server



## ENDREALTIMETASK

### Syntax

**ENDREALTIMETASK**                    **functionname**

### Arguments

**functionname**                    name of function

### Description

It stops the execution of a real time task. See also STARTREALTIMETASK.

## ENDTASK

### Syntax

**ENDTASK**                                **[taskname]**

### Arguments

**taskname**                            name of task

### Description

It interrupts the execution of a task together with all the tasks activated by it (child tasks). This instruction also interrupts axis movement, cancels pending RECEIVES and closes any connections with the serial ports. If the **taskname** variable is omitted, it ends the execution of the current task.

## GETPRIORITYLEVEL

### Syntax

**GETPRIORITYLEVEL**                    **level[,functionname]**

### Arguments

**level**                                    variable. Execution priority level  
**functionname**                    name of function

### Description

It returns the priority value of the task indicated by **functionname** to the **level** variable. This value is a number included between 1 and 255, where 1 indicates the highest priority level and 255 the lowest. If **functionname** is not specified, the priority value returned is the value of the current task, that is the function in which the GETPRIORITYLEVEL instruction is executed. See also SETPRIORITYLEVEL.

## GETREALTIME

### Syntax

**GETREALTIME**                            **varname**

### Arguments

**varname**                                integer variable

### Description

It returns to the **varname** variable the amount of time elapsed since the beginning of the last real-time axis handling. Time is expressed in microseconds. See also GETREALTIMECOUNT.

## GETREALTIMECOUNT

### Syntax

**GETREALTIMECOUNT**                    **varname**

### Arguments

**varname**                                integer variable

### Description

It returns to the **varname** variable the number of real-time axis-handlings executed since the last

numeric control initialization. See also GETREALTIME.

## HOLDTASK

**Syntax**  
**HOLDTASK** [nametask]

**Arguments**  
**nametask** name of task

### Description

It interrupts the execution of the task defined in **nametask**. This instruction does not stop axis movement, which has to be interrupted through the STOP instruction. If **nametask** is omitted, it interrupts the task in progress.

## RESUMETASK

**Syntax**  
**RESUMETASK** [nametask]

**Arguments**  
**nametask** name of task

### Description

It reactivates the execution of the task specified in **nametask**. If **nametask** is omitted, it reactivates the execution of the current task. If the task was interrupted using the STOPTASK instruction, axis movement is resumed as well.

## SENDMAIL

**Syntax**  
**SENDMAIL** mail, wait [, varname1 [...varnameN]]  
**SENDMAIL** mail, wait, matrix[row]

**Arguments**  
**mail** constant or integer variable. Mailbox number (1÷256)  
**wait** predefined constant. Command read or command execution wait mode.  
 The values that can be attributed to the wait constant are:  
**WAIT** waits for the command to be read  
**NOWAIT** does not wait for the command to be read  
**WAITACK** waits for command execution  
**varname1[...varname N]** constant or integer variable. Names of variables 1÷20  
**matrix[row]** constant or integer variable. Matrix row number

### Description

It sends a message (or command) to the **mail** box. The messages can be used to synchronise and exchange information between two or more tasks. If the **mail** box does not exist, meaning that no WAITMAIL or TESTMAIL instruction has been executed, the instruction is simply ignored. If the receiver task is not waiting for a message ( WAITMAIL instruction) or is engaged, the data sent from the instruction is saved in a queue. In this case:  
 1. if the wait argument is **NOWAIT**, execution carries on with the following instruction;  
 2. if the wait argument is **WAIT**, execution waits for the message to be read by the receiver task;  
 3. if the wait argument is **WAITACK**, execution waits for the message to be read and the execution of the command to be confirmed by the receiver task (through the same instruction or a new WAITMAIL).  
 It is very important that the number of the variables and their type coincide with those used to create the mail box with the WAITMAIL instruction. The control does not allow using different types and does not use automatic type conversion (cast) as usually happens.  
 A SENDMAIL without optional parameters (data) functions simply as a task synchronisation mechanism.

### Example

Axis movement server

## SETPRIORITYLEVEL

**Syntax**  
**SETPRIORITYLEVEL**            **level [, functionname]**

**Arguments**  
**level**                            constant or variable. Execution priority level.  
**functionname**                 name of function

**Description**  
 It sets in the **level** variable, the priority value of the task defined in **functionname**. This value is a number included between 0 and 255, where 0 indicates the highest priority level and 255 the lowest. If the name of the task is not specified in the **functionname** variable, it modifies the value of the current task, that is the execution level of the function in which the instruction is executed.

See also GETPRIORITYLEVEL.

## STARTTASK

**Syntax**  
**STARTTASK**                        **taskname [, parameters]**

**Arguments**  
**taskname**                         name of task  
**parameters**                     any parameters needed during task execution

**Description**  
 It activates the execution of the task defined in the **taskname** variable.  
 Any parameters needed during execution can be passed to the task. The number and type of the parameters must match the ones declared in the function implementing the task. If the task is already in execution the instruction does not have any effect.

**Example**  
 Parallel/Sequential execution

## STARTREALTIMETASK

**Syntax**  
**STARTREALTIMETASK**            **functionname**

**Arguments**  
**functionname**                    name of function

**Description**  
 It activates the execution of a real time task. This kind of task is executed with the same frequency as the axis control real time. Unlike normal GPL tasks, every real time is executed entirely, from the first function instruction to the first FRET instruction. See also ENDREALTIMETASK.

**Note:**  
 The local variables declared in the realtime task are initialized only by the start of the task and then they maintain the value of the last run.

## STOPTASK

**Syntax**  
**STOPTASK**                         **taskname**

**Arguments**  
**taskname**                         name of task



Together with RET, this instruction is a typical source of programming errors. We recommend taking great care when using it, in particular we suggest positioning the subprocedures at the end of the body of the function (after the FRET instruction) so as to avoid accidental execution of the subprocedure, as if it were an integral part of the main code. This situation, in the best of hypothesis, generates a system error; in other cases it causes anomalous behaviour of the machine whose origin is difficult to recognise.

## FCALL

### Syntax

**[FCALL]**                                      **functionname [, parameters]**  
**functionname**                                **[parameters]**

### Arguments

**functionname**                                name of the function to be called  
**parameters**                                    any parameters passed to the function

### Description

It calls a function, meaning that the **functionname** function is executed. Any necessary **parameters** are passed to the function. These must match in number and type the parameters declared in the call function. Execution of the caller function (the one where the FCALL is executed) restarts at the end of the call function (the one specified in the **functionname** parameter).

Note the difference from the STARTTASK instruction, which sends another function in execution in parallel with the caller function (it is used to have more tasks in execution at the same time).

### Example

Sequential/Parallel execution

## DELONFLAG

### Syntax

**DELONFLAG**                                      **flagname**

### Arguments

**flagname**                                        name of flag device

### Description

It disables the software interruption management on the state of a flag bit or flag switch which was previously enabled with the ONFLAG instruction.

## DELONINPUT

### Syntax

**DELONINPUT**                                      **nameinput**

### Arguments

**nameinput**                                        name of input

### Description

It disables the software interruption management on the state of an input which was previously enabled with the ONINPUT instruction.

## FOR/NEXT

### Syntax

**FOR**    **index, begin, end [, step]**  
     **instruction**  
     **instruction**  
     **...**  
**NEXT**

**Arguments**

|              |  |
|--------------|--|
| <b>index</b> | variable or countername  |
| <b>begin</b> | constant or variable or countername. Beginning value           |
| <b>end</b>   | constant or variable or countername. End value                 |
| <b>step</b>  | constant or variable or countername. Increase or decrease step |

**Description**

It repeats cyclically the execution of the instructions included between the FOR instruction and the NEXT instruction.

During the first cycle the **index** variable is set on the value of the **begin** variable. In the second cycle the value of the **index** variable will equal (**begin+step**), and so on until the **index** variable is greater (or smaller, if the **step** variable is a negative value), than the **end** variable. If the **step** variable is omitted, a default value equal to +1 is set.

The instructions included between FOR and NEXT can modify the number of repetitions by modifying **index**.

When the repetitions end, it executes the instruction after NEXT.

**Example**

```
Function Loop
  local i As integer
  local vector[10] as integer

  For i,1,10
    Setval i, vector[i] ; it fills in the elements
                        ; of the vector
                        ; with numbers 1,2, .... 10
  Next
Fret
```

```
Function loop2
  local j As integer
  local vector[10] as integer

  For j,1,10,2
    Setval 27, vector[j] ; sets the value 27 in the following
                        ; element of the vector: 1,3,5,7,9
  Next
Fret
```

**FRET****Syntax**  
**FRET****Arguments**

no argument

**Description**

Return from a function. It causes the interruption of the execution of a function and the release of the memory allocated for the local variables. If the function was sent in execution with an FCALL, caller function execution restarts from the next instruction.

If any WAITASKS were executed previously with the current function (the one in which the FRET is executed) as argument, the waiting tasks are released.

## GOTO

### Syntax

**GOTO** **label**

### Arguments

**label** label

### Description

It makes an unconditional jump to the label specified in the **label** parameter. A label is defined by a keyword followed immediately by the character ":". The label must be contained in the body of the function in which the GOTO instruction is executed.

### Note

The body of a function is the part included between the FUNCTION instruction, which declares the name of the function, and the instruction defining the following function (or the end of the file). It is clear, then, that it is possible to jump from the main body of the function to any existing subprocedures (see CALL and RET instructions). We highly discourage this programming style as it generates numerous errors which are difficult to identify.

### Example

```
; Function to make a flag flash
; (for ex. a warning light on a synoptic panel)
```

Function Loop

```
loop:
setflag alarm ; enables the flag
delay 1
resetflag alarm ; disables the flag
delay 1
goto loop
Next
Fret
```

## IF/IFVALUE/IFTHENELSE

### Syntax

**IF** **varname, comparison operator, value, GOTO label**  
**IF** **varname, comparison operator, value, CALL subprogramname**  
**IF** **varname, comparison operator, value, functionname**

**IF** **varname, comparison operator, value THEN**  
**instruction**  
**instruction**  
**...**

**ENDIF**

**IF** **varname, comparison operator, value THEN**  
**instruction**  
**instruction**  
**...**

**ELSE**

**instruction**  
**instruction**  
**...**

**ENDIF**

### Arguments

**varname** constant or variable or devicename  
**comparison operator** the symbols used for comparison are:  
< (smaller) = (equal)  
> (greater) =< (minor or equal)  
>= (greater or equal) <> (different)  
**value** constant or variable or devicename

|                       |                              |
|-----------------------|------------------------------|
| <b>label</b>          | name of the label to jump to |
| <b>subprogramname</b> | name of subprogram           |
| <b>functionname</b>   | name of function             |

**Description**

The IF and IFVALUE instructions are synonymous. We suggest using the short version. The instruction allows you to make a comparison between **varname** and **value** and, according to the result, to execute an action.

In the first three forms, if the comparison is positive, it can jump to label (GOTO), call a subprogram (CALL) or call a function (functionname). When the execution of the function or subprogram ends, it carries on from the following line. If the comparison is negative, the execution of the program continues. The IF...THEN construction allows to carry out one or more instructions conditionally. The instructions included between the keywords THEN and ENDIF are executed if the comparison between **varname** and **value** is positive.

The IF...THEN...ELSE construction allows you to define two blocks of instructions, of which only one will be executed. If the comparison between **varname** and **value** is positive, the instructions included between the keywords THEN and ELSE will be executed, if it's negative it will execute the instructions included between the words ELSE and ENDIF. In both cases the execution then continues with the instruction following ENDIF.

**Note**

IFVALUE is kept for compatibility with earlier GPL versions.

**IFACC****Syntax**

|              |                                  |
|--------------|----------------------------------|
| <b>IFACC</b> | <b>axis, GOTO label</b>          |
| <b>IFACC</b> | <b>axis, CALL subprogramname</b> |
| <b>IFACC</b> | <b>axis, functionname</b>        |

**Arguments**

|                       |                          |
|-----------------------|--------------------------|
| <b>axis</b>           | name of axis device      |
| <b>label</b>          | name of label to jump to |
| <b>subprogramname</b> | name of subprogram       |
| <b>functionname</b>   | name of function         |

**Description**

It checks whether the axis specified in the **axis** variable is in acceleration. If it is, it jumps to **label** or calls **subprogramname** or **functionname**.

**IFAND****Syntax**

|              |   |
|--------------|---|
| <b>IFAND</b> | <b>operand1, operand2, testvalue, GOTO label</b>          |
| <b>IFAND</b> | <b>operand1, operand2, testvalue, CALL subprogramname</b> |
| <b>IFAND</b> | <b>operand1, operand2, testvalue, functionname</b>        |

|              |   |
|--------------|---|
| <b>IFAND</b> | <b>operand1, operand2, testvalue THEN</b> |
|              | <b>instruction</b>                        |
|              | <b>instruction</b>                        |
|              | ...                                       |

**ENDIF**

|              |   |
|--------------|---|
| <b>IFAND</b> | <b>operand1, operand2, testvalue THEN</b> |
|              | <b>instruction</b>                        |
|              | <b>instruction</b>                        |
|              | ...                                       |

|  |                    |
|--|--------------------|
|  | <b>instruction</b> |
|  | <b>instruction</b> |
|  | ...                |

**ELSE**

|  |                    |
|--|--------------------|
|  | <b>instruction</b> |
|  | <b>instruction</b> |
|  | ...                |

**ENDIF****Arguments**

|                 |                                    |
|-----------------|------------------------------------|
| <b>operand1</b> | constant or variable or devicename |
|-----------------|------------------------------------|



|                       |  |
|-----------------------|--|
| <b>operand2</b>       | constant or variable or devicename   |
| <b>testvalue</b>      | constant. Value used to check the result of the operation. Possible values are:<br><b>TRUE</b> 1<br><b>FALSE</b> 0 |
| <b>label</b>          | name of the label to jump to   |
| <b>subprogramname</b> | name of the subprogram   |
| <b>functionname</b>   | name of the function   |

**Description**

Two comparisons are performed, the first between **operand1** and **operand2**, the second between the result of the first comparison and **testvalue**.  
 The first comparison consists of a binary AND between **operand1** and **operand2**. The two operands are interpreted as bit masks. If in the result of the binary AND at least one bit is not equal to 0, the result of the first comparison is TRUE. This will then be compared with **testvalue**. If the two values coincide, a jump to label or a call function or call subprogram is performed.  
 For more details on the IF-THEN-ELSE construct, see IF / IFVALUE / IF-THEN-ELSE.

**IFBIT**

**Syntax**

**IFBIT** **mask, nbit, state, GOTO label**  
**IFBIT** **mask, nbit, state, CALL subprogramname**  
**IFBIT** **mask, nbit, state, functionname**

**IFBIT** **mask, nbit, state THEN**  
**instruction**  
**instruction**  
 ...

**ENDIF**

**IFBIT** **mask, nbit, state THEN**  
**instruction**  
**instruction**  
 ...

**ELSE**

**instruction**  
**instruction**  
 ...

**ENDIF**

**Arguments**

|                       |   |
|-----------------------|---|
| <b>mask</b>           | constant or integer variable or countername or nameport. Value to be verified   |
| <b>nbit</b>           | constant or integer variable or countername. Number of the bit (1÷32)   |
| <b>state</b>          | predefined constant. State to be verified on mask.<br>Acceptable values are:<br><b>ON</b> chosen bit to 1<br><b>OFF</b> chosen bit to 0 |
| <b>label</b>          | jump label (GOTO)   |
| <b>subprogramname</b> | call subprogram (CALL)  |
| <b>functionname</b>   | name of function  |

**Description**

Test on a single bit of the passed bit **mask**. The **mask** argument must correspond to an integer value with a maximum of 32 bits. The number assigned to the **nbit** variable to identify the bit to be tested must be included between 1 and 32. If the condition indicated in **state** is satisfied, it jumps to **label** or calls **subprogramname** or **functionname**.  
 For more details on the IF-THEN-ELSE construct, see IF / IFVALUE / IF-THEN-ELSE.

**IFBLACKBOX****Syntax**

|                   |                            |
|-------------------|----------------------------|
| <b>IFBLACKBOX</b> | <b>GOTO label</b>          |
| <b>IFBLACKBOX</b> | <b>CALL subprogramname</b> |
| <b>IFBLACKBOX</b> | <b>functionname</b>        |

**Arguments**

|                       |                              |
|-----------------------|------------------------------|
| <b>label</b>          | name of the label to jump to |
| <b>subprogramname</b> | subprogram name              |
| <b>functionname</b>   | function name                |

**Description**

If the record is active, it jumps to **label** or it calls **subprogramname** or **functionname**. See also STARTBLACKBOX, PAUSEBLACKBOX and ENDBLACKBOX.

**IFCHANGEVEL****Syntax**

|                    |  |
|--------------------|--|
| <b>IFCHANGEVEL</b> | <b>axis [, state], GOTO label</b>          |
| <b>IFCHANGEVEL</b> | <b>axis [, state], CALL subprogramname</b> |
| <b>IFCHANGEVEL</b> | <b>axis [, state], functionname</b>        |

**Arguments**

|                       |   |
|-----------------------|---|
| <b>axis</b>           | name of axis device   |
| <b>state</b>          | type of variation. Acceptable values are:<br><b>POSITIVE</b><br><b>NEGATIVE</b> |
| <b>label</b>          | name of label to jump to  |
| <b>subprogramname</b> | name of subprogram  |
| <b>functionname</b>   | name of function  |

**Description**

It tests if axis speed has varied.

If the axis specified in the **axis** variable is subject to speed variation during movement, a jump to **label** or a call to **subprogramname** of **functionname** is performed.

The **state** parameter specifies if speed has increased (POSITIVE) or decreased (NEGATIVE).

**IFCOUNTER****Syntax**

|                  |  |
|------------------|--|
| <b>IFCOUNTER</b> | <b>countername, comparison operator, value, GOTO label</b>   |
| <b>IFCOUNTER</b> | <b>countername, comparison operator, value, CALL</b>         |
| <b>IFCOUNTER</b> | <b>countername, comparison operator, value, functionname</b> |

|                    |   |
|--------------------|---|
| <b>IFCOUNTER</b>   | <b>countername, comparison operator, value THEN</b> |
| <b>instruction</b> |   |
| <b>instruction</b> |   |
| <b>...</b>         |   |
| <b>ENDIF</b>       |   |

|                    |   |
|--------------------|---|
| <b>IFCOUNTER</b>   | <b>countername, comparison operator, value THEN</b> |
| <b>instruction</b> |   |
| <b>instruction</b> |   |
| <b>...</b>         |   |
| <b>ELSE</b>        |   |
| <b>instruction</b> |   |
| <b>instruction</b> |   |
| <b>...</b>         |   |
| <b>ENDIF</b>       |   |

**Arguments**

|                            |                                      |
|----------------------------|--------------------------------------|
| <b>countername</b>         | name of the counter                  |
| <b>comparison operator</b> | the symbols used for comparison are: |

|                       |                                      |
|-----------------------|--------------------------------------|
|                       | < (smaller) = (equal)                |
|                       | > (greater) =< (minor or equal )     |
|                       | >= (greater or equal) <> (different) |
| <b>value</b>          | constant or variable or countername  |
| <b>label</b>          | name of the label to jump to         |
| <b>subprogramname</b> | name of subprogram                   |
| <b>functionname</b>   | name of function                     |

**Description**

This instruction tests the counter. If the content of the counter defined in the **countername** variable satisfies the condition specified by the **comparison operator**, with the value expressed in the **value** variable, it jumps to the label specified in **label** or calls the subprogram defined in **subprogramname** or the function defined in **functionname**. For more details on the IF-THEN-ELSE construct, see IF / IFVALUE / IF-THEN-ELSE.

**IFDEC**

**Syntax**

|              |                                  |
|--------------|----------------------------------|
| <b>IFDEC</b> | <b>axis, GOTO label</b>          |
| <b>IFDEC</b> | <b>axis, CALL subprogramname</b> |
| <b>IFDEC</b> | <b>axis, functionname</b>        |

**Arguments**

|                       |                          |
|-----------------------|--------------------------|
| <b>axis</b>           | name of axis device      |
| <b>label</b>          | name of label to jump to |
| <b>subprogramname</b> | name of subprogram       |
| <b>functionname</b>   | name of function         |

**Description**

It checks if the axis defined in the **axis** variable is decelerating. If the condition is confirmed, it jumps to **label** or calls **subprogramname** or **functionname**.

**IFDIR**

**Syntax**

|              |   |
|--------------|---|
| <b>IFDIR</b> | <b>axis, direction, GOTO label</b>          |
| <b>IFDIR</b> | <b>axis, direction, CALL subprogramname</b> |
| <b>IFDIR</b> | <b>axis, direction, functionname</b>        |

|              |  |                             |
|--------------|--|-----------------------------|
| <b>IFDIR</b> |  | <b>axis, direction THEN</b> |
|--------------|--|-----------------------------|

|                    |
|--------------------|
| <b>instruction</b> |
| <b>instruction</b> |

...

**ENDIF**

|              |  |                             |
|--------------|--|-----------------------------|
| <b>IFDIR</b> |  | <b>axis, direction THEN</b> |
|--------------|--|-----------------------------|

|                    |
|--------------------|
| <b>instruction</b> |
| <b>instruction</b> |

...

**ELSE**

|                    |
|--------------------|
| <b>instruction</b> |
| <b>instruction</b> |

...

**ENDIF**

**Arguments**

|                       |  |
|-----------------------|--|
| <b>axis</b>           | name of axis device  |
| <b>direction</b>      | axis direction. Acceptable values are:<br><b>POSITIVE</b> positive axis direction<br><b>NEGATIVE</b> negative axis direction |
| <b>label</b>          | name of label to jump to   |
| <b>subprogramname</b> | name of subprogram   |
| <b>functionname</b>   | name of function   |

**Description**

It tests the current direction of an axis.

If the **axis** is moving in the direction specified in the **direction** variable, a jump to **label** or a call to **subprogramname** or **functionname** is performed.

For more details on the IF-THEN-ELSE construct, see IF / IFVALUE / IF-THEN-ELSE.

**IFERRAN****Syntax**

**IFERRAN** **axis, comparison operator, value, GOTO label**  
**IFERRAN** **axis, comparison operator, value, CALL subprogramname**  
**IFERRAN** **axis, comparison operator, value, functionname**

**IFERRAN** **axis, comparison operator, value THEN**  
**instruction**  
**instruction**  
 ...

**ENDIF**

**IFERRAN** **axis, comparison operator, value THEN**  
**instruction**  
**instruction**  
 ...

**ELSE**

**instruction**  
**instruction**  
 ...

**ENDIF****Arguments**

|                            |   |
|----------------------------|---|
| <b>axis</b>                | name of axis device   |
| <b>comparison operator</b> | the symbols used for comparison are:<br>< (smaller) = (equal)<br>> (greater) =< (minor or equal )<br>>= (greater or equal) <> (different) |
| <b>value</b>               | constant or variable or countername   |
| <b>label</b>               | name of the label to jump to  |
| <b>subprogramname</b>      | name of subprogram  |
| <b>e</b>                   |   |
| <b>functionname</b>        | name of function  |

**Description**

It checks the value of the tracking error (loop error) of the axis defined in the **axis** variable.

If the **axis** loop error confirms the condition expressed by the **comparison operator** with the value expressed by **value**, it jumps to **label** or calls **subprogramname** or **functionname**.

For more details on the IF-THEN-ELSE construct, see IF / IFVALUE / IF-THEN-ELSE.

**IFERROR****Syntax**

**IFERROR** **number, IDposiz, GOTO label**  
**IFERROR** **number, IDposiz, CALL label**  
**IFERROR** **number, IDposiz, functionname**  
**IFERROR** **devicename, state, IDposiz, GOTO label**  
**IFERROR** **devicename, state, IDposiz, CALL label**  
**IFERROR** **devicename, state, IDposiz, functionname**

**Arguments**

|                   |  |
|-------------------|--|
| <b>number</b>     | DEFMSG or constant or integer variable   |
| <b>devicename</b> | name of device   |
| <b>state</b>      | predefined constant. State to be verified<br>Acceptable values are:<br><b>ON</b><br><b>OFF</b> |

**IDposiz** constant or variable. A numeric value used in synoptics.  
**label** name of label to jump to  
**functionname** name of function

**Description**

It tests if cycle error is enabled.  
 If cycle error, identified by **number** and **IDposiz** or by **devicename**, **state** and **IDposiz**, is enabled it can jump to **label** or call function **functionname**.  
 Parameter **number** can identify an error of module cycle (therefore an entire numeric value) or of group (in this case a DEFMSG is used).  
 Parameter **devicename** is the name of a device and the parameter **state** represents the state ON/OFF in which the device is located, when the error is generated.  
 Parameter **number** can identify an error of module cycle (therefore an entire numeric value) or of group (in this case a DEFMSG is used).  
 Parameter **devicename** is the name of a device and the parameter **state** represents the ON/OFF state in which the device should be found, when the error is generated.  
 Parameter **IDposiz** is an optional parameter, specifying the numeric value used in the synoptics to sort out cycle errors in different cells. It must match the specified value in the synoptics creator for that particular display cell. If there is no need to point out a specific cell, the predefined NOPLACE constant must be assigned. The range of the values that can be set is included between 0 (NOPLACE) and 1023.  
 If the instruction is used without enabling the alarms management to status conditions, an error system is generated.  
 See also instruction ERROR.

**IFFLAG**

**Syntax**

**IFFLAG** **flagname, state, GOTO label**  
**IFFLAG** **flagname, state, CALL subprogramname**  
**IFFLAG** **flagname, state, functionname**

**IFFLAG** **flagname, state THEN**  
 instruction  
 instruction  
 ...

**ENDIF**

**IFFLAG** **flagname, state THEN**  
 instruction  
 instruction  
 ...

**ELSE**

instruction  
 instruction  
 ...

**ENDIF**

**Arguments**

**flagname** name of flag device  
**state** predefined constant. State to be tested. Possible values are:  
**ON** enabled  
**OFF** disabled  
**label** name of label to jump to  
**subprogramname** name of subprogram  
**functionname** name of function

**Description**

It tests the logical state of a flag.  
 If the flag defined in the **flagname** variable satisfies the indicated **state**, it jumps to **label** or calls **subprogramname** or **functionname**.  
 For more details on the IF-THEN-ELSE construct, see IF / IFVALUE / IF-THEN-ELSE.

**IFOR****Syntax**

**IFOR**                    **operand1, operand2, testvalue, GOTO label**  
**IFOR**                    **operand1, operand2, testvalue, CALL subprogramname**  
**IFOR**                    **operand1, operand2, testvalue, functionname**

**IFOR**                    **operand1, operand2, testvalue THEN**

**instruction**  
**instruction**  
 ...

**ENDIF**

**IFOR**                    **operand1, operand2, testvalue THEN**

**instruction**  
**instruction**  
 ...

**ELSE**

**instruction**  
**instruction**  
 ...

**ENDIF****Arguments**

**operand1**            constant or variable or devicename  
**operand2**            constant or variable or devicename  
**testvalue**            constant. Value used to check the result of the operation.  
                           Possible values are:  
                           **TRUE** 1  
                           **FALSE** 0  
**label**                name of the label to jump to  
**subprogramname**    name of the subprogram  
**functionname**        name of the function

**Description**

Two comparisons are performed, the first between **operand1** and **operand2**, the second between the result of the first comparison and **testvalue**.

The first comparison consists of a binary OR between **operand1** and **operand2**. The two operands are interpreted as bit masks. If in the result of the binary OR at least one bit is not equal to 0, the result of the first comparison is TRUE. This will then be compared to **testvalue**. If the two values coincide, a jump to label or a call function or call subprogram is performed.

For more details on the IF-THEN-ELSE construct, see IF / IFVALUE / IF-THEN-ELSE.

**IFINPUT****Syntax**

**IFINPUT**                **inputname, state, GOTO label**  
**IFINPUT**                **inputname, state, CALL subprogramname**  
**IFINPUT**                **inputname, state, functionname**

**IFINPUT**                **inputname, state THEN**

**instruction**  
**instruction**  
 ...

**ENDIF**

**IFINPUT**                **inputname, state THEN**

**instruction**  
**instruction**  
 ...

**ELSE**

**instruction**  
**instruction**  
 ...

## ENDIF

### Arguments

|                       |   |
|-----------------------|---|
| <b>inputname</b>      | name of input   |
| <b>state</b>          | predefined constant. State to be verified<br>Acceptable values are:<br><b>ON</b> enabled<br><b>OFF</b> disabled |
| <b>label</b>          | name of label to jump to  |
| <b>subprogramname</b> | name of subprogram  |
| <b>functionname</b>   | name of function  |

### Description

It tests the analog state of an input. If the input specified in the **inputname** variable is in the indicated **state**, a jump to **label** or a **subprogramname** or **functionname** call is performed. For more details on the IF-THEN-ELSE construct, see IF / IFVALUE / IF-THEN-ELSE.

## IFMESSAGE

### Syntax

|                  |                                      |
|------------------|--------------------------------------|
| <b>IFMESSAGE</b> | <b>number, IDposiz, GOTO label</b>   |
| <b>IFMESSAGE</b> | <b>number, IDposiz, CALL label</b>   |
| <b>IFMESSAGE</b> | <b>number, IDposiz, functionname</b> |

### Arguments

|                     |  |
|---------------------|--|
| <b>number</b>       | DEFMSG or constant or integer variable                   |
| <b>IDposiz</b>      | constant or variable. A numeric value used in synoptics. |
| <b>label</b>        | name of label to jump to                                 |
| <b>functionname</b> | name of function   |

### Description

It tests if message is enabled. If message, identified by **number** and **IDposiz** is enabled it can jump to **label** or call function **functionname**, Parameter **IDposiz** is an optional parameter specifying the numeric value used in synoptics to sort out cycle errors in different cells. It must correspond with the specified value in the synoptics creator for that particular display cell. If there is no need to point out a specific cell, the predefined NOPLACE constant must be assigned. The range of the values, that can be set is included between 0 (NOPLACE) and 1023. If the instruction is used without enabling the alarms management to status conditions, an error system is generated. See also instruction MESSAGE.

## IFOUTPUT

### Syntax

|                 |   |
|-----------------|---|
| <b>IFOUTPUT</b> | <b>outputname, state, GOTO label</b>          |
| <b>IFOUTPUT</b> | <b>outputname, state, CALL subprogramname</b> |
| <b>IFOUTPUT</b> | <b>outputname, state, functionname</b>        |

**IFOUTPUT**                      **outputname, state THEN**

**instruction**  
**instruction**

...

**ENDIF**

**IFOUTPUT**                      **outputname, state THEN**

**instruction**  
**instruction**

...

**ELSE**

**instruction**  
**instruction**

**ENDIF**           ...

### Arguments

|                       |   |
|-----------------------|---|
| <b>outputname</b>     | name of output  |
| <b>state</b>          | predefined constant. State to be verified on output<br>Acceptable values are:<br><b>ON</b> enabled<br><b>OFF</b> disabled |
| <b>label</b>          | name of label to jump to  |
| <b>subprogramname</b> | name of subprogram  |
| <b>functionname</b>   | name of function  |

### Description

It tests the analog state of an output.

If the input specified in the **outputname** variable is in the indicated **state**, a jump to **label** or a **subprogramname** or **functionname** call is performed.

For more details on the IF-THEN-ELSE construct, see IF / IFVALUE / IF-THEN-ELSE.

## IFQUOTER

### Syntax

```
IFQUOTER           axis, comparison operator, value, GOTO label
IFQUOTER           axis, comparison operator, value, CALL subprogramname
IFQUOTER           axis, comparison operator, value, functionname
```

```
IFQUOTER           axis, comparison operator, value THEN
                  instruction
                  instruction
                  ...
```

**ENDIF**

```
IFQUOTER           axis, comparison operator, value THEN
                  instruction
                  instruction
                  ...
```

```
ELSE               instruction
                  instruction
                  ...
```

**ENDIF**

### Arguments

|                            |   |
|----------------------------|---|
| <b>axis</b>                | name of axis device   |
| <b>comparison operator</b> | the symbols used for comparison are:<br>< (smaller) = (equal)<br>> (greater) =< (minor or equal )<br>>= (greater or equal) <> (different) |
| <b>value</b>               | constant or variable or countername   |
| <b>label</b>               | name of the label to jump to  |
| <b>subprogramname</b>      | name of subprogram  |
| <b>functionname</b>        | name of function  |

### Description

It tests the real position specified by the **axis** variable.

If the value of the **axis** variable complies with the condition expressed in the **comparison operator** with the value specified by **value**, it jumps to **label** or calls **subprogramname** or **functionname**.

For more details on the IF-THEN-ELSE construct, see IF / IFVALUE / IF-THEN-ELSE.

## IFQUOTET

### Syntax

```
IFQUOTET           axis, comparison operator, value, GOTO label
IFQUOTET           axis, comparison operator, value, CALL subprogramname
```



**IFQUOTET** axis, comparison operator, value, functionname

**IFQUOTET** axis, comparison operator, value **THEN**

instruction  
instruction  
...

**ENDIF**

**IFQUOTET** axis, comparison operator, value **THEN**

instruction  
instruction  
...

**ELSE**

instruction  
instruction  
...

**ENDIF**

**Arguments**

**axis** name of axis device  
**comparison operator** the symbols used for comparison are:  
 < (smaller) = (equal)  
 > (greater) =< (minor or equal )  
 >= (greater or equal) <> (different)  
**value** constant or variable or countername  
**label** name of the label to jump to  
**subprogramname** name of subprogram  
**e**  
**functionname** name of function

**Description**

It tests the theoretical position specified by the **axis** variable.  
 If the value of the **axis** variable complies with the condition expressed in the **comparison operator** with the value specified by **value**, it jumps to **label** or calls **subprogramname** or **functionname**.  
 For more details on the IF-THEN-ELSE construct, see IF / IFVALUE / IF-THEN-ELSE.

**IFRECEIVED**

**Syntax**

**IFRECEIVED** [source, ] identifier, **GOTO** label  
**IFRECEIVED** [source, ] identifier, **CALL** subprogramname  
**IFRECEIVED** [source, ] identifier, functionname

**Arguments**

**source** string constant  
**identifier** string constant  
**label** name of label to jump to  
**subprogramname** name of subprogram  
**functionname** name of function

**Description**

It tests if a RECEIVE instruction has been satisfied.  
 If a specified former RECEIVE was satisfied, it jumps to label or calls subprogramname or functionname.  
 See also instructions RECEIVE, WAITRECEIVE, SEND.

**IFREG**

**Syntax**

**IFREG** axis, **GOTO** label  
**IFREG** axis, **CALL** subprogramname  
**IFREG** axis, functionname

**Arguments**

|                       |                          |
|-----------------------|--------------------------|
| <b>axis</b>           | name of axis device      |
| <b>label</b>          | name of label to jump to |
| <b>subprogramname</b> | name of subprogram       |
| <b>functionname</b>   | name of function         |

**Description**

It checks that the axis specified in the **axis** variable is in regime state.  
If the condition is confirmed, it jumps to **label** or calls **subprogramname** or **functionname**.

**IFSAME****Syntax**

|               |  |
|---------------|--|
| <b>IFSAME</b> | <b>operand1, operand2, GOTO label</b>          |
| <b>IFSAME</b> | <b>operand1, operand2, CALL subprogramname</b> |
| <b>IFSAME</b> | <b>operand1, operand2, functionname</b>        |

**Arguments**

|                       |                              |
|-----------------------|------------------------------|
| <b>operand1</b>       | variable or devicename       |
| <b>operand2</b>       | variable or devicename       |
| <b>label</b>          | name of the label to jump to |
| <b>subprogramname</b> | name of the subprogram       |
| <b>functionname</b>   | name of the function         |

**Description**

Test between two operands.  
It verifies if the value defined in **operand1** and **operand2** refer either to the same device or the same memory area.  
If the test between the two operands is confirmed, it jumps to **label** or calls **subprogramname** or **functionname**.

**IFSTILL****Syntax**

|                |                                  |
|----------------|----------------------------------|
| <b>IFSTILL</b> | <b>axis, GOTO label</b>          |
| <b>IFSTILL</b> | <b>axis, CALL subprogramname</b> |
| <b>IFSTILL</b> | <b>axis, functionname</b>        |

**Arguments**

|                       |                          |
|-----------------------|--------------------------|
| <b>axis</b>           | name of axis device      |
| <b>label</b>          | name of label to jump to |
| <b>subprogramname</b> | name of subprogram       |
| <b>functionname</b>   | name of function         |

**Description**

It tests if the axis defined in the **axis** variable is really still, that is if it is "in position".  
If the condition is confirmed, it jumps to **label** or calls **subprogramname** or **functionname**.  
See also IFTARGET and IFWIN.

**IFSTR****Syntax**

|              |   |
|--------------|---|
| <b>IFSTR</b> | <b>string1, comparison operator, string2, GOTO label</b>          |
| <b>IFSTR</b> | <b>string1, comparison operator, string2, CALL subprogramname</b> |
| <b>IFSTR</b> | <b>string1, comparison operator, string2, functionname</b>        |

|                    |   |
|--------------------|---|
| <b>IFSTR</b>       | <b>string1, comparison operator, string2 THEN</b> |
| <b>instruction</b> |   |
| <b>instruction</b> |   |
| <b>...</b>         |   |

**ENDIF**

|                    |   |
|--------------------|---|
| <b>IFSTR</b>       | <b>string1, comparison operator, string2 THEN</b> |
| <b>instruction</b> |   |
| <b>instruction</b> |   |
| <b>...</b>         |   |

```

ELSE          instruction
              instruction
              ...
ENDIF

```

**Arguments**

|                            |   |
|----------------------------|---|
| <b>string1</b>             | string variable. The first ASCII string   |
| <b>comparison operator</b> | the symbols used for comparison are:<br>< (smaller) = (equal)<br>> (greater) =< (minor or equal )<br>>= (greater or equal) <> (different) |
| <b>string2</b>             | string variable. The second ASCII string  |
| <b>label</b>               | name of the label to jump to  |
| <b>subprogramname</b>      | name of subprogram  |
| <b>functionname</b>        | name of function  |

**Description**

Test on ASCII strings.  
 If the string defined in **string1** confirms the condition expressed by the **comparison operator** with the string in **string2**, a jump to **label** or a **subprogramname** or **functionname** call is performed. For more details on the IF-THEN-ELSE construct, see IF / IVALUE / IF-THEN-ELSE.

**IFTARGET**

**Syntax**

|                 |                                  |
|-----------------|----------------------------------|
| <b>IFTARGET</b> | <b>axis, GOTO label</b>          |
| <b>IFTARGET</b> | <b>axis, CALL subprogramname</b> |
| <b>IFTARGET</b> | <b>axis, functionname</b>        |

**Arguments**

|                       |                          |
|-----------------------|--------------------------|
| <b>axis</b>           | name of axis device      |
| <b>label</b>          | name of label to jump to |
| <b>subprogramname</b> | name of subprogram       |
| <b>functionname</b>   | name of function         |

**Description**

It checks if the axis defined in the **axis** variable has reached the final programmed position. Even if it has reached the final target position, this does not necessarily mean that it has stopped, as it usually has to recover the loop error. If the condition is confirmed, it jumps to **label** or calls **subprogramname** or **functionname**. See also IFSTILL and IFWIN.

**IFTASKHOLD**

**Syntax**

|                   |                                      |
|-------------------|--------------------------------------|
| <b>IFTASKHOLD</b> | <b>nametask, GOTO label</b>          |
| <b>IFTASKHOLD</b> | <b>nametask, CALL subprogramname</b> |
| <b>IFTASKHOLD</b> | <b>nametask, functionname</b>        |

**Arguments**

|                       |                          |
|-----------------------|--------------------------|
| <b>nametask</b>       | name of parallel task    |
| <b>label</b>          | name of label to jump to |
| <b>subprogramname</b> | name of subprogram       |
| <b>functionname</b>   | name of function         |

**Description**

It checks whether the task has been interrupted (hold state).  
 If the **nametask** is in hold, a jump to **label** or a **subprogramname** or **functionname** call is performed.

**IFTASKRUN****Syntax**

|                  |                                      |
|------------------|--------------------------------------|
| <b>IFTASKRUN</b> | <b>nametask, GOTO label</b>          |
| <b>IFTASKRUN</b> | <b>nametask, CALL subprogramname</b> |
| <b>IFTASKRUN</b> | <b>nametask, functionname</b>        |

**Arguments**

|                       |                          |
|-----------------------|--------------------------|
| <b>nametask</b>       | name of parallel task    |
| <b>label</b>          | name of label to jump to |
| <b>subprogramname</b> | name of subprogram       |
| <b>functionname</b>   | name of function         |

**Description**

It checks if the task is in execution.

If the task defined in **nametask** is in execution, it jumps to **label** or calls **subprogramname** or **functionname**.

**IFTIMER****Syntax**

|                |   |
|----------------|---|
| <b>IFTIMER</b> | <b>nametimer, comparison operator, value, GOTO label</b>          |
| <b>IFTIMER</b> | <b>nametimer, comparison operator, value, CALL subprogramname</b> |
| <b>IFTIMER</b> | <b>nametimer, comparison operator, value, functionname</b>        |

|                |   |
|----------------|---|
| <b>IFTIMER</b> | <b>nametimer, comparison operator, value THEN</b> |
|----------------|---|

**instruction**  
**instruction**  
...

**ENDIF**

|                |   |
|----------------|---|
| <b>IFTIMER</b> | <b>nametimer, comparison operator, value THEN</b> |
|----------------|---|

**instruction**  
**instruction**  
...

**ELSE**

**instruction**  
**instruction**  
...

**ENDIF****Arguments**

|                            |   |
|----------------------------|---|
| <b>nametimer</b>           | name of timer device  |
| <b>comparison operator</b> | the symbols used for comparison are:<br>< (smaller) = (equal)<br>> (greater) =< (minor or equal )<br>>= (greater or equal) <> (different) |
| <b>value</b>               | constant or variable or nametimer. The comparison value.  |
| <b>label</b>               | name of the label to jump to  |
| <b>subprogramname</b>      | name of subprogram  |
| <b>functionname</b>        | name of function  |

**Description**

Timer test.

If the content of the **nametimer** timer satisfies the condition expressed in the **comparison operator** with the value expressed in value, a jump to **label** or a **subprogramname** or **functionname** call is performed.

For more details on the IF-THEN-ELSE construct, see IF / IFVALUE / IF-THEN-ELSE.

**IFVEL****Syntax**

|              |  |
|--------------|--|
| <b>IFVEL</b> | <b>axis, comparison operator, value, GOTO label</b>          |
| <b>IFVEL</b> | <b>axis, comparison operator, value, CALL subprogramname</b> |

**IFVEL** **axis, comparison operator, value, functionname**

**IFVEL** **axis, comparison operator, value THEN**

**instruction**  
**instruction**  
...

**ENDIF**

**IFVEL** **axis, comparison operator, value THEN**

**instruction**  
**instruction**  
...

**ELSE**

**instruction**  
**instruction**  
...

**ENDIF**

**Arguments**

**axis** name of axis device  
**comparison operator** the symbols used for comparison are:  
 < (smaller) = (equal)  
 > (greater) =< (minor or equal )  
 >= (greater or equal) <> (different)  
**label** name of the label to jump to  
**subprogramname** name of subprogram  
**functionname** name of function

**Description**

It tests current speed of an axis.  
 If the speed of the axis confirms the condition expressed in the **comparison operator** with the value expressed in **value**, a jump to **label** or a **subprogramname** or **functionname** call is performed.  
 For more details on the IF-THEN-ELSE construct, see IF / IFVALUE / IF-THEN-ELSE.

**IFWIN**

**Syntax**

**IFWIN** **axis, GOTO label**  
**IFWIN** **axis, CALL subprogramname**  
**IFWIN** **axis, functionname**

**Arguments**

**axis** name of axis device  
**label** name of label to jump to  
**subprogramname** name of subprogram  
**functionname** name of function

**Description**

It tests if the axis specified in the **axis** variable has entered the arrival position window (see Glossary).  
 If the condition is confirmed, it jumps to **label** or calls **subprogramname** or **functionname**.  
 See also IFTARGET and IFSTILL.

**IFXOR**

**Syntax**

**IFXOR** **operand1, operand2, testvalue, GOTO label**  
**IFXOR** **operand1, operand2, testvalue, CALL subprogramname**  
**IFXOR** **operand1, operand2, testvalue, functionname**

**IFXOR** **operand1, operand2, testvalue THEN**

**instruction**

```

instruction
...
ENDIF

IFXOR          operand1, operand2, testvalue THEN
instruction
instruction
...
ELSE
instruction
instruction
...
ENDIF

```

**Arguments**

**operand1** constant or variable or devicename  
**operand2** constant or variable or devicename  
**testvalue** constant. Value used to verify the result of the operation.  
Possible values are:  
**TRUE 1**  
**FALSE 0**

**label** name of the label to jump to  
**subprogramname** name of the subprogram  
**functionname** name of the function

**Description**

Two comparisons are performed, the first between **operand1** and **operand2**, the second between the result of the first comparison and **testvalue**.

The first comparison consists in a binary XOR between **operand1** and **operand2**. The two operands are interpreted as bit masks. If in the result of the binary XOR at least one bit is not equal to 0, the result of the first comparison is TRUE. This will then be compared to **testvalue**. If the two values coincide, a jump to label or a call function or call subprogram is performed.

For more details on the IF-THEN-ELSE construct, see IF / IFVALUE / IF-THEN-ELSE.

**ONERRSYS****Syntax**

```
ONERRSYS          functionname
```

**Arguments**

**functionname** name of function

**Description**

It enables system error management. The normal behaviour of the control, when a system error occurs, is to interrupt all the tasks. The system error management allows you to avoid closing down the tasks for which it has been enabled.

When a system error occurs the **functionname** function is sent in execution. The function's task is to analyse the system error and carry out the necessary actions to secure the machine.

The **functionname** function has two limitations:

First of all, it has to accept the following parameters:

- the number of the system error, as Integer number.
- the task where the error took place, as Function
- the device which generated the error, as device.

Secondly, it can not contain certain GPL instructions. See List of instructions which can not be used with interrupt.

In the case of multiple System Errors, the function is called once for each error generated, in sequence. If the function itself generates a System Error, all tasks are interrupted.

During function execution, the task for which the error management has been enabled stops, and it only restarts at the end of the first function called by the ONERRSYS instruction.

**Example**

Main Cycle with error management



**ENDREP**     ...**Arguments**

**value**                             constant or variable or countername. Number of repetitions.

**Description**

It repeats the execution of the instructions enclosed between the REPEAT instruction and the ENDREP instruction as many times as indicated in the **value** variable.

When the program reaches the ENDREP instruction, the counter of the number of repetition decreases and, if its value is not less or equal to zero, the block of instructions is reexecuted starting from the instruction after REPEAT. This means that the instructions are executed at least once (even if the value parameter is naught or negative from the beginning).

When the repetitions are concluded, the instruction following ENDREP is executed.

See also instruction FOR/NEXT.

**Example**

```
; example of cycle moving an axis
; between two positions for 10 times
Function Cycleo
  Repeat 10
    MovAbs axis,100
    waitinput switch,ON
    Movabs axis,-100
    Waitinput switch, OFF
  EndRep
Fret
```

**RET****Syntax**

**RET**

**Arguments**

no arguments

**Description**

It ends the execution of a subprogram and returns to the instruction immediately after the call CALL. See also the instruction CALL.

**Note**

This instruction, together with CALL, is a typical source of programming errors. We recommend taking great care when using it, in particular we suggest positioning the subprocedures at the end of the body of the function (after the FRET instruction) so as to avoid accidental execution of the subprocedure, as if it were an integral part of the main code. This situation, in the best of hypothesis, generates a system error; in other cases it causes anomalous behaviour of the machine whose origin is difficult to recognise.

**SELECT****Syntax**

**SELECT varname**

**CASE value**  
**GOTO label**

**CASE value1 TO value2**  
**CALL subprogramname**

**CASE IS < = > value**  
**[FCALL] functionname [parameter1,...parameterN]**

**CASE ELSE**  
**GOTO label**



**ENDSELECT**

**Arguments**

|                                |   |
|--------------------------------|---|
| <b>varname</b>                 | constant or integer variable or countername |
| <b>value, value1, value2</b>   | integer constants                           |
| <b>label</b>                   | name of label to jump to                    |
| <b>subprogramname</b>          | name of subprogram                          |
| <b>functionname</b>            | name of function                            |
| <b>parameter1...parameterN</b> | parameter passed to the call function       |

**Description**

Multiple selection with jump to **label**, call to **subprogramname** or **functionname** according to the **value** of the **varname** variable.  
 Each CASE (optional) can have only one GOTO, CALL or FCALL instruction.  
 At least one case must be included between SELECT and ENDSELECT. The latter indicates the end of the SELECT instruction.  
 After each CALL or FCALL the execution of the function continues with the instruction following ENDSELECT.  
 The CASE-ELSE branch is executed if no previous CASE is satisfied.

**Example**

Axis movement server

**TESTIPC**

**Syntax**

|                |   |
|----------------|---|
| <b>TESTIPC</b> | <b>IPCname, [, varname1 [, varnameN, ...]], GOTO label</b>          |
| <b>TESTIPC</b> | <b>IPCname, [, varname1 [, varnameN, ...]], CALL subprogramname</b> |
| <b>TESTIPC</b> | <b>IPCname, [, varname1 [, varnameN, ...]], functionname</b>        |
| <b>TESTIPC</b> | <b>IPCname, matrix[row], GOTO label</b>                             |
| <b>TESTIPC</b> | <b>IPCname, matrix[row], CALL subprogramname</b>                    |
| <b>TESTIPC</b> | <b>IPCname, matrix[row], functionname</b>                           |
| <b>TESTIPC</b> | <b>IPCname, vector, GOTO label</b>                                  |
| <b>TESTIPC</b> | <b>IPCname, vector, CALL subprogramname</b>                         |
| <b>TESTIPC</b> | <b>IPCname, vector, functionname</b>                                |

**Arguments**

|                              |  |
|------------------------------|--|
| <b>IPCname</b>               | string constant. Name of IPC                       |
| <b>varname1[...varnameN]</b> | constant or variable. Names ranging from 1÷N       |
| <b>matrix[row]</b>           | constant or integer variable. Row number of matrix |
| <b>vector</b>                | name of vector                                     |
| <b>matrix</b>                | name of matrix                                     |
| <b>label</b>                 | name of label to jump to                           |
| <b>subprogramname</b>        | name of subprogram                                 |
| <b>functionname</b>          | name of function                                   |

**Description**

It tests and receives IPC commands.  
 When the TESTIPC instruction is executed for the first time the shared memory is allocated; the memory's dimension is calculated on the basis of the size of sent data. The maximum shared memory dimension is 64 Kb.  
 A semaphore is connected to the memory to allow the synchronisation of the tasks accessing it. The task accessing it checks if an active semaphore is present, it reads the data of the shared memory and disables the semaphore. Immediately after, a jump to label instruction, or the function or the program described as last parameter of the TESTIPC instruction, is executed.  
 See also SENDIPC and WAITIPC.

**TESTMAIL**

**Syntax**

|                 |  |
|-----------------|--|
| <b>TESTMAIL</b> | <b>mail, [varname1 [,...varnameN]], GOTO label</b> |
| <b>TESTMAIL</b> | <b>mail, [varname1 [,...varnameN]], CALL label</b> |

|                 |   |
|-----------------|---|
| <b>TESTMAIL</b> | <b>mail, [varname1 [,..varnameN]], functionname</b> |
| <b>TESTMAIL</b> | <b>mail, matrix[row], GOTO label</b>                |
| <b>TESTMAIL</b> | <b>mail, matrix[row], CALL subprogramname</b>       |
| <b>TESTMAIL</b> | <b>mail, matrix[row], functionname</b>              |

**Arguments**

|                              |   |
|------------------------------|---|
| <b>mail</b>                  | constant or integer variable (1÷256). Number of mailbox |
| <b>varname1[...varnameN]</b> | integer variable. Names ranging from 1÷20               |
| <b>matrix[row]</b>           | constant or integer variable. Row number of matrix      |
| <b>label</b>                 | name of label to jump to                                |
| <b>subprogramname</b>        | name of subprogram                                      |
| <b>functionname</b>          | name of function  |

**Description**

It tests and receives messages.

The first TESTMAIL in the **mail** mailbox creates the mailbox.

If the message is in the **mail** mailbox, the data sent with the message is saved either in the **varname** variables (1÷20), if they are indicated, or in the row of the matrix indicated by **matrix[row]**; moreover it jumps to **label** or calls **subprogramname** or **functionname**.

During execution, congruence between passed data and expected date is verified.

See also instructions SENDMAIL, WAITMAIL and ENDMAIL.

**9.2.13 Various****CLEARERRORS****Syntax**

**CLEARERRORS**                      **[IDposiz]**

**Arguments**

**IDposiz**                                      constant or variable. A numeric value used by synoptics

**Description**

It tells the supervisor PC to delete all the cycle errors concerning the module which is executing the instruction, previously sent by the ERROR instruction. The **IDposiz** parameter is an optional parameter that specifies the numeric value used in synoptics to sort cycle errors in different cells. It must match the value specified in the synoptic creator for that specific display cell. Albatros uses this identifier to manage cycle errors in separate queues. A new queue is created for each IDposiz. The range of the values that can be set is included between 0 (NOPLACE) and 1023. If the **IDposiz** parameter is not specified, all the cycle errors both in the default queue and in the possible other queues are deleted.

See also instructions ERROR and DELERROR

**CLEARMESSAGES****Syntax**

**CLEARMESSAGES**                      **[IDposiz]**

**Arguments**

**IDposiz**                                      constant or variable. A numeric value used by synoptics

**Description**

It tells the supervisor PC to delete all the messages concerning the module which is executing the instruction, previously sent by the MESSAGE instruction. The **IDposiz** parameter is an optional parameter that specifies the numeric value used in synoptics to sort messages in different cells. It must match the value specified in the synoptic creator for that specific display cell. Albatros uses this identifier to manage messages in separate queues. A new queue is created for each IDposiz. The range of the values that can be set is included between 0 (NOPLACE) and 1023. If the **IDposiz** parameter is not specified, all the messages both in the default queue and in the possible other queues are deleted.

See also instructions MESSAGE and DELMESSAGE.

## DEFMSG

### Syntax

```
DEFMSG      label [, languageprefix1], "messagestring"
            , ... ,
            [, languageprefixN, "messagestring"]
```

### Arguments

|                       |  |
|-----------------------|--|
| <b>label</b>          | mnemonic name of message to be displayed   |
| <b>languageprefix</b> | predefined constant. Language in which the message is written<br>Allowed values are:<br><b>ITA</b> Italian<br><b>ENG</b> English<br><b>FRA</b> French<br><b>ESP</b> Spanish<br><b>DEU</b> German |
| <b>messagestring</b>  | message to be displayed. It must be written in inverted commas ("")  |

### Description

It assigns a **label** to a message. The DEFMSG instruction must be declared before implementing the functions. The definition of the message can only be used inside the file (or group) in which it is declared. It is possible to insert messages in various languages by using the predefined constant **languageprefix**. In this case the MESSAGE instruction will display the message in the language currently used by Albatros. A message that no prefix is associated with is used when the language currently in use does not match any of the existing prefixes. A maximum of six messages can be defined per label: five with language prefix plus one with no language prefix. All the labels of different languages can be written on the same line or on more lines, beginning a new paragraph each time by pressing the character "-" preceded by one space. DEFMSG instruction can be passed as parameter to a function. In this way the function that receives it can use it as one of the three arguments of ERROR or MESSAGE. (See example 2). See also instructions MESSAGE, DELMESSAGE, ERROR, DELERROR.

### Example 1

```
;assigning a message string to a label without language selection
DEFMSG      MSG_GRU_1  "Message group 1"

;using the definition
MESSAGE     MSG_GRU_1          ;display: "Message group 1"

;assigning a message string to a label with language selection
DEFMSG      MSG_GRU_1  ITA "Messaggio gruppo 1"
            ENG "Message group 1"

;using the definition when Albatros is set on ENG
MESSAGE     MSG_GRU_1          ;display: "Message group 1"
```

### Example 2:

```
Into a group:
DEFMSG      MSG_TEST  "Execution error"

FUNCTION    ChiamaTest
            Test MSG_TEST
FRET

Into a library:
DEFMSG      MSG_BASE  "Error signal: $1"
...
FUNCTION    Test Public
            PARAM      codice AS integer
            ERROR      MSG_BASE NOPLACE NOSTORE codice
FRET
Visualized cycle error is: Error signal: Execution error
```

**DELAY****Syntax****DELAY** **value****Arguments****value** constant or variable. Delay expressed in seconds.**Description**

It waits as long as indicated in **value**. When time is up, the following instruction is executed. The programmable minimum value is 4 msec. (0,004 seconds)

**DELERROR****Syntax****DELERROR** **devicename** [,state [, **IDposiz** [**STORE**]]  
**DELERROR** **number** [, **IDposiz** [**STORE**]]**Arguments**

**devicename** devicename  
**number** DEFMSG or constant or variable  
**IDposiz** constant or variable. A numeric value used in synoptics  
**state** predefined constant  
 Possible values are:  
**ON**  
**OFF**  
**STORE** predefined numeric constant which, if enabled, allows you to save the cycle error in the current month's error report file

**Description**

It tells the supervisor PC to supervise the deletion of a cycle error previously sent by the ERROR instruction.

If the name of a device is specified, instead of the number, it sends the PC the type and logic address of the device. For the clearance to be effective, all the values set in the parameters must coincide with those used to generate the error. The STORE parameter, however, behaves anomalously. Errors saved on the report file are not eliminated from the file, but only from the error window, while a new registration of the error deletion is added to the file (the size of the file increases!).

Parameter **IDposiz** is an optional parameter, specifying the numeric value used in the synoptics to sort out cycle errors in different cells. It must match the specified value in the synoptics creator for that particular display cell. If there is no need to point out a specific cell, the predefined NOPLACE constant must be assigned. The range of the values that can be set is included between 0 (NOPLACE) and 1023.

If cycle errors are managed like warning signals, all cancel requests are sent. If alarms are managed like statuses, cycle error cancelling is only sent if cycle error is active, otherwise DELERROR instruction is ignored. See also instructions ERROR, CLEARERRORS.

**DELMESSAGE****Syntax****DELMESSAGE** **number** [, **IDposiz**]**Arguments**

**number** DEFMSG or constant or variable  
**IDposiz** constant or variable. Numeric value used in synoptics

**Description**

It sends to the PC a request to delete a message previously sent with a MESSAGE instruction. If messages are managed like warning signals, all corresponding messages are cancelled. If messages are managed like statuses, message cancelling is only sent if its status was active, otherwise DELMESSAGE instruction is ignored.

Parameter **IDposiz** is an optional parameter, specifying the numeric value used in the synoptics to sort out cycle errors in different cells. It must match the specified value in the synoptics creator for that particular display cell. If there is no need to point out a specific cell, the predefined NOPLACE constant must be assigned. The range of the values that can be set is included between 0 (NOPLACE) and 1023.

See also instruction MESSAGE.

## ERROR

### Syntax

```
ERROR devicename [,state [, IDposiz [, log]]]
ERROR number [, IDposiz [, log [, arg1, ..., arg3]]]
```

### Arguments

|                        |   |
|------------------------|---|
| <b>devicename</b>      | name of device  |
| <b>number</b>          | DEFMSG or constant or variable  |
| <b>IDposiz</b>         | constant or variable. A numeric value used in synoptics.  |
| <b>state</b>           | predefined constant<br>Possible values are:<br><b>ON</b><br><b>OFF</b>  |
| <b>log</b>             | predefined numeric constant<br>Possible values are:<br><b>STORE</b> error saved to file<br><b>NOSTORE</b> error not saved to file |
| <b>arg1, ..., arg3</b> | constant or device or variable.   |

### Description

It generates a cycle error. The error is identified by the **number** parameter or by the name of the device. The parameter **number** can identify a module cycle error (i.e. a whole number) or group cycle error (in this case, DEFMSG applies).

If the name of a device is specified, instead of the number, it sends the PC the type and logic address of the device. The cycle error is sent to the supervisor PC and displayed on the Albatros error bar.

The **IDposiz** parameter is used in synoptic views to sort cycle errors in different cells. It must match the value specified in the synoptic creator for that specific display cell. Albatros uses this identifier to manage cycle errors in separate queues. A new queue is created for each IDposiz. If the IDposiz parameter is not specified or when the predefined constant NOPLACE is used, the cycle error is located in the default queue with the value IDposiz=0. The range of the values that can be set is included between 0 (NOPLACE) and 1023.

Setting **log** parameter to **STORE** causes the cycle error to be saved in the error report file of the current month. A high number of generated or cleared errors may put the performance level of the remote modules at risks. In fact, the PC supervisor must control all the errors sent (and they possible clearance). This may slow down the sending of important data to the control, particularly the processing programs.

The optional **arg1, ..., arg3** parameters are used to define parameter error messages. The error message's definition string will feature markers that will be replaced - when the error is generated - with the value or name of the device or variable passed as a parameter. Markers to be inserted in the string are as follows:

- \$1, ... \$2 replaced with the **name** of the device or variable (\$1 stands for arg1 etc.)
- \$(1), ..., \$(3) replaced with the **value** of the device or variable.

Types of data valid for the arg1, ..., arg3 parameters are as follows:

- CHAR
- INTEGER
- FLOAT
- DOUBLE (though it is automatically converted into FLOAT)
- message number (or DEFMSG label)
- device
- global or local variable
- function parameter. It can be used as function parameter the label defined by the DEFMSG instruction.

Strings, matrices and vectors cannot be used as parameters (although individual vector or matrix elements are valid). For local variables, only the value can be decoded, not the name.

For the purpose of deleting a message with the DELERROR instruction, the arg1, ...arg3 parameters are disregarded.

Two error management modes are defined and established by manufacturer of the machine:

**Alarms managed like warning signals:** all cycle errors are sent. Albatros keeps a queue of the last 10 errors of the specified queue and the last 100 errors of the default queue.

**Alarms managed like statuses:** error is considered active or inactive. If active, any further

sending of the same cycle error (by ERROR instruction) is ignored.  
See also instructions DELERROR, CLEARERRORScannot be used.

**Example 1**

```
DEFMSG ERR_TOOL "Tool missing"
DEFMSG ERR_TOOL_P "Load tool $(1) in slot $(2)"

; tag for synoptic views
CONST TOOLCHANGE = 5

; error shown in the Errors Bar or in not tagged sinoptic views' cells
ERROR ERR_TOOL

; error saved in report file and shown in synoptic views' cells tagged
; with code 5
ERROR ERR_TOOL, TOOLCHANGE, STORE

; error saved in report file but not dispatched to tagged synoptic
; views'cell
ERROR ERR_TOOL, NOPLACE, STORE

; error with parameters
ERROR ERR_TOOL_P, NOPLACE, NOSTORE, MxTools[3].Cod, 5
```

**Example 2**

```
; defined in a group
DEFMSG MSG_ERR_CARICO "Error on loading tool"

Function ShowError
    MsgTool MSG_ERR_CARICO MxUtensili[3].Cod
fret

; defined in a library
DEFMSG MSG_ERR_TOOL "Error tool: $1 $(2)"

Function MsgTool public
    PARAM parameter1 as integer
    PARAM parameter2 as integer

    MESSAGE MSG_ERR_TOOL NOPLACE parameter1 parameter2
fret
```

**IFDEF/ELSEDEF/ENDDF****Syntax**

```
IFDEF          constant
    instruction
    ...
ENDDF

IFDEF          constant, comparison operator, value
    instruction
    ...
ENDDF

IFDEF          EXIST, namegroup
    instruction
    ...
ENDDF
```

```

IFDEF          LINKED, devicename
    instruction
    ...
ENDDDEF

IFDEF          UNLINKED, devicename
    instruction
    ...
ENDDDEF

IFDEF          constant, comparison operator, value
    instruction
    ...
ELSEDEF
    instruction
    ...
ENDDDEF

```

**Arguments**

|                            |   |
|----------------------------|---|
| <b>constant</b>            | integer, char, double, string constant  |
| <b>varname</b>             | integer, char, double or string constant  |
| <b>comparison operator</b> | the symbols used for comparison are:<br>< (smaller) = (equal)<br>> (greater) =< (minor or equal )<br>>= (greater or equal) <> (different) |
| <b>value</b>               | constant or name of device  |
| <b>namegroup</b>           | name constant or name of group  |
| <b>devicename</b>          | string constant or device name  |

**Description**

The conditional compilation allows you to check which parts of a GPL function file must be compiled and executed. The compiler verifies that the condition requested as argument of the IFDEF instruction is satisfied. In this case it compiles the code included between the IFDEF instruction and the ENDDDEF or ELSEDEF instruction. If an ELSEDEF instruction exists, and the condition is not satisfied, it will compile the code included between the ELSEDEF instruction and the ENDDDEF instruction.

The compilation condition can be expressed in some different ways:

- a constant is specified after the IFDEF instruction. In this case the condition is satisfied if a global constant or a constant of the existing group with the specified name exists.
- A relation between two operators and an operand is specified after the IFDEF instruction. The first operand must be a constant. In this case the condition is satisfied if the relation is true (for ex. MAX\_TOOLS = 100).
- The keywords EXIST or NOTEXIST, followed by the name of a machine group or by a string containing the name of a machine group or the name of a library, are specified after the IFDEF instruction. In this case the condition is satisfied if a group with the same name exists or doesn't exist in the Machine Configuration.
- After the IFDEF instruction LINKED or UNLINKED key word followed by the name of a device is specified. In this case the condition is verified, if the device is connected (LINKED) or not connected (UNLINKED) in virtual-physical. The device name can be expressed under this form: Group\_Name.Subgroup\_Name.Device\_Name or Group\_Name.Device\_Name or Subgroup\_Name\_DeviceName or Device\_Name. If the device does not exist in the configuration a compilation error appears.

It is possible to set more IFDEF instructions, remembering that each IFDEF instruction must correspond to an ENDEF instruction.

**Example 1**

```

; GPL code execution changes if the FRESA group is present in
; the machine
Const FresaGroup = "Fresa"
IFDEF Exist FresaGroup
    instruction
    instruction
ELSEDEF
    instruction
    instruction
ENDDDEF

```

**Example 2**

```
; GPL code execution changes according to the module
IFDEF _ID_MODULE = 1 ; compile instruction for module 1
instruction
instruction
ELSEDEF ; compile instruction for the other modules
instruction
instruction
ENDEF

; compile code for the 2.4.10 version of Albatros
IFDEF _VER_MAJOR = 2
IFDEF _VER_MINOR = 4
IFDEF _VER_REVISION = 10
instruction
instruction
ENDEF
ENDEF
ENDEF

; compile code for the service pack 10 version of Albatros
IFDEF _VER_SP = "Service Pack 10"
instruction
ENDEF

; compile code only if the system is configured for a Clipper
module
IFDEF _REMOTE_MODULE = 1 ; 1 = Clipper, otherwise 0
instruction
ENDEF

; compile code for the 2.4 version service pack 10 Albatros
IFDEF _VER_FULL = $0002040AH
instruction
ENDEF
```

**Example 3**

```
; the execution of the GPL code changes
; if the device is connected in virtual-physical
IFDEF LINKED out1 ; if out1 is connected, the code is executed
instruction
instruction
instruction
ENDIF
```

**MESSAGE****Syntax**

**MESSAGE**      **number** [, **IDposiz** [, **arg1**, ..., **arg3**]]

**Arguments**

**number**            constant or variable  
**IDposiz**           constant or variable. Numeric value used in synoptics.  
**arg1, ..., arg3**    constant or device or variable.

**Description**

It generates a message for the operator.  
It generates a message for the operator. The parameter **number** can identify a module cycle error (i.e. a whole number) or group cycle error (in this case, DEFMSG applies). An argument, indicated by **IDposiz**, can also be passed if required. It indicates in which synoptic window the message should be displayed. It must correspond to the value specified in the synoptic creator for that specific



display cell. Albatros uses this identifier to handle messages in separate queues. A new queue is created for each IDposiz. If the IDposiz parameter is not specified, the message is set in the default queue with the value IDposiz=0. The range of the values that can be set is included between 0 (NOPLACE) and 1023. Albatros keeps a queue of the last 10 messages of the specified queue and of the last 100 messages of the default queue. When the messages queue is full, the latest message is overwritten. If the previous message of the queue is the same as the one that is going to be sent, the message is not sent (same task, same number, same argument).

The optional **arg1, ..., arg3** parameters are used to define parameter messages. The message's definition string will feature markers that will be replaced - when the message is generated - with the value or name of the device or variable passed as a parameter. Markers to be inserted in the string are as follows:

- \$1, ... \$2 replaced with the **name** of the device or variable (\$1 stands for arg1 etc.)
- \$(1), ..., \$(3) replaced with the **value** of the device or variable.

Types of data valid for the arg1, ..., arg3 parameters are as follows:

- CHAR
- INTEGER
- FLOAT
- DOUBLE (though it is automatically converted into FLOAT)
- message number (or DEFMSG label)
- device
- global or local variable
- function parameter. It can be used as function parameter the label defined by the DEFMSG instruction.

Two error management modes are defined and established by manufacturer of the machine:

**Messages managed like warning signals:** all messages are sent. Albatros keeps a queue of the last 10 messages of the specified queue and the last 100 errors of the default queue. When the message queue is full it overwrites the oldest message. If the previous message is identical to the one to be sent, the message is not sent (same task, same number, same argument).

**Messages managed like statuses:** message is considered active or inactive. If active, any further sending of the same message (by MESSAGE instruction) is ignored..

Strings, matrices and vectors cannot be used as parameters (although individual vector or matrix elements are valid). For local variables, only the value can be decoded, not the name.

For the purpose of deleting a message with the DELMESSAGE instruction, the arg1, ...arg3 parameters are disregarded.

See also instructions DELMESSAGE and CLEARMESSAGES.

**Example 1**

```
DEFMSG MSG_TOOL "Change the tool"
DEFMSG MSG_TOOL_P "Tool number $(1) loaded"

; tag for synoptic views
CONST TOOLCHANGE = 7

; message shown in the Errors Bar or in not tagged sinoptic views' cells
MESSAGE MSG_TOOL

; message shown in the Errors Bar and in sinoptic views' cells
; tagged with code 7
MESSAGE MSG_TOOL, TOOLCHANGE

; message with parameters
MESSAGE MSG_TOOL_P, NOPLACE, MxTools[3].Cod
```

**Example 2**

```
; defined in a group
DEFMSG MSG_CARICO "loading"
```

```
Function ShowMessage
    MsgTool MSG_CARICO MxUtensili[3].Cod
fret

; defined in a library
DEFMSG MSG_TOOL "Tool: $(1) $2"

Function MsgTool public
PARAM parameter1 as integer
PARAM parameter2 as integer

    MESSAGE MSG_TOOL NOPLACE parameter1 parameter2
fret
```

## SYSFAULT

### Syntax

**SYSFAULT**

### Arguments

no arguments

### Description

It disables the SYSOK signal.

This signal is disabled to indicate that the machine is not secured (for ex. the GPL that manage emergencies are not in execution).

See also instruction SYSOK.

## SYSOK

### Syntax

**SYSOK** [nameoutput1 [, ... nameoutput8]]

### Arguments

**nameoutput1** [...nameoutput8] name of digital output device

### Description

Indicates to the numerical control which are the outputs are connected to the safety circuits of the machine (it can be an output connected to a safety relay, which controls the power supply of the machine). The outputs are activated when the numeric control has completed machine booting and has activated all emergency management tasks. At this stage the machine can be considered safe. Up to a total of 8 digital outputs can be defined. On each remote one output can be enabled. Only the outputs available on the CN2004 can be enabled and not those available on the remotes connected to it. The list of the outputs declared in the first use of SYSOK instruction cannot be changed during the possible next sysok calls, until the control has been initialized. If the instruction is executed without parameters, the signal of SYSOK is restored.  
See also instruction SYSFAULT.

## TYPEOF

### Syntax

**TYPEOF** name, result

### Arguments

**name** name of device, constant, functionname, variable, vector, matrix or matrix row

**result** integer variable. Type of the first argument

### Description

It returns the **name** type argument to the **result** variable.

## WATCHDOG

### Syntax

**WATCHDOG** **status**

### Arguments

**status** predefined constant. Acceptable values are: **ON**, **OFF**

### Description

This instruction enables the use of the watchdog connected to the TMSWD-Hardware. It allows you to identify error situations occurring while executing the GPL code.

To enable the use of Watchdog, assign **ON** to the parameter **status**.

To upgrade the counter of the board, assign **ON** to the parameter **status**. If you do not upgrade, the watchdog starts and the TMSWD deactivates the emergency exit of the machine.

To finish the use of Watchdog, assign **OFF** to the parameter **status**.

This instruction can only be used with TMSbus+, TMSCan+ and TMSCombo+ boards with FPGA 2.0 or higher and mounted TMSWD hardware module.

### Example

Function TestWatchDog autorun

```
watchdog ON ; enables the watchdog management
```

Loop:

```
watchdog ON ; upgrades the counter of the board
```

```
goto loop
```

```
fret
```

## 9.2.14 CANopen

### TMSbus boards with CAN control

#### GETCNSTATE

##### Syntax

**GETCNSTATE** **board, node, status**

##### Arguments

**board** constant or variable integer. Board number  
**node** constant or variable integer. Number of the node  
**status** constant or variable integer.

##### Description

It returns the status of the NMT protocol for the **node** of the **board** CANOpen as shown. For further information about the meaning of these parameters, make reference directly the documentation concerning each single CANopen device.

#### GETSDOERROR

##### Syntax

**GETSDOERROR** **board, error**

##### Arguments

**board** constant or variable integer. Board number (from 1 to 4)  
**Error** variable integer. Error code

##### Description

It returns the last **error** occurred, referred to the SDO communication for the **board** CANOpen as shown. For further information about the meaning of these parameters, make reference directly the documentation concerning each single CANopen device.

## GETMNSTATE

### Syntax

**GETMNSTATE**                      **board, status**

### Arguments

**board**                                constant or variable integer. Board number (from 1 to 4)  
**status**                                constant or variable integer.

### Description

It returns the status of the NMT protocol for the master node of the CANOpen **board** as shown. For further information about the meaning of these parameters, make reference directly the documentation concerning each single CANopen device.

## RECEIVEDPDO

### Syntax

**RECEIVEDPDO**                      **board, node, PDOnumber**

### Arguments

**board**                                constant or variable integer. Board number (1 to 4)  
**node**                                 constant or variable integer. Number of the node  
**PDOnumber**                         constant or variable integer. Number of the PDO

### Description

It reads the PDO content specified from **PDO number** for the mentioned node. This instruction is used to read asynchronous PDOs (i.e. those PDOs that in the canbus.def file are shown with "ASYNC" attribute).

The read data are copied in the respective device just as defined in the canbus.def file. (Make reference to the canbus.def file description).

This instruction can only be used with TMSCan and TMSCan+ boards.

### Example

In a CANBUS.DEF file written in this way

```
....  
  
CN(1) RPDO=2ASYNC+2+1ASYNC TPDO=2+1ASYNC ;  
  
...  
  
VAR  
  
...    TPA.Byte1 AS %IB1.1.4 ;  
...  
  
END_VAR
```

To read the content in the third asynchronous PDO, you should enter in the file of the function this line of code:

```
RECEIVEDPDO 1,1,3
```

according to the description in the CANBUS.DEF file the content of the TPA.Byte1 device is copied

## SENDPDO

### Syntax

**SENDPDO**                            **board, node, PDOnumber**

### Arguments

**board**                                constant or variable integer. Number of the card  
**node**                                 constant or variable integer. Number of the node  
**PDOnumber**                         constant or variable integer. PDO number

### Description

It writes the specified PDO content from **PDO number** for the mentioned node. This instruction is used to write asynchronous PDOs (i.e. those PDOs that in the canbus.def file are shown with "ASYNC"

attribute). (Make reference to the canbus.def file description).  
 This instruction can only be used with TMSCan and TMSCan+ boards.

**Example**

```
In a CANBUS.DEF file written in this way
....

CN(1) RPDO=2ASYNC+2+1ASYNC TPDO=2+1ASYNC ;

...

VAR

...
    TPA.Byte1 AS %IB1.1.2 ;
...

END_VAR
```

To send to the node the value contained in the TPA.Byte1 device, you should enter in the file of the function this line of code:  
 SENDPDO 1,1,2

**SETNMTSTATE**

**Syntax**

**SETNMTSTATE**                      **board, node, status**

**Arguments**

**board**                                      constant or variable integer. Board number (from 1 to 4)  
**node**                                        constant or variable integer. Number of the node  
**status**                                      constant or variable integer.

**Description**

It sets the status of the NMT protocol for the **node** of the **board** CANOpen shown. If the value of the node is equal to 0 (zero) or higher than 126, setting is applied to all the existing and configured nodes on CANOpen channel. For further information about the meaning of these parameters, make reference directly the documentation concerning each single CANopen device.

| Value | Protocol status |
|-------|-----------------|
| 1     | Operational     |
| 128   | Pre-Operational |

**Board CIF30**

**CANOPENDRIVER**

**Syntax**

**CANOPENDRIVER**                      **card, reserved, [error]**

**Arguments**

**card**                                        constant or variable. Number of the card  
**reserved**                                    constant or variable. Reserved  
**[error]**                                      variable. Error code

**Description**

It opens the communication channel between GPL and the CANopen Card. The second parameter is reserved for future use. The optional **error** parameter contains the codes of errors that could be generated during functioning; if it is not specified, in case of error, a system error occurs. See also CANCLOSEDRIVER.

**CANCLOSEDRIVER****Syntax****CANCLOSEDRIVER**            **card, [error]****Arguments****card**                            constant or variable. Number of the card  
**[error]**                            variable. Error code**Description**

It closes the communication channel between GPL and the CANopen Card. If the channel hadn't been opened it generates an error. The optional **error** parameter contains the codes of errors that could be generated during functioning; if it is not specified, in case of error, a system error occurs. See also CANOPENDRIVER

**CANRESETBOARD****Syntax****CANRESETBOARD**            **card, [error]****Arguments****card**                            constant or variable. Number of the card  
**[error]**                            variable. Error code**Description**

It executes the reset of the indicated CANopen Card. The optional **error** parameter, if specified, contains the codes of errors that could be generated during functioning; if it is not specified, in case of error, a system error is generated.

**CANSETOBJECT****Syntax****CANSETOBJECT**            **card, node, index, subindex, data, length, [error]****Arguments****card**                            constant or variable. Number of the card  
**node**                            constant or variable. Number of the node  
**index**                            constant or variable. Index of objects folder  
**subindex**                        constant or variable. Subindex of objects folder  
**data**                            constant or variable. Data to be written  
**length**                         constant or variable. Length of data in bytes  
**[error]**                            variable. Error code**Description**

It writes a CANopen object on the indicated **card**. The parameters **node**, **index** and **subindex** allow you to address the CANopen device and the location on which the CANopen object must be written. For further information about the meaning of these parameters, as well as the type and dimension of the data, consult directly the documentation concerning each single CANopen device. The optional **error** parameter, if specified, contains the codes of the errors that could be generated during functioning; if it is not specified, in case of error a system error is generated. See also CANGETOBJECT.

**CANGETOBJECT****Syntax****CANGETOBJECT**            **card, node, index, subindex, data, length, [error]****Arguments****card**                            constant or variable. Number of the card  
**node**                            constant or variable. Number of the node  
**index**                            constant or variable. Index of objects folder  
**subindex**                        constant or variable. Subindex of objects folder  
**data**                            variable. Data to be read  
**length**                         constant or variable. Length of data in bytes  
**[error]**                            variable. Error code

**Description**

It reads a CANopen object from the indicated **card**. The parameters **node**, **index** and **subindex** allow you to address the CANopen device and the location from which the CANopen object must be read. For further information about the meaning of these parameters, as well as the type and dimension of the data, consult directly the documentation concerning each single CANopen device. The optional **error** parameter, if specified, contains the codes of the errors that could be generated during functioning; if it is not specified, in case of error a system error is generated. See also CANSETOBJECT.

## 9.2.15 Mechatrolink II

### MECCOMMAND

**Syntax**

**MECCOMMAND**                      **axis,command,parameters,reply,error**

**Arguments**

|                   |                              |
|-------------------|------------------------------|
| <b>axis</b>       | name of digital axis device  |
| <b>command</b>    | integer constant.            |
| <b>parameters</b> | integer array.               |
| <b>reply</b>      | integer array                |
| <b>error</b>      | integer variable. Error code |

**Description**

It sends to indicated **axis** activation a **command** and waits for the reply. Necessary data for the execution of the command are inserted into **parameters** vector, while returned data from the execution of the instruction are stored into the **reply** vector. **Parameter** and **reply** vector must have the same size and the maximum number of elements must be 14. The consider value is the lowest byte of single integer. The **error** parameter contains the codes of eventual errors generated during the operation.

The error codes should be handled by Gpl as cycle errors.

The returned error codes are:

| <b>Error Codes</b> | <b>Message</b>   |
|--------------------|--|
| -40                | Command not allowed in the current functioning conditions          |
| -41                | Timeout error during the execution of a Mechatrolink II command    |
| -44                | Timeout error during the execution of a Mechatrolink II subcommand |
| -45                | Link error of the drive  |

For the values that must be assigned to parameters **command**, **parameters**, **reply** and **error** see Yaskawa Mechatrolink II official documentation, where the values to be allocated to the command are described in the index 2 up to the index 15. The values to be set to the subcommands are described in the index 18 up to the index 32.

Commands can be distinguished in the following way:

- command. They have code includes between 0x00 and 0xFF. Because of safety reasons they are executed only if servo axis is enabled.
- subcommand. The commands used as subcommands must add to documented value the code 0x100. For example the command NOP has documented code 0x00, used as subcommand is 0x100.
- procedure. The commands used as procedures have command with value starting from 0x200. Currently those procedures are contemplated:
  - \$201H habilitation procedure for offline parameters (to use with disenabled axis)

This instruction can only be used with Albmech, Dualmech and Dualmech Mono boards. For further information about the use of this instruction contact T.P.A. S.p.A

**Note**

**This instruction acts on the actions of digital axes and it should be used in controlled context.**

### MECGETPARAM

**Syntax**

**MECGETPARAM**                      **axis,parameter,dimension,data,error**

**Arguments**

|                  |                               |
|------------------|-------------------------------|
| <b>axis</b>      | name of digital axis device   |
| <b>parameter</b> | constant or integer variable. |
| <b>dimension</b> | constant or integer variable. |
| <b>data</b>      | integer variable.             |
| <b>error</b>     | integer variable. Error code  |

**Description**

It reads a parameter of the activation of indicated **axis** and it stores the parameter into **data** variable. The **error** parameter contains the codes of the possible errors generated during the operation. The error codes should be handled by Gpl as cycle errors.

The returned error codes are:

| <b>Error Codes</b> | <b>Message</b>   |
|--------------------|--|
| -40                | Command not allowed in the current functioning conditions          |
| -41                | Timeout error during the execution of a Mechatrolink II command    |
| -44                | Timeout error during the execution of a Mechatrolink II subcommand |
| -45                | Link error of the drive  |

For the values that must be assigned to **parameter** and **dimension** variables see Yaskawa Mechatrolink II official documentation.

This instruction can only be used with Dualmech and Dualmech Mono boards. For further information about the use of this instruction contact T.P.A. S.p.A

**MECGETSTATUS**

**Syntax**

**MECGETSTATUS axis,state,inout,error**

**Arguments**

|              |                               |
|--------------|-------------------------------|
| <b>axis</b>  | name of digital axis device   |
| <b>state</b> | constant or integer variable. |
| <b>inout</b> | constant or integer variable. |
| <b>error</b> | integer variable. Error code  |

**Description**

It reads and stores into **state** variable the value of STATUS and ALARM and into **inout** variable the value of IO\_MON relative to specified **axis**. For the values of STATUS, ALARM, IO\_MON see Yaskawa Mechatrolink II official documentation.

The **error** parameter contains the codes of the possible errors generated during the operation. The error codes should be handled by Gpl as cycle errors.

The returned error codes are:


| <b>Error Code</b> | <b>Message</b>   |
|-------------------|--|
| -40               | Command not allowed in the current functioning conditions          |
| -41               | Timeout error during the execution of a Mechatrolink II command    |
| -44               | Timeout error during the execution of a Mechatrolink II subcommand |
| -45               | Link error of the drive  |

A sequence of error categories is defined. The category that represents the value of the highest nibble of ALARM.

into one of following categories 0x30,0x70,0xD0,0xF0 must be sent a command of CLEAR (0x06).

Alarms that are included into one of following categories 0x00,0x10,0x40,0xB0 can't be deleted with a command. It is necessary to solve the problem that creates the alarm, turn out the servodriver and switch it on again.

The structure of variables **state** and **inout** is a mask of bit structured as in the following representation:





**STATUS**

|           |           |           |           |           |           |           |          |
|-----------|-----------|-----------|-----------|-----------|-----------|-----------|----------|
| <b>8</b>  | <b>7</b>  | <b>6</b>  | <b>5</b>  | <b>4</b>  | <b>3</b>  | <b>2</b>  | <b>1</b> |
| DEN       | ZPOINT    | Reserved  | PON       | SVON      | CMDRDY    | WARNG     | ALM      |
| <b>16</b> | <b>15</b> | <b>14</b> | <b>13</b> | <b>12</b> | <b>11</b> | <b>10</b> | <b>9</b> |
| Reserved  | Reserved  | Reserved  | N-SOT     | P-SOT     | NEAR      | L_CMP     | T_LIM    |

**Meaning of STATUS bits**

| Bit | Command                                    | Physical pins that can be connected in Virtual-Physical |
|-----|--|---|
| 1   | ALM (Alarm)                                | Digital input   |
| 2   | WARNG (Warning)                            | Digital input   |
| 3   | CMDRDY (Command Ready)                     |   |
| 4   | SVON (Servo ON)                            | Digital output  |
| 5   | PON (Main Power ON)                        | Digital input   |
| 6   | Reserved                                   |   |
| 7   | ZPOINT (Zero Point)                        |   |
| 8   | PSET (Position Complete)                   |   |
| 9   | DEN ( Command Distribution Completed Flag) |   |
| 10  | T_LIM (Torque Limit)                       |   |
| 11  | L_CMP (Latch Completed)                    |   |
| 12  | NEAR (Position Proximity)                  |   |
| 13  | P-SOT (Forward-direction Software Limit)   |   |
| 14  | N-SOT (Reverse-direction Software Limit)   |   |
| 15  | Reserved                                   |   |
| 16  | Reserved                                   |   |

**IO\_MON**

|           |           |           |           |           |           |           |          |
|-----------|-----------|-----------|-----------|-----------|-----------|-----------|----------|
| <b>8</b>  | <b>7</b>  | <b>6</b>  | <b>5</b>  | <b>4</b>  | <b>3</b>  | <b>2</b>  | <b>1</b> |
| EXT2      | EXT1      | PC        | PB        | PA        | DEC       | N_OT      | P_OT     |
| <b>16</b> | <b>15</b> | <b>14</b> | <b>13</b> | <b>12</b> | <b>11</b> | <b>10</b> | <b>9</b> |
| IN4       | IN3       | IN2       | IN1       |           |           | BRK       | EXT3     |

**Meaning of IO\_MON bits**

| Bit | Command                         | Physical pins that can be connected in Virtual-Physical |
|-----|---------------------------------|---|
| 1   | P_OT (Forward Over Travel)      |   |
| 2   | N_OT (Reverse Over Travel)      |   |
| 3   | DEC (Deceleration Limit Switch) |   |

|    |                                    |               |
|----|------------------------------------|---------------|
| 4  | PA (Phase A)                       |               |
| 5  | PB (Phase B)                       |               |
| 6  | PC (Phase C)                       | Digital input |
| 7  | EXT1 (First external latch input)  | Digital input |
| 8  | EXT2 (Second external latch input) | Digital input |
| 9  | EXT3 (Third external latch input)  |               |
| 10 | BRK (Brake output)                 |               |
| 11 |                                    |               |
| 12 |                                    |               |
| 13 | IN1 (General-purpose input 1)      |               |
| 14 | IN2 (General-purpose input 2)      |               |
| 15 | IN3 (General-purpose input 3)      |               |
| 16 | IN4 (General-purpose input 4)      |               |

This instruction can only be used with Albmech, Dualmech and Dualmec Mono boards. For further information about the use of this instruction contact T.P.A. S.p.A

## MECSETPARAM

### Syntax

**MECSETPARAM**                      **axis,parameter,dimension,data,error**

### Arguments

|                  |                               |
|------------------|-------------------------------|
| <b>axis</b>      | name of digital axis device   |
| <b>parameter</b> | constant or integer variable. |
| <b>dimension</b> | constant or integer variable. |
| <b>data</b>      | integer variable.             |
| <b>error</b>     | integer variable. Error code  |

### Description

It writes a **data** into the **parameter of indicated axis**.

For the values that must be assigned to **parameter** and **dimension** variables see Yaskawa Mechatrolink II official documentation. The **error** parameter contains the codes of the possible errors generated during the operation. The error codes should be handled by Gpl as cycle errors.

The returned error codes are:

| <b>Error Code</b> | <b>Message</b>   |
|-------------------|--|
| -40               | Command not allowed in the current functioning conditions          |
| -41               | Timeout error during the execution of a Mechatrolink II command    |
| -44               | Timeout error during the execution of a Mechatrolink II subcommand |
| -45               | Link error of the drive  |

This instruction can only be used with Albmech, Dualmech and Dualmec Mono boards. For further information about the use of this instruction contact T.P.A. S.p.A

### Note

**This instruction acts on the actions of digital axes and it should be used in controlled context. To input data into into the non-volatile memory the instruction MECCOMMAND is to be used.**

## 9.2.16 PowerlinkII and EtherCAT

### Instructions to initialize the Powerlink nodes

#### Syntax

**GETCNSTATE**                      **board, node, state**

**GETMNSTATE**                    **board, state**  
**SETNMTSTATE**                **board, node, state**

**Description**

Make reference to the documentation in the chapter TMS boards with CAN control.

**AXCONTROL**

**Syntax**

**AXCONTROL**                    **axis, data**


**Arguments**

**axis**                                device name of axis type  
**data**                                variable or integer constant. it sets the ControlWord

**Description**


It sets the ControlWord **data**, in conformity with the functioning operativity, according to "CiA 402 CANopen device profile".

**PowerLink and EtherCAT value definition table**



| Bit | Meaning                     | Name in virtual-physical |
|-----|-----------------------------|--------------------------|
| 1   | so=Switch ON                | CW1                      |
| 2   | ev=Enable voltage           | EV                       |
| 3   | qs=Quick stop               | STOP                     |
| 4   | eo=Enable operation         | SVON                     |
| 5   | oms=Operation mode specific | CW5                      |
| 6   | oms=Operation mode specific | CW6                      |
| 7   | oms=Operation mode specific | CW7                      |
| 8   | fr=Fault reset              | RESALM                   |
| 9   | h=Halt                      | CW9                      |
| 10  | oms=Operation mode specific | CW10                     |
| 11  | r=Reserved                  | CW11                     |
| 12  | ms=Manufacturer specific    | CW12                     |
| 13  | ms=Manufacturer specific    | CW13                     |
| 14  | ms=Manufacturer specific    | CW14                     |
| 15  | ms=Manufacturer specific    | CW15                     |
| 16  | ms=Manufacturer specific    | CW16                     |

**Table to define the values for S-CAN**



| Bit | Meaning  | Name in virtual-physical |
|-----|--|--------------------------|
| 1   | Ten_cmd=torque enable command<br>1:torque axis<br>0:free axis              | SVON                     |
| 2   | Ien_cmd=movement enable command<br>1:enabled movements<br>0:axis stall     | ENMOVE                   |
| 3   | Stp_cmd=stop command<br>1:active stop command<br>0:non-active command stop | STOP                     |
| 4   | Alm_rst= alarm status<br>1:alarm command reset                             | RESALM                   |
| 5   | Ltc_rst: reset bit 5 of StatusWord   | CW5                      |
| 6   | oms=selected mode specific   | CW6                      |
| 7   | oms=selected mode specific   | CW7                      |
| 8   | oms=selected mode specific   | CW8                      |

**ACTIVATEMODE**

*Syntax*

**ACTIVATEMODE**                      **axis, data, err**

*Arguments*

**axis**                                      device name of axis type  
**data**                                      constant or integer variable. Operating mode  
**err**                                        integer variable. Error code not returned by the servocontrol

*Description*

Sets the operating mode defined in the **data** variable according to "CiA 402 CANopen device profile". The operating mode of the starting axis corresponds to the **data** value = 9, that is "Synchronous speed configuration". The instruction returns **err**= 0 value, if the command succeeded, otherwise it returns an error code.  
 Given below, the table of the values to assign to data to choose the operating mode.

| Value | Definition                |
|-------|---------------------------|
| +6    | Homing mode               |
| +9    | Cyclic sync velocity mode |

**AXSTATUS**

*Syntax*

**AXSTATUS**                                **axis, value**


*Arguments*

**axis**                                      device name of axis type  
**value**                                      integer variable

*Description*


It return the value in the StatusWord in accordance with "CiA 402 CANopen device profile".

**PowerLink II and EtherCAT value definition table**



| Bit | Meaning                       | Name in virtual-physical |
|-----|-------------------------------|--------------------------|
| 1   | rtso=Ready to switch on       | RTSO                     |
| 2   | so=Switched on                | SW2                      |
| 3   | oe=Operation enabled          | OE                       |
| 4   | f=Fault                       | ALM                      |
| 5   | ve=Voltage enable             | VE                       |
| 6   | qs=Quick stop                 | QS                       |
| 7   | sod=Switch on disabled        | SOD                      |
| 8   | w=Warning                     | WARNG                    |
| 9   | ms=Manufacturer specific      | SW9                      |
| 10  | rm=Remote                     | SW10                     |
| 11  | tr=Target reached or reserved | SW11                     |
| 12  | ila=Internal limit active     | SW12                     |
| 13  | oms=Operation mode specific   | SW13                     |
| 14  | oms=Operation mode specific   | SW14                     |
| 15  | ms=Manufacturer specific      | SW15                     |
| 16  | ms=Manufacturer specific      | SW16                     |

**S-CAN value definition table**



| Bit | Meaning   | Name in virtual-physical |
|-----|---|--------------------------|
| 1   | Ten_st=torque enable status<br>1:torque axis<br>0:free axis | SW1                      |
| 2   | Ien_st=movements enable status<br>1:enabled movements       | SW2                      |

|   |   |     |
|---|---|-----|
|   | 0:axis stall  |     |
| 3 | Stp_st=stop status<br>1:running stop ramp<br>0:stop is not activated or ramp finished                             | SW3 |
| 4 | Alm_st=alarm status<br>1:alarmed machine<br>0:no alarm detected   | ALM |
| 5 | Ltc_st=Position latch status<br>1:position latch executed, register ready to read<br>0:no position latch detected | SW5 |
| 6 | oms=operation mode specific   | SW6 |
| 7 | oms=operation mode specific   | SW7 |
| 8 | oms=operation mode specific   | SW8 |

## CNBYDEVICE

### Syntax

**CNBYDEVICE**                      **device, board,cn**

### Arguments

**device**                      device name  
**board**                      integer variable. Board number returned  
**cn**                              integer variable. CN-number returned

### Description

Returns the EPL-coordinates of the device defined in the **device** parameter. This instruction can be used for instructions without direct connections to devices, as, for instance READDICTIONARY and WRITEDICTIONARY, that are directly connected to the EPL network.

### Note

To further information concerning this instruction, see "CiA 402 CANopen device profile".

## GETPDO

### Syntax

**GETPDO**                              **board,node,nPDO,nObj,data,[error]**

### Arguments

**board**                      constant or variable integer. Board number  
**node**                      constant or variable integer. Position held by the slave in the EtherCAT chain (from 1 on)  
**nPDO**                      constant or variable integer. PDO identifier (ex. \$1600h) or position of the same in the list of configured PDO configured in the ECATBIS.DEF file for the node under consideration (from 1 to 8)  
**nObj**                      constant or variable integer. Object identifier (ex. \$6040h) or position of the same within the list of object configured in the PDO (from 1 to 8)  
**data**                      variable integer. It receives the value.  
**Error**                      variable integer. Error code

### Description

It returns in **[data]** the content of an object exchanged through the PDOs configured for the EtherCAT node. If the passed arguments are wrong and if the **error** parameter has not been set, a system error is generated. If an **error** parameter has been set, this will contain the numeric code for the corresponding system error.

## HOMING

### Syntax

**HOMING**                              **axis, data, speed, speed1,offset,err**

### Arguments

**axis**                              device name of axis type

|               |  |
|---------------|--|
| <b>data</b>   | constant or integer variable. Kind of homing                                   |
| <b>speed</b>  | constant or float or double variable. Search speed of the switch               |
| <b>speed1</b> | constant or float or double variable. Search speed of zero                     |
| <b>offset</b> | constant or float or double variable. Zero - offset beside the homing position |
| <b>err</b>    | integer variable. Error code returned by the servocontrol                      |

**Description**

This instruction can be used in Powerlink II configuration only. It runs the "zero search" according to the DS402 specifications. To know if the kind of **data** homing is supported by the servodrive, it is necessary to make reference to the producer's specifications. At the end of the homing operations, CN is placed into the previous operating mode.

**Note**

To further information concerning this instruction, see "CiA 402 CANopen device profile".

**READDICTIONARY**

**Syntax**

**READDICTIONARY board,cn,index,subindex,dimdata,data,err**

**Arguments**

|                 |  |
|-----------------|--|
| <b>board</b>    | constant or integer variable. Board number                               |
| <b>cn</b>       | constant or integer variable. CN number                                  |
| <b>index</b>    | constant or integer variable. Object's index in the dictionary           |
| <b>subindex</b> | constant or integer variable. Object's subindex in the dictionary        |
| <b>dimdata</b>  | integer variable. Dimension of the read data                             |
| <b>data</b>     | char variable, integer, float,double,string. Variable receiving the data |
| <b>err</b>      | integer variable. Error code returned by CN                              |

**Description**

It reads the content of an objects' dictionary object, contained in CN. The instruction enables to read by means of the SDO protocol all the objects defined in accordance with "CiA 402 CANopen device profile" beside all the other objects made available by the manufacturer. To know the meaning of the **index**, **subindex** and **dimdata** parameter, reference is made to "CiA 402 CANopen device profile" or to the specifications of the CN manufacturer. For the S-CAN devices the sub-index parameter must always be set to zero.

**SETPDO**

**Syntax**

**SETPDO board,node,nPDO,nObj,data,[error]**

**Arguments**

|              |  |
|--------------|--|
| <b>board</b> | constant or variable integer. Board number)  |
| <b>node</b>  | constant or variable integer. Position held by the slave in the EtherCAT chain (from 1 on)   |
| <b>nPDO</b>  | constant or variable integer. PDO identifier (ex, \$1600h) or position of the same in the list of configured PDO configured in the ECATBIS.DEF file for the node under consideration (from 1 to 8) |
| <b>nObj</b>  | constant or variable integer. Object identifier (ex. \$6040h) or position of the same within the list of object configured in the PDO (from 1 to 8)  |
| <b>data</b>  | variable integer . Set value   |
| <b>Error</b> | variable integer . Error code  |

**Description**

It sets the content [**data**] of an object exchanged through the PDOs configured for the EtherCAT node. If the passed arguments are wrong and if the **error**, parameter has not been set, a system error is generated. If an error parameter has been set, this will contain the numeric code for the corresponding system error.

## WRITEDICTIONARY

### Syntax

**WRITEDICTIONARY**      **board,cn,index,subindex,dimdata,data,err**

### Arguments

|                 |  |
|-----------------|--|
| <b>board</b>    | constant or integer variable. Board number                               |
| <b>cn</b>       | constant or integer variable. CN number                                  |
| <b>index</b>    | constant or integer variable. Object's index in the dictionary           |
| <b>subindex</b> | constant or integer variable. Object's subindex in the dictionary        |
| <b>dimdata</b>  | constant or integer variable. Dimension of the data to write             |
| <b>data</b>     | char variable, integer,float,double,string. Variable containing the data |
| <b>err</b>      | integer variable. Error code returned by CN                              |

### Description

It writes the content of an objects' dictionary object, contained in CN. The instruction enables to read by means of the SDO protocol all the objects defined in accordance with "CiA 402 CANopen device profile" beside all the other objects made available by the manufacturer. To know the meaning of the **index**, **subindex** and **dimdata** parameter, reference is made to "CiA 402 CANopen device profile" or to the specifications of the CN manufacturer. For the S-CAN devices the sub-index parameter must always be set to zero.

## 9.2.17 SLM

### SLMCOMMAND

#### Syntax

**SLMCommand**      **axis, command [,error]**

#### Arguments

|                |   |
|----------------|---|
| <b>axis</b>    | name of digital axis device   |
| <b>command</b> | integer variable. Code of command to be executed. Possible values range between 0-255 |
| <b>error</b>   | integer variable. Error code  |

#### Description

It executes an SLM command. Any execution errors can be managed by GPL by means of an "Error" optional parameter. If the **error** variable has not been defined, in case of error it generates a system error.

This instruction can be used only with digital axis cards.

For further information about the use of this instruction contact T.P.A. S.p.A.

### SLMEEPROMDISABLE

#### Syntax

**SLMEEPROMDISABLE**      **axis, [,error]**

#### Arguments

|              |                              |
|--------------|------------------------------|
| <b>axis</b>  | name of digital axis device  |
| <b>error</b> | integer variable. Error code |

#### Description

It executes the write disabling command of an EEPROM memory location. It also returns any possible protocol errors that may be managed by GPL by means of the optional **error** parameter. If the **error** variable has not been specified, in case of error it generates a system error. This instruction can be used only with digital axis cards.

For further information about the use of this instruction contact T.P.A. S.p.A.

### SLMEEPROMENABLE

#### Syntax

**SLMEEPROMENABLE**      **axis, [,error]**

#### Arguments

|              |                              |
|--------------|------------------------------|
| <b>axis</b>  | name of digital axis device  |
| <b>error</b> | integer variable. Error code |



**Description**

It executes the write enabling command of an EEPROM memory location. It also returns any possible protocol errors that may be managed by GPL by means of the optional **error** parameter. If the **error** parameter has not been specified, in case of error it generates a system error. This instruction can only be used with digital axis cards.  
 For further information about the use of this instruction contact T.P.A. S.p.A.

**SLMGETEEPROM**

**Syntax**

**SLMGetEEPROM**                      **axis, address, data [,error]**

**Arguments**

**axis**                                      name of digital axis device  
**address**                                  integer variable. Location to be read. Possible values range between 0-128  
**data**                                        integer variable. Data returned from read  
**error**                                        integer variable. Code error

**Description**

It executes the reading of an EEPROM memory location. Any execution errors can be managed by GPL by means of the optional "Error" parameter. If the **error** variable has not been defined, in case of error it generates a system error.  
 This instruction can be used only with digital axis cards.  
 For further information about the use of this instruction contact T.P.A. S.p.A.

**SLMGETPARAM**

**Syntax**

**SLMGetParam**                            **axis, address, data [,error]**

**Arguments**

**axis**                                      name of digital axis device  
**address**                                  integer variable. Location to be read. Possible values range between 0-128  
**data**                                        integer variable. Data returned from read  
**error**                                        integer variable. Code error

**Description**

It executes the reading of an SLM parameter. Any execution errors can be managed by GPL by means of the optional "Error" parameter.  
 This instruction can be used only with digital axis cards.  
 For further information about the use of this instruction contact T.P.A. S.p.A.

**SLMGETREGISTER**

**Syntax**

**SLMGetRegister**                        **axis, register, data [,error]**

**Arguments**

**axis**                                      name of digital axis device  
**register**                                    integer variable. Number of SLM register. Possible values range between 1-16  
**data**                                        integer variable. Data returned from read  
**error**                                        integer variable. Code error

**Description**

It executes the reading of the specified SLM register. Any execution errors can be managed by GPL by means of the optional "Error" parameter.  
 This instruction can be used only with digital axis cards.  
 For further information about the use of this instruction contact T.P.A. S.p.A.

## SLMGETSTATUS

### Syntax

**SLMGetStatus**                      **axis, parameter, data [,error]**

### Arguments

|                  |   |
|------------------|---|
| <b>axis</b>      | name of digital axis device   |
| <b>parameter</b> | integer variable. Read address (for ex. 8000h). Possible values range between 0-65535 |
| <b>data</b>      | integer variable. Data returned from read   |
| <b>error</b>     | integer variable. Code error  |

### Description

It executes the write of the Multiax Read Address and returns the read parameter to the "Drive Status". It manages automatically a 1ms delay between two operations. Any execution errors can be managed by GPL through the optional "Error" parameter.

This instruction can be used only with digital axis cards.

For further information concerning the use of this instruction, contact T.P.A. S.p.A.

## SLMSETEEPROM

### Syntax

**SLMSetEEPROM**                      **axis, address, data [,error]**

### Arguments

|                |   |
|----------------|---|
| <b>axis</b>    | name of digital axis device   |
| <b>address</b> | integer variable. Location to be written. Possible values range between 0-128 |
| <b>data</b>    | integer variable. Data to be written  |
| <b>error</b>   | integer variable. Code error  |

### Description

It executes the write of an EEPROM memory location. Any execution errors can be managed by GPL through the optional "Error" parameter.

This instruction can be used only with digital axis cards.

For further information concerning the use of this instruction, contact T.P.A. S.p.A.

## SLMSETPARAM

### Syntax

**SLMSetParam**                      **axis, address, data [,error]**

### Arguments

|                |   |
|----------------|---|
| <b>axis</b>    | name of digital axis device   |
| <b>address</b> | integer variable. Location to be written. Possible values range between 0-128 |
| <b>data</b>    | integer variable. Data to be written  |
| <b>error</b>   | integer variable. Code error  |

### Description

It executes the writing of an SLM parameter. Any execution errors can be managed by GPL through the optional "Error" parameter.

This instruction can be used only with digital axis cards.

For further information concerning the use of this instruction, contact T.P.A. S.p.A.

## SLMSETREGISTER

### Syntax

**SLMSetRegister**                      **axis, register, data [,error]**

### Arguments

|                 |  |
|-----------------|--|
| <b>axis</b>     | name of digital axis device  |
| <b>register</b> | integer variable. Number of SLM register. Possible values range between 1-16 |
| <b>data</b>     | integer variable. Data to be written   |

**error** integer variable. Code error

**Description**

It executes the writing of the specified SLM. Any execution errors can be managed by GPL through the optional "Error" parameter.

This instruction can be used only with digital axis cards.

For further information concerning the use of this instruction, contact T.P.A. S.p.A.

## 9.2.18 Simulation

### DISABLE

**Syntax**

**DISABLE** **axis1,[...axis6]**

**Arguments**

**axis1...[...axis6]** name of axis devices

**Description**

It disables the specified axes. This allows you to carry out simulations of the machine cyclic without physically moving the axes. A disabled axis can not read the information coming from the encoder but simulates a loop error proportionally to current speed. Disabling the axis, however, does not disable the speed reference, implying that power on the axes connector will not equal zero during simulated movements. For this reason it is necessary to disconnect the controls from the power supply or from the axis card during simulated movements, that is when axes are disabled. See also **ENABLE**.

**Note**

Step-by-step axes can be used in this instruction only if they are controlled by a TRS-AX remote.

### DISABLEFORCEDINPUT

**Syntax**

**DISABLEFORCEDINPUT**

**Arguments**

no arguments

**Description**

It disables the possibility of using functions to force the inputs. If any inputs have been previously forced, executing this instruction resets the real state. See also **ENABLEFORCEDINPUT**, **DISABLEFORCEDINPUT**, **SETFORCEDINPUT**, **RESETFORCEDINPUT**, **SETFORCEDBCD**, **SETFORCEDPORT**, **SETFORCEDANALOG**.

### ENABLE

**Syntax**

**ENABLE** **axis1,[...axis6]**

**Arguments**

**axis1...[...axis6]** name of axis devices

**Description**

It enables the specified axes. The axes are always enabled in the initialization phase. This instruction is only called if the axes were previously disabled by a **DISABLE** instruction.

**Note**

Step-by-step axes can be used in this instruction only if they are controlled by a TRS-AX remote.

### ENABLEFORCEDINPUT

**Syntax**

**ENABLEFORCEDINPUT**

**Arguments**

no arguments

**Description**

It enables input forcing. Before using instructions to enable or disable forced input devices, it is necessary to execute this instruction. Otherwise the input forcing instructions have no effect. See also DISABLEFORCEDINPUT, SETFORCEDINPUT, RESETFORCEDINPUT, SETFORCEDBCD, SETFORCEDPORT, SETFORCEDANALOG.

**RESETFORCEDINPUT****Syntax****RESETFORCEDINPUT      nameinput****Arguments****nameinput**                      name of digital input**Description**

It forces to OFF the input specified in **nameinput**.

To use this instruction it is necessary to have already enabled input forcing, with the ENABLEFORCEDINPUT instruction.

See also DISABLEFORCEDINPUT, SETFORCEDINPUT, SETFORCEDBCD, SETFORCEDPORT, SETFORCEDANALOG.

**SETFORCEDANALOG****Syntax****SETFORCEDANALOG      analoginput, value****Arguments****analoginput**                      name of analog input device  
**variable**                              constant or integer or float or double variable**Description**

It forces the **value** of the analog input specified in **analoginput**.

To use this instruction it is necessary to have first enabled input forcing, using the ENABLEFORCEDINPUT instruction.

See also, DISABLEFORCEDINPUT, SETFORCEDINPUT, RESETFORCEDINPUT, SETFORCEDBCD, SETFORCEDPORT.

**SETFORCEDBCD****Syntax****SETFORCEDBCD              namedigit1, [namedigit2,...], variable****Arguments****namedigit1,[namedigit2...]**      name of nibble device  
**variable**                              constant or integer or char variable**Description**

It converts the **variable** decimal value into a sequence of digits. Each digit is then converted in binary system and the bit mask thus obtained is forced in the relative input nibble.

The highest weight digit is associated to the first nibble (**namedigit1**).

To use this instruction it is necessary to have first enabled input forcing, using the ENABLEFORCEDINPUT instruction.

See also DISABLEFORCEDINPUT, SETFORCEDINPUT, RESETFORCEDINPUT, SETFORCEDPORT, SETFORCEDANALOG.

**SETFORCEDINPUT****Syntax****SETFORCEDINPUT              nameinput**

**Arguments**

**nameinput**                      name of digital input

**Description**

It forces to ON the input specified in **nameinput**.  
 To use this instruction it is necessary to have first enabled input forcing, using the ENABLEFORCEDINPUT instruction.  
 See also DISABLEFORCEDINPUT, RESETFORCEDINPUT, SETFORCEDBCD, SETFORCEDPORT, SETFORCEDANALOG.

**SETFORCEDPORT**

**Syntax**

**SETFORCEDPORT**                      **portname, value**

**Arguments**

**portname**                      name of input port device  
**variable**                      constant or integer or char variable

**Description**

It forces the value in the input port indicated by portname. The input port is interpreted as a bit mask. If a bit equals 1 the relative input is forced to "ON".  
 To use this instruction it is necessary to have already enabled input forcing, with the ENABLEFORCEDINPUT instruction.  
 See also DISABLEFORCEDINPUT, SETFORCEDINPUT, RESETFORCEDINPUT, SETFORCEDBCD, SETFORCEDANALOG.

**9.2.19 Blackbox**

The purpose of the "BlackBox" functionality is to record in a database all the activities of a machine, that is a local or a remote module. The "activity of a machine" is the variation over time of a subgroup of all logic devices that can be used in GPL. This is the way to analyse afterwards the behaviour of the machine, linking the states of the stored devices. The database has a table containing a temporal information and the state of all devices in that time, one for each column. In the GPL language new instructions have been introduced to start, and and query for the recording activity and are described later.

Each file of blackbox is a SQLite database and it contains information concerning one only module. The file name includes the number of the module, the date and the time of the recording start.

Records are added in the database in a transactional manner. Each transaction contains at the most the records generated in 1 second. In the event of a power failure the coherence of the file is guaranteed and the last transaction can be lost. The maximum duration of the transaction can be modified by an entry in Tpa.ini (for further information, please contact T.P.A. S.p.A).

A limit of 12 hours to the duration of the recording has been inserted. This means that each database will always contain only the last 12 hours of recording. During the recording the most ancient records are removed from the database. The maximum duration of the history recorded in the database can be modified by an entry in Tpa.ini (for further information, please contact T.P.A. S.p.A).

This functionality is available for physical devices on GreenBus, EtherCAT, CAN, S-CAN and Mechatrolink II buses, connected through TMSbus, TMSbus+, TMScan, TMScan+, DualMech, DualMech Mono and AlbMech.

**ENDBLACKBOX**

**Syntax**

**ENDBLACKBOX**

**Description**

It ends the record on file functionality for all the activity of a local and remote module. See also STARTBLACKBOX and PAUSEBLACKBOX.

**PAUSEBLACKBOX****Syntax****PAUSEBLACKBOX****Description**

It pauses the file logging functionality of all the activity of a local or remote module. To resume the recording you need to carry out the instruction STARTBLACKBOX instruction without arguments. See also ENDBLACKBOX.

**STARTBLACKBOX****Syntax****STARTBLACKBOX** [value][,error]**Arguments**

**value** constant or variable integer. Recording period  
**error** variable integer. Error code

**Description**

It activates the file recording functionality of all the activity of a local or remote module. The activity of a module is the variation over time of the state of the logic devices excluding the flag switch, input nibble and output nibble devices.

Recording period (**value**) is expressed in milliseconds. It cannot be less than 10 and it must be a multiple of the realtime period. Otherwise, the system error no. 4399 (Parameter outside the range) would be generated.

If the instruction starts a record and the **value** is omitted, the considered default value is 20.

If the instruction resumes a previously interrupted record, no set **value** is considered.

If it was not possible to start the recording, **error** contains a value not equal to 0, otherwise it contains 0.

| Error code | Description   |
|------------|---|
| 0          | No errors   |
| 1          | There are some differences between the device configuration in the numeric control and the device configuration in Albatros |
| 2          | The number of the devices to record exceeds the maximum number provided for the system                                      |
| 3          | No devices in the configuration   |
| 4          | The communication software in the remote module does not support the blackbox functionality (remote modules only)           |
| 5          | The numeric control prevents the recording from being started   |
| 6          | Error in uploading the database management library  |
| 7          | The number of columns for the table exceeds the maximum number of columns that can be managed by the database               |
| 8          | Couldn't open the database on disc  |
| 9          | Couldn't create in the database the recording table   |
| 10         | Error in IP address for the communication with the remote module (remote modules only)                                      |
| 11         | Couldn't create the communication socket to receive the data (remote modules only)  |
| 12         | Couldn't associate a local address to the communication socket (remote modules only)  |
| 13         | Couldn't connect to the remote socket (remote modules only)   |
| 14         | Couldn't access to the memory region shared with the numeric control  |
| 15         | The hardware configuration prevents from using the "BlackBox" functionalities   |
| 16         | The functionality has been disabled in tpa.ini  |

See also PAUSEBLACKBOX and ENDBLACKBOX.

**9.2.20 ISO****ISOG0****Syntax****ISOG0** label, axis1 position1, axis2, position2, axis3, position3, axis4, positiona4,axis5, position5, [value]**Arguments**

**label** constant or variable integer. Label identifying a displacement bloc. N in the ISO

|                  |  |
|------------------|--|
|                  | standard.  |
| <b>axis1</b>     | device name of axis type. (X in the ISO standard)  |
| <b>position1</b> | constant or variable Position of axis1 operational space                                   |
| <b>axis2</b>     | device name of axis type. (Y in the ISO standard)  |
| <b>position2</b> | constant or variable Position of axis2 operational space                                   |
| <b>axis3</b>     | device name of axis type. (Z in the ISO standard)  |
| <b>position3</b> | constant or variable Position of axis3 operational space                                   |
| <b>axis4</b>     | device name of axis type. (C in the ISO standard)  |
| <b>position4</b> | constant or variable Position of axis4 joint space   |
| <b>axis5</b>     | device name of axis type. (B in the ISO standard)  |
| <b>position5</b> | constant or variable Position of axis5 joint space   |
| <b>value</b>     | constant or variable double. It represents the feed rate percentage. F in the ISO standard |

**Description**

It sets the rapid movement. The rapid movement sections are managed as synchronized. The points defined by the user are the extrema of the single space of displacement covered, so that all the axes are synchronized to each other. That means that the physical axes move individually, even though they start and arrive simultaneously, in the same way as in the instructions MULTIABS and MULTIINC. The tool point does not cover a line in the operational space and its trajectory is not checked. The parameter **label** is used in association with the instruction SETLABELINTERP to identify univocally the displacement bloc. The first three **positions** identify the position of the point in the operational space, while the following two positions define the value of the rotating axes in the joint spaces. The feed rate **value** defines the percentage of reduction as regards the most possible speed rate (In ISO: F0 highest speed, F100 FeedRate null, therefore the axes are still).

The instruction generates a system error (4105- Instruction not executable on axis AxisName), if used on step-to-step axes.

The instruction WAITCOLL cannot be used, because starting from the collision the interpolation link to the other axes that contribute to the movement and generate a profile other than that expected, would be get lost.

If used, the system error no. "4101 - Inconsistent axis AxisName management" is generated".

**ISOG1**

**Syntax**

**ISOG1 label, axis1, position1,axis2, position2, axis3, position3,axis4,position4,axis5, position5, [value]**

**Arguments**

|                   |  |
|-------------------|--|
|                   | constant or variable integer. Label identifying a displacement bloc. (N in the ISO standard) |
| <b>axis1</b>      | device name of axis type. (X in the ISO standard)  |
| <b>position 1</b> | constant or variable Position of axis1 operational space                                     |
| <b>axis2</b>      | device name of axis type. (Y in the ISO standard)  |
| <b>position2</b>  | constant or variable Position of axis2 operational space                                     |
| <b>axis3</b>      | device name of axis type. (Z in the ISO standard)  |
| <b>position3</b>  | constant or variable Position of axis3 operational space                                     |
| <b>axis4</b>      | device name of axis type. (C in the ISO standard)  |
| <b>position4</b>  | constant or variable Position of axis4 operational space                                     |
| <b>axis5</b>      | device name of axis type. (B in the ISO standard)  |
| <b>position5</b>  | constant or variable Position of axis5 operational space                                     |
| <b>feed rate</b>  | constant or variable double. it represents the Feed value. (F in the ISO standard)           |

**Description**

It defines the point in the operational space that should reach the tool point at the end of the interpolation of the current bloc. The parameter **label** is used in association with the instruction SETLABELINTERP to identify univocally the displacement bloc. The first three **positions** identify the position of the tool point in the operational space, while the following two positions define the value of the rotating axes in the configuration space. The **value** Feed defines the feed rate of the tool point as measure unit (millimeters or grades) per minute (set in the presence of an instruction ISOG94) as inverse of the execution time (in the presence of the instruction ISOG93). The parameter **value** is compulsory for the first instruction ISOG1 of the interpolation movement.

The instruction generates a system error (4105- Instruction not executable on axis AxisName), if used on step-to-step axes.

The instruction WAITCOLL cannot be used, because starting from the collision, the interpolation link to the other axes that contribute to the movement and generate a profile other than that expected, would be get lost.

If used, the system error no. "4101 - Inconsistent axis AxisName management" is generated".





## ISOG94

### Syntax

**ISOG94**                    **axis**

### Arguments

**axis**                            name of device of type axis

### Description

It sets the interpretation of the speeds as units of measure per minute. The parameter **axis** finds the interpolation channel with 5 axes, that from this instruction on will interpret the speed rates as measure units per minute (default condition).

## ISOG216

### Syntax

**ISOG216**                            **RotariesMatrixName, ToolHolderMatrixName, ToolsMatrixName,EnablingMask, axis1, axis2,axis3,axis4,axis5**

### Arguments

|                              |  |
|------------------------------|--|
| <b>RotariesMatrixName</b>    | name of the matrix. It contains the data concerning the rotary axes. |
| <b>ToolHolderMatrixName</b>  | name of the matrix. It contains the data concerning the toolholders  |
| <b>ToolHoldersMatrixName</b> | name of the matrix It contains the data concerning the tools.        |
| <b>EnablingMask</b>          | variable or integer constant. C and B axes enabling mask             |
| <b>axis1</b>                 | device name of axis type. (X in the ISO standard)                    |
| <b>axis2</b>                 | device name of axis type. (Y in the ISO standard)                    |
| <b>axis3</b>                 | device name of axis type. (Z in the ISO standard)                    |
| <b>axis4</b>                 | device name of axis type. (C in the ISO standard)                    |
| <b>axis5</b>                 | device name of axis type. (B in the ISO standard)                    |

### Description

It identifies the three matrices for the machine parametrisation and the five devices of axis type composing the same. Such instruction **should** be performed before every other ISO instruction. The parameter **EnablingMask** defines which rotation axes (C and/or B) should be enabled. To set the values, reference is made to the following table:

| EnablingMask | Description              |
|--------------|--------------------------|
| 31           | Desabling C and B axes   |
| 23           | Enabling the only B axis |
| 15           | Enabling the only C axis |
| 7            | Desabling C and B axes   |

### Note

The unit of measure, in which the values of the rotary axes are expressed in the configuration, must be degrees.

The link among the physical axes and the virtual ISO axes, set through this instruction, is brought to the end through the instruction ISOM2 or when the task, where the instruction is defined, has finished. Therefore, the axes can be used for classic movement.

## ISOG217

### Syntax

**ISOG217**                            **axis1,axis2,axis3,axis4,axis5,virtualAxis1,virtualAxis2,virtualAxis3,virtualAxis4,virtualAxis5.**

### Arguments

**axis1**                            device name of axis type



|                           |  |
|---------------------------|--|
| Z-Offset                  | Offset along Z between the pivot point and the control point of the head                 |
| Out-of-alignment of X     | Deviation in X between rotation and slewing axes (when the position of C-axis = 0)       |
| Out-of-alignment of Y     | Deviation in Y between rotation and slewing axes (when the position of C-axis = 0)       |
| Out-of-alignment of Z     | Nose-pivot point distance  |
| $\delta$ - angle $\delta$ | Angle around Z for the correct placement of the head with respect of zero point machine. |
| $\gamma$ - angle $\gamma$ | Angle between rotation and slewing plane.  |

| <b>Matrix fields</b> | <b>Toolholder Matrix</b>   |
|----------------------|--|
| PU X-Offset          | Offset in X between the toolholder's coupling point to the motor and the tool's coupling point to the toolholder (when the position of C-axis = 0 and vertical motor)  |
| PU Y-Offset          | Offset in Y between the toolholder's coupling point to the motor and the tool's coupling point to the toolholder (when the position of C-axis = 0 and vertical motor)  |
| PU Z-Offset          | Offset in Z between the toolholder's coupling point to the engine and the tool's coupling point to the toolholder (when the position of C-axis = 0 and vertical motor) |
| Angle $\alpha$       | Phase displacement angle between motor and toolholder axis (with respect to Z)   |
| Angle $\beta$        | Phase displacement angle between motor and toolholder axis (with respect to Y)   |

| <b>Matrix fields</b> | <b>Matrix of the toolholders</b> |
|----------------------|----------------------------------|
| Length of the tool   | Length of the tool               |

**ISOSETPARAM**

*Syntax*

**ISOSETPARAM**                      **ParameterIndexNumber, value**

*Arguments*

**ParameterIndexNumber**            constant or variable integer. It is the number identifying a parameter

**constant**                              value or variable float. It is the value to set.

*Description*

It sets some parameters ruling the fluidity of the ISO interpolated movement. The meaning of each **ParameterIndexNumber**, the values within which the variable should be **included** and the values defaults are explained in the table, as follows:

| <b>ParameterIndexNumber</b> | <b>RANGE</b> | <b>Default</b> | <b>Meaning</b>   |
|-----------------------------|--------------|----------------|--|
| 0                           | 0.0-100.0    | 50.0           | Linear axes slowdown percentage in case of angular point<br>(0= no slowdown, 100= maximum slowdown allowed by the interpolator)    |
| 1                           | 0.0-100.0    | 50.0           | Rotating axes slowdown percentage in case of angular point.<br>(0= no slowdown, 100= maximum slowdown allowed by the interpolator) |
| 2                           | 0.5-1.0      | 0.9            | Factor of speed reduction on curviliear abscissa in case of angular point.<br>(1=no reduction, 100=maximum slowdown allowed)       |
| 3                           | 0.0-100.0    | 60.0           | Slowdown percentage in case of close   |

|   |           |       |   |
|---|-----------|-------|---|
|   |           |       | discontinuities.<br>(0=no slowdown, 100=maximum slowdown allowed by the interpolator)   |
| 4 | 0.0-100.0 | 10.0  | Smooth percentage of the trajectory   |
| 5 | 0.2-1.0   | 0.2   | Minimum dimension of the space to cover with only linear axes. The value is expressed in millimeters.   |
| 6 | 0.1-1.0   | 0.1   | Minimum dimension of the space to cover with only linear axes. The value is expressed in millimeters.   |
| 7 | 0.0-100.0 | 100.0 | Percentage of the applied minimum smooth value<br>(0 = minimum value of invalid smooth, 100 = maximum percentage of the minimum smooth value) |

## KINEMATICEXPR

### Syntax

**KINEMATICEXPR**                      **axis = expression**

### Arguments

**axis**                                      name of device of physical or virtual axis type  
**expression**                              group of operators

### Description

It allows you to define single expressions of direct and inverse kinematics. Before performing this instruction, the instruction ISOG217 describing the physical axes and the virtual axes, that make up the machine, must be called. For each axis defined in ISOG217 the instruction KINEMATICEXPR. must be called. The kinematics expression of an axis in the space of the joints (inverse kinematics) can be a function of

- variables
- constants
- coordinates of the axes in the operational space.

The kinematics expression of an axis in the operational space (direct kinematics) can be a function of

- variables
- constants
- coordinates of the axes in the space of the joints.

The expression **syntax** is the same as in the instruction EXPR, the only difference being that local variables cannot be used. Furthermore, axes of the same type as the axis, declared in **axis** and not declared in the instruction ISOG217, cannot be used. E.g, if the kinematics of a virtual axis, already declared in the instruction ISOG217 is being defined, in the expression only the five physical axes, that are declared in the ISOG217, can be used.

### Example

```
ut as double ; tool number
offsety as double ; offset Y nose fulcrum
offsetz as double ; offset Z nose fulcrum
```

### Function IS05Ax

```
setval 100,ut
setval 120.0,offsety
setval 60.0,offsetz
; EXPLICIT KINEMATICS
ISOG217 Rx Ry Rz Rc Rb X Y Z C B

; DEFINITION OF THE KINEMATICS EXPRESSIONS
; EXPLICIT INVERSE KINEMATICS Rx physical AXIS
KinematicExpr Rx = X - 135 + ut * sin ( B ) * cos ( C )

; EXPLICIT INVERSE KINEMATICS RY physical AXIS
```

```

KinematicExpr Ry = Y + offsety + ut * sin ( B ) * sin ( C )

; EXPLICIT INVERSE KINEMATICS Rz physical AXIS
KinematicExpr Rz = Z + offsetz + ut * cos ( B )

; EXPLICIT INVERSE KINEMATICS Rc physical AXIS
KinematicExpr Rc = C

; EXPLICIT INVERSE KINEMATICS Rb physical AXIS
KinematicExpr Rb = B

```

### 9.2.21 Instructions which can not be used with interrupt

The following instructions cannot be used in the functions called by ONFLAG, ONINPUT and ONERRSYS. Their usage is not allowed in realtime tasks too.  
instructions.

Instructions which, in turn, call a function on interrupt:

- ONFLAG
- ONINPUT
- ONERRSYS

Instructions which involve a wait:

- WAITINPUT
- WAITFLAG
- WAITACC
- WAITCOLL
- WAITDEC
- WAITREG
- WAITTARGET
- WAITWIN
- WAITSTILL
- WAITTASK
- WAITRECEIVE
- WAITPERSISTINPUT
- MULTIWAITFLAG
- MULTIWAITINPUT

Communication instructions:

- SEND
- RECEIVE
- CLEARRECEIVE
- COMOPEN
- COMCLOSE
- COMREAD
- COMREADSTRING
- COMWRITE
- COMWRITESTRING
- COMGETERROR
- COMCLEARRXBUFFER
- COMGETRXCOUNT

Following instructions involving axis movement:

- MOVINC
- MOVABS
- LINEARINC
- LINEARABS
- CIRCLE
- CIRCINC
- CIRCABS
- HELICINC
- HELICABS
- COORDIN
- MULTIABS
- MULTINC
- SETRIFLOC
- SETTOLERANCE

- RESRIFLOC
- SETPFLY
- SETPZERO
- SETINDEXINTERP
- STARTINTERP
- FASTREAD
- ENABLE
- DISABLE
- ENDMOV

ISO instructions:

- ISOG0
- ISOG1
- ISOG9
- ISOG90
- ISOG91
- ISOG93
- ISOG94
- ISOG216
- ISOG217
- ISOM2
- ISOM6
- ISOSETPARAM
- KINEMATICEXPR

Following instructions involving Powerlink II management:

- HOMING
- READDICTIONARY
- WRITEDICTIONARY

Digital axis card configuration instructions:

- SLMGETPARAM
- SLMSETPARAM
- SLMCOMMAND
- SLMGETSTATUS
- SLMGETEEPROM
- SLMSETEEPROM
- SLMGETREGISTER
- SLMSETREGISTER
- SLMEEPROMENABLE
- SLMEEPROMDISABLE

Instructions involving multitasking:

- SENDMAIL
- WAITMAIL
- ENDMAIL
- SENDIPC
- WAITIPC
- TESTMAIL
- TESTIPC

Instructions which imply a long processing time:

- SORT
- FIND
- FINDB
- MOVEMAT
- CANOPENDRIVER
- CANSERETBOARD

## 9.2.22 Instructions which are no longer available

|                  |  |
|------------------|--|
| CLEARSTOPDISABLE | it clears the field stop disabling counter |
| STOPDISABLE      | it disables the field stop                 |
| STOPENABLE       | it enables the field stop                  |
| IFSTOPDISABLED   | test on disabled field stop                |

|         |                                      |
|---------|--------------------------------------|
| SPINDLE | it sets the speed of a winding block |
|---------|--------------------------------------|

|                             |  |
|-----------------------------|--|
| SETPARINV<br>WINDING        | it sets the wireguide inversion parameters for winding<br>it stops an axis   |
| BRAKEENABLE<br>BRAKEDISABLE | it enables break management<br>it disables break management  |
| SETPREARN<br>SETPREARP      | it sets a prestop position for negative direction movement<br>it sets a prestop position for positive direction movement |
| LET                         | it calculates arithmetical expressions   |
| SENDRECEIVE                 | it sends data outside with a confirmation request  |
| SEED                        | it sets the seed for a sequence of random numbers.   |

## 9.3 Examples

### 9.3.1 Homing on Interrupt

```

-----
; Example of on the fly homing routine
; The function executes the following operations:
;
; 1) It sets the axis by disabling software limits
;    and setting position on zero.
; 2) It checks that the sensor is not already on ON state.
;    If it is on ON, it moves the axis and waitsfor it to return
;    to OFF state. If this does not happen in 30 seconds
;    it generates an error message.
; 3) It sets the sensor search speed
; 4) It launches axis movement and enables "on the fly" homing
;    for the specified axis. when the interrupt is released,
;    the axis position is set on zero and movement to a disengage
;    position is started automatically.
; 5) It waits for the axis to reach the disengage position.
; 6) It resets axis limits
;
; © T.P.A. S.p.A.
-----
Function Fast_Homing

    ResLimPos    axis          ; Axis start-up
    ResLimNeg    axis
    SetQuote     axis,0

    IfInput      FastInput,OFF,Goto Continue    ; Test occupied sensor
    SetVel       axis,5                        ; Set disengage speed
    MovAbs       axis,30                       ; Move axis
    WaitInput    FastInput,OFF,30,Call Error    ; Test micro disengage
                                                    ; Error after TimeOut=30

    EndMov       axis                    ; Stop axis
    WaitStill    axis                    ; Wait for axis stop

Continue:
    SetVel       axis,10                    ; Homing sensor search speed
    MovAbs       axis,-1000                ; Sensor search negative movement
    SetPFly      axis,ON,10,0              ; Interrupt attach
                                                    ; and set disengage position and speed

```

```

waitStill    axis          ; wait for axis Stop

SetLimPos    axis          ; Reset axis limits
SetLimNeg    axis

Fret

; subprocedure to send error messages
Error:
  Error      ERR_SETP      ;Error signalled: impossible to proceed
  Ret

```

### 9.3.2 Axis movement server

```

-----
; Example of axis movement server:
;
; The server moves the machine's axes
; on behalf of other tasks.
;
; The client tasks send their commands in the form of
; messages (mails) to a postbox.
;
; The server takes the commands from the box and executes them.
;
; The requests are queued in the post box, so that
; if a request arrives while the server is already
; engaged, it is not lost, and will be dealt with as soon as possible.
;
; The server is the only task to move axes. This avoids
; conflicts.
;
; The server is implemented by the Master_axes function.
;
; An example of client is implemented by the Check_flag function.
; This function checks the state of a flag
; periodically and when it finds it on ON it sends the server
; the axis homing execution command.
; The flag will presumably be set on ON manually
; by the operator, using for example the synoptic view.
-----

-----
; -- MACHINE GLOBAL CONSTANTS --
-----
Const MBOX = 101      ; identifies the command post box

Const SETP = 10      ; axis homing
Const CHG  = 11      ; change tool
Const FORO = 12      ; execute perforation

;
; ----- AXES GROUP -----
;
; definition of error messages
Defmsg ERR_CMD "Axis group command unknown"

; --- Server ---
Function Master_axes autorun

  local cmd as integer      ; command

```



```

local position_X as double      ; position X perforation
local position_Y as double      ; position Y perforation

loop:
  waitmail MBOX,cmd,position_X,position_Y    ; wait command

  ; when the command arrives we identify it
  ; and execute the required action
  select cmd

  case SETP
    fcall homing_axes      ; Axis Homing
  case CHG
    fcall Change_tool      ; Execute tool change
  case FORO
    fcall Perforation position_X,position_Y ; perforation in
                                           ; specified position
  case else
    call error
  endselect

  endmail MBOX              ; command execution notification
  goto loop                 ; wait for new command

fret

; subprocedure for error message sending
error:
  error ERR_CMD
  ret

;-----
; --- GENERIC GROUP ---
;-----

; --- Client ---
Function Check_flag

loop:

  ifflag Setp_axes,OFF, goto loop          ; test flag state

  ; OK the flag is on ON, send command
  sendmail MBOX,WAITTACK,SETP,0.0,0.0

  resetflag Setp_axes                      ; reset flag

  goto loop                                ; back to wait

fret

; NOTICE THAT:
; - after the "SETP"command, the two parameters "position_X"
;   and "position_Y" must be specified even if it does not
;   make sense for the Homing operation.
;   Because the server can not know beforehand which command

```

```

; it will receive,we must specify two values
; of the type expected by the server,
; in this case, two DOUBLE. The values to be set are "0.0" and "0.0".
; - the "WAITACK" parameter makes the client wait
; for the server to conclude the command.
; The client can continue its own execution only when the Server
; has executed an ENDMAIL or has started processing a new
; command (WAITMAIL).

```

### 9.3.3 Main Cycle with error management

```

;-----
; Hypothetical main function
; start machine and execute test cycle
;-----
Function Main
  OnErrSys      GestErrSys      ; enable error management

  StartTask    Emergencies      ; start
  StartTask    Processor
  Enableaxes

Loop:
  IfFlag      Flag,OFF, ResetEmergencies
  .....
  Goto      loop
Fret

;-----
; error management function
;-----
Function GestErrSys
  Param nerror as integer
  Param task as function
  Param typedevice as device

  EndTask      task              ; End Processor task
  If          nerror, >, 5, goto noerraxis ; The first 5 errors
                                           ; concern
                                           ; axes

  ResetFlag    Flag
  Disableaxes

noerraxis:
Fret

```

### 9.3.4 Operations on strings

```

;-----
; Example of string manipulation
;-----
Function example
  Local      string1 as string
  Local      string2 as string
  Local      string3 as string
  Local      length as integer
  Local      position as integer

  SetString  "String of",string1      ; string1 now contains
                                       ; "String of"
  SetString  " test",string2

```

```

AddString  string1,string2,string3      ; stringa3 contains
                                                ; "Test string"

Search    string3,'t',position          ; position equals 2
Search    string3,'z',position          ; position equals -1

Left      string3,7,string1            ; string1
                                                ; contains "String"

Right     string3,2,string2            ; string2
                                                ; contains "va"

Mid       string3,9,2,string3          ; string3
                                                ; contains "of"

ControlChar 65,string1                 ; string1
                                                ; contains "A"

Len       string3,length               ; length equals 2

Str       length,string3               ; string3
                                                ; contains "2"

Val       position,string1             ; string1
                                                ; contains "-1"

AddString "The result is",string1,string2
; string2 contains "The result is -1"

```

Fret

### 9.3.5 Sequential / Parallel Execution

```

;-----
; Example of a routine testing the Homing
; of a 3 axes machine to avoid any
; mechanical interference.
;
; The Homing of the single axes is implemented
; by functions whose text has been omitted.
; See example "Homing Routine".
;
; The Homing of the z axis is carried
; out first(as theoretically it can not be
; done with the others),
; when this is concluded, the X and Y axis Homing
; is executed simultaneously.
;-----

; message for the operator (translated in set language)
DefMsg      MSG_SETP      ITA  "Homing assi in corso ..."
           ENG  "Homing in progress ..."

Function Homing

Message     MSG_SETP      ; inform operator

Fcall      HomingAxisZ    ; Homing of Z axis

; OK Z axis Homing is concluded

```

```

StartTask HomingAxisX      ; launch homing X and Y
StartTask HomingAxisY

WaitTask HomingAxisX      ; wait for task end
WaitTask HomingAxisY

DelMessage MSG_SETP      ; delete message
                          ; for the operator

```

Fret

### 9.3.6 Homing Routine

```

-----
; Example of axis setpoint routine
;
; The function executes the following operations:
; 1) it disables the software axis limits
; 2) it sets the switch search speed
; 3) it moves the axis to an incremental position that
;    guarantees reaching the switch
; 4) it waits for the axis to release the switch
; 5) it stops the axis and waits for movement to end
; 6) it sets the speed (low) of the disengage switch
; 7) it makes the axis move backwards the sufficient space
;    to disengage the switch
; 8) it waits for switch disengage
; 9) it sets the new position for the axis
; 10) it resets default speed and software limits
;
; © T.P.A. S.p.A.
-----

```

Function Homing

```

ResLimPos axis      ; disable software limits
ResLimNeg axis

SetVel axis,10      ; set speed

MovInc axis,10000   ; move the axis

WaitInput Switch,ON ; wait for switch

EndMov axis         ; stop axis
waitStill axis      ; wait for axis stop

SetVel axis, 0.1    ; set disengage speed

MovInc axis,-100    ; move axis

WaitInput Switch,OFF ; wait for switch disengage

SetQuote axis,0     ; assign new position

SetVel axis         ; reset speed
SetLimpos axis      ; reset software limits
SetLimneg axis

```

Fret

### 9.3.7 Synchronized movement

```

-----
; Example of synchronized movement
;
; A profile is generated using the instruction SYNCRO
; profile is then executed using the instruction COORDIN.
;
; © T.P.A. S.p.A.
-----

```

```

const CH1 = 1          ; synchronized movement channel
const CAD = 4          ; frequency of generation/execution of the positions
                        (4 ms)

```

```

pMat[5000] as double:Qx double:Qy integer:index
pVar as integer

```

```

Function Sincro
  local ini as integer

  ; profile generation
  SyncroOpen          CH1, CAD, pMat, pVar, ON

  SyncroSetVel        CH1, X, 20, 20
  SyncroSetVel        CH1, Y, 20, 20

  SyncroMove          CH1, X, 100, Y, 100
  SyncroMove          CH1, X, 110, Y, 120
  SyncroMove          CH1, X, 140, Y, 130

  syncroSetVel        CH1, X, 10, 10      ; change speed axis X

  SyncroMove          CH1, X, 150, Y, 160
  SyncroMove          CH1, X, 200, Y, 180

  SyncroStartMove    CH1
  SyncroClose         CH1

  ; profile execution
  setval              1,ini
  Coordin             pMat, CAD, UP, ini, pVar, $11b, X, 1, Y, 2

  waitStill           X, Y

Fret

```

### 9.3.8 Iso movements

```

-----
; Example of ISO movement
;
; A profile is generated using the instruction ISOG0 and ISOG1
;
; © T.P.A. S.p.A.
-----*

```

```

; Declaration of ISO matrices
Matrix of rotary axes
MxRot[5] as double:off_X double:off_Y double:off_Z double:dis_X
double:dis_Y double:dis_Z double:delta double:gamma
; Toolholder matrix

```

```

MxPorta[1] as double:off_X double:off_Y double:off_Z double:alpha
double:beta
; Tools matrix
MxTools[10] as double:ut double

```

```
Function ISOInterpolation
```

```
; setting of standard values of machine parametrisation
```

```
setval 90.0 MxRot[5].gamma
setval 260.3 MxTools[10].ut
setval MxTools[10].ut ut

```

```
; setting of parameters of algorithm
```

```
IsosetParam 0 50
IsosetParam 1 50
IsosetParam 2 0.9
IsosetParam 3 60
IsosetParam 4 30

```

```
; machine settings: declares the three matrices used for
; the machine parametrisation
; and the physical axes used in the ISO movements.

```

```
isog216 MxRot MxTool MxHolder 31 X Y Z C B ; IMPLICIT KINEMATICS
```

```
; setting of group of parameters describing the machine's kinematics.
```

```
isom6 X 5 1 10 ; IMPLICIT KINEMATICS
```

```
; setting of the starting value
```

```
setquote x 500
setquote y 300
setquote z 0
setquote c 0
setquote b 0
setvel x
setvel y
setvel z
setvel c
setvel b
setveli x y z c b

```

```
; profile execution
```

```
isog0 1001,X 998.0,Y 600.0,Z 0.0,C 90.0,B 45.0,50.0
isog1 1001,X 998.0,Y 600.0,Z 0.0,C 90.0,B 45.0,10000.0
isog1 1003,X 996.0,Y 600.0,Z 0.0,C 90.0,B 45.0,10000.0
isog1 1002,X 600.0,Y 600.0,Z 0.0,C 90.0,B 45.0,10000.0
isog1 1004,X 599.131759111665,Y 599.924038765061,Z 0,C 100,B
45.0,10000.0
isog1 1006,X 598.289899283372,Y 599.69846310393,Z 0,C 110,B 45.0,10000.0
isog1 1005,X 597.5,Y 599.330127018922,Z 0,C 120,B 45.0,10000.0
isog1 1003,X 596.786061951567,Y 598.830222215595,Z 0,C 130,B
45.0,10000.0
isog1 1002,X 596.169777784405,Y 598.213938048433,Z 0,C 140,B
45.0,10000.0
isog1 1012,X 595.669872981078,Y 597.5,Z 0,C 150,B 45.0,10000.0
isog1 1011,X 595.301536896071,Y 596.710100716628,Z 0,C 160,B
45.0,10000.0
isog1 1031,X 595.075961234939,Y 595.868240888335,Z 0,C 170,B
45.0,10000.0
isog1 1102,X 595.0,Y 0.0,Z 0.0,C 180.0,B 45.0,10000.0
waitstill X Y Z C B

```

```
fret
```



**Tecnologie e Prodotti per l'Automazione s.p.a**

Via Carducci 221  
I - 20099 Sesto S.Giovanni (MI)  
Tel. +39 02.36527550  
Fax. +39 02.2481008  
[www.tpaspa.it](http://www.tpaspa.it)