

DENALI

GEN II CANsmart™ Controller
 DNL.WHS.25900
 BMW R1300GS

ONLINE USER GUIDE

DENALIElectronics.com/BMW-CANsmart-User-Guide

Thank you for choosing DENALI

We know you would rather be riding your bike than wrenching on it, so we go the extra mile to make sure our instructions are clear and as easy to understand as possible. If you have any questions, comments, or suggestions don't hesitate to give our experts a call at 401.360.2550 or visit WWW.DENALIELECTRONICS.COM

Please Read Before Installing

DENALI products should always be installed by a qualified motorcycle technician. If you are unsure of your ability to properly install a product, please have the product installed by your local motorcycle dealer. DENALI takes no responsibility for damages caused by improper installation. **Caution:** When installing electronics it is extremely important to pay close attention to how wires are routed, especially when mounting products to the front fender, front fork, or fairing of your motorcycle. Always be sure to turn the handlebars fully left, fully right, and fully compress the suspension to ensure the wires will not bind and have enough slack for your motorcycle to operate properly.


Installation Tips

We strongly recommend using medium strength liquid thread locker on all screws and bolts. It is also important to ensure that all hardware is tightened to the proper torque specifications as listed in your owner's manual. For included accessory hardware please refer to the default torque specifications provided below. Inspect all hardware after the first 30 miles to ensure that proper torque specifications are maintained.


Bolt Size	in-lbs	ft-lbs	Nm
M3	10.0 in-lbs	-	1.0 Nm
M4	23.0 in-lbs	-	2.5 Nm
M5	44.5 in-lbs	3.5 ft-lbs	5.0 Nm
M6	78.0 in-lbs	6.5 ft-lbs	9.0 Nm
M8	-	13.5 ft-lbs	18.0 Nm
M10	-	30.0 ft-lbs	41.0 Nm
M12	-	52.0 ft-lbs	71.0 Nm

Hardware Sizing Guide

Not sure what size bolt you have? Use this ruler to measure screws, bolts, spacers, etc. Remember, the length of a screw or bolt is measured from the start of the "mounting surface" to the end of the screw, so only include the screw head when measuring countersunk screws.




What's In The Box?



Kit Contents

- (a) CANsmart™ Controller.....Qty 1
- (b) 3-Pin 5ft Horn Extension.....Qty 1
- (c) 3-Pin 5ft LED Light Extension.....Qty 2
- (d) 3-Pin Brake Light Wiring Adapter.....Qty 1
- (e) Zip Tie.....Qty 4
- (f) Adhesive Dual Lock.....Qty 1
- (g) USB to Micro USB Programming Cable.....Qty 1




1.1 - Overview of Device

The DENALI CANsmart™ Controller provides plug-n-play installation and integrated control of up to four accessories to enable dozens of customizable settings that can be controlled right from the BMW Multi Controller or the CANsmart™ Accessory Manager Software.

The four circuits are preprogrammed to connect and independently control two sets of DENALI 2.0 lights, a SoundBomb horn, and our B6 auxiliary brake light. However, our Circuit Function Selector in the CANsmart software will let you run any accessory of your choice on any of the four circuits.

The illustration above depicts the preprogrammed default configuration, to see all available circuit functions and settings please refer *Section 6* or visit our online user guide at: DENALIElectronics.com/cansmart-user-guide



1.2 - Overview of System Features

The two auxiliary light circuits enable independent adjustment of high and low beam brightness right from the vehicle's "WonderWheel". It also features a "flash to pass" and "strobe when horn active" setting that will strobe the auxiliary lights when you pulse your high beam switch or sound your horn.


The feature-rich brake light circuit will transform a simple 2-wire brake light into a "smart brake light" complete with running light, multiple flash patterns, and deceleration activated braking functionality.

The horn circuit enables the addition of an auxiliary horn without having to add a relay and dedicated horn wiring harness.

The R1300GS CANsmart has an additional protective function "Only on when engine is running". When the ignition is switched on, the high power consumers remain powered off. These are Aux1, Aux2 & Heated Gear. Once the RPM is above zero the CANsmart will wait for 2s of stable Running RPM (not cranking) whereafter it will enable these Power Consumers. When you hit the KILL switch (but ignition is still on) these will remain ON for 5s before they will be switched OFF. If you just switch off the ignition these will switch off immediately.

For a full list of features and available settings refer to *Section 6*.

2. Connecting To CAN bus



2.1 - Connecting to the DWA Plug


Step One: The DWA unit is located at the rear of the motorcycle in the compartment under the passenger seat. Remove the rear seat in this area to gain access to the unit.

Step Two: Unplug the connector from the DWA unit, or connector holder depending on the vehicle.

Step Three: The CANsmart™ Controller plugs in-line between the motorcycle's harness and the DWA unit. First plug the DWA connector into the male 6-pin connector on the CANsmart™ Controller.

Step Four: Plug the female 6-pin connector on the CANsmart™ Controller into the DWA unit, or connector holder.

3. Connecting Accessories



3.1 - Light Set One & Two (Red & White Circuits)

In the default configuration, the circuit for Light Set One is the longest red lead, the shortest white lead is for Light Set Two. Both circuits are designed to handle up to 10 amps each.


Step One: Plug the male 3-pin connector of the Light Extension-Splitter into one of the CANsmart™ Controller's light circuits.

Step Two: Begin routing the harness toward the front of the bike. Secure the harness to the vehicle's frame along the way with the included zip ties. Be sure to avoid any moving components such as radiator fan blades or suspension.

Step Three: Plug the DENALI Light Pods into the female 3-pin connectors of the Extension-Splitter. Repeat steps *One* through *Three* using a second Light Extension-Splitter for the second set of lights.

Two-Wire Dimming: Turn off "Three-Wire Dimming Mode" for correct dimming operation of auxiliary LED lights that have only two wires. If enabled the 3rd yellow wire will be deactivated and PWM data will instead be transmitted through the red wire.

Wire two wire lights using the red wire for positive (+) and the black wire for negative (-).




3.2 - Horn (Blue Circuit)

Step One: Plug the male 2-pin connector of the Horn Extension into blue horn circuit on the CANsmart™ Controller.

Step Two: Begin routing the harness toward the front of the bike. Secure the harness to the vehicle's frame along the way with the included zip ties. Be sure to avoid any moving components such as radiator fan blades or suspension.

Step Three: Plug the spade connectors of the Horn Extension into the DENALI SoundBomb Horn. The Green wire connects to the positive (+) terminal on the horn, the Black wire goes to the negative (-) terminal.




3.3 - Brake Light (Yellow Circuit)

Step One: Route the harness of the DENALI B6 Brake Light from the rear of your motorcycle toward the CANsmart™ Controller.

Step Two: Plug the Brake Light Pigtail into the connector on the DENALI B6 Brake Light.

Step Three: Plug the male 2-pin connector of the Brake Light Pigtail into the yellow brake light circuit on the CANsmart™ Controller.


4. Connecting To The Battery



4.1 - Connect To The Battery

- Step One:** Remove the fuse from the fuse holder.
 - Step Two:** Gain access to the vehicle's battery and disconnect the negative (-) and positive (+) terminals.
 - Step Three:** Connect the CANsmart™ wiring harness to the battery via the ring terminals. Be sure the orange wire lead with the fuse holder goes to the positive (+) terminal of the battery.
 - Step Four:** Re-install the fuse into the fuse holder.
- Note:** Place the fuse holder in an easily accessible location for convenient service in the event of a blown fuse.

5. Alternate Light Wiring Options



5.1 - Left/Right Split Lights

Wiring your LED Lights split left/right enables the "Off When Turn Signal Active" feature to cancel only the LED lights on the corresponding side of the bike that the signal was activated. When lights are wired as sets (Figure 3.1), the LED lights on both sides of the bike will cancel regardless which side turn signal is activated.

- One:** Plug the male 3-pin connector of the Light Extension-Splitter into one of the CANsmart™ Controller's light circuits.
- Step Two:** Begin routing the harness toward the front of the bike. Secure the harness to the vehicle's frame along the way with the included zip ties. Be sure to avoid any moving components such as radiator fan blades or

Step Three: Plug the DENALI Light Pods from the right side of the motorcycle into the female 3-pin connectors of the Extension-Splitter. Repeat steps One through Three using a second Light Extension-Splitter for the lights on the left side of the motorcycle

Step Four: Connect the CANsmart to the Device Manager Software. Using Circuit Function Selector, reassign the circuits used to be "Left Light 1" for the circuit powering the left side LED lights, and "Right Light 1" for the circuit powering the right side LED lights.

6. Software Overview

The screenshot shows the CANsmart software interface. At the top, there are logos for 'Powered by HEX INNOVATE', 'DENALI CANSMART ACCESSORY MANAGER', and a warning icon. Below the logos, the text 'Circuit Functions' is followed by the instruction 'Click on the icons to change the function of each circuit'. There are four main circuit categories: Red Circuit, Blue Circuit, Yellow Circuit, and White Circuit. Each category has a set of icons representing different functions. The Red Circuit is currently selected. Below the circuit categories, there is a grid of 15 icons representing various functions: LEFT LIGHT 1, RIGHT LIGHT 1, LIGHT PAIR 1, ACCESSORY, HORN, LEFT LIGHT 2, RIGHT LIGHT 2, LIGHT PAIR 2, LEFT TURN, RIGHT TURN, BRAKE LIGHT, BRAKE & TURN LEFT, BRAKE & TURN RIGHT, and HEATED GEAR. Below the grid, there is a note: '10A continuous, 25A Maximum (for 25s) per circuit. 25A continuous current draw for the entire system'. At the bottom, there are 'Apply' and 'Cancel' buttons.

6.1 - Circuit Function Selector

The Circuit Function Selector in the CANsmart software will let you run any accessory of your choice on any of the four circuits. Click on a circuit icon to open the drop down menu and make your selection from the list of available circuit functions. Continue reading for an overview of each circuit function and its available settings.


The screenshot shows the 'Auxiliary Lights One' settings screen. On the left, there are two light beam icons: 'HIGH BEAM' (blue) and 'LOW BEAM' (yellow). For each beam, there are sliders for 'Day Intensity' and 'Night Intensity'. The High Beam settings are set to 100% for both day and night. The Low Beam settings are set to 50% for both day and night. On the right side, there are several toggle switches for additional settings: 'Only on when engine running' (checked), 'Off when turn signal active' (unchecked), 'Strobe when Horn active' (checked), 'Strobe on "Flash to pass"' (checked), 'Inverse flashing when hazards active' (checked), and 'Modulation' (unchecked). At the bottom right, there is a 'Three-Wire Dimming Mode' toggle (checked) with a note: 'Disable this mode for two-wire auxiliary LED lights'.

6.2 - Auxiliary Lights One (Pair or Split)

The Auxiliary Light One circuit function enables independent adjustment of high and low beam brightness right from the vehicle's original switches. Available settings include "Off when turn signal active", "Flash when turn signal active", "Strobe when horn active", "Strobe on flash to pass", "Inverse flashing when hazards active" as well as "Modulation". "Three-Wire dimming mode" can be turned off to properly dim LED lights which do not have a dedicated 3rd dimming wire. From the extra settings window you can adjust the "Strobe Intensity" as well as the "Modulation variation".


6. Software Overview (continued)

Auxiliary Lights Two



HIGH BEAM

Day Intensity: 100 %
Night Intensity: 100 %



LOW BEAM

Day Intensity: 50 %
Night Intensity: 50 %


- Only on when engine running
- Off when turn signal active
- Strobe when Horn active
- Strobe on "Flash to pass"
- Inverse flashing when hazards active
- Modulation

Three-Wire Dimming Mode
Disable this mode for two-wire auxiliary LED lights

6.3 - Auxiliary Lights Two (Pair or Split)

The Auxiliary Light Two circuit function enables independent adjustment of high and low beam brightness right from the vehicle's original switches. Available settings include "Off when turn signal active", "Flash when turn signal active", "Strobe when horn active", "Strobe on flash to pass", "Inverse flashing when hazards active" as well as "Modulation". "Three-Wire dimming mode" can be turned off to properly dim LED lights which do not have a dedicated 3rd dimming wire. From the extra settings window you can adjust the "Strobe Intensity" as well as the "Modulation variation".

Auxiliary Brake Light



BRAKE LIGHT

Running Light Intensity: 10 %
Brake Light Intensity: 100 %

- Solid on braking
- Brake Applied Flashing (Continuous)
- Brake Applied Flashing (California legal)
- Flash on Emergency Stop
- Flash on Rapid Engine Braking

6.4 - Auxiliary Brake Light

The feature-rich Auxiliary Brake Light circuit function will transform a simple 2-wire brake light into a "smart brake light" complete with running light, multiple flash patterns, and deceleration activated braking functionality. From the extra settings window you can also adjust the "Brake Flashing Travel Speed" as well as the "Deceleration activated braking sensitivity".

Auxiliary Horn




HORN

Horn enabled

6.5 - Auxiliary Horn

The horn circuit enables the addition of an auxiliary horn without having to add a relay and dedicated horn wiring harness.

Accessory / Ignition Supply



ACCESSORY


10 s Time-out

Accessory Power

6.6 - Accessory

The Accessory circuit function will provide simple switched 12v power to an accessory of your choice when the motorcycles ignition is turned on. Additionally a time-out can be set from 0-60 seconds, which determines how long the accessory circuit will remain on after the motorcycles ignition is turned off. The 3rd "data" wire always turns off instantly with ignition.

Turn Signals



6.7 - Turn Signals

The turn signal circuit enables the addition of an auxiliary turn signals without having to tap into the bikes factory turn signal harness.

Run/Brake/Turn Light




- Flash on Emergency Stop
- Flash on Rapid Engine Braking

6.8 - Run/Brake/Turn

The run/brake/turn signal circuit enables the addition of an auxiliary run brake turn signals complete with flash patterns, all without having to tap into the bikes factory turn signal or brake harness.

Heated Gear




6.9 - Heated Gear

The heated gear signal circuit enables heated gear to work in conjunction with the motorcycles factory heated grip settings. The temperature of the heated gear can be adjusted from 0%-100% for each stage the motorcycle has for the factory heated grips.

6.10 - Where To Download The Software

The CANsmart™ Accessory Manager Software is available for both Windows and Mac operating systems. To download your copy please visit WWW.DENALIELECTRONICS.COM/BMW




6.11 - Connecting The Device To The Software

- Step One:** Remove the protective cap from micro USB port on the end of the CANsmart™ Controller.
- Step Two:** Plug the provided programming cable into the CANsmart™ Controller, and plug the other end into your computers USB port.
- Step Three:** Open the CANsmart Accessory Manger Software and turn the motorcycle's ignition to the "ON" position.

Controlling Accessories From The Motorcycle

Auxiliary Light Set One	
On/Off	Press and hold turn signal cancel button for 3 seconds.
Enter WonderWheel Dimming Mode	Hold "WonderWheel" left for 3 seconds.
Adjust Intensity	Scroll "WonderWheel" up/down to adjust between 0% to 100%.
Exit WonderWheel Dimming Mode	Hold "WonderWheel" left for 1 second or wait for 5 second time out.
Auxiliary Light Set Two	
On/Off	Rapidly press turn signal cancel button 3 times.
Enter WonderWheel Dimming Mode	Hold "WonderWheel" right for 3 seconds.
Adjust Intensity	Scroll "WonderWheel" up/down to adjust between 0% to 100%.
Exit WonderWheel Dimming Mode	Hold "WonderWheel" right for 1 second or wait for 5 second time out.
Auxiliary Horn	
Sound Auxiliary Horn	Press vehicle's original horn button.
Auxiliary Brake Light	
Activate Auxiliary Brake Light	Apply vehicle's front or rear brakes. (Can be set to flash upon deceleration.)

8. Troubleshooting Guide

 Diagnostics
✕

Output Circuits

Red Circuit

Average: 0.00 A

Peak: 0.00 A

Blue Circuit

Average: 0.00 A

Peak: 0.00 A

Yellow Circuit

Average: 0.00 A

Peak: 0.00 A


White Circuit

Average: 0.00 A


Peak: 0.00 A

Output Circuit Test


Red Circuit




Blue Circuit



Yellow Circuit



White Circuit



Use the sliders to test circuits. Closing the diagnostics window will revert back to normal operation.

Horn and Accessory circuits can only be turned on at 100% intensity

System

Temperature

26.5 °C

Battery Voltage

0.00 V

Switch State

Open

Horn Input Voltage

0.00 V

CANBUS data

Inactive

Messages

Device not connected to battery. Please check connection and physical fuse.

No CAN bus data detected. This could be due to a faulty connection or ignition is off.

8.1 - Diagnostics Windows

The Diagnostics Window can be opened from the main menu. Use this window to get an overall view of the systems power consumption, as well as Battery/CAN bus voltage and device temperature.

Each circuit can be tested by sliding the slider underneath the circuit name. The unit must be connected to the battery or another source of 12V DC power in order to use the circuit test feature. The circuits will revert to normal operation when the diagnostics window is closed.

CANsmart™ Status Indicator Light Key

LED Color	Status	Solution
Solid Green	Normal operation, no errors present. (Vehicle Ignition ON)	N/A
Slow Flashing Green	Normal operation, no errors present. (Vehicle Ignition OFF)	N/A
Quick Flashing Green	Bootloader Mode (Should only be seen during firmware upgrade)	Connect to software, should reset into normal operation
Solid Red	Recovered from a unexpected failure	Connect to software, should attempt to reset to normal operation. Please report the exact circumstances to DENALI for analysis.
Flashing Red	At least one channels electronics fuse has been tripped.	Check/Increase fuse settings, cycle ignition to reset electronic fuses
Solid Green & Flashing Red	Application Firmware Corrupt	Connect to software, should offer an upgrade/recovery
Solid Red & Solid Green	Device has been deactivated	Return to DENALI for analysis. Please send log files info@DENALIElectronic.com for analysis by DENALI.
Flashing Red & Flashing Green	Data/configuration fault. (missing CAN bus data)	Check that the correct CAN bus connector was used. If the problem persists please send log files to info@DENALIElectronics.com for analysis by DENALI

8.2 - Status Indicator Light

The CANsmart controller features a LED status indicator light, the light is located next to the micro USB programming port. The chart above defines each of the LED colors/flash patterns, and provides possible solutions to any faults that are present in the system.

8.3 - Online Trouble Shooting Guide

For the most up to date comprehensive trouble shooting guide, please visit DENALIElectronics.com/BMW