


Bonsenkitchen

Hand Blender Operation Instructions

Model: HB3203



Read this booklet thoroughly before using and save it for future reference

www.bonsenkitchen.com

Contents

IMPORTANT SAFEGUARDS	1-2
PARTS & ACCESSORIES	3
TECHNICAL DATA	4
PACKAGE CONTENTS	4
USING YOUR IMMERSION HAND BLENDER	5-13
· IMMERSION HAND BLENDER CONTROLS	5
· OPERATING INSTRUCTION FOR BLENDER	5-7
· OPERATING INSTRUCTION FOR EGG WHISK	7-9
· OPERATING INSTRUCTION FOR CHOPPER	10-13
PROCESSING GUIDE	14
PROCESSING GUIDE	15
RECOMMENDED USE CHART	16-17
CLEANING AND MAINTENANCE	17
QUICK CLEANING	18
TROUBLE SHOOTINGS	18
WARRANTY CLAIM PROCEDURE	19

IMPORTANT SAFEGUARDS


Like any electrical appliance, the Immersion Hand Blender must be handled with care at all times. To ensure your own safety, the following precautions should be followed.

1. **BEFORE USING YOUR IMMERSION HAND BLENDER, READ ALL INSTRUCTIONS CAREFULLY.**
2. This product is not intended for people (including children) who are physically impaired, have sensory or mental disabilities, or lack relevant experience and knowledge, unless someone responsible for their safety supervises or directs their use of the product.
3. Keep the product and its cables out of the reach of children.
4. The product is intended for home use. It is not intended for commercial use.
5. Please check if the voltage marked on the product matches the local power supply voltage, before connecting the product to the power supply.
6. Keep power cord away from hot surfaces, sharp objects, or open fire.
7. Do not use this product if the plug, power cord, or product is damaged.
8. Do not submerge the power cord in water.
9. Do not let cord hang over the edge of a table or counter, touch hot surfaces, or become knotted, trapped or pinched.
10. Pulling or stumbling over the power cord can result in tilting over or falling of the appliance, causing serious injury.
11. If this appliance begins to malfunction during use, immediately unplug the cord.
12. Always insert the attachment first, then plug cord into the outlet. To disconnect, switch the appliance off, then remove plug from the wall outlet.
13. Always unplug the appliance from power supply if you leave it unattended. After use and before cleaning, always switch off the appliance and disconnect it from power supply by taking the power cord connector out of the electric socket.
14. Do not immerse the MAIN BODY in water. To protect against electrical shock, do not immerse the cord, power plug, or appliance in any liquid, do not rinse under the tap.
15. Never use the appliance for any other purpose than what is described in this instruction book.
16. For indoor use only. Not intended for outdoor use.






17. The product must be allowed to cool before cleaning.
18. Be careful when handling and cleaning the blades. They are very sharp.
19. Always turn off the appliance and disconnect it from power socket by pulling the power cord, before doing any of the following: replacing accessories or accessible parts that move during operation, cleaning or maintenance, and assembly and disassembly.
20. If the processed food starts to stick to the appliance (e.g. on BLADE, WHISK) , switch off the appliance and clean the accessories carefully .
21. Never insert e.g. fingers, fork, knife, spatula, spoon into rotating parts of the appliance or the accessories.
22. Before you remove the appliance or the drive unit from the container, let the rotating parts stop completely.
23. Make sure that your hair, clothes and accessories do not get into close vicinity to the rotating parts.
24. Make sure that the power supply cable does not get between the rotating parts of the accessories.
25. Do not process food at a temperature exceeding about 176°F Foodstuffs should not be too hot, as splattering contents may cause scalding.
26. Do not wind the power cord around the appliance, this will reduce its life.
27. This appliance has a polarized plug (one blade is wider than another). To reduce the risk of electric shock, this plug will fit only one way into a polarized outlet. If the plug does not completely fit in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not modify the plug in any way.
28. If the supply cord is damaged it must be replaced by the manufacturer or a authorized service agent or a qualified technician in order to avoid a hazard
29. The appliance cannot be used for chopping ice or blending hard and dry substance , other wise the blade could be blunted.
30. To reduce the risk of injury , never place cutting blade on base without first putting bowl properly in place
31. The use of accessory not recommended by the manufacturer maycause Injuries to persons.
32. Always remove the blade assembly before pouring contents from beaker.
33. Be sure chopper lid is securely locked in place before operating appliance.

SAVE THESE INSTRUCTIONS FOR HOUSEHOLD USE ONLY

PARTS & ACCESSORIES



- 1.SPEED DIAL
- 2.POWER BUTTON
- 3.TURBO BUTTON
- 4.MAIN BODY
- 5.RELEASE BUTTON
- 6.BLENDER STICK COLLAR
- 7.BLENDER STICK



TECHNICAL DATA

MODEL NO.	HB005-A (HB3203)
POWER	120VAC 60Hz 500W
PRODUCT SIZE	6.77x2.17inches (172x55mm)
NET WEIGHTT	2.73lbs (1.24kg)


PACKAGE CONTENTS

ITEM	QUANTITY
MAIN BODY	1 PC
BLENDER STICK	1 PC
EGG WHISK COLLAR	1 PC
EGG WHISK	1 PC
BEAKER (AS)	1 PC
MANUAL	1 PC
CHOPPER (AS)	1 PC

USING YOUR IMMERSION HAND BLENDER

Before the first use, clean the blender according to the section of “Quick cleaning”.

The maximum operation time should be less than 1 minute each time, and a 30-minute rest time must be maintained after 5 consecutive cycles (one minute of work and one minute of stop is one cycle).

 **WARNING:** Sharp blade on BLENDER STICK! Handle with extreme care.

IMMERSION HAND BLENDER CONTROLS

1.SPEED DIAL


Adjusts the blending speed from 1 to 20.
(With the POWER BUTTON pressed)

2.POWER BUTTON

Press and hold to use the Immersion Hand Blender. To stop blending, release button.

3.TURBO BUTTON


Press and hold to use maximum power. To stop blending, release button.




OPERATING INSTRUCTION FOR BLENDER

1: Place food into the BEAKER.


Note: When blending the carrots, cut the carrots into small pieces and put them in BEAKER, then add the water (the ratio of carrots to water is 2:3).




2: Align the MAIN BODY with the BLENDER STICK and push the pieces together until you hear and feel them click together. It may be helpful to press the RELEASE BUTTON when assembling.




3: Plug the Power Cord into power outlet.




4: Lower the blender into food. Then press and hold the low speed button or high speed button to start operating.




5: To stop the blender by releasing the low speed button or high speed button.



6: Unplug the Power Cord from the power outlet.




7: To remove, press the RELEASE BUTTON and unplug the BLENDER STICK.




OPERATING INSTRUCTION FOR EGG WHISK

8: When stirring food in non-standard containers (such as: pots or glass bowls, etc.), the knife head can not be exposed to the level of the liquid, otherwise the food liquid will splash.




Note: Items such as pots or glass bowls for operating demonstrations." For operational demonstration only, not standard with the product"


1: Put the egg whites into the cup , usually two egg whites are enough.




2.1: Insert the EGG WHISK into the EGG WHISK COLLAR . Ensure that the ribs on the EGG WHISK are aligned with the slots in the hole. Press firmly until you here a "click" and check EGG WHISK is locked into place.




2.2: Align the MAIN BODY with the EGG WHISK and push the pieces together until you hear and feel them click together.




3: Plug the Power Cord into power outlet.




4: Lower the EGG WHISK into food.




5: Then press and hold the low speed button or high speed button to start operating.




6: To stop the EGG WHISK by releasing the low speed button or high speed button of the motor unit.



7: Unplug the Power Cord from the power outlet.



8: To remove, press the RELEASE BUTTON and unplug the BLENDER STICK COLLAR.




OPERATING INSTRUCTION FOR CHOPPER

1: Place the BLADE on the center pin of the CHOPPER BOWL. Press down the BLADE and lock CHOPPER BOWL.


NOTE: Always place the CHOPPER BOWL on the anti-slip base.

NOTE: To reduce the risk of injury, never place BLADE on CHOPPER BOWL without first putting CHOPPER BOWL properly in place.




2: Place the food in the CHOPPER BOWL.


NOTE: Debone the meat and cut it into small pieces, then place the meat in CHOPPER BOWL. The maximum amount of meat per blending cannot exceed 16 ounces.



3: Rotate the CHOPPER LID clockwise to fit into the CHOPPER BOWL.




4: Insert the MAIN BODY into the hole of the CHOPPER LID until it locks.



5: Plug the Power Cord into power outlet.

NOTE: Do not lift the **BLADE** before the chopping operation has completely finished.




6: Press and hold the low speed button or high speed button to start operating.




WARNING

Do not operate the blender for longer than 60 seconds at a time. Failure to do so can result in overheating.


NOTE: Be sure **CHOPPER LID** is securely locked in place before operating blender.




7: To stop the chopper by releasing the low speed button or high speed button.



8: Plug the Power Cord into power outlet.




9: Press the RELEASE BUTTON and unplug the MAIN BODY.



10: Open the CHOPPER LID by turning it in anti-clockwise and remove the chopped food.

NOTE: Rotates counter-clockwise when opened.




























PROCESSING GUIDE

(FOR 500ML CHOPPER BOWL)

Food		Maximum	Operation
Meat		250g	15sec
Herbs		50g	10sec
Nut, Almonds		150g	15sec
Cheese		100g	10sec
Bread		80g	10sec
Onions		200g	10sec
Biscuits		150g	10sec
Soft fruit		200g	10sec
Yeast dough	Flour	250g	10sec
	Water	165g	
	Cream	2.5g	
	Power	1.0g	
	Sugar	1.5g	

PROCESSING GUIDE (FOR 700ML BEAKER)

			 MIN-MAX	 00:00	
 			200-300 g	60 s	
			200-300 g	60 s	
			200-300 g	60 s	
			1 x 0	60 s	
			200-300 g	60 s	
			200-300 g	60 s	

RECOMMENDED USE CHART

Refer to the table below for guide on recommended use for different food types

ACCESSORY	USEFUL FOR
BLENDER STICK	Soups Sauces Mayonnaise Smoothies Milkshakes Baby food
EGG WHISK	Whipped cream Whipped egg whites Vinaigrettes Pancake and crepe batters
CHOPPER	Meat Herbs Nut Cheese Bread Onions Biscuits Soft fruit

CLEANING AND MAINTENANCE



NOTE: Do not immerse the MAIN BODY in water.



NOTE: Do not immerse the detachable stem of the blender in water because overtime the lubrication on the bearings may wash away.












This appliance requires little maintenance. It contains no user serviceable parts. Do not try to repair it yourself. Contact the Customer Service Department for any unusual issues you may experience.

1. Always unplug the Immersion Hand Blender before cleaning.
2. Ensure the Immersion Hand Blender has cooled down before cleaning.
3. Be very careful when cleaning BLENDER STICK blades, the blades are very sharp.
4. To clean MAIN BODY, wipe down with a clean, damp cloth and dry thoroughly after every use. Never submerge in water or other liquids. DO NOT place BLENDER STICK COLLAR OR EGG WHISK COLLAR or CHOPPER LID in water.

5. Never use harsh chemical detergents, powder or scouring pads on any of the parts.
6. To clean all detachable parts and accessories, wipe with a soft cloth and a mild detergent before rinsing again. Soak in hot water for a few hours for easy cleaning. Then wipe down with a damp cloth and allow to dry.
7. Do not place the Immersion Hand Blender, or any of its attachments in the dishwasher, as this will damage internal components. Do not use abrasive cleaners.
8. Store Immersion Hand Blender in a clean, dry place.
9. Contact Customer Service for any issues or malfunctions.

Quick cleaning

Between processing tasks, hold the hand blender in the beaker half filled with water and turn on for a few seconds.

			
	✓	✗	✗
	✓	✗	✗
	✓	✗	✗
	✓	✓	✓
	✓	✓	✓
	✓	✗	✗
	✓	✓	✓
	✓	✓	✓

TROUBLE SHOOTINGS

Problem	Case of problem	Solution
The machine doesn't work	The whole machine does not work and has no power.	Check whether the power cord plug position, pressed in place to check whether to send the opening.
	The mixing rod and the MAIN BODY can not be assembled.	Check the mixingrod and the MAIN BODY need to be aligned with the silk screen solution position and the knob is in place as required .
	The chopper and the MAIN BODY cannot be assembled.	Check whether there is debris in the CHOPPER LID,if not,check whether the position of the MAIN BODY is aligned with the slot on the CHOPPER LID and fit in place.It can work when it is in place.

WARRANTY CLAIM PROCEDURE

To ensure quick processing of your case, please observe the following instructions: Please have the till receipt and the item number (S/N: 1 2345) available as proof of purchase.

You will find the item number as a sticker on the rear or bottom of the appliance.

If malfunctions or other defects occur, please contact our customer service listed either by telephone or by email.

If you request any further assistance, please contact us:

Customer service: customer-service@bonsenoa.com

ENVIRONMENT FRIENDLY DISPOSAL

Disposal:

This product must not be disposed together with the domestic waste. This product has to be disposed at an authorized place for recycling of electrical and electronic appliances. By collecting and recycling waste, you help save natural resources, and make sure the product is disposed in an environmental friendly and health way.

Directives:



The packaging materials have been selected for their environmental friendliness and ease of disposal and are therefore recyclable.

Dispose of packaging materials that are no longer needed in accordance with applicable local regulations.

Bonsenkitchen

Manufacture: Bonsen Electronics Limited

 : No.11-12, Lun Pin Chong Industrial Zone San Tun Community, Hou Jie Town 523941 Dongguan City, Guangdong PEOPLE'S REPUBLIC OF CHINA

 : customer-service@bonsenoa.com