# YOST-PVISES

Thank you for choosing a Yost Vise. For future reference please record the following:

Model #:	M9WW
Purchase Date:	
Supplier:	

Inspection and Acceptance

Claims for damage, shortage or errors in shipping must be reported within one (1) day following delivery to Buyer. Buyer shall have seven (7) days from the date Buyer receives any products to inspect such products and services for defects and nonconformance which are not due to damage, shortage or errors in shipping and notify Seller, in writing, of any defects, nonconformance or rejection of such products. After such seven (7) day period, Buyer shall be deemed to have irrevocably accepted the products, if not previously accepted. After such acceptance, Buyer shall have no right to reject the products for any reason or to revoke acceptance. Buyer hereby agrees that such seven (7) day period is a reasonable amount of time for such inspection and revocation. Buyer shall have no right to order any change or modification to any product or services previously ordered by Buyer or its representatives or cancel any order without Seller's written consent and payment to Seller of all charges, expenses, commissions and reasonable profits owed to or incurred by Seller. Specially fabricated or ordered items may not be canceled or returned, and no refund will be made. The sole and exclusive remedy for merchandise alleged to be defective in workmanship or material would be the replacement of the merchandise subject to the manufacturer's inspection and warranty.

#### Product Specifications:

1. Technical Statistics:

Model	Item	Jaw	Jaw	Pipe	Throat	
Number	Number	Width	Opening	<b>Capacity</b>	<u>Depth</u>	<u>Weight</u>
M9WW	20019	9"	10"	N.A.	4"	31 lbs

#### **IMPORTANT SAFETY INSTRUCTIONS**

Warnings: Misuse of vises can cause serious injury to eyes, hands and or other body parts. Vises must be set up and used properly. Before setup and use, read, understand and follow all instructions outlined below.

ALWAYS use proper nuts, bolts and lock washers in all mounting holes, to hold bench vise down.

ALWAYS make sure bench

tops are properly secured.

ALWAYS use vise of proper size and capacity to hold work object.

ALWAYS wear eye, face, and ear protection when striking or using power tools with a vise.

ALWAYS wear dust mask or respirator when working with wood, metal, chemical dusts or mists.

ALWAYS wear restrictive hair covering and anti slip footwear while operating vise.

ALWAYS hand tighten handles of lockdowns for swivel base.

ALWAYS inspect vise for stress fatigue or damage to the vise before using.

ALWAYS maintain the vise – grease main screw regularly.

NEVER use a hammer, extension pipe, or cheater bar on spindle handle of vise.

NEVER unscrew movable jaw beyond maximum specified opening of vise.

NEVER weld base of vise to any metal object.

NEVER use a vise to press an object into or out of another object.

NEVER use and extension pipe to tighten handles of lockdowns.

NEVER place pressurized containers or combustible materials in vise.

NEVER wear loose clothing or jewelry while operating vise.

N E V E R apply extreme heat or prolong heat to the vise as it may alter structural properties.

If there is any question about a condition being safe or unsafe, do not operate the vise.

#### **Mounting Instructions:**

- With the help of another person, hold the vise up against the workbench in the desired location. Mark the mountings holes with a pencil.
- 2. If the workbench is less than 2-1/4" thick, use a shim, as shown in figure 2, to adjust the workbench to 3-1/2" thick.
- **3.** Use a 1/8" drill bit for drilling pilot holes into the workbench for the Wood Screws.
- **4.** Use a <sup>1</sup>/<sub>4</sub>" drill bit for drilling pilot holes in the work bench for the Lag Screws
- 5. Using the two woodscrews (#10 x 2") mount the vise to the workbench.
- 6. Reinforce the vise to the workbench with the 4 lag screws (5/16" x 1-3/4" Lag screw and 5/16" Washer)
- 7. If you are using a shim make sure that the lag screws go completely through the shim and into the workbench.






Figure 1 – Mounting Vise to Work Bench





(Mounting Hardware not included)


## **Operating Instructions:**

- **1.** To open the vise turn the vise handle counter clockwise. This will move the front jaw away from the stationary jaw.
- **2.** To close the vise, turn the vise handle clockwise. This will move the front jaw closer to the stationary jaw
- **3.** To use the quick release feature of this vise, move the lever toward the vise handle. This will disengage the nut and allow you to quickly open or close the vise.
- **4.** The bench dog can be moved in position by loosening the finger bolt on the front of the vise.

## Maintaining your Vise:

- **1.** Apply dry graphite or silicon based lubricant to the main screw to keep it operating smoothly and prevents any sawdust from building up in the threads.
- **2.** If saw dust does build up on the vise threads, use a blade or bit cleaner to remove the built up dust.

# <u>Parts List:</u>



1	Flat Coil Spring	M9WW-1
2	Nut	M9WW-2
3	Back Jaw	M9WW-3
4	Front Jaw	M9WW-4
5	Guide Rod (2)	M9WW-5
6	Main Screw	M9WW-6
7	Torsion Bar	M9WW-7
8	Back Stop	M9WW-8
9	Main Handle	M9WW-9
10	Balled End (2)	M9WW-10
11	Retaining Rod	M9WW-11

12	Pin	M9WW-12
13	Finger Bolt	M9WW-13
14	Vise Dog	M9WW-14
15	Lever	M9WW-15
16	Washer	M9WW-16
17	Cotter Pin	M9WW-17
18	Washer -Wavy	M9WW-18
19	Hex Bolt (2)	M9WW-19
20	Washer (2)	M9WW-20
21	Half Nut	M9WW-21
22	Nut Housing	M9WW-22