



# MANUAL

CE

We meet the SJ/T 31049-1994 Standard after the quality inspection.

Read and Understand the manual before operating the cart.

# Preface

Dear Users,

Many thanks for purchasing our company 's electric cars while adopting advanced technology of Europe and the US and main imported components, the cars are also with the innovative design, luxury professional painting and high strength steel welding material ,all of which make our cars look fashionable, reliable, beautiful and excellent in performance. With light weight, strong climbing ability, low noise , convenient charging, good braking performance and reasonable price, our cars are the most advanced in the electric car field at present.

In order to help users operate and maintain the car correctly,make the car play the best performance and length its working time,hereby we make the operation manual. Please read it carefully.

The product is always in improving. If the manual doesn't match with the real product,the real product is the standard.

Reproduction without permission is prohibited.

# IMPORTANT MANUAL INFORMATION

Particularly important information is distinguished by using the following symbols and notes :



**THE SAFETY ALERT SYMBOL  
ATTENTION ! BE ALERT ! YOUR  
SAFETY IS INVOLVED!**

**! WARNING**

Failure to follow WARNING instructions could result in severe injury or death to the golf car passengers , bystanders, or the person driving the golf car .

**CAUTION**

This message describes special precautions that must be taken so as to avoid damage to the car.

**NOTE:**

This message provides additional main information .

**NOTE:**

Ecar Golf continually seeks improvement in product quality. Even though this manual contains the latest product information available at the time of printing , there may be minor discrepancies between your golf car and this manual . If you have any questions concerning this manual , please contact your Ecar Golf dealer and we will work it out . This manual should be considered a permanent part of your golf cart and should stay with the car when resold .

**! WARNING**

Read and understand the manual completely before operating your golf car .

# Contents

Operation ..... 1-4

Structure & Specifications ..... 5-6

Operation & Control ..... 7-9

Pre-operation Check ..... 10-13

Maintenance ..... 14-23


S8.FA operation and control ..... 24-26

Storage and warranty ..... 27-29

# SAFETY OPERATION

## Before operating :

- 1、 read this manual and all the other operations or labels marked on the car body before operating
- 2、 only authorized people should drive the car only in the designated area
- 3、 do not OVERLOAD
- 4、 do not drive the car if drinking any alcohol or drugs which could distract the driver's vision and judgment




## When operating :

- 1.Keep your body in the car and keep well-seated when the car starts moving
- 2.do not start the car until all passengers are seated
- 3.Keep your hands on the steering wheel and your eyes on the path ahead
- 4.Be especially careful when backing the car incrowded places.Pleasekeep watching your rear and roll back slowly
- 5.Avoid sudden starts and braking
- 6.Please accelerate or decelerate the car according to the road rules
- 7.Do not turn the steering wheel too sharply at high speeds
- 8.Keep driving slowly straight up or straight down, not on an angle when on slopes

Do not overload or make any modification towards spare parts without approval

# IMPORTANT LABELS



①

## OPERATION INSTRUCTIONS

Brake pedal



Accelerator pedal

- Read the manual and safety instruction labels on the golf car before driving .
- Be sure that passengers are seated stably .
- Select “ forward “ or “ reverse “ key .
- Tread the accelerator to start moving ; and tread the parking pedal to stop .
- Please drive safely according to the terrain ,visibility and driving experience ; please drive carefully in the crowded and slippery places .
- When parking , please tread the parking pedal and draw up the handle of hand brake . When starting the car , please release the handle .

②



## WARNING / Avertissement

### EXPLOSIVE GASES



are released when batteries are charged or discharged. Keep well ventilated. Keep sparks, flames and cigarettes away. Shield eyes when working near batteries.



### SULFURIC ACID

in batteries will burn skin, eyes, and clothing. Do not tip battery. Keep vent caps tight and closed. In event of injury, flush with physician immediately.



### ELECTRICAL SHOCKS

can result in burns. Do not make connection between positive and negative battery terminals.

③



## WARNING

- Please read the safety and instruction labels on the steering wheel before operating ;
- No extra passengers can be allowed ;
- Start the car until all passengers are seated well ;
- Drive slow when turning ;
- Tread the parking pedal before leaving the car ;
- Pull the main switch and turn the key off when not using the car ;
- The passengers should be seated stably and hold the armrest tight ;
- Keep hands and feet inside the car .

④



## WARNING



Windshields do not provide protection from other flying objects.


# OPERATION SAFETY

Ecar golf carts are designed to be simple to operate. However, be sure to follow these steps:



## **BEFORE OPERATING:**



1. read this manual and all the other operations or labels marked on the car body before operating.
2. do the pre-operation checks in Section 6 of this manual.
3. only authorized people should drive the car only in the designated area from the owners.
4. do not overload, the cart only has a certain weight limit
5. do not drink any alcohol or have any drugs which could distract the driver's vision and judgement.
6. do not drive the car on public roads, streets, highways etc. Such use is illegal and dangerous, because golf&sightseeing car is kind of off-board vehicle, and collision might happen.



## **WHEN OPERATING:**

1. make sure your body does not stick out of the car, and remain firmly seated when driving.
2. do not start the car until all passengers are seated.




# OPERATION SAFETY



1. keep your hands on the steering wheel and your eyes on the path ahead.
2. be especially careful when backing the car in crowded places. Please keep watching back and roll back slowly.
3. avoid sudden and strong shock to the car and change to the proper speed according to the ground condition.
4. do not turn the steering wheel too sharply when at high speed.
5. keep driving slowly straight up or straight down, not on an angle.
6. Do not make any modification or addition about the operation safety and loading capacity, and this whole manual.



# Structure & Specifications



## Structure:

- |                       |                      |
|-----------------------|----------------------|
| ① Car body            | ⑩ Rear mirror        |
| ② Front windshield    | ⑪ Rear light         |
| ③ Sunroof             | ⑫ Hostess plate      |
| ④ Front turning light | ⑬ Carpet             |
| ⑤ Front bumper        | ⑭ Seat cushion       |
| ⑥ Rear seat handle    | ⑮ Metert             |
| ⑦ Steering wheel      | ⑯ Voltage indicator  |
| ⑧ Front light         | ⑰ Scrape switch      |
| ⑨ Scrape arm          | ⑱ Front light switch |
|                       | ⑲ Key switch         |
|                       | ⑳ Electricity meter  |
|                       | ㉑ DVD                |
|                       | ㉒ Speaker            |
|                       | ㉓ Shaft              |
|                       | ㉔ sicula             |
|                       | ㉕ hand brake handle  |
|                       | ㉖ brake pedal        |
|                       | ㉗ accelerator pedal  |
|                       | ㉘ tire               |

# CONFIGURATION AND SPECIFICATION

Configuration and specification sheet:

Electronic system	controller	Toyota AC Controller		
	battery	Maintenance-Free Gel Batteries 8pcs*6V		
	Motor	AC motor 3.7KW		
	charger	Intelligent charger,input 220V,output 48V,25A		
	Electric accelerator	Input 48V,0-5V output		
Body configuration	Front windshield	2+2 fold windshield	Sunroof	capsule
	Seat	Leather cover	Floor	Antiskid floor mat
	Side mirror	Left&right side each	steering	Two way gear steering system,automatically backlash compensation
	Light&signal	Front light,turning light,rear light,horn,reverse beeper		
	Car body	Fiber glass	chassis	High tensile steel welding structure,electrophoresis treatment for anti-rust
	Meter	Fiber glass dashboard,meter,voltage indicator,mp3 player,speaker,key switch,group switch,mileage		
	Brake system	Front disc rear drum+hand brake		
	Front suspension	Spring+independent hydraulic suspension		
	Rear transaxle&suspension	Transaxle speed rate 12.31:1,semi-independent hydraulic suspension		
	tire	165/70R13 79N		
passenger	8 including driver			

## 1. specification

1.1 dimension:L*W*H	5050*1480*1900mm
1.2 wheelbase	3465mm
1.3 weight(including batter)	860kg
1.4 load capacity	640kg
1.5 max speed	25km/h
1.6 mileage	70-90km/h
1.7 min turning radius	6500mm
1.8 max climbing ability	15%
1.9 min clearance	142mm
1.10 brake distance	≦12m
1.11 tread	front1200mm/rear 1210mm


## 2. battery specification

lead acid battery	
2.1 battery type	216Ah
2.2 volume	48V
2.3 voltage	

## 3. motor specification


DC motor	
3.1 motor type	3.7kw
3.2 rated power	2500r/min
3.3 rated rotating speed	48V
3.4 rated voltage	105A
3.5 rated currency	15min
3.6 ration	

# OPERATION AND CONTROL



## Turning On Main Switch

1. Shifting the switch to RUN position then you can turn on the power supply of car.
2. Shifting the switch to OFF position and then can turn off the power supply of car.




## Key Switch

- 1、 Plugging in the key and turn right then can turn on the key switch (Note:Shifting the F/R switch to the middle position before turning on Main switch).
- 2、 Turning left and then you can turn off the switch. Switch can be removed only at this state.




Completely stop car before shifting F/R switch. When shifting F/R switch, please turn switch to middle position for 2s at first, then Forward switch or Reverse switch. Don't shift F/R switch too quickly in case the sensor will burn out or switch will malfunction.

# OPERATION AND CONTROL



## Combined Switch


includes:horn,side light,wiper switch; End button is horn switch; shifting forward to turn on right side light;shifting backward to turn on left side light;shifting upward to turn on wiper.



## 48V Voltage Indicator


Voltage Indicator is to show the electricity and remains custom to charge on time. The voltage will show fully charged when charging is complete.

- 1、 Electricity display reduces with the consumption of electricity during operation
- 2、 When electricity is close to empty ,a warning signal will show by moving between first space and second space;
- 3、 When electricity enters into under-charger, a warning will display by flashing of first space in left.



## Accelerator Pedal


Turning on the key switch,choosing right gear,then loosening hand brake,putting your foot on accelerator pedal and pressing down slowly. Do not accelerate too fast.



## Hand Brake

After fully stopping car, pull up hand brake about 5-7 gear to release parking function.

# OPERATION AND CONTROL



## Brake Pedal

Press Brake Pedal to reduce speed and stop car.

**Warning:** Avoid braking suddenly.

# PRE OPERATION

Pre-operation checks should be made each time you use your golf car. Get in the habit of performing the following checks in the same way so that they become second nature.

## WARNING

Be sure that the main switch key is removed before performing the pre-operating checks to prevent accidental starting, and apply the parking brake to keep the car from moving.

## PRE-OPERATION CHECKLIST

Before each use, please check the following

- ✓ Batteries
- ✓ Tire condition
- ✓ Steering system
- ✓ Back-up buzzer
- ✓ Pedal operation
- ✓ Body and chassis

## SEAT

Open the seat for checking and servicing

# PRE OPERATION


## BATTERY

Charge batteries before each use. See charging steps in chapter 6.


Check that the batteries are held securely in place to prevent the batteries from vibration or jarring. Also check that to prevent battery acid from spilling. Check the battery terminals for corrosion.

## TIRE CONDITION

Check the tire air pressure before the operation of car.



Tire pressure  
36PSI




### Tire wear limit

Check the tire surface for damage, cracks or embedded objects. When tire tread wears down to 0.04(1mm),relace the tire.

Ⓐ Wear limit

# PRE OPERATION

## STEERING SYSTEM



Check the steering system for excessive freeplay.

- Moving the steering wheel up and down, and back and forth.
- Turning the steering wheel slightly to the right and left.


If you feel excessive freeplay or hear rattling sounds, which may indicate loose steering components, consult an ecar dealer immediately.

## BACK UP BUZZER

Check the back up buzzer by moving the drive select switch to “REV” for reverse.

## PEDAL OPERATION

Check the following pedal controls for proper operation. If a pedal does not work properly, consult an ecar dealer.



## BRAKE PEDAL

Make sure that the brake pedal feels firm when pressed and returns to its original position when releases.

(B) Brake pedal




# PRE OPERATION

## HAND BRAKE

Make sure that the hand brake has a good parking brake effect.

Ⓒ hand brake




**NOTE** \_\_\_\_\_  
Release the hand brake before pressing on the accelerator pedal.  
\_\_\_\_\_

## WARNING \_\_\_\_\_

Before checking operation of the accelerator pedal, make sure that the main switch is in the "OFF" position.  
\_\_\_\_\_

Make sure that the accelerator pedal operates smoothly.

Ⓐ Accelerator pedal



## BODY AND CHASSIS

Before each use, carefully inspect the car body and chassis for damage and/or missing parts.

# MAINTENANCE

## PERIODIC MAINTENANCE CHARTS

Regular maintenance is required for the best performance and safe operation of your car.



### WARNING

---

Make sure to turn off the main switch and apply the hand brake when you perform maintenance. If you are not familiar with machine serving, this work should be done by a Ecar dealer or other qualified mechanic.

---

# MAINTENANCE

C=Check CA=Check Adjust R=Replace S=Service CL=Clean and Lubricate L=Lubricate

	Remarks	Pre-Operation	20 rounds 20 hours 20 hours 160kms( Every Month)	125 rounds 125 hours 600 miles 1000kms( Every 6	250 rounds 250 hours 1200 miles 1000kms( Every Years)	500 rounds 500 hours 2500 miles 4000kms( Every 2 Years)	1000 rounds 1000 hours 5000 miles 8000kms (Every 4	Page
Pre-Operation	Charge	S	S	S	S	S	S	8-5
	Clean Battery tops, for tightness of hold-down screws and terminals	S	S	S	S	S	S	8-3/6-2
	Check brake pedal freeplay and adjust if necessary	C	CA	CA	CA	CA	CA	8-9/8-10
	Check steering operation	C	C	C	C	C	C	6-3
	Check tire pressure tread depth tire surface for damage	C	CA	CA	CA	CA	CA	6-2
	Check body and chassis, for damage	C	C	C	C	C	C	6-4
	Check tightness of all bolts, nuts and screw	C	C	C	C	C	C	*
	Check reverse buzzer	C	C	C	C	C	C	6-3
Every month	Check electrolyte level		C	C	C	C	C	8-3/8-4
	Check for loose or broken connections		C	C	C	C	C	*
	Clean Lube Pedal control area		CL					*
Every 6 month	Check all wire insulation for crack and/or worn spots			C	C	C	C	*
	Check shock absorbers for oil leaks and damaged springs			C	C	C	C	*
Every year	Perform a discharge test				S	S	S	*
	protectant				S	S	S	*
	Check shoe lining thickness and rear axle beating play				C	C	C	*
	Check steering knuckle bushing freeplay/Adjust wheel alignment				CA	CA	CA	*
	Check wheel nut tightness front wheel bearing play				C	C	C	8-9/*
	Check gear box oil level and leakage				C	C	C	8-8
	Check operation and adjust pedal stop if necessary				CA	CA	CA	*
Every 4 month	Replace gear box oil						R	*
	Check for grease leakage; adjust gear box if						CA	8-8

Items without a page number referene should be serviced by approved agent or qualified technician.

This manual doesn't contain these procedures. They are contained in the Service Manual

# MAINTENANCE

## Battery Care

### WARNING

Battery electrolyte is poisonous and dangerous, causing severe burns, etc. It contains sulfuric acid. Avoid contacting with skin, eyes and clothes.

Antidote:

EXTERNAL: Flush with water

INTERNAL: Drink large quantities of water or milk. Follow with milk of magnesia, beaten egg, or vegetable oil. Call physician immediately.

EYES: Flush with water for 15 minutes and get prompt medical attention.

Batteries produce explosive gases. Keep sparks, flames and cigarettes away.

Make sure it is ventilated when charging or using in enclosed space. Always shield eyes when working near batteries.

### WARNING

## Keep out reach of children.

Batteries provide power for your electric car and must be properly maintained and recharged for maximum performance and service life. The ways to maintain your batteries.

1. Clean the top of the batteries with soda water if necessary to remove corrosion.

### CAUTION

Do not allow cleaning material to enter battery cells.

2. Check the fluid level before and after charging.


# MAINTENANCE

## Before charging:

Only add distilled water. If fluid is below the top of the plates, add just enough to cover plates.

## After charging:

check that the fluid level is appropriately 1/4 to 1/2 inch above the plates and 1/4 to 3/8 inch below the level is low. Add distilled water carefully. Adding distilled water after charging helps prevent boiling over



A Battery cap

B Plates

C Maximum fluid level


D Minimum fluid level

---

Normal tap water contains minerals which are harmful to a battery; therefore, refill only with distilled water.

---

3. Using a hydrometer, check the specific gravity of the battery fluid in each cell against the readings on the chart below. Consult an car dealer if any low readings are found.



Temperature		Satisfactory Hydrometer Reading
° F	° C	
120	48.9	1.244
110	43.3	1.248
100	37.8	1.252
90	32.2	1.256
80	26.7	1.260
70	21.1	1.264
60	15.6	1.268
50	10	1.272
40	4.4	1.276
30	-1.1	1.280

# MAINTENANCE

## BATTERY CHARGING

### WARNING

Read and understand the manual provided with your car's battery charger before charging batteries.

### WARNING

Explosive hydrogen gas is produced while batteries are being charged. Only charge batteries in well ventilated areas(A minimum of 5 air changes per hour is recommended)


Follow the instructions contained in your battery charger's owner's manual to charge the batteries in your car.

The following is a summary of the charging steps. Do not attempt to recharge your car's batteries without thoroughly reading and understanding the manual.

Connect the charger properly with the plug case(see charger's owner's manual).Do not insert the AC output plug into the car directly.

### CAUTION

Use battery chargers that are only used for this car. Thoroughly read and understand the manual.



# MAINTENANCE

## WARNING

Do not disconnect the DC output cord from the battery receptacle when the charger is on because that may cause an explosion.


3.the charger will turn off automatically when the batteries reach full charge.

4.after the charger has turned off , disconnect the DC output plug from the golf car receptacle by grasping the plug body and pulling the plug straight out of the receptacle.

## BATTERY INSTALLATION

### WARNING


When installing the batteries, do not put the wrenches or other metal objects across the battery terminals. An arc can occur causing explosion of the batteries.



1.install the battery hold down plates as shown

- Ⓐ Forward
- Ⓑ Battery
- Ⓒ battery fitting plates

# MAINTENANCE



2.link the cables as per picture

A) front

B) to receptacle

C)to motor control unit

D)between the batteries

## WARNING

When installing the batteries:


- 1.Please carefully place the cables down,making sure the cables not crossover the vent caps
- 2.always remove the negative(-)cable from the motor controller first,and install it at last

## CAUTION

Do not overtighten the battery nuts, too much force will damage the battery case




# MAINTENANCE



check the oil level in the gearbox

## gearbox oil

1. place the car on a flat horizontal level
2. lift the seat
3. remove the oil plug
4. pour in the gear oil slowly until it reaches the opening



recommended oil :  
SAE 90 gearoil

Gearcase capacity :

5. it's fine for oil overflowing.

Make it stop when it flows out


## CAUTION

Foreign objects are forbidden from getting into the gearbox

6. put the oil plug back

## NOTE :

For oil changes, please consult your car dealer or another qualified mechanic.




# MAINTENANCE

## CAUTION

Be sure the main switch is in the "off" position, before you check the wheel or braking system.

## Tire Replacement

For removing or installing a tire:



1. take out the wheel nuts, after the car is completely still.
2. elevate the car with a jack and take out the tire and the screw bolt.
3. use the steps above conversely, when installing the tire

wheel nut tightening torque:

105NM-120NM •

## Braking Adjustment

The brake of this car can be adjusted by yourself.




Please use your foot to press the braking pedal, making sure it has been functioning properly

## ⚠ WARNING

Consult your Ecar dealer before using the car, if you have any problem with the brake. Because serious accident would be caused from brake failure.

# MAINTENANCE

## Brake system: free adjustment



### CAUTION

Before adjusting the brake , tread the brake pedal several times to adjust the brakes .

To adjust the brake distance :

1. Remove the cover of the dash board
2. Check the brake pedal by pressing with two fingers with proper force and measuring the forwarding distance of the pedal until resistance is felt .


Brake pedal forwarding distance :  
85-95mm ( 3.35-3.74 inch)

3. If the brake system doesn't work well , you should tread the brake pedal more to exhaust the air in the oil tube .

### WARNING

Do not loosen the brake cables because of air leakage , which will also affect the brake adjustment and result in the braking malfunction .


# Structure & Specifications



## Structure:

- |                       |                 |                          |
|-----------------------|-----------------|--------------------------|
| ① Car body            | ⑩ Side light    | ⑱ Forward/reverse switch |
| ② Front windshield    | ⑪ Scrape arm    | ⑲ Forward/reverse switch |
| ③ Sunroof             | ⑫ Rear mirror   | ⑳ Front light switch     |
| ④ Front turning light | ⑬ Rear light    | ㉑ Key switch             |
| ⑤ Front bumper        | ⑭ Hostess plate | ㉒ Electricity meter      |
| ⑥ Rear seat handle    | ⑮ Carpet        | ㉓ DVD                    |
| ⑦ Steering wheel      |                 | ㉔ Speaker                |
| ⑧ Front turning light |                 | ㉕ Group switch           |
| ⑨ Decoration horn     |                 | ㉖ sicula                 |
|                       |                 | ㉗ hand brake handle      |
|                       |                 | ㉘ brake pedal            |
|                       |                 | ㉙ accelerator pedal      |
|                       |                 | ㉚ tire                   |
|                       |                 | ㉛ scrape switch          |


# OPERATION AND CONTROL



## Turning On Main Switch

1, Shifting the switch to the RUN position then can turn on the power supply of car.


2, Shifting the switch to OFF position turns off the power supply of car.



## Key Switch

1、 Plugging in the key and turn right then can turn on the key switch (Note: Shifting the F/R switch to the middle position before turning on Main switch).

2、 Turning left and then can turn off the switch. Switch can be removed only at this state.




## Forward/Reverse Switch

The Forward/Reverse Switch is used to shift the car to forward, reverse or stop. Forward for upward, Reverse for downward, Park for middle. When choosing reverse switch, the reverse buzzer sounds.




Completely stopping car before shifting F/R switch. When shifting F/R switch, please turn switch to middle position for 2s at first, then choosing Forward switch or Reverse switch. Don't shifting F/R switch in a hurry in case that the sensor will be burnt or switch will be out of use.

# OPERATION AND CONTROL



## Combined Switch

includes:horn,side light,wiper switch;  
End button is horn switch;shifting  
forward to turn on right side  
light;shifting backward to turn on left  
side light;shifting upward to turn on  
wiper.




## 48V Voltage Indicator

Voltage Indicator is to show the charge and.  
The voltage will shows fully charged  
when charging is complete.

1、 Charging indicator display reduces  
throughout cart operation


2、 When electricity is close to empty  
a warning light will show by moving  
between first space and second space;

3、 When electricity enters into under-  
electricity warning, it will display by  
flashing of first space



## Scrape switch

Press on the Scrape switch to enable the  
scrape work.



## Accelerator Pedal

Turning on the key switch, choosing  
correct gear, then loosening hand brake,  
putting your foot on accelerator pedal and  
pressing down slowly. Do not accelerate too  
fast.

# STORAGE

Perform the following prepararions when leaving your golf car unused for a long time:

NOTE :

Turn the main switch key to the “OFF” position , remove the key , and put it in a safe place .

## CHASSIS PREPARATION

1. Verify the air pressure of the tire is 51 psi ( 36psi);
2. Clean the outside of the car with anti-rust oil;
3. Cover the car and store it in a dry and well-ventilated place.

## BATTERY PREPARATION

- 1.Recharge the batteries and check the fluid levels at least once a month .
- 2.Disconnect cables in case of long storage

## CAUTION

Cleaning products are forbidden to put into battery cells

3. Clean the top of the batteries with baking soda and water so as to avoid errosion.

# WARRANTY AND AFTER-SALES SERVICE

Please read the following carefully for your interest and good after sales service from us.

## What is under warranty and valid date

Please read this instruction book carefully after you buy a car from us. We promise to change or repair for material quality or design problems.

## Objects & Content

### After the car is delivered from our factory

- 1 We do free repair services as per our standard warranty
- 2 Please contact us for universal parts, like tyres, seats, which are out of warranty.
- 3 We will send technicians if there is a serious quality problem.
- 4 provide long-term after sales service when warranty date is invalid

### Below conditions are not under warranty

- 1 Do not do as per instruction book
- 2 Repair car in places which are not approved by us
- 3 Out of warranty
- 4 Use spare part from other manufacturers
- 5 Assemble or modify without our permission
- 6 Overload weight capacity
- 7 Natural disasters like typhoon, flood, earthquake, etc



# WARRANTY AND AFTER-SALES SERVICE

## Valid Warranty

Buyers need to fill warranty card, stamp and return to us. The warranty comes into effect once we receive and confirm.

Any damage caused by improper action, which does not match instruction book, we will not accept as warranty.

ECAR GOLF

7/42 Export Drive

Molendinar, 4214

Queensland, Australia

[www.ecargolf.com.au](http://www.ecargolf.com.au)

E-MAIL: [info@ecaraustralia.com.au](mailto:info@ecaraustralia.com.au)