

DIY Kit Product

Operating Instructions

套件产品操作说明书

深圳市鑫力能电子有限公司


SHENZHEN EEL BATTERY CO.,LTD

地址：广东省深圳市龙岗区横岗街道银信中心 E 座 1403 室

Add: Room 1403, Yinxin Center E Block, Henggang Street, Longgang District, Shenzhen, Guangdong, China.

Battery Kit Operation	3
Upper Computer Operation	6
1. Decompress the host computer file	6
2. Open the monitor software	6
1) Open the folder	6
2) select the upper computer software	6
3) double click to open the upper computer ...	6
3. Load protocol file	6
1) Select Import Protocol	6
2) pop up the folder	6
3) select the protocol suffix EN	6
4) click OK	6
4. Communication Port Configuration	8
1) Port number	8
2) Baud rate : 9600	8
3) Click Connect	8
5. Login	9
6. Loading and uploading parameters	9
6.1 Upload Parameters	9
6.2 Modify parameters	10
6.3 Load Parameters	10
7. Communication Protocol Configuration	12
8. Display Interface Introduction	15
9. Parallel Mode	18
10. Firmware update	20
11 .Real Time Record	22

Battery Kit Operation



- 1 Bottom pad**
- 2 BMS screws**
- 3 Bracket screws**

- 4 Case screws**
- 5 Terminal screws**
- 6 Bus bars screws**

- 7 M8 screws for connection**

EEZ:
EELBATTERY



Installation instructions

Step

Figure






Pay attention to the connection sequence of positive and negative poles!

{Refer to next page(P5)}

Parts List

- 1 * Battery Case
(Bottom case, Front Panel, Top Bracket, Front Bracket, Top cover)
- 1 * Battery BMS
- 2 * PCB Board
(for BMS and Cell Connection)
- 1 * Weak electric switch
- 1 * LCD Screen
- 1 * LCD Screen Sticker
- 3 * Wires
(LCD Screen wire, PCB board A and PCB board Connector)
- 2 * Battery Terminals
- 6 * Copper busbars (BMS connection)
- 15 * Flexible busbars (Cell connection)
- 10 * Epoxy sheet (Between cell and the case)
- 26 * EVA Tape (Between cells)





EEV*i*

EELBATTERY



Upper Computer Operation

1. Decompress the host computer file

BatteryMonitor V2.1.8

2. Open the monitor software

- 1) Open the folder
- 2) select the upper computer software
- 3) double click to open the upper computer

Agreement	2022/3/18 9:12	文件夹
BatteryMonitor V2.1.8	2022/3/18 9:13	文件夹
de	2022/3/18 9:12	文件夹
es	2022/3/18 9:12	文件夹
ja	2022/3/18 9:12	文件夹
Languages	2022/3/18 9:12	文件夹
logs	2021/10/21 9:28	文件夹
RealTimeRecord	2021/10/21 9:27	文件夹
ru	2022/3/18 9:12	文件夹
Battery Monitor V2.1.8操作说明.pdf	2021/10/21 8:56	PDF 文件 6,075 KB
BatteryMonitor.exe	2021/10/21 20:12	应用程序 1,785 KB
BatteryMonitor.exe.config	2021/10/20 19:52	XML Configuration... 3 KB
BatteryMonitor.pdb	2021/10/20 20:10	PDB 文件 522 KB
DevExpress.Data.v15.2.dll	2017/11/17 21:43	应用程序扩展 5,082 KB
DevExpress.Data.v15.2.xml	2017/11/17 21:43	XML 文档 1,098 KB
D:\...\BatteryMonitor\BatteryMonitor.exe.manifest	2017/11/17 21:43	应用图标程序 3,221 KB

3. Load protocol file

- 1) Select Import Protocol

See Figure 3-1

- 2) pop up the folder (select *Agreement* in the upper computer folder)

See Figure 3-1

- 3) select the protocol suffix EN in the *Agreement* folder that corresponds to the English protocol (e.g. 16s _ V20 _ ADDR _ EN)

See Figure 3-2

- 4) click **OK**

See Figure 3-3




Figure 3-1




Figure 3-2




Figure 3-3

4. Communication Port Configuration

- 1) **Port number** (the upper computer will automatically identify the USB to 485 serial port number)
- 2) **Baud rate** : 9600
- 3) Click **Connect** (After successful connection, the upper computer displays the battery data.)





Figure 4-1

5. Login

Account: admin
Password: admin




6. Loading parameters and uploading parameters

Load parameter: download parameter to BMS from upper computer

Upload parameter: upload parameter to upper computer from BMS

6.1 Upload Parameters


When you use the upper computer at the first time, **downloading parameters directly without checking is not allowed**, you need to upload the parameters at first and then close them



6.2 Modify parameters



- 1) Click "Upload Parameters" here to upload parameters from BMS
- 2) Change the internal BMS parameters and function switches
- 3) Click **Set all** to enable the modification


Note: The red numbers in the figure below indicate the operation sequence



6.3 Load Parameters

- 1) Click **Load Parameters** (step 1 below)
- 2) Choose the **target parameter document** (step 2 below) and click **open**(step 3 below)
- 3) Click **Set All**(step 4 below)
- 4) Click **Close** (step 5 below)after prompting success
Parameters have been configured OK





7. Communication Protocol Configuration

Click CAN, Select the corresponding CAN protocol according to the inverter type

- 1) 5 options: Pylon / Growatt / Victron / Sofar / Luxpower

Protocol Type	Supported Inverter Brands
Pylon	Pylon/Goodway
Growatt	Growatt
Victron	Victron
Sofar	Sofar
Luxpower	Luxpower

See Figure 7.1

- 2) after switching the protocol, confirm whether the protocol is switched **successfully**, refresh the protection board information

See Figure 7.2

- 3) the corresponding manufacturer information will displayed in “**BMS information**” frame

See Figure 7.3




Figure 7.1




Figure 7.2




Figure 7.3




Figure 7.4(other manufacturer information)

8. Display Interface Introduction

After successful connection, the red box below is the display Interface Introduction

See Figure 8-1

Detailed introduction see Table 8-1




Figure 8-1

Name	Description	Notes	Figure
Max voltage	Highest voltage cell		
Min voltage	Lowest voltage cell		
Voltage difference	Voltage difference between the max voltage and min voltage		

Battery voltage	Battery total voltage		Battery voltage 52.79V
Current	Charge current Or Discharge current (negative value)		Current 0.00A
Remain_capacity	Current battery capacity	Upload parameter-Num59 can set current capacity	Remain_capacity 49.87 Ah
Total_capacity	Actual capacity after full battery		Total_capacity 100.00 Ah
SOC	State of charge	Remain_capacity/Total_capacity*100%	SOC 49.8 %
Nominal_capacity	Rate capacity.	Upload parameter-Num58 can set capacity	Nominal capacity 50.00 Ah
Battery_cycles	Cycle number	The number of cycles will be increased by one when the cumulative discharge capacity reaches 80% of the full capacity	Battery_Cycles 4 times
SOH	state of health		SOH 100.0 %
Bus voltage	Port voltage. Detection of external voltage	When there is no external connection, the bus voltage is equal to the total battery voltage	Bus voltage 52.79 V








Discharge switch	Discharge switch indicator	Green: switch connected Gray: switch disconnected	 Discharge switch
Charge switch	Charge switch indicator	Green: switch connected Gray: switch disconnected	 Charge switch
Current limit switch	Current limit switch indicator	Green: switch connected Gray: switch disconnected	 Current limit switch
Temperature control switch	Temperature control switch indicator	Green: switch connected Gray: switch disconnected	 Temperature control switch
Warn and Protect	BMS warning and protect display area		 Warn and Protect
Battery_Temp1	Cell temperature1 value		 Battery_Temp1 19.5 °C
Battery_Temp2	Cell temperature2 value		 Battery_Temp2 19.9 °C
Battery_Temp3	Cell temperature3 value		 Battery_Temp3 20.0 °C
Battery_Temp4	Cell temperature4 value		 Battery_Temp4 29.1 °C
Ambient_Temp	Ambient temperature value		 Ambient_Temp 22.7 °C
Power_Temp	Power temperature value		 Power_Temp 20.8 °C

Table 8-1

9. Parallel Mode

1) Parallel pack selection

When several batteries (max to 16) are combined, ensure that the corresponding address dialed by the BMS is consistent with the address set (**pack x**) by the upper computer (click the pack number to light up or greyed the icon).

See Figure 9-1

2) When confirming the number of parallel machines, click connect to upper computer and select **Cycle Refresh**. The upper computer can see the number of parallel machines and pack refresh data

See Figure 9-2

3) On the upper computer interface, you can click **Multiple** to see each group of PACK data

See Figure 9-3




Figure 9-1

In figure 9-1, there are 2 pack icons display in the pack frame, this means there are 3 packs in parallel status. Only the slave pack can be displayed in the pack frame.




Figure 9-2





Figure 9-3


10. Firmware update


10.1 Open Firmware Update (BMS boot state)





10.2 Use USB to 485 communication line, select the corresponding port, select the baud rate of 9600, and click Open.

10.3 Select folder —— Jump out of corresponding box —— choice the target program (This program. ehex format)







10.4 Click **download** and the progress bar will appear (When you report an error, try pressing the reset button or downloading it several times)



10.5 after the program upgrade **OK**, prompt download successful proof that the program upgrade OK.



Note: This upgrade software can also be upgraded according to the corresponding address. If the address of BMS is consistent with the address of Pack number, it can be upgraded.



11 .Real Time Record

The real time record will record all the real time information of the battery. The function can be used for automatic monitoring of battery working status

- 1、 Click **Real Time** to enable real time record
See figure 11-1
- 2、 Click **Real Time Record** to edit the detail information

See figure 11-1/11-2/11-3




Figure 11-1

The screenshot shows a 'Real time record' table with 10 rows of data. The columns are: Num, Pack#, Date, Time, Mode, Warn, Cell01(V), Cell02(V), Cell03(V), Cell04(V), Cell05(V), Cell06(V), Cell07(V), Cell08(V), Cell09(V), Cell10(V), Cell11(V), Cell12(V), Cell13(V), Cell14(V), and Cell15(V). The data shows battery voltages for each cell over a period from March 22, 2022, at 11:06:39 to 11:08:59, with all cells consistently showing 3.299V.

Num	Pack#	Date	Time	Mode	Warn	Cell01(V)	Cell02(V)	Cell03(V)	Cell04(V)	Cell05(V)	Cell06(V)	Cell07(V)	Cell08(V)	Cell09(V)	Cell10(V)	Cell11(V)	Cell12(V)	Cell13(V)	Cell14(V)	Cell15(V)
1	0	2022-03-22	11:06:39	Standby	None	3.299	3.300	3.300	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299
2	0	2022-03-22	11:08:41	Standby	None	3.299	3.300	3.300	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299
3	0	2022-03-22	11:08:44	Standby	None	3.299	3.299	3.300	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299
4	0	2022-03-22	11:08:46	Standby	None	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299
5	0	2022-03-22	11:08:48	Standby	None	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299
6	0	2022-03-22	11:08:50	Standby	None	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299
7	0	2022-03-22	11:08:52	Standby	None	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299
8	0	2022-03-22	11:08:55	Standby	None	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299
9	0	2022-03-22	11:08:57	Standby	None	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299
10	0	2022-03-22	11:08:59	Standby	None	3.299	3.299	3.300	3.300	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299	3.299

Figure 11-2

Click **STOP** to stop record.




Figure 11-3

Click **RUN** to record again.

Click **Clear** to empty the record frame.

Click **Save** to export the record document.