


HYDRA KOOL





3560 NW 56th Street
Fort Lauderdale, FL 33309
Tel.: 786.600.4687 / Toll Free: 844.218.8477
Fax.: 786.661.4100

5659 Royalmount Avenue
Montreal, Qc, Canada H4P 2P9
Tel.: 514.737.9701 / Toll Free: 888.275.4538
Fax.: 514.342.3854 / Toll Free: 877.453.8832

INDEX

1	General information	5
1.1	Case description	5
2	Getting started with your KGL Overunder series	11
2.1	Location	11
2.2	Uncrating	12
2.3	Check for damage	13
2.4	Control panel and main features	14
2.5	Check serial, model numbers and requested options	15
2.6	Warning/Caution labels	16
2.7	Check your electrical installation	19
2.8	Plugging and start	19
3	Refrigeration	22
3.1	Self contained refrigeration equipment and defrost	22
4	Electrical	24
4.1	Electrical specifications data	24
4.2	Electrical diagrams	25
4.3	Electronic controller	27
5	Maintenance	30
5.1	Exterior cleaning	30
5.2	Interior cleaning	31
5.3	Shelf removing/adjustment	31
5.4	Sliding doors removal	32
5.5	Light substitution	32
5.6	Panels and protection grill removal	33
5.7	Condensator cleaning	33
5.8	Evaporator cleaning	34
5.9	Evap Pan cleaning	35
6	Troubleshooting/Service	36
6.1	Troubleshooting	36
6.2	Service	37
7	Warranty	39
8	Notes	40

This page has been left blank intentionally.

1 General information

1.1 Case description

KGL Overunder series model (number) system.

KGL OF 40 S

AAA BB CC D

AAA

BB

CC

D

Basic model

Model variation

Length

Type of Unit.

KGL

OU-Overunder

40"


S-Self Contained

50"

60"

80"

KGL Overunder Series



KGL-OU-S



KGL-OU-S

Implantation




Drain outlet




Electrical board




Refrigeration piping




KGL-OU-40-S



KGL-OU-50-S



KGL-OU-60-S



KGL-OU-80-S
















KGL Overunder series intended to multipurpose, are type 1 equipment - 75°F/55%RH. Temperature for both compartments is set for 36°F, having has standard option the possibility during service to transform the upper compartment in dry mode. The shelves on the upper compartment have a 5,5 lb/ft² loading limit. The shelves on the lower compartment have a 31 lb/ft² loading limit.

Model	Dimensions (LxDxH in inches)	Service dimensions (LxDxH in inches)	Volume (ft ³)
KGL-OU-40-S	35 ⁷ / ₈ " x 39 ⁹ / ₁₆ " x 59 ¹ / ₄ "	35 ⁷ / ₈ " x 44 ¹ / ₁₆ " x 59 ¹ / ₄ "	
KGL-OU-50-S	48 ¹¹ / ₁₆ " x 39 ⁹ / ₁₆ " x 59 ¹ / ₄ "	48 ¹¹ / ₁₆ " x 44 ¹ / ₁₆ " x 59 ¹ / ₄ "	
KGL-OU-60-S	59 ¹¹ / ₁₆ " x 39 ⁹ / ₁₆ " x 59 ¹ / ₄ "	59 ¹¹ / ₁₆ " x 44 ¹ / ₁₆ " x 59 ¹ / ₄ "	
KGL-OU-80-S	71 ⁷ / ₈ " x 39 ⁹ / ₁₆ " x 59 ¹ / ₄ "	71 ⁷ / ₈ " x 44 ¹ / ₁₆ " x 59 ¹ / ₄ "	

2 Getting started with your KGL Overunder series

2.1 Location

To your new equipment perform well please respect the following warnings:

-  This is type 1 equipment, intended to work with 75°F / 55%RH.
-  This equipment is intended for maintaining temperature only.
-  Be sure products are not ambient temperature (must be cold)
-  This equipment must be located in an indoor environment.
-  Check for air drafts and avoid them.
-  Air movement from ac units shouldn't be directed to the equipment.
-  The equipment must not be directly or indirectly exposed to the sun.
-  Check for rejected heat from another refrigeration units and avoid that.
-  Place the equipment in a levelled floor.
-  Do not obstruct the air way in front of the condenser.
-  Make sure there is a drain preparation (remotes and fish display cases only).
-  Models to be positioned against a wall keep a safe distance of 2³/₈".
-  After servicing always close the doors.
-  Make sure you have a suitable electrical installation.
-  This equipment should be handled by a qualified technician.

2.2 Uncrating




All operations must be done carefully.




All plastic protective films must be removed before using the equipment for the first time.


1




2



3



4



2.3 Check for damage

At the end of production HYDRA KOOL products are carefully inspected. No damaged units are sent out.

HYDRA KOOL doesn't take responsibility for damage between factory and client.

Possible damage on the unit must be checked to file a claim near the transportation company.

The unit must be checked in the following points:

Exterior panels

Doors

Shelves

Glasses


Paint job

Door handles


Top structure

2.4 Control panel and main features


The pictures below, shows the main features and all necessary controls




Electrical board




Self contained control panel



Return air grille
Discharge air grille



Discharge air grille






2.5 Check serial, model numbers and requested options

Before start your equipment, check the serial number, model numbers and requested options.

This inspection should be made visually in the following items:



Self contained numbers



MVP GROUP CORP. For service, please call: (514) 737-9701 www.mvpgroupcorp.com		COMMERCIAL REFRIGERATOR CONFORMS TO UL STANDARD 471 AND NSF STD 7 CERTIFIED TO CAN/CSA STD C22.2 NO. 120																	
																			
MADE IN PORTUGAL																			
ETL MODEL <input type="text"/>		Intertek 4004083																	
CASE FAMILY <input type="text"/>		120V CIRCUIT																	
SERIAL NO. <input type="text"/>		<table border="1"> <tr> <td>EVAP PAN</td> <td>DOOR HEATER</td> <td>ANTI-S LIGTHS</td> <td>EVAP FANS</td> <td>COND FANS</td> <td>COMP</td> </tr> <tr> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> </tr> </table>		EVAP PAN	DOOR HEATER	ANTI-S LIGTHS	EVAP FANS	COND FANS	COMP	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>				
EVAP PAN	DOOR HEATER	ANTI-S LIGTHS	EVAP FANS	COND FANS	COMP														
<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>														
DATE MFG <input type="text"/>		<table border="1"> <tr> <td>REF AMOUNT LEFT</td> <td>REF AMOUNT RIGHT</td> <td>REF TYPE</td> <td>--AMPS--</td> <td>--QTY--</td> <td>--PHASE--</td> <td>--HRTZ--</td> <td>LRA--</td> </tr> <tr> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="text"/></td> </tr> </table>		REF AMOUNT LEFT	REF AMOUNT RIGHT	REF TYPE	--AMPS--	--QTY--	--PHASE--	--HRTZ--	LRA--	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
REF AMOUNT LEFT	REF AMOUNT RIGHT	REF TYPE	--AMPS--	--QTY--	--PHASE--	--HRTZ--	LRA--												
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>												
<table border="1"> <tr> <td>PSI HIGH SIDE</td> <td>PSI LOW SIDE</td> <td>MINI BRANCH</td> <td>CIRCUIT AMPACITY</td> <td>MAX OVERCURRENT PROTECTION AMPS</td> </tr> <tr> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="text"/></td> <td><input type="text"/></td> </tr> </table>		PSI HIGH SIDE	PSI LOW SIDE	MINI BRANCH	CIRCUIT AMPACITY	MAX OVERCURRENT PROTECTION AMPS	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<table border="1"> <tr> <td>TOTAL CASE AMPS</td> </tr> <tr> <td><input type="text"/></td> </tr> </table>		TOTAL CASE AMPS	<input type="text"/>				
PSI HIGH SIDE	PSI LOW SIDE	MINI BRANCH	CIRCUIT AMPACITY	MAX OVERCURRENT PROTECTION AMPS															
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>															
TOTAL CASE AMPS																			
<input type="text"/>																			


2.6 Warning/Caution labels



Before starting, HYDRA KOOL products have caution and warning labels to be respected.

Self contained labels





Label 1

CAUTION

MOVING PARTS.
DO NOT OPERATE UNIT
WITH (PART) REMOVED

Label 2

ATTENTION

PIÈCES MOBILES.
NE FAIRE PAS
FONCTIONNER AVEC
DES PIÈCES ENLEVER

Label 3

-NOTE-

TYPE 1 EQUIPMENT - AMBIENT
LOCATION MUST NOT EXCEED 75
F AND 55% R.H.

Label 4

-NOTE-

CETTE VITRINE TYPE 1 EST
CONÇUE POUR FONCTION-
NER SELON LES CONDITIONS
DU MAGASIN ET NE DOIT
DÉPASSER
75 F AND 55% R.H.

Label 5

CAUTION

CONDENSING UNIT SWITCH ONLY

Label 6

ATTENTION

INTERRUPTEUR DE L'UNITÉ DE
CONDENSATION UNIQUEMENT

Label 7

CAUTION

RISK OF ELECTRIC SHOK.
DISCONNECT ALL
POWER BEFORE
SERVICING UNIT

Label 8

ATTENTION

RISQUE DE CHOC
ELECTRIQUE.
AVANT TOUT TRAVAIL
COUPER LE COURANT

Label 9

CAUTION





HOT PARTS.
DO NOT OPERATE UNIT
WITH (PART) REMOVED

Label 10

ATTENTION

PIÈCES BRULANTES.
NE FAIRE PAS
FONCTIONNER AVEC LES
PIÈCES ENLEVER

Label 11

MVP GROUP CORP.		COMMERCIAL REFRIGERATOR CONFORMS TO UL STANDARD 471 AND NSF STD 7 CERTIFIED TO CAN/CSA STD C22.2 NO. 120	
For service, please call (514) 737-9701 www.mvpgroupcorp.com		   	
MADE IN PORTUGAL		Intertek #004082	
ETL MODEL		120V CIRCUIT	
CASE FAMILY	REF AMOUNT	REF AMOUNT	REF
SERIAL NO.	SIZE	SIZE	
DATE MFG	HSR SIZE	LOW SIZE	
	PSIG	PSIG	
	TOTAL CASE AMPS		
	EVAP PAN	DOOR HEATER	LIGHTS
	ANTI-S	FANS	FANS
	EVAP FANS	FANS	COND
	COMP		
	AMPS	QTY	
	PHASE	HRTZ	
	MINI BRANCH	CIRCUIT AMPACITY	
	MAX OVERCURRENT	PROTECTION AMPS	

Label 12

120V / 60Hz

Label 13

Warning

- This appliance requires a properly grounded dedicated circuit using a NEMA rated wall receptacle do not remove the grounding prong on the plug or the risk of an injury due to shock from the ungrounded electrical service may occur.
- This product can expose an individual to chemicals that have been identified by the state of California to possibly be dangerous leading to various diseases birth defects or other human reproductive system harm. For more information go to www.p65warnings.ca.gov.


2.7 Check your electrical installation




This equipment is intended to be connected to an outlet with 115V/ 60Hz/ 1 phase.



For the wright connection check tension and frequency stated in the marking plate.



Nema-5-15P



Nema-5-20P

2.8 Plugging and start

To start your equipment follow the steps:

1 - Check for page with parameters inside the manual.



2 - After uncrating and placed the equipment respecting all warnings set in 2.1 chapter, and all switches are set to off position.





Connect the equipment.



Make sure you have the correct outlet!



Nema-5-15P




Nema-5-20P


3 - Check lights, using button referenced on chapter 2.4. If not working consult the maintenance chapter.

4 - Select operation mode:


Dry/cooling : Upper compartment dry and lower compartment cooling.



Cooling/cooling: Upper compartment cooling and lower compartment cooling.





5 - Turn ON power button referenced in 2.6 chapter



 Noise will be heard when compressor starts! If compressor doesn't start, call a technician!

6 - Check for air movement in the discharge air grille.

Dry/cooling:




Cooling/cooling:



7 - Before loading, leave the equipment working for about 2h.

8 - Load your KGL-Overunder series.


- ⚠ Loading must be done respecting loading limits and weight per square foot mentioned in page xx. This equipment is intended for maintaining temperature, be sure the products are cold, and not ambient temperature.
- ⚠ Volumes inside must respect the refrigerated shelf area.



- ⚠ After loading check for any obstruction in the discharge and return air grilles.
- ⚠ Maintain doors closed after loading.

9 - If any problem encountered, see troubleshooting or call a qualified technician!


10- To fully disconnect the unit must pull the plug.



3 Refrigeration

3.1 Self contained refrigeration equipment and defrost

The refrigeration equipment it's laid out in the base of the equipment.




All self contained KGL Overunder series use the following equipment: capillary tube, finned coil ventilated systems (condenser/evaporator), hermetic compressor, electrical water evaporation system.

Model	Circuit pressure (psig)		Refrigerant and charge (OZ)	Defrost
	High side	Low side		
KGL-OU-40-S	331	174	R 404A xx	Automatic 4/day
KGL-OU-50-S	331	174	R 404A xx	Automatic 4/day
KGL-OU-60-S	331	174	R 404A xx	Automatic 4/day
KGL-OU-80-S				

4 Electrical

4.1. Electrical specifications data

 Electrical data can be found on the marking plate.

Standard equipment include led lighting.


115V/60Hz/1 phase

Model	Compressor F.L.A./L.R.A.	Lights	Fans		Evap pan	Total amps (self contained)
			EVP	CND		
KGL-OU-40-S	---	---	---	---	---	---
KGL-OU-50-S	---	---	---	---	---	---
KGL-OU-60-S	---	---	---	---	---	---
KGL-OU-80-S						

The data regards to standard options only.

4.3. Electrical diagrams

KGL-OU-50-S



N ^o	Discription
1	Compressor
2	Overload
3	Relay
4	Start capacitor
5	Condenser fan
6	Controller
7	Temperature probe
9	Terminal block
11	Ground connection
12	Evaporator fan
13	Compressor relay
20	Light Switch
21	Pilot light
22	Switch
27	Run capacitor
29	Transformer
30	Led lighting
31	Socket
32	Evaporative condensate pan

4.4. Electronic controller



Carel - IR33FOAHEO

TECHNICAL SPECIFICATIONS

	Model	Voltage	Power	
Power supply	IRxxxxExxxx	230 V~, 50/60 Hz	3 VA, 25 mA~max.	
	IRxxxxAxxxx	115V~, 50/60 Hz	3 VA, 50 mA~max.	
	IRxxxxHxxxx	115 to 230 V~, 50/60 Hz	6 VA, 50 mA~max.	
	IRxxxxLxxxx IRxxxx0xxxx	12 to 24V~, 50/60 Hz, 12 to 30 Vdc 12V~, 50/60 Hz, 12 to 18 Vdc	3 VA, 300 mA~/mAdc max. Use only SELV power supply	
Insulation guaranteed by the power supply	IRxxxxExxxx IRxxxxAxxxx IRxxxxHxxxx	insulation in reference to very low voltage parts	reinforced 6mm clearance, 8 mm creepage 3750 V insulation	
		insulation from relay outputs	basic 3mm clearance, 4 mm creepage 1250V insulation	
	IRxxxxLxxxx IRxxxx0xxxx	insulation in reference to very low voltage parts	externally guaranteed by safety transformer (SELV power supply)	
		insulation from relay outputs	reinforced 6mm clearance, 8 mm creepage 3750 V insulation	
	Inputs	S1 (probe 1)	NTC (IRxxx0xxxxx) o NTC e PTC (IRxxx7xxxxx)	
		S2 (probe 2)	NTC (IRxxx0xxxxx) o NTC e PTC (IRxxx7xxxxx)	
DI 1 S3 (probe 3)		free contact, contact resistance < 10 Ω, closing current 6 mA NTC (IRxxx0xxxxx) o NTC e PTC (IRxxx7xxxxx)		
DI 2 S4 (probe 4)		free contact, contact resistance < 10 Ω, closing current 6 mA NTC (IRxxx0xxxxx) o NTC e PTC (IRxxx7xxxxx)		
Maximum dittance of probes and digital inputs less than 10 m.				
Note: during installation keep the power and loads connection separate from probe cables, digital inputs, repeater display and supervisory system.				
Probe type	Std. CAREL NTC	10 kΩ at 25 °C, - 50T90 °C range		
		measurement error:	1 °C in the - 50T50 °C range 3 °C in the - 50T90 °C range	
	NTC high temperature	50 kΩ at 25 °C, - 40T150 °C range		
		measurement error:	1,5 °C in the - 20T115 °C range 4 °C in the - 20T115 °C range	
	PTC std. CAREL (specific model)	985 Ω a 25 °C, range da - 50T150 °C		
		measurement error:	2 °C in the - 50T50 °C range 4 °C in the - 50T150 °C range	

Relay outputs		depending on the model				
model	relay	EN 60730-1		UL 873		
		250 V~	operating cycles	250 V~	operating cycles	
<i>IRxxxx(E,A)</i> <i>(P,Q,S,U,V,X,Y,Z)xxx</i>	R2 (*)	5(1)A	100000	5 A resistive 1FLA 6 LRA C 300	300000	
<i>IRxxxx(E,A)</i> <i>(N,R,C,B,A,M,L,T)xxx</i>	R3 (*)	5(1)A	100000	5 A resistive 1FLA 6 LRA C 300	300000	
<i>IRxxxx(E,A)</i> <i>(N,R,C,B,A,M,L,T)xxx</i> <i>IRxxxx(O,L,H)</i> <i>(N,R,C,B,A,M,L,T)xxx</i>	R1,R2	8 (4)A N.O. 6 (4)A N.C.	100000	8 A resistive 2FLA 12 LRA C300	300000	
	R2,R3 R4 (*)	2 (2)A N.O./N.C.				
	R1	12 (2)A N.O./N.C.				
<i>IRxxxx(E,A)</i> <i>(P,Q,S,U,V,X,Y,Z)xxx</i> <i>IRxxxx(O,L,H)</i> <i>(N,R,C,B,A,M,L,T)xxx</i>	R1 (*)		100000	12 A resistive 5FLA 30 LRA C300	300000	
	insulation from very low voltage parts					reinforced
						6 mm clearance, 8 mm creepage 3750 V insulation
insulation between the relay outputs independent				basic		
				3 mm clearance, 4 mm creepage 1250 V insulation		

SSR outputs Max output voltage : 12 Vdc, Output resistance: 600 Ω, Max output current: 20 mA

(*): Relay not suitable for fluorescent loads (neon lights, ...) that use starters (ballasts) with phase-shift capacitors. Fluorescent lamps with electronic control devices or without phase-shift capacitors can be used, within the operating limits specified for each type of relay.

Connessioni	Type of connection			Cross-section Max. current
Model <i>IRxxxxxx0xx</i> <i>IRxxxx(E,A)x1xx</i> <i>IRxxxxxx2xx</i> <i>IRxxxx(E,A)x3xx</i> <i>IRxxxx(E,A)x5xx</i>	Relay screw faston removable faston vertical screw	P. Supply screw faston removable faston vertical screw	Probes screw removable removable screw vertical screw	for wires from 12 A 0.5 a 2.5 mm ²

the installer has to provide the correct dimensioning of the power supply and cable connection between the instruments and the loads. Depending on the model, the maximum current in the common terminals 1, 3 or 5 is 12 A. When using the controller at maximum operating temperature and full load, use cables featuring a maximum operating temperature of 105 °C at least.



Controller must be handled by a qualified technician.

Signals on the display

The blinking status indicates a request for activation that cannot be implemented until the end of the corresponding delay times.

Icon	Function	ON	OFF	blink	Startup
	COMPRESS.	compressor ON	comp. OFF	compressor request	
	FAN	fan ON	fan OFF	fan request	
	DEFROST	defrost in progress	defrost not required	defrost request	
	AUX	auxiliary output AUX active	auxiliary output AUX not active	anti-sweat heater function active	
	ALARM	delayed external alarm (before the expiry of the time "A7")	no alarm present	alarms in normal operation (eg. high/low temp.) or alarm from ext. digital input immediate or delayed	
	CLOCK	at least one timed defrost has been set	no timed defrost is present	clock alarm	ON if Real-Time Clock present
	LIGHT	auxiliary output LIGHT ACTIVE	auxiliary output LIGHT NOT ACTIVE	anti-sweat heater function active	
	SERVICE		no malfunction	malfunction (eg. EEPROM error or probe fault)	
	HACCP	HACCP function	HACCP function enabled	HACCP alarm (HA and/or HF) not enabled	
	CONTINUOUS CYCLE	enabled	not enabled	request	



Controller must be handled by a qualified technician.

Buttons on the keypad

Normal operation

Button	Press. the button alone	Pressing together with other buttons		
	<ul style="list-style-type: none"> if pressed for more than 5 s accessed the menu for setting type "F" (frequent) parameters in the event of alarm: silences the audible alarm (buzzer) and disables the alarm relay 	<ul style="list-style-type: none"> if pressed for more than 5 s together with the SET button, accesses the menu for setting the type "C" (configuration) or downloading the parameters if pressed for more than 5 s together with the UP/AUX button resets any alarm with manual reset 	Start-up: if pressed for more than 5 s at start-up, starts the default parameter setting	Automatic address assignment: if pressed for 1 s enters the automatic serial address assigning procedure
	if pressed for more than 1 s, enables/disables the auxiliary output	<ul style="list-style-type: none"> if pressed for more than 5 s together with DOWN/DEF button, enables/disables the continuous cycle operation if pressed for more than 5 s with SET button, starts the procedure for printing the reports (function available, with management to be implemented) if pressed for more than 5 s together with PRG/MUTE button, resets any active alarm with manual reset 		
	if pressed for more than 5 s, enables/disables a manual defrost	<ul style="list-style-type: none"> if pressed for more than 5 s together with UP/AUX button, enables/disables the continuous cycle operation if pressed for more than 1 s together with SET button, displays a submenu with the HACCP alarm parameters (HA, HAn, HF, HFn) 		
	if pressed for more than 1 s, displays and/or set the set point	<ul style="list-style-type: none"> if pressed for more than 5 s together with PRG/MUTE button, accesses the menu for setting the type "C" parameters "C" (configuration) or downloading the parameters if pressed for more than 1 s together with DOWN/DEF button, displays a submenu with the HACCP alarm parameters (HA, HAn, HF, HFn) if pressed for more than 5 s together with UP/AUX, starts the procedure for printing the report (function available, with management to be implemented) 		

Main parameters

Symbol	Code	Parameter	Models	UOM	Type	Min	Max	Def.
🔧	/3	Probe display response	MSYF	-	C	0	15	0
	/5	Select °C or °F 0: °C 1: °F	MSYF	flag	C	0	1	0
	/A2	Configuration of probe 2 (S2) 0: Probe absent 1: Product probe (display only) 2: Defrost probe 3: Condenser probe 4: Antifreeze probe	YF MS	- -	C C	0 0	4 4	2 2
	/c1	Calibration of probe 1	MSYF	°C/°F	C	-20	20	0,0
	St	Temperature set point	MSYF	°C/°F	F	r1	r2	0,0
rd	Control delta	SYF	°C/°F	F	0,1	20	2,0	
c2	Minimum compressor OFF time	SYF	min	C	0	15	0	
dl	Interval between defrosts	SYF	hours	F	0	250	8	
dP1	Maximum defrost duration, evaporator	SYF	min	F	1	250	30	


5 Maintenance

5.1 Exterior cleaning



All operations must be done with the unit disconnected.


Clean surfaces (glass/metal/plastic) with soft detergents or warm water. Do not use abrasive cleanser.



5.2 Interior cleaning

 All operations must be done with the unit disconnected.


Clean surfaces (glass/metal/plastic) with soft detergent or warm water. Do not use abrasive cleanser.



5.3 Shelf removing/ adjustment

 All operations must be done with the unit disconnected.

To remove or adjust shelves take care with light connections.




5.4 Sliding doors removal

Sliding doors are easy to take off.

- Grab door push up and then tilt the bottom towards you.

To put the door back on, just reverse the previous step.



5.5 Light substitution




All operations must be performed by a qualified technician.



All operations must be done with the unit disconnected.


To replace lights follow the steps:

- Turn off power and unplug the equipment.
- Disconnect the light
- Unscrew the light holder and remove the light
- Insert a new light in the same place of the old one, screw the holder connect it
- Screw the holder and connect it
- Plug and turn on the light



5.6 Panels and protection grille removal


- ⚠ Th is operation must be performed by a qualified technician.
- ⚠ All operations must be done with the unit disconnected.





5.7 Condenser cleaning

- ⚠ All operations must be performed by a qualified technician.
- ⚠ All operations must be done with the unit disconnected.

Condenser must be regularly cleaned (every month). Use a brush or vacuum it. To get to the condenser must remove frontal protection.





5.8 Evaporator cleaning

-  All operations must be performed by a qualified technician.
-  All operations must be done with the unit disconnected.





To access the evaporator:

- Open your unit
- Lift and remove exposition panels
- Use tool for the screws and clean






5.9 Evap Pan cleaning

-  This operation must be performed by a qualified technician.
-  All operations must be done with the unit disconnected.
-  Pan can be hot!
-  This operation must be done weekly.

To access the evap pan:

- Remove protection grille.
- Unplug the evap pan.
- Relieve the screws and take the evap pan off.
- Clean with soft detergent or warm water.



6.1 Troubleshooting



Service must be performed by a qualified technician.

Doors not closing:

Check for leveled floor.

Check for obstruction.

Remove doors and check the bearings.

Lights not working:

Check light switch position.

Check light connections.

Warm case temperature:

Check for air return grille obstruction.

Check for air drafts.

Check store temperature.

Check for condenser obstruction and cleaning.

Check for frozen evaporator.

Check set point.

Display area is over filled.

Fans not working:

Check electrical connections.

Check for any debris.

Case not aligning:

Check for leveled floor.

Check instructions for joining.

Display not working:

Check main power switch position..

Check electrical connections.

Compressor not starting:

Disconnect switch open.

Blown fuse.

Overload protective tripped.

Low charge of refrigerant.

Relay defective.

Equipment runs constantly:

Condenser dirty.

Condenser fan malfunction.

Temperature and relative humidity too high.

Starting relay burns out:

Low voltage.

High voltage.

Compressor short cycles.

Incorrect running capacitor.

Incorrect relay.

Head pressure too high:

Unit overcharged.

Air or other non condensable gases in the system.

Clogged condenser.

Defective condenser fan motor.

Unit location too hot.

Restriction in charge line.

Head pressure too low:

Insufficient refrigerant charge.

Leak in the system.

Cold location.

Noisy unit:

Compressor oil charge low.

Fan blade causing vibrations.

Tube rattle.

Loose parts.

Case not leveled.

6.2 Service



This operation must be performed by a qualified technician.



For spare parts, contact your distributor.

7 Warranty

12 month warranty for all parts from the invoice date. A new part will be provided free of charge. Defective part must be returned to the manufacturer.

Warranty claims: All claims must include model number, serial number, date of purchase, date of installation and additional information about the supposed defect.

All service work must be authorized by MVP group.

MVP group reserves the right to select the service company.

Loss of food or other damages caused by faulty equipment aren't covered by this warranty.

Warranty does not cover damage when uncrating.

Work made necessary, by lack of maintenance or cleaning are not covered by this warranty.

Warranty does not cover damage or malfunction result of improper use or installation.

Warranty does not cover negligence, misuse and operation on wrong voltage.

Warranty does not apply if the serial number is altered or defaced.

Warranty does not cover any glass break.

Warranty doesn't cover any act of negligence.

Warranty doesn't cover defects on units with unoriginal parts.

Warranty doesn't cover acts of repair or maintenance by non fully authorized personel.

This page has been left blank intentionally.

This page has been left blank intentionally.

This page has been left blank intentionally.



MVP GROUP CORPORATION
www.mvpgroupcorp.com