

## PRECAUTIONS

### PLEASE READ CAREFULLY BEFORE PROCEEDING

\* Please keep this manual in a safe place for future reference.

#### WARNING

Always follow the basic precautions listed below to avoid the possibility of serious injury or even death from electrical shock, short-circuiting, damages, fire or other hazards. These precautions include, but are not limited to, the following:

##### Do not open

This device contains no user-serviceable parts. Do not open the device or attempt to disassemble the internal parts or modify them in any way. If it should appear to be malfunctioning, discontinue use immediately and have it inspected by qualified Yamaha service personnel.

##### Water warning

Do not expose the device to rain, use it near water or in damp or wet conditions, or place on it any containers (such as vases, bottles or glasses) containing liquids which might spill into any openings. If any liquid such as water seeps into the device, have the device inspected by qualified Yamaha service personnel.

#### CAUTION

Always follow the basic precautions listed below to avoid the possibility of physical injury to you or others, or damage to the device or other property. These precautions include, but are not limited to, the following:

##### Location

- Do not place the device in an unstable position where it might accidentally fall over.
- Do not place the device in a location where it may come into contact with corrosive gases or salt air. Doing so may result in malfunction.
- Construction work should be carried out in accordance with construction-related law and always by a professional constructor. If the device installation requires construction work, make sure to observe the following precautions.
  - Choose mounting hardware and an installation location that can support the weight of the device.
  - Avoid locations that are exposed to constant vibration.
  - Use the required tools to install the device.
  - Inspect the device periodically.

##### Connections

- Before connecting the device to a power amplifier, turn off the power for all devices. Before turning the power on or off for all devices, set all volume levels to minimum.
- Use only speaker cables for connecting speakers to the speaker jacks. Use of other types of cables may result in fire.

##### Maintenance

- Do not wipe the outer packaging with benzene, thinner, or synthetic detergent and do not use electrical contact cleaner. These may damage the outer packaging and dissolve the parts.

#### Handling caution

- Do not insert your fingers or hands in any gaps or openings on the device (ports).
- Avoid inserting or dropping foreign objects (paper, plastic, metal, etc.) into any gaps or openings on the device (ports). If this happens, have the device inspected by qualified Yamaha service personnel.
- Do not operate the device if the sound is distorting. Prolonged use in this condition could cause overheating and result in fire.
- When choosing a power amplifier for use with this device, make sure that the output power of the amplifier is lower than the power capacity of this device (see SPECIFICATIONS).
- Even if the output power of the amplifier is lower than the power capacity of this device (program), use of excessive input signals resulting in clipping may cause damage to the device. Malfunction or fire may occur especially when the following sounds or noises are generated:
  - feedback, when using a microphone
  - continuous and extreme volume sound from a musical instrument
  - extreme continuous distorted sound
  - noise caused by plugging/unplugging the cable while the amplifier is turned on

#### NOTICE

To avoid the possibility of malfunction/damage to the product, damage to data, or damage to other property, follow the notices below.

##### Handling and Maintenance

- Do not place vinyl, plastic or rubber objects on the device, since this might discolor the panel.
- When cleaning the device, use a dry and soft cloth. Do not use paint thinners, solvents, cleaning fluids, or chemical-impregnated wiping cloths.
- Condensation can occur in the device due to rapid, drastic changes in ambient temperature-when the device is moved from one location to another, or air conditioning is turned on or off, for example. Using the device while condensation is present can cause damage. If there is reason to believe that condensation might have occurred, leave the device for several hours until the condensation has completely dried out.
- Be sure to observe the amplifier's rated load impedance (see SPECIFICATIONS), particularly when connecting speakers in parallel. Connecting an impedance load outside the amplifier's rated range can damage the amplifier.
- ABOUT THE PROTECTION CIRCUIT**  
This speaker system has an internal protection circuit that shuts off the speaker unit when an excessive input signal is applied. If the speaker unit emits no sound, reduce the volume level of the amplifier immediately. The sound will return automatically in several seconds.
- Do not swing the speaker by its strap.
- Do not place the speaker face down with the grille attached, as deformation of the grille may result.
- When placing the speaker face down, always place it on a flat and smooth surface.
- Do not touch the speaker driver unit.

##### About This Manual

The illustrations as shown in this manual are for instructional purposes only, and may appear somewhat different from those on your device.

Yamaha cannot be held responsible for damage caused by improper use or modifications to the device.

## UNPACKING

Unpack the contents and confirm that all the following items are included.

- Speaker × 2
- Grille × 2
- O-ring × 2
- Tile Rail × 4
- Screw × 4
- Cutout Template × 1
- Owner's Manual (this manual)
- \* Speaker cable and safety wire are not included.

## SPECIFICATIONS


Type	Full Range with Back Can, Bass-reflex	
Component	4" (10 cm) Full Range	
Coverage Angle (500 Hz – 4 kHz on average)	130° conical	
Nominal Impedance	8 Ω	
Power Rating (IEC, 100h) *1	NOISE	30 W
	PGM	60 W
	MAX	120 W
Sensitivity (1W, 1m) *2	87 dB SPL	
Maximum SPL (Calculated, 1m) *3	108 dB SPL	
Frequency Range (-10 dB) *2	80 Hz – 20 kHz	
Connector	Euroblock (4 pin) × 1 (input: +/-, loop-thru: +/-) Max. wire size 12 AWG (2.5 mm <sup>2</sup> )	
Transformer Taps	70 V	30 W, 15 W, 7.5 W, 3.8 W
	100 V	30 W, 15 W, 7.5 W
Overload Protection	PolySwitch	
Magnetically Shielded	No	
Enclosure	Shape	Back Can
	Back Can Material	Steel 1mm, Black
	Baffle Material	HIPS
Grille	Material	Powder coated perforated steel (t=0.6 mm) Trim Ring: ABS Aperture ratio: 51%
	Finish	VXC4 : Black painting (approximate value: Munsell N3)
		VXC4W : White painting (approximate value: Munsell 5Y9/05)
Dimensions (Speaker only)	Ø225 × 195H mm (Ø8 7/8" × 7 5/8"H)	
Net Weight (Speaker only, 1 piece)	2.6 kg (5.7 lbs)	
Cutout Size	Ø186 mm (Ø7 5/16")	
Required ceiling board thickness	1 mm – 35 mm	
Conduit Tube	Up to 1/2"	
Packaging	Packaged in pair	

\*1: IEC shaped pink noise with 6 dB crest factor.

\*2: Half-space (2π)

\*3: Calculated based on power rating and sensitivity, exclusive of power compression.

## DIMENSIONS




## INSTALLING THE SPEAKERS

Install the speakers onto the ceiling with the supplied hardware. Ensure that the strength of the ceiling rail is sufficiently strong.

### Pre-installation (Preparation of the Cable)

Use stranded wire for cables attached to the Euroblock connector. Strip their insulation as shown in the figure and connect them.



#### NOTE

Do not plate stranded wires by solder. Doing so will cause the wire to break.

### 1 CUT OUT A HOLE IN THE CEILING


Put the supplied cutout template to the ceiling and draw a circle by tracing it. Make sure to use the cutout template so that hole is the correct diameter.

#### NOTE

If you use a circular cutter, set the diameter with the cutout template. Cut the hole by tracing the circle. Be careful to prevent chips or powder entering your eyes while cutting the hole.


### 2 INSTALL THE TILE RAILS AND O-RING

- Insert the two tile rails through the cut hole and place them on the ceiling surface within your reach. Be sure that each tile rails are oriented as shown below.
- Insert the folded O-ring through the cut hole and open it in the ceiling.
- Secure the O-ring and tile rails with supplied two screws through either slot of both O-ring brackets.




### 3 CONNECT THE WIRING TO THE CONNECTOR AND FIX THE CABLE

- Pull the wiring from the amplifier through the cut hole.
- Loosen the screw at the right of the terminal cover to open the terminal cover and remove the Euroblock connector.




- After loosening the terminal screws of the Euroblock connector with a flat-blade screwdriver, insert the cable into each terminal and tighten the screws. Make sure that cables cannot be pulled out.



#### NOTE

Use a flat-blade screwdriver with a blade less than 3 mm (0.1 in.).




There are two acceptable wiring methods.

#### CAUTION

When connecting with low impedance, take note of the combined resistance.


#### Using Loop-Through Terminals

For this method, cables are connected from terminals 1 and 4 to the subsequent speaker. If the Euroblock connector is disconnected from a speaker, all subsequent speakers will not work. This can be useful to identify which speaker has a problem.




#### Paralleling Input Terminals

For this method, cables are connected to terminals 2 and 3 of each speaker. Since the cables are connected via Euroblock connectors, subsequent speakers can work even if a problem occurs with a speaker.




- Plug the connected Euroblock connector into the socket in the speaker.




- Loosen the screw A of the strain relief clamp.


- Remove the screw B of the strain relief clamp. If the cable is not to be held, remove the screw A and remove the strain relief fitting, then proceed to step 8.



- Hold the cable in the strain relief clamp, then tighten screws A and B.




- Close the terminal cover and tighten the screw.



### 4 FIX THE SPEAKERS ONTO THE CEILING


- Attach the safety wire to the safety wire ring, and connect the wire to an independent support point, such as a joist.




#### CAUTION

Always take measures to prevent the speaker falling down. If the safety wire is too short, prepare another wire appropriate for the speaker weight and installation conditions. If the wire is too long, should the speaker fall, the wire may break as a result of too much strain.


- Push up the speaker slowly into the ceiling, taking care not to trap the cable.



When all the Anti-Drop tabs cross over the O-ring, the speaker is held temporarily. You can release your hands from the speaker.




To release the speaker from the O-ring, press the Anti-Drop tabs. These are located above the ▲ mark near the edge of the cabinet's face.



- Turn the screwdriver a half turn counterclockwise to loosen the attachment screw. This makes the clamp easier to align in the channel.

- Turn the screwdriver clockwise to tighten the attachment screw. The first turn of the attachment screw aligns the clamp with the channel. Further turns move the clamp down the channel to pull the speaker up into the ceiling.




#### CAUTION

- Do not over-tighten the attachment screw. Otherwise, the attachment screw and clamp will break.
- Do not turn any screws that do not have a guide sleeve in the screw hole. Otherwise, the speaker may fall or malfunction.

### 5 SET THE LINE VOLTAGE/IMPEDANCE AND POWER

Select the line voltage/impedance (100V/70V/8Ω) and power tap for 100V/70V line distributed system, by rotating the tap selector switch on the front side of the speaker with a flat-blade screwdriver.




#### CAUTION

The "X" position should not be selected. The 8Ω position should be selected for 8Ω audio systems only. If the setting is incorrect, it may cause malfunction of the speaker and amplifier.

### 6 ATTACH THE GRILLE

Fit the grille to the cabinet front and turn it clockwise.



#### CAUTION

The grille may fall down if it is attached inadequately. Attach it firmly.

## Important Notice: Guarantee Information for customers in European Economic Area (EEA) and Switzerland

Important Notice: Guarantee Information for customers in EEA* and Switzerland	English
For detailed guarantee information about this Yamaha product, and Pan-EEA* and Switzerland warranty service, please either visit the website address below (Printable file is available at our website) or contact the Yamaha representative office for your country. * EEA: European Economic Area	
Wichtiger Hinweis: Garantie-Information für Kunden in der EWR* und der Schweiz	Deutsch
Für nähere Garantie-Information über dieses Produkt von Yamaha, sowie über den Pan-EWR*- und Schweizer Garantieservice, besuchen Sie bitte entweder die folgend angegebene Internetadresse (eine druckfähige Version befindet sich auch auf unserer Webseite), oder wenden Sie sich an den für Ihr Land zuständigen Yamaha-Vertrieb. *EWR: Europäischer Wirtschaftsraum	
Remarque importante: Informations de garantie pour les clients de l'EEE et la Suisse	Français
Pour des informations plus détaillées sur la garantie de ce produit Yamaha et sur le service de garantie applicable dans l'ensemble de l'EEE ainsi qu'en Suisse, consultez notre site Web à l'adresse ci-dessous (le fichier imprimable est disponible sur notre site Web) ou contactez directement Yamaha dans votre pays de résidence. * EEE <span> </span> : Espace Economique Européen	
Belangrijke mededeling: Garantie-informatie voor klanten in de EER* en Zwitserland	Nederlands
Voor gedetailleerde garantie-informatie over dit Yamaha-product en de garantieservice in heel de EER* en Zwitserland, gaat u naar de onderstaande website (u vindt een afdrukbaar bestand op onze website) of neemt u contact op met de vertegenwoordiging van Yamaha in uw land. * EER: Europese Economische Ruimte	
Aviso importante: Información sobre la garantía para los clientes del EEE* y Suiza	Español
Para una información detallada sobre este producto Yamaha y sobre el soporte de garantía en la zona EEE* y Suiza, visite la dirección web que se incluye más abajo (la versión del archivo para imprimir esta disponible en nuestro sitio web) o póngase en contacto con el representante de Yamaha en su país. * EEE: Espacio Económico Europeo	
Avviso importanti: informazioni sulla garanzia per i clienti residenti nell'EEA* e in Svizzera	Italiano
Per informazioni dettagliate sulla garanzia relativa a questo prodotto Yamaha e l'assistenza in garanzia nei paesi EEA* e in Svizzera, potete consultare il sito Web all'indirizzo riportato di seguito (è disponibile il file in formato stampabile) oppure contattare l'ufficio di rappresentanza locale della Yamaha. * EEA: Area Economica Europea	
Aviso importante: informações sobre as garantias para clientes da AEE* e da Suíça	Português
Para obter uma informação pomenorizada sobre este produto da Yamaha e sobre o serviço de garantia na AEE* e na Suíça, visite o site a seguir (o arquivo para impressão está disponível no nosso site) ou entre em contato com o escritório de representação da Yamaha no seu país. * AEE: Área Económica Europeia	
Σημαντική σημείωση: Πληροφορίες εγγύησης για τους πελάτες στον ΕΟΧ* και Ελβετία	Ελληνικά
Για λεπτομερείς πληροφορίες εγγύησης σχετικά με το προϊόν προϊόν της Yamaha και την κάλυψη εγγύησης σε όλη τη χώρα του ΕΟΧ και την Ελβετία, επισκεφτείτε την παρακάτω ιστοσελίδα (Εκτυπιώσιμη μορφή είναι διαθέσιμη στην ιστοσελίδα μας) ή απευθυνθείτε στην αντιπροσωπεία της Yamaha στη χώρα σας. * ΕΟΧ: Ευρωπαϊκός Οικονομικός Χώρος	
Viktigt: Garantinformation för kunder i EES-området* och Schweiz	Svenska
För detaljerad information om denna Yamahaprodukt samt garantiservice i hela EES-området* och Schweiz kan du antingen besöka nedanstående webbadress (en utskriftsvänlig fil finns på webbplatsen) eller kontakta Yamahas officiella representant i ditt land. * EES: Europeiska Ekonomiska Samarbetsområdet	
Viktig merknad: Garantinformasjon for kunder i EØS* og Sveits	Norsk
Detaljert garantinformasjon om dette Yamaha-produktet og garantiservice for hele EØS-området* og Sveits kan fås enten ved å besøke nettstedene nedenfor (utskriftsversjon finnes på våre nettsider) eller kontakte kontakke Yamaha-kontoret i landet der du bor. *EØS: Det europeiske økonomiske samarbeidsområdet	
Vigtig oplysning: Garantoplysninger til kunder i EØO* og Schweiz	Dansk
De kan finde detaljerede garantiplysninger om dette Yamaha-produktet og den fælles garantiserviceordning for EØO* (og Schweiz) ved at besøge det websted, der er angivet nedenfor (der findes en fil, som kan udskrives, på vores websted), eller ved at kontakte Yamahas nationale repræsentationskontor i det land, hvor De bor. * EØO: Det Europæiske Økonomiske Område	
Tärkeä ilmoitus: Taku tiedot Euroopan talousalueen (ETA)* ja Sveitsin asiakkaille	Suomi
Tämän Yamaha-tuotteen sekä ETA-alueen ja Sveitsin takuuta koskevat yksityiskohtaiset tiedot saatte alla olevasta nettiosoitesta. (Tulostettava tiedosto saatavissa sivustollamme.) Voitte myös ottaa yhteyttä paikalliseen Yamaha-edustajaan. *ETA: Euroopan talousalue	
Ważne: Warunki gwarancyjne obowiązujące w EOG* i Szwajcarii	Polski
Aby dowiedzieć się więcej na temat warunków gwarancyjnych tego produktu firmy Yamaha i serwisu gwarancyjnego w całym EOG* i Szwajcarii, należy odwiedzić wskazaną poniżej stronę internetową (Plik gotowy do wydruku znajduje się na naszej stronie internetowej) lub skontaktować się z przedstawicielstwem firmy Yamaha w swoim kraju. * EOG — Europejski Obszar Gospodarczy	
Důležité oznámení: Záruční informace pro zákazníky v EHS* a ve Švýcarsku	Česky
Podrobné záruční informace o tomto produktu Yamaha a záručním servisu v celém EHS* a ve Švýcarsku naleznete na níže uvedené webové adrese (soubor k tisku je dostupný na našich webových stránkách) nebo se můžete obrátit na zastoupení firmy Yamaha ve své zemi. * EHS: Evropský hospodářský prostor	
Fontos figyelmeztetés: Garancia-információk az EGT* területén és Svájcban élő vásárlók számára	Magyar
A jelen Yamaha termékre vonatkozó részletes garancia-információk, valamint az EGT*-re és Svájcra kiterjedő garanciális szolgáttatás tekintetében keresse fel webhelyünket az alábbi címen (a webhelyen nyomtatható fájl is talál), vagy pedig lépjen kapcsolatba az országában működő Yamaha képviselői irodával. * EGT: Európai Gazdasági Térség	
Oluline märkus: Garantiteave Euroopa Majanduspiirkonna (EMP)* ja Šveitsi klientidele	Eesti keel
Täpsema teabe saamiseks selle Yamaha toote garantii ning kogu Euroopa Majanduspiirkonna ja Šveitsi garantiiteeniduse kohta, külastage palun veebisaiti alljärgneval aadressil (meie saidil on saadaval printitav fail) või pöörduge Teie regiooni Yamaha esinduse poole. * EMP: Euroopa Majanduspiirkond	
Svarige paziņojums: garantijas informācija klientiem EEZ* un Šveicā	Latviešu
Lai saņemtu detalizētu garantijas informāciju par šo Yamaha produktu, kā arī garantijas apkalpošanu EEZ* un Šveicā, lūdzu, apmeklējiet zemāk norādīto tīmekļa vietnes adresi (tīmekļa vietnē ir pieejams drukājams fails) vai sazinieties ar jūsu valsti apkalpojošo Yamaha pārstāvniecību. * EEZ: Eiropas Ekonomikas zona	
Démesio: informacija dėl garantijos pirkėjams EEE* ir Šveicarijoje	Lietuvių kalba
Jei reikia išsamios informacijos apie šį „Yamaha“ produktą ir jo techninę priežiūrą visoje EEE* ir Šveicarijoje, apsilankykite mūsų svetainėje toliau nurodytu adresu (svetainėje yra spausdintinas failas) arba kreipkitės į „Yamaha“ atstovybę savo šalyje. *EEE — Europos ekonominė erdvė	
Dôležité upozornenie: Informácie o záruke pre zákazníkov v EHP* a Švajčiarsku	Slovenščina
Podrobne informácie o záruke týkajúce sa tohto produktu od spoločnosti Yamaha a garančnom servise v EHP* a Švajčiarsku nájdete na webovej stránke uvedenej nižšie (na našej webovej stránke je k dispozícii súbor na tlač) alebo sa obráťte na zástupcu spoločnosti Yamaha vo svojej krajine. * EHP: Európsky hospodársky priestor	
Pomembno obvestilo: Informacije o garanciji za kupce v EGP* in Švici	Slovensčina
Za podrobnejše informacije o tem Yamahinem izdelku ter garancijskem servisu v celotnem EGP in Švici, obiščite spletno mesto, ki je navedeno spodaj (natisljiva datoteka je na voljo na našem spletnem mestu), ali se obrnite na Yamahinega predstavnika v svoji državi. * EGP: Evropski gospodarski prostor	
Важно съобщение: Информация за гаранцията за клиенти в ЕИП* и Швейцария	Български език
За подробна информация за гаранцията за този продукт на Yamaha и гаранционното обслужване в паневропейската зона на ЕИП* и Швейцария или посетете посочения по-долу уеб сайт (на нашия уеб сайт има файл за печат), или се свържете с представителния офис на Yamaha във вашата страна. * ЕИП: Европейско икономическо пространство	
Notificare importantă: Informații despre garanție pentru clienții din SEE* și Elveția	Limba română
Pentru informații detaliate privind acest produs Yamaha și serviciul de garanție Pan-SEE* și Elveția, vizitați site-ul la adresa de mai jos (fișierul imprimabil este disponibil pe site-ul nostru) sau contactați biroul reprezentanței Yamaha din țara dumneavoastră . * SEE: Spațiul Economic European	

<http://europe.yamaha.com/warranty/>

URL\_4

For details of products, please contact your nearest Yamaha representative or the authorized distributor listed below.

Pour plus de détails sur les produits, veuillez-vous adresser à Yamaha ou au distributeur le plus proche de vous figurant dans la liste suivante.

Die Einzelheiten zu Produkten sind bei Ihrer unten aufgeführten Niederlassung und bei Yamaha Vertragshändlern in den jeweiligen Bestimmungsländern erhältlich.

Para detalles sobre productos, contacte su tienda Yamaha más cercana o el distribuidor autorizado que se lista debajo.

NORTH AMERICA		
<b>CANADA</b> <b>Yamaha Canada Music Ltd.</b> 135 Milner Avenue, Scarborough, Ontario, M1S 3R1, Canada Tel: 416-298-1311		
<b>U.S.A.</b> <b>Yamaha Corporation of America</b> 6600 Orangethorpe Ave., Buena Park, Calif. 90620, U.S.A. Tel: 714-522-9011		
CENTRAL & SOUTH AMERICA		
<b>MEXICO</b> <b>Yamaha de México S.A. de C.V.</b> Calz. Javier Rojo Gómez #1149, Col. Guadalupe del Moral C.P. 09300, México, D.F., México Tel: 55-5804-0600		
<b>BRAZIL</b> <b>Yamaha Musical do Brasil Ltda.</b> Rua Joaquim Floriano, 913 - 4º andar, Itaim Bibi, CEP 04534-013 Sao Paulo, SP. BRAZIL Tel: 011-3704-1377		
<b>ARGENTINA</b> <b>Yamaha Music Latin America, S.A. Sucursal de Argentina</b> Olga Cossetini 1553, Piso 4 Norte Madro Este-C1107CEK Buenos Aires, Argentina Tel: 011-4119-7000		
<b>PANAMA AND OTHER LATIN AMERICAN COUNTRIES/ CARIBBEAN COUNTRIES</b> <b>Yamaha Music Latin America, S.A.</b> Torre Banco General, Piso 7, Urbanización Marbella, Calle 47 y Aguinal de la Guardia, Ciudad de Panamá, Panamá Tel: +507-269-5311		
EUROPE		
<b>THE UNITED KINGDOM/IRELAND</b> <b>Yamaha Music Europe GmbH (UK)</b> Sherbourne Drive, Tilbrook, Milton Keynes, MK7 8BL, England Tel: 01908-366700		
<b>GERMANY</b> <b>Yamaha Music Europe GmbH</b> Siemensstraße 22-34, 25462 Rellingen, Germany Tel: 04101-3030		
<b>SWITZERLAND/LIECHTENSTEIN</b> <b>Yamaha Music Europe GmbH Branch Switzerland in Zürich</b> Seefeldstrasse 94, 8008 Zürich, Switzerland Tel: 044-387-8080		
<b>AUSTRIA/BULGARIA</b> <b>Yamaha Music Europe GmbH Branch Austria</b> Schleiergasse 20, A-1100 Wien, Austria Tel: 01-60203900		
<b>CZECH REPUBLIC/HUNGARY/ ROMANIA/SLOVAKIA/SLOVENIA</b> <b>Yamaha Music Europe GmbH Branch Austria (Central Eastern Europe Office)</b> Schleiergasse 20, A-1100 Wien, Austria Tel: 01-602039025		
<b>POLAND/LITHUANIA/LATVIA/ESTONIA</b> <b>Yamaha Music Europe GmbH Branch Poland Office</b> ul. Wrotkowa 14 02-553 Warsaw, Poland Tel: 022-500-2925		
<b>MALTA</b> <b>Olimpus Music Ltd.</b> The Emporium, Level 3, St. Louis Street Msida MSD06 Tel: 02133-2144		
<b>THE NETHERLANDS/ BELGIUM/LUXEMBOURG</b> <b>Yamaha Music Europe Branch Benelux</b> Clarissenhof 5-b, 4133 AB Vianen, The Netherlands Tel: 0347-358 040		
<b>FRANCE</b> <b>Yamaha Music Europe</b> BP 70-77312 Marne-la-Vallée Cedex 2, France Tel: 01-64-61-4000		
<b>ITALY</b> <b>Yamaha Music Europe GmbH, Branch Italy</b> Viale Italia 88, 20020 Lainate (Milano), Italy Tel: 02-935-771		
<b>SPAIN/PORTUGAL</b> <b>Yamaha Music Europe GmbH Ibérica, Sucursal en España</b> Ctra. de la Coruna km. 17, 200, 28230 Ras Rozas (Madrid), Spain Tel: +34-902-39-8888		
<b>GREECE</b> <b>Philippos Nakas S.A. The Music House</b> 147 Skiathou Street, 112-55 Athens, Greece Tel: 01-228 2160		
<b>SWEDEN/FINLAND/ICELAND</b> <b>Yamaha Music Europe GmbH Germany filial Scandinavia</b> J. A. Wettergrens Gata 1, Box 30053 S-400 43 Göteborg, Sweden Tel: 031 89 34 00		
<b>DENMARK</b> <b>Yamaha Music Europe GmbH, Tyskland – filial Denmark</b> Generatortvej 6A, DK-2730 Herlev, Denmark Tel: 44 92 49 00		
<b>NORWAY</b> <b>Yamaha Music Europe GmbH Germany - Norwegian Branch</b> Grini Næringspark 1, N-1345 Østerås, Norway Tel: 67 16 77 70		
<b>RUSSIA</b> <b>Yamaha Music (Russia)</b> Room 37, bld. 7, Kievskaya street, Moscow, 121059, Russia Tel: 495 626 5005		
<b>OTHER EUROPEAN COUNTRIES</b> <b>Yamaha Music Europe GmbH</b> Siemensstraße 22-34, 25462 Rellingen, Germany Tel: +49-4101-3030		
AFRICA		
<b>Yamaha Corporation, Asia-Pacific Sales &amp; Marketing Group</b> Nakazawa-cho 10-1, Naka-ku, Hamamatsu, Japan 430-8650 Tel: +81-53-460-2303		
MIDDLE EAST		
<b>TURKEY/CYPRUS</b> <b>Yamaha Music Europe GmbH</b> Siemensstraße 22-34, 25462 Rellingen, Germany Tel: 04101-3030		
<b>OTHER COUNTRIES</b> <b>Yamaha Music Gulf FZE</b> LOB 16-513, P.O.Box 17328, Jubel Ali, Dubai, United Arab Emirates Tel: +971-4-881-5868		
ASIA		
<b>THE PEOPLE'S REPUBLIC OF CHINA</b> <b>Yamaha Music &amp; Electronics (China) Co.,Ltd.</b> 2F, Yunhedasha, 1818 Xinzha-lu, Jingan-qu, Shanghai, China Tel: 021-6247-2211		
<b>INDIA</b> <b>Yamaha Music India Pvt. Ltd.</b> Spazedge Building, Ground Floor, Tower A, Sector 47, Gurgaon- Sohna Road, Gurgaon, Haryana, India Tel: 0124-485-3300		
<b>INDONESIA</b> <b>PT. Yamaha Musik Indonesia (Distributor) PT. Nusantik</b> Gedung Yamaha Music Center, Jalan Jend. Gatot Subroto Kav. 4, Jakarta 12930, Indonesia Tel: 021-520-2577		
<b>KOREA</b> <b>Yamaha Music Korea Ltd.</b> 8F, 9F, Dongsung Bldg. 158-9 Samsung-Dong, Kangnam-Gu, Seoul, Korea Tel: 02-3467-3300		
<b>MALAYSIA</b> <b>Yamaha Music (Malaysia) Sdn., Bhd.</b> Lot 8, Jalan Perbandaran, 47301 Kelana Jaya, Petaling Jaya, Selangor, Malaysia Tel: 03-78030900		
<b>SINGAPORE</b> <b>Yamaha Music (Asia) PRIVATE LIMITED</b> Blk 202 Hougang Street 21, #02-00, Singapore 530202, Singapore Tel: 6747-4374		
<b>TAIWAN</b> <b>Yamaha KHS Music Co., Ltd.</b> 3F, #6, Sec.2, Nan Jing E. Rd. Taipei. Taiwan 104, R.O.C. Tel: 02-2511-8688		
<b>THAILAND</b> <b>Siam Music Yamaha Co., Ltd.</b> 4, 6, 15 and 16th floor, Siam Motors Building, 891/1 Rama 1 Road, Wangmai, Pathumwan, Bangkok 10330, Thailand Tel: 02-215-2622		
<b>OTHER ASIAN COUNTRIES</b> <b>Yamaha Corporation, Asia-Pacific Sales &amp; Marketing Group</b> Nakazawa-cho 10-1, Naka-ku, Hamamatsu, Japan 430-8650 Tel: +81-53-460-2303		
OCEANIA		
<b>AUSTRALIA</b> <b>Yamaha Music Australia Pty. Ltd.</b> Level 1, 99 Queensbridge Street, Southbank, Victoria 3006, Australia Tel: 3-9693-5111		
<b>COUNTRIES AND TRUST TERRITORIES IN PACIFIC OCEAN</b> <b>Yamaha Corporation, Asia-Pacific Sales &amp; Marketing Group</b> Nakazawa-cho 10-1, Naka-ku, Hamamatsu, Japan 430-8650 Tel: +81-53-460-2303		

PA31

**HEAD OFFICE** **Yamaha Corporation, Pro Audio Division**  
Nakazawa-cho 10-1, Naka-ku, Hamamatsu, Japan 430-8650  
Tel: +81-53-460-2441