



StylusTimer

PROTECT YOUR RECORDS: | TRACK YOUR LISTENING TIME: | KNOW WHEN TO REPLACE YOUR STYLUS

Thank you for purchasing Your Stylus Timer, brand chronograph.

The Stylus Timer, chronograph is a unique, patent-pending precision instrument developed specifically for tracking stylus hours. You will find it adds a fun new dimension to your listening experience, as well as help you track your stylus hours precisely.

Using Your StylusTimer,

We recommend a two-handed approach for simplicity and to quickly train yourself to start and stop your Stylus limer each and every time you play a record. You will find it to be an intuitive, coordinated process that quickly becomes part of your record playing routine.

- Put your Stylus Timer to the left of your turntable.
- Set the stylus above the lead-in groove, then put your right fingers on the tonearm cuing lever and your left fingers on the Stylus Timer.
- As you lower the arm with your right hand, push START with your left hand. If
 you want to time your usage with extreme precision you can press START when
 the stylus actually makes contact with the record. You will hear a beep and the
 H will flash to show it is recording hours.
- At the end of playback (or if playback is interrupted) when you raise the arm with your right hand, press STOP with your left. You will hear two beeps and the H will stop flashing. Cumulative hours up to 9,999 will be recorded.

BATTERY

Remove the battery door and insert a AAA battery (not included.) Alkaline batteries are recommended.

Because of the internal back-up power it is possible the Stylus Timer may have been activated during shipping. If your Stylus Timer is running when you insert the battery, simply press Stop and then hold down Reset until Stylus Timer resets to 0.

Hours are remembered during battery changes. A low battery indicator will tell you when it is time to change the battery. Because of the internal back-up power it is possible to trigger the Stylus Timer when no battery is inserted, so we recommend you change it before the screen blanks due to low power.



THE TWO-HANDED APPROACH

RESETTING YOUR STYLUSTIMER.

Stylus Timer is designed to require deliberate effort to reset, so an accidental push of the RESET button will not cause you to lose your recorded time.

To reset, hold the RESET button down until the display resets to 0. This takes approximately 3 seconds.

STYLUS LIFFSPAN

Clean records mean your stylus will last longer, dirty & scratched records mean it will last less. A lifespan of 1,000 hours is a good rule of thumb for a high quality stylus playing a mix of new & old records.

www.stylustimer.com

STYLUSTIMERT CREATED BY SYNDICATED SOUND ADVICE COLUMNIST DON LINDICH

US & International Patents Pending