



®

REMANUFACTURED

Instruction manual.



**POWER PATH™
PRO**
CARPET WASHER



**POWER PATH™
PRO XL**
CARPET WASHER



**POWER PATH™
PRO *ADVANCED***
CARPET WASHER

IMPORTANT: Read carefully before assembly and use.

Welcome to Hoover[®] ownership.

Get cleaning confidence for 6 months
with the Hoover[®] limited warranty.

Your Guide:

Safety Instructions	1
How to assemble your Power Path™ Pro	3
Getting started with your Power Path™ Pro	5
Using your Power Path™ Pro	7
How to attach your Power Path™ Pro tools	11
Keeping your Power Path™ Pro running properly	17
Troubleshooting	25
Warranty	26

IMPORTANT SAFETY INSTRUCTIONS

SAVE THESE INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE. THIS PRODUCT IS INTENDED FOR HOUSEHOLD USE ONLY. IF USED COMMERCIALY WARRANTY IS VOID.

WARNING: TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK, DAMAGE OR INJURY:


- Fully assemble before operating.
- Operate cleaner only at voltage specified on data plate on lower back of cleaner.
- Do not leave appliance when plugged in. Unplug from outlet when not in use and before cleaning or servicing.
- Use indoors only.
- Do not immerse. Use only on carpet moistened by cleaning process.
- Use only HOOVER® cleaning products intended for use with this machine.
- Do not allow to be used as a toy. Not intended for use by children age 12 and under. Close supervision is necessary when used near children. To avoid injury or damage, keep children away from product, and do not allow children to place fingers or other objects into any openings.
- Use only as described in this manual. Use only manufacturer's recommended attachments and products.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, take it to a service center prior to continuing use.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not place product on cord. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs. To avoid personal injury or damage, and to prevent the cleaner from falling, always place cleaner at bottom of stairs or on floor. Do not place cleaner on stairs or furniture, as it may result in injury or damage.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or fine wood sandings, or use in areas where they may be present.
- Connect to a properly grounded outlet only. See Grounding Instructions.
- Unplug before connecting SpinScrub® powered hand tool.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without filters and tanks in place.
- Do not clean over floor electrical outlets.

WARNING: This product contains chemicals known to the State of California to cause cancer, birth defects or reproductive harm. **WASH HANDS AFTER HANDLING.**

GROUNDING INSTRUCTIONS:

This appliance must be grounded. If it should malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This appliance is equipped with a cord having an equipment-grounding conductor (C) and grounding plug (A). The plug must be inserted into an appropriate outlet (B) that is properly installed and grounded in accordance with all local codes and ordinances.

WARNING: Improper connection of the equipment-grounding conductor can result in the risk of electric shock. Check with a qualified electrician or service person if you are in doubt as to whether the outlet is properly grounded. Do not modify the plug provided with the appliance - if it will not fit the outlet, have a proper outlet installed by a qualified electrician. This appliance is for use on a nominal 120-volt circuit and has a grounding plug that looks like the plug (A) illustrated in Fig. 1. A temporary adapter (D) may be used to connect this plug to a 2-pole receptacle (E) if a properly grounded outlet is not available (Fig. 2). The temporary adapter should be used only until a properly grounded outlet (B) can be installed by a qualified electrician (Fig. 1). The green colored rigid ear, lug, or the like (F) extending from the adapter must be connected to a permanent ground (G) such as a properly grounded outlet box cover (Fig. 2). Whenever the adapter is used, it must be held in place by a metal screw. NOTE: In Canada, the use of a temporary adapter is not permitted by the Canadian Electrical Code.




CAUTION: TO REDUCE THE RISK OF DAMAGE:

- Avoid picking up hard, sharp objects with this product, as they may cause damage.
- Store appropriately indoors in a dry place. Do not expose machine to freezing temperatures.
- Do not use sharp objects to clean out hose as they can cause damage.
- To assist in reducing drying time, be certain the area is well ventilated when using detergents and other cleaners with this machine.
- To help prevent matting and resoiling, avoid contact with carpets until they are dry. Keep children and pets away from carpets until they are completely dry.
- Do not store extractor with solution in tanks.
- With brushes and brushroll on, do not allow cleaner to sit in one location for an extended period of time, as damage to the floor can result.
- Do not use this extractor on hard floors. Using this machine on hard floors may scratch or damage your floor.
- Water will drip from the brushes and underside of the product after use and may puddle. To avoid damage to wood and laminate flooring and to avoid potential slip hazard, after use (a) do not leave the product on wood and laminate surfaces and remove to a hard surface and (b) place unit on absorbent material (such as a towel) to soak up drips.


How to assemble your Power Path™ Pro:

ATTENTION


Prior to use, consult with Carpet Manufacturer on cleaning recommendations for natural fiber carpeting (including silk and wool), soft carpeting, and loop Berber carpeting. Do not use on rugs or carpet when dry cleaning is recommended.



1 Insert the handle on to the base.




2 Turn the dial clockwise to the "LOCK" position.



3 Angle the Clean Water Tank in like this on the handle above the dirty water tank. It'll click.

Cord storage:



- 1** Wrap cord around the cord hooks for convenient storage. Attach the plug end to the cord.

Before you begin cleaning:

- 1.** Vacuum carpet and upholstery thoroughly with a Hoover® vacuum.
- 2.** Use your Hoover® carpet washer only if upholstery fabric is marked with a “W” (for “wet” clean) or “S/W” (for “solvent/dry” or “wet” clean). Don’t clean fabric marked “S” (“solvent/dry” clean only).
- 3.** Test for colorfastness in a small, hidden area. Gently rub surface with a dampened white cloth. Wait ten minutes and check for color removal or bleed with a white paper towel.
- 4.** Move furniture out of area to be cleaned. Place aluminum foil or wax paper under legs of furniture too heavy to move to prevent wood finishes from staining carpet.
- 5.** Pretreat spots and heavy traffic areas with a Hoover® Cleaning Solution*. See “Cleaning Solutions” section.

*Available at additional cost if not included with your model.

ATTENTION


Some Berber, Natural Fiber, and Soft Fiber carpets can fuzz with wear. Some vacuums & carpet cleaners can worsen this carpet wear. Test a hidden area before using on a full room & consult with your carpet manufacturer on cleaning recommendations.

NOTE: To prevent staining, use plastic or aluminum foil to protect wood or metal surfaces from possible water spray.

NOTE: To avoid damage to wood floors underneath area rugs or carpet, place waterproof material (e.g. plastic) underneath them before cleaning.

Getting started with your Power Path™ Pro:


Remove and replace clean water solution tank:



- 1** Press the Clean Water Solution Tank button on handle. Angle the Clean Water Solution Tank out and remove.



- 2** Turn water cap counter-clockwise and pull up to remove.



- 3** Fill Clean Water Tank with hot tap water to the fill line.




- 4** Fill Solution Tank with solution to the fill line. Replace both caps.

⚠ WARNING ⚠


Use only HOOVER® cleaning products intended for use with this machine. (See the "Cleaning products" section in this manual for details.) They are specially formulated for use with your cleaner. Non-Hoover® cleaning solutions may harm the machine and void the warranty.

⚠ CAUTION ⚠


Do not fill with water above 140°F (60°C).



5 Angle the Clean Water Solution Tank back onto the handle. It'll click.



6 To wash carpets, turn the dial to "Wash".




7 To rinse carpets and remove excess solution, turn the dial to "Rinse" and go over carpets again.

⚠ CAUTION ⚠

Water will drip from the brushes and underside of the product after use and may puddle. To avoid damage to wood and laminate flooring and to avoid potential slip hazard, after use (a) do not leave the product on wood and laminate surfaces and move to a hard surface and (b) place unit on absorbent material (such as a towel) to soak up drips.

NOTE: Using more than the recommended amount of cleaning solution may cause excessive foaming.


Using your Power Path™ Pro:




- 1** Plug in. Step on the handle release pedal to put unit in cleaning position.



- 2** Step on the power pedal to turn ON (I=ON). Press the power pedal again to turn OFF (0=OFF).



- 3** Squeeze trigger to apply cleaning solution. Slowly push forward then backwards while squeezing the trigger (wet stroke).



- 4** Release the trigger and slowly push forward over the sprayed area. Then slowly pull back toward you without squeezing trigger (dry stroke). Continue using dry strokes until little water is visible passing through the nozzle.

NOTE: For best results, use straight, parallel strokes. Overlap strokes by 1 in. to help prevent streaking.

5 If cleaning on Berber, Natural Fiber, or Soft Fiber carpeting, first test a small hidden area of carpet by running the carpet washer over it. If no fuzzing or overwetting occurs, continue cleaning. Avoid overwetting Berber carpets. If you have any questions or concerns, consult with your carpet manufacturer on deep cleaning recommendations.

For best cleaning results, end with more dry strokes. (Continue using dry strokes until little water is visible passing through the nozzle.)

For best results, Hoover® recommends rinsing carpet with water only. This removes residual carpet cleaning solution. Fill Clean Water tank, then turn knob to rinse mode. For heavily soiled areas, repeat. Avoid saturating carpet.


NOTE: Empty Dirty Water Tank when the motor sound becomes higher pitched and there is a loss in suction (see “Automatic shut-off”).

NOTE: It is best to alternate wet and dry strokes as described above.

 **CAUTION** 

Do not clean over floor electrical outlets. Water will drip from the brushes and underside of the product after use and may puddle. To avoid damage to wood and laminate flooring and to avoid potential slip hazard, after use (a) do not leave the product on wood and laminate surfaces and move to a hard surface and (b) place unit on an absorbant material (such as a towel) to soak up drips.


Emptying your Power Path™ Pro dirty water tank:




1 Grasp Dirty Water Tank handle and push latch to release. Lift tank out at an angle like this.




2 Empty the Dirty Water Tank by pulling up on the latch at the back of the tank to open.



3 Remove lid and empty tank.



4 Replace lid by lining up the hinge and pulling latch down to lock. Latch will line up with hinge and snap when secured.



5 Insert Dirty Water Tank at an angle back into cleaner until it clicks into place.

Automatic Shutoff:

Your carpet washer is equipped with a shut-off float. When the Dirty Water Tank becomes full, the float will rise, shutting off the air flow through the nozzle. A higher pitched sound will come from the motor. When activated, empty the dirty water tank.

If the dirty water tank does not appear full, turn off and wait for the float to reset. If the float repeatedly shuts off the suction, empty the dirty water tank.

For best results, use only Hoover® brand cleaning solution. Other solutions may generate excessive foam which will cause the float to shut off the suction.

How to attach your Power Path™ Pro tools*:



1 Place handle in upright position.



2 Slide the hose on the tool's connector until it locks. Push forward with your thumb and on the latch to remove.

⚠ CAUTION ⚠
To reduce risk of injury from moving parts – Unplug before servicing.

⚠ CAUTION ⚠
Not to be used for grooming a pet.

⚠ CAUTION ⚠
Use extra care when cleaning on stairs. To avoid personal injury or damage, and to prevent the cleaner from falling, always place cleaner at bottom of stairs or on floor. Do not place cleaner on stairs or furniture, as it may result in injury or damage.

* Available on select models only.

Upholstery Tool*:

*Select Models Only



The Upholstery Tool's built-in brush provides scrubbing action.

NOTE: Tools are located and stored in Mesh Storage Bag*.

*Select Models Only


Multi-Floor Squeegee*:

*Select Models Only



The Multi-Floor Squeegee extends cleaning from carpet to hard floor. Pivot squeegee on front nozzle and snap back to secure squeegee for hard floor use.

Using your Power Path™ Pro tools:



- 1** Look for the nozzle release at the bottom of the Dirty Water Tank.
Insert hose end connector by inserting firmly into Suction Port.



- 2** Press the button on the end of hose and pull the hose and solution connection from machine to remove.



- 3** Close the nozzle release.


NOTE: Make sure to close door to ensure proper suction.

NOTE: Spot Treater Wand* attachment is the same process as attaching hose to the unit.

NOTE: Upholstery* and SpinScrub® Powered Hand Tool* attach to the hose in the same manner.

*Select Models Only

After using tool:



- 1** Drain suction hose by turning cleaner ON and holding nozzle up for several minutes. Do not press the trigger. Disconnect hose and solution tube from cleaner. Drain solution tube by placing round end in sink and raising the trigger end at the hose nozzle above your head.




- 2** Press the trigger to release air and fluid. Replace Hose and tools in the Mesh Storage Bag*.
*Select Models Only


How to clean upholstery with your Power Path™ Pro:

Read “Before You Begin Cleaning” instructions. Be sure to check Hoover® Cleaning Guide on page 4 and the cleaning code on your upholstery. Use your cleaner only on upholstery marked “W” or “W/S”.


⚠ CAUTION ⚠
To reduce risk of injury from moving parts – Unplug before servicing.



1 Attach hose to the unit. Follow steps "Using your Power Path™ Pro Tools" on page 13.




2 Dry hands and plug into an outlet, then turn ON.



3 Gently press the tool* onto the fabric. Press the trigger and slowly pull the nozzle over the fabric.

*Select Models Only



4 Overlap strokes by 1/2 in. to prevent streaking. Make additional strokes without pressing the trigger to remove more solution.

For heavily soiled areas, repeat the cleaning process.

For best cleaning results, Hoover® recommends to rinse the upholstery with water only. This removes residual cleaning solution.

If additional cleaning is necessary, wait until the upholstery is completely dry before using the tool again.

Empty Dirty Water Tank when the motor sound becomes higher pitched and there is a loss in suction (see “Automatic Shut-Off”).

When finished cleaning, follow “After Cleaning” and “After Using Tool” instructions on page 14.

Keeping your Power Path™ Pro running properly:

Cleaning the dirty water tank:

LUBRICATION


The motor and brushroll are equipped with bearings which contain sufficient lubrication.

Additional lubricant could cause damage. Do not add lubricant to motor or brushroll.


Familiarize yourself with these home maintenance tasks. Proper use and care of your cleaner will ensure continued cleaning effectiveness.

Any other servicing should be done by an authorized service representative. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, take it to a service center prior to continuing use.

Note: During normal use, debris may accumulate inside of dirty water tank. In order to keep your unit functioning properly, rinse out your dirty water tank with fresh water after each use.




1 Remove the Dirty Water Tank by pressing on latch and pulling the tank out at an angle.



2 Pull up on back latch to open Dirty Water Tank. Remove top and rinse tank with clean water.




3 To clean Dirty Water Tank, place it under faucet and dispense high pressure clean water to backflush any loose debris.



Note: The filter screen is not removable. Attempting to remove the filter screen from the tank may damage it

4 Be sure to clean the filter screen located in the duct of the recovery tank base.




5 Allow to air dry completely. Pull up on latch, then back down to lock. Latch will snap when locked. Replace Dirty Water Tank back onto unit until it snaps.

Keeping your Power Path™ Pro running properly:


Cleaning the Nozzle:




1 To prevent leaking, remove Solution Tank and Dirty Water Tank. With handle in upright position, tilt carpet washer back.



2 Pull up on nozzle latch to unsnap nozzle from the base of the carpet washer.




3 Pull nozzle forward to remove.



4 Rinse debris from the nozzle.

NOTE: If lint or other debris becomes lodged in nozzle, it can be removed for cleaning.

⚠ CAUTION ⚠
To reduce risk of injury from moving parts – Unplug before servicing.



5 Position nozzle onto the base, making sure to align the tabs at the bottom of the nozzle with the notches on the base.



6 Press down on nozzle latch. It'll click.

STORAGE


Before storing:

- Empty Solution Tank and let air dry.
- Empty Dirty Water Tank, rinse tank and lid thoroughly with clean water and let air dry.
- Replace tanks on cleaner.


Allow brushes and underside of carpet cleaner to air dry thoroughly before storing cleaner on a carpeted or wood surface.

Keeping your Power Path™ Pro running properly:


Cleaning SpinScrub® Brushes:



1 Flip cleaner on back.



2 Grasp SpinScrub® Brushes and pull out.




3 Rinse off debris. Replace SpinScrub® Brushes by lining up tab and pushing back in.

Keeping your Power Path™ Pro running properly:


Removing the flat belt:




- 1** Flip cleaner on its back to expose bottom of cleaner. Make sure nozzle and SpinScrub® Brushes are removed.



- 2** To access the belt, remove the 8 Philips screws. Circles show location of screws.




- 3** Flip cleaner to the upright position.



- 4** Press the ON/OFF button and the handle release button to loosen hood.

⚠ CAUTION ⚠
To reduce risk of injury from moving parts – Unplug before servicing.



- 5** Pull up on hood and move to side. Hood will still be attached to unit.



- 6** Make sure unit is in upright position. Slide off flat belt and replace with new belt. To reassemble, reverse steps.

Belt: What to Buy

For replacement belts please order part number 440006154 for tooth/timing belt or 440006155 for flat belt. To locate a dealer nearest you, please call 1-800-944-9200 or visit our website at www.hoover.com.

NOTE: Flat belt is smooth while timing belt has teeth.

Hoover Cleaning Solution Guide:

	Clean Plus 2x	Pet Plus 2x	Pro Plus 2x	Professional Strength	Multi-Floor Plus
Sizes available	32 oz./64 oz.	32 oz./64 oz.	32 oz./64 oz.	50 oz.	32 oz./64 oz.
Power Path™ Pro Carpet Washer	✓	✓	✓	✓	✓

For optimal performance use Hoover® brand solutions, wipes and spot cleaners available at Hoover.com and retailers nationwide.

⚠ WARNING ⚠

To reduce risk of fire and electric shock due to internal component damage, use only Hoover® cleaning products intended for use with the appliance as noted below.

Need Help?

If you need further assistance:

If your product needs servicing within the warranty period, please contact Customer Service at 1-800-944-9200; Mon-Fri 8am-7pm EST. Always identify your carpet washer by the complete model number when requesting information or ordering parts. (The model number of the carpet washer is located on the data plate)

PLEASE DO NOT RETURN THIS CLEANER TO THE STORE.

QUESTIONS OR CONCERNS?

Contact Us:

(800) 944-9200

For a Complete Troubleshooting Guide, see:

Twitter: @HooverUSA

Facebook: facebook.com/hoover

Do not return to store. See back of product for model number.

Troubleshooting:

Any other servicing should be done by an authorized service representative.

USE TROUBLESHOOTING GUIDE AS A FIRST STEP TO RESOLVE ANY PROBLEMS YOU MAY BE EXPERIENCING.

If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, call Customer Service at 1-800-944-9200 for further instruction before continuing use.



WARNING



To reduce the risk of personal injury - Unplug before cleaning or servicing.

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
Cleaner won't run	<ol style="list-style-type: none"> 1. Power cord not firmly plugged into outlet. 2. Blown fuse or tripped breaker. 3. Needs service. 	<ol style="list-style-type: none"> 1. Plug unit in firmly. 2. Check fuse or breaker in home. Replace fuse/reset breaker in home. 3. Take to service center. To find nearest location, visit our website at www.hoover.com or call 1-800-944-9200.
Cleaner won't pick-up or low suction	<ol style="list-style-type: none"> 1. Dirty Water Tank is not installed correctly. 2. Dirty Water Tank is full. 3. Dirty Water Tank is clogged. 4. Air path is clogged. 	<ol style="list-style-type: none"> 1. Review Placing Dirty Water Tank in base of cleaner - Pg. 8. 2. Empty Dirty Water Tank. 3. Clean Dirty Water Tank. 4. Unclog air path.
Water escaping from Cleaner	<ol style="list-style-type: none"> 1. Dirty Water Tank is full. 2. Dirty Water tank is not installed correctly. 3. Clean Water Solution Tank not installed properly. 	<ol style="list-style-type: none"> 1. Empty Dirty Water Tank. 2. Review Placing Dirty Water Tank in base of cleaner 8. 3. Review Clean Water Solution Tank Installation.
Cleaner won't dispense	<ol style="list-style-type: none"> 1. Clean Water Solution Tank is empty. 2. Clean Water Solution Tank not installed properly. 3. Needs service. 	<ol style="list-style-type: none"> 1. Fill Clean Water Solution Tank. 2. Review Clean Water Solution Tank Installation. 3. Take to service center. To find nearest location, visit our website at www.hoover.com or call 1-800-944-9200.
Hose nozzle will not spray after filling the Clean Water Tank or Detergent Container.	<ol style="list-style-type: none"> 1. Air is trapped in the pump and hose. 2. The connection to the tool port is loose. 	<ol style="list-style-type: none"> 1. Turn on the cleaner. If hose does not spray, prime the pump by lowering the hose down to the floor and hold the trigger for up to 1 minute. 2. Ensure that the Hose is securely connected to the hose connection.
Motor noise becomes high-pitched	<ol style="list-style-type: none"> 1. Dirty Water Tank is full. 2. Dirty Water Tank is clogged. 3. Air path is clogged. 4. The float in the Dirty Water Tank has been activated. 	<ol style="list-style-type: none"> 1. Empty Dirty Water Tank. 2. Clean Dirty Water Tank. 3. Unclog air path. 4. Review Emptying & Cleaning the Dirty Water Tank.
Brushrolls are not spinning	<ol style="list-style-type: none"> 1. Belt needs to be changed. 2. Something is jammed in the brushroll. 	<ol style="list-style-type: none"> 1. Refer to how to change belt. 2. Remove jammed item from cleaner with unit turned off and unplugged.

WARRANTY

LIMITED SIX MONTH WARRANTY (DOMESTIC USE)

WHAT THIS WARRANTY COVERS

When used and maintained in normal household use and in accordance with the Owner's Manual, your HOOVER® remanufactured product is warranted against original defects in material and workmanship for six months from date of purchase (the "Warranty Period"). During the Warranty Period, Hoover® will provide labor and parts, as described in this Warranty, to correct any such defect in products purchased in the United States, U.S. Military Exchanges and Canada.

HOW TO MAKE A WARRANTY CLAIM

If this product is warranted, take the product to a Hoover® Authorized Warranty Service Dealer along with proof of purchase. If you need assistance: Visit our website at hoover.com. Follow the authorized dealer locator link to find the Hoover® authorized dealer nearest you or call 1-800-944-9200 for an automated referral of Hoover® authorized dealer locations (U.S. Only) or speak with a customer service representative.

WHAT THIS WARRANTY DOES NOT COVER

This Warranty does not cover: Bags, belts, brushes, light bulbs, use of the product in a commercial operation (such as maid, janitorial, and equipment rental services), improper maintenance of the product, damage due to misuse, acts of God, nature, vandalism or other acts beyond the control of Hoover®, owner's acts or omissions, use outside the country in which the product was initially purchased and resale of the product by the original owner. This warranty does not cover pick up, delivery, transportation or house calls.

OTHER IMPORTANT TERMS

This warranty is not transferable and may not be assigned. This Warranty shall be governed and constructed under the laws of the state of Ohio. The Warranty Period will not be extended by any replacement or repair performed under this Warranty.

THIS WARRANTY IS THE EXCLUSIVE WARRANTY AND REMEDY

PROVIDED BY HOOVER®. ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE, ARE DISCLAIMED. IN NO EVENT WILL HOOVER® BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY KIND OR NATURE TO OWNER OR ANY PARTY CLAIMING THROUGH OWNER, WHETHER BASED IN CONTRACT, NEGLIGENCE, OR STRICT PRODUCTS LIABILITY OR ARISING FROM ANY CAUSE WHATSOEVER. Some states do not allow the exclusion of consequential damages, so the above exclusion may not apply to you. This warranty gives you specific rights; you may also have others that vary from state to state.



#RethinkCleaning

Hoover.com

Find us on:



youtube.com/hover



facebook.com/hover



twitter.com/hoverusa