


Replacement of Pivotrol (Patented)[®] Motive Inlet Valve


Warning: Ensure that system is isolated/relieved of all pressure prior to ANY work being done.


- 1. Disconnect any motive inlet or exhaust piping to the cover mechanism.
- 2. Loosen and remove all cover bolts using the following socket/wrench sizes:

PTC/PTF: ¾" PTF-HTF: 15/16" PTF4: 11/4" PTF-HP: 36 mm

- 3. Secure cover mechanism using lifting hook located on top of cover.
- 4. Lift cover mechanism from pump body carefully:







- 5. Inspect cover gasket and bolts for damage. Replace if needed.
- 6. Remove the (3) or (2) bolts that secure the mechanism frame to the cover using a ¾" socket or wrench. PTC/PTF/PTF-HTF: You may need to loosen one of the (2) baffle screws using a ¾6" Allen key/socket and carefully swing baffle out of the way.


PTC/PTF/PTF-HTF




PTF4/PTF-HP



- 7. Carefully remove the entire mechanism frame assembly and sit to the side.
- 8. Loosen the motive inlet valve using a 1" socket or wrench.



- 9. Inspect the motive inlet valve gasket and replace if necessary.
- 10. Replace with the new inlet valve. Tighten to recommended torque of 85 90 ft/lbs.
- 11. Replace the mechanism frame back on to the cover. Tighten bolts to recommended torque of 30 34 ft/lbs.
- 12. For PTC/PTF/HTF only: Return baffle back to position and torque screw to 12 15 ft/lbs using a 3/46" Allen Socket.



- **13.** Check inlet valve gap setting with a .050" gauge strip(s). Check the float arm gap setting with a .020" gauge strip(s).
- 14. Return cover mechanism back to pump body. Ensure cover gasket is in place. Refer to IMI-5-201 Sections 5.0 - 5.2 and Figure 11 for replacing the cover mechanism assembly and recommended torque values for the cover bolts.
- 15. Reconnect all motive inlet and exhaust piping.

SPIRAX SARCO, INC. • 1150 NORTHPOINT BLVD. • BLYTHEWOOD, SC 29016 spiraxsarco.com/global/us
PHONE 803-714-2000 • FAX 803-714-2200



