

Limerick Airport Business Center Pottstown, PA 19464 Fax: (610)495-5134 www.watsonmcdaniel.com

## INSTALLATION

1. Before installing the trap, blow out piping thoroughly to remove loose scale and dirt. Use pipe dope or teflon tape sparingly when attaching the trap to the pipe. Observe the pressure limitation shown on the trap label.

2. Install the trap below the equipment being drained in a location easily accessible for maintenance and inspection. Be certain that the flow arrow on the trap points in the proper direction.

3. Install a drip pocket to keep dirt away from the trap.

4. Discharge piping should be amply sized to avoid excessive back pressures.

5. To provide for easy maintenance and service, install a block valve on each side of the trap and install a strainer ahead of the inlet connection.

6. All valves should be full ported to achieve the rated capacity of the trap.

7. If discharge piping is to be elevated, be certain that the available differential pressure is adequate to permit proper drainage. Remember, two feet of lift equals approximately one psig.

### MAX. OPERATING CONDITIONS

PMO 75 PSIG TMO Sat. Steam Temp. PMA 75 PSIG at 450°F TMA 450°F @ 75 PSIG

### TROUBLESHOOTING


### PROBLEM


CAUSE

- 1. Trap does not discharge. a) Damaged float.
  - b) Operating pressure too high.
- 2. Trap does not close.
- a) Dirt lodged on valve disc or thermostat seat area.b) Worn out internals; damaged thermostat.

# SERIES FT FLOAT & THERMOSTATIC STEAM TRAP INSTALLATION INSTRUCTIONS

## INSTRUCTION PART NO. 2265700 REVISION 2





## **ORDERING SPARE PARTS**

Specify the descriptions of the part. Indicate the Model Number, Size, and Operating Pressure, which are shown on the name plate.

Typical Specification: Cover & Gasket for 1" FT-8 steam trap

#### ACTION

- a) Replace float.
- b) Install trap suitable for operating pressure.
- a) Clean trap; replace thermostat; install strainer
- b) Replace internals or thermostat; be sure to match model no. and pressure

Each Watson McDaniel Company Product is warranted against defects in material and workmanship for one year from date of shipment. This warranty extends to the first retail purchaser only. All defective material must be returned to the person from whom you purchased the Product, transportation prepaid, free of any liens or encumbrances, and if found to be defective will be repaired free of charge or replaced, at the warrantor's or seller's option. If the material is replaced, any replacement will be invoiced in the usual manner and after inspection of alleged defective material an adjustment will be made for depreciation caused by purchaser's use. In no event will Watson McDaniel Company be liable to do more than refund the original contract price. Incidental and consequential damages are excluded, whether under this warranty or otherwise. All implied warranties, including warranties of merchantability and fitness for a particular purpose, are disclaimed and excluded.