

TRUE WIRELESS BUD STYLE EARPHONES

HPK13141 - HPW13142



USER MANUAL

Multifunction Buttons

NOTE: Some features may differ pending paired device software versions and platforms.

	Left Earphone (L)	Right Earphone (R)
Play / Pause	Single Click	Single Click
Reply/End Calls	Single Click	Single Click
Refuse Calls	Press and Hold	Press and Hold
Previous Track	Double Click	
Next Track		Double Click
Volume -	Triple Click	
Volume +		Triple Click
Voice Assistant	Press and Hold for 3 Seconds	Press and Hold for 3 Seconds

Auto Power Off

Earphones will automatically turn off if there is no operation for 3 minutes after removing from the charging case.


Pairing Left and Right Earphones

If the connection from right to left is lost, place both earphones back in the charging case. Wait a few seconds and then remove both earphones from the charging case and they will re-connect automatically. If this procedure does not work, disconnect the earphones from your device, wait a few minutes, then reconnect them (both earphones must be placed inside the charging case). For both procedures it is necessary that the earphones inside the charging case are charging, make sure that the charging case is sufficiently charged to complete this function.

Maintenance

Do not use abrasive cleaning solvents to clean the product. Do not touch the product with any sharp object as this will cause scratching and damage. Please keep the product away from high-temperature, dust, humidity & liquids.

Product Overview



Specification

Bluetooth® Version	: 5.3
Driver Size	: 8mm
Earphone Charging Time	: 1.5hr
Charge Case Charging Time	: 2hr
Earphone Battery Type	: Li-polymer 3.7V/40mAh
Charge Case Battery Type	: Li-polymer 3.7V/280mAh
Sensitivity	: 103dB ± 3dB
Frequency Response	: 20Hz-20KHz
Bluetooth® Range	: 10m
Playing Time	: 16 Hours including case
Standby Time	: 60hr
Operation Temperature	: 0°-40°C

Charging

Charge the battery to full capacity before first time use. To charge, plug the charging cable into the product charging port connecting it to a charger/PC with a USB port (5V, 1A). The blinking light on the front of the charging case shows the progress. When the light stops blinking, the charging case is fully charged.

Once you place the earphones inside the charging case, the earphones will automatically charge from the battery inside the case. When the earphones require charging you will hear a prompt through the earphone speaker and the earphone light on the case will flash indicating charging is required.

WARNING: The earphones can only be used with the provided charging case!

Turning On and Pairing

Remove the earphones from the charging case and they automatically turn ON. The earphones must be connected to a device within 3 minutes, otherwise the earphones will go into power saving mode. To activate the pairing mode again, simply put the earphones back in the charging case and wait a few seconds before repeating the above procedure again.

Turn ON the Bluetooth on your device, go to the Bluetooth menu, search for "HPK13141/HPW13142", select to pair and connect. You will hear "Connected" sound play through the earphone when pairing is complete.

Special Note: *Before using the earphones for the first time, place both earphones into the supplied charging case once and then remove them. This will activate the multifunction button option.*

Automatic Reconnection

When the earphones are removed from the case they will automatically turn ON and sync to each other. If they have previously been paired to a device, they will automatically re-connect provided it is within range.

MONO/STEREO Function

You can use only one earphone to listen to music and take calls. This function (MONO function) is available for both earphones. To use this function, remove one earphone from the charging case. To switch to the STEREO mode, remove the second earphone at any time. To switch to MONO mode, place one earphone back into the charging case.

Read this user manual before using the product.

Keep the user manual for future reference and include it when passing the product to third parties.

Liquid Ears will not in any way be held responsible for injury or damage caused to persons or property arising from misuse of the product.

WARNING: The included charging cable is for use with this product only.

Charging cable maximum load: 5V/1A



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by The Crest Company is under licence. Other trademarks and trade names are those of their respective owners.

WARNING Do not dispose of unit in fire or water. • Never attempt to disassemble and reassemble. • Waste electrical products should not be disposed of with household waste, please recycle where facilities exist. • Check with your local authority for recycle advice.

- Keep your device and all accessories out of the reach of children and animals.
- Small parts may cause choking or serious injury if swallowed.
- Avoid exposing your device to very cold or very hot temperatures (below 0°C or above 45°C).
- Extreme temperatures can cause deforming of the device and reduce the charging capacity and life of your device.
- Do not allow your device to get wet—liquids can cause serious damage.
- Do not handle your device with wet hands.