




4.5L Air Fryer

Operating and Safety Instructions

Model: AF-311A-W



- FOR INDOOR HOUSEHOLD USE ONLY-

For your safety and continued enjoyment of this product, always read the instruction manual carefully before using.



CONTENTS

■ Specification & Feature	01
■ Important Safeguards.....	03
■ Save These Instructions	03
■ Control Panel Instructions	07
■ Operation Instructions	08
■ Troubleshooting	12

Specification & Feature

Voltage: AC220-240V~50Hz

Wattage: 1500 Watt

Capacity of basket: 4.5 L

Adjustable temperature: (50-205) °C

Timer: (0-60) min

General description (Fig.1)

- 1 Top cap
- 2 Control panel
- 3 Gridiron
- 4 Pot
- 5 Basket handle
- 6 Air outlet
- 7 Power cord




Fig.1

Warning: Hot Surface!
Advertencia: ¡Superficie Caliente!
Avertissement: Surface Chaude!

Fig.2




Fig.3




Fig.4




Fig.5




Fig.6

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed including the following:

- Read all instructions.
- Do not touch hot surfaces.
- To protect against electric shock do not immerse cord, plugs, or base in water or other liquid.
- **WARNING:** This electrical appliance contains a heating function. Surfaces, also different than the functional surfaces, can develop high temperatures. Since temperatures are differently perceived by different persons, this equipment shall be used with **CAUTION**. The equipment shall be touch only at intended handles and gripping surfaces, and use heat protection like gloves or similar. Surfaces other than intended gripping surfaces shall get sufficiently time to the cool down before getting touched.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Type Y: If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord in the wall outlet. To disconnect, turn any control to "off," then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- The appliances are not intended to be operated by means of an external timer or separate remote-control system.

Save These Instructions

Introduction

This all now Hot-air fryer provides an easy and healthy way of preparing your favorite ingredients. By using hot rapid air circulation and a top Removable Crisping Insert, it is able to make numerous dishes. The best part is that the Hot-air fryer heats food at all directions and most of the ingredients do not need any oil.

Important


Please read this manual carefully before you use the appliance and save it for future reference.

Danger

- Never immerse the housing, which contains electrical components and the heating elements, in water or rinsing under the tap
- Avoid any liquid enter the appliance to prevent electric shock or short-circuit.
- Keep all ingredients in the Removable Crisping Insert or prevent any contact from heating elements.
- Do not cover the air outlet when the appliance is working.
- Fill the pot with oil may cause a fire hazard.
- Don't touch the inside of the appliance while it is operating.

Warning

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Check if the voltage indicated on the appliance fits the local mains voltage.
- Do not use the appliance if there is any damage on plug, mains cord or other parts.
- Do not go to any unauthorized person to replace or fix damaged main cord.
- Keep the mains cord away from hot surfaces.
- Do not plug in the appliance or operate the control panel with wet hands..
- Do not place the appliance against a wall or against other appliances. Leave at least 10cm free space on the back and sides and 10cm free space above the appliance.
- Do not place anything on top of the appliance.
- Do not use the appliance for any other purpose than described in this manual.
- Do not let the appliance operate unattended.
- During hot air frying, hot steam is released through the air outlet openings, Keep your hands and face at a safe distance from the steam and from the air outlet openings.
- Also be careful of hot steam and air when you remove the pot from the appliance.
- Any accessible surfaces may become hot during use (Fig.2)
- Immediately unplug the appliance if you see dark smoke coming out of the appliance. Wait for the smoke emission to stop before you remove the pay from the appliance.



Caution

- Ensure the appliance is placed on a horizontal, even and stable surface.
This appliance is designed for household use only. It may not be suitable to be safely used in environments such as staff kitchens, farms, motels, and other non-residential environments. Nor is it intended to be used by clients in hotels, motels, bed and breakfasts and other residential environments.
- If the appliance is used improperly or for professional or semi-professional purposes or if it is not used according to the instructions in the user manual, the guarantee becomes invalid and we could refuse any liability for damage caused.
- Always unplug the appliance while not using.
- The appliance needs approximately 30 minutes to cool down for handling or cleaning safely.

Automatic switch-off

This appliance is equipped with a timer, when the timer has counted down to 0, the appliance produces a bell sound and switches off automatically. To switch off the appliance manually, turn the timer knob anticlockwise to 0.

Before first use

1. Remove all packaging materials
 2. Remove any stickers or labels from the appliance
 3. Thoroughly clean the Removable Crisping Insert and pot with hot water, some washing-up liquid and a non-abrasive sponge.
 4. Wipe inside and outside of the appliance with a moist cloth.
- This is an oil-free fryer that works on hot air, Do not fill the pot with oil or frying fat.

Preparing for use

1. Place the appliance on a stable, horizontal and even surface.
Do not place the appliance on non-heat-resistant surface.
2. Place the gridiron in the pot (Fig.3).
3. Pull the cord from the storage compartment which locates on the bottom of the appliance.
Do not fill the pot with oil or any other liquid.
Do not put anything on top of the appliance, the airflow will be disrupted and affects the hot air frying result.

Using the appliance

The oil-free can prepare a large range of ingredients. The recipe booklet included helps you get to know the appliance.

Hot air frying

1. Plug in the mains plug..
2. Carefully pull the pot out of the Hot-air fryer (Fig.6)
3. Put the ingredients in the Removable Crisping Insert. (Fig.5)

Note: Do not exceed the MAX indicator (see section "settings" in this chapter), as it may effect the quality of the food.

4. Slide the pot back into the Hot-air fryer (Fig 4)
Noting to carefully align with the guides in the body of the fryer.
Never use the pot without the Removable Crisping Insert in it.


Caution: Do not touch the pot during and some time after use, as it gets very hot. Only hold the pot by the handle.

5. Determine the required preparation time for the ingredient (see section 'Settings' in this chapter).
Add 3 minutes to the preparation time when the appliance is cold.

Note: If you want, you can also let the appliance preheat without any ingredients inside. Then fill the Removable Crisping Insert and turn the timer knob to the required preparation time.

- a. The timer starts counting down the set preparation time.
- b. Excess oil from the ingredients is collected on the bottom of the pot.

Control Panel Instructions



Recipe indicator

No.	1	2	3	4	5	6	7	8
Presets	Preheat	Drumsticks	Steak	Fries	Desserts	Vegetables	Fish	Reheat
Food(g)	/	800	350	500	300	400	400	/
Temp(°C)	205	195	205	195	150	150	175	175
Time(min)	5	25	6	22	30	12	8	15



Operation Instructions

1. Connect the main plug into an earthed wall socket.
2. Carefully pull the pot out of the air fryer (fig.6).
3. Put the gridiron into pot.
4. Place the ingredients on the gridiron.
5. Slide the pot back into the AIR FRYER (fig. 4) .


Note: Do not exceed the MAX indication , as it may affect the quality of the cooked food.


Caution: Do not touch the pot while the unit is operating and right after the cooking process as it gets very hot. Only hold the pot by the handle.







Do not fill the pot with oil or any other liquid.

6. Tap the "Power"  key to light the whole screen.
7. Tap the "Menu"  key to choose your desired function (8 Preset Functions Are Available). Time & temperature setting can be adjusted, and adjustment can be made directly by pressing corresponding keys.

Notes: 8 Preset Functions are provided: Preheat, Drumsticks, Steak, Fries, Desserts, Vegetables, Fish, Reheat.

Tap the "Time/Temp"  key once. There are two keys (for TEMPERATURE '^' & 'v') in the control panel which can adjust the temperature setting - Increase/Decrease 5 degrees per press or increase/decrease rapidly by long press.

Tap the "Time/Temp"  key again. There are two keys (for TIME '^' & 'v') on the control panel which can adjust time setting - Increase/Decrease 1 minute per press or increase/decrease rapidly by long press.

8. After choosing the function, Please press "Start/Pause"  key to start cooking .
Reminder: During the hot air frying process, The LED "fan"  indicator and the LED "heat"  indicator will light up.
then if you Press the "Start/Pause"  key ,The LED "fan"  indicator will go out after a few minutes and the LED "heat"  indicator will go out immediately.
9. Some ingredients require shaking halfway through the preparation time (see section "Settings" in this chapter). To shake the ingredients, pull the pot out of the appliance by the handle and shake it. Then slide the pot back into the air fryer.

Tip: If you set the timer to half the preparation time, you hear the timer bell when you have to shake the ingredients. However, this means that you have to set the timer again to the remaining preparation time after shaking.

10. When you hear the timer bell, the set preparation time has elapsed. Pull the pot out of the appliance and place it on a heat resistant table.
Note: You can also switch off the appliance manually. Press Power' key 3 second, unit turns off.
11. Check if the ingredients are cooked ready.
If the ingredients are not cooked ready yet, simply slide the pot back into the appliance and set the timer to a few extra minutes.
12. To remove ingredients (e.g. fries), pull the pot out of the Hot-air fryer and place it on a heat resistant table.
Do not turn the pot upside down with the gridiron still attached to it, as any excess oil that has collected on the bottom of the pot will leak onto the ingredients.
Depending on the different types of ingredients, steam may escape from the pot while the ingredients are heating.
13. Pour ingredients from pots into bowls or plates.
Tip: To remove large or fragile ingredients, lift the ingredients out of the basket by a pair of tongs
14. When a batch of ingredients is ready, the Hot-air fryer is instantly ready for preparing another batch.

Important

This table below will help you to select the basic settings for the ingredients.

Note: Keep in mind that these settings are indications. As ingredients differ in origin, size, shape as well as brand, we cannot guarantee the best setting for your ingredients.

Because the Rapid Air technology instantly reheats the air inside the appliance instantly Pull the pot briefly out of the appliance during hot air frying barely disturbs the process.

Tips

- Smaller ingredients usually require a slightly shorter preparation time than larger ingredients.
- A larger amount of ingredients only requires a slightly longer preparation time, a smaller amount of ingredients only requires a slightly shorter preparation time.
- Shaking smaller ingredients halfway through the preparation time optimizes the end result and can help prevent unevenly fried ingredients.
- Add some oil to fresh potatoes for a crispy result. Fry your ingredients in the Hot-air fryer within a few minutes after you added the oil.
- Do not prepare extremely greasy ingredients such as sausages in the Hot-air fryer .
- Snacks that can be prepared in a oven can also be prepared in the Hot-air fryer
- The optimal amount for preparing crispy fries is 500 grams.
- Use pre-made dough to prepare filled snacks quickly and easily. Pre-made dough also requires a shorter preparation time than home-made dough.
- Place a baking tin or oven dish in the Hot-air fryer basket if you want to bake a cake or quiche or if you want to fry fragile ingredients or filled ingredients
- You can also use the Hot-air fryer to reheat ingredients. To reheat ingredients, set the temperature to 150°C for up to 10 minutes.

	Min-max Amount (g)	Time (min.)	Temperature (°C)	Shake	Extra information
Potato & fries					
Thin frozen fries	300-400	15-20	200	shake	
Thick frozen fries	300-400	20-25	200	shake	
Potato gratin	500	20-25	200	shake	
Meat & Poultry					
Steak	100-500	15-20	180		
Pork chops	100-500	15-20	180		
Hamburger	100-500	15-20	180		
Sausage roll	100-500	13-15	200		
Drumsticks	100-500	15-22	180		
Chicken breast	100-500	15-20	180		
Snacks					
Spring rolls	100-400	8-10	200	shake	Use oven-ready
Frozen chicken nuggets	100-500	10-15	200	shake	Use oven-ready
Frozen fish fingers	100-400	15-20	200		Use oven-ready
Frozen bread crumbed	100-400	8-10	180		Use oven-ready
cheese snacks					
Stuffed vegetables	100-400	10-15	160		
Baking					
Cake	300	10-15	160		Use baking tin
Quiche	400	20-22	180		Use baking tin/oven dish
Muffins	300	15-18	200		Use baking tin
Sweet snacks	400	20	160		Use baking tin/oven dish

Note: Add 3 minutes to the preparation time when you start frying while the Hot-air fryer is still cold.

Cleaning

Clean the appliance after every use.

The pot and the non-stick coating Removable Crisping Insert. Do not use metal kitchen utensils or abrasive cleaning materials to clean them, as this may damage the non-stick coating.

1. Remove the mains plug from the wall socket and let the appliance cool down.

Note: Remove the pot to let the Hot-air fryer cool down more quickly.

2. Wipe the outside of the appliance with a moist cloth.

You can use degreasing liquid to remove any remaining dirt.

Tip: If dirt is stuck to the Removable Crisping Insert or the bottom of the pot, fill the pot with hot water with some washing-up liquid. Put the Removable Crisping Insert in the pot and let the pot and the Removable Crisping Insert soak for approximately 10 minutes.

3. Clean the inside of the appliance with hot water and non-abrasive sponge.

4. Clean the heating element with a cleaning brush to remove any food residues.

Storage

1. Unplug the appliance and let it cool down.

2. Make sure all parts are clean and dry.

Environment

Do not throw away the appliance with the normal household waste when it is exhausted, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment

Guarantee and service

If you need service or information or if you have a problem, please contact your local authorized service centre

Troubleshooting

Problem	Possible Cause	Solution
The Hot-air fryer does not work	The appliance is not plugged in.	Put the mains plug in polarized outlet.
The ingredients fried with the air fryer are not done.	The amount of ingredients in the Removable Crisping Insert is too big.	Put smaller batches of ingredients in the Removable Crisping Insert. Smaller batches are fried more evenly.
The ingredients are fried unevenly in the air fryer.	Certain types of ingredients need to be shaken halfway through the preparation time.	Ingredients that lie on top of or across each other (e.g. fries) need to be shaken halfway through the preparation time. See section 'Settings' in chapter 'Using the appliance'.
Fried snacks are not crispy when they come out of the air fryer.	You used a type of snacks meant to be prepared in a traditional deep fryer.	Use oven snacks or lightly brush some oil onto the snacks for a crispier result.
White smoke comes out of the appliance.	You are preparing greasy ingredients.	When you fry greasy ingredients in the air fryer, a large amount of oil will leak into the pot. The oil produces white smoke and the pot may heat up more than usual. This does not affect the appliance or the end result.
Fresh fries are fried unevenly in the air fryer.	You did not use the right potato type.	Use fresh potatoes and make sure they stay firm during frying.
Fresh fries are fried unevenly in the air fryer.	The crispiness of the fries depends on the amount of oil and water in the fries.	Rinse the potato sticks properly to remove starch from the outside of the sticks.

Acekool

Your home in sync

Model: AF-311A-W

Email: support@acekool.vip

Website: <https://www.acekool.vip>

Made in China

