

Assembly Instructions For The Poly Marlboro Swingbed

Tools Needed For Assembly

Hammer For Light Tapping
7/16" Wrench or Socket
1/2" Wrench or Socket
Ratchet
Screwgun

Parts List

Seat Assembly (1)
Back Assembly (1)
Left Arm Assembly (1)
Right Arm Assembly (1)
Chains Or Ropes (4)

Hardware

1/4" x 4-1/2" Carriage Bolts (2)
1/4" x 3" Carriage Bolts (6)
1/4" Washers (16)
1/4" Hex Nuts (8)
5/16" x 3-1/4" Eyebolts (4)
5/16" Hex Nuts (4)

Step 1 Bolt the seat and back assemblies together with the 4-1/2" bolts. Put a small washer under the 1/4" nut. Semi-tighten only with the 7/16" socket. **Note: Do not fully tighten these nuts until all bolts are put in the arms in Step 2. This allows the back to be adjusted.**

Step 2 Fasten the arms to the seat and back. Align the holes in the bottom of the arm assembly with two of the holes on the side of the bed. (The first hole in the front is used to attach the eyebolt). Put a 3" bolt through the holes in the bottom of the arm and attach to the bed by putting on 1/4" washers and 1/4" nuts and tightening with the 7/16" socket. Put another 3" bolt through the hole in the block on the back of the armrest, align with the bottom hole on the back assembly and put on a washer and 1/4" nut and tighten. (**Note:** If the holes do not line up properly loosen the nuts on the bottom of the seat assembly then the back can be adjusted). Now tighten all nuts.

Step 3 Put a 1/4" washer on a 3-1/4" eyebolt & put through the hole above the arm on the back assembly. (The eye of the bolt belongs on the outside). Put another 1/4" washer on the inside & put on a 5/16" hex nut and tighten with the 1/2" wrench. Repeat on the other side. Now find the predrilled holes in the side of the seat in front of the arm braces. Repeat above steps & put eyebolts in both holes.

If your swingbed has chains go to Step 4, if it has ropes skip Step 4 and go to Step 5.

Step 4 Attach the chains to the swingbed. **NOTE:** If you cannot hook the chain onto the eyebolts loosen the nuts on the end of the eyebolts. Turn the eyebolts so the opening is turned down. Now fully tighten the hex nuts with the 1/2" wrench while holding the head of the eyebolt. Attach the chain to hooks at the ceiling. (You will need to get the hooks unless you ordered our swing hanging kit). The Marlboro swingbeds should be hung from four points at the ceiling.

Step 5 Attach the rope to the swingbed. Take a rope, put the end through the hole in the armrest, & through the eyebolt below the arm. Pull on through the eyebolt & make a knot in the end of the rope. (See photos below). Attach another rope to the eyebolt in the back assembly the same way then repeat on other side. The swingbed is now ready to hang. Hook the rings on hooks at the ceiling or if you purchased comfort springs hook the rings on one end of the springs and hook the other end of the springs to the ceiling. The Marlboro swingbeds should be hung from four points at the ceiling.

Step 6 You will now need to adjust the ropes until the swingbed is at the desired height. The ropes are all fully adjustable. To lower the swingbed push the bottom loops on the end of the rope further up the rope then hold the top loops with one hand & pull the end of the rope up through the loops. To raise the swingbed pull the rope through the loops in the opposite direction. The ropes attached to the front of the swingbed will need to be adjusted to a different length than the ropes attached to the back. If the swingbed hangs crooked adjust the ropes accordingly until it hangs properly.
How to make a knot:

