



Warning

- Please use the original USB cable in the box to charge the lamp.
- Make sure charging and plug-in are done safely according to local standards.
- Keep the lamp dry and away from rain and wet areas.
- Battery care: Charge the lamp as soon as the light gets dim. If you're not using it, fully charge it every three months to keep the battery in good condition.
- The LED light in this lamp can't be replaced. When it stops working, you'll need to get a new lamp.
- Don't try to open the lamp for repairs or cleaning unless you're qualified.

Contents

- 1 x Cordless LED Table Lamp
- 1 x USB Type-C Charging Cable
- 1 x Instruction Manual

Operations

1. We don't ship our lamps with fully charged batteries for safety reasons. Please charge it before first use. Follow the steps below for your lamp to perform at optimum service life.
2. To charge the lamp, plug the USB cable into the port on the side of the lamp base. The light on the charger will turn red while charging and change to green when the lamp is fully charged.
3. Touch the top of the lampshade to cycle through Low, Medium and High brightness and Off.
4. If the lamp doesn't charge after not being used for some time, try charging it for 24 hours to reactivate the battery.

Care & Cleaning

- Wipe the exterior of the lamp with a soft, damp cloth, never use metal polish or cleaner, and dry thoroughly.

Warranty

- Our lamps come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure. Where a failure does not amount to a significant fault, Tomkin Australia is entitled to choose between providing you with a repair, replacement or refund.

The manufacturer warrants the lamp to be free from defects in materials for 12 months from the date of purchase.

To claim under this warranty, please contact Tomkin Australia with proof of purchase.