

V 1.0

AM-10 REVISION 2 MANUAL



It is important that you read this manual before attempting the installation of your battery. Please take note of certain steps to ensure correct inverter compatibility.

Please visit www.hubblelithium.co.za for the latest version of this manual.



WARNING:

Working with high voltage systems is dangerous. Do not attempt to modify your inverter and battery setup unless you are certain you understand the risk. Speak to a qualified electrician if you are unsure.

INDEX

PRODUCT DESCRIPTION	3
INTERFACE & SIZE	4
PARALLEL CONNECTION OF BATTERIES	5
INSTALLATION NOTES	6
DIP SWITCH SETTINGS	8
INTERFACE DEFINITION	10
INTERFACE FUNCTIONS	12
PARALLEL FUNCTIONS	14
WARNINGS	15
COMPLETING SETUP	16

PRODUCT DESCRIPTION



SMART

Every module is equipped with an independent BMS system.



EASY INSTALLATION

Just plug & play.



SAFE

Safe lithium iron phosphate battery cell.



CERTIFIED

CE IEC UN38.3 MSDS.



MODULAR

Modular expansion



LONGER LIFETIME

6000 cycles, 15 years design life.

TECHNICAL SPECIFICATIONS

Model	AM-10
Battery Type	LiFePO4 (LFP)
Normal Voltage (V)	51.2V
Normal Energy (KWH)	10KWH
Design Capacity	200AH
Design Years	15 Years

PRODUCT SIZE

Size	673*618*193mm
Weight	89kg

TECHNICAL PARAMETER

Cycle Life	Unlimited Cycles within the 10 year warranty. T's & C's Apply.
Operating Voltage Range	40V-58.4V
Charging Voltage	DC 58.4V
Charge/Discharge Current(A)	Maximum 200A
Internal Resistance	≥30mΩ

BMS PARAMETERS

Self-Consumption	≥2W
Rated Voltage	51.2V
Balance Current	30-65(MA)
Communication Method	CAN/RS485/RS232
Intelligent Current Limiter	20A


AMBIENT TEMPERATURE

Operating Temperature	-10C ~ 50C
Storage Temperature	10C ~ 50C
Humidity	15%-75%


Lithium battery systems are widely used in residential energy storage systems, such as solar energy storage systems and UPS. The power wall LiFePO4 battery pack adopts the international advanced lithium iron phosphate battery application technology and BMS control technology.

INTERFACE

& SIZE




1. POWER SWITCH
2. DRY CONTACT
3. RESET
4. ADDRESS
5. RS485
6. CAN
7. RS232
8. BATTERY LINK
9. BATTERY +
10. BATTERY -




PARALLEL CONNECTION OF BATTERIES

Connect the positive pole and positive pole in parallel, and the negative pole and negative pole in parallel, as shown in the figure below:



SOLUTION DIAGRAM:



SUN SYNK

Deye 德业

solar edge

GOODWE

Growatt

Sol-Ark

SOLAX POWER

STUDER

LBb
PURSUIT OF PERFECTION

invr

HUAWEI

ENPHASE

MPP Solar
Helping Your Future Go Greener

Voltronic Power
SOLAR INVERTER

SOLAR

SMA

solis
SOLAR INVERTER

victron energy
SOLAR INVERTER

LU X POWER TEK

OutBack POWER

EPEVER
EPOLAR TECHNOLOGY

MUST

SUNGROW 阳光电源

KSTAR

SRNE 顺日


Schneider Electric

Ahern


INSTALLATION

NOTES


1. As shown in the figure below, press the mounting structure on the wall surface, use a marker to draw the installation positioning hole of the fixed pendant, remove from wall and drill the holes.



2. As shown in the figure below, fix the attached six expansion bolts in the opening of the mounting structure, and tighten the nuts on the bolts.



3. Lift up the AM-10 battery carefully and hook it into position securely onto the wall mount bracket.



LED WORKING STATUS INDICATION







STATUS	NORMAL / ALARM / PROTECTION	RUN	ALM	SOC INDICATION LEDs				REMARK
								
POWER OFF	Dormancy	OFF	OFF	OFF	OFF	OFF	OFF	All off
STANDBY	Normal	Fash 1	OFF	According to the electricity instruction				Standby state
	Alarm	Flash 1	Flash 3					Cell low voltage
CHARGE	Normal	Lighting	OFF	According to the electricity instruction (Power level indicates maximum LED flash 2)				Alarm when overvoltage light is off
	Alarm	Lighting	Flash 3					
	Overcharge Protection	Lighting	OFF	Lighting	Lighting	Lighting	Lighting	If there is no charging the LED light is in standby state
	Temperature Over-current Protection	OFF	Lighting	OFF	OFF	OFF	OFF	Stop charging
DISCHARGE	Normal	Flash 3	OFF	According to the electricity instruction.				
	Alarm	Flash 3	Flash 3					
	Undervoltage protection	OFF	OFF	OFF	OFF	OFF	OFF	Stop discharge
	Temperature Overcurrent Short-circuit Reverse connection Failure protection	OFF	Lighting	OFF	OFF	OFF	OFF	Stop discharge
FAIL		OFF	Lighting	OFF	OFF	OFF	OFF	Stop charging and discharging.

TABLE 2 CAPACITY INDICATION INSTRUCTIONS

STATE		CHARGE				DISCHARGE			
Capacity Indicator Light		L4	L3	L2	L1	L4	L3	L2	L1
Battery Power (%)	0 ~ 25%	OFF	OFF	OFF	Flash 2	OFF	OFF	OFF	Lighting
	25 ~ 50%	OFF	OFF	Flash 2	Lighting	OFF	OFF	Lighting	Lighting
	50 ~ 75%	OFF	Flash 2	Lighting	Lighting	OFF	Lighting	Lighting	Lighting
	75 ~ 100%	Flash 2	Lighting	Lighting	Lighting	Lighting	Lighting	Lighting	Lighting

TABLE 3 LED FLASH INSTRUCTIONS

FLASH MODE	ON	OFF
FLASH 1	0.25 S	3.75 S
FLASH 2	0.5 S	0.5 S
FLASH 3	0.5 S	1.5 S

Note: can enable or prohibit LED indicator light alarm through the upper machine, the factory default is enabled.

DIP SWITCH SETTINGS



Dialing code function area:

1	Master/Slave Setting
2	Slave Address Setting
3	CAN Bus terminal resistance setting

From left to right, are 1#~8# dial switches, switch up is ON, down is OFF.

Dip switch 8# Dial ON means that the end resistor of the CAN port (for CAN inverters) is loaded; 8# Dial OFF means that the end resistor of the CAN port (for CAN inverters) is unloaded.

The inverter communication protocol selects the DIP mode, which is only valid for the master battery (the slave does not communicate with the inverter), set the target PACK as the master battery through the dial. Then select different inverter communication protocols through DIP 2#~6# ON/OFF. The corresponding definition between the specific DIP status and the selection of the inverter communication protocol is as follows


NO.	1#	2#	3#	4#	5#	6#	Mark
0	ON	ON	OFF	OFF	OFF	OFF	Master Battery \ Enable CAN BUS Port
1	OFF	OFF	OFF	OFF	OFF	OFF	Slave 2
2	OFF	ON	OFF	OFF	OFF	OFF	Slave 3
3	OFF	OFF	ON	OFF	OFF	OFF	Slave 4
4	OFF	ON	ON	OFF	OFF	OFF	Slave 5
5	OFF	OFF	OFF	ON	OFF	OFF	Slave 6
6	OFF	ON	OFF	ON	OFF	OFF	Slave 7
7	OFF	OFF	ON	ON	OFF	OFF	Slave 8
8	OFF	ON	ON	ON	OFF	OFF	Slave 9
9	OFF	OFF	OFF	OFF	ON	OFF	Slave 10
10	OFF	ON	OFF	OFF	ON	OFF	Slave 11
11	OFF	OFF	ON	OFF	ON	OFF	Slave 12
12	OFF	ON	ON	OFF	ON	OFF	Slave 13
13	OFF	OFF	OFF	ON	ON	OFF	Slave 14
14	OFF	ON	OFF	ON	ON	OFF	Slave 15

INTERFACE

DEFINITION


DIAGRAM OF THE COMMUNICATION INTERFACE

RS232 communication port definition:




INTERFACE	DEFINED DECLARATION	
RJ12, RS232 pin layout	PIN 1	NC (empty)
	PIN 2	NC (empty)
	PIN 3	TX protection board sends data (computer receiving data foot)
	PIN 4	RX protection board receives data (computer sends data)
	PIN 5	Ground signal ground
	PIN 6	NC (empty)

RS 485-1 / CAN COMMUNICATION INTERFACE DEFINITION:




INTERFACE	DEFINED DECLARATION		DEFINED DECLARATION			
X1 Communication port definition	RJ45 CAN pin layout	PIN 1	CANL	RJ45, RS485 pin layout	PIN 1	RS485-B1
		PIN 2	CGND		PIN 2	RS485-A1
		PIN 3	NC (empty)		PIN 3	RS485-GND
		PIN 4	CANH		PIN 4	RS485-B1
		PIN 5	CANL		PIN 5	RS485-A1
		PIN 6	NC (empty)		PIN 6	RS485-GND
		PIN 7	CGND		PIN 7	NC (empty)
		PIN 8	CANH		PIN 8	NC (empty)

RS485-2 COMMUNICATION INTERFACE DEFINITION:



INTERFACE		DEFINED DECLARATION		DEFINED DECLARATION		
Battery link ports	A part RS-485-2 Interface	PIN 1	RS485-B2	B part RS-485-2 Interface	PIN 1	RS485-B2
		PIN 2	RS485-A2		PIN 2	RS485-A2
		PIN 3	RS485-GND		PIN 3	RS485-GND
		PIN 4	NC (empty)		PIN 4	NC (empty)
		PIN 5	NC (empty)		PIN 5	NC (empty)
		PIN 6	RS485-GND		PIN 6	RS485-GND
		PIN 7	RS485-A2		PIN 7	RS485-A2
		PIN 8	RS485-B2		PIN 8	RS485-B2

DRY CONTACT DESCRIPTION



1 2

DRY CONTACT

This BMS can provide one channel of dry contact signal, all dry contact signals are passive switches, regardless of polarity.

KRY 1 (2P terminal)		
BMS STATE	DESCRIPTION	REMARK
Normal Operation	1/2 pin is disconnected	
BMS Alarm	1/2 pin is connected	Output when SOC alarm, under voltage and over voltage alarm and BMS protection state, such as under voltage protection, over voltage protection or short circuit protection;

BUTTON OPERATION INSTRUCTIONS

- When the BMS is in sleep state, press the button for more than 1 S, the protection board is activated.
- When the BMS is in operating state, pressing the button more than 3 seconds and less than 6 seconds, then the BMS will enter sleep state. When the BMS is in working state, the protection board will reset when the button is pressed for more than 6S.

BUZZER ACTION DESCRIPTION

- In the case of short-circuit protection, the buzzer beeps every 2 seconds. If a short circuit is detected 3 times in a row then the short-circuit protection is locked, the buzzer will no longer beep. Disconnect the battery and wait a few minutes to switch it back on. It might take up to 5 minutes to redetect a clear condition and then the BMS will re enable.

INTERFACE FUNCTIONS

WARNING

Interfacing or plugging in any 3rd party or non approved Hubble products or peripherals into the RS232 (serial) or RS485 (Battery Link) ports, can cause damage to the BMS and cause the BMS to malfunction. This may also result in damaging the internal cells. Plugging in non approved Hubble products into these ports can immediately void your warranty.

DESCRIPTION OF SLEEP FUNCTION

In order to reduce the power consumption of the whole system, the system has a sleep function.

When the following conditions are met, the system will enter the sleep mode:

1. The over-discharge protection of the BMS has not been released for 5 minutes.
2. The duration of the standby state has reached 24 hours (no communication, no charge and discharge, no charger connected).

DESCRIPTION OF WAKE-UP FUNCTION

Please note that the battery enters sleep mode due to single or overall over-discharge, and cannot be activated or switched on by serial port or the comm ports.

The BMS will activate and wake from sleep when the following is detected:

1. If a charge current is applied to the battery from the inverter/ups.
2. If the power button is pressed.
3. Through communication from the RS232 or CANBus in certain circumstances.

CURRENT LIMITING FUNCTION

The BMS has a advanced current limiting function built in. The charge current limiter is designed to activate if charging current has reached the maximum battery design charge limit. This ensures the battery does not disconnect from the circuit and the current limiter takes over and reduces the charge to 20Amps per battery.

The default start-up condition of the charging current limit is to start when the charging current is greater than 100A. After entering the current limit, the test will be performed again every 10 minutes. When the current is less than the current limit start value, the current limit function will be turned off. When the current is bigger than the current limit start value, then the current limiting mode with stay enabled.

COMMUNICATION DESCRIPTION

1. The RS232 port is only for use with Hubble specific peripherals or technicians or at a service centre to interface with the BMS. Attempting to use this port for anything else or 3rd party products can cause damage.
2. The CAN Port is specifically to be used to any interfacing 3rd party equipment like inverters etc. This port is dedicated to inverters and other CAN bus ports for communication to get battery information.
3. The RS485 communication port can be interfaced with 3rd party inverters that does not have a CAN port and is supported by Hubble.
4. The Battery link ports are only for connecting more batteries of the same model to increase capacity and to enable multiple battery communications.

OPTIONAL CLOUDLINK DEVICE

The Hubble Cloudlink is an optional add-on to the Hubble X and AM range of products. As long as the device is connected to Wi-Fi it will cloud, all battery and inverter data to our cloud-server, enabling users to remotely monitor their power system.

Learn more about the Hubble Cloudlink here:

<https://www.hubblelithium.co.za/about-the-cloudlink>

Access the latest Cloudlink Setup Guide here:

<https://www.hubblelithium.co.za/cloudlink-setup.html>




PARALLEL FUNCTIONS

PARALLEL (CASCADE) FUNCTION OF BATTERY PACKS

When the battery packs are cascaded, the one with the communication address of 0001 is called the master battery pack, and the other ones with the communication address are called the slave battery packs. The slave battery pack can communicate with the master battery pack through the RS485 communication interface, and the master battery pack centrally packs and manages the data of each battery pack in this cascaded system.

When the battery packs are cascaded, only the main battery pack can communicate with the host computer, upload the data, status and information of all battery packs in the cascaded system, integrate monitoring and management, and realize remote monitoring.



RS485 PARALLEL WIRING DIAGRAM

When performing multi-machine parallel communication operation, it is necessary to configure the DIP address of each PACK first. [See Dip Switch Settings for more information.](#)

WARNING



TO ENSURE PROPER USE OF THE BATTERY PLEASE READ THE MANUAL CAREFULLY BEFORE USING IT.

HANDLING

Do not expose the battery to fire.
Do not place the battery in a charger or equipment with wrong terminals connected.
Avoid shorting circuiting the battery .
Avoid excessive physical shock or vibration.
Do not disassemble or deform the battery.
Do not immerse in water.
Do not mix the battery with other different makes, type, or model batteries.
Keep out of the reach of children.

CHARGE AND DISCHARGE

The battery must be charged with a appropriate charger/inverter only.
Never use a modified or damaged charger.

STORAGE

Store the battery in a cool, dry and well-ventilated area.

DISPOSAL

Regulations vary for different countries. Dispose of in accordance with local regulations.

BATTERY OPERATION INSTRUCTION

CHARGING

Charging current: Do not surpass the specified charging current.
Charging voltage: Do not surpass the specified charging voltage.
Ensure correct DC polarity before connecting the terminals.

DISCHARGING CURRENT

The discharging current must not surpass this maximum battery specification.

BATTERY STORAGE

The battery should store in the product specification book stipulation temperature range. If has surpasses above for six months the long time storage, suggested you should carry on additional charge to the battery.

COMPLETING

SETUP

CONGRATULATIONS!

Once all the above steps have been completed you can proceed to follow the start-up instructions given by your inverter manufacturer.

If you have any difficulties with setting up your system, please contact our Technical Support Department via support@hubblelithium.co.za. Be sure to include the following information in your initial email so that we can provide you with timely assistance:

1. Inverter make & model
2. Model & number of connected batteries
3. Are your batteries in Series or Parallel?
4. A brief description of your system and any issues you may be having
5. If possible; images of your power system
6. Contact Details, if we should need to contact you

VIEW OUR WEBSITE FOR
MORE INFORMATION

www.hubblelithium.co.za

