MAINTENANCE INSTRUCTIONS For Position Indicator for 750 Series Diaphragm Valve Size 1/2" - 2"

Installation (all sizes)

Refer to **ASSEMBLY DRAWING 750** and proceed as follows:

NOTE: Isolate the valve from the pipeline before performing any maintenance.

- 1. From bottom of body (1), remove the bolts (12) to release the actuator portion.
- 2. Remove the body from the actuator. Inspect and replace if necessary.
- 3. Unscrew the process diaphragm (2) from the adaptor assembly (6).
- 5. Inspect and replace process diaphragm if necessary.
- 5. To re-assemble valve follow steps 1 through 4 in reverse order, tightening to the bolt torques recommended in the chart below.

IMPORTANT When re-assembling valve ensure that holes in lower part of valve, diaphragm and cover are in line. When tightening diaphragm, if it stops turning before its tab lines up with that on the actuator, unscrew diaphragm totally until it backs off one screw thread, then retighten. The tab should now line up with that on the actuator. Also if attaching to actuator, ensure that all screw holes line up.

VALVE	DIAPHRAGM	MATERIAL	
SIZE	BOLT	TORQUE	(IN-LB)
	EPDM	Viton	Teflon
1/2	44	44	44
3/4	44	44	44
1	44	44	44
1-1/4"	80	80	106
1-1/2"	80	80	106
2	124	124	159



Maintenance Instructions 750 Series Diaphragm Valve cont.



