



# CD800a

## DIGITAL MULTIMETER

### INSTRUCTION MANUAL

SANWA ELECTRIC INSTRUMENT CO., LTD.  
 Dempa Bldg., 4-4 Sotokanda 2-Chome  
 Chiyoda-Ku, Tokyo, Japan

#### [1] SAFETY PRECAUTIONS Before use, read the following safety precautions.

This instruction manual explains how to use your new digital multimeter CD800a safely. Before use, please read this manual thoroughly. After reading it, keep it together with the product for reference to it when necessary. The instruction given under the heading of "WARNING" must be followed to prevent accidental burn or electrical shock.

#### 1-1 Explanation of Warning Symbols

The meaning of the symbols used in this manual and attached to the product is as follows.

#### ⚠️ Very important instruction for safe use.

The warning messages are intended to prevent accidents to operating personnel such as burn and electrical shock. The caution messages are intended to prevent damage to the instrument.

- ⊕ : Ground    ⊡ : Diode    ⊞ : Fuse
- 🔔 : Buzzer    ⊚ : Capacitance    ⊠ : Resistance
- ⏏ : Direct current(DC)    Hz : Frequency
- Ⓜ : Duty cycle    ~ : Alternating current(AC)
- 🔍 : Double insulation(Protection Class II)
- ⊕ : Plus input (Red)    ⊖ : Minus input (Black)

#### 1-2 Warning Instruction for Safe Use

- 1. Be sure to disconnect the test pins from the circuit when changing the function.
- 2. Before starting measurement, make sure that the function and range are properly set in accordance with the measurement.
- 3. Never use meter with wet hands or in a damp environment.
- 4. Never open tester case except when replacing batteries or fuse. Do not attempt any alteration of original specifications.
- 5. Do not use the device near an item of strong electromagnetic generation or a charged item.
- 6. To ensure safety and maintain accuracy, calibrate and check the tester at least once a year.
- 7. The multimeter is for indoor use only.

- 8. Be sure to disconnect the test pins from the circuit when changing the function.
- 9. Before starting measurement, make sure that the function and range are properly set in accordance with the measurement.
- 10. Never use meter with wet hands or in a damp environment.
- 11. Never open tester case except when replacing batteries or fuse. Do not attempt any alteration of original specifications.
- 12. Do not use the device near an item of strong electromagnetic generation or a charged item.
- 13. To ensure safety and maintain accuracy, calibrate and check the tester at least once a year.
- 14. The multimeter is for indoor use only.

#### 1-3 Overload protections

Function	Input terminals	Maximum rating input value	Maximum overload protection input
V	(Red) (Black)	DC · AC 600 V	DC 600 V AC 600 V or Peak Max 840 V
Ω / ▽ / ♁ / ⊞	(Black)	△Voltage and Current input prohibited	DC · AC 600 V
Hz / %	(Black)	DC · AC 400 mA	0.5 A / 250 V Fuse

\*AC voltage is regulated by rms. value of sinusoidal wave.

- ⚠️ CAUTION
- 1. Correct measurement may not be performed when using the meter in the ferromagnetic / intense electric field such as places near a transformer, a high-current circuit, and a radio.
- 2. The meter may malfunction or correct measurement may not be performed when measuring special waveform such as that of the inverter circuit.

#### [2] APPLICATION AND FEATURES


##### 2-1 Applications

This instrument is portable digital multimeter designed for measurement of weak current circuits. It plays an important role in circuitry analysis by using additional functions as well as measurements of small type communication equipment, electrical home appliance, lighting voltage and batteries of various type.

#### 2-2 Features

- Sharp contrast LCD with character 17.5 mm high is employed, and unit symbols are displayed on the screen of the LCD.
- Frequency, capacitance and duty cycle measurement function.
- Attachment body cover is used for protection of the meter and as a tilt stand.
- The current function is protected by a fuse.

#### [3] NEME OF COMPONENT UNITS




#### [4] DESCRIPTION OF FUNCTIONS

**⚠️ WARNING**  
 In the case of action or cancel that function as follows, do not turn the function switch in the condition applied input.


- 4-1 **Function Switch**  
Turn this switch, to turn on and off the power and to select the functions of V ~ Ω / ▽ / ♁ / ⊞ / Hz / %, mA ~ ~
- 4-2 **SELECT : Measurement Function Select**  
When the SELECT button is pressed (⇄), the functions change as follows.  
  - In the case of V, mA, the modes change as: V ~ Ω ~ ▽ ~ ♁ ~ ⊞ ~ Hz / %
  - In the case of Ω / ▽ / ♁ / ⊞, the modes change: Ω ~ ▽ ~ ♁ ~ ⊞ ~ Hz / %
- 4-3 **RANGE : Range Hold**  
Press the RANGE button momentary to set the manual range mode, then 'AUTO' disappears in the display. In manual range mode, press the button again to step through the ranges. To return to the auto mode, press the button for 1 sec. or more, then 'AUTO' is shown.  
 \*Manual mode is not available in ⊞, Hz, duty measurement, diode check, cont. buzzer functions.
- 4-4 **REL : Relative Mode**  
Relative zero allows the user to offset the meter consecutive measurements with the displaying reading as the reference value. Press the REL button momentary to activate and to exit relative zero mode.
- 4-5 **HOLD : Data Hold**  
When the HOLD button is pressed, the display is hold ('DH' is shown on the display). The display will not be changed while the function is active. Press the button again to cancel the function. ('DH' on the display disappears.)  
 \*DATA HOLD function does not work when measuring frequency.
- 4-6 **Hz/% : Frequency and duty cycle select button**  
Frequency and duty cycle measurement functions are activated alternatively by pressing the button. In the case of the mode change as Hz / %
- 4-7 **Auto Power Off**  
The meter will enter a low power consumption sleep mode automatically to extend battery life after approximately 30 minutes of no function switch or push button operations. To wake up the meter from Auto Power Off, press any buttons momentarily or turn the function switch to the OFF position. Then turn back on again. To disable the Auto Power Off feature, press the SELECT button while turning the function switch on.  
 \*Always turn the function switch to the OFF position when the meter is not in use.

#### [5] MEASUREMENT PROCEDURE


- 5-1 **Start-Up Inspection**  
 ⚠️ WARNING  
 1. Make sure that no low battery indication appear in the display.  
 2. Never use meter if the meter or test leads are damaged or broken.  
 3. Check continuity of test leads & fuse.  
 \*No display may suggest that a battery be exhausted.




- 5-2 **Voltage measurement**  
 ⚠️ WARNING  
 1. Never apply an input signal exceeding the maximum rating input value.  
 2. Be sure to disconnect the test pins from the circuit when changing the function.  
 3. Always keep your fingers behind the finger guards on the probe when making measurements.  
 DCV / ACV : Maximum rating input value 600 V DC/AC  
 1) Applications  
 DCV : Voltage of the battery and DC circuit are measured.  
 ACV : Sine wave AC voltage, such as lighting voltage, is measured.  
 2) Measuring ranges  
 DCV : 5 ranges from 400 mV to 600 V  
 ACV : 4 ranges from 4 V to 600 V




- 5-3 **Resistance Measurement (Ω)**  
 ⚠️ WARNING  
 Never apply voltage to the input terminals.  
 1) Applications  
 Resistances of resistors and circuits are measured.  
 2) Measuring ranges  
 6 ranges from 400 Ω to 40 M Ω



- 5-4 **Capacitance Measurement (⊞)**  
 ⚠️ WARNING  
 Never apply voltage to the input terminals.  
 ⚠️ CAUTION  
 1. Discharge the capacitance before measurement.  
 2. This is not suitable for measurement of electrolytic condenser such as a large leakage condenser.  
 3. It takes a while to measure large capacitance.




- 5-5 **Checking Continuity (🔔)**  
 ⚠️ WARNING  
 Never apply voltage to the input terminals.  
 1) Applications  
 Checking the continuity of wiring and selecting wires.  
 2) How to use  
 (1) Set the FUNTION switch at Ω / ▽ / ♁ / ⊞ .  
 (2) Select 🔔 by pressing the SELECT button.  
 (3) Apply the red and black test pins to a circuit or conductor to measure.  
 (4) The continuity can be judged by whether the buzzer sounds or not.  
 (5) After measurement, release the red and black test pins from the object measured.  
 ● Threshold : 10 ~ 120 Ω



- 5-5 **Checking Continuity (🔔)**  
 ⚠️ WARNING  
 Never apply voltage to the input terminals.

- 5-6 **Capacitance Measurement (⊞)**  
 ⚠️ WARNING  
 Never apply voltage to the input terminals.  
 ⚠️ CAUTION  
 1. Discharge the capacitance before measurement.  
 2. This is not suitable for measurement of electrolytic condenser such as a large leakage condenser.  
 3. It takes a while to measure large capacitance.



- 6-4 **Storage**  
 ⚠️ CAUTION  
 1. The panel and the case are not resistant to volatile solvent and must not be cleaned with thinner or alcohol.  
 2. For cleaning, use dry, soft cloth and wipe it lightly.  
 3. The panel and the case are not resistant to heat. Do not place the instrument near heat-generating devices (such as a soldering iron).  
 4. Do not store the instrument, in a place where it may be subjected to vibration or from where it may fall.  
 5. For storing the instrument, avoid hot, cold or humid places or places under direct sunlight or where condensation is anticipated.

- [7] AFTER-SALE SERVICE
- 7-1 **Warranty and Provision**  
 Sanwa offers comprehensive warranty services to its end-users and to its product resellers. Under Sanwa's general warranty policy, each instrument is warranted to be free from defects in workmanship or material under normal use for the period of one (1) year from the date of purchase.  
 This warranty policy is valid within the country of purchase only, and applied only to the product purchased from Sanwa authorized agent or distributor.  
 Sanwa reserves the right to inspect all warranty claims to determine the extent to which the warranty policy shall apply. This warranty shall not apply to fuses, disposables batteries, or any product or parts, which have been subjected to one of the following causes:  
 1. A failure due to improper handling or use that deviates from the instruction manual.  
 2. A failure due to inadequate repair or modification by people other than Sanwa service personnel.  
 3. A failure due to causes not attributable to this product such as fire, flood and other natural disaster.  
 4. Non-operation due to a discharged battery.  
 5. A failure or damage due to transportation, relocation or dropping after the purchase.

- 7-2 **Repair**  
 Customers are asked to provide the following information when requesting services:  
 1. Customer name, address, and contact information  
 2. Description of problem  
 3. Description of product configuration  
 4. Model Number  
 5. Product Serial Number  
 6. Proof of Date-of-Purchase  
 7. Where you purchased the product  
 Please contact Sanwa authorized agent / distributor / service provider, listed in our website, in your country with above information. An instrument sent to Sanwa / agent / distributor without those information will be returned to the customer.

Note:  
 1) Prior to requesting repair, please check the following:  
 Capacity of the built-in battery, polarity of installation and discontinuity of the test leads.

#### 8-2 測定範囲及び精度 / Measurement Range and Accuracy

精度保証範囲 : 温度23±5℃ 湿度: 80%RH以下 結露のないこと  
 Accuracy assurance range : 23±5℃ & less than 80% R.H. No Condensation


ファンクション&レンジ Function&Range	精度 Accuracy	入力端子 Input Impedance	備考 Remarks
直流電圧 DCV 4000.0 V	±(0.7%rdg+3dgt)	≥100 M Ω	
DCV 40.00 V	±(1.1%rdg+3dgt)	約10 M Ω	
DC Voltage 400.0 V 600 V	±(1.1%rdg+3dgt)	Approx. 10 M Ω	
交流電圧 ACV 4000.0 V	±(1.8%rdg+9dgt)	Approx. 11 M Ω	*正弦波交流電圧のみ 精度保証周波数範囲40~400 Hz *Accuracy in the case of sin wave 40~400 Hz
ACV 400.0 V 600 V	±(1.8%rdg+5dgt)	約10 M Ω Approx. 10 M Ω	
抵抗 4.000 k Ω 40.00 k Ω	±(1.5%rdg+5dgt)	開放電圧 : DC約 0.4 V Open voltage : Approx.DC 0.4 V	
Ω 400.0 k Ω 4.000 M Ω	±(2.0%rdg+3dgt)	測定電圧は特測抵抗の抵抗によって変化します。 The measuring current changes according to the resistance of the resistor to measure.	
40.00 M Ω	±(4.0%rdg+3dgt)		
静電容量 50.00 nF			*オートレンジのみ。 *Auto range only。 表示されている値をリリアティブ機能によってキャンセルした後の精度。 Accuracy was measured after canceling didplay value by relative key
⊞ 5.000 μF 50.00 μF 100.0 μF	±(5.0%rdg+10dgt)		

例) 直流電圧測定(DcVm) / For example: Measurement 400 mVDC Range.  
 真値 / True value : In a range of 0.00 [mV] ~ 100. [mV] の範囲内。  
 表示値 / Display value : 100.0 [mV]  
 レンジ精度 / Accuracy : 400.0 [mV] レンジ / Range : ±(0.3%rdg+4dgt)  
 誤差 / Error : ±(100.0[mV]×0.3%rdg+4dgt)=±0.7[mV]  
 計算式 / Calculation : 100.0 [mV] ±(100.0 [mV] × 0.3%rdg+4dgt)  
 真値 / True value : In a range of 0.00 [mV] ~ 100. [mV] の範囲内。  
 \*400.0 [mV] レンジにおける4 [dgt] とは、0.4 [mV] に相当します。  
 \*4 [dgt] in the 400.0 [mV] range correspond to 0.4 [mV]

#### [6] MAINTENANCE

- ⚠️ WARNING  
 1. The section is very important for safety. Read and understand the following instruction fully and maintain your instrument properly.  
 2. The instrument must be calibrated and inspected at least once a year to maintain the safety and accuracy.
- 6-1 **Maintenance and inspection**  
 1) Appearance  
 ● Is the appearance not damaged by falling?  
 2) Test leads  
 ● Is the cord of the test leads not damaged?  
 ● Is the core wire not exposed at any place of the test leads?  
 Note : If the built-in fuse is blown, only the current measurement becomes impossible. Make sure that the test leads are not cut, referring to the section 5-1.

- 6-2 **Calibration**  
 The manufacturer may conduct the calibration and inspection. For more information, please contact the dealers.
- 6-3 **Battery and Fuse Replacement**  
 ⚠️ WARNING  
 1. If the rear case or the battery lid is removed with input applied to the input terminals, you may get electrical shock. Before starting the work, always make sure that no input is applied.  
 2. Before starting the work, be sure to turn OFF the main unit power and release the test leads from the circuit.  
 3. Be sure to use a fuse of the specified rating or type. Never use a substitute of the fuse or never make a short circuit of the fuse.



- ⚠️ CAUTION  
 Set battery with its polarities facing in the correct directions.

周波数 Frequency	5.000 Hz 50.00 Hz 500.0 Hz 5.000 kHz 50.00 kHz 100.0 kHz	精度 Accuracy	備考 Remarks
		±(0.5%rdg+3dgt)	*オートレンジのみ。 *Auto range only. 1 Hz~1 kHz 4 Vrms~250 Vrms 10 Hz~100 kHz 4 Vrms~20 Vrms
デュティ比 % Duty Cycle	20~80 %	±(0.5%rdg+5dgt)	*オートレンジのみ。 *Auto range only. 5 Hz~60 Hz 2 Vrms~30 Vrms 60 Hz~200 Hz 4.9 Vrms~30 Vrms
直流電流 DCmA 40.00 mA 400.0 mA		約1 Ω ±(2.2%rdg+5dgt)	*直流電流のみ 直流電流測定 Without resistance of Fuse 約1 Ω Approx. 1 Ω *正弦波交流電圧のみ 精度保証周波数範囲40~400 Hz *Accuracy in the case of sin wave 40~400 Hz
交流電流 ACmA 40.00 mA 400.0 mA		±(2.8%rdg+5dgt)	約10 Ω Approx. 10 Ω
電圧降下 Voltage Drop	10~120 Ω 以下で発生 Buzzer sounds at less than 10~120 Ω	開放電圧 : DC約 0.4 V Open voltage: Approx.DC 0.4 V	
Testing Diode		開放電圧 : DC約 1.5 V Open voltage: Approx. DC 1.5 V	

\*トランスや大電流流など強磁界の発生している近く、また無線機など電界の発生している近くでは正常な測定ができない場合があります。

精度保証範囲 / Accuracy calculation  
 例) 直流電圧測定(DcVm) / For example: Measurement 400 mVDC Range.  
 真値 / True value : In a range of 0.00 [mV] ~ 100. [mV] の範囲内。  
 表示値 / Display value : 100.0 [mV]  
 レンジ精度 / Accuracy : 400.0 [mV] レンジ / Range : ±(0.3%rdg+4dgt)  
 誤差 / Error : ±(100.0[mV]×0.3%rdg+4dgt)=±0.7[mV]  
 計算式 / Calculation : 100.0 [mV] ±(100.0 [mV] × 0.3%rdg+4dgt)  
 真値 / True value : In a range of 0.00 [mV] ~ 100. [mV] の範囲内。  
 \*400.0 [mV] レンジにおける4 [dgt] とは、0.4 [mV] に相当します。  
 \*4 [dgt] in the 400.0 [mV] range correspond to 0.4 [mV]

ここに掲載した製品の仕様や外観は改良等の理由により、予告なしに変更することがありますのでご了承ください。  
 Specifications and external appearance of the product described above may be revised for modification without prior notice.