

Airport Accelerator™, Airport Commuter™, Airport Essentials™ Instructions

TRIPOD ATTACHMENT

tripods can be attached to the side of the backpack by putting two legs into the stretchable bottom pocket and then attaching it with two tripod straps.



Step 1: Locate the "tripod straps" with the two buckles inside of the backpack.



Step 2: Thread the tripod straps under the webbing near the top of the bag and directly above the stretch pocket (two locations).



Step 3: The side release buckle should be located on the side of the tripod. Adjust the strap position on the bag so it is in this position.



Step 4: The ladder lock buckle should also be located on the side of the tripod. Use this buckle to tighten the strap.

SETTING THE CABLE LOCK COMBINATION



Step 1: Start by setting the dials to 0-0-0. Take a ballpoint pen and press down (as hard as you can) the small recessed reset button located at the base of the clasp until you hear a "click" sound.



Step 2: Rotate the dials to the new combination of your choice.



Step 3: Depress the lock clasp until you hear a "click" sound. The lock will open using the new combination.

REMOVABLE WAISTBELT



The included waistbelt is removable by unthreading the webbing through the buckle.

ATTACHING A MODULAR BELT



Remove the included waist belt. Then feed the Pro Speed Belt™ or Thin Skin Belt™ through the opening in the bottom panel of the backpack.