

# Rotation 22L, Rotation 34L and Rotation Pro 55L+ Backpack Instructions

Serving the needs of traveling outdoor photographers

For more information please visit: [www.thinktankphoto.com](http://www.thinktankphoto.com)



## How To Rotate



1. Loosen buckles on waist belt



2. Pull down on ripcord attached to sliding buckle to release



3. Grab the side handle on belt pack and/or thumb-loop on waist belt to rotate the belt pack 180 degrees counter-clockwise



4. Reverse direction to stow away belt pack



5. Secure door flap by depressing flap and clicking buckle into place

## Waterproofing



Water repellent should be reapplied to the exterior of the backpack every 6 months. We recommend Nikwax: Tent & Gear Solarproof

## Flap Adjustment

Over time, the belt pack may catch on the side flap when rotating. To increase the flap clearance, follow the instructions below:



1. Adjust tension on elastic cord to lift flap to desired position



2. Tuck away loose elastic cord into the hole on the top right corner of the flap

## Quick Access Magnets vs Full Zippered Closure

Our magnetic belt pack opening allows for fast access and efficient workflow, however, we provided a full zippered closure if you find yourself in inclement weather or unstable footing



Magnetic closure



Zipper closure

## Security Leash



When packing/unpacking, it can be helpful to remove the security leash by unclipping the leash from the belt pack. Be sure to reattach the leash before wearing the pack to protect your gear against accidental damage



## Torso Adjustment for the Pro 50L+



1. Choose from three torso height attachment bars



3. Feed the webbing through the weblock and line up the green bar tacks



4. Attach the full hook and loop panels together



5. Slide the cover over the secured webbing assembly



2. Insert harness webbing through attachment bar

## Tripod Attachment – Side Panel (34L & Pro 50L+)



1. Place one or two tripod feet in the side pocket



2. Affix side compression strap around the tripod. Depending on the size of the tripod, you may want to wrap the strap around the top of the tripod to secure it to the bag

## Torso Adjustment for the 22L & 34L



1. Release the shoulder strap assembly from the pack by separating the hook-and-loop closure from the back



2. Adjust torso length



3. Adjust the length so the "collar cut" in the shoulder straps are in line with your neck and the waist belt is positioned on your hips

## Tripod Attachment – Front Panel



1. Remove tripod strap from top compartment under logo and release the tripod cup at the bottom of the bag



2. Place one or two tripod feet through the lower strap and into the tripod cup. Secure the lower strap over the remaining leg(s)



3. Affix top strap around the tripod. Depending on the size of the tripod, you may want to wrap the strap around the top of the tripod to secure it to the bag



## Rain Cover Attachment – Backpack



1. Locate the larger rain cover and orient the logo on the top of the bag and wrap around top corners. If a tripod is attached to your bag, slide the tripod legs through the hook and loop slot on the bottom of the rain cover.



2. Remove the belt pack from the rotation compartment  
3. Attach the three tabs to the inside of the rotation compartment



4. Wrap elastic band around sliding buckle



5. Tighten up the rain cover around the edges of the backpack

## Rain Cover Attachment – Belt Pack *Easier to do when wearing the pack*

1. Wrap smaller rain cover over belt pack with the logo on the front of the pack
2. Be sure the buckle receptacle is not covered

## Rain Cover - Care

If the rain cover gets dirty, soak it in cold water (no soap) and hang to dry.

Waterproofing: Water repellant should be reapplied to the exterior of the backpack and rain cover every 6 months. We recommend Nikwax: Tent & Gear Solarproof

## Hydration Hose Routing Pro 50L+ – Side Pocket



1. Fill reservoir and place in the side hydration pocket. Use the tether to hold your reservoir in place



2. Guide the tube through the pass through slot and down the shoulder straps. Secure with elastic straps and adjust to a convenient length.



## Hydration Hose Routing: 34L and Pro 50L+ – Front Pocket



1. Fill reservoir and place in the front pocket. Use the tether to hold the reservoir in place



2. Guide the tube through the passthrough slot on the left side of the front pocket



3a. **34L** – Guide the tube through the pass through slot on the left side of the main compartment and down the shoulder straps. Secure with elastic straps and adjust to a convenient length.



3b. **Pro 50L+** – Guide the tube along the outside of the bag and down the shoulder straps. Secure with elastic straps and adjust to a convenient length.



## Stash Master Top Load and Stash Master Pro Instructions – Sold Separately

For quick access, leave the openings unzipped and tucked away when loaded in a backpack

### Stash Master Top Load – Top Opening



1. Remove the foam from the flap



2. Fold the loose flap in front of the Stash Master Top Load

### Stash Master Pro – Top Opening



1. Remove the foam from the top-panel flap



2. Fold the loose flap in front of the Stash Master Pro

### Stash Master Pro – Back Opening



1. Remove the foam from the back-panel flap



2. Fold the loose flap underneath the Stash Master Pro

## Phone Holster Attachment Instructions – Sold Separately

### Belt Wing Attachment



1. Lift vertical flap and secure wing panels underneath



2. Feed the vertical panel through the webbing slot on the belt wing



3. Secure the vertical panel on the bottom of the Phone Holster

### Shoulder Strap Attachment



1. Open the wing attachment panels and secure the vertical panel underneath the phone holster



2. Feed sternum strap through hole in the wing panel closest to the midline of the backpack



3. Wrap the wing panels around the shoulder strap and secure to each other on backside of shoulder strap

Visit [thinktankphoto.com](http://thinktankphoto.com) to view and purchase all available accessories!