



atim cloud wireless™  
PRODUCT LINE

ATIM Cloud Wireless

# Temperature monitoring through RTD

## TMxP

### User Guide

Concerned models:

ACW/LW8-TM1P

ACW/LW8-TM2P

ACW/LW8-TM0P

ACW/SF8-TM1P

ACW/SF8-TM2P

ACW/SF8-TM0P



ATIM Radiocommunications  
Chemin des Guillets  
38250 Villard de Lans

[www.atim.com](http://www.atim.com)  
[info@atim.com](mailto:info@atim.com)



# Table of contents

DOCUMENT VERSION HISTORY .....	4
DISCLAIMER.....	4
TRADEMARKS AND COPYRIGHT.....	4
DECLARATION OF COMPLIANCE.....	5
ENVIRONMENTAL RECOMMENDATIONS .....	5
A. EXPLOSIVE ENVIRONMENT.....	5
B. ENVIRONMENT.....	5
C. RADIO.....	6
TECHNICAL SPECIFICATIONS.....	7
A. PRODUCT .....	7
B. SENSORS FUNCTIONS.....	7
HOUSING.....	8
A. SPACE REQUIREMENTS .....	8
B. MOUNTING TO A SUPPORT.....	9
C. IDENTIFICATION.....	9
D. OPENING THE ACW HOUSING.....	10
E. INSTALLATION .....	10
F. WIRING OF THE PROBES.....	11
3 wires probe.....	11
2 wires probe.....	11
OPERATING .....	12
A. OPERATING MODE .....	12
B. PRODUCT START UP .....	13
C. TEST FRAME EMISSION .....	13
D. DEEP SLEEP SETUP .....	13
E. RADIO MODULE ACTIVITY .....	13
F. THRESHOLD EXCEEDED .....	14
G. ANTI-FRAUD SYSTEM.....	14
H. SUBSTITUTION TO THE MAGNET .....	14
I. BATTERY PASSIVATION.....	14
ACW CONFIGURATOR .....	15
A. COMPATIBLE CONFIGURATOR VERSION .....	15
B. CONFIGURATION OF THE ACW-TMxP .....	16
<i>Emission period and samples in the frame</i> .....	16
<i>Keep alive frame period</i> .....	16
<i>Frame timestamp</i> .....	17
<i>Radio module configuration</i> .....	17
<i>Product's clock</i> .....	17
<i>Versions of the product</i> .....	17
<i>Temperature probes configuration</i> .....	17
<i>Digital input configuration</i> .....	17
<i>Validation the configuration</i> .....	18
C. FACTORY SETTINGS .....	18
D. UPDATE OF ACWS .....	19
FRAMES FORMAT .....	20
A. SIGFOX AND LoRAWAN .....	20
<i>Classic frame</i> .....	20
<i>The different type of frames</i> .....	21

<i>Measuring frame</i> .....	21
<i>Alert frame</i> .....	22
<i>Keep-alive frame</i> .....	23
<i>Error and alarm generic frame</i> .....	23
B.    EXAMPLES OF FRAMES.....	25
<i>Measuring frame</i> .....	25
<i>Alert measurement frame</i> .....	26
<b>DOWNLINK</b> .....	<b>27</b>
A.    CONFIGURATION OF THE FRAME PARAMETERS (SENDING PERIOD, NUMBER OF SAMPLES, ETC.) .....	27
B.    NUMBER OF PROBES .....	27
C.    TYPE OF PROBES .....	28
D.    THRESHOLD CONFIGURATION .....	28
E.    INPUT CONFIGURATION .....	28
F.    ANTI-REBOUND CONFIGURATION .....	28
G.    RESERVED CODES FOR FUTURES EVOLUTIONS .....	29
<b>TECHNICAL SUPPORT</b> .....	<b>30</b>

This user guide applies to the below product versions

	Product references	Product version (Visible on the product label)
LoRaWAN	ACW/LW8-TMxP	A.1
Sigfox	ACW/SF8-TMxP	A.1

## Document version history

Version	Date	Description	Author	Affects software version
0.1	02/01/2020	Document creation	AC	V0.0.1
0.2	05/03/2020	Corrections	AC	V0.0.1
0.3	11/03/2020	Probe wiring addition	AC	V0.0.1
0.4	25/03/2020	Corrections	AC	V0.0.1
0.5	28/04/2020	Endianness modification LED sequencies modifications	AC	V0.0.1
0.6	06/05/2020	Configurator page, title, operating mode modification Layout	AC	V0.0.1
0.7	15/06/2020	Error code modification	YLB	V0.0.1
0.8	24/06/2020	Documentation addition for the new input (setup, uplink and downlink frame)	AC	V0.0.1
0.9	07/09/2020	Keep-alive frame description	AC	V0.0.1
0.10	09/10/2020	Temperature probes features addition + error code table modification	AC	V0.0.2
0.11	23/10/2020	Batteries passivation description	AC	V0.0.2

## Disclaimer

The information contained in this document is subject to change without warning and does not represent a commitment on the part of ATIM.

## Trademarks and copyright

ATIM, ACW ATIM Cloud Wireless® and ARM Advanced Radio Modem® are registered trademarks of ATIM SARL in France. The other trademarks mentioned in this document are the property of their respective owners.

## Declaration of compliance

All ACW Atim Cloud Wireless® products comply with the regulatory requirements of the R&TTE Directive (1999/5/EC), article 3:



### **1 SAFETY** (Article 3.1a of the 1999/5/EC Directive)

NF EN60950-1 Ed. 2006/A1:2010/A11:2009/A12:2011 (health)

EN62479: 2010 (power <20mW) or EN62311:2008 (power > 20mW)

### **2 Electromagnetic Compatibility** (Article 3.1b of the 1999/5/EC Directive)

EN 301489-3 v1.4.1, EN 301489-1 V1.9.2

### **3 Efficient use of the radio frequency spectrum** (Art.3.2 of the 1999/5/EC Directive)

ETSI EN300 220-2 v2.4.1 and EN300 220-1 v2.4.1

## Environmental recommendations

### a. Explosive environment

Except for the ACW-ATEX range intended for this use, do not use ACW radio modems in the presence of flammable gas and smoke. The use of the equipment in this environment constitutes a danger.

### b. Environment

Respect the temperature ranges for storage and operation of all products. Failing to respect these guidelines could disrupt device operation or damage the equipment.

Follow the instructions and warnings provided below to ensure your own safety and that of the environment and to protect your device from any potential damage.



**General hazard** – Failure to follow the instructions presents a risk of equipment damage.



**Electrical hazard** – Failure to follow the instructions presents a risk of electrocution and physical injury.



**WARNING:** do not install this equipment near any source of heat or any source of humidity.



**WARNING:** for your safety, it is essential that this equipment be switched off and disconnected from mains power before carrying out any technical operation on it.



**WARNING:** the safe operation of this product is ensured only when it is operated in accordance with its intended use. Maintenance may only be performed by qualified personnel.



Waste disposal by users in private households within the European Union. This symbol appears on a product or its packaging to indicate that the product may not be discarded with other household waste. Rather, it is your responsibility to dispose of this product by bringing it to a designated collection point for the recycling of electrical and electronic devices. Collection and recycling waste separately at the time you dispose of it helps to conserve natural resources and ensure a recycling process that respects human health and the environment. For more information on the recycling center closest to your home, contact your closest local government office, your local waste management service or the business from which you purchased the product.

### c. Radio

Modems in the ACW line are radio-communication modems that use the ISM (industrial, scientific and medical) bands, which may be used freely (at no cost and with no authorization required) for industrial, scientific and medical applications.

## Technical specifications

### a. Product

Dimensions	154 x 54 x 54 mm	
Antenna	Integrated (¼ wave)	
Temperature probes	1 or 2 analog probes PT100 or PT1000	
Temperature	-25°C à +70°C (operating)	
	-40°C à +70°C (storage)	
Mounts to	Wall, tube or mast, DIN-Rail	
Casing	IP 65	
Power Supply	2 battery-packs [14,4 Ah]	
Weight	305 g	
Frequency	863 – 870 MHz	
Power	25 mW (14 dBm)	
Rate	Sigfox: 100 bits/s	
	LoRaWAN: 300 bit/s à 10 Kbit/s	
Consumption	Sigfox	LoRaWAN
Tx mode	60 mA	55 mA
IDLE		20 µA
Rx mode	50 mA	25 mA
Deep sleep mode		6 µA

### b. Sensors functions


Temperature	Range	-327.68 °C to 327.67 °C
	Resolution	0.05°C
	Precision from -25°C to +70°C (Operating range)	0.5*

\* Data applicable to 2-wire probes supplied for TM1P and TM2P versions

The product also includes a digital input configurable for counting or detection of change of state.

# Housing

## a. Space requirements



Maximum cable diameter through cable gland: 7mm



## b. Mounting to a support

ACW modems can be mounted on a flat wall, a tube or pole or a DIN rail, depending on the type of installation you require.

These three types of support frames attach to the rear of the housing.

Mounting on a flat wall (provided):

Mounting on flat wall (provided)



Installation on a tube




Mounting on a DIN rail




## c. Identification

The Sigfox or LoRaWAN product identifier is visible on the exterior label on the back of the device, on the electronic card inside and in the status bar in the ACW configuration tool.

For LoRaWAN modems, the communication keys are automatically provided by the network (pairing via 'Over The Air Activation', or OTAA).



#### d. Opening the ACW housing






The housing must be opened to access both the terminal block and the mini-USB port used to configure the module.

To do this, insert a screwdriver into the slot and tilt it downward to lift the inside tab (see photo). Then pull on the back panel to separate the two parts of the housing.

#### e. Installation



Install the modem at least 2 m above the ground and not right against the wall — ideally at least 20 cm away. The cables must be no longer than 10 m and must be shielded.

For optimal results, we recommend that you place it high up and at least 1 meter away from all metallic objects if possible (see diagrams below). Note that the antenna is integrated into the housing.




## f. Wiring of the probes

### 3 wires probe



### 2 wires probe



**Warning:** If 2-wire probes are used, two jumpers should be placed on J1 and J2 (above the 8-pin connector). Without this, the data reported by the product will be inconsistent.

# Operating

## a. Operating mode

The operating of the ACW-TMxP deals with several modes:





- **Exploitation mode:** this is the default mode when starting the product. In this mode, the module periodically sends measurements according to the configuration applied (if the product has never been configured, the factory configuration applies, cf. [Factory settings](#)).
- **Deep sleep mode:** this standby mode mainly allows the product to be put to sleep from the moment the product is powered on until it is installed on site. In this mode, no measurement or radio communication function is possible.
- **Mode Confirmation:** this mode is active FIVE minutes after exiting deep sleep mode and allows configuration of the product in **Bluetooth** using the PC configurator. In addition, radio frames are sent every minute (therefore five frames) to ensure that the product is properly commissioned. After these five minutes, the product returns to operating mode and **Bluetooth** is deactivated (possibility of reactivating it via **Downlink**).
- **Fault mode:** This mode allows the normal operation of the module to be interrupted when a critical event occurs. The nature of the event can be multiple:
  - Error on the measuring function
  - Low battery (less than 15% of the maximal charge)
  - Empty battery (less than x% of the minimum charge)
  - Error on the radio module
  - Error when automated tests
  - Error in the application

Entering Fault mode is indicated by a flashing **RED** LED of the product.

If the error does not come from the radio module, the product will send 3 radio frames every 24 hours containing the error code (s) (see chapter [Frames format](#) for error codes). In addition, the product will emit an audible and luminous warning depending on the nature of the event.

Once in this mode, the module must be restarted (by disconnecting and reconnecting the battery or by command in Downlink) to return to its normal operation.

At any time, it is possible to identify which mode the product is in by bringing a magnet close **at least for 2 seconds** to the diamond mark on the case. The product led will light up in one of these colors depending on the mode:

-  for operating mode
-  for configuration mode
-  for deep sleep mode
-  for fault mode

## b. Product start up

In most cases, the ACW-TMxP is started up before delivery (battery packs already connected) and then placed in deep standby to limit consumption.

To place the product in its operating mode, bring a magnet close to the diamond-shaped marking on the box for 6 seconds. During these **6 seconds**, the product LED should flash **WHITE** and then **GREEN** after six seconds to indicate that the product has started up.

The ACW then enters the network pairing phase. During this phase, a **FUSCHIA** light signal with a fading effect indicates that the search phase is in progress.

If the connection is successful, the product will emit an audible signal and a light signal depending on the quality of the network:

- **GREEN** light signal: good quality of network
- **YELLOW** light signal: low quality of network
- **ORANGE** light signal: bad quality of network
- **WHITE** light signal: no information on the quality of the network

The module will then enter its operating mode and start to send information to the network depending on the configuration.

In case of connection failure, the ACW will return to its fault mode because no radio transmission can be made.

**WARNING: To have information on the quality of the Sigfox or LoRaWAN network, it is necessary to provision a Downlink. It is this that will determine the quality of the network. The product emits at startup (directly for Sigfox after the Join phase for LoRaWAN), a test Uplink described in the [Classic frame](#) chapter (type of frame 0x02). If a Downlink is provisioned, information on network quality will then be fed back by the ACW (light and sound signal). If no Downlink is provisioned, then ACW will always display the **WHITE** light signal.**

## c. Test frame emission

When the product is in its operating mode (and only in this mode), it is possible to send a test frame (which avoids waiting for the next measurement frame) including a measurement sample.

To do this, simply bring the magnet closer until the **GREEN** light signal goes out. The successful sending of the test frame will be indicated by a **CYAN** light signal.

## d. Deep sleep setup

While transporting or storing the ACW-TMxP, it is best to place it in its deep sleep mode to limit unnecessary energy consumption.

From any operating mode (except fault mode), bring a magnet near the diamond marking on the box for **6 seconds**.

During these six seconds, the LED of the product will flash in the color corresponding to the operating mode then the end of the sequence will be indicated by a **WHITE** fade acknowledging that the product has been put on standby. The magnet can therefore be removed.

## e. Radio module activity

Any sending of a radio frame is indicated by three brief **GREEN** flashes of the LED.

#### f. Threshold exceeded

When thresholds have been configured using the configurator and the measurement values exceed these thresholds, the product LED emits a periodic **ORANGE** flash to notify it.

#### g. Anti-fraud system

A mechanism (push button) is present on the product to notify any opening of the case during normal operation.

Normally, the box exerts pressure on the button. As soon as the back cover is removed, the button is released, triggering an alert. A light signal indicates that the opening of the case has been considered.

In addition, if the module is connected to a network, an alarm frame will be sent immediately when the box is opened and then closed.

#### h. Substitution to the magnet

You can use the push button on the ACW-TMxP card to perform the same actions as the magnet (activate or standby the product, activate / deactivate Bluetooth).

To do this, open the box and press the push button twice at the same time. A white flash indicates that the button now acts as the magnet (**button pressed = magnet approached**, refer to the chapters [Product Start up](#), [Sending a test frame](#) and [Deep sleep setup](#) above to know how to use the button).

**WARNING: Once the operations are complete, press the button twice again to restore it to its main function. A white flash indicates that the manipulation was successful.**

#### i. Battery passivation

The ACW-TMXP incorporates a battery depassivation feature, to limit the phenomenon of battery passivation during prolonged phases of deep standby. This feature is automatically activated as soon as the product goes into its deep sleep mode. The product will then wake up once a day to start the battery depassivation sequence, then the product will automatically return to deep standby.

# ACW configurator

## a. Compatible configurator version


For a TMxP with the following application software version	Use the version of ACW Configurator
Sigfox: V0.0.1 LoRaWAN: V0.0.1	V5.0.1 or later

Download and install the configuration software setup "setupACW.exe" at:

<https://www.atim.com/en/support-2/downloading/>



When the ACW Configurator is launched, the waiting window appears on the screen.



Click on "Help" at the top left of the window then on "About" to display the version number of the ACW configurator.

Pairing the ACW-TMxP with the configurator can be done in two ways:

- **Through USB:** open the case of the ACW-TMxP and connect it to a computer with a micro-USB cable.
- **Through Bluetooth:** make sure that Bluetooth is activated (see chapter [Enabling / Disabling of Bluetooth](#))



**Do not leave the product connected to the configurator (via USB or Bluetooth) unnecessarily, otherwise the autonomy of the product will be seriously degraded.**

## b. Configuration of the ACW-TMxP

The screenshot shows the configuration interface for the ACW/LWS-TMxP Temperature Monitoring module. The interface is divided into several sections:

- Frame of Measurement:** Contains "Periods" (Statement: 0h, 10m, 0s) and "Data Logging" (Number of samples: 1, Depth of historic: 1).
- General settings:** Contains "Keep alive period" (Once every day) and "Timestamp" (Disable).
- Radio Settings:** Contains "Radio Mode" (LoRaWan Class A) and "Radio Channel" (dropdown).
- Time Settings:** Contains "No Date" (0) and "Date Offset (in sec)" (dropdown).
- Temperature configuration:** Contains two sensor configurations (Sensor 1 and Sensor 2) with RTD type (PT100), Threshold (High/Low), Hysteresis, and Duration settings. It also includes "Temperature calibration" (offset, coefficient) and "Input Configuration" (Event mode, Pull, Trigger mode, Actual level, Input bounce time).

Red numbers 1 through 12 are overlaid on the interface to highlight specific configuration options:

- 1: Statement field in Periods
- 2: Number of samples field in Data Logging
- 3: Depth of historic field in Data Logging
- 4: Keep alive period dropdown
- 5: Timestamp dropdown
- 6: Radio Mode dropdown
- 7: No Date dropdown
- 8: Bottom status bar
- 9: Temperature configuration section header
- 10: Temperature calibration section header
- 11: Input Configuration section header
- 12: Close, Reload from file, and Save to file buttons

### Emission period and samples in the frame

The transmission period (1) corresponds to the time interval between each sending of a measurement frame. This period can be configured from 10 min to 255 h and its default value is 1 hour.

In addition, it is possible to configure the number of samples in a frame (2). Thus, several measurements will be carried out before the sending of the frame which will contain all these measurements.

For example, with a period of 12 minutes and several samples of 4, a measurement will be made every 3 minutes and the 4 samples will be sent in a single frame every 12 minutes.

Finally, it is possible to apply a redundancy of the data (3), which means that samples having been sent in the frame n-1, n-2 or n-3 could be sent again in the frame n to the continuation of the new measurement samples (the most recent sample first in the frame and the least recent last).

For example, for a history depth of 3, data from the last 2 frames will be sent, in addition to the new data, in the next frame.

### Keep alive frame period

A life frame can be sent periodically (4). This frame will contain the supply voltage of the product.

The value of this period can be configured from 1 hour to 1 month. By default, the value is set to 4 days.



## Frame timestamp

It is possible to enable / disable the timestamp in all radio frames (5).

**WARNING: This option when activated monopolizes 4 bytes in the frame which cannot be used for useful data.**

## Radio module configuration

The radio module can be configured to pair with a network (Sigfox or LoRaWAN) or to operate in local (or point-to-point) mode (6). If the local (or point to point) mode is chosen, it will also be possible to configure the frequency band to be used (which must be the same on the receiving module).

## Product's clock

Each time you connect to the configurator, the product clock is updated (based on the computer clock) and displayed (7). In addition, an offset in seconds can be applied if needed.

## Versions of the product

When connecting to the product, the configurator retrieves all the software versions of the product (product software and radio module software) as well as the network identifier (8).

## Temperature probes configuration

On the ACW-TMxP, two temperature probes can be connected and configured (9). We find as a parameter:

- Activation / deactivation of the probe
- Choice of probe value (PT100 / PT1000)
- The type of probe wiring (2/4 or 3 wires)

In addition, a threshold detection can be activated on each probe to detect a high or low threshold according to a configurable hysteresis and duration of overrun. When a measurement reaches a threshold, a radio frame will be sent (see the [Alert Frame](#) chapter for details on the frame format).

Finally, temperature compensation can be applied to correct measurement errors (10) (changes in this compensation are directly visible on the temperature value which is sent back in real time by the product to the configurator). The compensation includes two setting points: a temperature offset as well as a multiplying coefficient.

## Digital input configuration

The input can be configured according to the following parameters (11):

- **The function of the input:** edge detection, counting or deactivation
- The type of pulling of the line: towards the mass or towards the supply
- **The triggering edge:** rising, falling or both.

In addition, it is possible to set a debounce time which corresponds to the wait after a change of level before taking it into account ("Input bounce time" in the configurator).

Finally, when the input is configured for edge detection, and only in this mode, the current state of the input is shown on the right (under "Active level").

## Validation the configuration

After having filled all the configuration parameters, it is imperative to click on the button "Apply to ACW" to send the configuration to the product (12).

It is also possible at any time to read the current configuration of the product which will update the parameters on the configurator or to reset the default configuration of the product.

### c. Factory settings

#### Radio frame settings

- Emission period of a radio frame: 10 minutes
- Number of samplings: 1
- History depth: 1

#### General settings

- Emission period of the keep alive frame: 4 days
- Timestamp: disabled

#### Sensors settings

##### Probe 1

- State: Enabled
- Type of probe: PT100
- Wiring: 2/4 wires
- Threshold: disabled
- Temperature calibration: offset = 0 / coefficient = 1

##### Probe 2

- State: Enabled
- Type of probe: PT100
- Wiring: 2/4 wires
- Threshold: disabled
- Temperature calibration: offset = 0 / coefficient = 1


#### Input

- Function: disabled
- Tirage de la ligne : vers l'alimentation
- Trigger edge: descending
- Debounce time = 50 ms

#### d. Update of ACWs

When connected with Bluetooth Low Energy to the product, it is possible to update the different software that composes it.

To do this, go to the menu *Tools->Updater (CTRL+U)*



## Frames format

### a. Sigfox and LoRaWAN

Uplink frame			
Byte 1	Byte 2	...	Byte n
Frame header	Frame specific data		

We can differentiate three types of frames:

- **Classic frame; New generation:** Very similar to the old frames, the difference is that you can activate the timestamp. These are for example the life frame, the error frame, the response to configuration frames, ... These last frames are common to all ACWs but, it is also possible to have other independent frames for each ACWs.
- **Measuring frame; New generation:** These frames consist of samples of the different values of each of the channels that an ACW can read. Beforehand, the number of samples and the depth of the history will be inserted in the header.
 

**Notes:** The number of samples and the depth of the history are in common for all the channels of the frame.
- **Alert frame (threshold crossing); New generation:** These frames combine a conventional frame and a measurement frame. They consist of a header warning that a threshold has been exceeded, followed by samples of each of the channels for which a threshold has been exceeded.

### Classic frame

Byte 1 - header							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
New generation= 1	Timestamp = 1 - enabled 0 - disabled	Measuring frame= 0	Reserved= 0	Type of frame			

If the Timestamp is activated, 4 bytes with the Timestamp value will be preceded by the header (byte 1).

## The different type of frames

Type of frame	Data size	Descriptions
0x00	--	Reserved
0x01	4 bytes	Keep alive frame
0x02	0 bytes	Downlink request for network testing
0x03	--	Reserved
0x04	--	Reserved
0x05	1 byte	Teste frame with counter
0x06	Variable	(Cfg box) Answer to a configuration frame
0x07	Variable	(Cfg box) Answer to a command frame
0x08	Variable	(Cfg box) Answer to an error frame
0x09	--	Reserved
0x0a	--	Reserved
0x0b	--	Reserved
0x0c	--	Reserved
0x0d	Variable	Alert measurement frame (threshold crossing or return to normal), followed by the sample of each of the alert channels
0x0e	TBD	General error - TBD (memory, ...)
0x0f	Variable ...	Subframe for ACW. In function of the ACW product

## Measuring frame

Byte 1 - Header							
Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
New generation= 1	Timestamp	Measuring frame= 1	Depth of history (-1) Max: 4		Number of samplings (-1) Max: 8		

If the Timestamp is enabled, 4 bytes with the Timestamp value will be preceded by the header (byte 1).

**WARNING: if Depth of history or Number of samplings is greater than 1, the frame emission period will be added after header (byte 1) on two bytes (Little Endian encoding, LSB first)**

For each channel, a header is inserted below and is constituted as follows:

Channel header							
Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
Reserved= 0		Number of the channel		Type of measure			

In the case of ACW-TMxP, **the type of measurement** can take three values:

- 1 in decimal (0x01 in hexadecimal) for the input state.
- 4 in decimal (0x04 in hexadecimal) for a counting channel.
- 8 in decimal (0x08 in hexadecimal) for a temperature channel.

A temperature measurement will be expressed in hundredths of ° C on 2 bytes (encoding in **Big Endian**, MSB first)

Type of measure	Units	Data size	Type of the data	Descriptions
0x01	Bit	1 byte	Bit field	State of 8 inputs
0x04	Impulsions	4 bytes ( <b>Big Endian</b> – MSB)	Unsigned integer	Meter value
0x08	c°C	2 bytes ( <b>Big Endian</b> - MSB)	Signed integer	Temperature in <b>hundredth</b> of a degree Celsius <ul style="list-style-type: none"> <li>➤ Resolution: 0.05°C</li> <li>➤ Max value: 327.67°C</li> <li>➤ Min value: -327.68°C</li> </ul>

Then follow the data of the measurement sample (s) (depending on the configuration of the product). The number of bytes sent can be determined as follows:

$$(\text{Size in bytes of the measurement}) * (\text{number of samples}) * (\text{history depth})$$

**Example:** For example, for measurement type 0x08 (the size of a value is two bytes) with a history depth of 2 and 3 samples, the size of the data to be read would be 12 bytes (2x2x3).

**WARNING:** a received temperature of 0x8000 corresponds to a measurement error. This is often due to an improperly connected cable.

### Alert frame

Byte 1 - Header							
Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
New generation= 1	Timestamp	Measuring frame= 0	Reserved= 0	Alert frame = 0x0d			

If the Timestamp is activated, 4 bytes with the Timestamp value will be preceded by the header (byte 1).

For each of the channels in alert, a header is inserted and is constituted as follows:

Channel header							
Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
Alert type		Number of the channel		Type of measure			

The type of **alert field** is used to identify whether it is a breach of the high threshold, the low threshold or a return between the thresholds.

**WARNING:** A threshold alert can only be triggered by a temperature channel.

These values are defined as follows:

Value	Description
0x00	Return in the comfort zone
0x01	Upper threshold crossing
0x02	Lower threshold crossing
0x03	Reserved

The measurement type field here is identical to that of the measurement frame (i.e. 0x08 in hexadecimal for the ACW-TMxP).

The sample that caused the alert is then inserted afterwards (with **Big Endian** encoding - MSB first).

### Keep-alive frame

The life frame is sent at regular intervals according to the configuration applied (by default 4 days) and contains the battery levels of the product when empty (the product does nothing) and when charging (the product is transmitting a frame radio).

Byte 1 - Header							
Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
New generation = 1	Timestamp = 0	Measurement frame = 0	Reserved = 0	Keep-alive frame = 0x01			

Following this header are 4 bytes, 2 for the empty battery level and 2 for the charging battery level.

The frame is therefore split as follows: 0xAABBBBCCCC

0xAA being the frame header (always equal to 0x81), 0BBBB the empty battery level (value in millivolts, MSB coding) and 0CCCC the charging battery level (value in millivolts, MSB coding)

Example : 0x81 0d24 0c68

0d24: empty battery level = 3364 mV or 3.364 V

0c68: battery charge level = 3176 mV or 3.176 V

### Error and alarm generic frame

Byte 1 - Header							
Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
New generation= 1	Timestamp	Measuring frame= 0	Reserved= 0	Error frame= 0x0e			

If the Timestamp is activated, 4 bytes with the Timestamp value will be preceded by the header (byte 1).

For each error message, a header is inserted and is formed as follows:

Error frame header							
Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
Message index			Length of the error frame				

The **message index** field is used to prioritize messages when several errors occur.

The **length of the error message** field indicates the size in bytes of the error message.

The following byte identifies the nature of the error that occurred:

Error code	Nature of the error	Description
0x81	ERR_UNKNOWN	
0x82	ERR_BUF_SMALLER	The data table is full, impossible to write any additional data
0x83	ERR_DEPTH_HISTORIC_OUT_OF_RANGE	The history depth is too large or too small for the frame
0x84	ERR_NB_SAMPLE_OUT_OF_RANGE	The number of sampling is too large or too small for the frame
0x85	ERR_NWAY_OUT_OF_RANGE	The number of the channel in the header of the frame is too large or too small
0x86	ERR_TYPEWAY_OUT_OF_RANGE	The type of measurement in the frame header is too large or too small
0x87	ERR_SAMPLING_PERIOD	Bad structure of sampling period
0x88	ERR_SUBTASK_END	End of a sub-task after leaving an infinite loop
0x89	ERR_NULL_POINTER	Pointer with value "NULL"
0x8A	ERR_BATTERY_LEVEL_DEAD	Critical battery level
0x8B	ERR_EEPROM	EEPROM is corrupted
0x8C	ERR_ROM	ROM is corrupted
0x8D	ERR_RAM	RAM is corrupted
0x8E	ERR_ARM_INIT_FAIL	Radio module initialization has failed
0x8F	ERR_ARM_BUSY	The module is already busy (possibly not initialized)
0x90	ERR_ARM_BRIDGE_ENABLE	The module is in bridge mode, cannot send data by radio
0x91	ERR_RADIO_QUEUE_FULL	Radio queue is full
0x92	ERR_CFG_BOX_INIT_FAIL	Error during black box initialization
0x93	ERR_KEEP_ALIVE_PERIOD	Wrong keep alive frame structure
0x94	ERR_ENTER_DEEP_SLEEP	The device entered deep sleep mode
0x95	ERR_BATTERY_LEVEL_LOW	Low battery
0x96	ERR_ARM_TRANSMISSION	A transmission has been initiated but an error has occurred
0x97	ERR_ARM_PAYLOAD_BIGGER	Message size is too large for the capacity of the network
0x98	ERR_RADIO_PAIRING_TIMEOUT	Impossibility to pair to a network within the fixed period
0x99	ERR_SENSORS_TIMEOUT	A timeout has been reached out on the sensor
0x9A	ERR_SENSOR_STOP	The sensor did not report a value after reading



0x9B	ERR_SENSORS_FAIL	The sensor has stopped to operate
0x9C	ERR_BOX_OPENED	Casing opening
0x9D	ERR_BOX_CLOSED	Casing closing

Only codes 0x8A and 0x95 are followed by additional data corresponding to the battery level in millivolts. This value is coded in two bytes, the most significant byte first (MSB)

**Warning: for codes ranging from 0x81 to 0x92, the product will enter its FAULT mode and will no longer perform its measurement function. For codes ranging from 0x93 to 0x9D, these correspond only to alarms, so the product continues to operate normally.**

b. Examples of frames

Measuring frame

With timestamp off, no history and sample number of 1 (input disabled)

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
0xA0	0x08	0x22	0x21	0x18	0x28	0x21
(new generation measurement frame, no history, 1 sample)	(channel 0, type of measurement: temperature)			(channel 1, type of measurement: temperature)		

The first sensor on channel 0 returns a value of 0x0885 (21.81 ° C) and the second sensor on channel 1 returns a value of 0x0850 (21.28 ° C).

Now with 2 samples (input disabled)

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8	Byte 9	Byte 10	Byte 11	Byte 12	Byte 13
0xA1	0x003C	0x08	0x22	0x21	0x28	0x21	0x18	0x96	0x23	0x51	0x23	
(new generation measurement frame, no history, 2 samples)	(emission period)	(channel 0, type of measurement: temperature)					(channel 1, type of measurement: temperature)					

Bytes 2 and 3 indicate the transmission period, here 60 minutes (so a sample is measured every 30 minutes),

For channel 0, the first sample is 0x0885 (21.81 ° C) and the second is 0x08A4 (22.12 ° C).

For channel 1, the first sample is 0x0823 (20.83 ° C) and the second is 0x08C8 (22.48 ° C).

Here is an example of a frame with the input configured as a counter (1 sample, no history):

Octet 1	Octet 2	Octet 3-6	Octet 7	Octet 8	Octet 9	Octet 10	Octet 11	Octet 12
0xA0 (new generation measurement frame, no history, 1 sample)	0x04 (channel 0, type of measurement: counter)	0x00000014	0x08 (channel 0, type of measurement: temperature)	0x08	0x85	0x18 (channel 1, type of measurement: temperature)	0x08	0x50

The value of the counter is equal to 0x00000014 (20 in decimal).

For temperature channel 0, the sample is 0x0885 (21.81 ° C).

For temperature channel 1, the sample is 0x0823 (20.83 ° C).

### Alert measurement frame

For a high threshold exceeded on channel 0, the frame will be:

Byte 1	Byte 2	Byte 3	Byte 4
0x8D (new generation alert frame)	0x48 (high threshold 0 threshold exceeded, distance measurement)	0x29	0x38

The sample that triggered the threshold is 0x2938 (105.52 °C).

## Downlink

This functionality is available on ACW-TMxP fulfilling the following conditions:

	Application software	Radio firmware
SIGFOX version	V0.0.1	V5.9.3.1
LoRaWAN version	V0.0.1	v4.0.0

The operation of the Downlink is explained in the document ATIM\_ACW-DLConfig\_UG\_FR\_v1.4, relating to version V1.2.0 of the ATIM Downlink Protocol (see this document for all parameters and commands common to all products).

The parameters specific to ACW-TMxP are as follows:

### a. Configuration of the frame parameters (sending period, number of samples, etc.)

Parameter code (Byte 1)	Parameter value (Byte 2)	Parameter value (Byte 3)	Parameter value (Byte 4)
0x94	0b00YY0ZZZ	0xYY	0xZZ

For byte 2, the two bits YY correspond to the history depth (max = 3) and the three bits ZZZ correspond to the number of samples per frame (max = 7)

Bytes 3 and 4 correspond to the period for sending a frame (= 0xYYZZ) ranging from 1 minute to 255 hours (15,300 minutes).

**Example:** Byte 2 = 0x13

4 samples per frame + addition of the four samples sent to the previous frame.

Byte 3 = 0x02 and byte 4 = 0x54

Sending period = 0x0254 = 596 minutes

### b. Number of probes

Parameter code (Byte 1)	Parameter value (Byte 2)
0x17	0x00 = no probes enabled 0x01 = only 1 probe enabled 0x10 = only 2 probes enabled 0x11 = both probes are enabled

### c. Type of probes

Parameter code (Byte 1)	Parameter value (Byte 2)
0x18	0xYZ

This parameter identifies if the characteristic of the probe (PT100 or PT1000)

Field Z corresponds to probe 1 and field Y corresponds to probe 2.

The possible values for these fields are:

1 => PT100 probe

2=> PT1000 probe

### d. Threshold configuration

Parameter code (Byte 1)	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
0xD5 (threshold probe 1)	Upper threshold value		Lower threshold value		Hysteresis		Length
0xD6 (threshold probe 2)							

**High threshold value** field: temperature in hundredths of ° C triggering the high threshold (**Big Endian** encoding)

**Low threshold value** field: temperature in hundredths of ° C triggering the low threshold (**Big Endian** encoding)

**Hysteresis** field: margin of uncertainty for thresholds in hundredths of ° C (**Big Endian** encoding)

**Duration** field: minimum waiting time before triggering the alert after threshold is exceeded

### e. Input configuration

Parameter code (Byte 1)	Byte 2
0x1B	0bAABB0CCC

For the parameter value (byte 2), the byte is divided into three parts:

Bits 7.6 (AA) => choice of trigger edge: Rising edge - AA = 1; falling edge - AA = 2; ascending and descending fonts - AA = 3

Bits 5,4 (BB) => choice of pulling resistance: "+" pulling - BB = 1; draw to the mass - BB = 2.

Bits 2-0 (CCC) => choice of input mode: Edge detection - CCC = 1; counter 1 - CCC = 2;

counter 2 - CCC = 3; counter 3 - CCC = 4; counter 4 - CCC = 5

### f. Anti-rebound configuration

Parameter code (Byte 1)	Byte 2
0x1C	0xXX

This parameter allows you to configure the input debounce value in milliseconds.

The value of the parameter 0xXX can therefore be between 0x0A and 0xFF

g. Reserved codes for futures evolutions

Parameter code (Byte 1)	Parameter value (Byte 2)
0x10	0x08
0x11	0x00

WARNING: DO NOT CHANGE THESE VALUES

## Technical support

Contact our technical support team by email with any questions or technical problems you may have:

[www.atim.com/en/support-2/technical-support/](http://www.atim.com/en/support-2/technical-support/)