




8 027908 556516 >

D814077 0AA03_01
installation manual

version: 08242021

KUSTOS ULTRA BT

Thalia control board



Be ahead

Professional installation suggested
welding might be required

GATE AUTOMATION INSTALLATION SAFETY

While the manufacturer has designed the system under strict safety standards, it is ultimately the installers responsibility to follow and comply with national and local laws, codes and safety standards that apply to the mechanical, electrical and operational aspects of the gate automation system. These include but are not limited to: safety standards established by entities like Underwriters Laboratory (UL), NFPA 70, or codes and laws stated by corresponding state, county or municipality.

While it may not be compulsory, we highly recommend following UL 325 safety standards.

UL 325 VEHICULAR GATE AUTOMATION CLASSIFICATION

This system can be used in Class I, Class II and Class III applications.

- **CLASS I – RESIDENTIAL VEHICULAR GATE OPERATOR** - A vehicular gate operator (or system) intended for use in a home of one-to four single family dwelling, or a garage or parking area associated therewith.
- **CLASS II – COMMERCIAL/GENERAL ACCESS VEHICULAR GATE OPERATOR** - A vehicular gate operator (or system) intended for use in a commercial location or building such as a multi-family housing unit (five or more single family units), hotel, garages, retail store, or other building servicing the general public.
- **CLASS III – INDUSTRIAL/LIMITED ACCESS VEHICULAR GATE OPERATOR** - A vehicular gate operator (or system) intended for use in an industrial location or building such as a factory or loading dock area or other locations not intended to service the general public.
- **CLASS IV – RESTRICTED ACCESS VEHICULAR GATE OPERATOR** - A vehicular gate operator (or system) intended for use in a guarded industrial location or building such as an airport security area or other restricted access locations not servicing the general public, in which unauthorized access is prevented via supervision by security personnel.

UL 325 ENTRAPMENT PROTECTION REQUIREMENTS

For all installation classes, it is required to properly adjust the inherent obstruction sensing system and install warning signs on both sides of the gate, warning pedestrians of the dangers of the automated gate system. For Class I and Class II installations, it is required to add a non-contact device, such as a photoelectric eye **OR** a contact device such as a gate edge. For Class III installations it is required to add a non-contact device, such as a photoelectric eye, **AND** a contact device such as a gate edge **OR** an audio alarm such as a siren, horn or buzzer.

UL325 INSTALLATION RECOMMENDATIONS

1. Install the gate operator only when:

- a. The operator is appropriate for the construction and the usage class of the gate.
 - b. All openings of a horizontal slide gate are guarded or screened from the bottom of the gate to a minimum of 4' (1.2 m) above the ground to prevent a 2-1/4" (6 cm) diameter sphere from passing through the openings anywhere in the gate, and in that portion of the adjacent fence that the gate covers in the open position.
 - c. All exposed pinch points are eliminated or guarded, and guarding is supplied for exposed rollers.
2. The operator is intended for installation only on gates used for vehicles. Pedestrians must be supplied with a separate access opening. The pedestrian access opening shall be designed to promote pedestrian usage. Locate the gate such that persons will not come in contact with the vehicular gate during the entire path of travel of the vehicular gate.
 3. The gate must be installed in a location so that enough clearance is supplied between the gate and adjacent structures when opening and closing to reduce the risk of entrapment. Swinging gates shall not open into public access areas.
 4. The gate must be properly installed and work freely in both directions prior to the installation of the gate operator.
 5. Controls intended for user activation must be located at least six feet (6') away from any moving part of the gate and where the user is prevented from reaching over, under, around or through the gate to operate the controls. Outdoor or easily accessible controls shall have a security feature to prevent unauthorized use.
 6. The Stop and/or Reset (if provided separately) must be located in the line-of-sight of the gate. Activation of the reset control shall not cause the operator to start.
 7. A minimum of two (2) WARNING SIGNS (supplied with the gate operator) shall be installed, one on each side of the gate where easily visible.
 8. For a gate operator utilizing a non-contact sensor:
 - a. Reference owner's manual regarding placement of non-contact sensor for each type of application.
 - b. Care shall be exercised to reduce the risk of nuisance tripping, such as when a vehicle trips the sensor while the gate is still moving.
 - c. One or more non-contact sensors shall be located where the risk of entrapment or obstruction exists, such as the perimeter reachable by a moving gate or barrier.
 9. For a gate operator utilizing a contact sensor such as an edge sensor:
 - a. One or more contact sensors shall be located where the risk of entrapment or obstruction exists, such as at the leading edge, trailing edge and post mounted both inside and outside of a vehicular horizontal slide gate.
 - b. One or more contact sensors shall be located at the bottom edge of a vehicular vertical lift gate.
 - c. A hard wired contact sensor shall be located and its wiring arranged so the communication between the sensor and the gate operator is not subject to mechanical damage.
 - d. A wireless contact sensor such as the one that transmits radio frequency (RF) signals to the gate operator for entrapment protection functions shall be located where the transmission of the signals are not obstructed or impeded by building structures, natural landscaping or similar obstruction. A wireless contact sensor shall function under the intended end-use conditions.
 - e. One or more contact sensors shall be located on the inside and outside leading edge of a swing gate. Additionally, if the bottom edge of a swing gate is greater than 6" (152 mm) above the ground at any point in its arc of travel, one or more contact sensors shall be located on the bottom edge.
 - f. One or more contact sensors shall be located at the bottom edge of a vertical barrier (arm).

OPERATIONAL SAFETY

⚠ WARNING

Moving Gate Can Cause Serious Injury or Death

Entrapment / Crush Zones for Double Swing Gate Application

Zone 1 - Leading edge of the gate and the fence post

Zone 2 - Between the gate and the gate post


Zone 3 - The travel path of the gate

Zone 4 - The space between the gate in the open position and any object such as a wall, fence, tree etc.

Zone 5 - Pinch points between the opener and gate

To reduce the risk of INJURY or DEATH:

- READ AND FOLLOW ALL INSTRUCTIONS.
- NEVER let children operate or play with gate controls. Keep the remote control away from children.
- ALWAYS keep people and objects away from the gate. NO ONE SHOULD CROSS THE PATH OF THE MOVING GATE.
- Test the gate operator monthly. The gate MUST reverse on contact with an object or reverse when an object activates the noncontact sensors. After adjusting the force or the limit of travel, retest the gate operator. Failure to adjust and retest the gate operator properly can increase the risk of INJURY or DEATH.
- Use the emergency release ONLY when the gate is not moving.
- KEEP GATES PROPERLY MAINTAINED. Read the owner's manual. Have a qualified service person make repairs to gate hardware.
- The entrance is for vehicles ONLY. Pedestrians MUST use separate entrance.



UL325 Entrapment Protection Requirements

- A **minimum of two** independent* monitored entrapment protection devices are required to be installed at each entrapment zone
- Every installation is unique. It is the responsibility of the installer to install external monitored entrapment protection devices in **each entrapment zone**
- This vehicular swing gate operator will operate only after installation of a **minimum of two** independent* monitored entrapment protection devices in either the open or close direction. If no entrapment zone exists in the other direction of gate travel, then the inherent (built into the operator) is all that is required in that direction.
- Entrapment protection device types include inherent (built into the operator), monitored external photoelectric sensors or monitored external edge sensors
- This operator is provided with an inherent entrapment protection device built into the operator that serves as one of the two independent devices

* Independent - the same type of device shall NOT be used for both entrapment protection devices.

GENERAL SAFETY

WARNING! An incorrect installation or improper use of the product can cause damage to persons, animals or property.

- Automation should be installed on a gate which is moving freely. Any issue with the smooth opening or closing of a gate will not be corrected by adding automation.
- Scrap packing materials (plastic, cardboard, polystyrene etc) according to the provisions set out by current standards. Keep nylon or polystyrene bags out of children's reach.
- Keep this instruction manual for future reference.
- This product was exclusively designed and manufactured for the use specified in the present documentation. Any other use not specified in this documentation could damage the product and be dangerous.
- The Company declines all responsibility for any consequences resulting from improper use of the product, or use which is different from that expected and specified in the present documentation.
- Do not install the product in explosive atmosphere.
- The Company declines all responsibility for any consequences resulting from failure to observe Good Technical Practice when constructing closing structures (door, gates etc.), as well as from any deformation which might occur during use.
- Follow and comply with national and/or local electrical codes when performing any electrical installation.
- Disconnect the electrical power supply before carrying out any work on the installation. Also disconnect any buffer batteries, if fitted.
- Fit all the safety devices (photocells, electric edges etc.) which are needed to protect the area from any danger caused by squashing, conveying and shearing, according to and in compliance with the applicable directives and technical standards.
- It is recommended to position at least one luminous signal indication device (blinker) where it can be easily seen for additional safety
- The Company declines all responsibility with respect to the automation safety and correct operation when other manufacturer's components are used.
- Only use original parts for any maintenance or repair operation.
- Do not modify the automation components, unless explicitly authorized in writing by the Company.
- Instruct the product user about the control systems provided and the manual opening operation in case of emergency.
- Anything which is not expressly provided for in the present instructions, is not allowed.
- Installation must be carried out using the safety devices and controls prescribed by the UL 325 Standard.

CHECKING INSTALLATION

Before the automated device is finally put into operation, perform the following checks meticulously:

- Make sure all components are fastened securely.
- Check that all safety devices (photocells, pneumatic safety edge, etc.) are working properly.
- Check the emergency operation control device.
- Check opening and closing operations with the control devices applied.
- Check the electronic logic for normal (or personalized) operation in the control panel.

ADJUSTING OPERATING FORCE

WARNING: Operating force is adjusted with extreme precision by means of the control unit's electronic control. Operation at the end of travel is adjusted electronically in the control panel. To provide good anti-crush safety, the operating force must be slightly greater than that required to move the leaf both to close and to open it.

CONTROL

There are various options when it comes to the control system (manual, remote control, access control with magnetic badge, etc.) depending on the installation's needs and characteristics. See the relevant instructions for the various control system options. People due to use the automated device must be instructed how to control and use it.

OPERATIONAL SAFETY

The Installer is responsible for communicating the following information to the end-user:

This product has been designed and built solely for the purpose indicated herein. Uses not contemplated herein might result in the product being damaged and could be a source of danger.

The Firm disclaims all responsibility resulting from improper use or any use other than that for which the product has been designed, as indicated herein, as well as for failure to apply Good Practice in the construction of entry systems (doors, gates, etc.) and for deformation that could occur during use. If installed and used correctly, the automated system will meet the required level of safety. Nonetheless, **it is advisable to observe certain rules of behavior so that accidental problems can be avoided:**




- Keep adults, children and property out of range of the automated system, especially while it is operating.
- Operate the system when the full path of the gate is within sight.
- It is essential to frequently check that all safety devices are in good working condition.
- This application is not meant for use by people (including children) with impaired mental, physical or sensory capacities, or people who do not have suitable knowledge, unless they are supervised or have been instructed by people who are responsible for their safety.
- Children must be supervised to ensure they do not play with the system. Keep remote controls or other control devices out of reach of children in order to avoid the automated system being operated inadvertently.
- Check the system frequently, especially hinges, cables, springs or supports, to detect any loss of balance and signs of wear or damage.
- When cleaning the outside or performing other maintenance work, always cut off mains power.
- Keep the photocells' optics and illuminating indicator devices clean. Check that no branches or shrubs interfere with the safety devices (photocells).
- Do not use the automated system if it is in need of repair. In the event of a malfunction, cut off the power, activate the emergency release to allow access and call in qualified technical personnel (professional installer).
- If the automated system requires work of any kind, employ the services of qualified personnel (professional installer).
- Anything that is not explicitly provided for in these instructions is not allowed.
- The operator's proper operation can only be guaranteed if the information given herein is complied with. The Firm shall not be answerable for damage caused by failure to comply with the installation rules and instructions featured herein.
- Have the complete system checked including all safety devices by a qualified professional technician at least once a year.

Descriptions and illustrations herein are not binding. While we will not alter the product's essential features, the Firm reserves the right, at any time, to make those changes deemed necessary to improve the product from a technical, design or commercial point of view, and will not be required to update this publication accordingly.


Installation Safety	2
Operational Safety	3
Applications and Capacities	5
Post Bracket Installation.....	6
Gate Bracket Installation.....	7
Push to Open Installation.....	8
Actuator Cable.....	9
Mounting the Actuator.....	10
Setting the Limits.....	11
Installing the Standard Control Box.....	12
Installing the Optional Control Box.....	13
Motor Connections.....	14
Quick Setup Menu.....	15
Presets.....	17
Accessory Connections.....	19
Accessory Power	
Command Inputs	
Safety Devices.....	20
Safety Loop Detector Wiring	
Auxiliary Outputs.....	21
Shadow Loop Detector Wiring	
Navigating the Main Menu.....	22
Programming Menu.....	23
Other Accessories Connections.....	24
Magnetic Lock Wiring	
Battery Backup Wiring	
Maintenance.....	25
Manual operation	
Common Error Codes	
Replacement Parts.....	26
Options & Accessories.....	27
At A Glance Quick Reference.....	28



Important. This product is intended to be installed and serviced by a professional technician. The product warranty may be voided if installed or serviced by a unqualified person.




an external locking mechanism is suggested
for gates over 10 feet long




*** Maximum hinge offset does not apply to push to open applications**

WARNING

Please read and follow all instructions before installing and operating this product. Follow all local and federal building and electrical. BFT is not responsible for faults or damage cause by improper installation, application, or failure to comply with building codes.




Depending on the size of the post, the type of hinge and its placement, the post bracket might have to be mounted offset to the gate post. This should require custom welding a brace or gusset (not supplied)



Hinge offset: Distance between the center-line of the hinge and the inside edge of the gate post

a, z, b... wtf?



Bft Easy Set 4+
BFT SpA
Free

Download the app:

For Apple Store:







For Andriod:



The suggested post bracket length positions are accurate only if the gate, on its fully closed position, is squared with the gate post








When the gate is on its fully open, or fully closed position, the distance from the center of the mounting hole of the gate bracket, to the hinge center-line, must be equal or less than that of the mounting hole on the post bracket to the hinge center-line. If you feel that you have followed the instructions on how to mount the brackets, and the distance of the hole of the gate bracket to the hinge center-line is greater than that of the post bracket, stop the installation process and contact technical support.




WARNING: Push to open installations are not standard installations. The post bracket should require modifications and/or welding. The following illustrations do not represent the actual assembly of the post bracket. Its intentions is to illustrate the directions and dimensions of the bracket in relationship to the gate




1. Strip about 1-1/2" off the outer jacket of the motor cable. Install the o-ring over the cable so that it is about 1/2" from the edge of the outer jacket




2. Turn the actuator upside down. Connect the white wire to terminal 1; the red wire to terminal 2; and the black wire to terminal 3



3. Install the back cover, making sure that the o-ring fits inside the groove to seal the operator from moisture





Attach the actuator to the mounting brackets as shown on the images above.




DO NOT INSTALL THE SNAP RINGS YET!!!


Place them in a secure location. Install the snap rings only once you have completely finalized the installation and all adjustments.




MAKE SURE THAT THE BODY OF THE ACTUATOR DOES NOT HIT THE MOUNTING BRACKET WHEN THE GATE IS FULLY CLOSED





Set to manual operation
disengage the drive gear by using the key
and turning clockwise



Remove cover plate and slide off cover




Push the gate to its fully open position




Loosen two bolts and slide the micro switch
limit cam up against stop. Tighten two bolts



Set to manual operation
disengage the drive gear by using the key
and turning clockwise



Push the gate to its fully closed position




Loosen two bolts and slide the micro switch
limit cam up against stop. Tighten two bolts



Re-engage the manual release by using the
key counterclockwise.

Mounting the enclosure

Use the mounting holes on the top and bottom flanges of the enclosure. Do not drill through the interior of the enclosure.






Do not perforate the top of the enclosure




Bring all your wiring and/or conduits through the bottom of the enclosure. For best results, use a step drill bit to perforate the enclosure to the needed size opening

Connecting power






For single gate installations,
connect your motor wires to Motor 1
motor output (terminals 10 & 11),
and Motor 1 limit input (terminal 42).



For dual gate installations,
connect your second motor wires to
Motor 2 motor output (terminals 14 &
15), and Motor 2 limit input (terminal
43).



When installing a two leaf gate system, connect the motor wires from the gate that needs to open first to Motor 1 connections (10, 11 & 42), and connect the motor wires from the gate that needs to close first to Motor 2 connections (14, 15, & 43).


****IMPORTANT** Photo sensor(s) MUST be properly installed (see p.20) BEFORE the AUTOSET procedure!**

****IMPORTANT** OPEN and CLOSE limit switches MUST be properly adjusted (see p.11 - 12) BEFORE the AUTOSET procedure!**

Quick Setup Menu flow chart



Quick Setup Menu navigation





Pressing the **[+]** button scrolls **UP**

Pressing the **[-]** button scrolls **DOWN**




Pressing the **[OK]** button moves to the **NEXT** selection.

Pressing **[+]** and **[-]** at the same time **EXITS** the menu




STEP 1. Enter Quick Setup Menu






STEP 2. Set the menu language






STEP 3. Select the type of operator






STEP 4. Set the number of motors connected



STEP 5. Set the opening direction



STEP 6. Set the desired preset



PRESETS

FEATURES	AR	SR	AC	SC	IND
	AUTOMATIC RESIDENTIAL	SEMI-AUTOMATIC RESIDENTIAL	AUTOMATIC COMMERCIAL	SEMI-AUTOMATIC COMMERCIAL	INDUSTRIAL
AUTOMATIC CLOSING TIMER	X		X		
PRE-ALARM			X	X	
UNINTERRUPTED OPEN CYCLE			X	X	
INSTANT REVERSE ON CLOSING	X		X		
HOLD TO RUN					X
QUICK REMOTE PROGRAMMING	X	X	X	X	

Automatic Closing Timer: Automatically closes the gate after gate fully opens and all safety devices are cleared.

Pre-Alarm: Energizes auxiliary relay with value set to “6”, for 3 seconds before energizing the motors.

Uninterrupted Open Cycle: Remote controls and START input is ignored during the open cycle.

Instant Reverse On Closing: A START command will instantly re-open gates during the close cycle. Otherwise, a START command first stops the gate requiring a second command to re-open.


Hold-To-Run: START command is disabled. Gate requires a constant “open “ or “close” command for it to run.

Quick Remote Programming: Allows adding remotes wirelessly using an existing working transmitter.


The “Residential” presets are not exclusive for residential applications the same way “Commercial” presets are not exclusive for commercial applications. They can both be used on any application depending on the needs and preferences of such installation. You can further customize your settings by using the Main Programming Menu.

STEP 7. Run the AUTOSET


AFTER SELECTING YOUR PRESET, THE SCREEN WILL DISPLAY "PROG" (PROGRAMMING) FOR A FEW SECONDS



THE SCREEN WILL DISPLAY "AUTOSET"




BE AWARE THAT THE GATE WILL RUN AT FULL TORQUE DURING THE PROCESS. PRESS [OK] WHEN READY




MAKE SURE THAT THE PATH OF THE GATE IS CLEAR OF TRAFFIC AND OBSTRUCTIONS.


THE MOTOR(S) WILL RUN FULL OPEN AND CLOSE CYCLES MORE THAN ONCE...



IF THE MOTOR(S) DON'T RUN AND/OR "KO" IS DISPLAYED, INSPECT THE GATE HARDWARE, MOTOR CONNECTIONS AND MANUAL RELEASE




ONCE "OK" IS DISPLAYED, PRESS THE [OK] BUTTON TO CONTINUE




STEP 8. Program wireless transmitters


THE DISPLAY WILL READ "MEM. REMOTES" (MEMORIZE REMOTES)...




...IMMEDIATELY FOLLOWED BY "HIDDEN BUTTON". FIRMLY PRESS AND HOLD DOWN THE 2 TOP BUTTONS ON YOUR MITTO REMOTE




WHEN THE SCREEN READS "RELEASE", RELEASE THE TWO BUTTONS




THE SCREEN WILL THEN READ "DESIRED BUTTON"



PRESS AND RELEASE THE BUTTON YOU WISH TO OPERATE THE GATE WITH




THE SCREEN DISPLAYS "HIDDEN BUTTON" AGAIN. YOU CAN REPEAT THE REMOTE LEARNING PROCESS OR PRESS [OK] TO END



ACCESSORY POWER

24 volts accessories and peripherals can be powered from terminals 50 and 51


Terminal	Name	Description
50	- 24 V	Accessory power negative common
51	+ 24 V	Accessory power positive
52	+ 24 V-Safe	Positive power when gate is not closed



COMMAND INPUTS

The Thalia board provides two command inputs (IC1 and IC2).

Terminal	Name	Description	Default
60	COM	Command positive common	common
61	IC 1	Command Input 1	START
62	IC 2	Command Input 2	PED




Command inputs 1 and 2 can be re-programmed to perform any of the following functions:

PROGRAMMING: LOGIC > IC # > 000 ~ 006

- 001 **START** Cycles between open, stop and close. Normally used with single push-buttons and radio receivers.
- 002 **OPEN** Open only command. Used with [open] buttons, free exit and/or open only devices.
- 003 **CLOSE** Close only. Used with [close] buttons and closing loop detectors
- 004 **PED** Pedestrian opening. Partially opens Motor 1 only.
- 005 **TIMER** Hold Open input.
- 006 **TIMER PED** Holds partially open motor 1

Please refer to LOGIC programming for IC 1 and IC 2 re-programming

EXAMPLE: OPEN ONLY DEVICES WIRING



PROGRAMMING: LOGIC > IC 1 > 001 (OPEN)


NOTE: The same entrapment features are NOT required to be active during both cycles, however, two entrapment features must be present during both cycles.

The Thalia board provides:

- one **STOP** command input;
- one obstruction sensing device input **UL 325-2016** compatible, **SAFE 1** with its mandatory supervision circuit input **FAULT 1**. The system reacts to the input in both opening (stops) and closing (reverses) cycles;
- Programmable obstruction sensing device input for **SAFE 1**, 001 PHOT TEST (default setting) and 005 PHOT CL TEST (reacts to input during closing only)
- two programmable obstruction sensing device inputs, **SAFE 2** and **SAFE 3**, both provided with their optional supervision circuit input **FAULT 2** and **FAULT 3**.

All the 3 safety inputs are **N.C. (normally closed)** contacts. All the FAULT inputs are **N.O. (normally open)** contacts. Below is a table with the terminal numbers and their corresponding functions and default values.


Terminal	Name	Description	Default	Notes
70	COM	Safety positive common	Common	
71	STOP	Stop command	STOP	Overrides all other commands
72	SAFE 1	Safety input #1	PHOT	Stops operators during opening, reverses on closing
73	FAULT 1	Supervisory circuit for SAFE 1	FAULT	Requires opposite relay state from SAFE 1
74	SAFE 2	Safety input #2	006 - BAR	Programmable input (see LOGIC sub-menu)
75	FAULT 2	Supervisory circuit for SAFE 2	FAULT	Requires opposite relay state from SAFE 2
76	COM	Safety positive common	Common	
77	SAFE 3	Safety input #3	015 - SHADOW	Programmable input (see LOGIC sub-menu)
78	FAULT 3	Supervisory circuit for SAFE 3	FAULT	Requires opposite relay state from SAFE 3




Both **SAFE 2** and **SAFE 3** can be programmed to perform any of the following functions under the **LOGIC** sub-menu:


VALUE	FUNCTION	DESCRIPTION
000	PHOT	System reacts to the input in both opening (stops) and closing (reverses) cycles
001	PHOT TEST	Same as above. Requires the device to be supervised (FAULT active)
002	PHOT OP	System reacts to the input only during the opening cycle (stops)
003	PHOT OP TEST	Same as above. Requires the device to be supervised (FAULT active)
004	PHOT CL	System reacts to the input only during the closing cycle (reverses)
005	PHOT CL TEST	Same as above. Requires the device to be supervised (FAULT active)
006	BAR	Safety edge input. It reacts in both opening and closing. It stops and partially reverses
007	BAR TEST	Same as above. Requires the device to be supervised (FAULT active).
008	BAR 8K2	Safety edge input with EOL resistor as supervision method. Active only on SAFE 2
009	BAR OP	Safety edge input. During opening it stops and partially reverses. During closing it stops.
010	BAR OP TEST	Same as above. Requires the device to be supervised (FAULT active)
011	BAR OP 8K2	Safety edge input with EOL resistor as supervision method. During opening it stops and partially reverses. During closing it stops. Active only on SAFE 2
012	BAR CL	Safety edge input. During closing it stops and partially reverses. During opening it stops.
013	BAR CL TEST	Same as above. Requires the device to be supervised (FAULT active)
014	BAR CL 8K2	Safety edge input with EOL resistor as supervision method. During closing it stops and partially reverses. During opening it stops. Active only on SAFE 2
015	SHADOW	Safety loop input. If the contact is closed, it prevents any movement of the leaves when gate is open (VALUE 0 of the LOGIC SHADOW) or when the gate is both open and closed (VALUE 1 of the LOGIC SHADOW). See chart example N. 3 on next page.

EXAMPLE 1: UL 325-2016
SAFETY PHOTO BEAM SENSOR WIRING



EXAMPLE 2: UL 325-2016
SAFETY PHOTO BEAM SENSOR WIRING



EXAMPLE 3: SHADOW LOOP DETECTOR WIRING**PROGRAMMING:**


LOGIC > SAFE 3 > 015 (SHADOW)
LOGIC > SHADOW > 0 or 1

GATE POSITION	LOGIC "SHADOW"	LOOP CONTACT	OPERATION
CLOSED	0	CLOSED	Opening allowed
CLOSED	0	OPEN	Opening allowed
IN MOVEMENT	0	CLOSED	No effect
IN MOVEMENT	0	OPEN	No effect
OPEN	0	CLOSED	Closing allowed
OPEN	0	OPEN	Closing not allowed
CLOSED	1	CLOSED	Opening allowed
CLOSED	1	OPEN	Opening not allowed
IN MOVEMENT	1	CLOSED	No effect
IN MOVEMENT	1	OPEN	No effect
OPEN	1	CLOSED	Closing allowed
OPEN	1	OPEN	Closing not allowed

AUXILIARY OUTPUTS

The Thalia board has two auxiliary outputs. The first (20 & 21), is a 24 volt, courtesy light output that will activate upon activation of the gate, and will remain on for 90 seconds after the gate has closed.


The second output labeled **AUX 3** (26 & 27), is defaulted as second channel radio receiver output, but can be re-programmed to perform any of the following functions under the **LOGIC** sub-menu:



AUX3 max contact rating: 24v, 3W
(transistor output)

VALUE	FUNCTION
0	2ND CHANNEL RECEIVER OUTPUT. Output active when transmitter activates the 2nd channel
1	GATE OPEN LIGHT. Output active when gate is not closed. flashes while closing
2	COURTESY LIGHT. Output active during and for 90 seconds after operation.
3	GATE NOT CLOSED. Output active until close limit is reached
4	START OF CYCLE. Output active for 1 second at the beginning of each cycle
5	GATE OPEN ALARM. Output active if gate is held open for more than double the timer to close time
6	GATE RUNNING. Output active while motors are powered
7	SOLENOID LOCK. Output active for 2 second at the beginning of open cycle
8	MAGNETIC LOCK. Output active when gate is closed

Main Programming Menu navigation




- Pressing the **[+]** button scrolls **up** or **increases** value
- Pressing the **[-]** button scrolls **down** or decreases value
- Pressing the **[OK]** button serves as **ENTER**
- Pressing **[+]** and **[-]** at the same time serves as **BACK**


(Parameters) PARAM	Sub-menu. All numerical value are set in this area (times, forces, & speeds).
LOGIC	Sub-menu. All features and functions are selected in this area .
RADIO	Sub-menu. Built-in receiver programming (remote controls and wireless devices).
DEFAULT	Restores all factory settings. Has no effect on RADIO programming.
LANGUAGE	Selection of menu language.
AUTOSET	Motor learn feature.
STAT	Provides firmware and memory information.
PASSWORD	Password setting for wireless programmer.


MAIN	SELECTION	DESCRIPTION	DEFAULT	RANGE
PARAM >	OPEN DELAY TIME	Motor 2 opening delay in seconds	1	0-10
	CLS DELAY TIME	Motor 1 closing delay in seconds	1	0-10
	TCA	Auto-close time adjustment in seconds	10	1-180
	TRF. LGHT.CLR. T	Traffic zone clear time adjustment in seconds	40	1-180
	OP. DIST. SLOWD	Slowdown starting distance from end of open travel expressed in percentage	10	0-50
	CL. DIST. SLOWD	Slowdown starting distance from end of close travel expressed in percentage	10	0-50
	DIST. DECEL	Slowdown starting distance from end of open and close travel expressed in percentage	15	0-50
	OP. FORCE	Percentage of opening force exerted over the AUTOSET value before obstruction is sensed	50	1-99
	CLS. FORCE	Percentage of closing force exerted over the AUTOSET value before obstruction is sensed	50	1-99
	OP SPEED	Motor opening speed expressed in percentage	99	15-99
	CL SPEED	Motor closing speed expressed in percentage	99	15-99
	SLOW SPEED	Slowdown speed expressed in percentage from maximum speed.	25	15-99
LOGIC >	MOTOR TYPE	1=Eli 250; 2=Phobos BT, 3=Igea BT	0	0-3
	TCA	Timer to Close Automatically. 0=OFF / 1=ON	0	0-1
	FAS T CLS.	Closes when sensors are cleared. 0=OFF / 1=ON	0	0-1
	STEP-BY-STEP MOVEMENT *	Determines how the system reacts when a START command is received during operation	0	0-2
	SHADOW	Configuration of safety loop input terminal 74 or 77 when SAFE 2 or SAFE 3 are set as 015 (SHADOW). Prevent any movement of the leafs when gate is open (VALUE 0) or when the gate is both open and closed (VALUE 1).	0	0-1
	SAFE 3 *	Configuration of safety input terminal 76. Defaulted as SHADOW (Safety loop)	15	0-15
	PRE-ALARM	Gate running output (AUX value=6) closes 3 sec. before gate movement. 0=OFF / 1=ON	0	0-1
	HOLD-TO-RUN	Requires continuous OPEN or CLOSE command input for gate to operate. 0=OFF / 1=ON	0	0-2
	IBL OPEN	Ignores START input during the opening cycle. 0=OFF / 1=ON	0	0-1
	IBL TCA	Ignores the START input while counting down for automatic closing. 0=OFF / 1=ON	0	0-1
	IBL CLOSE	Ignores the START input during the closing cycle. 0=OFF / 1=ON	0	0-1
	RAM BLOW C. OP	Pushes gate against physical stop before opening	0	0-1
	RAM BLOW C. CL	Pushes gate against physical stop before closing	0	0-1
	BLOC PERSIST	Hourly push against physical stop	0	0-1
	PRESS SWC	Pushes gate against physical stop for .5 seconds after close limit has been reached.	0	0-1
	ICE	Continuous force learning on every operation.	0	0-1
	1 MOT. ON	Single Motor operation. 0= (2)motors; 1=(1)motor.	0	0-1
	OPEN IN OTHER DIRECT.	0 = Pull to open; 1 = Push to open	0	0-1
	SAFE 1 *	Configuration of safety input terminal 72. Defaulted as Phot Test (Obstruction).	1	1&5
	SAFE 2 *	Configuration of safety input terminal 74. Defaulted as BAR (Safety Edge)	6	0-15
	SAFE 3 *	Configuration of safety input terminal 76. Defaulted as SHADOW (Safety loop)	15	0-15
	IC 1 *	Configuration of command input terminal 61. Defaulted as Start E	0	0-6
	IC 2 *	Configuration of command input terminal 62. Defaulted as Ped (Partial open)	4	0-6
	AUX 3 *	Configuration of auxiliary output terminals 26 & 27. Defaulted as 2 nd channel contacts.	0	0-8
	FIXED CODE	Rolling code defeat. 0 = rolling code; 1 = fixed code	0	0-1
	RADIO PROG	Quick remote programming. 0 = disabled; 1 = enabled	1	0-1
	SERIAL MODE	0 = Slave unit; 1 = Master unit	0	0-1
	ADDRESS	Unit's network identification number.	0	0-127
	EXPI 1 *	Configuration of Expansion board input 1. Defaulted as Start command.	1	0-14
	EXPI 2 *	Configuration of Expansion board input 2. Defaulted as Start command.	0	0-10
	EXPO 1 *	Configuration of Expansion board output 1. Defaulted as Traffic light control..	9	0-9
	EXPO 2 *	Configuration of Expansion board output 2. Defaulted as Traffic light control..	9	0-9
	TRAFFIC LIGHT PREFLASHING	Red light flashes for 3 sec. at every start. 0 = Off; 1 = On	0	0-1
	TRAFFIC LIGHT RED LAMP ALWAYS ON	Red light remains on when gate is closed. 0 = Off; 1 = On	0	0-1
RADIO >	ADD START	Learns transmitter button as START command		
	ADD 2CH	Learns transmitter button as 2 nd channel		
	ERASE 64	Erase complete memory		
	COD RX	Show receiver ID Code		
	WK	W LINK.		
DEFAULT	Restores board to factory settings. No effect on RADIO			
LANGUAGE >	ITA	Italian		
	FRA	French		
	DEU	German		
	ENG	English		
	ESP	Spanish		
AUTOSET	Operates motor(s) several times and automatically adjust its FORCE settings			
L. SW ADJ	Limit of travel adjustment. Only available with type 4 and 5 motors			
STAT >	VERS	Displays board firmware version.		
	N. CYCLES	Displays number of hundreds of cycles (001=100; 010=1000; 100=10,000)		
	N. REMOTES	Displays the number of remotes in memory.		
	ERR	Displays the last 30 board errors in descending order.		
PASSWORD	Password setting for wireless programmer			

MAGNETIC LOCK WIRING USING BFT 24V AC/DC RELAY



BATTERY BACKUP WIRING DIAGRAM






MANUAL OPERATION - Disengage the drive gear by using the key and turning clockwise. Re-engage the gears by turning the key counterclockwise.

COMMON ERROR CODES

ERROR	DESCRIPTION	ERROR	DESCRIPTION
ER20	MOTOR 2 IMPROPER ENCODER MOVEMENT DETECTED	ER35	MOTOR 1 OBSTACLE DETECTION DURING OPENING
ER22	MOTOR 2 OPPOSITE MOVEMENT	ER36	MOTOR 1 OBSTACLE DETECTION DURING CLOSING
ER25	MOTOR 1 IMPROPER ENCODER MOVEMENT DETECTED	ER37	MOTOR 1 OBSTACLE DETECTION DURING OPENING SLOWDOWN
ER27	MOTOR 1 OPPOSITE MOVEMENT	ER38	MOTOR 1 OBSTACLE DETECTION DURING CLOSING SLOWDOWN
ER30	MOTOR 2 OBSTACLE DETECTION DURING OPENING	ER40	THERMAL OVERLOAD
ER31	MOTOR 2 OBSTACLE DETECTION DURING CLOSING	ER61	OPERATING ON BATTERY POWER
ER32	MOTOR 2 OBSTACLE DETECTION DURING OPENING SLOWDOWN	ERSW	ERROR SETTING LIMITS
ER33	MOTOR 2 OBSTACLE DETECTION DURING CLOSING SLOWDOWN	ERF9	LOCK OUTPUT OVERLOAD
ERF3	SAFETY INPUT CONFIGURATION ERROR	ER01	PHOTOCELL TEST FAILED



D111881 00001 Thalía Board Replacement

OPTIONS AND ACCESSORIES



Thalía UL SE

Small enclosure
no battery back-up



UL Alarm and Reset

Included in small and large enclosure

KUSTOS SERIES

- KR935317 00004 - SE Kustos Thalia UL SE – Single Kit
 KLEBR93531704 - LEB Kustos Thalia UL Large Enclosure-
 Battery Back Up - Single Kit
 KR935317 00005 - SE Kustos Thalia UL SE- Dual Kit
 KLEBR93531705 - LEB Kustos Thalia UL Large Enclosure –
 Battery Back Up - Dual Kit
 P935101 00002 - Kustos Ultra Bt A25
 (Rated For Gates 10ft/550lbs.)
 P935102 00003 - Kustos Ultra Bt A40 UL Operator Only
 (Rated For Gates 16ft./550lbs.)

Thalia UL SE

- 10" x 12" Hinged fiberglass enclosure
- UL 2018 compliant
- UL Alarm and Reset



Thalia UL LEB

- Large 12" x 14" Hinged fiberglass enclosure
- UL 2018 compliant
- Includes: Battery backup with (2) 12V, 9 AH batteries, 115V outlets for accessories
- UL Alarm and Reset



ACCESSORIES



N999629 MITTO 4 RAINBOW
 4 X 4 CH Mitto Transmitters- White, Blue, Burgundy & Yellow
 4 button remote control
 433 Mgtz



P111468 B EBA WIFI GATEWAY Two serial connection interfaces required for MERAK UL board master and slave connections.



P125020 BT BAT
 Battery Backup For Thalia Control Boards
 - plugs directly into the board



P121024 Q B TOUCH
 Digital keypad with 10 channels and 100 combinations. Backlit



D111881 00001 THALIA UL BOARD ONLY



KHLKIT HOMELINK KIT
 HomeLink Compatible receiver and transmitter for installing HomeLink with BFT Zara



I100054 10010 BAG OF 10 manual release keys



D111904 MITTO 2 TRANSMITTER:
 12V Two channel 433Mhz rolling code remote control




D111906 MITTO 4 TRANSMITTER
 Four channel Rolling code remote control



K THERMO24
 Thermostatically controlled 5W heating element for use to ambient temperatures of -40°C. Thermostat adjustable to activate from -10°C to 50°C, 7K switching differential, 35mm DIN rail mount.

AT A GLANCE QUICK REFERENCE

KUSTOS ULTRA BT Geometry




Programming

Quick Setup Menu: Press **OK** once



Main Programming Menu: Press **OK** twice RAPIDLY

(Parameters) PARAM	Sub-menu. All numerical value are set in this area (times, forces, & speeds).
LOGIC	Sub-menu. All features and functions are selected in this area.
RADIO	Sub-menu. Built-in receiver programming (remote controls and wireless devices).
DEFAULT	Restores all factory settings. Has no effect on RADIO programming.
LANGUAGE	Selection of menu language.
AUTOSET	Motor learn feature.
STAT	Provides firmware and memory information.
PASSWORD	Password setting for wireless programmer.



10 & 11	Motor 1 power output. Polarity reverses during close cycle
14 & 15	Motor 2 power output. Polarity reverses during close cycle
20 & 21	Dry contact for external lock. N.O. / N.C. selectable
26 & 27	Auxiliary dry contact. Programmable. Recv'r 2 nd channel default
28 & 29	UL alarm contact. N.O. Closes on double obstruction condition
40 - 45	Limit switches inputs.
50 & 51	Accessory power 24VDC
50 & 52	Switched accessory power 24VDC. Turns off when gate closes.
60 & 61	Input 1. Defaulted as OPEN command.
60 & 62	Input 2. Defaulted as CLOSE command.
70 & 71	STOP / RESET command input. N.C.
70 & 72	SAFE 1. Obstruction sensor input. Defaulted as Photo TEST Obstruction (Loop and/or Photo)
70 & 73	Circuit supervision for SAFE 1
70 & 74	SAFE 2. Obstruction sensor input. Defaulted as CONTACT (Safety edge) obstruction sensing
70 & 75	Circuit supervision for SAFE 2
76 & 77	SAFE 3. Obstruction sensor input. Defaulted as SHADOW sensor input
76 & 78	Circuit supervision for SAFE 3