


Silo MASSAGE CHAIR

OPERATION INSTRUCTIONS

SAVE THESE INSTRUCTIONS



Thank you for purchasing this product. Please read this manual instruction carefully in order to know how to use this product correctly before operation. Please pay more attention to some important safety warning and keep this manual book properly for future use.

Note: Our company reserves the right to change and explain the design of the product. If there is some difference between the product function in market circulation and the description in the manual, it is a normal update of the product, and our company will not inform you otherwise. The specific product function and color shall prevail in kind.

CONTENTS

Before Use

Safety Precautions ----- 02-04
Installation Parts ----- 05
Place Massage Chair ----- 06-07
Before Use ----- 08-09
Product Structure ----- 10-15

Usage Method

Operation Instructions ----- 16-22

Maintain



Cleaning and Maintenance ----- 23

Important

Troubleshooting ----- 24
Product Specifications ----- 25

Safety Precautions (must be observed)


- Please read all relevant instructions carefully before use.
- The notes marked here will help you to use the product safely and correctly.
- In order to clearly indicate the extent of harm and damage, precautions are divided into **"Warning"** and **"Caution"** that may be caused by incorrect use. Both of them are important for safety and must be followed.

 Warning	Indicates that serious injury or death may result from improper use.
 Caution	Indicates that misuse may cause minor injury or property damage.


- Please pay attention to the symbol before each safety item.


 Forbidden	Absolute prohibition
--	----------------------


The following populations should not use this product

 Forbidden	<ul style="list-style-type: none"> ■ The device is not intended for use by persons (including children) with physical disabilities, sensory or neurological impairments or who lack experience and common sense, unless they are supervised and instructed in the use of the device by those responsible for their safety. Children must be supervised to ensure they do not play with instruments. ■ Patients with osteoporosis. ■ Patients with heart disease or wearing electronic medical devices such as a pacemaker. ■ People who have a fever. ■ Pregnant women . ■ Patients who are injured or have a skin disease. ■ When unsupervised, any children are under the age of 14 and those unconscious are not allowed to use this product. ■ People who are told by their physicians to have rest or who feel unwell. ■ People whose bodies are wet are forbidden to use this product. ■ This product has a hot surface. Persons insensitive to heat must pay attention when using this product. ■ If the supply cord is damaged, to avoid danger, it must be replaced by a professional from the manufacturer, its maintenance department or similar department
---	---


Safety Precautions (must be observed)


Important safety warnings	
 Warnings	<ul style="list-style-type: none"> ■ Do not allow children to touch any movable part of this product. ■ Use the well-grounded power supply unit suitable for this product. ■ Pull out the plug after use or before cleaning to avoid any physical injury or damage to the product. ■ Operate this product as instructed in this manual. ■ Do not use any parts or accessories which are not recommended. ■ Do not use this product outdoors. ■ Please read the Operation Instructions carefully before operation. ■ Never use this product for any other purpose not listed herein. ■ 20 minutes of usage each time is recommended. ■ Do not use this product if the cover or leather is broken or damaged. ■ Do not drop anything into this product. ■ Never fall asleep while using this product. ■ Do not use this product if you are drunk or feel unwell. ■ Do not use this product within one hour after a meal. ■ Do not use this product with excessive force to avoid any injury.


Safety precautions	
 Caution	<ul style="list-style-type: none"> ■ Check whether voltage is consistent with the specification of this product. ■ Never insert or pull out the plug with a wet hand. ■ Do not let water flow into this product to avoid electric shock or cause damage to this product. ■ Do not pull the power cord when plugging or unplugging it. Rough handling is forbidden. ■ Do not damage the wire or modify the circuit of this product. ■ Do not clean live parts of this product with a wet cloth such as a power switch and plug. ■ Be away from this product in case of power failure to avoid any injury if power is restored suddenly. ■ Stop using this product at once while it works abnormal, and consult your local supplier. ■ Stop using this product if you feel unwell, and consult your health care practitioner.

Storage conditions	
 Caution	<ul style="list-style-type: none"> ■ Storage room temperature: 41°F to 104 °F. ■ Relative humidity (RH) between 20% and 80%; free of corrosive gases, and a well-ventilated room.

Safety Precautions must be observed

Product service and maintenance	
 Caution	<ul style="list-style-type: none">■ This product should be maintained by the service center designated by the manufacturer only. No user should disassemble or maintain it without permission.■ Do not forget to turn off the main power switch after usage.■ Do not use this product if the power socket becomes loose.■ If this product will be left unused for a long period of time, it is necessary to roll up the power cord of this product and store this product in a dry and dust-free environment.■ Do not store this product at a high temperature or near open flame. Avoid prolonged exposure to direct sunshine.■ Please clean this product with dry cloth. Never use thinner, benzene or alcohol.■ The mechanical components of this product are specially designed and manufactured, so no special maintenance is needed.■ Do not use a sharp object to stab at this product.■ Do not roll or pull this product on any uneven ground. Instead, it should be lifted before moving.■ Please use this product intermittently. Do not keep it working continuously for a long period of time.





Operating environment	
 Caution	<ul style="list-style-type: none">■ Do not use this product in a very moist environment such as the bathroom.■ Stop using this product immediately when the ambient temperature changes sharply.■ Do not use this product in any heavily-dusty or caustic environment.■ Do not use this product in a small space or a place without good ventilation.

Solutions to ordinary malfunctions	
 Caution	<ul style="list-style-type: none">■ If the motor sounds during operation of this product, this is the normal operation sound.■ If the controller cannot work normally, check whether the plug and the power socket are connected reliably, and whether the power switch is turned on.■ If the rated working time is over, this product will automatically activate the power-off button; If this product keeps operating for a long period of time, the temperature protector will stop this product automatically. The product can be used again after half an hour.

Installation parts

Calf installation instructions

1. Insert the wire of the calf and the air pipe into the front socket of the steel frame assembly (Figure 1).
2. Then push the connected wire and air pipe into the hole in the backrest frame (Figure 2).
3. After the wire docking is completed, open the calf fixing covers on both sides of the steel frame assembly (Figure 3).
4. Lift the calf into the notch, close the fixing covers, and secure it in place with 2 pieces screws (Figure 4).




Place massage chair

Installation placement

Make sure there is enough space for the massage chair can be tilted at least 11.8 inches.


Do not expose the massage chair directly to high temperature environment due to sunlight (such as: in front of heating equipment), and place it to where can avoid high temperature and direct sunlight. It is recommended to lay a soft cushion for long-term use in a designated location. When laying the cushion, the size of the cushion should be enough to cover the range where the machine touches the floor and the range where your feet touch the floor.



Product lift instruction

Require team work to lift and move the chair to avoid injury.

1. Please lift the massage chair to move it on vulnerable ground such as wooden floor.
2. When moving on a similar wooden floor, it is recommended to lift it. Avoid damage to the casters. When the floor is lifted and moved to the designated position, be careful to keep your hands out of the way to avoid injury, and be careful of your feet being crushed. Do not let go of the unit until the unit is completely flat, the floor may be damaged, therefore, it is recommended to place mats, etc. on the floor.




Place massage chair

Move method

Use the rear casters to move the massage chair. Move the chair by tilting it down and backward about 45° as shown in the diagram.




NOTE: Excessive force to title will cause the chair to tip over completely and product damage.

1. Before moving, please shut down the machine properly to reset the whole machine, and then cut off the power.
2. Please keep the chair vacant when moving. (People, pets or clutter will not be able to stay on the chair.)
3. When moving, do not cross a drop barrier higher than 2mm or a gap greater than 5mm.
4. When using casters to move this product, single continuous movement is not supported; if the distance exceeds 164ft, please make this product move slowly and evenly.



How to disassemble and use headrest cushion and backrest cushion


Using a headrest cushion can reduce the intensity of kneading massage on the neck and shoulders, and you can decide whether to use a headrest cushion according to your needs (recommended to use a headrest cushion). The backrest cushion and the backrest are connected by a zipper (1), and the headrest cushion and the backrest cushion are connected by a zipper (2).



Before use

Check around


Make sure that there are no people, pets and other objects around the unit.



CAUTION

Make sure there are no foreign objects in the gaps of the machine

Before massaging, make sure that no foreign objects are caught in the legs, feet, etc.
Under no circumstances allow hands, feet, and head to penetrate into the area between the lower leg mechanism and main body, or the area between the armrest and the capsule.
Under no circumstances should hands, feet, or head sink under the fabric or leather covering of the massage area.




CAUTION

Before Use


Turn on the power

Caution


Plug in power cord



Schematic diagram of power on



Turn on the power switch ("I" position)




Warn

- Please check whether the power cord and power plug are damaged before use.
- Please supply power to this product in accordance with the working power requirements of this product's calibration.
- It is strictly forbidden to use a power supply other than the nominal power supply of this product.
- It is strictly forbidden to connect various power conversion devices to supply power to this product without authorization.


Product Structure

Parts description




Product Structure

Function distribution



Product Structure

I .Introduction of the remote controller





Product Structure

- 1.Pause/run button
- Pause or run all massage functions.
- 2.Automatic button
- Please refer to page 14 of this manual.
- 3.Spot massage button
- Please refer to page 16 of this manual.
- 4.Shoulder position up button
- Manually adjust the shoulder position upwards.
- 5.Auto lying button
- There are three automatic lying modes and reset and standing modes, which can be switched cyclically according to your own needs.
- 6.Width adjustment button
- Adjustable in 3 modes: wide, medium and narrow.
- 7.Technique button
- Please refer to page 15 of this manual.
- 8.Linkage lift adjustment button
- Please refer to page 14 of this manual.
- 9.Switch power button
- Turn on or off all massage functions.
- 10.Lock button
- Please refer to page 16 of this manual.
- 11.Partial massage button
- Please refer to page 16 of this manual.
- 12.Shoulder position down button
- Manually adjust the shoulder position down.
- 13.Full body massage button
- Please refer to page 16 of this manual.
- 14.Air pressure adjustment button
- Adjust the strength/weakness of the pressure.
- 15.Speed adjustment button
- Adjust three speeds: slow, medium and fast.


Operation Instructions

II . Start massage




1. Press the power button to start the massage, the default is Comfort massage.
2. Automatic angle adjustment (you can press the "AUTO" button to skip).
3. Automatic human shoulder position detection, keep the sitting posture fit with the massage chair (you can press the "AUTO" button to skip).
4. Shoulder position fine-tuning, if the detected position deviates from the actual shoulder position, adjust it to the appropriate position through the up and down buttons of the shoulder position (you can press the "AUTO" button to skip), there are 11 shoulder positions in total. If there is no adjustment within 10 seconds, it will enter into the massage function.

Button	Description
	Move the massage balls upward to a suitable position
	Move the massage balls downward to a suitable position

• Automatic massage





Button	Auto program	Description	Display
	Comfort	The most comfortable massage experience.	<input checked="" type="radio"/> Comfort <input type="radio"/> Shoulder&neck <input type="radio"/> Back&Waist
	Back&waist	Focus on back and waist massage.	<input type="radio"/> Comfort <input checked="" type="radio"/> Shoulder&neck <input type="radio"/> Back&Waist
	Shoulder&neck	Focus on shoulder and neck massage.	<input type="radio"/> Comfort <input type="radio"/> Shoulder&neck <input checked="" type="radio"/> Back&Waist

• Adjust lying Angle


Button	Function	Description
	Sit up	Press this button, backrest frame slowly rise, calf frame slowly fall, and issued "di...di..."until it reached the top. Press this button again in the process of sitting, then stop sitting immediately.
	Lie down	Press this key, backrest frame slowly down, calf frame slowly up, and issued "di...di..."until it stops. Press this key again in lying down process, stop lying down immediately.
	Zero-G	Each time the button is pressed, it switches to an automatic lying mode, with a total of four modes (including the reset and standing mode), which can be switched cyclically.

Operation Instructions


• Manual massage

Button	Auto program	Description
	Knead	Speed.
	Tap	Speed, Width.
	Knead & tap	Speed.
	Shiatsu	Speed, Width.

• Width adjustment






Function	Button	Description	Gear	Display
Width adjustment		With 3 gears adjustment, narrow, medium, wider cyclic switching	Narrow	<input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>
			Medium	<input type="radio"/> <input checked="" type="radio"/> <input type="radio"/>
			Wide	<input type="radio"/> <input type="radio"/> <input checked="" type="radio"/>

• Speed adjustment


Function	Button	Description	Gear	Display
Speed adjustment		With 3 gears adjustment, 1,2,3 cyclic switching	1	<input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>
			2	<input type="radio"/> <input checked="" type="radio"/> <input type="radio"/>
			3	<input type="radio"/> <input type="radio"/> <input checked="" type="radio"/>

Operation Instructions


• Massage interval

Function	Button	Description	
Back stretch		Fixed position (fixed point) massage	
		Small range (local) round-trip massage	
		Full body (whole course) round-trip massage	
Position adjustment		Massage position adjustment (in spot and partial mode, the massage position can be adjusted)	Manipulator up
			Manipulator down

• Air pressure adjustment massage

Function	Button	Description	Gear	Display
Air intensity adjustment		With 3 gear adjustment and off gear, cyclic switching	1	● ○
			2	○ ●
			3	● ●
			OFF	○ ○


Other Manual function:

Function	Button	Description
Lock		Press and hold for 3 seconds, that lock is successful, and other keys can not be used after being locked; press and hold for 3 seconds in locked state, that unlock is successful and keys function returns to normal.


VI. End the massage

1. During the massage process, press the power off key on the controller, all massage functions immediately turn off, the backrest and leg rest will reset, or when the massage timer expires, it will automatically turn off all massage functions, but the backrest and leg rest will not reset.


2. Cut off the power of the whole machine. Figure (switch power off)



① Power off ("0" position)



② Take off the power plug



③ Take off the product power cord

Cleaning and Maintenance

Clean PVC leather and plastic parts

Wipe the leather with a soft, dry cloth.

■ Do not use chemicals such as thinner, gasoline, alcohol, etc. to clean the unit.

■ When using commercially available leather care products (rags), please follow the instructions for use.

■ If the PVC leather is particularly dirty, wipe it by the following methods.

① Immerse a soft cloth in water or hot water containing 3% to 5% neutral detergent, then wring it out thoroughly.

② Use the above soft cloth to wipe the leather surface.

③ Wipe off the cleaning solution with a cloth soaked in clean water and thoroughly wrung out.

④ Wipe with a wrung soft cloth.

⑤ Let it air dry naturally.

■ When it is difficult to remove stains, please immerse commercially available melamine foam in neutral detergent, and then wipe the machine with it.

■ Do not use a hair dryer to dry the surface.

■ As the color of the fabric will stain the surface of the PVC leather, be careful when wiping the chair with denim and colored fabrics.

■ Do not keep these parts in contact with plastic for a long time, as this will cause discoloration.

■ PVC leather may be discolored, so when using hair dye, please cover the touched part with a towel.



Trouble shooting

Fault	When the calf mechanism or the backrest reaches a certain position, press the corresponding adjustment button and it will no longer change, and a continuous "beep, beep" sound will be emitted.
Solution	Due to product structure design and ergonomic requirements, this product has a limited protection design for the limit state of attitude adjustment. At the same time, a reminder sound will sound when the limit is reached.
Fault	The function does not work or some functions do not work after the machine is turned on.
Solution	After the machine is turned on by pressing the switch key, it is necessary to manually select an automatic massage program or other working state. If it is not operated, the machine will automatically shut down after 20 minutes. If the manual operation mode is selected, the functions that are not selected may be disabled, and the working mode needs to be manually set in the manual mode.
Fault	The machine makes a leather rubbing sound when adjusting its posture.
Solution	This product adopts high-grade anti-corrosion leather that meets environmental protection requirements. Due to the inherent characteristics of leather materials, there will be a normal slight noise when rubbing at the relative movement, which is a normal phenomenon. Note: If you hear fabric or leather tearing sound when the machine is running, please stop using it immediately and seek professional maintenance.
Fault	The massage wheel did not reach the shoulders or neck.
Solution	If the head does not touch the head cushion or the back does not touch the backrest, the shoulder position may be lower than the actual position during the body shape detection process. Sit in the deepest position of the seat, rest your head on the headrest, and start over from the beginning.
Fault	The unit is damaged. The power cord or power plug is abnormally hot.
Solution	To prevent accidents, be sure to contact an authorized service center.

Please feel free to contact the designated service personnel for any questions or doubts about this product.

Product Specifications

Model: Silo
 Name: Massage Chair
 Rated voltage: 110-120V~ 60Hz
 220-240V~ 50Hz/60Hz
 Rated power: 70W
 Rated time: 20min
 Safety structure: Class I

Material description: PVC, PA, steel parts, electric and electron components

MATERIAL	PU	LEATHER	CLOTH	WOOD