

Remote Control User Guide

WholeBody® 8.0

RESTORE/PARK – Press and hold to stop the massage, restore the chair to the upright position with the footrest lowered, and park the massage rollers at the top of the backrest.

WIDTH – Adjust the massage width as desired. This feature works with Flex and Glide massage targeted benefits.

POSITION – Press and hold to position any stationary massage technique just where you need it. You can press this button before or after selecting the massage technique.

TARGETED BENEFITS – Toggles among three stationary massage techniques, each designed to provide unique muscle benefits. Use with the glide function for a partial- or full-back massage.

POWER RECLINE – Press and hold to recline/incline the backrest.

BACK WARM AIR – Activates the warm air lumbar heat.

STOP – Stops the massage.

RANGE – Customizes your vertical massage range.

FULL
PARTIAL

AUTO MASSAGE PROGRAMS – Seven unique programs automatically massage you for 15 minutes each, using a variety of massage techniques.

INTENSITY 3D – Sets the upper and lower back 3D massage intensity independently to soft (I), medium (II), or intense (III).

POWER FOOTREST ANGLE – Controls the footrest angle for recline comfort and massage.

BODYMAP® PRO – Push the button that corresponds to the area you want to feel better, and let the massage chair do the rest!

FOOT/CALF – Toggles through two fixed speeds and an auto massage program.

restore/park stop
width range
position glide
massage auto massage
stretch flex tone soothe refresh full upper lower relax sleep
intensity 3D
shoulders low back
back legs
bodymap PRO
back warm air foot / calf massage
high low auto
3D FlexGlide™ massage
human touch®

For more detailed operation instructions, please see the Use and Care Manual.