

QUICKSTART GUIDE


Model : C00 | V1.0





Basic








Main Menu



Laser Measure





Tech Specs

Battery	900mAh, input:5V-1A
Materials	ABS Plastic, PC Plastic
Display	1.89" IPS LCD Display with Tempered Glass
Resolution	240ppi
Accuracy	± 1/16in (± 2mm)* In Ideal Circumstances
Range	164ft (50m)
APP	Bluetooth Connection With MEAZOR APP

MEAZOR APP



ONLINE USER INSTRUCTIONS

Access to detailed multilingual instruction manuals, FAQ & Instruction video in:
English | Chinese | Japanese | German | Spanish | Italian | French



Copyright

The above product specifications are subject to change without notice. All rights of interpretation are reserved by HOZO DESIGN CO. All trademarks, images, technical data, and intellectual property rights are the properties of HOZO DESIGN CO., Limited and are subject to copyright infringement.



Warrenty

Warranty period

HOZO Design. CO. - One-year Limited Consumer Warranty covers your product against manufacturing defects for one year from the date you bought your product.

How to send it for repair

If the product needs to be repaired, please contact the distributor and send the product accordingly, and provide a valid **batch number** with proof of purchase.



batch number

Support Email: customersupport@hozodesign.com
Online Form: hozodesign.com/pages/support-center

Special cases

The following cases are not covered by the warranty policy during the warranty period and will be repaired at extra cost.

- 1) Damage caused by improper use, maintenance, or storage by the user.
- 2) Dismantling of parts under unauthorized circumstances.
- 3) No proof of purchase.
- 4) The serial number does not correspond to the product sent for repair or has been altered
- 5) Damage to the body caused by force majeure
- 6) Normal wear and tear of the parts, which need to be replaced
- 7) Damage caused by abnormalities in the temperature/humidity of use or storage
- 8) Damage to the battery caused by not charging in accordance with the instructions
- 9) Any damage caused by not following the instructions.

Basic

Rear Measuring Button

Trigger Auto-Align from the position of the Rear Button

Locking Buckle

Press buckles on both sides to unlock the module

Drawing Mode Switch



Allows the Joystick to draw lines in any direction

Limits the Joystick to draw lines at 90/45 degrees

2×AA Battery Console

Front Measuring Button

Drawing Joystick

Undo Button

* Long Press to clear the drawing board

Battery life Indicator

Indicates the battery life of 2xAA Batteries, not for the battery in the main module.

Tech Specs

Auto Leveling

Current Measurement

Swipe to Enter Drawing Panel

Send Drawing to App

Auto Align

*Tap to switch to manual alignment

Measurement Display

Blue: Current measuring data

Orange: Locked data

Drawing Contour

Drawing Direction

Swipe to enter Control Panel

Battery Adapt with 2×AA Batteries (Not Included)

Power Input: 5V--1A, Output:5V--1A

Materials ABS Plastic, PC Plastic, Aluminum Alloy

Joystick 360 deg with 1deg resolution


QUICKSTART GUIDE

Model : C-M01 | V1.0



Smart Room

Point the laser at a wall to measure it. Then, use the joystick to pick the wall's direction. Do this for each wall to measure the whole room.



1) Measure a Wall

Place the product at the starting point (1), aim it towards the endpoint (2), and press the Measure button to lock the distance. Then, press the Measure button again to draw the first line on the drawing panel.



2) Choose Direction for the Next Wall

Use the joystick to point in the direction of the next wall. Repeat the measuring process to draw walls 2, 3, 4, and 5 in order. Make sure each new wall is next to the previous one.



Auto-Leveling

This feature calculates the horizontal distance between walls, minimizing potential errors during measurement. Example: When measuring wall AB with an obstruction at point B, measure to point B' instead. The device will then calculate the actual horizontal length of AB.




Auto-Leveling unavailable

Auto-leveling may be disabled if the device is excessively tilted (beyond 30°).



Auto-Leveling Off

The auto-leveling feature can be manually turned off as per user preference.



Auto Alignment

The device automatically selects the starting point based on how the measuring is triggered.


Front button Trigger

Activating the front measuring button aligns the device from the bottom of the module.



Rear button Trigger


Using the rear measuring button aligns the device from the gap between the main unit and the module.




Contour Enclosure

Connect the starting point of the first wall to the endpoint of the last wall. This creates a closed contour, which can be sent to the app for easier area calculation.

Contour Enclosure OFF



Contour Enclosure ON





Basic

Locking Buckle

* Press buckles on both side to unlock module

Cross Laser ON/OFF

Back/Clear Button

Receiver Lens

Physical Bubble Level

Laser Emitter Lens

Cross Laser Line Emitter

QUICKSTART GUIDE

Model : C-M03 | V1.0

Tech Spec

Power	input:5V-1A
Materials	ABS Plastic, PC Plastic, Aluminum Alloy
Accuracy	±1/8in (± 3mm)* In Ideal Circumstances
Range	Max 330ft(100m) with dual side
Cross Laser	520nm(Green Beam) 90° expanded angle





Bilateral Laser Measuring

Enables measurement from both ends of the device to swiftly determine the distance between two walls.




1) Dual Align

Engage the laser from both ends of the device for measurement



2) Tripod Align

Utilize the device's tripod hole for aligned measurements.



Auto-Leveling

The product automatically calculates the horizontal distance between walls, reducing the likelihood of measurement errors.

Front Laser Measurement

Rear Laser Measurement

Auto Leveling Status

Tilting Angle

Total Measurement



Auto-Leveling ON

When measuring wall AB, if you measure line a'b', the device will automatically calculate the horizontal length of AB.




Auto-Leveling unavailable

Auto-leveling becomes inactive if the device is tilted at a large angle (exceeding 30°).



Auto-Leveling Off

The Auto-Leveling feature can be manually deactivated as needed.



Cross-Laser Leveling

Press the Green Cross button located on the side of the module to activate the cross-line feature.

Adjusting for Level

Rotate and lock the tripod's ball head until both axes indicate 0 degrees, ensuring proper leveling.

Cross Level ON/OFF



QUICKSTART GUIDE

Model : C-M05 | V1.0



Basic

- Locking Buckle**
* Press buckles on both side to unlock module
- Laser Measure ON/OFF**
- Back/Clear Button**
- Rolling Ruler ON/OFF**
Tap or hold the button to start measuring.
Tap again or release to stop measuring.
- Cross Laser Line Emitter**

Tech Spec

- Power** input:5V-1A
- Materials** ABS Plastic, PC Plastic, Aluminum Alloy
- Accuracy** ±1/32in (± 1mm)* or ±0.2% In Ideal Circumstances
- Range** Max 330ft(100m) with 0.5mm resolution
- Cross Laser** 635nm(Red Beam)
- Scales** 93 built-in scales in 8 modes +Customized Scales



41 Built-in Metric Scales			
Arch	ENG I	ENG II	MAP
	√1		
√2	√25	√1000	√100k
√3	√50	√250	√25k
√4	√200	√500	√200k
√5	√250	√625	√250k
√10	√300	√2000	√500k
√20	√400	√2500	√1000k
√25	√500	√5000	√2000k
√30		√6000	√2500k
√40		√10k	
√50		√12.5k	
√72		√20k	
√75		√25k	
√100		√50k	

Rolling Ruler

Roll the ruler across the object's edge while using the laser line for guidance. Utilize the perpendicular laser line to determine the start/end points.

Point-to-Point Align

Measure from the start to the end point, both centered on the rolling wheel.

Point-to-Side Align


Start measuring from the center of the rolling wheel, ending with the left side of the device. An additional width of 1.69 inches (43 mm) will be included in the measurement.

Scale Ruler

Choose from 93 standard scales. Use the rolling ruler to measure along a line on a printed scaled drawing, aided by the laser line.

Customized Scale Ruler

For Drawings with Non-Standard Scales Use this feature when drawings are off-scale or in non-standard scales. The device will calculate the measuring scales based on inputted lengths.



Sending Measurements to the App

Select Scale



Press Measure button to confirm scale

Switching Scale Modes
Swipe left or right to toggle between Metric and Imperial modes.



Step 1: Measuring Drawing Length

Measure the length on the drawing using the rolling ruler or input the length manually via the keypad.



Select either the rolling ruler or keypad for inputting the length.



Step 2: Measuring Actual Length

Measure the actual length of the object corresponding to the drawing using the laser measure or input the length manually via the keypad.



Choose either the laser measure or keypad for inputting the length.

52 Built-in US Standard Scales

Arch	ENG I	ENG II	MAP
1" = 1"			
6" = 1"	1" = 10'	1" = 300'	1" = 1Mi
4" = 1"	1" = 20'	1" = 333'	1" = 15 Mi
3" = 1"	1" = 30'	1" = 46.6'	1" = 2 Mi
2" = 1"	1" = 40'	1" = 500'	1" = 3 Mi
1 1/2" = 1"	1" = 50'	1" = 583.3'	1" = 4 Mi
1" = 1"	1" = 60'	1" = 600'	1" = 5 Mi
3/4" = 1"	1" = 70'	1" = 625'	1" = 6 Mi
1/2" = 1"	1" = 80'	1" = 666'	1" = 10 Mi
3/8" = 1"	1" = 83.3'	1" = 750'	1" = 20 Mi
1/4" = 1"	1" = 90'	1" = 1000'	1" = 24 Mi
3/16" = 1"	1" = 100'	1" = 1200'	1" = 25 Mi
1/8" = 1"	1" = 166.6'	1" = 2000'	
3/32" = 1"	1" = 200'	1" = 3000'	
1/16" = 1"	1" = 250'		

Smart Planner

Get smarter on floorplanning



Flexibility to adapt

To capture floorplan with any angle and any structure.



8 Directions & 360°

One-Tap Button



Bilateral Laser +

Fastest Results + Versatile Demands



Bilateral Laser

Bilateral Laser

328 ft
100M

Precision

$\pm 1/8$ in
 ± 3 mm

Advanced Auto-Calibration



Scale Roller

From curves to lines, measure on any scale



Object Measurement



Clear to See



93 Built-in scales



Customized scales



Object measurement



M-Green Line



Precision with Cross-line Projection

