

MAG



ALIA TECHNOLOGY LLC

Electromagnetic Flowmeter

Operation Manual

AMC2100 Series



CE

Index

1. Sensor -----	2
1.1 AMF900 Flange Type-----	2
1.2 AMF500 Wafer Type-----	3
1.3 AMF301 Installation -----	3
1.4 AMF500 Installation -----	3
1.5 AMF601 Installation -----	4
1.6 AMF900 Installation -----	4
2. Installation-----	5
2.1 Install position-----	5
2.2 Remove the interference of magnetic field -----	5
2.3 Straight tube length-----	5
2.4 Install method-----	5
3. Converter AMC2100 Operate Manual -----	7
3.1 Converter AMC2100 Operate Manual-----	7
3.1.1 Power and signal output connected line(compact and separate model) -----	7
3.1.2 Separate Wiring -----	8
3.1.3 AMC2100 Panel deploy -----	8
3.2 Survey mode setting -----	9
3.3 Example-----	9
3.4 Totalizer Reset -----	9
3.5 Auto zero Adjustment -----	10
3.6 Check for power off message-----	10
3.7 Operate flow chart -----	11
3.8 User operate description-----	12
3.9 System Mode -----	17
3.10 Advance Mode -----	19
3.11 Points Reviseion-----	21
3.12 Batch Control-----	23
4. Common Alarm Code Indication -----	25

1. Sensor

EM Flowmeter composed by sensor and Converter, be compact version or separate version, there are several specification of sensor as follow:

1.1 AMF900 Flange Type

Size: 10Amm ~ 2000mm (3/8A" ~ 80")

Liner : Neoprene

Polyurethane

FEP


PTFE

PFA

Protection : IP68

Max.Temp.:180 Deg. C

Installation : Flange End



Size (mm)	Standard Pressure Kg/cm ²	Liner Material				Dimensions (mm)			Weight Kg
		FEP / PFA	Neoprene	Polyurethane	PTFE	L	D	H	
10A	40	⊙			⊙	120	90	145	3.5
10		⊙			⊙	120			3.5
15		⊙			⊙	150	95	155	3.5
20		⊙			⊙		105	160	4.5
25		⊙		⊙	⊙		115	166	4.5
32		⊙		⊙	⊙		140	180	6.5
40		⊙		⊙	⊙	150	190	7.0	
50		⊙	⊙	⊙	⊙	200	165	201	9.5
65		⊙	⊙	⊙	⊙		185	220	12
80		⊙	⊙	⊙	⊙		200	235	15
100	16	⊙	⊙	⊙	250	220	254	17	
125		⊙	⊙	⊙		⊙	250	284	21
150		⊙	⊙	⊙	⊙	300	285	314	28
200	10	⊙	⊙	⊙	450	350	340	369	36
250		⊙	⊙	⊙		⊙	400	395	430
300		⊙	⊙	⊙	⊙	600	445	480	61
350			⊙	⊙	⊙		505	540	79
400			⊙	⊙	⊙		500	565	600
450			⊙		⊙	700	615	640	121
500			⊙		⊙		670	700	143
600			⊙		⊙		780	800	187
700			⊙		⊙		895	910	260
800			⊙		⊙	800	1015	1020	342
900		⊙		⊙	900	1115	1120	420	
1000		⊙		⊙	1000	1230	1230	503	
1200	6		⊙		⊙	1200	1405	1405	666
1400			⊙		⊙	1400	1630	1630	1036
1600			⊙		⊙	1600	1830	1830	1333
1800			⊙		⊙	1800	2045	2045	1720
2000			⊙		⊙	2000	2265	2265	2190

1.2 AMF500 Wafer Type


Size: 25mm ~ 200mm (1" ~ 8")

Liner: FEP/PTFE

Protection: IP68


Max.Temp.: 180 Deg. C

Installation: Wafer




Size		Dimensions (mm)		
mm	Inch	L	D	H
25	1"	90	71	138
32	1-1/4"	100	80	147
40	1-1/2"		86	153
50	2"	115	100	167
65	2-1/2"	115	120	187
80	3"	130	131	198
100	4"	155	151	218
125	5"	155	181	248
150	6"	185	206	273
200	8"	215	261	328


1.3 AMF301 Installation




1.4 AMF500 Installation



1.5 AMF601 Installation



1.6 AMF900 Installation



Installation Note:

- 1) The pipe flange should be welded well before installing flowmeter. It's not allowed to weld flange after flowmeter is installed. And welding part of pipe flange should be flat, having no sharp residue. Otherwise liner will be damaged. After flowmeter is installed, if other places in pipe needs to be welded, flowmeter's power must be shut down.
- 2) Usually there will be weld residues in newly installed pipe. Before installing the sensor, those residues should be cleaned off so as to avoid liner damage
- 3) If pipe is not alligned well or sloped, there will be leakage problem or liner damage.

2. Installation

When you design the tube, please consider following items:

2.1 Install position


Please avoid the sunlight when you install the flowmeter, the ambient temperature between -25~60 Deg.C will be great.

2.2 Remove the interference of magnetic field

Please DO NOT install flowmeter near motor-driven machine, transformer, frequency transformer etc. for it will cause interference of magnetic field..

2.3 Straight tube length

In order to guarantee the EM Flowmeter accuracy, upstream and downstream of the installation should satisfied the following conditions(Picture).




When the upside and downside is shrink tube, the degree θ should be smaller than 15°


Generally tube installation, the flowmeter Upstream could try to stay 5D-10D ,Downstream 2D-5D.

2.4 Install method

- Flowmeter can be horizontal, vertical or slanting, please make sure the tube is full of fluid no matter if it is moving or not.
- When fluid contained solid material, It's suggested to try vertical installation(bottom to top), which can avoid the solid material sink inside the tube.




- Pipe design should make sure no air bubble in the flowmeter position.



d. Electrode position should parallel with ground

EM Flowmeter installed by horizontal or slanting the electrode position(A.B) should match the 2 side(right/left)of tube, converter(wiring box)should be top of the tube.




Horizontal install, the electrode position A.B should on the right and left side.


e. Transportation

When you moving, please remember DO NOT use rope through the flowmeter tube, it may cause Liner inside broken.


Please DO NOT use your hand or rope to hang on Converter or wiring box, if Flowmeter size is bigger than 80mm, because the material of converter and wiring box is tender aluminum, it can't stand huge weight.



f. Grounding measure



General metal tube




Non-metal tube (plastic tube Liner)

3. Converter AMC2100 Operate Manual

3.1 Converter AMC2100 Operate Manual

3.1.1 Power and signal output connected line(compact and separate model)




Open the 4 screws of the converter, and you can see terminal, decide if you need to connect according to your needs.




1. 4~20mA output+
2. 4~20mA output-
3. Pulse output+
4. Pulse output-
5. RS485 output+
6. RS485 output-

Cable from sensor


Power supply
90~260V AC
50/60Hz
or
24VDC

 <p>Output a load: 600Ω</p>	 <p>Max. Outer Voltage: 30VDC</p>	 <p>Modbus protocol</p>
<p>4~20mA Output (Hart protocol)</p>	<p>1.Pulse (Frequency)Output 2.Batch Control</p>	<p>RS485 Output</p>

3.1.2 Separate Wiring



3.1.3 AMC2100 Panel deploy



Key Name	Button Sign	Normal status function	Parameter setting status function
Setting	ENT	Login parameter setting level	Save presently settled parameter. Jump to next parameter setting
Up	^	Selected one of 4 display line	Change present digit, dot and survey unit. Up/Down movement
Right	>	Change the selected line on the display	Move



3.2 Survey mode setting

Flowmeter will enter to normal mode when electrified, every line has several choice as follow:


Position	Display	Unit sign	Unit	Description
Line 1	Totalizer	Σ	L, M3, G , kg, T,ml	Σ = Σ+ (-) Σ-
	Totalizer+	Σ+		
	Totalizer-	Σ-		
Line 2	Velocity		m/s	When reverse flow, it will show"- "
	Flowrate		m3/h	When reverse flow, it will show"- "
	% of Full Scale		%FS	Actual flowrate should match flowrate%
	mA output value		mA	Actual mA output Value
	Frequency		Hz	Full scale output : 5000Hz

3.3 Example


If you need Line 1 display from m3/h turn to %



In normal display press button until Line 2 is selected.




Press button to change m3/h to %FS




When alarm select" batch control",It will display"


3.4 Totalizer Reset



In general display, Press or button and select ,make sure enter zero window



Zero window.
Σ current totalizer value Σ1 last totalizer value Σ2 the time before last time totalizer value
Please selected CLR and press enter,doing the zero operation



Select YES for making zero operation and press to confirm

3.5 Auto zero Adjustment

When the tube are full pipe, and no flow, flowmeter still show the flowrate, then you could use Auto Zero adjustment to adjust your flowmeter to Zero, the method as follow:

Σ 123.456 m3
+0.1234m3/h
Ⓜ Ⓟ Ⓢ Ⓣ

In the normal display, press **ENT** button for 5 seconds, then it will go to next setting

ENT
OPERATIONS
SET **ZERO** ESC

In this setting, Press **▷** or **◁** button till you selected ZERO and press **ENT** to confirm

ENT
ZERO
NO **YES**

Select YES, and press **ENT** to confirm .

ENT
Zero Trimming ...

Zero Adjustment.

ENT
Zero Trim End
-2.624mv
Zero Esc

Zero Adjustment end. Select ESC, press **ENT** to turn back to the operations select (If you want to do Zero Adjustment again, Pls select ZERO)

ENT
OPERATIONS
SET ZERO **ESC**

Select ESC, press **ENT** to confirm and turn back to the normal display

ENT
Σ 123.456 m3
+0.0000m3/h
Ⓜ Ⓟ Ⓢ Ⓣ

the normal display

3.6 Check for power off message


Σ 123.456 m3
+0.0000m3/h
Ⓜ Ⓟ Ⓢ Ⓣ


In general display, Press **▷** or **◁** button to select **Ⓢ** , Press ENT to confirm, then check for the power off message window

ENT
ON 2008/04/23
13:30:55
OFF 2008/04/23
13:30:55
Q: 1.0234 m3/h
Σ: 4.123 m3
01 PgUP PgDN ESC


Power off message window
ON: date & time when power on OFF: date & time when power off
Q: the flowrate when power off Σ: the totalizer when power off
Example: 01 means the power off recorded series No.(It could record 99 times of power off)
Press PgUP or PgDN check the history record of power off.
Ps: Press PgDN till the last page, OFF option means current date, time, and flowrate.

3.7 Operate flow chart





3.8 User operate description



Pulse Level
Active L
Active H

ENT

Low Cutoff (%fs)
0.0

ENT

Damping (s)
01

ENT

Hydro – State
Normal Waved

ENT

Max Limit (%fs)
05

ENT

Limit Time (s)
05

ENT

Direction
Fwd. Rev. Bid.

ENT

Indication
Forward Reverse

ENT

Empty Detect
NO YES

ENT

Empty Limit (%)
50

ENT

Pulse Level
Press or to selected Pulse Level

Function for cutoff the low flowrate
Press button to move, press button to change the Value
Setting Range: 0.0% ~ 9.9%

The flowrate response time setting,
Press button to move, Press button the Value
Setting Range:01 ~ 99 Seconds, Factory Standard set value is 2 Seconds

Hydro-State
Press or button to selected the Hydro-State
Normal: for general application
Waved: For fluid in wave states

Response speed adjustment
Press button to move, Press button to change the value
Range: 00~30%, 1% means max 1% flowrate value change for each Limit Time

Response time
Press button to move, Press to change the value
Response time range: 00~99, Adjust flowmeter response time.

Direction
Press or button to select the Hydro-state
1. Forward 2. Reverse 3. Bidirection

Indication
Press or button to select the Indication
1. Forward 2. Reverse

Empty pipe detect
Press or button to select if it needs empty pipe detect

Empty pipe detect the value
Press button to move, Press to change the value

Comm
 OFF ON

Communication
 Press or button to select if need to use communication function

ENT

HART Address
 00

Please read page 17

MODBUS Type
 RTU ASCII

MODBUS Mode
 Press or button to select MODBUS mode

ENT

Baudrate
 1200 2400
 4800 9600
 19200 38400

RS485 Speed
 Press or button to select communication speed.

ENT

Data Bit
 7 8

Data Bit
 Press or button to select the Data Bit
 1. 7 2. 8 (When MODBUS model selects RTU, the Data Bit is 8 which is fixed)

ENT

Parity
 NONE ODD EVEN

Parity Type
 Press or button to select the parity type
 1. None 2. Odd 3. Even

ENT

Stop Bit
 1 2

Stop Bit
 Press or button to select the Stop Bit
 1. 1 2. 2

ENT

MODBUS Address
 01

MODBUS address
 Press button to move, Press button to change the digit

ENT

DATE (yy-mm-dd)
 8-01-10

Date Setting
 Press button to move, Press button to change the digit.

ENT

TIME (hh:mm:ss)
 7:09:49

Time Setting
 Press button to move, Press button to change the digit.
Pls press button for 5 seconds, then it will go back to the normal display.

HART operate description

HART Address
00

ENT

DATE (yy-mm-dd)
08-01-10

ENT

TIME (hh:mm:ss)
17:09:49

HART Address
Press or button to select HART Address

Date Setting
Press button to move, Press button to change the digit.

Time Setting
Press button to move, Press button to change the digit.
Pls press button for 5 seconds, then it will go back to the normal display.

3.9 System Mode

OPERATIONS
SET ZERO ESC

In the normal display, press **ENT** button for 5 seconds, then it will go to next setting
 In this setting, Press **▷** or **◁** button till you selected SET

ENT
 Password
 1111

Password login window
 Input the system password:
 Password: 1111

ENT
 Sensor NO.
 A7082106

Sensor No.
 Press **▷** button to move, Press **◁** button to change the digit.

ENT
 Size (mm)
 0065

Diameter
 Press **▷** button to move, Press **◁** button to change the diameter

ENT
 Sensor Factor
 0.94100

Sensor Factor KS
 KS is the original factory rectified factor, please don't change it unless professional or technical staff Press **▷** button to move, Press **◁** button to change the value

ENT
 Revise
 NO YES

Revise
 If choose YES, 11 points liner revision will be started, please see page 22-23 for details.
 Choose **NO** jump to Output Calibration.

ENT
 Output Check
 NO YES

Output Calibration
 Press **▷** or **◁** button to choose **YES** select if needs calibration
 Choose **NO** jump to Empty Tube Trim

ENT
 Loop Test
 4 8 12
 16 20

4-20 mA simulated output
 Press **▷** or **◁** button to select the simulated output value
 4 . 8 . 12 . 16 . 20


ENT
 Pulse Test
 1 10 100
 1000 2000 5000

Pulse Simulated output
 Press **▷** or **◁** button to select the calibration type
 1 . 10 . 100 . 1000 . 2000 . 5000

ENT
 Coil Test
 ON X→Y Y→X

Excit voltage calibration
 Check the coil X to Y or Y to X excit signal are correct or have fail
 Press **▷** or **◁** button to select the calibration type
 Choose X->Y, the Voltage will be 24VDC, Choose Y->X, then Y to X will be 24 VDC

ENT



Empty Tube Trim
 Press or to choose whether to Empty Tube Trim or not, or input empty tube frequency value. Choose NO to skip to Full Tube Trim, choose YES to conduct Empty Tube Trim. If there is empty tube empirical value, you can choose Keyin to modify empty tube frequency value. Otherwise it is not recommended to modify empty tube frequency value.

Full Tube Trim
 Press or to choose whether to Full Tube Trim or not, or input full tube frequency value. Choose NO to skip to Restore Factory Settings, choose YES to conduct Full Tube Trim. If there is full tube empirical value, you can choose Keyin to modify full tube frequency value. Otherwise it is not recommended to modify full tube frequency value.

Restore the parameter to second memory
 Press or button to select if it needs to restore the factory setting
Pls press button for 5 seconds, then it will go back to the normal display.

3.10 Advance Mode

OPERATIONS
SET ZERO ESC

In the normal display, press **ENT** button for 5 seconds, then it will go to next setting
 In this setting, Press **▶** or **◀** button till you selected SET

ENT
 Password

Password login window
 Input the system password:
 Password: *****

ENT
 Sensor NO.
 A7082106

Sensor No.
 Press **▶** button to move, Press **◀** button to change the value

ENT
 Size (mm)
 0065

Diameter
 Press **▶** button to move, Press **◀** button to change the diameter

ENT
 Sensor Factor
 00.94100

Sensor Factor KS
 KS is the original factory rectified factor, please don't change it unless professional or technical staff
 Press **▶** button to move, Press **◀** button to change the value

ENT
 Revise
NO YES

Revise
 If choose YES, 11 points liner revision will be started, please see page 22-23 for details.
 Choose **NO** jump to Output Calibration

ENT
 Output Check
 NO **YES**

Output Calibration
 Press **▶** or **◀** button to choose **YES** select if needs calibration
 Choose **NO** jump to Empty Tube Trim

ENT
 Loop Test
4 8 12
 16 20

4-20 mA simulated output
 Press **▶** or **◀** button to select the calibration type
 4 . 8 . 12 . 16 . 20


ENT
 Pulse Test
 1 10 100
 1000 **2000** 5000

Pulse Simulated output
 Press **▶** or **◀** button to select the calibration type
 1 . 10 . 100 . 1000 . 2000 . 5000

ENT
 Coil Test
ON X→Y Y→X

Excit voltage calibration
 Check the coil X to Y or Y to X excit signal are correct or have fail
 Press **▶** or **◀** button to select the calibration type
 Choose X->Y, the Voltage will be 24VDC, Choose Y->X, then Y to X will be 24 VDC

ENT



Empty Tube Trim
 Press or to choose whether to Empty Tube Trim or not, or input empty tube frequency value. Choose NO to skip to Full Tube Trim, choose YES to conduct Empty Tube Trim. If there is empty tube empirical value, you can choose Keyin to modify empty tube frequency value. Otherwise it is not recommended to modify empty tube frequency value.

Full Tube Trim
 Press or to choose whether to Full Tube Trim or not, or input full tube frequency value. Choose NO to skip to Restore Factory Settings, choose YES to conduct Full Tube Trim. If there is full tube empirical value, you can choose Keyin to modify full tube frequency value. Otherwise it is not recommended to modify full tube frequency value.

Restore the parameter to second memory
 Press or button to select if it needs to restore the factory setting

Converter No.
 Press button to move, Press button to change the value

Converter Factor KC
 Press button to move, Press button to change the value

Coil Current IC(A)
 Ic is the tested current of the converter when out of factory, please don't change it unless agent or professional technical staff.
 Press button to move, Press button to change the value


Coil Frequency (Hz)
 Press or button to select the coil frequency
 Original setting Value: 6.25

Zero Factor manual setting
 Press button to move, Press to change the value

4mA output calibration
 Press button to move, Press to change the Value

20mA output calibration
 Press button to move, Press to change the value
Pls press button for 5 seconds, then it will go back to the normal display.

3.11 Points Revision



Revise
Flow accuracy curve correct Factor,11 points
Choose **YES** and shift to 11points revision.

Revise
Flow accuracy curve correctFactor,11 points
Speed_1 ~ Speed_11 presents the flow velocity, you can set 11 point single flow velocity
Revise_1 ~ Revise_11 separately to corresponding Speed_1 ~ Speed_11, it use on amend the inaccuracy by the flow velocity amend.
Use button to move, button to change the value, Any related setting sample please see below.
ps: normally flowmeter accuracy it's during standard accuracy, only if it's necessary, please do not adjust any accuracy curve or you can ask Alia professional engineer to adjust with you

Example 1: size :50 mm(2"), Calibration flowrate are:0.5 M3/Hr, 1 M3/hr, 2 M3/Hr, 4 M3/hr, totally 4 points, first calibration result as follow:

	Measure point 1	Measure point 2	Measure point 3	Measure point 4
Actual flowrate	0.5 m3/h	1 m3/h	2 m3/h	4 m3/h
Actual Velocity	0.071 m/s	0.142 m/s	0.283 m/s	0.566 m/s
Flowmeter flowrate	0.530 m3/h	0.983 m3/h	2.046 m3/h	4.176 m3/h
Flowmeter Velocity	0.075 m/s	0.139 m/s	0.289 m/s	0.591 m/s


4point flowrate, its inaccuracy calculation as follow:
Point 1: $0.5 / 0.530 = 0.943$, new Revise valve = 0.943
Point 2: $1 / 0.983 = 1.017$, new Revise valve= 1.017
Point 3: $2 / 2.046 = 0.978$, new Revise valve= 0.978
Point 4: $4 / 4.176 = 0.958$, new Revise valve= 0.958

Filled the 4 points Revise valve in order to the new flow Velocity adjust parameter as follow:

	1	2	3	4
Speed	0.071	0.142	0.283	0.566
Revise	0.943	1.017	0.978	0.958

You will get the digit :
Speed_1= 0.071, Revise_1=0.943, Speed_2=0.142, Revise_2=1.017
Speed_3= 0.283, Revise_3=0.978, Speed_2=0.566, Revise_4 =0.958

Separately filled the converter related parameter,then the adjustment finished, that times Revise_5, Revise_6, Revise_7, Revise_8, Revise_9, Revise_10, Revise_11, Speed_5, speed_6, Speed_7, speed_8, Speed_9, speed_10 speed_11 doesn't need to change



Example 2: Size :500 mm (20"), Calibration one point flowrate to 4000 m³/h
 Supposed the actual flowrate was 4000 m³/h, the actual speed was 5.66 m/s, display
 4012 m³/h, Velocity 5.677 m/s.
 New Revise=4000/4012=0.997
 Flow Velocity 5.66 m/s during Revise_5 (4 m/s) and Revise_6 (6 m/s), so you can set
 as follow:

Speed_5=5.66, Revise_5=0.997, Speed_6 and Revise_6 not change
 or Speed_6=5.66, Revise_6=0.997, Speed_5 and Revise_5 not change

3.12 Batch Control

Σ 123.456 m3
+0.0000m3/h
 🔔 ✎ ⏸ ⚠

In the normal display, press **ENT** button for 5 seconds, then it will go to next setting

ENT ↓
 OPERATIONS
SET ZERO ESC

In this setting, Press **▶** or **◀** button till you selected SET

ENT ↓
 Password
 0000

Password login window
 Input the password
 Password: 0000

ENT ↓
 Language
 简体 繁體
ENG 韩文

Language
 Press **▶** or **◀** to selected the language

ENT ↓
 PV Units
m3/h L/h GPH
 Kg/h t/h GPM
 L/m m3/m ...

Select Flow Engineer unit
 Press **▶** or **◀** to select the Engineer unit
 0: m3/h 1: L/h 2: GPH 3: Kg/h 4: t/h 5: GPM
 6: L/m 7: m3/m 8: ml/h 9: ml/m 10: ml/s

ENT ↓
 URV m3/h
 70.0000

Flow Range
 Setting Flow Range, that's mean 4-20mA and Pulse, frequency output max. Value
 Press **▶** button to move, Press **◀** to change the Value

ENT ↓
 Switch Func
 Default Pulse
 Freq **Alarm**

Contact output
 Press **▶** or **◀** button to selected the output, Please choose the "Alarm"
 1. Default 2. Pulse 3. Frequency 4. Alarm

ENT ↓
 Alarm Select
MAX MIN
BAT DIR

Alarm Select
 Press **▶** or **◀** button to "BAT"
 1. Max(Upper-Alarm) 2. Min(Lower-Alarm) 3. Batch 4. Direction

ENT ↓
 Low Cutoff (%fs)
 0.0

Function for cutoff the low flowrate
 Press **▶** button to move, press **◀** button to change the Value
 Setting Range: 0.0% ~ 9.9%
Pls press ENT button for 5 seconds, then it will go back to the normal display.

ENT ↓

Σ 123.456 m3
 +0.0000 m3/h
 [] [] [] [] []

In general display, Press [] or [] button and select [], make sure enter batch control window

[ENT]
 Batch Control
 SET AUTO
 MANUAL EXIT

Batch Control
 Press [] or [] button to SET

[ENT]
 Batch Value(m3)
 1.00000

Batch Value(m3)
 Press [] button to move, press [] button to change the Value

[ENT]
 Batch Control
 SET AUTO
 MANUAL EXIT

Batch Control
 Press [] or [] button to AUTO or MANUAL

[ENT]
 SET 1.000m3
 RUN 0.000m3
 START CLR EXIT

Press [] or [] button to START, To start batch control
 If choose CLR, The actual flow value will be zero

[ENT]
 SET 1.000m3
 RUN 0.000m3
 PAUSE

In this setting, Press [ENT] button, The flow metering will be pause

[ENT]
 SET 1.000m3
 RUN 0.000m3
 START CLR EXIT

At this time, If choose START, It will continue the next flow
 If choose EXIT, It will quit the batch control

[ENT]
 Batch Control
 SET AUTO
 MANUAL EXIT

Batch Control
 Press [] or [] button to EXIT
 Press [ENT] button. then it will go back to the normal display.

4. Common Alarm Code Indication


AMC2100 Alarm Table			
Code	Contents	Meaning	Solution
8	OV. Flow	Over range	Increase range
16	OV. Flow	Exceeding AD value of flowrate	Slow fluid velocity
24	OV. Flow	Over range Exceeding AD value of flowrate	Increase range Slow fluid velocity
32	OV. Freq	Exceeding Fmax range	Increase the frequency setting range
64	UPPER	Exceeding the upper limit value of alarm settings	Turn off alarm output or raise alarm upper limit value
72	OV. Flow ; UPPER	Exceeding the upper limit value of alarm settings Over range	Increase range Turn off alarm output or raise alarm upper limit value
128	LOWER	Under the lower limit value of alarm setting	Turn off alarm output or decrease the alarm lower limit value
136	OV. Flow ; LOWER	Over range Under the lower limit value of alarm setting	Increase range Turn off alarm output or decrease the alarm lower limit value
256	EMPTY	Empty pipe alarm	Check the pipe & full the pipe
512	Zero	Zero mv value>99mv	Re-zero when fluid is static.
1024	Coil	Exciting Current<40%	Check the XY wiring fall off or not
1032	OV. Flow ; Coil	Over range Exciting Current <40%	Increase range Check the XY wiring fall off or not
1088	UPPER ; Coil	Exceeding the upper limit value of alarm settings Exciting Current <40%	Turn off alarm output or raise alarm upper limit value Check the XY wiring fall off or not
1152	LOWER ; Coil	Under the lower limit value of alarm setting Exciting Current <40%	Turn off alarm output or decrease the alarm lower limit value Check the XY wiring fall off or not
1280	EMPTY ; Coil	Empty pipe alarm Exciting Current <40%	Check the pipe to full the pipe Check the XY wiring fall off or not
1536	Zero; Coil	Zero mv value>99mv Exciting Current <40%	Re-zero when fluid is static. Check the XY wiring fall off or not



Quality we care!

ALIAMAG ALIAPANEL ALIASONIC

ALIADP ALIAPT ALIAVA ALIAVTX



Tel: +1-213-533-4139

Fax: +1-213-223-2317

URL: www.alia-inc.com

Email: alia@alia-inc.com

633 W. 5th Street, 26th Floor, Los Angeles, CA 90071, USA

