

MAG



ALIA TECHNOLOGY LLC

Electromagnetic Flowmeter

Operation Manual

AMC3200 Series



CE

Index

1. Sensor	2
1.1 AMF900 Flange Type	2
1.2 AMF500 Wafer Type	3
1.3 AMF301 Installation	3
1.4 AMF500 Installation	3
1.5 AMF601 Installation	4
1.6 AMF900 Installation	4
2. Installation Considerations	5
2.1 Installation position	5
2.2 Avoid magnetic field interference	5
2.3 Straight Pipe Distance	5
2.4 Installation method	5
3. AMC3200 Operation	7
3.1 Wiring Diagram of Power and Signal Output (either compact or separate)	7
3.2 Wiring Diagram for Separate Type	8
3.3 AMC3200 Panel & Dimensions	8
3.4 Measurement Mode	9
3.5 Examples	9
3.6 Totalizer Reset	10
3.7 Zero Trim	10
3.8 Operational Flowchart	11
3.9 User Operation	14
3.10 System Mode	17
3.11 Advanced Mode	18
3.11.1 Trim Settings	18
3.11.2 Converter Settings	22
3.11.3 Special	23
3.11.4 Bluetooth Settings	23
3.12 Batch Control	24
4. AMC3200 APP Software	27
5. Common Alarm Code	36
6. APP Download Link	36

1. Sensor

Electromagnetic flowmeter is made up with sensor and converter. Either for compact or separate version, Sensor's specifications vary as below:

1.1 AMF900 Flange Type


Size: 10Amm ~ 2000mm (3/8"A ~ 80")

- Liner: Neoprene
- Polyurethane
- FEP
- PTFE
- PFA

Protection Class: IP68

Max.Temp.:180 Deg. C

Process Connection: Flange End



Size (mm)	Standard Pressure Kg/cm ²	Liner Material				Dimensions (mm)			Weight Kg
		FEP / PFA	Neoprene	Polyurethane	PTFE	L	D	H	
10A	40	⊙			⊙	120	90	145	3.5
10		⊙			⊙	120			3.5
15		⊙			⊙	150	95	155	3.5
20		⊙			⊙		105	160	4.5
25		⊙		⊙	⊙		115	166	4.5
32		⊙		⊙	⊙		140	180	6.5
40		⊙		⊙	⊙	150	190	7.0	
50		⊙	⊙	⊙	⊙	200	165	201	9.5
65		⊙	⊙	⊙	⊙		185	220	12
80		⊙	⊙	⊙	⊙		200	235	15
100	16	⊙	⊙	⊙	⊙	250	220	254	17
125		⊙	⊙	⊙	⊙		250	284	21
150		⊙	⊙	⊙	⊙	300	285	314	28
200	10	⊙	⊙	⊙	⊙	350	340	369	36
250		⊙	⊙	⊙	⊙	400	395	430	49
300		⊙	⊙	⊙	⊙	450	445	480	61
350			⊙	⊙	⊙		505	540	79
400			⊙	⊙	⊙	500	565	600	99
450			⊙		⊙	600	615	640	121
500			⊙		⊙		670	700	143
600			⊙		⊙		780	800	187
700			⊙		⊙	700	895	910	260
800			⊙		⊙	800	1015	1020	342
900		⊙		⊙	900	1115	1120	420	
1000		⊙		⊙	1000	1230	1230	503	
1200	6		⊙		⊙	1200	1405	1405	666
1400			⊙		⊙	1400	1630	1630	1036
1600			⊙		⊙	1600	1830	1830	1333
1800			⊙		⊙	1800	2045	2045	1720
2000			⊙		⊙	2000	2265	2265	2190

1.2 AMF500 Wafer Type


Size: 25mm ~ 200mm (1" ~ 8")

Liner: FEP

Protection Class: IP68


Max.Temp.: 180 Deg. C

Process Connection: Wafer




Size		Dimensions (mm)		
mm	Inch	L	D	H
25	1"	90	71	138
32	1-1/4"	100	80	147
40	1-1/2"		86	153
50	2"	115	100	167
65	2-1/2"	115	120	187
80	3"	130	131	198
100	4"	155	151	218
125	5"	155	181	248
150	6"	185	206	273
200	8"	215	261	328


1.3 AMF301 Installation




1.4 AMF500 Installation



1.5 AMF601 Installation



1.6 AMF900 Installation



Note:

- 1) Pipe flange should be welded before flow meter's installation. Welding after flow meter's installation is prohibited. And the welding part of pipe flange should be flat, having no sharp residue. Otherwise liner will be damaged. After Flow meter is installed, if other places in pipe needs to be welded, flow meter's power must be shut down.
- 2) Usually there will be weld residues in newly installed pipe. Before installing the sensor, those residues should be cleaned off so as to avoid liner damage.
- 3) If pipe is not aligned well or sloped, there will be leakage or liner damage.

2. Installation Considerations

Before tube design, please take the following situations into consideration:

2.1 Installation position


Please avoid sunlight when installing the flowmeter; the ambient temperature should be $-25\sim 60$ Deg.C.

2.2 Avoid magnetic field interference

Please do NOT install flow meter near devices such as motor-driven machine, transformer, frequency transformer etc as it will cause magnetic field interference.

2.3 Straight Pipe Distance

In order to guarantee EM Flow meter's accuracy, upstream and downstream should meet below requirements (Picture)




If upstream/downstream pipe is reduced, the reduced pipe's degree should be less than 15° .


And upstream distance should be $5D\sim 10D$ while downstream $2D\sim 5D$.

2.4 Installation method


- Flowmeter can be horizontal, vertical or slant. Please make sure pipe is full either fluid is running or not.
- If there are particles inside fluid, it's recommended to try vertical installation (bottom to top) so as to avoid particles deposit inside pipe.



- There shouldn't be air bubbles inside pipe where flowmeter is installed.



d. Electrode position should parallel with ground. The electrodes' position (A.B) of EM Flowmeter which is horizontally-installed or slant-installed should match the 2 sides (right/left) of tube, and converter (wiring box) should be on the top of the tube.




Horizontal installation, the electrode position A.B should on the right and left side.


e. Transportation

Do NOT use rope to hang the flowmeter through its tube as it may cause inside Liner broken.

Do NOT use your hand or rope to hang the converter or junction box. As their material is tender aluminum, if flowmeter size is bigger than 80mm, they can not stand such heavy weight.




f. Grounding measurement



Grounding resistance <math>< 10 \Omega</math>

General metal tube




Grounding resistance <math>< 10 \Omega</math>





Non-metal tube (plastic tube Liner)

3. AMC3200 Operation


3.1 Wiring Diagram of Power and Signal Output (either compact or separate)

Connect terminals one by one when back cover is opened.




 <p>Max. Output Load: 600Ω</p>	 <p>Max. Supply Voltage: 30VDC Max. Current: 50mA</p>	 <p>Output Voltage: 15VDC Max. Current: 50mA</p>	 <p>MODBUS Output</p>
<p>4~20mA Output (Hart Protocol)</p>	<p>Passive Pulse (Frequency) Output (0~5000Hz)</p>	<p>Active Pulse (Frequency) Output (0~2000Hz)</p>	<p>RS485 Output</p>

3.2 Wiring Diagram for Separate Type



3.3 AMC3200 Panel & Dimensions



Name	Button	Functions Under Measurement	Functions Under Parameter Settings
Set		Press it to enter parameter settings mode	Save current settings and shift to next setting interface. Press and hold ENT key for 5 seconds to exit parameter settings and return to measuring interface.
Up		Press it to choose one of the four lines in screen	Move cursor up or down; change numerical value, decimal point and unit
Right		Press it to revise chosen content	Move cursor


3.4 Measurement Mode


Converter will be in normal display when power up. The display contents are as follows:


Position	Display	Symbols	Unit	Description
1 st Line	Totalizer	Σ	M3, L, ml, lgal, gal, Mgal, bbl, ft3, a-ft, t, kg, g, lb, ston, lton	$\Sigma = \Sigma+ (-) \Sigma-$
	Positive Totalizer	$\Sigma+$		
	Negative Totalizer	$\Sigma-$		
2 nd Line	Velocity		m/s	Display "-" when flow is reverse.
	Flow Rate		m3/h	Display "-" when flow is reverse.
	%Scale		FS%	Actual flow's scale percentage
	Current		mA	Actual flow's current
	Frequency		Hz	Frequency for full scale: 5000Hz

3.5 Examples


To change the unit m3/h as % in first line, please do as follows.




Under normal display interface, hold  until number in second line is chosen.



Press  to change m3/h as %FS.



If batch control is chosen in Alarm option,  icon will be shown in the main display.

3.6 Totalizer Reset

Σ 123.456 m3
+0.0000m3/h
 ⓑ ✎

ENT

Σ 123.456 m3
 Σ1 123.450 m3
 Σ2 123.400 m3
 EXIT CLR

ENT

Clear Total
 NO **YES**

Under normal display interface, press \triangleright or \triangleleft key to choose \varnothing and enter trimming interface.

Trimming Window

Σ: present totalizer Σ1: last totalizer Σ2: totalizer before last
 Choose CLR to start trimming.

Choose YES and press ENT to confirm.

3.7 Zero Trim

If pipe is full and static, Zero Trim can be used to adjust flowmeter to Zero when deviation is produced by ground resistance. Procedures are as follow:

Σ 123.456 m3
+0.0000m3/h
 ⓑ ✎

ENT

Password
 2222

ENT

ZERO
 V0:+1.929mv
 V1:-1.929mV
 NO **YES**

ENT

Zero Trimming ...

ENT

Zero Trimming ...
 -0.624mv

ENT

ZERO
 V0: +0.189mV
 V1: -0.189mV
NO YES

ENT

Σ 123.456 m3
+0.0000m3/h
 ⓑ ✎

Under normal display interface, hold ENT for 5s and release to enter parameter setting interface.

Password

Input password 2222 and press ENT to confirm.

Press \triangleright or \triangleleft to choose YES and press ENT to confirm.


Zero Trimming...


Zero Trimming...


Choose NO and press ENT to return to normal display interface.

Normal display.

3.8 Operational Flowchart







3.9 User Operation

Σ 123.456 m3
+0.0000 m3/h

ENT

Password
0000

ENT

Language
爭既 ENGLISH
縵侯 ESPAÑOL

ENT

Total	Units	/h
m3	L	mL
lgal	gal	Mgal
bbl	ft3	...

ENT

Time Units m3
Sec min
hour day

ENT

URV (FS) m3/h
70.0000

ENT

Low Cutoff (%fs)
1.0

ENT

Damping (s)
01

ENT

Hydro-State
Normal Waved

ENT

Max Limit(%FS)
00

Under normal display interface, hold **ENT** for 5s and release to enter parameter setting interface.

Password
Input password 0000 and press **ENT** to confirm.

Language
Press **▷** or **◁** to choose language.

Totalizer Units
Press **▷** or **◁** to choose totalizer units.
0: m3 1: L 2: mL 3: lgal 4: gal 5: Mgal 6: bbl 7: ft3 8: a-ft 9: t
10: kg 11: g 12: lb 13: Ston 14: LTon

Time Units
Press **▷** or **◁** to change cursor, and press **ENT** to choose time units.


Range Limit
Set range limit, namely 4-20mA. 20mA corresponds to max. range and max. frequency output.
Press **▷** to move cursor, and press **◁** to change value.

Low cutoff
Press **▷** to move cursor, press **◁** to change value. Choose proper low cutoff value.
Setting limit: 0.0% ~ 9.9%. E.g., flow range is set to 100m3/h and low cutoff is set to 1%. If flow rate is lower than -1m3/h~+1m3/h, it would be cutoff and converter shows 0 flow rate.


Damping
Press **▷** to move cursor, and press **◁** to change value.
Setting limit: 01 ~ 99s, default value is 2s.
You can set damping here when flow rate has a large fluctuation, the greater the damping, the slower the flow rate changes.

Fluid State
Press **▷** or **◁** to choose fluid state:
Normal and Waved.


Max Limit (%FS)
Press **▷** to move cursor and press **◁** to change value.
Range: 0~30% It means the max permitted fluctuation value of flow rate in each Limit Time.
If exceed this limit, it will be regarded as interference value.




Limit Time (s)
 Press \leftarrow to move cursor and press \rightarrow to change value.
 It's used to adjust limit time.




Direction
 Press \leftarrow or \rightarrow to choose flow direction.
 1. forward 2. bidirectional




Indication
 Press \leftarrow or \rightarrow to choose flow indication.
 1. forward 2. Reverse



Empty Detection
 Press \leftarrow or \rightarrow choose Yes nor No.




Empty Limit
 Press \leftarrow to move cursor, and press \rightarrow to change value.




PIO Interface
 Press \leftarrow or \rightarrow to choose output type (F+ F-).
 1. passive pulse 2. active pulse 3. alarm output 4. contact input

If user want to choose batch control in Alarm option.


Please see page 23 for its details.




Pulse Factor Unit
 Press \leftarrow or \rightarrow to choose pulse factor unit.



Pulse Factor
 It's the factor of Liter quantity per pulse (Liter/Pulse).
 Press \leftarrow to move cursor and \rightarrow to change value.



Pulse Width
 Press \leftarrow or \rightarrow to choose pulse width.



Contact Mode
 Press or to choose:
 1. normally closed 2. normally open

Communication
 Press or to choose communication on or off.

MODBUS Mode
 Press or choose MODBUS mode.

Baud Rate
 Press or to choose baud rate.

Data Bit
 When MODBUS mode is chosen as RTU, data bit is defaulted as 8.

Parity
 Press or to choose parity.
 1. None 2. Odd 3. Even

Stop Bit
 Press or to choose stop bit.
 1. 1 2. 2

MODBUS Address
 Press to move cursor, and to change value.
 Setting range: 0~247

HART Address
 Press to move cursor and to change address.
 Setting range: 0~15 This option is only available when there is HART function.
Press and hold key for 5 seconds, it will return to normal display.

3.10 System Mode

Σ 123.456 m3
+0.0000m3/h
⏏ ✎

ENT

Password
1111

ENT

Sensor NO.
A70821060

ENT

Size (mm)
0065

ENT

Sensor (Ks)
0.9410

ENT

Load Settings
NO YES

Under normal display interface, hold **ENT** for 5s and release to enter parameter setting interface.

Password
Input password 1111.

Sensor No.
Press **▶** to move cursor and **▲** to change value.

Size
Press **▶** to move cursor and **▲** to change size. Please enter real size as size influences flow rate.

Sensor Factor KS
KS is factory calibrated factor, It's not allowed to be changed unless representative/original factory technician.
Press **▶** to move cursor and **▲** to change value.

Factory Reset
Press **▶** or **▲** to choose Yes or No.
Choose NO and hold ENT for 5s to return to normal display.

3.11 Advanced Mode

3.11.1 Trim Settings

Σ 123.456 m3
+0.0000m3/h

Under normal display interface, hold **ENT** for 5s and release to enter parameter setting interface.

ENT
 Password
 Input system password: ****.

Password
 Input system password: ****.

ENT
 0.0000 m3/h 0%
 0.00m/s DN 15
 150.00 m3/h 0.46
 0.160A 0mV

Display Window
 1. flow rate 2. %range 3. velocity 4. size 5. range 6. zero mV 7. Excitation current 8. gain mV

ENT
 Back Bsc Sensor
 Zero **Trim** Conv
 Spec Bluetooth
 Exit

Options
 Press **▷** or **◁** to choose options.
 1. return 2. basic 3. sensor 4. zero 5. trim 6. converter 7. spec 8. Bluetooth

ENT

Back **Bsc** Sensor
 Zero Trim Conv
 Spec Bluetooth
 Exit

See page 14

ENT

Back Bsc **Sensor**
 Zero Trim Conv
 Spec Bluetooth
 Exit

See page 17

ENT

Back Bsc Sensor
Zero Trim Conv
 Spec Bluetooth
 Exit

See page 10

ENT
 Actual Zero(mV)
+01.9286


Zero Point
 Please do not change it as it's the zero point after trimmed.

ENT
 F.Offset m3/h
+0.0000

Flow Offset m3/h
 Press **▷** to move cursor and press **◁** to change value. It's used to correct flow rate.
 Range: 9.99999~+9.99999m3/h

ENT
 V.Offset m/s
+0.0000

Velocity Offset m/s
 Press **▷** to move cursor and press **◁** to change value. It's used to correct velocity, and flow rate will change with velocity.
 Range: -1~+1m/s



Zero Correction Factor
 Press to move cursor and to change value. This is used for small flow rate (zero correction range 1 and zero correction range 2).

Span Correction Factor
 Press to move cursor and to change value. This is used for linear correction of range. Please do not change it.

Current output Test
 Press or to choose analogue output.
 OFF . 4 . 8 . 12 . 16 . 20

Frequency Output Test
 Press or to choose frequency type.
 OFF . 1 . 10 . 100 . 1000 . 2000 . 5000

Excitation Test
 Voltage of X->Y/Y->X should be more than 24VDC/ -24VDC. If less than 24VDC, converter fails to work normally. Press or to choose options.
 If choose X->Y, voltage will be 24VDC; if Y->X, voltage will be -24 VDC.


Full Tube Value
 It's not allowed to be changed by anyone unless representative/original factory technician.
 Press to move cursor and to change value.

Full Tube Trim
 Press or to choose Yes or Not, do not change it at will.

Empty Tube Value
 It's not allowed to be changed by anyone unless representative/original factory technician.
 Press to move cursor and to change value.

Empty Tube Trim
 Press or to choose Yes or No. Do not change it at will.

4mA Value
 Press to move cursor and to change value.
 If 4mA value has error, you may enter error to make it accurate. For example: if 4mA value's error is +0.1mA, input 0.1mA in this window to trim 4mA. Do not change it at will.



4mA Trim
 Press to move cursor and to change value.
 Another way to trim 4mA value is as follows: when 4mA is measured as 3.9mA, input 3.9mA in this window to trim 4mA. It's for the same purpose like the window above. Do not change it at will.

20mA Value
 Press to move cursor and to change value.
 Please refer to the way of 4mA Value, do not change it at will.

20mA Trim
 Press to move cursor and to change value. Please refer to the way of 4mA Trim, do not Change it at will. **Hold for 5s to return to main window.**

Zero Correction Range 1 Unit (m/s)
 Press to move cursor and to change value, then press to confirm.
 It's used to set small flow rate and influenced by zero factor.


Zero Correction Range 2 Unit (m/s)
 Press to move cursor and to change value, then press to confirm.
Hold for 5s to return to main window.

Linear revision
 11point revision is used for trimming accuracy.
 Choose YES to start linear revision.

Linear revision
 11point revision is used for trimming accuracy.
 Speed_1 ~ Speed_11 are revision velocity points, they can be set for revision.
 Revise_1 ~ Revise_11 are flow factors of Speed_1 ~ Speed_11 to trim flow rate.
 Press to move cursor and to change value. For operation details, please see example below.
 Note: accuracy is standard, please do not do linear revision unless it's necessary; or you may contact ALIA technician for help.

Example 1: size: 50 mm(2"), calibrated flow rate: 0.5 M3/Hr, 1 M3/hr, 2 M3/Hr, 4 M3/hr
 Here is the test result for these four points:

	Measure point 1	Measure point 2	Measure point 3	Measure point 4
Actual flowrate	0.5 m3/h	1 m3/h	2 m3/h	4 m3/h
Actual Velocity	0.071 m/s	0.142 m/s	0.283 m/s	0.566 m/s
Flowmeter flowrate	0.530 m3/h	0.983 m3/h	2.046 m3/h	4.176 m3/h
Flowmeter Velocity	0.075 m/s	0.139 m/s	0.289 m/s	0.591 m/s



Error of these four points:

Point 1: $0.5 / 0.530 = 0.943$, new Revise value = 0.943
 Point 2: $1 / 0.983 = 1.017$, new Revise value= 1.017
 Point 3: $2 / 2.046 = 0.978$, new Revise value= 0.978
 Point 4: $4 / 4.176 = 0.958$, new Revise value= 0.958

	1	2	3	4
Speed	0.071	0.142	0.283	0.566
Revise	0.943	1.017	0.978	0.958

Then you have to input the following value:

Speed_1= 0.071, Revise_1=0.943, Speed_2=0.142, Revise_2=1.017
 Speed_3= 0.283, Revise_3=0.978, Speed_2=0.566, Revise_4 =0.958

After those inputs above, please do NOT change the following values:

t Revise_5, Revise_6, Revise_7, Revise_8, Revise_9, Revise_10,
 Revise_11, Speed_5, speed_6, Speed_7, speed_8, Speed_9, speed_10
 speed_11.

Example 2: Size: 500 mm (20"), for example if a calibrated flow rate is 4000 m³/h

Actual flow rate 4000 m³/h, actual flow velocity 5.66 m/s,

Display flow rate 4012 m³/h, display flow rate 5.677 m/s.

New Revise=4000/4012=0.997

As 5.66 m/s is between Revise_5 (4 m/s) and Revise_6 (6 m/s),
 you may set as below:

Speed_5=5.66, Revise_5=0.997, Speed_6 and Revise_6: no change.

Or Speed_6=5.66, Revise_6=0.997, Speed_5 and Revise_5: no change.

3.11.2 Converter Settings

Back Bsc Sensor
Zero Trim **Conv**
Spec Bluetooth
Exit

ENT

Converter NO.
A0000000

ENT

Converter Factor
0.35000

ENT

Coil current (A)
0.1620

ENT

Coil Freq (HZ)
3.125 6.25
12.5 25

ENT

Power Freq(HZ)
50HZ 60HZ

ENT

PGA
x1. x2. x4. x8.

Converter

Press \leftarrow or \rightarrow to choose options and press **ENT** to enter chosen parameter settings.

Converter No.

Press \leftarrow to move cursor and \rightarrow to change value; do not change it at will.

Converter Factor KC

KC is the calibration value of full tube. It's not allowed to be changed by anyone unless representative/original factory technician.

Press \leftarrow to move cursor and \rightarrow to change value.

Excitation Current I_c (A)

I_c is the factory calibration current, It's not allowed to be changed by anyone unless representative/original factory technician.

Press \leftarrow to move cursor and \rightarrow to change value.

Coil Frequency (Hz)

Press \leftarrow or \rightarrow to choose coil frequency, default value: 6.25.

Power Frequency (HZ)


Press \leftarrow or \rightarrow to choose power frequency.

Gain Settings

Press \leftarrow or \rightarrow to choose Gain Settings.

Hold **ENT for 5s to return to main window.**

3.11.3 Special




Spec
Press \leftarrow or \rightarrow to choose special option and press ENT to enter settings.

Factor (K)
This factor is the reciprocal value of sensor factor KS. It's the factory calibration value. It's not allowed to be changed by anyone unless representative/original factory technician.
Press \leftarrow to move cursor and \rightarrow to change value.

HART Function
Press \leftarrow or \rightarrow to enable or disable HART function, and then press ENT to confirm.

Password
Press \leftarrow to move cursor and \rightarrow to change value. Press ENT to confirm. This is used to set HART communication password. **Hold ENT for 5s to return to main window.**

3.11.4 Bluetooth Settings



Bluetooth
Press \leftarrow or \rightarrow to choose Bluetooth option and press ENT to enter settings.

Bluetooth Password
Press \leftarrow to move cursor and \rightarrow to change value. Press ENT to confirm. This is used to change Bluetooth password between converter and Bluetooth app. Do not change it at will.

Bluetooth Name
Press \leftarrow to move cursor and \rightarrow to change Bluetooth name. Press ENT to confirm. The modified Bluetooth name will take effect when the converter is powered on again.

Bluetooth Password
Press \leftarrow to move cursor and \rightarrow to change value. Press ENT to confirm. This is used to change Bluetooth password between converter and Bluetooth app. Do not change it at will. **Hold ENT for 5s to return to main window.**

Exit
Choose cursor to exit.

3.12 Batch Control

Σ 123.456 m3
+0.0000 m3/h

ENT

Password
0000

ENT

Language
爭既 ENGLISH
縵侯 ESPAÑOL

ENT

Total	Units	/h
m3	L	mL
lgal	gal	Mgal
bbl	ft3	...

ENT

Time Units	m3
Sec	min
hour	day

ENT

URV (FS) m3/h
70.0000

ENT

Low Cutoff (%fs)
1.0

ENT

Damping (s)
01

ENT

Hydro-State
Normal Waved

ENT

Direction
Fwd. Bid.

ENT

Under normal display interface, hold **ENT** for 5s and release to enter parameter setting interface.

Password

Input password 0000 and press **ENT** to confirm.

Language

Press **▷** or **◁** to choose language.

Totalizer Units

Press **▷** or **◁** to choose totalizer units.

0: m3 1: L 2: mL 3: lgal 4: gal 5: Mgal 6: bbl 7: ft3 8: a-ft 9: t
10: kg 11: g 12: lb 13: Ston 14: LTon

Time Units

Press **▷** or **◁** to change cursor, and press **ENT** to choose time units.

Range Limit

Set range limit, namely 4-20mA. 20mA corresponds to max. range and max. frequency output.

Press **▷** to move cursor, and press **◁** to change value.

Low cutoff

Press **▷** to move cursor, press **◁** to change value. Choose proper low cutoff value.

Setting limit: 0.0% ~ 9.9% E.g., flow range is set to 100m3/h and low cutoff is set to 1%. If flow rate is lower than -1m3/h~+1m3/h, it would be cutoff and converter shows 0 flow rate.

Damping

Press **▷** to move cursor, and press **◁** to change value.

Setting limit: 01 ~ 99s, default value is 2s. You can set damping here when flow rate has a large fluctuation, the greater the damping, the slower the flow rate changes.

Fluid State

Press **▷** or **◁** to choose fluid state:

Normal, Waved.

Direction

Press **▷** or **◁** to choose flow direction.

1. forward 2. bidirectional

Indication
Fwd **Rev**

ENT

Empty Detect
NO **YES**

ENT

Empty Limit (%)
50

ENT

PIO Interface
Passive Active
Alarm Input

ENT

Alarm Select
UPPER LOWER
DIR **BAT**

ENT

Pulse Type
Normally Closed
Normally Open

ENT

Σ 123.456 m3
+0.0000m3/h
⌂ ⌘ ⌘

ENT

Batch Control
SET AUTO
MANUAL EXIT

ENT

Batch Value(m3)
1.00000

ENT

Batch Control
SET **AUTO**
MANUAL EXIT

Indication
Press \rightarrow or \leftarrow to choose flow indication.
1. forward 2. Reverse

Empty Detection
Press \rightarrow or \leftarrow choose Yes nor No.

Empty Limit
Press \rightarrow to move cursor, and press \leftarrow to change value.

PIO Interface
Press \rightarrow or \leftarrow to choose output type (F+ F-).
1. passive pulse 2. active pulse 3. alarm output 4. contact input

Alarm Selection
Press \rightarrow or \leftarrow to choose "BAT".
1. upper limit 2. lower limit 3. Direction 4. Batch Control


Contact Mode
Press \rightarrow or \leftarrow to choose:
1. normally closed 2. normally open
Hold ENT for 5s to return to normal display.

Press \rightarrow or \leftarrow to choose \rightarrow and then enter batch control.

Batch Control
Press \rightarrow or \leftarrow to choose SET option.

Batch Value (m3)
Press \rightarrow to move cursor and \leftarrow to change value.

Batch Control
Press \rightarrow or \leftarrow to choose MANUAL or AUTO mode.



Batch Control
 Press or to choose START option.
 If choose CLR, actual flow rate will be cleared to zero.


Batch Control
 Press to stop flow measuring.

Batch Control
 Choose START to continue the measuring that is suspended last time.
 Exit batch control.

Batch Control
 Press or to choose EXIT.
 Press to return to normal display interface.

4. AMC3200 APP Software

1. AMC3200 converter and android phone (should be android system)
2. Operation procedures
 - ① Install the app on cell phone (android)
 - ② Enable Bluetooth after app is successfully installed.
 - ③ Enter the app as shown below:




- ④ Three modes available:


Read-write mode: read and write any parameters in converter (default mode). If enter the wrong Bluetooth password, you will be prompted to enter in read-only mode.

Terminal mode: Use PC software to realize remote monitoring through IP address.


Client mode: Use APP to realize remote monitoring through IP address.



⑤ If parameters are to be changed, please choose read-write mode and then choose login. Cell phone will search device automatically. See pictures below.




⑥ After converter's name is searched (such as ALIA0000000003), press it and enter PIN code 1234. This code is the Bluetooth identification between cell phone and converter and needs to be entered every time they connect. You don't have to enter the code if this interface does not appear. See picture below.




⑦ After entering system, you will see Bluetooth name in the middle of upper interface, mode in upper right interface, flowmeter version, password and nickname in bottom interface.


Set Nickname: you can set a nickname for AMC3200, and this won't change the Bluetooth name. The nickname will be displayed only after Bluetooth name. For example, if you set AMC3200's nickname as "flow", the Bluetooth name will become ALIA0000000003 (flow). See picture below:



⑧ Only the input password is conformed to Bluetooth password can parameters be changed. Password is defaulted to be 0000. If you forget your password, please enter Bluetooth option of advanced settings in converter to check the Bluetooth password. If password is input wrong in APP, it will give a warning to enter read-only mode. See picture below:




⑨ Once Bluetooth password is conformed, system will be as below:




⑩ Menu (7 functions in bottom screen)


Fist function: Real-time flow rate. Slide to the left/right to shift interface so as to check real-time flow rate such as totalizer, flow rate, output current and output frequency. Data can be shared to your email or software through its billing function.




Second function: Parameter settings. 5 options inside: basics, interface, communication, sensor and converter. Or user can slide the screen to left/right to shift these options.





A. For example, if totalizer unit ft3 is to be changed to m3:



B. Press the column of "Totalizer unit" and change unit to m3:




C. After pressing "confirm", screen will be shown as below. The unit before arrow is current unit while after is the changed m3. Click "set" to finish settings.




Third function: Flowmeter function. 3 options inside: Basics, Empty Pipe and Calibration. You can slide screen to the left/right to shift interface.




Fourth function: Virtual keys. 3 virtual keys and 3 keys on converter have the same functionality.







Fifth function: Batch control. You can set batch control here when converter is set to batch control.



Sixth function: Operation records.



Seventh function: Parameter backup. Recreate a file and rename it. Press "Function" in upper part to choose: export measurement data, export config data, export measurement config data and import setting parameters.



5. Common Alarm Code

AMC3200 Alarm Table			
Code	Content	Meaning	Solution
2	Overflow	Over range	Increase range
4	Over upper limit	More than setting upper limit	Turn off alarm output or increase alarm upper limit
6	Overflow, over upper limit	More than setting upper limit Over range	Increase range Turn off alarm output or increase alarm upper limit
8	Over low limit	Less than setting low limit	Turn off alarm output or decrease alarm low limit
10	Overflow, over low limit	Over range Less than setting low limit	Increase range Turn off alarm output or decrease alarm low limit
16	Empty pipe	Empty pipe alarm	Please check pipe and make sure it's full
128	Storage	EEPROM fault	Internal storage malfunctioned, send CPU board to ALIA for repair

6. APP Download Link

Link 1: scan QR code to download.




Link 2: click the following link to download:
http://www.alia-inc.net/download/alia/amc3200/alia_AMC3200.apk



Quality we care!

ALIAMAG ALIAPANEL ALIASONIC

ALIADP ALIAPT ALIAVA ALIAVTX



Tel: +1-213-533-4139

Fax: +1-213-223-2317

URL: www.alia-inc.com

Email: alia@alia-inc.com

633 W. 5th Street, 26th Floor, Los Angeles, CA 90071, USA

