
TIGER SHARK UNIVERSAL INSTRUCTIONS

INCLUDES BASE FOR FILTER AND PUMP



TOOLS REQUIRED • O-ring lube


- Phillips head screwdriver
- Flat head screwdriver

PARTS FOR SAND FILTER

NOTE See breakdown on following page for model specific part lists.



FILTER TANK



BASE




4 WAY VALVE



CLOSURE CLAMP



STANDPIPE



VALVE O-RING



HOSE CLAMPS (6)




PRESSURE GAUGE



STRAIGHT FITTING (3)



TEFLON TAPE





LONG HOSE (2)




HOSE ADAPTERS (2)



DRAIN PLUG

FILTER PARTS BY MODEL



PART #	MODEL #	DESCRIPTION	QTY
1	AC 85685	Filter Base	1
2	AC 83402	Drain Plug	1
3	AC 83380	Stand Pipe	1
4	AC 83399	Filter Tank	1
5	AC 83348	O-Ring	1
6	AC 83364	Flange Clamp	1
7	AC 83321	4 Way Valve	1
8	AC 84514	Bolt Kit	1
9	BS 40061	Straight Fitting	3
10	BS 35815	Clamps	6
11	AC 52221	1.25" x 24" Hose	1
12	BS 10014	1.5" x 3' Hose	2
13	AC 76473	Rear Mount Pressure Gauge	1

ASSEMBLY INSTRUCTIONS FOR SAND FILTER




Filter may be partially assembled; however, nothing has been properly tightened. DO NOT operate filter system without completing assembly instructions.

STEP 1

• Remove the valve from the box and place it to the side until instructed to attach it.



 Inside the tank you will find the standpipe and a plastic bag containing various parts, remove from tank and set aside.



STEP 2

ATTACHING THE DRAIN ASSEMBLY



If drain assembly is all together, take it apart.


Take one rubber gasket and put over threaded part of the drain assembly. Flat part of gasket must be flush against sealing plate.

From inside the tank insert drain assembly through hole in bottom of tank, you will see the threaded part on the outside of the tank.



- The second secon
- Place other gasket on threaded part of the drain assembly that is outside of tank flat side to the tank.

Place locking nut on threaded part and thread until snug. Hand tighten only. Be sure to hold drain assembly from inside while tightening locking nut.






Place drain cap over threaded port on outside of tank. Hand tighten only.


STEP 3

• The filter and pump should be attached to the base prior to filling the filter with sand as it will be difficult to maneuver after the tank is full.

A. CRADLE STYLE MOUNT



- Pumps with cradles located directly under the motor should be aligned with the 4 holes that match up to the cradle. This type of mount will require the use of four mounting bolts and nuts from the hardware supplied with the base.
- Place nuts underneath the base, in the properly aligned hole





- Bolt the housing of the pump through the base and tighten.
- Cover the threads of each straight fitting with teflon tape and thread one fitting into the front of the motor and one fitting to the top of the motor.
- Attach the 1 1/4" hose with a clamp on each fitting.




STEP 4



 Before filling tank with sand, place nub on bottom of tank into notched out piece of the base, twist to the right till snug.

 Place standpipe inside the filter, cover standpipe with the round plastic standpipe protector to prevent sand from entering standpipe.



NOTE Sand should be filled no less than 1/2 way up the tank and no more than 3/4. Over-filling will result in permanent damage to your Filter System.

 Add filter grade sand (sold separately) to filter tank around standpipe.

12" Tank 50 Lbs.





NOTE NEVER FILL SAND TANK MORE THAN 1/2 TO 3/4 OF THE WAY.

 Remove plastic protector and fill tank with water until the tank is filled right below opening of standpipe.

STEP 4 — CONTINUED



- Locate o-ring in bag with various parts.
- Lubricate with o-ring lube to ensure proper seal on tank.(O-Ring lube not included)
- Push o-ring against the lip of the valve. It **MUST** sit flat against the lip to protect from leaking at the valve.

- Clean off any sand or debris on top lip of filter and position valve over the opening of the standpipe.
- Valve will slide ONTO standpipe when positioned properly in tank (as shown). Push down firmly to make sure valve slides on all the way.





• Place valve so that pump port is directly over the pump.



You CANNOT pull standpipe up to secure the valve.
Pulling up can damage the hub and cause sand to get sent back with water flow to pool.

STEP 4 — CONTINUED



 Once valve is in place, hold clamp as shown and position clamp around lip of filter and over edge of valve. 2 long screws and nuts are provided to put clamp together.

• The clamp should sit flat around the lip of the tank and valve. If it is not sitting flat the clamp will leak.





 Make sure that the screws of the clamp are lined up with the seams of the tank. Tighten two screws on clamp a little at a time. Alternating from side to side so that both sides are tightened equally. Failure to follow these instructions will result in a leak at the clamp.

Cover threads of pressure gauge with Teflon tape.
 Remove temporary plug from valve and thread gauge into opening.



STEP 5

- The valve ports are labeled "RETURN", "POOL" and "WASTE" with raised letters next to or on the the openings.
- Attach one long hose to the bottom of the thru-wall skimmer and to the front of the pump with hose clamps on each fitting.
- Attach second long hose to the fitting on the "RETURN" and to the pools return fitting with hose clamps on each fitting.
- "WASTE" port will accept a standard fitting and a backwash hose (sold separately) which will be used during maintenance.
- Check drain plug at bottom of filter to ensure that it is screwed on tight.



HOSE CONNECTIONS FOR STANDARD ABOVEGROUND POOLS

- 1. Take the short hose. Place a clamp onto each end of the short hose. Leave loose. Slide one end of the short hose over the exhaust port of you pump. This is the port opening at the top of the pump not the one in front of the pump. Once in place tighten that clamp. Take the other end of the short hose and slide it onto the port of the multiport valve labeled PUMP. This port is identified by the word "PUMP" embossed on the side of the port on the vale itself. Tighten the clamp.
- 2. Take one of the long hoses. Place a clamp onto each end of the hose. Again leave them loose. Slide one end of the hose over the intake port of the pump. This is the port at the very front of the pump. Tighten the clamp. Take the other end of the 6' hose and slide it over the port of the pools thru wall skimmer. Once in place tighten the clamp.
- 3. Take the remaining long hose. Place a clamp over each end of the hose, again loosely. Slide one end of the hose over the port on the multiport valve labeled "POOL". The word "POOL "is embossed next to the correct port on the valve. Once in place tighten clamp. Take the other end of the 6' hose and slide it over the pools return fitting connection on the outside of the pool wall. Once in place tighten the clamp.



HOSE CONNECTIONS FOR TEMPORARY ABOVEGROUND POOLS AC 124EZ5G and FILTERS EQUIPPED WITH AC 22764 FITTINGS

- 1. Take the short hose. Place a clamp onto each end of the short hose. Leave loose. Slide one end of the short hose over the exhaust port of you pump. This is the port opening at the top of the pump not the one in front of the pump. Once in place tighten that clamp. Take the other end of the short hose and slide it onto the port of the multiport valve labeled PUMP. This port is identified by the word "PUMP" embossed on the side of the port on the vale itself. Tighten the clamp.
- 2. Take one of the long hoses. Place a clamp onto each end of the hose. Again leave them loose. Slide one end of the hose over the intake port of the pump. This is the port at the very front of the pump. Tighten the clamp. Take the other end of the 6' hose and slide one of the AC 22764 fittings onto the end and tighten the clamp. Attach the fitting (now connected to the hose) to the suction/intake port of your temporary pool. Hand tighten fitting.
- 3. Take the remaining long hose. Place a clamp over each end of the hose, again loosely. Slide one end of the hose over the port on the multiport valve labeled "POOL". The word "POOL" is embossed next to the correct port on the valve. Once in place tighten clamp. Take the other end of the long hose and slide the other AC 22764 fitting into the end and tighten the clamp. Attach the fitting to the pools return port on the outside of the pool wall. Hand tighten fitting



AC 22764

OPERATING YOUR FILTER

NOTE

Your filter cannot be run if the water is not at the proper level in the pool. Running the filter without water can cause serious damage to your pump and filter.

- Prime filter prior to starting up filter system. <u>DO NOT</u> turn motor on until system has been primed, you can damage your pump.
 - Make sure water in pool is up to middle of skimmer(s) and that there is nothing blocking water flow from return(s) and skimmer(s) (i.e. plug, plate).
 - Push down selector handle on valve and turn to notch labeled <u>BACKWASH</u>. Let go of handle
 and the valve is now in backwash position. Make sure backwash hose (sold separately) is
 attached to the waste port so water will not spray all over you once pump is started.
 - Remove lid of strainer basket on pump (if applicable) and fill with water. Skimmer and return lines should be filled with water as well (when water level is in proper place in pool this will happen naturally).
 - Place cover back on basket and plug in/switch on pump. When pump starts up, water will come
 out through the backwash hose. If the pump is properly primed, the water in the strainer basket
 will fill completely and air pocket will be eliminated.
 - Repeat above until all air is purged from the system then turn off the pump. If this does not get air out of system, double check all connections to make sure they are properly tightened and try again.
- To use filter, with pump OFF, push down selector handle on valve and turn to notch labeled FILTER.
 - Connect pump to power to start filter operation.
 - Note pressure gauge reading at this time.
- When pressure through return fades and pressure gauge reads 5 psi above starting pressure, you will need to backwash the filter system to remove debris.
 - Turn pump off before moving selector to **BACKWASH** position. Once in backwash, turn pump back on.
 - Water will come out through the waste port, so position backwash hose where you would like water to run out.
 - NEVER backwash for longer than ONE MINUTE at a time! Backwashing longer than one minute
 will cause sandblasting of internal components and can lead to damage of standpipe and/or
 hub and VOIDS WARRANTY.
 - Turn pump off and move selector to *RINSE* position. Rinse will allow water to flow through to clear out the lines and prevent a puff of sand or debris back into the pool after backwashing.
 - Rinse for approximately 15 seconds and turn off pump again. Move selector back to filter and turn pump back on. You are now filtering water.



NOTE NEVER move selector handle while pump is on. Pump MUST be switched off to change the position of the valve. Failure to comply will cause damage to your valve and is not covered by WARRANTY.

TROUBLESHOOTING

LOW	SHORT	POOL WATER
WATER FLOW	FILTER CYCLES	WON'T CLEAR UP
 Check skimmer and pump strainer baskets for debris. Check for restrictions in intake and discharge lines. Check for air leak in intake line (indicated by bubbles returning to pool). Backwash filter. Bring sand level in filter down to 1/2 full. 	1. Check for algae in pool and superchlorinate as required. 2. Be sure chlorine and pH levels are in proper range. Adjust as required. 3. Check surface of filter sand for crusting or caking. Remove 1" of sand if necessary. 4. Check hair and lint basket on pump for possible air leak, lubricate basket lid 0-Ring as necessary.	 Check chlorine, pH and total alkalinity levels and adjust as required. Be sure flow rate through filter is sufficient. Operate filter for longer periods. Be sure valve is set on "Filter" position. Be sure sand is between 1/2 and 3/4 full in tank.

WINTERIZING

Failure to winterize your filter properly may result in damage to the tank and pmp which is NOT covered under any warranty.

- At the end of the season once you disconnect filter system, remove the valve from the tank.
 Valve selector handle should be positioned **BETWEEN** any of the notches to allow for air ventilation through the valve to protect from cracking.
- Remove drain plug from bottom of sand tank to drain water out of the filter tank. Keep this plug off for the winter to allow any potential water build-up to escape from the tank.
- Empty ALL sand from the filter system and dispose of as it is recommended to replace sand EACH season.
- Rinse out inside of tank and air dry. Remove standpipe from tank.
- Store tank in an area where it will be protected from the elements and keep valve and tank stored **APART** to protect from condensation forming and causing cracks in the tank or valve.
- Run hose water through pump to rinse out and store in a warm, dry place for the winter.