P6-Series

Infrared Sauna Instruction Manual

Models: P6-H106-01/P6-H206-01/P6-H306-01 1, 2 & 3 Person FAR Infrared Saunas







CARBON MODEL SAUNA FOR INDOOR USE ONLY

120VAC 15AMP Dedicated Circuit Required (1 & 2 Person Models) 120VAC 20AMP Dedicated Circuit Required (3 Person Models)

Carefully and thoroughly read this Owner's Manual before using/operating the sauna. We recommend keeping this Owner's Manual for regular review and future reference.

TABLE OF CONTENTS

Packing List	2
Visual Assembly Diagrams	6
Parts Description	9
Assembly Instructions	15
Operating the Sauna	22
Tips for Using Your Sauna	25
Safety Instructions	25
Safeguards for Your Sauna	27
Troubleshooting Guide	27
Warranty	31
Warranty Card	33

WARNING: Visually inspect all heaters before assembly to make sure they are not damaged. Any excessive vibrations during transport could cause damage to the heating elements. DO NOT START the sauna if damage is detected! Contact your dealer or manufacturer for troubleshooting and replacement parts.

Packing List (main panels)

1pc Front Panel	1pc Rear Panel	1pc Right Side Panel
1pc Left Side Panel	1pc Roof Panel	1pc Roof Cover
1pc Bench	1pc Bench Heat Emitter Panel	1pc Floor Panel


NOTE: Your model sauna has been completely assembled and tested prior to packaging. The rear wall panel is intentional warped as part of the overall design. Two adults will be needed to assemble the sauna room.

CAUTION: Exit Sauna Immediately If You Feel Dizzy, Sleepy, Or Any Discomfort.

What Are Infrared Rays?

Infrared is the band of light we perceive as heat. We cannot see this band of light with the naked eye, but we can feel this type of light in the form of heat. Our sun produces most of its energy output in the infrared segment of the spectrum. Infrared rays heat your body without having to heat the air in-between. This process is called conversion.

The infrared is divided into 3 segments by wavelengths measured in microns: Near Infrared – 0.76-1.5 microns; Middle Infrared – 1.5-5.6 microns; and Far Infrared – 5.6-1000 microns. Among these segments, Far Infrared penetrates organic substances such as the human body two to three inches so that the warming effect is very uniform.



ARE INFRARED RAYS SAFE?

Because infrared rays are part of sunlight, they are not only safe but also highly beneficial to our bodies on a cellular level. Health professionals have used infrared heat lamps for decades to **treat muscle and joint problems.** In hospital baby care units, incubators are often equipped with infrared heating systems to **keep newborn babies warm.**

WHAT IS AN ELECTROMAGNETIC FIELD (also known as EMF)?

An Electromagnetic Field is a physical field produced by electrically charged objects. It is one of the fundamental forces of nature. The field can be viewed as the combination of an electric field and a magnetic field. The electric field is produced by stationary charges and the magnetic field by moving charges referred to as currents. The magnetic field is measured in milligauss (mG). Our sauna products have been developed to have low EMF. Our Low EMF carbon heater panels range between an average of 5mG-10mG at about two inches from the heater panel, our Ultra Low EMF carbon heater panels range between

3mG-5mG, and our Near Zero EMF/Full Spectrum models range at less than 3mG (NIR heaters range at about 5mG-7mG at the same approximate 2 inches)

EMF Levels from Common Homes Sources

mG at 3 fee	mG up to 4 inches	SOURCE
0.3-3	50-220	Blender
0.1-4	8-200	Clothes Washer
0.1	6-29	Coffee Maker
2-5	4-20	Computer
0.1-5	400-4,000	Flourescent Lamp
0.1-6	60-20,000	Hair Dryer
1-25	100-500	Microwave Oven
0.1-6	5-100	Television
3-40	230-1,300	Vacuum Cleaner
	50	Airplane


After many years and numerous studies on EMF exposure, no government body including the Occupational Safety and Health Administration (OSHA) have established permissible exposure limits (PEL). Currently, there is no consensus on the potential health hazard from any exposure to EMF. The mainstream scientific evidence suggests that low-power, low-frequency, electromagnetic radiation associated with household currents like that of the infrared sauna does not constitute a short- or long-term health hazard.

DISCLAIMER

The infrared rays emitted by your sauna are reported to offer a wide range of possible therapeutic benefits based on research completed over the last 40 years from all around the world. These benefits are presented for reference purposes only and no implication of infrared saunas creating a cure for or treating any disease is implied nor should it be inferred. If you have a medical/health condition, are taking prescription drugs, or have acute joint injuries, please consult with your medical physician before using the sauna. Persons with surgical implants (metal pins/rods, artificial joints, silicone, or other types of surgical implants) typically do not experience any adverse effects, but should also consult their medical physician or surgeon before using the sauna room.

HOW IT WORKS

Infrared Saunas differ from traditional saunas in that they use infrared radiant energy to directly penetrate into the body's tissue to produce perspiration. Traditional saunas use steam to heat the air inside the sauna, which then heats your body until you begin to perspire. In order for this to be effective, temperatures would need to reach in the upwards of 190 degrees Fahrenheit. Infrared saunas only need a temperature of up to 120 degrees Fahrenheit to obtain the same effect. This lower temperature makes the environment more tolerable and allows you to breathe easier.



Health Benefits

Because infrared rays penetrate the body through conversion, there is a deep heating effect in both the muscle tissues and internal organs without putting too much burden on the heart.

Our body reacts to the increased heating through the natural cooling process of perspiring. Through the perspiration process, acid and waste residue like toxins, sodium, alcohol, nicotine, cholesterol, and the potentially carcinogenic heavy metals are removed from the cells (especially zinc, lead, nickel, cadmium, etc.). The pores of our skin open and discharge waste products shedding any old skin cells leaving the skin glowing and clean, with improved tone, elasticity, texture, and color.

Health Benefits Include, But Are Not Limited To:

*Pain relief from Rheumatoid Arthritis *Relaxes muscle spasms

*Increases blood circulation *Clears, rashes, acne

*Cardiovascular conditioning *Reduces stress & fatigue

*Reduces cellulite


*Enhances skin tone

*Removes toxins

Sauna Maintenance


Since infrared saunas do not require hot rocks, water, or steam to operate, they require very little maintenance. You can simply wipe it down with water – use a damp, soft, and clean cloth. **Do not use any chemical-based cleaning agents** as they can be absorbed into the wood and be released into your sauna during use.

Visual Assembly Diagram




Visual Assembly Diagram

P6-H206-01




Visual Assembly Diagram

P6-H306-01



PARTS DESCRIPTION

P6-H106-01



	Elec	tronic	components
No.	Name	No.	Name
1	Speakers	2	Temperature sensor
3	Color therapy	4	Roof lights
5	Power supply	6	control panel
10	CD Player		

Power layout				
Location	No.	Dimension	Power	
Left side wall panel	7	1000*300mm	200W	
Rear wall panel	8 1000*400mm		300W	
kear wall panel	9	1000*400mm	300W	
Bench Heater	11	700*300mm	150W	
Floor Panel	12	700*300mm	150W	
rioor ranei	13	700*300mm	150W	
Right side wall panel	14	1000*300mm	200W	
TOTAL			1450W	

PARTS DESCRIPTION

P6-H206-01




	Elec	tronic	components
No.	Name	No.	Name
1	Speakers	2	Temperature sensor
3	Color therapy	4	Roof lights
5	Power supply	6	control panel
8	CD Player		

Power Layout				
Location	No.	Dimension	Power	
Left side wall Panel	7	1000*400mm	300W	
D 11 D 1	9	1000*400mm	300W	
Rear wall Panel	10	1000*400mm	300W	
Floor Panel	11	1000*400mm	300W	
Bench Heater	12	1000*300mm	200W	
Right side wall Panel	13	1000*400mm	300W	
TOTAL			1700W	

PARTS DESCRIPTION

P6-H306-01



	Elec	tronic	components
No.	Name	No.	Name
1	Speakers	2	Temperature sensor
3	Color therapy	4	Roof lights
5	Power supply	6	control panel
11	CD Player		

Power layout				
Location	No. Dimension Po		Power	
Left side wall Panel	7	1000*400mm	300W	
	8	1000*400mm	300W	
Rear wall Panel	9	1000*300mm	200W	
	10	1000*400mm	300W	
Bench Heater	12	1000*300mm	200W	
Floor Panel	13	1000*400mm	300W	
Floor Panel	14	1000*400mm	300W	
Right side wall Panel	15	1000*400mm	300W	
TOTAL			2200W	

Highlights

I. Power Supply (Control Box)

The POWER SUPPLY is the control center of the sauna room. It is installed on the topside of the ROOF PANEL and has inputs/outputs connected to it. (see Figure 1)



Figure 1

POWER IN - main power of the sauna room
HT1, HT2, HT3, HT4, HT5, HT6 - heat emitter cords
LAMPROOF - roof lamp power (optional)
LIGHTING - chromotherapy lights
PANEL CONTROL - control panel
FUSE RESET - protects against power

II. Component Labeling

Power Cord – Main power cord connects the POWER SUPPLY to the dedicated wall outlet

HT1, HT2, HT3, HT4, HT5, HT6 – Heater cords connect the heat emitters to the POWER SUPPLY at these ports (HT5 & HT6 are not used on most models)

Lighting – Connects the interior lighting to the POWER SUPPLY at this port

LampRoof – Connects the exterior roof lights to the POWER SUPPLY at this port

Panel Control – Connects the Control Panel through the CTRL harness to the Power Supply at this port

L/R Speakers – Connects the speakers through these wires to the Control Panel

Temp Sensor – Connects the Temperature Sensor through this wire to the Control Panel

III. MP3 Auxiliary Port

The MP3 Auxiliary Port allows you to connect a MP3 player or other device with the auxiliary function to the speakers in the sauna room for your listening pleasure. (see Figure 2)



Figure 2

IV. Buckles

A. External Buckles

The external buckles are used to connect the LEFT and RIGHT SIDE PANELS to the REAR PANEL and FRONT WALL PANELS. (see Figure 3)




Figure 3


V. Panel Descriptions

For easier assembly, please understand and distinguish the differences between each panel.

A. FLOOR PANEL

When you place the FLOOR PANEL at its designated location, be sure to leave enough space so that you are able to move around the FLOOR PANEL during the assembly process. The wood guide inserts are located on the FLOOR PANEL at the front and rear. You will place the FRONT WALL PANEL and REAR WALL PANEL up snugly against the wood guide inserts on the FLOOR PANEL. Please note that there are two FLOOR PANEL styles: Style 1 will have the single

FLOOR HEATER towards the front of the sauna room. Style 2 will have two FLOOR HEATERS and will have wood plank guides on the floor for the BENCH HEAT EMITTER PANEL. (see Figure 4)



B. Understanding the Difference Between the Top and Bottom of the Wall Panels

The (4) panels are in the upright position when the heat emitter panels are closer to the top of the wall panel than the bottom of the wall panel. There will be 2 or 3 carbon heat emitter panels on the REAR PANEL depending on your model sauna. The REAR PANEL and SIDE WALL PANELS will have the heater cords coming from the top of each wall panel which will be connected once the ROOF PANEL is put on top. (see Figure 5)




Figure 5

Assembly Instructions

Please note that your sauna has been completely assembled and tested at the factory prior to packaging. Please further note that the rear wall panel is intentional warped as part of the overall design. Two adults will be needed to assemble the sauna room.

A. Choose a good location to assemble the sauna

- 1. The location must be dry, leveled, and away from any source of water MAIN POWER cord must be easily accessible
- 2. Two adults are required for installation
- 3. Wood cabin installation order: Floor Panel Front Wall Panel with Glass Door Right Side Wall Panel Left Side Wall Panel Rear Wall Panel Bench Heat Emitter Panel Bench Roof Panel Roof Cover
- 4. Tools Required: Philips Screwdriver and Ladder

PLEASE NOTE THAT SOME MODELS WILL VARY IN ASSEMBLY.

B. Installing the FLOOR PANEL

Place the FLOOR PANEL on the floor. SOME MODELS
 HAVE WOOD BRACES THAT MUST BE INSTALLED ON
 THE UNDERSIDE OF THE FLOOR PANEL BEFORE
 ASSEMBLING THE SAUNA ROOM. Please check to see if such wood braces were packed in the box containing the FLOOR PANEL. If so, mount according to the designated labels located on the underside of the FLOOR PANEL. Once installed, turn the FLOOR PANEL right side up. Make sure the front side of the FLOOR PANEL is facing the correct direction. (see Figure 4)

C. Installing the REAR WALL PANEL, RIGHT SIDE WALL PANEL, and LEFT SIDE WALL PANEL

1. Place the REAR WALL PANEL up and onto the FLOOR PANEL. Remove any protection paper/tape from the buckles if necessary and align the buckles on the REAR WALL PANEL and the LEFT SIDE WALL PANEL (or RIGHT SIDE WALL PANEL as the order of installing the side wall panels is not important). Once aligned, proceed in locking the buckles into place. Do the same for the RIGHT SIDE WALL PANEL (or LEFT SIDE WALL PANEL depending on which side you installed first). (see Figure 6 and Figure 7)





Figure 6

Figure 7

NOTE: If any of the wall panels do not slide all the way down, then follow this tip:

- 1. First, remove the side wall panel.
- 2. Locate the guide and guide insert brackets on the two wall panels (6 pieces total).
- 3. Loosen the screws on the guide and guide insert brackets by two-to-three turns (so the guide and guide inserts have a slight movement)
- 4. Reattached the wall panels

The above will help as sometimes the guide and guide insert brackets are countersunk too deep. Please note that the guide and guide insert brackets slide together at an angle - as the wall panels slide downward, the guide and guide insert brackets pull the wall panels tighter together.

D. Installing the FRONT WALL PANEL

1. Remove any protection paper/tape from the buckles. Place the FRONT WALL PANEL up and onto the FLOOR PANEL. Next, attach the FRONT WALL PANEL to the LEFT SIDE WALL PANEL and use the buckles to latch together. Do the same for the RIGHT SIDE WALL PANEL. The black protection corners used to protect the corners of the glass door can be removed and discarded. (see Figure 8)




Figure 8

E. Installing the BENCH HEAT EMITTER PANEL and BENCH

- Installing the BENCH HEAT EMITTER PANEL can be a little tricky on some sauna models. You will need to slide the BENCH HEAT EMITTER PANEL into place at an angle as indicated in the pictures below. (see Figure 9)
- 2. Plug in the BENCH HEAT EMITTER connector to the corresponding inlet located on the LEFT SIDE WALL PANEL. Also plug in the FLOOR HEAT EMITTER PANEL connector to the corresponding inlet on the RIGHT SIDE WALL PANEL.
- 3. Install the BENCH at an angle as also seen in Figure 10. Then slide it over the BENCH HEAT EMITTER PANEL all the way back and against the REAR WALL PANEL. Make sure to install the BENCH with the smooth and finished side facing upward. If screws were provided, it is optional to use them to screw down the bench.



BENCH HEAT EMITTER PANEL
Guides On Side Walls



(Bench & Bench Heat Emitter Panel Do Vary In Installation & Design)

Figure 9

F. Installing the ROOF PANEL

- **1.** The side of the ROOF PANEL with the power supply (control box) is the top of the roof panel.
- 2. The edge nearest the power supply is the front of the ROOF PANEL. Be careful of the wires coming from the SIDE and REAR PANELS when you set the ROOF PANEL down onto the panels. Feed the wires through the holes in the ROOF PANEL. Feed the control cable and buzzer plug up through the ROOF PANEL.
- 3. Be careful not to force the ROOF PANEL into place. Make sure that the wires are properly fed through the holes. Furthermore, make sure the ROOF PANEL sits snugly onto all of the wall panels. Pull down on the ROOF PANEL slightly to make sure it is secured in place. (see Figure 10)



Figure 10

G. Connecting the plugs on the ROOF PANEL

- Connect the plugs according to their respective labels. (see Figure 11)
- **2.** You will need to connect the right and left speaker connectors, the MP3 connector, and the CTRL wire connector.





Before Connecting

After Connecting

Figure 11

H. Assembling the RADIO BOX

- **1.** Locate the wood sides for the Radio Housing Box. There is one for the front, side, and bottom. (see Figure 12)
- **2.** Attach "A" on side panel with "A" on bottom panel and insert screws.
- **3.** Attach "B" on front with "B" on side panel and "C" on front panel with "C" on bottom panel and insert screws.
- 4. Screw the Radio Housing Box to the REAR PANELS. The back opening (the larger opening) on the Radio Housing Box will face the RIGHT REAR PANEL. The front opening (the small opening and where the CD/radio is inserted) on the Radio Housing Box will face the LEFT SIDE PANEL.




Figure 12

I. Installing the RADIO (radio model subject to change)

- **A.** Locate Locate the RADIO and remove it from any packaging. (see Figure 13)
- 2. Connect the plug from the RADIO with the plug coming down from the roof and the left/right speaker plugs. (see Figure 14)
- **3.** Connect the antenna plug to the RADIO. (see Figure 15)
- 4. Insert the RADIO into the RADIO BOX. It is not necessary to mount the RADIO once you slide it into the RADIO WOOD BOX because the radio will just sit in place. (see Figure 16 and Figure 17)



SPEAKER

Figure 13 Figure 14





Figure 16



Figure 17

J. Installing the TEMPERATURE SENSOR and <u>optional accessories</u> (varies by model)

1. Enter the sauna and remove the protective covering (masking tape) from the TEMPERATURE SENSOR. Please note that the black plastic section of the TEMPERATURE SENSOR is part of the TEMPERATURE SENSOR. Situate the TEMPERATURE SENSOR so that it is vertical and pointing downward. (see Figure 18)



Figure 18

Note: Some sauna models are shipped with a spare TEMPERATURE SENSOR in case the TEMPERATURE SENSOR is damaged during transit. The manufacturer decides this according to sauna models and packaging.

K. Putting on the ROOF COVER

 Place the ROOF COVER over the top of the sauna. Be cautious when pulling the power cord through the hole in the roof cover. Gently place the ROOF COVER onto the ROOF PANEL. When the edges are aligned, screw the ROOF COVER to the roof panel. (see Figure 19)



Figure 19

ASSEMBLY COMPLETE!

Operating the Sauna



Control Panel

Power On/Off: Press to control the main power of the sauna Power Indicator: Indicates the status of the sauna's main power Work Start/Stop: Press to control the working functions of the

sauna

Work Indicator: Indicates the working status of the sauna **Heat Indicator:** Indicates the status of heating function

Light: Press to control the lighting function

Time Display: Displays the heating time of the sauna in minutes

Time: Press to adjust the setting of the timer

Temperature Display: Displays the actual interior temperature of

the sauna room in ⁰C/⁰F

Temperature: Press to adjust the temperature setting

OC/OF: Press to change the temperature display between OC/OF

- 1. Plug the sauna into the wall outlet.
- 2. Press the POWER button once. The POWER light will come on, the TIME DISPLAY will show 90 (minutes), the TEMPERATURE DISPLAY will show 151°F / 66°C, and the control panel will flash.
- 3. Press the up/down arrows under the TIME DISPLAY to adjust the amount of time you want the sauna to remain on. Press the C/F button to choose between Celsius and Fahrenheit. Press the up/down arrows under the TEMPERATURE DISPLAY to adjust the temperature setting. Once you have set these adjustments to the desired settings, press the START/WORK button. If you do not press the button for 5 seconds, the control panel will stop flashing and the set-up values will be memorized. The WORK and HEAT lights will now be on and the emitters will now be generating heat. You can either pre-heat the sauna to the set temperature before entering or sit inside the sauna as the temperature rises to the set temperature. Please keep in mind that you will increase the time it takes for the sauna to reach the set temperature if you enter the sauna room before it has reached the set temperature.
- 4. During your sauna session, set-up time will count down the minutes one by one. You can use the up/down arrows to adjust the time. If you do choose to adjust the time, the control panel will flash and the emitters will stop generating heat. Once you set the time to the desired setting, then press the START/WORK button twice and the control panel will stop flashing and heat will began coming from the emitters once again.
- **5.** Heating times do vary. Generally, it will take approximately twenty to thirty minutes to preheat the sauna to the average used temperature range of approximately 118 degrees Fahrenheit / 48 degrees Celsius. When the ambient temperature is low, heating requires additional time. For the first few times of use, you may use 115

degrees Fahrenheit / 46 degrees Celsius as a reference starting point for a time period of about 20 to 30 minutes (this represents the actual time you are in the sauna at the desired temperature). As you become more comfortable and familiar with the sauna, you can increase the temperature and time period according to your personal preference.

- 6. When the temperature is at the set-up value, the digital control will maintain the set temperature. The WORK light will remain on and the HEAT light will turn off. The emitters will stop generating heat. Once the inside temperature drops approximately 4 degrees Fahrenheit, the HEAT light will turn back on and heat will again be generated by the emitters. With the digital control, the inside temperature will always remain around the set-up value.
- 7. Reading lamps and/or roof lamps and/or color therapy lamps are operated by pressing the respective buttons located towards the center of the control panel. These lamps are offered on some models and are not available on all models.
- 8. Color Lighting can be operated as follows: First, you will need to install the battery. Once the battery has been inserted into the remote, you are ready to operate the color therapy lighting system. Press the READING LIGHT button on the sauna control panel. The white light will come on. While pointing the remote at the ceiling light, you can press any of the colors on the remote and that color will be displayed. You can use the SHADE button on the remote to go through a sequence of colors. If you want to turn the light off during your sauna session, you can press the POWER button on the remote. Please note: You must be inside the sauna room for the remote to work.



Please note that the lights and music will remain ON for approximately 15 minutes when the time on the control panel has timed out.

9. Bluetooth can be used on the sauna room. You first will need to pair your device with the sauna room. Open your device's Settings Menu and then locate and open Bluetooth. You will find "iSauna" or "BT100" or "Bluetooth". Now you can pair your device. Once pairing is successful, your device will be connected. Please note that you must unpair/disconnect from Bluetooth if your sauna model has the optional MP3 Jack at the ceiling and you choose to use the Aux Wire to connect to the speaker

- system. If you need to reset the Bluetooth/Aux system, you can do so by unplugging the sauna's power cord for 15 minutes.
- 10.The MP3 Jack will allow you to connect your musical device using the AUX wire. Plug one end of the AUX wire into your musical device and the other end into the MP3/AUX Jack on the radio. Do not leave the AUX wire connected when not using this function as it may cause static interference at the speakers. Please see the Owner's Manual for the radio for additional guidance.

Please Note: On average, it takes our model saunas approximately:

- *20 minutes to reach into 100 degrees Fahrenheit/38 degrees Celsius (with a Starting temperature above 70 degrees Fahrenheit/21 degrees Celsius)
- *25-30 mins to reach about 115-120 degrees Fahrenheit/46-49 degrees Celsius (depending on sauna model)
- *35-40 minutes to reach about 125-130 degrees Fahrenheit/52-54 degrees Celsius (depending on sauna model)
- *45-60 minutes to reach up to approximately 135 degrees Fahrenheit/57 degrees Celsius (depending on sauna model)

Please keep in mind that you can either preheat the sauna to the set temperature before entering or sit inside the sauna as the temperature rises. In addition, you will increase the time it takes for the sauna to reach the set temperature if you enter the sauna room before it has reached the set temperature. Also, the most commonly used temperature setting is between 118 degrees Fahrenheit / 48 degrees Celsius and 122 degrees Fahrenheit / 50 degrees Celsius. The way the sauna room works is when you set the Control Panel to say 120 degrees F / 49 degrees C, the heat emitters will turn off when that set temperature is reached. And even though the sauna does allow the user to set the Control Panel to 151 degrees F/66 degrees C, this is specifically for those users who do not want the heat emitters to ever turn off as the sauna room will never achieve 151 degrees F / 66 degrees C. After 3 hours of continuous use, the sauna needs to be shut down for one hour.

CAUTION: Exit sauna immediately if you feel dizzy, sleepy, or any discomfort.

Tips for using Your Sauna

- 1. If you take a hot/warm shower or bath before using your sauna, you may perspire more and experience more comfort.
- 2. Drink water prior to, during, and after your sauna session to replenish body fluids.
- 3. To regulate the set temperature inside the sauna to your comfort level, use the movable roof vent or leave the door slightly open. The roof vent is installed on the sauna and used based on personal preference.
- 4. Use 2 towels during your sauna session. Fold the first towel several times and place it on the bench. As you sit on this towel, it will absorb a majority of your perspiration while adding comfort as you sit on the bench. Use the second towel to either constantly wipe the perspiration from your body to perspire faster and also to avoid having too much perspiration dripping onto the floor. Never place any towels over the floor heater. If your legs become cold, you can use a third towel to drape over your legs to trap the heat.
- 5. This is a non-commercial sauna. For every three hours ON, the sauna must be turned OFF for one hour to cool down.
- 6. At the first sign of a cold or flu, increasing your sauna sessions may be beneficial in boosting your immune system and decreasing the reproductive rate of the virus.
- 7. To help relieve sore and tense muscles, massage the affected areas during your sauna session.
- 8. To treat your ankles and feet more effectively, you can elevate them and move them close to one of the heat emitters to achieve a deep heating effect.
- 9. To utilize the sauna's heat therapy effect, put oil and treatment into your hair and wrap it with a towel. After your sauna session is over, rinse your hair thoroughly.
- 10. The peaceful and relaxed state rendered by a sauna session may help you to sleep easier and deeper.
- 11. To conserve energy consumption, please unplug your sauna when not in use especially if you do not plan on using the sauna for an extended period of time.
- 12. After the sauna session is over, do not jump into the shower or bath immediately. Because your body was heated up during the sauna session, it will continue to perspire even after the heat emitters are off. Sit in the sauna with the door slightly opened and let your body cool down. Once your body has cooled down and you feel comfortable, you can exit the sauna. After about fifteen minutes and when your body has completely cooled down, you can take a shower or bath to clean your body.

Safety Instructions

- 1. Read and follow all instructions carefully before using the sauna.
- 2. When assembling and using the electrical equipment, safety precautions should always be followed.
- 3. To reduce the risk of injury, do not allow children to use the sauna unless they are closely supervised at all times by an adult. Children should not use the sauna unless prescribed or advised by their medical doctor.

- 4. Do not use the sauna immediately following strenuous exercises. Wait at least 30 minutes to allow the body to cool down completely.
- 5. Pregnant or possibly pregnant women should contact their medical physician prior to using the sauna. Excessive temperatures have a high potential for causing fetal harm during pregnancy.
- 6. **Hyperthermia Danger:** The normal body temperature can't rise above 103°F (39°C). Symptoms of excessive hyperthermia include dizziness, lethargy, drowsiness, and/or fainting. The effects of excessive hyperthermia may include, but are not limited to failure to perceive heat, physical inability to exit the sauna, unawareness of impending hazards, unconsciousness, and/or fetal harm in pregnant women. Hyperthermia could make your body's core temperature rise. Setting the desired temperature to an excessively high temperature is not recommended.
- 7. The use of alcohol, drugs, or medications (prescribed or non-prescribed) prior to or during the sauna session may lead to unconsciousness and/or other harmful physical injuries.
- 8. Persons suffering from obesity or with a medical history of heart disease, low or high blood pressure, circulatory system problems, diabetes, or other medical conditions should consult with a medical physician prior to using the sauna.
- 9. Persons using medications should consult with a medical physician before using the sauna. Some medications may induce drowsiness while other may affect the heart rate, blood pressure, and/or blood circulation.
- 10. Use care when exercising before and after sauna use.
- 11. Never sleep inside the sauna.
- 12. Do not use any type of cleaning agents on the interior of the sauna. Only wipe down the sauna room with water and a damp cloth. Never use any chemical based cleaners.
- 13. Do not stack or store any objects on top of or inside the sauna.
- 14. If the power supply cord becomes damaged, it must be replaced immediately by the manufacturer or its agent. If you find the power cord is too hot (normally it will become warm) or that the electrical equipment may be experiencing technical problems, please contact the manufacturer or its agent immediately to avoid hazardous situations.
- 15. Make sure that the electrical outlet is in good working order. A common problem with electrical outlets is loose wiring on the connection points of the terminals of the outlet. A loose wire will also make for a bad connection and cause an unusual amount of heat buildup. Loose connections can also cause sparking in the junction box that can result in arcing. You'll likely see burn marks around the terminals if this occurs. If this happens, do not use the sauna and have the outlet replaced by a certified electrician. If the power cord is damaged, please contact Customer Support.
- 16. Do not use the sauna during an electrical storm to avoid risk of shock or injury.
- 17. Do not continuously switch the power ON and OFF excessively as it will compromise the life of the electrical components.
- 18. Your hands must be dry and free of moisture before plugging and unplugging cords and wiring harnesses from the power supply and circuit boards. Never operate the sauna with wet hands or wet feet to avoid the risk of electrical shock or injury. Never touch the metal prongs of the plug.

- 19. Do not attempt to make any repairs yourself unless authorized by the manufacturer or its agent. If a problem occurs with the sauna, please contact the manufacturer or its agent immediately to avoid safety risks. Unauthorized repair attempts will void the manufacturer's warranty.
- 20. Please make sure the outlet power supply meets the specifications required. Failure to meet the requirements may cause safety risks.
- 21. Some sauna models are equipped with reading and/or roof lamps. Because the lamp temperature will become very hot once powered ON, do not attempt to touch the lamp to avoid being burned. Do not attempt to touch it for at least 20 minutes or until it cools down completely if a need to touch it arises.
- 22. Do not pour water or any other liquids onto the infrared heat emitters. Do not bump, hit, or break the heating elements as it may cause an electrical short and pose a safety risk.
- 23. Do not make any modifications to the sauna, the sauna structure, or the sauna components.
- 24. Prior to each sauna session, the sauna room is to be inspected for correct operation. If for any reason your sauna does not seem to be operating properly, discontinue use and contact Customer Service.

Safeguards For Your Sauna

- 1. Do not install the sauna near water, near a bathtub (if water will splash on the sauna), near a shower (if water will splash on the sauna), in a wet basement, or near a swimming pool (if water will splash on the sauna).
- 2. Do not use liquid cleaners or aerosol cleaners on the sauna. Unplug the sauna from the wall outlet before cleaning. Use plain water and a soft damp cloth for cleaning.
- 3. The power supply cord should be routed so that it is not walked on or pinched by any object that may be placed against it.
- 4. When replacement parts are required, be sure they meet the specified requirements of the manufacturer. Unauthorized substitutes may result in a fire, electrical shock, or other hazardous situations. After any repairs, please ask the service technician to perform a safety check to determine that the sauna is in good working order.
- 5. Do not use any wall receptacle adapter, surge protector, or extension cord between the sauna cord and wall outlet.

Troubleshooting

	Issue	Possible Reason	Solution
1	indicator light for power	The connector is not connected	Check the connector or replace a
	supply not working	properly	new one
		No power supply input	Check your circuit breaker to
			confirm power at the wall outlet
		Indicator light is broken	replace the circuit panel
2	Indicator light for	The heating indicator light is	Replace the relevant control panel
	function is not working	broken	

wire is not connected sung and tight The temperature sensor is broken check the connection of the temperature sensor The circuit board or the relay is not replace the circuit board working Power supply problem Power supply may need to be replaced Light bulb is not working Light bulb is burned out replace it Light bulb wiring is loosen Check connection and/or replate the lamp assembly Problems with electrical control panel Sauna is not powering up Power cord is unplug Plug the power cord into wall outlet Outlet has no power Check your circuit breaker to confirm power at the wall outlet GFCI protected outlet/circuit breaker is not recommended with non-GFCI ones The temperature display shows "EP" Sensor is loose, not connected, or sensor is damaged The temperature display shows "H" The temperature inside the sauna room is too high The speaker wire is loose The speaker wire is loose Disconnect and reconnect the speaker connections			The circuit board or components are broken	Replace the circuit board
The wire junction or the heater's wire is not connected Check that the connections are sung and tight			The temperature sensor is broken	
wire is not connected The temperature sensor is broken The circuit board or the relay is not replace the circuit board working Power supply problem Power supply problem Power supply may need to be replaced Light bulb is not working Light bulb is burned out replace it Light bulb wiring is loosen Check connection and/or replate the lamp assembly Problems with electrical control panel Sauna is not powering up Power cord is unplug Up Power cord is unplug Plug the power cord into wall outlet Outlet has no power Check your circuit breaker to confirm power at the wall outlet GFCI protected outlet/circuit breaker is not recommended The connector of temperature display shows "EP" The temperature display shows "H" The temperature is loose The temperature is loose The speaker is broken The speaker wire is loose Disconnect and reconnect the same specifications The speaker wire is loose Disconnect and reconnect the speaker connections			The heater is broken	Replace heater panel
temperature sensor The circuit board or the relay is not replace the circuit board working Power supply problem Power supply may need to be replaced Light bulb is not working Light bulb is burned out replace it Light bulb wiring is loosen Check connection and/or replate the lamp assembly Problems with electrical control papenel Power cord is unplug Plug the power cord into wall outlet Outlet has no power GFCI protected outlet/circuit breaker is not recommended The connector of temperature display shows "EP" The temperature display shows "H" The temperature inside the sauna room is too high The speaker wire is loose The speaker wire is loose Disconnect and reconnect the same specifications The speaker wire is loose Disconnect and reconnect the same specifications The speaker wire is loose Disconnect and reconnect the same specifications Disconnect and reconnect the same specifications The speaker wire is loose Disconnect and reconnect the same specifications				Check that the connections are sung and tight
A			•	temperature sensor
The temperature display shows "EP" The temperature display shows "H" The temperature display shows "H" The speaker is broken The speaker wire is loose The connect and reconnect the speaker connect the speaker connections The speaker wire is loose The speaker connect and reconnect the speaker connect and reconnect the speaker connections The speaker wire is loose The speaker wire is loose The speaker connect and reconnect the speaker connections The speaker wire is loose The speaker connect and reconnect the speaker connections The speaker wire is loose The speaker connect and reconnect the speaker connections The speaker wire is loose The speaker connect and reconnect the speaker connections The speaker wire is loose The speaker connect and reconnect the speaker connections The speaker wire is loose The speaker connect and reconnect the speaker connections The speaker wire is loose The speaker connect and reconnect the speaker connections The speaker wire is loose The speaker connections The speaker wire is loose The speaker connections The speaker connect			working	•
Check connection and/or replate it	4 Oo	Odor from the sauna	Power supply problem	
the lamp assembly Problems with electrical control panel Sauna is not powering up Power cord is unplug Outlet has no power GFCI protected outlet/circuit breaker is not recommended The connector of temperature display shows "EP" The temperature display shows "H" The temperature display shows "H" The temperature display shows "H" The temperature inside the sauna room is too high The speaker is broken The speaker wire is loose The speaker wire is loose The lamp assembly Replace the relevant control panel Plug the power cord into wall outlet Check your circuit breaker to confirm power at the wall outlet Replace the outlet/circuit breake with non-GFCI ones Disconnect and reconnect the connector of temperature sens or change to a new temperature sensor Turn off the unit, and contact the manufacturer Plug the power cord into wall outlet Check your circuit breaker to confirm power at the wall outlet Check your circuit breaker to confirm power at the wall outlet Check your circuit breaker to confirm power at the wall outlet Check your circuit breaker to confirm power at the wall outlet Check your circuit breaker to confirm power at the wall outlet Check your circuit breaker to confirm power at the wall outlet Replace the outlet/circuit breaker to confirm power at the wall outlet Check your circuit breaker to confirm power at the wall outlet Check your circuit breaker to confirm power at the wall outlet Check your circuit breaker to confirm power at the wall outlet Check your circuit breaker to confirm power at the wall outlet Check your circuit breaker to confirm power at the wall outlet Check your circuit breaker to confirm power at the wall outlet Check your circuit breaker to confirm power at the wall outlet Replace the outlet/circuit breaker to confirm power at the wall outlet Replace the outlet/circuit breaker to confirm power at th	5 Liç	ight bulb is not working	Light bulb is burned out	Remove burned out light bulb and replace it
Fower cord is unplug and the power cord into wall outlet and power condition wall outlet and power confirm power at the wall outlet and power confirm power cond into wall outlet and power confirm power at the wall outlet and power confirm power and power confirm power and power confirm power and power confirm power				Check connection and/or replace the lamp assembly
up Outlet has no power Outlet has no power Check your circuit breaker to confirm power at the wall outlet Replace the outlet/circuit breaker is not recommended The temperature display shows "EP" The temperature sensor is loose, not connected, or sensor is damaged The temperature display shows "H" The temperature inside the sauna room is too high The speaker is broken Replace the outlet/circuit break with non-GFCI ones Disconnect and reconnect the connector of temperature sens or change to a new temperatur sensor Turn off the unit, and contact the manufacturer Replace with a new one of the same specifications The speaker wire is loose Disconnect and reconnect the speaker connections			panel	Replace the relevant control panel
Confirm power at the wall outlet				outlet
The temperature display shows "EP" The temperature display shows "EP" The temperature display shows "H" The temperature sensor is loose, not connected, or sensor is damaged The temperature display shows "H" The temperature inside the sauna room is too high The speaker is broken The speaker wire is loose Disconnect and reconnect the connector of temperature sens or change to a new temperature sensor Turn off the unit, and contact the manufacturer Replace with a new one of the same specifications The speaker wire is loose Disconnect and reconnect the speaker connections			·	confirm power at the wall outlet
display shows "EP" sensor is loose, not connected, or sensor is damaged The temperature display shows "H" The temperature inside the sauna room is too high The speaker is broken Speaker does not work The speaker is loose The speaker wire is loose Disconnect and reconnect the speaker connections			breaker is not recommended	with non-GFCI ones
display shows "H" room is too high manufacturer Speaker does not work The speaker is broken Replace with a new one of the same specifications The speaker wire is loose Disconnect and reconnect the speaker connections			sensor is loose, not connected, or	connector of temperature sensor or change to a new temperature
The speaker wire is loose Disconnect and reconnect the speaker connections			•	Turn off the unit, and contact the manufacturer
speaker connections	9 Sp	Speaker does not work	The speaker is broken	Replace with a new one of the same specifications
			The speaker wire is loose	
is off				Turn on the switch to start work
10 Radio Player doesn't work Power connector is loose or damage Disconnect and reconnect the connection		-	damage	connection
DC power supply has no power to the radio player Check DC power supply replace the power supply				Check DC power supply wiring or replace the power supply
Radio player is defective Replace the CD-player			• •	
Radio player protection fuses is burnt out Replace the fuses				Replace the fuses

1. The Glass Door Is Rubbing The Door Jamb

Solution: The glass door may need to be adjusted. To adjust the glass door, you will need two pieces of cardboard like in the image below. The below images are from our more common sauna models. Please do note that you will need two people for this task. For the second person who will be holding the glass door, we recommend wearing protective gloves. Start by having the glass door slightly open and the first person loosening the hinge screws on the glass door. Only loosen the screws slightly so that the door can adjust itself once it is closed. Next, the second person will close the glass door. You may need to lift up on the door handle to get the door to shut all the way. Now cautiously retighten the hinge screws on the glass door. The screws must be tight.







Maintenance:

Cleaning

Do not use liquid cleaners or aerosol cleansers inside the sauna. Unplug the sauna from the wall outlet before cleaning. Use plain water and a soft cloth for cleaning. Do not use benzene, alcohol, or strong cleaning chemicals in or on the sauna. NOTE: Any chemical that can damage wood or be absorbed into the wood will damage the sauna.

Transportation and storage

- 1. Avoid exposure to rain, snow or other strong weather elements.
- 2. Do not store in damp environments.

Limited Lifetime Warranty

5 Year Limited Warranty: Golden Designs, Inc. under its brand names warranties the wood, structure, heating elements, and electronics against defects in material and workmanship for a period of 1 to 5 years from the original date of purchase. This sauna is for INDOOR use only. Placing your sauna outdoors will VOID this warranty. Any damage due to exposure to outdoor elements such as rain, snow, sun, wind or extreme temperatures will not be covered by this warranty. Any damages as a result of modifications made to the sauna or its components will void this warranty.

Extent of Warranty: This limited warranty applies to products manufactured or distributed by Golden Designs, Inc. under its brand names, delivered in the continental United States or Canada and extends to the original purchaser at the original site of installation only. This warranty becomes valid at time of purchase and terminates either by specified time frame listed above, owner transfer, or relocation. **Your sales receipt showing the date of purchase of the product is your proof of purchase. Warranty is not transferable.**

Manufacturer Warranty

All Golden Designs, Inc. products are manufactured with the highest quality appliances and are warranted to be free from defects in material and workmanship at the time of delivery. The appliance warranty is extended through the manufacturer for the product including, but not limited to: stereos, CD players, etc. All exchanged parts and products replaced under this warranty will become the property of Golden Designs, Inc. Golden Designs, Inc. reserves the right to change manufactures of any part to cover any existing warranty. Any parts determined to be defective must be returned to Golden Designs, Inc. to obtain warranty service. You must prepay any shipping charges, export taxes, custom duties and taxes, or any other charges associated with the transportation of the parts. In addition you are responsible for insuring any parts shipped or returned. You must present Golden Designs, Inc. with proof of purchase documents (including the date of purchase). Any evidence of alteration, erasing or forgery of proof of purchase documents will be cause to **VOID** this limited warranty. Products on which the serial number has been defaced or removed is not eligible for warranty service. This warranty covers parts, but does not cover labor.

Warranty Limitations

This warranty does not apply if the unit has been subject to full commercial use, negligence, alteration, modification, misuse, abuse, repairs by non-Golden Designs, Inc. authorized personnel, inappropriate installations, or any case beyond the control of Golden Designs, Inc. invalidating this warranty including but are not limited to:

- Use of lacquer or paints
- Sauna and other Golden Designs, Inc. products accessories placed on nonapproved surfaces
- Outdoor applications
- Normal wear and tear or weathering
- Use of product not in accordance with instructions
- Worn out receptacle

Surface cracks are not considered defects in material or workmanship, as they are normal characteristics of all woods. This includes minor cracks due to wood expansion and contraction. Note: Since the wood used in construction has been kiln dried, a certain amount of expansion and contraction occurs in the wood in a sauna environment.

Disclaimers

Golden Designs, Inc. and its affiliates shall not be liable for loss of use of sauna or other Golden Designs, Inc. products or other secondary or incidental or consequential costs, expense or damages - which may include the removal of permanent deck or other custom fixtures or the necessity for crane removal - arising directly or indirectly out of the use or inability to use the product. Any implied warranty shall have duration equal of the applicable warranty stated above. Under no circumstances shall Golden Designs, Inc. or any of its representatives be held liable for injury to any person or damage to any property, however arising. Specifications are subject to change without notice or obligation.

Legal Remedies

This limited warranty gives you specific legal rights. You may have other rights, which may vary from state to state.

Customer Service

For customer service, contact your authorized dealer. If you need additional information or assistance, please email Golden Designs, Inc. at info@goldendesignsinc.com or call (909) 212-5555.

^{*}Limited Lifetime Warranty of Sauna Products is 5 years on heating elements and electronics from the date of purchase. The radio and wood structure have a 1 year limited warranty.

WARRANTY CARD

Congratulations on your purchase of an Infrared Sauna from Golden Designs, Inc. Please take the time to complete the following Warranty Card and mail it back to:

Golden Designs, Inc. 3550 Jurupa Street, Unit B Ontario, CA 91761

Please include a copy of your sales receipt showing date of purchase as this will serve as proof of purchase.

Warranty will be VOID if the following warranty card is not mailed back within 60 days of purchase date along with proof of purchase.

Serial number (S/N) is located on the sauna's front panel, rear panel, or on the carton.

DETACH HERE

	WARR	ANTY	CARD	
All fields must be completed	d to validate t	the warra	anty.	
Name:	_			
Address:				
City:	State:	Zip	Code:	
Phone Number:				
Purchase Date:				
Purchase From:				
Serial Number:				