# **GPS Tracking System User Guide**

2020-6-23

V 2.2

# Contents

GPS Tracking System User Guide	
1. Overview	4
2. Architecture	4
3. Conventions	4
3.1 Italic Text	4
3.2 Bold	5
3.3 Tips	5
3.4 Note	5
4. Features	5
4.1 Login/Logout	5
4.1.1 Login	5
4.1.2 Logout	7
4.2 Settings & Alerts	7
4.2.1 Settings	8
4.2.2 Mail Push Settings	9
4.2.3 Alerts Settings	10
4.3 Mi Coins & Statistical	15
4.3.1 My Wallet	15
4.3.2 Account Details	18
4.3.3 Messages	19
4.3.4 Commamd	19
4.4 Device Management	21
4.4.1 Import Device	21
4.4.2 Searching Device	22
4.4.3 View & Edit Device	24
4.4.4 Move Device	30
4.4.5 Export Device	31
4.4.6 Send Command/Set Working Mode.	33
4.4.7 Enable/Disable Device	39
4.5 Account Management	40
4.5.1 New Account	41
4.5.2 Edit Account	43
4.5.3 Delete Account	44
4.5.4 Reset Password	45
4.5.5 Move Account	45
4.5.6 Export Account	46
4.5.7 Virtual Account	46
4.6 Monitor	47
4.6.1 Objects	50
	54
4.6.3 Map	55
4.6.4 History	60


4.6.5 Tracking	65
4.6.6 Places	66
4.7 Report	71
4.7.1 Device Overview	73
4.7.2 Battery	74
4.7.3 External Battery	74
4.7.4 Fuel Consumption	75
4.7.5 Temperature	75
4.7.6 Driving Behavior	76
4.7.7 Moving Overview	77
4.7.8 Trips	78
4.7.9 Overspeed	79
4.7.10 Parking	79
4.7.11 Idling	80
4.7.12 Ignition	80
4.7.13 Offline	81
4.7.14 Online	81
4.7.15 Alert Overview	82
4.7.16 Alert Details	83
4.8 Video	84
4.8.1 Event Video	84
4.8.2 Live	85
4.8.3 History Video	87
4.8.4 Setting	89
4.9 Fleet	89
4.9.1 Dashboard	90
4.9.2 Driver	90
4.9.3 Vehicle	93
4.9.4 RFID History	96
4.9.5 Route Planning	97
4.10 Advanced Search	99
4.10.1 Search Device	99
4.10.2 Search Account	103
4.10.3 Search APP User	107
4.10.4 Search Device by License Plate No.	108
4.11 Help	108
4.11.1 Feedback	109
4.11.2 Business Log	109
4.11.3 Login logs	
4.11.4 Release Note	110
4.12 Command Management	111
4.12.1 Working Mode Template	
4.12.2 Batch working mode	
4.12.3 Working Mode Status	114

4.12.4 Batch Command	114
4.12.5 Command Status	115
4.12.6 Command Template	115

# 1. Overview

A GPS tracking platform, all-in-one solution for tracking, support IOS & Android mobile Apps, can work in any country, 15+ languages. Including tracker/DVR devices management, account management, Geo-fence, alerts, real-time tracking & playback, video ,report etc.

# 2. Architecture



# 3. Conventions

# 3.1 Italic Text

Text format as italic indicates this is a field name or terms in this tracking platform.

User might need to input *Captcha* if account or password was incorrect for more than 3 times. Password can be retrieved by email if forgot it.

# **3.2 Bold**

Some text formatted as bold to emphasize the information.

# **3.3 Tips**

Tips given for user to know how to use this tracking platform better. It's marked with tips icon, and uses a smaller font size, for example:



To expand the visible area, user could click fold/unfold on top or collapse/expand button on the right of panel.

### 3.4 Note

Remind user to pay attention to some operations, It's marked with note icon, and uses a smaller font size, for example:




Demo account or virtual account only has *Logout* menu item. Only distributor has *Mail Push Setting*. Account which has no recharge card will not show the card balance.

# 4. Features


# 4.1 Login/Logout

### 4.1.1 Login


Platform account can not be registered online, it should be got from Distributor or customer services. The initial password for account is 888888, user should change it after first login.




User might need to input *Captcha* if account or password was incorrect for more than 5 times. Password can be retrieved by email if forgot it.



System provide a *Demo* account to preview full features of this platform. More than 15 language are supported.




Scan QR Code to download corresponding Apps.



# **4.1.2 Logout**

To logout system, just click *Logout* in *Settings* on the header.



# 4.2 Settings & Alerts

Settings contain some common features like Settings, Messages, My Wallet, Command, Help, Mail Push Setting

Mail Push Setting is used to configure distributor's own SMTP, system sends mail via this SMTP server rather than system default SMTP server if a SMTP host configured.






Demo account or virtual account only has Logout menu item. Only Distributor has Mail Push Setting.

### 4.2.1 Settings


### My Profile

My Profile includes configurable fields like time zone, account nick name (Customer Name), phone number, email, Google key, Default Map, Homepage. All time stores in database are by UTC(GMT) time, system converts to local time by this time zone setting. If user time zone is not set, it will be replaced by the time zone of browser.






System pops up a window and ask user to set time zone if user haven't set yet. If the time zone of user's browser is not identical to user setting time zone, a window will pop up for user to choose it.



# 4.2.2 Mail Push Settings

Some distributor request to sending email by their own SMTP server rather than default one, therefore, system provide a mail push setting for customize this information. System gets the closest superior account mail push setting as the SMTP server while sending mails.

Generally, *SMTP Auth* is required, *Username* is equal to *Mail From*. The default SMTP port is 25, but 465 for SSL.




⚠ Note

To guarantee SMTP setting is valid, recommend to send a test mail after finish configuration. Otherwise, you might not able to get email notification while tracking device alerts rise.

### Change Password

The initial password is 88888, user should change it after first login. New password should contain letter and number, 6+ length.




### Model Name Alias

Distributor could give their tracking devices an alias mode name, all customers of this Distributor will see the alias mode name rather than default model name in entire platform, this is good for Distributor sell product in the market.




### Virtual Account

User could create multiple virtual account for current account, and specify different access permissions for it, this helps team members to cooperate with the same account. Virtual account is not a real account, it's an alias account with different access rights.




# 4.2.3 Alerts Settings

The alert information is displayed in the Events bar on the Monitor page, it indicates whether existing unread alerts for current login account, click the icon to view details. Can mark as read or remark this alert.



Click the corresponding Alert can view device details.

- Mark all as read all alerts status become read the alarm no longer flashing.
- Enable alarm sound play the sound while new alert coming.
- Mark as read make selected alert as read.
- **Process** add a remark information for selected alert.




:Exist unread alerts

:All alerts are read

To receive alerts, user should switch them on in Alert Settings according to the alert type.

### **Basic Settings**



**Offline Alert Time** - the threshold for offline alerts, if device offline more than the specified time system will generate an alert.

**Stay Alert Time** - if user enable a stay alerts (Long time not enter/exit a Geo-fence), device stay in associated Geo-fence more than this threshold will generate a corresponding alert.


**Iding Alert Time**-the threshold for Iding alerts, if device iding more than the specified time and speed no more than the threshold will generate a corresponding alert.


Synchronize to Sub-account - sub-account have the same setting as current login account.

View Sub-Account Alerts - alerts from sub-account will also displayed in current account's alert list.

# **Push Settings**


User enable the alert by check the corresponding alert type, if email address is configured, system will also send a notification by email, support to set multiple email address. Web Alert and App Alert are depends on the same switch.






### **Alert sound**


Customize alert sound, upload audio file and enable alert sound






Some alert type might marked as *terminal* or *platform* with parentheses, this indicates the alert generates source, terminal represents alert is from tracking device, platform means alert is calculated in platform and alerts is sent by platform, for example, *Overspeed alert(platform)*, if user configured *Overspeed Threshold* in *Device Detail* as 100km/h, then if the calculated speed is more than 100km/h, platform will trigger an alert. However, the threshold of *Overspeed alert(terminal)* is configured by sending command to device.





Cancel




# 4.3 Mi Coins & Statistical

# 4.3.1 My Wallet


Display the current amount of Mi Coins, and provide the entry of Mi Coins currency recharge and transfer

Several searching criteria are also provided for user to search the Mi Coins used results , like *Operation Time, Account, IMEI* .




# Import device

Import tracking devices to platform and start to use. User can import devices by Mi Coins. To import devices manually, click Import Device button, fill the required fields in the pop up window and click save button, note that IMIE is support multiple, one IMEI for each line.




### Renew device

Renew expired device, fill in the Service Type and device IMEI.




# Transfer Mi Coins

Transfer the Mi Coins from one account to another



### Messages

Messages gives the information of devices offline and expired.




### 4.3.2 Account Details

### 4.3.1.1. Device Overview




- Sub-account devices: Check the sub-account Settings, Including statistics of the total number of sub-accounts and inventory, device status, etc
- Stock: show the quantity of all devices under current login account, not include devices from sub-account.
- Total: quantity of all devices under current account and its sub-accounts. Click to view the devices list.
- **Expire Soon/Expired:** Counts all expiring and expired devices of current account and sub-account. System navigates to *Device* page to show the detail devices.
- **Activated/Inactivated**: Calculates quantity of all activated and Inactivated devices (Device is activated when first GPS coordinate uploaded to server), click it to navigate to *Device* page to show the detail devices.



- Increased: Calculates quantity of new imported devieces.
- Activated: Calculates quantity of increasing active devices.
- Year/Month: calculates according to different year and month

# 4.3.3 Messages

System searches devices that is offline more than 3 days or to be expired in 15 days on schedule, and send notifications to user by mail(if mail address is provided in Account). Meanwhile, they are also displayed in this message box. All unread messages can be mark as read.



### 4.3.4 Command


# 4.3.4.1 Working Mode Template

It's a template for set GPS data packet uploading frequency. See Working Mode for more details.

# **Create Template**

Click Create Template to add a new working mode template.






# **Edit & Remove Template**




### **Command**

Fill device(s) IMEI and Click Send Command send working mode command to device.



# 4.4 Device Management



Device management includes following features:


- Import devices import tracking devices to platform and start to use. User can import devices by license code or by recharge card.
- Searching devices search devices by different filter conditions. User also can find the
  expiration of devices by the Expiration tab.
- View & edit device view and edit tracking device information, including basic information, other information, alert setting by device. System also support to edit records by download Excel file and upload it to update devices, *Upload Images* is a function to upload installation images in bulk, *Set Fuel Tank Vol.* allow user to set fuel tank volume for batch devices. *Update User Expiration* is a feature to update user expiration date of sub-account's devices in bulk.
- Move devices *Bulk Sell* support user to move multiple devices to sub-account.
- Export devices Export selected devices or all devices(matching searching criteria) to Excel
  file.
- Send Command/Set Working Mode Synchronize command or working mode to devices.
- Enable/Disable device To stop or resume device using in platform.
- Recharge devices Renew devices effective time in system, user can renew device by license code or recharge card.

### 4.4.1 Import Device

To use tracking device in platform, user need to import them first. Import devices to system manually by Mi Coins

### By Mi coins

Import devices by Mi Coins if you already have purchased it, otherwise you can't import devices, select the application target, model and fill in IMEI of devices, click OK button to import devices.






If system prompt a message that AMS validation error, you might need to double check with your superior user or customer services to make sure the IMEI is a valid one and exits in a system called AMS.

### 4.4.2 Searching Device


System provides simple and advanced search to help user find devices. Expiration tab is another way to find devices according to expiration date.



### Simple Search

Simple search including following criteria fields: *IMEI* (support multiple IMEI), *Device Name*, *Model*, also provide a checkbox *Sub-account devices* to include devices of sub-account.






You can provide multiple IMEI of devices at one time, break to new line to separate them. User can also search a device by typing the last 5 digital of IMEI.

### Advanced Search

Advanced search allow user to search devices by several additional query criteria.



License Plate No. - Plate Number of associated vehicle(or other type target).

VIN - Vehicle Identification Number.

**SIM** - SIM card number if user specified.

Application - target of tracking device attached.

Activated Date - Searches devices by activated date range (start time to end time).

**Expiration Date(P)** - Searches devices by Platform expiration date range.

**Expiration Date(U)** - Searches devices by User expiration date range.

### **Expiration Criteria**

**Expiring Soon** - Gets devices which platform expiration date will expiring soon.

**Expired** - Gets devices which platform expiration date have been expired.

**Expiring Soon(User)** - Get devices which user expiration date will expiring soon.

**Expired(User)** -Get devices which user expiration date have been expired.



**Platform Expiration Date** - indicates how long the devices can be used in this platform, depends on the years specified when import or renew a device, no matter which account the devices belongs to.

**User Expiration Date** - each account associate with the device can be set a user expiration date, superior account can change the user expiration date of devices for sub-account. User Expiration Data help Distributor controls expiration date of devices for sub-accounts.

### **Activation State**

Search activated or inactivated devices

### **Bound State**

Search devices which have been bound by App or not.

### Model

Search devices which is powered by battery or cable.

### Groups

Search devices by device group.

### Expiration Search


Search devices by the expiration criteria. User can specify searching criteria like: platform expiration date or user expiration date, expired or expiring soon and the number of days. The searching criteria in the left is used to find accounts, however, the top one are used to filter devices. Then user can export all recorder.




### 4.4.3 View & Edit Device

System list all devices by default in the data grid, display matching results with pagination. User could view device details on the pop up window by click the IMEI link or do other operations at


the last column of each row. The account tree on the left shows the account list, including devices quantity of account(Stock/Total).








You can collapse/expand the account tree one the left to expand the visible area of main content.



We'll look into each operations of device in the following sections.

### Edit

The pop up window of Edit device contains 3 tabs: Basic Information, Other Information, Alerts. **Basic Information** 




Some fields in basic information tab is editable, some fields are not, check the following list:

Field Name	Editable	Description
Device IMEI	No	Unique number for tracking device.
Model	No	Device model.
Device Name	Yes	Give a name for device, the default device name is model name + last 5
		digital of IMEI, for example AB310-17219
SIM	Yes	SIM card number from mobile network.
Group	Yes	Device group, user can add group in Monitor page.
Activated Date	No	The date of first GPS data packet upload to sever.
Application	Yes	Device application target, like a car or a cow.
Expiration Date(P)	No	Platform Expiration Date, it cannot be changed except import or

		renew(recharge) device.
ICCID	No	Automatically update by device.
IMSI	No	Automatically update by device.
Sales Time	No	The time devices sell from superior account to sub-account.
Import Time	No	The time devices imported to system.
Expiration Date(U)	Yes	User Expiration Date, User is not allow to change expiration of his own
		devices(stock devices), but is able to specify it for sub-account. User
		Expiration Date of sub-account should not later than superior account.
Allow Bind User	Yes	Check it to enable binding this device by App. Uncheck it to unbind the
		App user and not allow App user to bind it.
Remark	Yes	Add additional information for this device.
Fuel Tank Information	Yes	Select a shape type of fuel tank and provide the parameter for it. This
		will affects the Fuel Consumption Report and Fuel information upload
		by device.

### **Other Information**

System provides some additional fields for user to record relative information, like driver's information, vehicle information, installation information, user could add it on demand, system will not validate the input value, only save and display it as what user inputted.



# **Alerts**

Some alert type can be configured by device level, like Overspeed alert, maintenance alert, night driving alert.

# Overspeed alert

# Speed Threshold & Duration

For instance, if speed threshold is 100km/h, duration is 10s, that means if the device's average speed in 10 seconds is above 100km/h, system recognizes it as over speed, and will send an Overspeed alert(platform).

### **Maintenance Alert**

There are two types maintenance alert: Mileage and ACC-ON Duration.




As the example figure above shows, if current mileage is times of Mileage Threshold(2000km), like 202000km, 204000km, 206000km...., system will generate an alert to current user.


ACC-ON Duration can be used to send reminder if device engine on for a specific hour, for example, an excavator engine if it worked for 1000 hours, system send out an alert.

### **Night Driving Alert**

If device is moved during the configured time range, system generates an alert. Please do not specify a time range cross day, for example, 18:00 - 05:00(second day) will not works, you should convert to two time range: 18:00 - 23:59 and 00:00 - 05:00.



### Sensors



### Analog input(ADC)

If the device is connected to an external sensor, including the detection of external voltage and capacitive fuel sensor, the corresponding setting should be selected. If user want to display the percentage of external power, you need to set the rated voltage of the battery

Analog Input (ADC)



### Serial port (TTL/RS232)

If the device is connected to an external sensor, including temperature sensor/ultrasonic fuel sensor, and the connect way by serial port, the corresponding setting should be selected.

# Please choose serial port sensor type : Please select... Please select... Temperature sensor Ultrasonic fuel sensor

### More Actions

### Sell

The essential of sell devices is move devices from current account to sub-account, Distributor settles with his customers offline and move devices to his/her account.

### Monitor

Navigate to **Monitor** page and monitor this device. See <u>Monitor</u> for more detail.

### **Playback**

Navigate to Monitor page and get the last trip of device to playback. See Playback for more detail.

### **Trips**


Navigate to Monitor page and list all trips. See <u>Trips</u> for more detail.

### Command

Send command to selected device, see **Send Command/Working Mode** for more detail.

### **Geo Fence**

Show associated Geo-fence, user can delete the association by click the delete link.



### **Alert**

Navigate to Alert Details Report.

### 4.4.4 Move Device

Devices can be moved from one account to another by features like *Rapid Sale*, *Sell*, *Bulk Sell* or *Move Device*. These operation usually happen between Distributor and his customers, after create an account for customer, Distributor might need to move devices to customer's account.


Distributor(superior account) is able to specify an effective time for the moved devices, this time will become user expiration date for the customer's account associate with those devices. The specified user expiration date should not large then Distributor's effective time, once customer's devices expired, they could ask Distributor to extend the effective time for them.


Devices can be move in bulk if user provide multiple IMEI at one time.

### Sell/Move

Select devices or enter IMEI and click Add button to figure out which devices you want to move, specify effective time to determine how long these devices can be used by the target account, select target sub-account on the right and click Sell button to complete this operation.

Click *Delete* link to delete selected device entry. Click *Clear* button to remove all devices added.








No limitation(Not Set) means that user expiration date for the target account associate with those devices is not set, system regards it equals to the user expiration date of superior account.

# 4.4.5 Export Device

User can export devices to Excel. System support to export selected devices and export all query results devices. The maximum rows is 5,000.


### ■ Export

Select the devices you want to export(system will highlight them), then click *Export* button, system download the Excel in your browser.






User can select more than 20 rows by changing the page size of query result.



### ■ Export All


Click Export All to export all devices of current guery results.







If you want to export devices include sub-account's, check Sub-account devices, then click Export All button.



# 4.4.6 Send Command/Set Working Mode

System allow user to send supported command or set working mode to device by internet. If device is online, it will be executed immediately and return the results, however, if device is offline, the command will be stored and executed after device online next time, this is called pending offline command, system support only one offline command, it will be overwritten by subsequent offline commands.

Set Working Mode is a special command for some devices to change frequency of uploading GPS packet. For example, an asset tracking device might need to change the frequency.

# 4.4.1.1. Send Command


Commands in platform can be divided into two types: predefined command and user defined command.

### **Predefined Command**

Command are configured by several command type, user can select one of them, subsequently, system will list all available commands by tab, each tab is a command, each command might have several parameters, user inputs or select the parameter value and click button to send command, see below figure for example.

The bottom data grid lists the selected device's support for current command. *Pending Command?* 

indicates whether existing pending offline command that we mentioned in previous section.






Command will be ignored if devices do not support it. Pending offline command will be overwritten by new offline command.


### **User Defined Command**

Users can send command which not defined in platform by select *User-defined* command type and input the command content manually, for instance, command 'version#' will return version information of device firmware. In some cases, the password of current login account should be provided for security reason.




There are server entrance to send command individual or in bulk, see following example:


### a. In device list, click More -> Command




### b. Monitor



### c. Advanced Search




d. Device list, select devices and click Send Command button to send command in bulk.



# 4.4.1.2. Set Working Mode

Set Working Mode is a feature to configure device packet uploading frequency, it can be set by different mode, like Timing Mode, Week Mode or Normal Mode. Event more, the working mode can be set as template and combines multiple frequency settings.




#### **Timing Mode**

Device uploading frequency will be set to repeat by m day n times, for example if m = 1 and n = 12, that is identical to upload GPS packet every 2 hours(12 times for 1 day), some asset tracking device like logistics tracking device might be used to track oversea cargo shipping, the frequency of uploading GPS packet can be set to one or two days for each data packet uploading, this is beneficial to the saving of battery power.

**Sync Time1:** the start time of this frequency setting.


Limitation: how long devices upload GPS packet according to this frequency setting.



#### **Week Mode**

Set device uploading frequency of GPS packet by weekday.


**Sync Weekday**: the weekday of uploading GPS packet. **Sync Time**: the time of weekday to upload GPS packet.




#### **Normal Mode**

Actually, this mode is same as Timing Mode, can be used to set the frequency of uploading GPS packet by an interval.

Wake Up Time: The first time device upload GPS packet according to this frequency setting. Sync Interval: the interval of uploading GPS data packet, minimum is one hour, maximum is 15 days.



After working mode template was created, user could select the target devices to send working mode like send command in bulk, the field *Support?* in the datagrid shows whether selected devices support working mode or not.




# 4.4.7 Enable/Disable Device

In a few cases, user probably want to disable devices of sub-account for some reason. The disabled device will not able to monitor, track device, or playback tracks until superior account enable it.

#### Disable Device

To disable devices, select devices and click *Disable* button, system will ask user to confirm it, Click *Yes* to disable devices, click *No* to cancel current operation. A disabled device will have no other actions for *More* link at the end of each row.






Expiration Date(P)	Expiration Date(U)	Status
2020-12-06	2020-12-06	Disabled
2018-12-06	2018-12-06	Disabled
2018-12-06	2018-12-06	Disabled
2038-12-06	2038-12-06	Disabled
2037-11-07	2037-11-07	Disabled
2038-09-29	2018-09-29	Disabled


#### ■ Enable Device

To resume devices which have been disabled, just select devices and click *Enable* button.



# 4.5 Account Management

Since this tracking platform does not provide account registration online, a new account should be created by superior user. Usually, Distributor create sub-account for his customer, lower level Distributor create sub-account for his customer recursively. For example, Distributor A sell tracking devices to B, B is also a Distributor, B sell products to End User C, in this case, A will create account for B, B create account for C.



**New Account** - Creates a new sub-account, which superior account is the current login account. **Account Search** - Search account on the account tree on the left, or search it by role.

Operations	lcon	Description
Tracking	<u>Q</u>	navigate to Monitor page, locating to user's current position on
		the Map.
Edit		Edit account information.
Delete	Ŵ	remove account.
Reset Password	6	reset password for selected sub-account.
Move		move account to another account.

### 4.5.1 New Account

Create a new sub-account for current login account.

There are four account types in system:

**Sales** - an account type for sales in this tracking platform, sales account is able to create sub-account like Sales, Distributor, Enterprise user and End User.


**Distributor** - This account type can create Distributor, Enterprise User and End User sub-account. Can manage, sell/move devices to sub users, but can't use as enterprise user;


**Enterprise user**- This account type can create Enterprise user and End User sub-account. It's a collection of company or department level administrators, can manage all sub accounts and devices, and has access to Enterprise Specific Section;

**End User** – This account type can't create sub-account, Can only manage and monitor single or multiple devices;



- 1 .Distributor and End User can be changed to Enterprise User, and after being changed to Enterprise User, Can't change to other roles.
- 2 .Enterprise user can't change to other roles.
- 3. If Distributor have their own Fleet, can create a new Enterprise user account, transfer the device to this account, and use this new Enterprise user account to manage their own Fleet.
- 4. The Enterprise Specific Section include: Fleet (Fleet functionality can only be used by Enterprise user. The hierarchy from highest to lowest is: Sales->Distributor->Enterprise user->End user. Superiors can modify or create sub-account, as Distributor can change its subordinates to enterprise User .when role is modified to Enterprise User can use Fleet, and the sales or administrator role can also enter the Fleet page).





## **Superior Account**

Default to current login account, user is able to change it at the account tree one the right.

### **Account Type**

Radio options are Sales, Distributor, Enterprise user, End User. The radio options will changes according to account type of selected superior account.

Sales - available options are Sales/Distributor/ Enterprise user /End User

Distributor - available options are Distributor/ Enterprise user /End User

Enterprise user - available options are Enterprise user/End user

**End User** – only manage and monitor single or multiple devices;

#### **Customer Name**

A string with length of 3-50 characters.

#### **Login Account**

The username you login system, recommend that not contains blank in the middle of string, allow to include some special character like @ and ., that means email address is supported.

#### **Password**

For security reason, password not allow less than 6 characters, and must be a combination of letters and numbers. The default password is 888888, if not specify an password, the new created account should change it after first login. On the contrary, system will not ask for change password if provided it while creating account.

### **Confirm Password**

This field should match previous entered password.

#### Telephone

Phone number.

### **Email**

Email is required, if user want to retrieve password if forgot it. System also will send some notifications like expiration or offline information of device to this email address.

#### **Contact Person**

The contact person will be shown as Service Provider in Dashboard of sub-account.

## **Company Name**

Company name of sub-account.

Note that Customer Name, Account Type, Contact Person as well as Telephone of current account and super-account will be displayed in the Dashboard.

### **Permissions**


Permissions	Description
Web Login	Created account is able to login platform by Web.
App Login	Created account is able to login from Android or iOS Apps.
Send Command	Created account is allowed to send command to devices.
Set Working Mode	Created account is allowed to set working mode for devices.
Edit by Web	Created account is able to save data in platform.
Edit by App	Created account is able to save data through Android or iOS Apps.



The scope of permissions inherited by sub-account is equal to permissions superior account have, that is, some permissions probably not available for sub-account if his superior account did not have these permissions


### 4.5.2 Edit Account

User can change account after created it, Note that Login account is not editable. System also shows an additional.




#### 4.5.3 Delete Account

If account have no sub-account or tracking device, it can be removed, otherwise, it's not allow to remove. System will ask user for double check this operation before delete it.




### 4.5.4 Reset Password

User is able to reset password for sub-account if he/she forget password. The default password is 888888, sub-account should change the default password after login system.




### 4.5.5 Move Account

Move account help user to reorganize accounts when business relationship changed. Note that after account moved the devices account associated, account permissions, as well as the quantity of recharge cards will not be changed.




Click the move user icon and select target account, then click Save button to finish this operation.



# 4.5.6 Export Account

Users can select accounts in batches and click export to export account information in batches




# 4.5.7 Virtual Account


Virtual account allows user to manage tracking devices among team members with an identical account. These virtual accounts are reference to the same account with different access rights as following:

Modify Data - able to add, edit and save data.

**Send Commands** - able to send command to device.

View report - able to see Report page.







# 4.6 Monitor

Monitor help user to locate devices quickly and view the status, position on the Map. User can select one or several devices to show target on the Map at the same time, and chose a device to tracking or playback tracks in a new browser window.

Platform provide various fast way to locate devices, find the devices from the account tree on the left, or directly input the IMEI on the keyword field. In addition, tracking devices can be organized by group or followed as favorite.





## **Account Tree**

The account tree in *Monitor* page is same as other page, user can search account fast by provide a searching keyword.

#### **Device List**

The middle section is the device list, which is divided into two groups, All and Following. *All* shows all devices of account selected on the left account tree. *Following* lists devices of current user followed.


There are 5 status for tracking device:

Moving - device is in moving state, display in Green color.

**Stop** - device is not running and speed is 0 or ACC is off but still have heart beat data packet uploaded to server, shows in Red color.


**Iding-** device is not running and ACC is on, still have heart beat data packet upload to server, show in Yellow color **Offline** - no heart beat data packet uploaded to server, displays in Gray color.


**Inactive -** not active, not ever upload GPS data packet to server, displays in Gray color.



## **Show history & Tracking**


A tracking device might have several trips within a period of time. Each trip can be playback on the Map. Playback is an operation to show current trip of tracking device with an animation from start point to end point according to the tracks. The coordinates of track can also be exported as KML. Both trips and playback support to search by time.





## **Tracking**


Tacking is used to monitor moving device real-time on the Map. System shows the tracks of start point to current point which device passed by.



# 4.6.1 Objects


Device list in *Monitor* page shows the devices of selected account on the left account tree(not include devices from sub-account). Devices are grouped and can be filtered by different status. User can check devices on the list to show it on the Map, each device support operation like

playback, tracking and so on, the icon color indicates the status of device, some additional information like battery might also be shown. If device is in moving state, speed will also be displayed, if status is static or offline, the time length will be shown.



#### **More Records**


System retrieves 200 devices initially, user can get other devices by clicking more button. Devices in *Online/Offline* tab are calculated base on the results of devices in *All* tab, if some devices are miss, you can click more button to loaded it.



## **IMEI Searching**

Provide an IMEI(full length of IMEI or last 6 digital) and click search button, system shows the

matching result in drop-down list.




## **Sorting Devices**

Sorting devices by different field.



# Create/Move/Edit/Delete Group

Add group for devices, the group name will also be displayed in devices list of *Device* page. Move group by clicking the menu item of each device in the list and select a target group.




Edit and delete group.




## Follow/Unfollow Device

A followed device shows a heart icon on the list, unfllow it the icon disappears.




## **Device Command**

A pop up menu item to send command individuality like *Command* in *Device* page. Refer to <u>Send</u> <u>Command</u> for more details.




#### **Device Detail**

Pop up a window to show device detail like Edit device in Device page. See Edit for more details.




#### **4.6.2 Events**


Record all alerts pushed to the platform under the current account.



# Filter alerts by searching for the different device model




### Alert push settings pls refer to Mail Push Settings



# 4.6.3 Map

#### **Map Popover**




Map popover shows some critical information for devices or target.

Field	Description
IMEI	Unique number of tracking device.
Device Name	Device name of tracking device.
Telephone	Driver's phone number.
External Voltage	Voltage of target like a Motorcycle.
Battery	Battery of tracking device.
Door	Door status which detected by tracking device.
Fuel	Fuel information for the target like a car.
ACC	Engine status of target
Speed	Speed of tracking device.
Location Time	The time of last uploaded GPS data packet.
Last Update	The time of last uploaded Heartbeat data packet.

# **Share Location**







- : Enlarge the map to full screen
- : Choose different map
- :Enlarge and narrow the map


### **Show Geo Fence/POI**

Check Geo Fence/POI to show the Corresponding area marked in *Geo Fence* page.




### **Find Vehicle**

Draw an area to find vehicles.



# **Google Street**

Click icon to view Google Street.



Live traffic



**Ruler**Click **Ruler** to measure distance between two points on the map.





# **Refresh Interval**



# 4.6.4 History

User is able to playback tracks of tracking device for a specified time range(maximum 7 days). Generally, system show the playback by tracks, however, for some model of device, it can be switch to dot. playback speed is adjustable, *Track Detail* shows the detail information of all coordinate on a bottom datagrid, and can be exported by Excel. A KML format file is also available for download.






### **Playback Searching**


The time length of tracks for playback can not large than 7 days under last 6 months, user select locating type and time range to find the tracks going to play. There are 3 Locating Type: GPS, LBS, WIFI, all of them will be retrieved by default. *Tracking Time* is a shortcut to select time range, if time range large than 7 days, *Search* button will be disabled. The matching tracks show as address of start point and end point below the *Search* button.

Search IMEI support user to change to another tracking device by input a IMEI. Collapse/Expand button is for display/hide the searching criteria. User also can search it by trips.




**Trips** 

Each tracking device might have several trips in a specific time range, for example, the figure below shows trips from 2018-04-01 00:00 to 2018-04-24 15:16 for device TR06-41965, the first trip are selected and tracks are shown on the map. Besides showing the address of start point and end point, each trip also shows total mileage and average speed as well as a *Playback* button. Click *Playback* button to playback the tracks of this trip. Trips can be searched in 30 days of last 6 months, if time range large than 30 days, the *Search* button will be disabled.



To expand the visible area, user could click fold/unfold on top or collapse/expand button on the right of panel.




### **View Tracks**

Usually, tracks are display as line path on the map, a few mode of device support playback by dots, system displays an addition button *Play by dots*, click it change to dots playback, click again return to line tracks playback. *Tracks* button toggle showing tracks on the map.

*Track Detail* shows information for all matching coordinates, including fields like Locating Time, Coordinate, Speed, Direction, Locating Type, Satellite(Quantity), Position. Click *Get Address* to parse address base on the coordinate. Check *Get All Address* checkbox to parse all address on the datagrid.









# **Export Excel/Export/Export KML**

Export Excel and Export button in Track Detail are function to export all coordinates which matched the searching criteria to an Excel.


KML is a XML format contains coordinates, click Export Kml to download Kml format file.





## **Show crossed Geo-fence/POI**

Check corresponding checkbox to show Geo Fence or POI on the map.




# 4.6.5 Tracking

Tracking is a function to monitor moving device. System shows device information real time, fields like IMEI, ACC, speed, locating time, address are shown on the left and display tracks on the map, they are updated by every 10 seconds in default.



## **4.6.6 Places**

Places use to create Geo Fence and POI




# **Geo Fence**

To create Geo-fence, just click *New* button and draw a circular or polygon area on the map, after that, system pops up a window for user to specify Geo-fence name and description. User can choose to save Geo-fence and assign devices at the same time or later on.


Geo Fence Alerts include following events:

- Enter Geo Fence
- Exit Geo Fence
- Long time not enter Geo-fence
- Long time not exit Geo-fence

### **Create Geo Fence**





### **Edit Geo Fence**



# **Assign Device**


To assign devices, click *Save & Assign Device* while create Geo-fence, or click *Assign Device* in the Geo-fence list.






# **Delete Geo Fence**






### **View Geo Fence**

Besides for rising an alert, Geo-fence can be shown on the map in *Monitor* or *playback* page.








POI is an area marked by user with a specified name, it can be displayed on the map in *Monitor* or *playback* page.


# **Create POI**

Click *POI* tab in *Geo Fence* page, click *New* button to create POI. Creation of POI is quite same as create Geo-fence, user draw a circular or polygon shape on the map and give a name and description for POI.

### **Edit POI**



## **Delete POI**



# 4.7 Report

Report includes Device Statistics , Motion Statistics, State Statistics, Alert Statistics, Logistics Statistics and Auto Report. Each Statistics contains several reports, Most of reports are support to Export Excel and Print.




Most of reports need to provide searching criteria before searching, there are share some common operation, takes *Trips* report for example:

Time range default to today, from 00:00 till current time, the options of time drop-down list are shortcuts to select a time range.



An account tree also provided to select account, once account is selected, devices associated to this account will be listed on the IMEI drop-down.

Some report may contains coordinates, if you want to get address rather than coordinates in the download Excel, please check *Address* checkbox.





- 1. To select all IMEI, just check *Select all,* system also support Shift + mouse click to select multiple IMEI. Devices will be order by alphabet order.
- 2. To search by known IMEI, firstly click Reset button to clear entered value, then paste the known IMEI and click Search button.

## **Device Statistics**

Includes *Device Overview* Report, *Battery* Report, Fuel Consumption Report, Temperature Report, *Driving Behavior* Report, Positioning &Battery Report.

#### **Motion Statistics**

Includes *Moving Overview* Report, Trips Report, *Overspeed* Report, *Parking* Report, *Idling* Report, *Ignition* Report(ACC Report).

### **State Statistics**

Includes Offline Report and Online Report.

#### **Alert Statistics**

Consists of Alert Overview Report and Alert Details Report.

### **Logistics Statistics**

**Includes Logistics Statistics** 

## **Auto Report**


Includes Auto Report and Auto Report History

#### 4.7.1 Device Overview


1. The first chart shows stock devices quantity, total device quantity, online/offline devices quantity, as well as activated devices quantity.



2. The second chart shows stock quantity and total quantity for all sub-accounts.




3. The third chart shows the trend of Increased/Activated devices for current login account.




# 4.7.2 Battery

This report shows device battery information. Include Currently some models support fetching battery electric in platform.




## 4.7.3 External Battery

This report shows external battery, it's for the vehicle and motor device. When the device has an external battery, the percentage of external electric quantity will be displayed




# 4.7.4 Fuel Consumption

Only devices support fuel sensor and already configure fuel tank volume in *Device* page can be shown in this report. See <u>Set Fuel Tank Vol</u>.




# 4.7.5 Temperature


Only devices are connected to an external temperature and humidity sensor and the already configure information in device page can be shown in this report, see <a href="Serial port">Serial port (TTL/RS232)</a>




# 4.7.6 Driving Behavior

Driving behavior is a subset of *Alert Details* report, which only includes *Sudden Acceleration Alert*, *Sudden Deceleration Alert*, *Sharp Turn Right Alert* and *Sharp Turn Left Alert* and *Collision Alert*. Some device models support this feature.








## 4.7.7 Moving Overview

This report shows total mileage, overspeed times and stopover times for all the devices. Click total milage link, system navigates to *Mileage* report for details. Note the result not include today's mileage.




This report shows the detail mileage of devices with an explicit start time and end time, the *Total Fuel* is calculated base on total mileage, It also support to displays detail mileage day by day, however, records with none mileage will be ignored. The data of mileage is updated by every half hour.

Total Fuel = Total Mileage / 100 \* Fuel/100km


## 4.7.8 Trips

Trips report shows the start time, end time, start point, end point and mileage, total fuel, avg. speed information for device for all matching trips.




This report shows the detail mileage of devices with an explicit start time and end time, the *Total Fuel* is calculated base on total mileage, It also support to displays detail mileage day by day, however, records with none mileage will be ignored. The data of mileage is updated by every half hour.

Total Fuel = Total Mileage / 100 \* Fuel/100km




## 4.7.9 Overspeed

Shows all overspeed records for selected devices.




## **4.7.10** Parking

Shows all parking records for selected devices.




# 4.7.11 Idling

Shows all idling records for selected devices.




# **4.7.12** Ignition

Shows ACC(Engine) status for selected tracking devices, the status is ON/OFF.




# 4.7.13 Offline

Display all records for offline devices.




# 4.7.14 Online

Search all online devices and current position of selected account.




## 4.7.15 Alert Overview

Counts the times of alert for each alert type, this is an overview report for *Alert Details*. Click the number alerts to view more detail alert information.




Click view to check alert times and details



## 4.7.16 Alert Details


This report shows alerts of selected devices. User can change read/unread status of selected alerts by clicking *Mark as Read,* and add comments for the selected alerts.



# 4.8 Video


Video includes following features:

- Event Video-page list shows event video data, click the list line platform user can watch video. the video stored in the cloud, users can download videos and save them locally.
- Live-user can view video remotely in real time, capture photos and videos remotely. Help user view vehicle conditions even thousands of miles away.
- History Video-users can view the historical video stored on the local memory card by the remote network connection.



## 4.8.1 Event Video

### 4.8.1.1 Search Bar



 $\textbf{IMEI} \cdot \textbf{fill in the IMEI number, user can search multiple IMEI at the same time.}$ 

**Device Name** - fill in the device name, user can search for multiple devices at the same time.

**Device Mode** - select a device with event video.

Date - the default is 7 days, can select all dates or 7 days.

**Reading Status** - the default is unread, can select all state or unread.

**Event Type** - the default is all event type, can select other type event.

**Sub-account Devices** - user can choose to search for sub-account devices, which is not checked by default.

Reset - click the button to reset the filter.


**Play** - It is not clickable by default. When the user selects events in the list, the button will be activated. After clicking, the event video will be rotated.

**Download** - It is not clickable by default. This button is activated when the user selects events in the list, and clicks to download video files in batches.

#### 4.8.2 Live

### 4.8.1.2 Video Playback Window

The video playback content two parts. the upper part is the video content, and the lower part is the event information. The playback window is hidden by default. When the user clicks a row in the event list, it pops up and plays automatically until the window is closed or the next event is played or click the pause button.



Close Button - click the button to close the video.

Download - download current event video.

**Direction Switch** - click to switch camera direction.

Sound Switch - click to turn sound on or off.

Play/Pause Switch - click to play or pause video.

Zoom Button - Click the button to enlarge or reduce the video playback window.




#### **Account Tree**

The account tree in Live is same as other page, user can search account fast by provide a searching keyword.

### **Device List**

The middle section is the device list, which is almost the same with the device list of monitor pages, but the remote photo, video and live video functions are added on this page.



**Remote media button** – when the user clicks the remote media button, a selection popup appears on the right. Click get button to get photograph or short video.

## 4.8.2.1 Video Playback Window

Click the live video button or select box to pop up the live video playback window. The platform supports 9-grid screen display. When the user selects multiple devices in the left list bar, the map area displays multi-screen.



**Close Button** - click the button to close the video.


**Direction Switch** - click to switch camera direction.

Sound Switch - click to turn sound on or off.

Play/Pause Switch - click to play or pause video.

**Zoom Button** - Click the button to enlarge or reduce the video playback window.

## 4.8.3 History Video



#### **Account Tree**

The account tree in Live is same as other page, user can search account fast by provide a searching keyword.

### **Device List**

The middle section is the device list, which is almost the same with the device list of monitor pages, but the remote photo, video functions.

#### **Search Bar**

**Date** -when the user selects the device, the default date is today, click the time picker to select the time.

**Direction Switch** - click to switch camera direction. the default direction is front.


**Search** - click the button to search data by filters.

Last Day - click the button to search the previous day's data.

**Next Day** - click the button to search the data for the next day.

**Time Line** - When there is a video in the selected date, the time period with the video is color-coded in the timeline. The user can operate the timeline to choose to watch the video.

# Video Playback Window



Close Button - click the button to close the video.

Sound Switch - click to turn sound on or off.

Play/Pause Switch - click to play or pause video.


**Zoom Button** - click the button to enlarge or reduce the video playback window.

Map - the map appears at the bottom after clicking the button.

Last Minute - click the button to play the last minute video

Next Minute - click the button to play the next minute video.

# 4.8.4 Setting



## **DMS Setting**


Setting DMS is devided into two parts

**Switch** - Setting whether the DMS event video is uploaded to platform. If the user do not want to upload videos to the platform, can set the button turn off. Click the save button to take effect. The user can set the device in batch.

**List** - Display the information of the selected device on the left, click the delete button to cancel the selected device.


## 4.9 Fleet






## 4.9.1 Dashboard

Preview the driver and vehicle situation and graphic report information, such as total number of drivers, total number of vehicles, total mileage, engine running time, fuel consumption, task preview function, and relevant TOP data, such as maximum fuel consumption, maximum mileage, driving behavior score.




### 4.9.2 Driver

Register driver information, license plate number, RFID Card No, Register Date, Expired Date, Phone, Email etc




User can also customize the License expiration reminder, support send to email.





## Add driver information

User can add Driver No, Driver name, RFID Card No, Register Date, Expired Date, Phone, Email etc, can also upload picture, only support jpg/png, file size should not large than 2048kb.




## **Export driver information**






#### **Edit and Detele**




#### 4.9.3 Vehicle

Vehicle is mainly to add the Vehicle information and some Settings related to the Vehicle, such as Vehicle No., Tracking Device, Engine Number, Max Speed, Brand, Model, Insurance Effect Date, Insurance Expire Date, VIN, Fuel/100km, Overspeed Alert, etc.




Users can set up a reminder for Maintenance expiration (according to Mileage or ACC-On Duration) /Timing mode for regular reminders




#### **Add Vehicle information**


User can add Vehicle No, Tracking Device, Engine Number, Max Speed, Brand, Model, Insurance Effect Date, Insurance Expire Date, VIN, Fuel/100km, Overspeed Alert etc.



**Export Vehicle information** 




## **Edit and Detele**



# 4.9.4 RFID History

View and query the ID card record. The query is based on the ID of the card ( the starting and the end time) Every time you swipe your card, a record is created.





## 4.9.5 Route Planning

Route planning includes creating the route, bind the vehicle. If the vehicle is not in the form created on the route, an alert message will be generated by the Fleet. At the top right



Currently only two points (start and end points) are supported to create a route, which is automatically generated. click "Add" new route, assign device to this route.






## **Detele Route**



# 4.10 Advanced Search

Advanced search provides very rich functions for user to search device, platform user and app user. Almost all functions in this tracking platform can be found in advanced search.





User(platform user) we mentioned in previous section is same definition to account, but App user is registered in Apps, it's not in the account tree.

#### 4.10.1 Search Device

By default, search devices in *Advanced Search* is base on IMEI or device name by default, however it also support other criteria:

Account - search device by selected account.


Device Fields - including IMEI, License Plate No, Model, SN, VIN, SIM, Device Name


Date Type - including Activated Date, User Expiration Date, Platform Expiration Date

Status - Expired or Not Activated

The matched results will be list on the bottom datagrid.







△ No data found.


The Actions links in the result help user to do other operations:

**Detail** - navigates to device relative information tabs in current pop up window.

Playback - new page to playback tracks.

Tracking - new page to view real-time tracking.

**Alert** - new page to alert details report.




Click Detail link shows following tabs:

**User Relationship** - shows device basic fields and relationship between device and account.

**Device Detail** - shows device detail information, same as *Device Detail* in *Device* page.

Move Device - Move device to other account, is identical to Rapid Sale/Sell/Bulk Sell

**Device Command** - Send command to device, same as *Command/Send Command* in *Device* Page or *Device Command* in *Monitor* page.



### **User Relationship Tab**

This tab shows device basic fields and relationship between device and account, also includes following links:

Playback - new page to playback tracks for this device.


Tracking - new page to show real-time tracking for this device.

Alert - new page to alert details report.


Monitor(Location) - new page to Monitor page, showing selected device or devices of selected account.

View (Devices)- new page to Device page to view devices of selected account.

Reset Password - reset selected account to initial password 888888.




In this tab, user can edit device detail like Edit in Device page.




#### **Move Device Tab**

Move devices like Rapid Sale in Dashboard, Sell/Bulk Sell in Device page.




### **Device Command Tab**

Send commands like Command/Send Command in Device page, Device Command in Monitor.



## Click Back to go to the basic search.



## 4.10.2 Search Account


Search user by customer name or account, including sub-account. The result datagrid includes following links:

**Monitor** - new page to monitor devices of selected account.

**Detail** - navigates to User relative Information, including 5 tabs.

**Reset Password** - reset password to initial password 888888 for selected account.

View (Devices)- new page to view devices of selected account in Device page.



Click Detail link in the account list shows 5 tabs for selected account.


User Relationship - shows the structure of accounts.

User Information - Account details.

Sell Device - Move devices to selected account.


Add Sub-account - new sub-account for selected account.

Move Account - move selected account to another sub-account.




### **User Relationship**

Show the structure of accounts. Monitor link navigates to a new page to monitor device, click View link to view devices of selected account in *Device* page.




#### **User Information**

Identical to Edit in Account, user can edit account details in this tab. Refer to Edit Account.




## **Sell Device**

Move devices to this selected account. This function almost identical to Sell/Bulk Sell/Rapid Sale/Move Device in previous section. The difference selected account is the target account in this function. See <u>Sell/Move</u>




#### **Add Sub-account**

Add new sub-account for selected account. This is a function identical to <u>New Account</u>, set the selected account as superior account and not allow to change.




## **Move Account**

Move selected account to a target account select from the account tree.



### 4.10.3 Search APP User

Generally, App user is registered from Apps by an email account, To search App user, User provides email account and click *Search* button to search sub-account for current login account. App user will not included in the searching results if it haven't bound a device.



### **Operation Links**

Monitor - new page to monitor bound devices of selected App user.

**Reset Password** - reset App user password to initial password, 888888.

Detail - navigates to device relative 4 tabs. Identical to Detail link in Search Device.

Playback - new page to playback tracks of this device.


Tracking - new page to show real-time tracking of this device.

Alert - new page navigates to alert detail report.

**Unbundling** - unbind device from this App user.


## 4.10.4 Search Device by License Plate No.

This function provide a shortcut to search device by License Plate No. Identical to <u>Search Device</u> in previous section.



# 4.11 Help

Help contains business logs, login logs, feedback and release notes. You can find release notes in Help if you miss the pop up window while new version released.



**Business Logs** - records operations of all devices for current login account and modification of accounts.


**Login Logs -** records the login operation of current login account.

**Feedback** --- For user to submit advises, request new feature, report issues and so on.

**Release Notes ---** Records change log for each version, it might include a user manual document.


### 4.11.1 Feedback


An online feedback for user to report issues, request new feature, please write the description in English, recommend to provide contact email



### 4.11.2 Business Log


Provides logs for device and account for core business operation.





# 4.11.3 Login logs


Display login logs for current login account.



# 4.11.4 Release Note

Display change log for every release version, it might include a user manual(Word document) for

new features. Change log pops up while new version released, if you miss it, view it in this page.



# **4.12 Command Management**

Sometimes user need to send command to device for changing device configuration. Besides sending command individual or in bulk, system also provides feature <u>working mode template</u> and command template to make it more convenient to send commands to device.

### **Synchronize Working Mode Task**

Each operation of *Set Working Mode* in bulk(in *Device* module) is considered as a batch operation, system generates a batch number for it. *View Detail* link navigates to *Synchronize Working Mode* shows all operated devices in this batch.

#### **Synchronize Working Mode**


Shows details records of Set Working Model in bulk.

#### **Sending Command Task**

Each operation of *Send Command* in bulk(in *Device* module) is considered as a batch operation, system generates a batch number for it. *View Detail* link navigates to *Sending Command* shows all operated devices in this batch.

#### **Sending Command**

Shows details records of Send Command in bulk.




# **4.12.1** Working Mode Template

It's a template for set GPS data packet uploading frequency. See Working Mode for more details.

## **Create Template**

Click Create Template to add a new working mode template.




**Edit/Remove Template** 



#### Command

Fill device(s) IMEI and Click Send Command send working mode command to device.






## 4.12.2 Batch working mode

Each operation of *Set Working Model* in bulk(in *Device* module) is considered as a batch operation, system generates a record for this operation in this datagrid. The record includes following fields: Batch No. ,Template Name, Device Qty, Send Time and a link navigates to *Synchronize Working Mode to* view details of operated devices.




In this example, there are 2 devices operated in this synchronize working mode operation, Batch


No. is 20170922144722343, because the device is offline, the command(Set Working Mode is a special command) is pending, therefore, there is no start time and end time.



### Click view for details.




Click Cancel Command/Cancel All Command button to cancel fail/pending command.



## 4.12.3 Working Mode Status

### 4.12.4 Batch Command


Send Command in bulk(in *Device* module) generates a record in *Sending Command Task* datagrid, click *View Detail* link, the detail operated devices will be shown in Sending Command datagrid. Command can be canceled and exported in the details datagrid.



## 4.12.5 Command Status

## **4.12.6 Command Template**

Command template is a new function supports to configure several different commands in a template and send to specified devices list, the command will be send to selected device respectively. Each account allow to create up to 5 command templates. User should select *Model* first, then add commands, provide value for parameter and save it.



After save the template, user selects devices and click *Send Command* button, a new window pops up to show the execution results, mouse over on the information icon to view the details of return results from device.

