KETTLER

PALMA Armless Chair w/ Cushions 10330A-2100**



IMPORTANT

PLEASE KEEP THIS BOOKLET FOR FUTURE REFERENCE.
THIS IS IMPORTANT INFORMATION REGARDING THE USE AND
CARE OF YOUR GARDEN FURNITURE.

Parts Request Form

KETTLER International, Inc. Parts & Service Dept. 1355 London Bridge Rd. Virginia Beach, VA 23453 Phone - 866.804.0440 Fax - 757.427.0183

Email - parts@kettlerusa.com Web Site - www.kettlerusa.com

Model #			quired)*]	Model Name		
	*Serien N	r. or Baujahr					
Qty			Parts Descripti	on			Item # (Optional)
	-					_	
	_	-				_	
Spare part	s do not incl	ude mounting har	dware. Please speci	fy "with ha	dware" if need	ed.	
Is this a w	arranty parts	order?					
Yes		-	Date of purchase	:	Place of	Purchase:	
		y be required)					
No	on for order:	Method of payn	nent: Check		CC:		
	Visa. MC		d check/money		_		a S&H fee.
Card type:							
	Last 3 digi	its from security c	ode on back of CC:	-	(Required)	· -	
Ship to:	Name:						
Attn:				P.O./Refe	rence #:		
Address:							
City:							
City.					State/Flov.		
Zip/Postal	Code:			_Country:			
Home Pho	ne Number:				_	Fax:	
Email:							
Billing Ad	ldress for CC	C: (If different from	n above address)				
Address:							
Zip/Posta	I Code:						

Unit that parts are being requested for:

*Model numbers for toys and tennis table products can usually be found on a white sticker about 1 inch in diameter located on the underside of the unit; it will be the 08xxx-xxx or 07xxx-xxx #. Model number for fitness products can be found on the silver label located on the frame of the unit listed as a TYP # or ART. NR. Note: If a computer is being ordered for any Ergometer the BAUJAHR or the SERIEN NR. off of the unit MUST be included in the description; this can also be found on the silver label. If you cannot provide the model # a picture is required for product identification.

Any order placed without the model # supplied will be non - refundable.

Maintenance and Care Instructions

- The table top conforms to the UK BS standard. We recommend that you follow these simple tips and instructions to ensure it retainsits good looks.
- This product may only be used for its intended purpose for residential premises.
- Kettler furniture is designed to be left outdoors all year round (excluding cushions).
- We recommend you clean your Kettler furniture at the beginning and end of the season.
- To clean your Kettler furniture, wash only with warm water and mild detergent. Do not use abrasive cleaners. Spray cleaners can and will cause the table to dis-colour.
- Remove food and drink residue, tree sap and bird droppings as soon as possible to avoid staining. Marks should be removed using neat mild detergent with a soft cloth and washed off with water.
- Do not leave hot items directly on the table. Coasters will protect your table from heat and water rings.
- Do not drop anything sharp or heavy onto the table.
- Take care when placing items onto the table to avoid scratches.
- Moving parts such as locking mechanisms, catches and joints need to be lubricated where necessary.
- Kettler furniture can be covered we recommend that you only use Kettler tailored covers (where available).
- This product is 100% recyclable. At the end of the products life, please dispose of responsibly.
- We recommend flipping cushion seats and backs to ensure even wear for added longevity.
- Some styles of wine glasses and other glass objects can act as a prism in strong sunlight. Take care to avoid contact of these items directly with the table surface.
- Colours may vary slightly.



Attention

Please be aware that painted/varnished surfaces can be damaged by sunscreens and oil based products. If the surface of your Kettler leisure furniture comes into contact with sunscreens, the surface is to be cleaned without delay as described above. Only in this way can lasting discolouration of the surface by the ingredients of the sunscreen be prevented.

For Your Safety

- This product may only be used for its intended purpose as furniture for residential properties.
- · Check all components regularly for correct function, damage and loose connections especially at the start of the season and at 1-2 month intervals dependent on use.
- Damaged components may endanger your safety or shorten the life of the product. Replace all damaged parts immediately. Use only spare parts manufactured by Kettler. Should you wish to purchase spare parts, they can be ordered directly from: www.kettlerusa.com
- Kettler will not be responsible for damaged caused by improper use.



Attention

- Whilst assembling this product keep out of the reach of children. (Choking hazard contains small parts)
- Ensure that your working area is free of possible sources of danger, for example don't leave any tools lying around.
- Always dispose of packaging material in such a way that it may not cause any danger. There is always a risk of suffocation if children play with plastic bags!
- We reserve the right to make changes for technical reasons.



KFTTI FR USA 1355 London Bridge Road Virginia Beach, VA 23453





Warranty For Home Use

This product is covered by a 3 &1 year warranty against manufacturing faults. This warranty applies to domestic use only. It does not cover commercial use, mis-use or accidental damage.

To validate your warranty, register at www.kettlerusa.com and quote the product code from the front of this booklet.