

Yolin

Electric Bike Display

User's Manual

YL81F

Tianjin Yolin Technology Co. Ltd.

TABLE OF CONTENTS

1. Product Name and Model Number	1
2. Specification	1
3. Appearance and Size	1
4. Function Overview and Functional Areas	3
4.1 Functional overview	3
4.2 Functional areas	3
4.3 Button definitions	3
5. Routine Operation	4
5.1 Power on/off	4
5.2 Display interface switching	4
5.3 Walk boost mode	5
5.4 Turning on/off lights	5
5.5 PAS level selection	6
5.6 Battery level display	6
5.7 Error code display	7
6. Personalized Parameter Settings	7
6.1 Metric and Imperial setting	8
6.2 Rated voltage setting	8
6.3 PAS level setting	9
6.4 Wheel diameter setting	10
6.5 Number of speed sensor magnets setting	10
6.6 Speed Limit Setting	11
6.7 Controller Current Limit Setting	11
6.8 PAS sensor setting	12
6.9 Throttle setting	13
6.10 Power-on password setting	14
6.11 Auto Sleep Time Setting	15
7. Shortcut Operation	16
8. Quality Assurance and Warranty	17
8.1 Warranty info	17
8.2 Warranty does not cover	17
9. Wire Connection Diagram	17
10. Precautions	17
Schedule 1: Error Code Definition	18
Schedule 2: Pedal Assist Level Default Ratio Value	18

1. Product Name and Model Number

Smart LCD display for electric bicycle; Model: YL81F.

2. Specification

- 24V/36V/48V power supply
- Display rated current 15mA
- Display maximum current 30mA
- Shutdown leakage current <1uA
- Supplied current to the controller 50mA
- Operating temperature -20~60°C
- Storage temperature -30 to 70° C

3. Appearance and Size



Figure 3-1 Physical picture of the YL81F display



Figure 3-2 Physical picture of the K5 control button



Figure 3-3 Physical picture of the K6 control button




Figure 3-4 90T-V Front View Dimension




Figure 3-5 90T-V Side View Dimension

4. Function Overview and Functional Areas

4.1 Functional overview

The YL81F display offers a variety of features to suit your riding needs, including:

- Battery level indicator
- Pedal assist (PAS) level indicator
- Speed (current speed, maximum speed, average speed)
- Mileage display (single and total mileage)
- Walk boost mode
- Light ON/OFF
- Error code indicator
- Motor power indicator (optional)
- USB connection indicator (optional)
- Cruise control indicator (optional)
- Bluetooth connection indicator (optional)
- Personalized parameter settings (e.g. wheel diameter, speed limit, rated voltage, PAS parameter, password, and controller current limit setting, etc.).
- Factory default parameter recovery function

4.2 Functional areas










Figure 4-1 YL90T-V functional area distribution interface


4.3 Button definitions

The YL81F display is equipped with five buttons on the corresponding operating unit: power on/off , plus , minus , light  and toggle .


5. Routine Operation

5.1 Power on/off

Long press  to power on/off the display. When the display is off, it will not use the battery power and the leakage current is less than 1uA.

 The display will automatically shut off if it is not used for more than 10 minutes.

5.2 Display interface switching

When the display is powered on, it will show the Current Speed (km/h) and Trip Odometer (km) by default. Short press  to switch between Trip Odometer(km), Odometer (km), Maximum Speed (km/h), and Average Speed (km/h).




Figure 5-1 Display Interface Switching

5.3 Walk boost mode




Long Press and hold , the electric bicycle enters the walk boost mode. The electric bicycle will walk at a fixed speed of 6 km/h and the display shows . Release  to stop the power output immediately and restore to the state before walk boost.



Figure 5-2 Helping to implement the display screen

⚠️ The walk boost mode can only be used when pushing the electric bicycle, please do not use it while riding.

5.4 Turning on/off lights



Press the  to make the controller turn on the lights and the display backlight becomes dim. Press  again to make the controller turn off the lights and the backlight restore brightness.



Figure 5-3 Backlight display interface

5.5 PAS level selection

Press **+** / **-** to switch PAS level of electric bicycle, thus changing the motor output power.




Figure 5-4 PAS level display interface

5.6 Battery level display

The Battery level is shown as 5 bars. When the battery is full charged, all of the 5 bars lighten up. When the battery is fully depleted, the bar will begin to flash, warning the user to charge the battery as soon as possible.




Figure 5-5 Battery Level Display Interface

5.7 Error code display

If there is a fault occurs in the electronic system of the electric bicycle, the display will automatically show an error code, see **Schedule 1** for a detailed definition of the error code.



When the error code appears on the display, please troubleshoot the problem in time, the electric bicycle will not be able to drive normally after the problem occurs.




Figure 5-6 Error Code Display

6. Personalized Parameter Settings

⚠ Each setting needs to be done with the bicycle stationary.

The personalized parameter setting procedure is as follows:

When the display is ON and the speed shows 0,

- (1) Press and hold **+** **-** simultaneously for more than 2 seconds to enter the personalized parameter setting interface.
- (2) Press **+** / **-** to toggle between the personalized parameter setting interface, and press **i** to enter the parameter changing state.
- (3) Press **+** / **-** to select the parameter, long pres **+** for addition operation, long press **-** for subtraction operation.
- (4) Press **i** to save the parameter settings and return to the personalized parameter setting interface.
- (5) Long Press **i** to save the parameter settings and exit the personalized parameter setting interface.

The following options are available on the personalized parameter setting interface:

6.1 Metric and Imperial setting

01P is the metric and imperial setting, 00 for metric and 01 for imperial.

Press **i** to enter the parameter changing state. Press the **+**/**-** to select the parameter and press **i** to save the parameter setting and return to the personalized parameter setting interface.




Figure 6-1 Metric and Imperial Units Setting Interface

6.2 Rated voltage setting

02P is the rated voltage setting. The available rated voltage range is: 24V, 36V, 48V.

Press **i** to enter the parameter changing state. Press the **+**/**-** to select the parameter and press **i** to save the parameter setting and return to the personalized parameter setting interface.



Figure 6-2 Rated voltage setting interface

6.3 PAS level setting

03P is the Pedal assist level setting. The available PAS level settings are: 0~3, 1~3, 0~5, 1~5, 1~7, 0~7, 0~9, 1~9.

Press **i** to enter the parameter changing state. Press the **+**/**-** to select the parameter and press **i** to save the parameter setting and return to the personalized parameter setting interface.



Figure 6-3 PAS level setting interface

6.3.1 PAS level ratio value setting

To meet different requirements for users, the speed of every level can be adjusted by setting the PAS level ratio value. Please see the details from Schedule 2.

For example, “45-55%” is the ratio range of PAS 1. The default ratio value of PAS 1 is 50% which is adjustable.

Press the **+**/**-** to select the parameter and press **i** to save the parameter and enter into the next level setting.

Press **i** again to save the settings and return to the personalized parameter setting interface.




Figure 6-4 PAS level ratio value setting interface

6.4 Wheel diameter setting

04P is the wheel diameter setting. The adjustable wheel diameter range is: 8~50inch.

Press **i** to enter the parameter changing state. Press the **+**/**-** to select the parameter and press **i** to save the parameter setting and return to the personalized parameter setting interface.



Figure 6-5 Wheel diameter setting interface

6.5 Number of speed sensor magnets setting

05P is the speed sensor magnet number setting. The adjustable speed sensor magnet number range is: 1 ~ 15 pcs (5S protocol), 1 ~ 63 pcs (KDS protocol).

Press **i** to enter the parameter changing state. Press the **+**/**-** to select the parameter and press **i** to save the parameter setting and return to the personalized parameter setting interface.



Figure 6-6 Number of speed sensor magnets setting interface

6.6 Speed Limit Setting

06P is the speed limit setting. The adjustable speed limit range is: 1~60km/h or 1~41km/h. (The maximum adjustable speed limit varies by different protocols).

Press **i** to enter the parameter changing state. Press the **+**/**-** to select the parameter and press **i** to save the parameter setting and return to the personalized parameter setting interface.



Figure 6-7 Speed limit setting interface

6.7 Controller Current Limit Setting

07P is the controller current limit setting. The adjustable range is: 1~31.5A.

Press **i** to enter the parameter changing state. Press the **+**/**-** to select the parameter and press **i** to save the parameter setting and return to the personalized parameter setting interface.



Figure 6-8 Controller current limit setting interface

6.8 PAS sensor setting

08P is the PAS sensor setting.

6.8.1 PAS sensor direction setting

run is the PAS sensor direction setting. run-F is front direction and run-b is opposite direction.

Press **i** to enter the parameter changing state. Press the **+**/**-** to select the parameter and press **i** to save the parameter setting and enter into 6.8.2 PAS sensor sensitivity setting interface.




Figure 6-9 PAS sensor direction setting interface

6.8.2 PAS sensor sensitivity setting

SCN is the PAS sensor sensitivity setting. The adjustable range is: 2-9. 2 is the highest level sensitivity while 9 is the lowest.

Press the **+**/**-** to select the parameter and press **i** to save the parameter setting and enter into 6.8.3 PAS magnets number setting interface.



Figure 6-10 PAS sensor sensitivity setting interface

6.8.3 Number of pedal assist sensor magnets setting

PAS is the pedal assist sensor magnets setting. The adjustable range is: 5-31.

Press the **+** / **-** to select the parameter and press **i** to save the parameter setting and to return to the personalized parameter setting interface.




Figure 6-11 Pedal assist sensor magnets setting

6.9 Throttle setting

09P is the throttle setting.

6.9.1 Throttle 6KM/H walk boost setting

HL is the throttle 6KM/H walk boost setting. HL-Y is to enable the walk boost and the speed will maintain at 6KM/H when using throttle. HL-N is to disable the walk boost and it can reach the max speed when using throttle.

Press the **+** / **-** to select the HL-Y and press **i** to save the parameter setting and return to the personalized parameter setting interface.

Press the **+** / **-** to select the HL-N and press **i** to save the parameter setting and enter into 6.9.2 Throttle Level setting interface or long press **i** to return to the personalized parameter setting interface.




Figure 6-12 Throttle 6KM/H walk boost setting

6.9.2 Throttle level setting

HF is the throttle Level setting. HF-Y is to enable the throttle level. When using the throttle, the max speed depends on the throttle level. (0~3, 1~3, 0~5, 1~5, 1~7, 0~7, 0~9, 1~9) HF-N is to disable the throttle level. The speed is independent with the throttle level and can reach the rated max speed.

Press the **+** / **-** to select the parameter and press **i** to save the parameter setting and **ESC** to return to the personalized parameter setting interface.




Figure 6-13 Throttle level setting

6.10 Power-on password setting

10P is the power-on password setting. The power-on password is not activated by default but users can activate it from setting PSd-y. The factory default password is 1212. Users can set other four-digit password. Please keep the password in mind after changing it, otherwise you will not be able to use the display.

Press **i** to enter the parameter changing state. Press the **+** / **-** to select the parameter. PSd-y means the power-on password is activated while PSd-n is off. Press **i** to confirm the mode and enter the state of setting the four digits power-on password or exit to the personalized parameter setting interface.



Remember your password after changing it, or you will not be able to use the meter!




Figure 6-14 Password OFF interface




Figure 6-15 Password Activated interface

In the password setting mode, the adjustable digit will flash. Press the **+** / **-** to select the parameter and press **i** to save the numbers and go to the next digit setting. Long press **i** to save the parameter setting and return to the personalized parameter setting interface after finish setting the four digits in turn.




Figure 6-16 Power-on password setting interface

6.11 Auto Sleep Time Setting

11P is the auto sleep time setting. To save the battery power and reach higher range, this display will be turned off after it has not been used for a time. The adjustable range is: 1~60min, 00 means no auto shutdown. The factory default setting is 10 minutes.

Press **i** to enter the parameter changing state. Press the **+** / **-** to select the parameter and press **i** to save the parameter setting and return to the personalized parameter setting interface.




Figure 6-17 Auto Power Off Time Setting Interface

7. Shortcut Operation

7.1 Restore factory settings operation

dEF is the restore factory default parameter settings. dEF-Y is to restore default settings, and dEF-N is not to restore.








Enter into the main setting interface and keep the speed at 0, press and hold  and  simultaneously for 2s to enter the restore factory default setting interface. Pressing  /  to toggle to dEF-Y. Then after pressing  to confirm, the display will show dEF-0 for a few seconds and then automatically start to restore the factory default settings. The display will automatically exit to setting interface after the restoration.



Figure 7-1 Restore Factory Default Settings Interface

7.2 Trip odometer reset operation

The display can record trip odometer and odometer. Trip odometer is not automatically reset after turning off. The trip odometer needs to be reset manually.

Enter into the main setting interface and keep the speed at 0, press and hold  and  simultaneously for 2s to reset the trip odometer. The main interface will flash during the reset process.




Figure 7-2 Trip Odometer Reset Interface

8. Quality Assurance and Warranty

8.1 Warranty info

● Yolin will offer a limited warranty for any failure caused by the product defects under normal use during the warranty period.


- The product is warranted for 12 months from the date out of factory.

8.2 Warranty does not cover

- The shell is opened.
- The connector is damaged.
- Scratches on the appearance after the product is out of factory.
- Scratched or broken wires
- Failure or damage caused by force majeure (e.g. fire, earthquake, etc.) or natural disaster (e.g. lightning strike, etc.)
- Out of warranty period.

9. Wire Connection Diagram

Standard wire connection sequence:



Controller connector

Display connector (Female terminal) Display connector (Male terminal)

Figure 9-1 Wire Connection Diagram

Table 9-1 Standard connector wire sequence table

Standard Wire Sequence	Standard wire color	Function
1	Red (VCC)	Display power wire
2	Blue (Kp)	Controller power wire
3	Black (GND)	Display ground wire
4	Green (RX)	Display data reception wire
5	Yellow (TX)	Display data transmit wire

■ Some models are equipped with waterproof connectors and the color inside wires can not be seen.

10. Precautions

Pay attention to all the general operating when using the products and do not plug and unplug the display while it is powered on.

- ◆ Avoid bumping the display as much as possible.
- ◆ Please do not change the parameter settings at will, otherwise normal riding cannot be guaranteed.
- ◆ If display does not work properly, please send it to the repair center as soon as possible.
- ◆ There may be differences between the physical products and this manual due to normal upgrade. Please refer to the physical products.

Schedule 1: Error Code Definition

YL-01, YL-02 Error codes			
Error code	Definition	Error code	Definition
E001	Controller failure	E004	Throttle failure
E002	Communication failure	E005	Brake failure
E003	Hall failure	E006	Motor phase failure
YL-05, KDS, YL-J Error codes			
Error code	Definition	Error code	Definition
E021	Current failure	E024	Hall failure
E022	Throttle failure	E025	Brake failure
E023	Motor phase failure	E030	Communication failure

Schedule 2: Pedal Assist Level Default Ratio Value

Level selection \ Level	1	2	3	4	5	6	7	8	9
0-3/1-3	50%	74%	92%	-	-	-	-	-	-
0-5/ 1-5	50%	61%	73%	85%	96%	-	-	-	-
0-7/ 1-7	40%	50%	60%	70%	80%	90%	96%	-	-
0-9/ 1-9	25%	34%	43%	52%	61%	70%	79%	88%	96%

Tel: 022-86838795

Fax: 022-86838795

Email: store@yolintech.com

Website: www.yolintech.com

Address: Plant 52-1, Yougu Xinke Park, East of Jingfu Road, Pharmaceuticals and Medical Equipment Industrial Park, Beichen Economic Development Zone, Beichen District, Tianjin