

# Table of Contents

| Safety Information                               | 3  |
|--------------------------------------------------|----|
| Intended Use                                     | 4  |
| Product Features                                 |    |
| Touch Panel Description                          | 5  |
| Product Dimensions                               | 5  |
| Operational Specifications                       | 5  |
| Package Contents                                 | 6  |
| Materials Needed                                 | 6  |
| Installation                                     |    |
| Determine Installation Location                  | 7  |
| Install the Dispenser                            | 7  |
| Flush the Filters                                | 8  |
| Install the Filters and Tubing                   |    |
| Connect to the Cold Water Supply                 | 1′ |
| Complete the Installation                        | 12 |
| Operation                                        | 12 |
| Turn the Dispenser On/Off                        | 12 |
| Set the Time                                     | 13 |
| Set the Cold Water Temperature Level             | 13 |
| Set the Hot Water Temperature Level              | 13 |
| Dispense Cold and Room Temperature Water         | 14 |
| Disable Child Safety Lock and Dispense Hot Water | 14 |
| Troubleshooting                                  | 14 |
| Cleaning and Maintenance                         | 15 |
| Filter Replacement Schedule                      | 15 |
| Replace the Filters                              |    |
| Filter Specifications                            |    |
| Care and Maintenance                             |    |
| Warranty                                         | 17 |



## Safety Information

**WARNING:** To reduce risk of injury and property damage, you must read this entire guide before assembling, installing and operating the dispenser.

**WARNING:** This product dispenses water at very high temperatures. Failure to use properly can cause personal injury. When operating this dispenser, always exercise basic safety precautions, including the following:

- Prior to use, this dispenser must be properly assembled and installed in accordance with this manual.
- For indoor use only. Keep the water dispenser in a dry place away from direct sunlight. Do NOT use outdoors.
- Install and use only on a hard, flat and level surface.
- Do NOT place the water dispenser in an enclosed space or cabinet.
- Do NOT operate the dispenser in the presence of explosive fumes.
- Use only properly grounded outlets.
- · Do not use an extension cord.
- Always grasp the plug and pull straight out from the outlet. Never unplug by pulling on the power cord.
- Do NOT use the dispenser if the cord becomes frayed or otherwise damaged. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- To protect against electric shock, do NOT immerse cord, plug, or any other part of the dispenser in water or other liquids.
- Ensure the water dispenser is unplugged prior to cleaning.
- Never allow children to dispense hot water without proper and direct supervision. Unplug the unit to prevent unsupervised use by children.
- Service should be performed only by a certified technician.
- The appliance must not be cleaned by a water jet and is not suitable for installation in an area where a water jet could be used.

**WARNING:** Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.

**WARNING:** Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

- This appliance should work under environment of temperatures from 4°C~40°C (39°F~104°F) and humidity ≤90%.
- Never turn the machine upside down or lean it more than 45°.
- · After turning the dispenser off, allow the dispenser to sit idle for 3 minutes before turning on again.

WARNING: UV light source. Disconnect the electrical supply to UV radiation BEFORE opening cover.

- UV-LED lamp must be repaired by manufacturer on.
- UV-LED lamp model no. YB09-950-022, rated DC 24V, 0.17W±20%.
- Disposal of the UV-LED lamp must be done in accordance with local laws and regulations.



# Intended Use

This dispenser is intended to be used in household and similar applications such as:


- Staff kitchen areas, offices and other working environments
- Farm houses
- Hotels, motels and other residential-type environments
- · Bed-and-breakfast environments
- Catering and similar non-retail applications

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

# **Product Features**








| Part | Description         |
|------|---------------------|
| 8    | Sediment filter     |
| 9    | Pre carbon filter   |
| 10   | Carbon block filter |
| 11   | Drain outlet        |
| 12   | Water inlet         |
| 13   | Condenser           |



### **Touch Panel Description**

| No. | Description           |  |
|-----|-----------------------|--|
| 1   | Up arrow button       |  |
| 2   | LED display           |  |
| 3   | Change filter icon    |  |
| 4   | Self-cleaning UV icon |  |
| 5   | Down arrow button     |  |
| 6   | Lock button           |  |
| 7   | Hot water button      |  |
| 8   | Ambient water button  |  |
| 9   | Cold water button     |  |



### **Product Dimensions**

| Height           | Width              | Depth              |
|------------------|--------------------|--------------------|
| 19.3 in. (49 cm) | 12.5 in. (31.7 cm) | 18.5 in. (46.9 cm) |


### **Operational Specifications**

**CAUTION:** This unit dispenses water at temperatures that can cause severe burns. Avoid direct contact with hot water. Keep children and pets away from unit while dispensing. Never allow children to dispense hot water without proper and direct supervision. Unplug unit to prevent unsupervised use by children.

|            | Temperature             | Tank Volume | Tank Capacity | Flow Rate |
|------------|-------------------------|-------------|---------------|-----------|
| Cold Water | 39°F-59°F / 4°C-15°C    | 3.6 L       | 2.5 L/h       | 1.2 L/min |
| Hot Water  | 174°F–194°F / 79°C–90°C | 1 L         | 4 L/h         | 1.2 L/min |




# Package Contents



| Part | Description                                 | Quantity |
|------|---------------------------------------------|----------|
| Α    | Filter connecting tube                      | 2        |
| В    | Shut off valve tube (7 ft.)                 | 1        |
| С    | Elbow joint tube                            | 1        |
| D    | Filter flushing tube (4 ft.)                | 1        |
| E    | Feedwater adapter (with extra nut)          | 1        |
| F    | Filter housing                              | 3        |
| G    | Filter (sediment, pre carbon, carbon block) | 3        |

| Part | Description             | Quantity |
|------|-------------------------|----------|
| Н    | Mounting bracket        | 3        |
| I    | Locking clip            | 10       |
| J    | Grounding bracket       | 1        |
| K    | Plumber's tape          | 1        |
| L    | Pressure-reducing valve | 1        |
| М    | Tubing cutter           | 1        |

# Materials Needed





Screwdriver

Wrench

### Installation

#### 1. Determine Installation Location

- A. Place the dispenser upright.
- **B.** Locate the dispenser on a hard and level surface in a cool shaded location near a grounded wall outlet and easily accessible to cold water line.

**NOTICE:** Do NOT plug in the power cord until the entire installation section is completed.


**C.** Position the back of the dispenser no closer than 8 in. (20 cm) from a wall and permit free airflow between the wall and water dispenser.




### 2. Install the Dispenser

**WARNING:** To avoid a hazard due to instability of the appliance, it must be secured in place in accordance with the instructions.


**A.** Loosen and remove the screw on the bottom left or right of the dispenser.



**B.** Use this screw to attach the grounding bracket (J) on the left or right bottom corner of the water dispenser.



- **C.** Make a hole on the surface where the water dispenser will be installed.
- **D.** Attach the grounding bracket (J) on the surface by screwing tightly.




#### 3. Flush the Filters


**IMPORTANT:** Follow this procedure every time you replace your filters.

**IMPORTANT:** Ensure the water supply is off before you begin.

**A.** Connect a filter (G) to the filter housing (F) by twisting the filter (G) clockwise.




- **B.** Connect the tip of the shut-off valve tube (B) to the left side of the filter housing (F).
- C. Connect the filter flushing tube (D) to the right side of the filter housing (F) and lay the open end of the filter flushing tube (D) over a sink or receptacle to collect water.



**D.** Follow instructions in table below to flush filters.

**IMPORTANT:** After each filter is flushed, be sure to shut off water supply before disconnecting tubes to flush the next filter.



| Stage 1:<br>Sediment Filter                                             | Stage 2:<br>Pre Carbon Filter                                     | Stage 3:<br>Carbon Block Filter                                   |
|-------------------------------------------------------------------------|-------------------------------------------------------------------|-------------------------------------------------------------------|
| At first, water may appear cloudy.                                      | At first, water may contain black debris.                         | At first, water may contain black debris.                         |
| Flush filter for an additional 4 minutes <u>after</u> water runs clear. | Flush filter for<br>up to 6 minutes<br>or until water runs clear. | Flush filter for<br>up to 4 minutes<br>or until water runs clear. |




### 4. Install the Filters and Tubing

**A.** Click the three black mounting brackets (H) onto the top of the condenser.

**B.** Attach one filter housing (F) to the top of a mounting bracket (H).

**C.** Connect the filter connecting tube (A) to the filter housing (F).






- **D.** Slide the next filter housing (F) onto the middle mounting bracket (H) and connect the other end of the filter connecting tube (A).
- **E.** Repeat for the third filter housing.

**F.** Connect the shut off valve with tube (B) to the left filter housing (F).

- **G.** Connect the filters (G) into the filter housings (F). The sediment filter goes on the left, the pre carbon filter in the middle, and the carbon block on the right.
- **H.** Add locking clips (I) to each connection where indicated.





### 5. Connect to the Cold Water Supply

**CAUTION:** DO NOT CONNECT THIS WATER LINE TO A HOT WATER SUPPLY LINE. The water supply to the unit MUST be from the COLD WATER LINE. Using HOT WATER will severely damage your filters.


**NOTE:** Plumber's tape has been included to facilitate installation. Use it on threaded plumbing connections to ensure a secure seal.

- **A.** Turn off the cold water supply, then disconnect the cold water pipe from the cold water supply line.
- **B.** Connect the feedwater adapter (E) to the cold water supply line.
- **C.** Connect the cold water pipe to the top of the feedwater adapter (E).

**NOTE:** An extra adapter nut is included on top of the feedwater adapter (E) to attach to a 3/8 in. or 1/2 in. feed plumbing line.

- **D.** Cut the shut off valve with tube (B) where indicated using the tubing cutter (M).
- E. Connect the two cut ends of the tubing straight into each end of the pressure-reducing valve (L). Ensure that the arrow will be pointing towards the flow of water into the dispenser when the shut off valve with tube (B) is connected in the next steps.
- **F.** Insert the shut off valve with tube (B) straight into the quick connector piece of the feedwater adapter (E).


**G.** Gently tug on the tube (B) to ensure a secure connection with the feedwater adapter (E).






#### 6. Complete the Installation

**A.** Connect the blue elbow joint tube (C) to the right filter housing (F) and to the water inlet hole on the back of the dispenser.



- **B.** Place locking clips (I) at the two connecting ends of the elbow joint tube (C).
- **C.** Turn on the water supply.



# **Operation**

**IMPORTANT:** This unit has been tested and sanitized prior to packing and shipping. During transit, dust and odors can accumulate in the tank and lines. Dispense and dispose at least one quart of water prior to drinking any water.

### Turn the Dispenser On/Off

**IMPORTANT:** Before you activate the heating and cooling switches, ensure water has filled the tanks inside the dispenser in order to prevent dry heating.

- **1.** Plug in the dispenser.
- 2. Press and hold hot and cold water buttons until water begins to dispense.
- 3. To power on the cooling system, flip the cooling switch on the back of the dispenser to the On position. The cold water button on the front of the dispenser illuminates in blue indicating that the dispenser is cooling water. The light changes to white when the cooling process is complete.
- **4.** To power on the heating system, flip the heating switch on the back of the dispenser to the On position. The hot water button on the front of the dispenser illuminates in red indicating that the dispenser is heating water. The light changes to white when the heating process is complete.



#### Set the Time

- 1. Simultaneously press and hold the up and down arrow buttons for 3 seconds or until displayed time begins to blink.
- 2. To set the hour, press the hot water button. The hour on the clock begins to blink. Use the up and down arrow buttons to scroll to the correct hour. To set the minutes, press the cold water button. The minutes on the clock being to blink. Use the up and down arrow buttons to scroll to the correct minutes.
- 3. Press the lock button until the selected time stops blinking. The time is now set.

### Set the Cold Water Temperature Level

You can select from 3 different cold water dispensing temperature levels: C1 (cold), C2 (colder), and C3 (coldest).

| Temperature Level | Dispensing Temperature Range |
|-------------------|------------------------------|
| C1                | 49°F to 55°F                 |
| C2                | 43°F to 49°F                 |
| C3                | 37°F to 43°F                 |

**NOTE:** The default temperature dispensing level for cold water is C3 (coldest).

To change the cold water temperature dispensing level, please do the following:

- 1. Press and hold the down arrow button for 3 seconds. The cold water button and time display screen begin to flash.
- 2. Press the up or down button to scroll through the 3 options. They will be displayed as C1, C2, and C3. After you have reached the desired temperature level, quickly press the lock button. The new level is now set. It takes approximately 2 hours for the cold water temperature range to adjust to the new level. During the adjustment process, the cold water light will illuminate in blue. Once the new level has been reached, the light will change to white.

**NOTE:** Cold water temperature is measured inside cold reservoir tank. Due to many variables, including but not limited to, ambient temperature, water receptacle size/temperature, internal travel from reservoir tank to dispense point, etc., temperature range of water dispensed will vary from stated range.

### Set the Hot Water Temperature Level

You can select from 3 different hot water dispensing temperature levels: H1 (hot), H2 (hotter), and H3 (hottest).

| Temperature Level | Dispensing Temperature Range |
|-------------------|------------------------------|
| H1                | 178°F to 184°F               |
| H2                | 184°F to 190°F               |
| H3                | 190°F to 196°F               |

**NOTE:** The default temperature dispensing level for hot water is H3 (hottest).

To change the hot water temperature dispensing level, please do the following:

- 1. Press and hold the up arrow button for 3 seconds. The hot water button and time display screen begin to flash.
- 2. Press the up or down button to scroll through the 3 options. They will be displayed as H1, H2, and H3. After you have reached the desired temperature level, quickly press the lock button. The new level is now set. It takes 15 to 20 minutes for the hot water temperature range to adjust to the new level. During the adjustment process, the hot water light will illuminate in red. Once the new level has been reached, the light will change to white.



**NOTE:** Hot water temperature is measured inside hot reservoir tank. Due to many variables, including but not limited to, ambient temperature, water receptacle size/temperature, internal travel from reservoir tank to dispense point, etc., temperature range of water dispensed will vary from stated range.

#### Dispense Cold and Room Temperature Water

**NOTE:** Water will take approximately 1 hour after plugging in and turning on to become completely chilled.

- 1. Place a drinking glass or container under the tap and press the cold water button to dispense cold water or the ambient water button to dispense room temperature water.
- 2. Release the button when your container is full.

### Disable the Child Safety Lock and Dispense Hot Water

CAUTION:

This unit dispenses water at temperatures that can cause severe burns. Avoid direct contact with hot water. Keep children and pets away from the unit while dispensing. Never allow children to dispense hot water without proper and direct supervision. Disable the heating feature by switching the heating switch to the Off position.

**NOTE:** Water will take approximately 15-20 minutes after plugging in and turning on to reach its hottest temperature.

- 1. This water dispenser is equipped with a child safety feature in order to prevent inadvertent dispensing. To disable the child safety lock feature, press the lock button.
- 2. To dispense hot water, place a drinking glass or container under the tap and press the hot water button.
- 3. Release the button when your container is full. Hot water button automatically relocks.

### Troubleshooting

| Problem                              | Solution                                                                                                                                                      |  |
|--------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
|                                      | It takes up to one hour after setup to dispense cold water.                                                                                                   |  |
|                                      | Make sure the power cord is properly connected to a working outlet.                                                                                           |  |
| The cold water is not cold.          | Make sure the back of the dispenser is at least 8 in. (20 cm) from a wall and there is free airflow on all sides of the dispenser.                            |  |
|                                      | Make sure green cooling switch on back of dispenser is On.                                                                                                    |  |
|                                      | It takes 15-20 minutes after setup to dispense hot water.                                                                                                     |  |
| The hot water is not hot.            | Make sure the power cord is properly connected to a working outlet.                                                                                           |  |
|                                      | Make sure red heating switch on back of dispenser is On.                                                                                                      |  |
| The dispenser is noisy.              | Ensure the dispenser is located on a level surface.                                                                                                           |  |
| The dispersion is noisy.             | The heating tube may be generating a slight noise. This is normal.                                                                                            |  |
| The machine is not dispensing water. | The dispenser has become too cold and the lines are blocked by ice. Turn the cooling switch off for at least 4 hours to allow the water in the lines to thaw. |  |



# Cleaning and Maintenance

This dispenser runs on a continuous UV cleaning cycle. It works for 40 minutes (UV icon on the display is on), turns off for 140 minutes, and then cycles back on again as long as the dispenser is plugged in and on.



| Task                       | Frequency      | Instruction                                                                                                                                                                                                                                                                                     |
|----------------------------|----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Sanitizing                 | Every 3 months | Use a disinfectant, purchased separately, following directions from manufacturer for proper amount to use. Use the Cleaning the Dispenser directions when sanitizing.                                                                                                                           |
| Removing minerals deposits | Every 6 months | Mix 4 liters water with 200g citric acid crystals, inject into the machine and make sure the water can flow out of the hot water tap. Switch on the power and allow it to heat for about 10 minutes. After 30 minutes, drain the liquid and clean it with water, dispensing two or three times. |

### Filter Replacement Schedule

| Filter Type  | Model No.  | Replacement Schedule    | Function                                                                                          |
|--------------|------------|-------------------------|---------------------------------------------------------------------------------------------------|
| Sediment     | NFMPP5M    | 6 months or 950 gallons | Performs coarse filtration of inlet water, removing sand, rust, dirt, and other suspended solids. |
| Pre Carbon   | NFMGAC     | 6 months or 950 gallons | Removes chlorine, and other unpleasant tastes and odors.                                          |
| Carbon Block | NFMCTO5MS3 | 6 months or 950 gallons | Performs final polish, removing any residual impurities.                                          |

### Replace the Filters

**IMPORTANT:** Only replace the filters with new filters designed for this dispenser. Any other type of filter will damage the machine and void any warranty.

When the filter indicator light begins to flash, the filters are reaching end of life. When the filter life indicator steadily illuminates and the dispenser beeps, the filters have expired and must be replaced immediately. To replace, do the following:

- 1. Shut off the water supply.
- 2. Remove the old filters and replace with new filters. Ensure filters are installed as follows, from left to right: sediment, pre carbon, and carbon block.
- 3. To flush your new filters, follow the instructions under "Flush the Filters."
- **4.** After replacing the filters, press and hold the filter reset switch (4) on the back of the dispenser for approximately 3 seconds to reset the filter indicator light and to turn off the beeping. When beeping stops, release the switch.



### Filter Specifications

#### **Sediment Filter**

(Sediment, Dirt, and Rust Removal)

| Filter Capacity | 950 Gallons   |
|-----------------|---------------|
| Flow Rate       | 0.8 GPM       |
| Suggested PSI   | 14.5 - 58 psi |
| Temperature     | 33 - 100 °F   |

#### **Carbon Block Filter**

(Final Polish)

| Filter Capacity | 950 Gallons   |
|-----------------|---------------|
| Flow Rate       | 0.8 GPM       |
| Suggested PSI   | 14.5 - 58 psi |
| Temperature     | 33 - 100 °F   |

#### **Pre Carbon Filter**

(Chlorine, Taste, and Odor Reduction)

| Filter Capacity | 950 Gallons   |
|-----------------|---------------|
| Flow Rate       | 0.8 GPM       |
| Suggested PSI   | 14.5 - 58 psi |
| Temperature     | 33 - 100 °F   |

#### Care and Maintenance

- Keep this dispenser in a dry and cool place and avoid direct sunshine.
- Ensure the back of the dispenser is at least 8 in. (20 cm) away from the wall.
- Never put the dispenser on paper or foam, which may store water and then cause creepage. Never put anything flammable beside this machine.
- Do not use the dispenser outdoors or in a place that can be splashed by water.
- If the dispenser is not in use for longer than a 24-hour period, turn off the heating and cooling switches to save power, and drain any remaining water.
- If the water supply is cut off, shut off the water supply and turn the dispenser off. When the water supply is back on, re-open the water supply to the dispenser, turn the dispenser on, and allow the dispenser to run in order to discharge sediment.



### Warranty

Brio ("Vendor") warrants to the original purchaser of the Brio Water Coolers (the "Product"), and to no other person, that if the Product is assembled and operated in accordance with the printed instructions accompanying it, then for a period of one (1) year from the date of purchase, all parts in the Product shall be free from defects in material and workmanship. This Limited Warranty shall be limited to repair or replacement of parts, which prove defective under normal use and service and which Vendor shall determine in its reasonable discretion upon examination to be defective. To take advantage of this Limited Warranty, please follow these steps:

- 1. Please retain your sales slip or invoice, as Vendor may require reasonable proof of your date of purchase.
- 2. Contact Vendor's Customer Service Department using the contact information listed below.
- 3. Return parts to Vendor, per Vendor's instructions, at your cost and expense.
- 4. Upon receipt by Vendor, Vendor shall advise you in writing whether a defect covered by this Limited Warranty exists in any returned part and whether your claim has been approved or denied.
- 5. Upon Vendor's approval of your claim, Vendor will replace such defective part without charge to you.

WHAT THIS LIMITED WARRANTY DOES NOT COVER: This Limited Warranty does not cover any failures or operating difficulties of the Product due to accident, abuse, misuse, alteration, misapplication, improper installation or improper maintenance or service by you or any third party, or failure to perform normal and routine maintenance on the Product, as set out in the User's Manual. In addition, this Limited Warranty does not cover damages to the finish, such as scratches, dents, discoloration or rust after purchase.

This Limited Warranty is the only express warranty given on the Product and is in lieu of all other express warranties. Vendor disclaims all warranties for products that are purchased from seller other than authorized retailers or distributors. THIS LIMITED WARRANTY RESTRICTS THE DURATION OF ANY AND ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION, THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE TO THE ONE (1) YEAR TERM OF THIS LIMITED WARRANTY. UPON THE EXPIRATION OF THE ONE (1) YEAR TERM OF THIS LIMITED WARRANTY, VENDOR DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, THE PRODUCT BEING THUS SOLD AS-IS, WITH ALL FAULTS. FURTHER, VENDOR SHALL HAVE NO LIABILITY WHATSOEVER TO PURCHASER OR ANY THIRD PARTY FOR ANY SPECIAL, INDIRECT, PUNITIVE, INCIDENTAL, OR CONSEQUENTIAL DAMAGES. OTHER THAN THIS LIMITED WARRANTY, THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF. Vendor assumes no responsibility for any defects caused by third parties. This Limited Warranty gives you specific legal rights, and you may have other rights which vary from state to state. State law may also override statements in this Limited Warranty regarding the restriction on the duration of implied warranties. Some jurisdictions do not allow exclusion or limitation of special, incidental or consequential damages, or limitations on how long a warranty lasts, so the above exclusion and limitations may not apply to you.





WWW.BRIOWATER.COM

©2024 Brio Water Technology Inc.