

sinopé


TH1400WF Installation Guide

Smart Low voltage Thermostat (24 Vac)




INSTALL YOUR THERMOSTAT


- 1 Unlock and lift the thermostat cover.




- 2 If necessary, mark and drill the appropriate fastening holes, using the installation template. If needed, use the wall anchors included.




- 3 Depending on the heating system, insert each wire into its terminal and screw firmly. (See connection layouts outlined in the following pages.)




- 4 Use the provided screws and wall anchors to fix the thermostat base on the wall.



- 5 Replace back and lock the thermostat cover.



- 6 Power up the thermostat.



AUXILIARY OUTPUT


The thermostat provides an auxiliary heating output that can act as a second stage of heating when controlling ambient temperature.

If the room temperature is too far from the setpoint or the main stage of heating has difficulties raising the temperature, the auxiliary output activates the secondary heating source to reach the set temperature.


Both outputs can control different types of heating load and can be configured in the user settings.

WIRING LAYOUT


Electric baseboard



Hot water valve




Electric floor heating with electric baseboard on the 2nd heating stage



CONNECTION OF THE FLOOR SENSOR (OPTIONAL)

Only for control applications in floor [F] mode or with floor limit.



ADD YOUR THERMOSTAT TO NEVIWEB

- 1 If you do not have an account yet, download the Neviweb app for iOS or Android to create an account and add your device.



- 2 Tap the , then select "Add Device".




- 3 Follow the steps of the installation wizard.






USER SETTINGS

All of the thermostat's settings can be set through the Neviweb app. However, if you have not created your account and wish to change the temperature format or the control cycle, you need to:

Lower the setpoint to its minimum and hold the  button for 10 seconds to access the menu.

Press the  or the  button to change the setting.

Press the  and the  buttons simultaneously to save and go to the next parameter. Continue to press until the end of the list to exit the menu.



The thermostat features two temperature control modes:

A mode (default): Regulation of ambient temperature with the possibility to limit floor temperature through an external temperature sensor.

F mode: Regulation of floor temperature through an external temperature sensor with the possibility to limit ambient temperature.

PARAMETERS THAT CAN BE CONTROLLED FROM THE DEVICE:

#	Name	Parameters & settings	Display
1	Temp	Temperature format °C or °F – [Default: °C]	°C
2	Control	Control mode of thermostat A [Air], F [Floor] – [Default: A]	A
3	Max Air	Maximum ambient temperature limit 5 °C to 36 °C – [Default OFF]	OFF

PARAMETERS THAT CAN BE CONTROLLED FROM THE DEVICE (continued):

#	Name	Parameters & settings	Display
4	Max Floor	Maximum floor temperature limit 7 °C to 36 °C – [Default: OFF]	OFF
5	Min Floor	Minimum floor temperature limit 5 °C to 36 °C – [Default OFF]	OFF
6	Cyc	Cycle length / Main output 15 sec, 5 min, 10 min, 15 min, 20 min, 25 min, 30 min – [Default: 15 min]	15
7	Aux Cyc	Cycle length / Auxiliary output OFF, 15 sec, 5 min, 10 min, 15 min, 20 min, 25 min, 30 min – [Default: OFF]	OFF
8	Sens	Floor sensor 10K or 12K – [Default: 10K]	10
9	PE	Circulator pump's anti-seizure ON or OFF [Default: OFF]	OFF

PARAMETERS THAT CAN BE CONTROLLED FROM THE DEVICE (CONTINUED):

3) Maximum limit of the ambient temperature (F mode)

Thermostat limits floor heating so as not to exceed the set ambient temperature limit.

4) Maximum floor temperature limit (A mode)

The thermostat limits floor heating to the set temperature to ensure it does not exceed the selected limit. This parameter is ideal for protecting engineered wood floors. [Verify with your flooring manufacturer to determine heat limit.]

This parameter is only usable when a floor sensor is connected to the thermostat.

5) Minimum floor temperature limit (A mode)

The thermostat limits the minimum temperature of the floor in order to keep it at a comfortable temperature.

This parameter can only be used when a floor sensor is connected to the thermostat.

6) et 7) Main and auxiliary output cycle length




The thermostat has a main and an auxiliary output. Select the appropriate cycle length based on your heating system. The selection of an inappropriate cycle length may damage your unit.


Minimum cycle length	0.15	5	10	15	20	25	30
Convector or baseboard heater activated by electronic relay [SSR]	×						
Fan-forced convector activated by electronic relay [SSR]		×	×				
Fan-forced convector or baseboard heater activated by mechanical relay			×	×			
Hydronic heating pump system				×	×	×	×
Furnace				×	×	×	×

9) Circulator pump's anti-seizure

When the thermostat is not heating for an extended period, this parameter will activate the main output during 1 minute every 24 hours to ensure the hydronic system pump does not seize.

DISCONNECT YOUR THERMOSTAT FROM THE WI-FI ROUTER OR THE NEVIWEB APP

To disconnect your thermostat from the Wi-Fi router press the  and  buttons simultaneously for 10 seconds. The  symbol will disappear from the display.



To remove your thermostat from Neviweb, press Delete in the thermostat settings.

TECHNICAL SPECIFICATIONS

Operating voltage: 24 Vac

Maximum load: 1 Amp

Setpoint range: 5 °C to 36 °C [41 °F to 97 °F]

Display range: 0 °C to 70 °C [32 °F to 99 °F]

Resolution: ± 0,5 °C [± 1 °F]

Storage: -20 °C to 50 °C [-4 °F to 122 °F]

Auxiliary output: 24 Vac / Vdc / 0,1 A

Protocol: Wi-Fi

Standard: IEEE 802.11 b/g/n

Frequency: 2.4 GHz

Compatible with:

- Baseboard heater activated by mechanical relay or electronic relay [SSR]
- Fan-forced convector activated by mechanical relay or electronic relay [SSR]
- Electric floor heating (activated by a relay)
- Hydronic floor heating
- Hydronic heating system
- Furnace [without fan control]

Controlling this HomeKit-enabled accessory automatically and away from home requires a HomePod, HomePod mini, or Apple TV set up as a home hub. It is recommended that you update to the latest software and operating system.

Use of the Works with Apple badge means that an accessory has been designed to work specifically with the technology identified in the badge and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

Apple, Apple Home, HomeKit, HomePod, HomePod mini, iPad, iPhone, Siri and Apple TV are trademarks of Apple Inc., registered in the U.S. and other countries and regions.

App Store is a service mark of Apple Inc., registered in the U.S. and other countries.

Neviweb® is a registered trademark of Sinopé Technologies Inc. in Canada and the United States.

Google Play and the Google Play logo are trademarks of Google Inc.

The Wi-Fi CERTIFIED™ Logo is a certification mark of Wi-Fi Alliance®

Transmitter Module IC : 21098-ESPWROOM32 / FCC ID: 2AC7Z-ESPWROOM32

This device complies with Industry Canada license exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device does not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment OFF and ON, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.