

## LED OUTDOOR WALL SCNCE - UP/DOWN CCT & WATTAGE SELECTABLE LR40345


### CAUTION

IN ORDER TO PREVENT POSSIBLE SHOCK, TURN OFF THE MAIN POWER AT THE CIRCUIT BREAKER BEFORE INSTALLING THE LIGHT FIXTURE.

### WARNING


ALL ELECTRICAL CONNECTIONS MUST BE IN ACCORDANCE WITH LOCAL AND NATIONAL ELECTRICAL CODE (N.E.C.) STANDARDS. IF YOU ARE UNFAMILIAR WITH PROPER ELECTRICAL WIRING CONNECTIONS HIRE A QUALIFIED ELECTRICIAN. REMOVE THE FIXTURE AND THE MOUNTING PACKAGE FROM THE BOX AND MAKE SURE THAT NO PARTS ARE MISSING BY REFERENCING THE ILLUSTRATIONS ON THE INSTALLATION INSTRUCTIONS.

### BOX CONTENTS



### TOOLS NEEDED

(NOT INCLUDED)



Phillips screwdriver

### INSTRUCTIONS

**1**

**2**

**3**

**4**

**5**

**6**

**7**

**8**

ONCE INSTALLED, USE WATERPROOF SILICONE (NOT INCLUDED) TO SEAL BETWEEN THE EDGES AND THE FIXTURE.

1	2	CCT	3	4	POWER	5	PHOTOCELL
↑	↑	OFF	↑	↑	24W	↑	ON
↑	↑	3000K	↑	↑	20W	↑	OFF
↑	↑	4000K	↑	↑	15W		
↑	↑	5000K	↑	↑	8W		

SLIDE	LIGHT DIRECTION
←	UP LIGHT
→	UP-DOWN LIGHT