

CHEFMAN[®]

RJ31-SS-V2

2-Slice Pop-Up
STAINLESS STEEL TOASTER



CUSTOMER SERVICE: 888.315.6553 | customerservice@chefman.com

Congratulations on your purchase!

Every Chefman product is manufactured to the highest standards of performance and safety. We are confident that you will be so satisfied with your purchase that Chefman will be your go-to company for appliances in the future.

Customer satisfaction is a key element of our company's philosophy. The Chefman brand exists to fill a void on retail shelves and in consumer kitchens for a truly value-focused kitchen appliance. By questioning and adding value and innovation at every touchpoint in the manufacturer to end user journey, Chefman provides home chefs with the tools they need to achieve picture-perfect results with maximum efficiency. In addition to manufacturing appliances that are dependable, affordable and built with intuitive features to enhance your kitchen experience, we pride ourselves on providing top-of-the-line post purchase support, which includes complimentary access to ClubChefman.com for product tutorials, delicious recipes, how-to videos and access to our team of dedicated chefs.

Should a problem arise, each product is backed by a comprehensive manufacturer's one-year warranty, as well as, outstanding after-sales service support through our dedicated customer service team. In the unlikely event that your product does not operate as described in the manual, please feel free to call or email our helpline for assistance. We understand that sometimes products can malfunction, so if you feel that your appliance is not operating as it should, warranty claims can be made within one year from the date of purchase when accompanied by a dated receipt.

This guarantee is in addition to your statutory rights; your statutory rights are not affected. This limited warranty does not apply in cases of damage caused by accident, improper use, abuse or force majeure.

This warranty gives you specific legal rights. Rights may vary depending on your state or province of residence. Some locations do not allow limitations on implied warranties or special incidental, or consequential damages, so the limitations may not apply to you. This limited warranty will be invalidated if the appliance is tampered with in any way whatsoever.

Our telephone helpline (888) 315-6553 is available for questions or technical assistance Monday through Friday, 9 a.m. to 5 p.m. EST.

Customers can also receive support by emailing customerservice@chefman.com.

INTRODUCTION

Meet the Chefman Pop-Up Toaster. We have a feeling it will become your new favorite go-to for everything from breakfast staples to late-night cravings. This 2-Slice Toaster features 1.5-inch extra-wide slots, so you can toast everything from bagels, bread, English muffins and frozen waffles to challah bread, hamburger buns and veggie burger patties. Its shade selector features seven options, so you can toast your food exactly the way you'd like. Plus, the Toaster's brushed stainless-steel and compact design rightly earns it a prime spot on the countertop.

Ready to start toasting? Read this User Guide before you get started.



READ ALL INSTRUCTIONS BEFORE USE

For your safety and continued enjoyment of this product, always read the instruction manual before using.

FUN FACTS

- The invention of the toaster happened over 100 years ago but didn't become a more common household item until the 1960s.
- Sliced bread was invented in 1933.
- Ever wonder why toasted bread taste so much better? The toasting process is a result of the Maillard reaction. When bread is toasted, its outer layers of sugars and amino acids interact resulting in that golden-brown color and new taste.
- Factory-made white bread is not only a tasty staple but has had some unique uses throughout history. It was once used to clean the frescoes on the ceiling of the Sistine Chapel.

CONTENTS

- 1** Safety Instructions
- 3** Features
- 4** Operating Instructions
- 5** Cleaning and Maintenance
- 6** Cooking Tips/Troubleshooting
- 7** Notes
- 9** Terms and Conditions
- 10** Warranty Card

SAFETY INSTRUCTIONS

IMPORTANT SAFEGUARDS

FOR HOUSEHOLD USE ONLY.

WARNING: When using electrical appliances, especially when children are present, basic safety precautions should always be followed to reduce the risk of fire, electric shock and/or injury to persons, including the following:

1. Read all instructions.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electrical shock do not immerse cord or plugs into water or other liquid.
4. Close supervision is necessary when this Toaster is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
6. Do not operate Toaster with a damaged cord or plug, or after the Toaster malfunctions or has been damaged in any manner. Return Toaster to the nearest authorized service facility for examination, repair or adjustment.
7. The use of accessory attachments not recommended by Chefman may cause injuries.
8. Do not let cord hang over edge of table or counter, or touch hot surfaces.
9. Do not place on or near a hot gas or electric burner, or in a heated oven.
10. Always attach plug to Toaster first, then plug cord into the wall outlet. To disconnect, turn any control to "off," then remove plug from wall outlet.
11. Do not use Toaster for other than intended use.
12. Oversized foods, metal foil packages, or utensils must not be inserted in Toaster as they may involve a risk of fire or electric shock.
13. A fire may occur if Toaster is covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
14. Do not attempt to dislodge food when Toaster is plugged in.

SAVE THESE INSTRUCTIONS.

SAFETY PRECAUTIONS

IMPORTANT SAFEGUARDS

WARNING: This appliance has a polarized plug (one blade is wider than the other). This plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way or force it into the outlet. This could result in injury or electric shock.

SHORT CORD INSTRUCTIONS

A short power supply cord is provided to reduce the hazards of entanglement or tripping over a longer cord. Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use. If a longer detachable power-supply extension cord is used:

1. The marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance.
2. The cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.

POWER CORD SAFETY TIPS

1. Never pull or yank on cord or the appliance.
2. To insert plug, grasp it firmly and guide it into outlet.
3. To disconnect appliance, grasp plug and remove it from outlet.
4. Before each use, inspect the power cord for cuts and/or abrasion marks. If any are found, this indicates that the appliance should be serviced, and the power cord replaced. Please return it to an authorized service representative or contact Chefman Customer Service for assistance.
5. Never wrap the cord tightly around the appliance, as this could place undue stress on the cord where it enters the appliance and cause it to fray and break.


DO NOT OPERATE APPLIANCE IF THE POWER CORD SHOWS ANY DAMAGE OR IF APPLIANCE WORKS INTERMITTENTLY OR STOPS WORKING ENTIRELY.

California Proposition 65:
(Applicable for California Residents only)



WARNING:
Cancer and Reproductive Harm -
www.P65Warnings.ca.gov

FEATURES



1. Toaster
2. 1.5-Inch Toasting Slots (Top)
3. Lever
4. Cancel Button
5. Reheat Button
6. Defrost Button
7. Bagel Button
8. Shade Setting Knob (7 settings)
9. Crumb Tray (Behind)
10. Power Cord (Behind)

OPERATING INSTRUCTIONS

BEFORE FIRST USE

1. Remove all packing materials and stickers from the inside and outside of the Toaster.
2. Gently wipe down the exterior with a damp cloth or paper towel. **WARNING:** Never immerse the Toaster or its plug in water or any other liquid. It is **NOT** dishwasher safe.
3. Read all instructions and follow them carefully.

HOW TO USE

1. Plug in Toaster.
2. Put desired food into Toasting Slots.
3. Turn the Shade Setting Knob to select desired setting. (The higher the number, the more golden-brown and crispy the results will be.)
4. If simply toasting bread, press down the Lever to start Toaster.
 - If reheating, defrosting or toasting bagels, press desired button and then push Lever all the way down. Note: Each button will illuminate as soon as it is pressed.
5. When food is done toasting, it will automatically pop up and Toaster will turn off. If the Reheat, Defrost or Bagel button was selected, it will also turn off.
6. Lift Lever up to raise food higher for easier retrieval.
7. To stop or check food at any time, press the Cancel Button.

SUGGESTED USES:

There's a setting for everyone!

- **Reheat:** Use to warm toasted or cooled bread. May also be used to warm Toaster pastries. This button, regardless of what shade setting is selected, will activate Toaster for 30 seconds.
- **Defrost:** Use to defrost and toast frozen foods like bread and waffles. This button defrosts and toasts simultaneously by increasing the toasting time by 10%.
- **Bagel:** Use for bagels or English muffins. Insert cut bagels or English muffins into Toaster with the cut side facing out. The bagel setting is designed to toast the inside of the bread to desired setting, while just warming the outside. If toasting both sides of the bread is desired, don't use the Bagel Button. This is the only button that toasts one side.

CLEANING AND MAINTENANCE

1. Unplug Toaster and cool completely.
2. When Toaster is completely cool, wipe down Toaster with damp cloth or paper towel to remove any fingerprints or smudges.
3. Remove the Crumb Tray periodically to avoid buildup:
 - Once Toaster is unplugged and fully cool, push the area where the Crumb Tray is at the bottom back of the Toaster. It'll then pop out so you can pull it out.
 - Pull out Crumb Tray.
 - Use a sponge and warm, soapy water to wash. The Crumb Tray is NOT dishwasher safe.
 - Dry completely.
 - Be sure to push Crumb Tray all the way back inside the bottom of the Toaster before next use.

COOKING TIPS

- Beware of hot surfaces when removing food from the Toaster. Warning: Never use metal utensils.
- To make quick and easy croutons in a snap, toast your desired bread on a higher setting. Then crumble over salad or soup.
- Store-bought gluten-free breads tend to be thin and crumble easily, making it difficult to evenly toast and keep in one piece. When shopping for gluten-free breads to toast, choose thicker slices with sturdier crusts.
- Since only the outward elements within the Toasting Slots heat up during bagel mode, be sure to load bagels with the cut sides facing out.
- Lift the Lever all the way up so toast pops out for easier retrieval.

TROUBLESHOOTING

Problem	Cause	Solution
Toaster will not turn on.	Plug could be damaged or power outlet may not be working.	Make sure that the Power Cord is not visibly damaged in any way and that the power outlet being used is working. If the Power Cord is damaged in any way, do not use the Toaster. Call Chefman Customer Service for assistance at 888-315-6553, Monday-Friday 9 a.m. to 5 p.m. EST.
My food is not burnt, but there is a burning smell coming from the Toaster.	Crumbs collect in the Crumb Tray during each use. They may burn if not removed often.	Turn the Toaster upside down and gently shake over a trash bin to remove any excess crumbs. Follow the cleaning and maintenance instructions on page five to remove Crumb Tray completely and clean.
Bread has fallen apart and crumbled inside the Toaster, making it difficult to remove in one piece.	While this Toaster can toast most breads of different sizes and thicknesses, slices that are very thin or crumbly will not toast properly.	Use bread that is thicker, so that it can fully and evenly toast.

TERMS & CONDITIONS

Limited Warranty

CHEFMAN® warrants, subject to the conditions stated below, that from the date of purchase, this product will be free from mechanical defects for a period of ONE (1) year. CHEFMAN®, at its option, will repair or replace this product found to be defective during the warranty period. Should this product become defective by reason of improper workmanship or material defect during the specified warranty period, CHEFMAN® will repair or replace the same effecting all necessary parts replacements for a period of one year from the date of purchase. If product is no longer available we will replace it with a product of equal value. Transportation charges on parts, or products in whole, submitted for repair or replacement, under this warranty, must be borne by the purchaser. This warranty is void if the product is used for other than single-family household use or subjected to any voltage and waveform other than as specified on the rating label (e.g., 120V ~ 60 Hz).

This warranty is available to consumers only. You are a consumer if you own a CHEFMAN® product that was purchased at retail for personal, family or household use. Except as otherwise required under applicable law, this warranty is not available to retailers or other commercial purchasers or owners.

CONDITIONS: This warranty is valid for the original USA and Canada retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty service or replacement. Dealers, service centers, or retail stores do not have the right to alter, modify or in any way, change the terms and conditions of this warranty. Warranty registration is not necessary to obtain warranty on CHEFMAN® Products. Save your proof of purchase receipt.

ABOUT YOUR PRODUCT WARRANTY: Most warranty repairs are handled routinely, but sometimes requests for warranty service may not be appropriate. For example, warranty service would NOT apply if the product damage occurred because of misuse, lack of routine maintenance, shipping, handling, 3rd party warehousing or improper installation. Similarly, the warranty is void if the manufacturing date or the serial number on the product has been removed or the equipment has been altered or modified. During the warranty period, the authorized service dealer, at its option, will repair or replace any part that, upon examination, is found to be defective under normal use and service.

NORMAL WEAR: This warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product; improper voltage or current; use contrary to the operation instructions; deviation from instructions regarding storage and transportation; repair or alteration by anyone other than CHEFMAN® or an authorized service center. Further, the warranty does not cover Acts of God, such as fire, flood, hurricanes and tornadoes. CHEFMAN® shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty. Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty. Some states, provinces or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or province to province.

HOW TO OBTAIN WARRANTY SERVICE: If your CHEFMAN® product should prove to be defective within the warranty period, we will repair it, or if we think necessary, replace it. To obtain warranty service, simply email customerservice@chefman.com or call our toll-free number 1-888-315-6553 for additional information from our Customer Service Representatives, or send the defective product to Customer Service at Chefman, 200 Performance Drive, Mahwah, NJ 07495.

This warranty is effective for the time periods listed above and subject to the conditions provided for within this policy.

CALIFORNIA RESIDENTS ONLY:

California law provides that for In-Warranty Service, California residents have the option of returning a nonconforming product (A) to the store where it was purchased or (B) to another retail store which sells CHEFMAN® products of the same type. The retail store shall then, at its discretion, either repair the product, refer the consumer to an independent repair facility, replace the product, or refund the purchase price less the amount directly attributable to the consumer's prior usage of the product. If the above two options do not result in the appropriate relief to the consumer, the consumer may then take the product to an independent repair facility if service or repair can be economically accomplished. CHEFMAN® and not the consumer will be responsible for the reasonable cost of such service, repair, replacement, or refund for nonconforming products under warranty.

CHEFMAN® is a registered trademark of RJ BRANDS, LLC.

WARRANTY

2-Slice Pop-Up STAINLESS STEEL TOASTER

CHEFMAN®

All data fields are required in order for us to process your request:

Model Number: _____

Full Name: _____

Address: _____

Phone: _____ Email: (if applicable) _____

Date of Purchase*: _____

*We recommend you keep the receipt with this warranty card

Retail Store of Purchase: _____

Description of Malfunction:

Return your completed warranty card to:

**RJ Brands
200 Performance Drive
Suite 207
Mahwah, NJ
07495**

**2-Slice Pop-Up
STAINLESS STEEL TOASTER**

**MODEL:
RJ31-SS-V2**

888.315.6553

customerservice@chefman.com

Phone lines available Monday to Friday, 9 a.m.-5 p.m. EST

1-YEAR LIMITED WARRANTY

CHEFMAN[®]



CLUBCHEFMAN.COM | CHEFMAN.COM | @MYCHEFMAN