

DRUM BEARING REPLACEMENT

DRUM MULCHER


DOC #15-2037

WARRANTY + SERVICE 888.960.0364
PARTS 888.960.0361



DIAMONDMOWERS.COM


DRUM BEARING REPLACEMENT



If bearings have side play, but do not require replacement, retorque the bearings following steps 1, 3-11, 13-14, (both sides), 15 (first bullet only - idle side only), 19-22 (drive side only), 25-30 (idle side only), 34-41, and 43.



ANTI-WRAP PLATES

1 Remove the side covers (1) from each side of the machine.



2 Remove the anti-wrap plates (2).

- Anti-wrap plates (2) are in (2) halves on each side (rear and front).
- Mounting bolts (3) are located around the bearings for each anti-wrap plate (2).
- Note location and orientation of bearing grease hoses (4).



BELT & PULLEYS

3 Loosen the motor mount (5) bolts.

4 Loosen the tension adjustment (6) bolt.


- Loosen the lock nut on the tension adjustment (6) bolt first.

5 Slide the motor mount (7) towards the tension adjustment (6) bolt.


6 Remove the belt (8).

CONTINUED ON NEXT PAGE

DRUM BEARING REPLACEMENT




- 7 Remove the set-screws⁽⁹⁾.
- 8 Thread a set-screw⁽⁹⁾ in the open hole⁽¹⁰⁾ to separate the tapered collar⁽¹¹⁾ from the pulley⁽¹²⁾.
- 9 Tap the tapered collar⁽¹¹⁾ with its shear key⁽¹²⁾ and the pulley⁽¹³⁾ off the drum shaft.




BEARINGS

- 10 Block⁽¹⁴⁾ the drum⁽¹⁵⁾ from rotation.



- 11 Use a floor jack⁽¹⁶⁾ (centered on the drum) to remove all weight from the drum⁽¹⁵⁾ and to center it in its mounts.
 - o **NOTE:** This step is critical in preventing the drum shaft from shifting while installing the bearings.




- 12 Remove remote grease hoses⁽¹⁷⁾ and their elbows.
- 13 Remove the button head screws⁽¹⁸⁾.
- 14 Remove the lock plates⁽¹⁹⁾.

CONTINUED ON NEXT PAGE


DRUM BEARING REPLACEMENT




- 15** Rotate the locknuts ⁽²⁰⁾ counter-clockwise several turns.
- Use a spanner or drift and hammer.
 - Unbolt the bearing bolts ⁽²¹⁾ and slide the bearings off the drum stub shafts ⁽²²⁾.
 - It may be necessary to thread in removal bolts ⁽²³⁾ to force the bearing off the drum stub shafts ⁽²²⁾.



- 16** Replace the drive side (non-floating) bearing (part #10-1068) onto the drum stub shaft ⁽²²⁾.
- Turn locknut ⁽²⁰⁾ counter-clockwise until the bearing will freely slide onto the drum stub shaft ⁽²²⁾.
 - **NOTE: BOTH** bearings need to be loosened prior to tightening the drive side bearing. Drive side bearing **MUST** be tightened **FIRST /BEFORE** the idle side bearing.




- 17** Replace the bearing bolts ⁽²¹⁾.
- Use Loctite 262 with primer 7649 on bolt threads ⁽²¹⁾.
 - Torque the bearing bolts ⁽²¹⁾ to 107ft-lbs (145Nm).
 - Confirm even gaps on either side of the drum ⁽¹⁵⁾ relative to the housing.
 - **NOTE:** Spacers may be used to center drum when tightening bearings ($\frac{1}{4}$ " for 60" units, and $\frac{3}{8}$ " for 72").




- 18** Rotate the locknut ⁽²⁰⁾ clockwise with both hands as tight as possible.
- Tap the locknut ⁽²⁰⁾ evenly all the way around its circumference, **WHILE** tightening the locknut ⁽²⁰⁾ again. Repeat until the locknut ⁽²⁰⁾ can no longer be rotated by hand.

CONTINUED ON NEXT PAGE


DRUM BEARING REPLACEMENT



- 19** Using the spanner socket ⁽²⁴⁾ (part #24-0378) and a torque wrench, torque the bearing locknut ⁽²⁰⁾.
- Torque to 250ft-lbs (339Nm).
 - Tap the locknut ⁽²⁰⁾ evenly all the way around its circumference and retorque again to 250ft-lbs (339Nm).
 - **NOTE:** Repeat this step 3 times; this is extremely important!



- 20** Replace the lock plate ⁽¹⁹⁾.
- Align tang of lock plate ⁽¹⁹⁾ with the adapter sleeve slot ⁽²⁵⁾.
- 21** **TIGHTEN, NOT LOOSEN** the locknut ⁽²⁰⁾ until the lock plate ⁽¹⁹⁾ slot overlaps the button head screw ⁽¹⁸⁾ holes.
- 22** Replace the button head screws ⁽¹⁸⁾.




- 23** Replace the idle side (floating) bearing (part #10-1069) and slide it onto the drum stub shaft ⁽²²⁾.
- Turn locknut ⁽²⁰⁾ counter-clockwise until the bearing will freely slide onto the drum stub shaft ⁽²²⁾.




- 24** Replace the bearing bolts ⁽²¹⁾.
- Use Loctite 262 with primer 7649 on bolt threads ⁽²¹⁾.
 - Torque the bearing bolts ⁽²¹⁾ to 107ft-lbs (145Nm).

CONTINUED ON NEXT PAGE

DRUM BEARING REPLACEMENT




25 Push the adapter sleeve ⁽²⁶⁾ insert in as far as possible (towards the drive side bearing).




26 Rotate the locknut ⁽²⁰⁾ clockwise with both hands as tight as possible.

- Tap the locknut ⁽²⁰⁾ evenly all the way around its circumference, **WHILE** tightening the locknut ⁽²⁰⁾ again. Repeat until the locknut ⁽²⁰⁾ can no longer be rotated by hand.



27 Using the spanner socket ⁽²⁴⁾ (part #24-0378) and a torque wrench, torque the bearing locknut ⁽²⁰⁾.

- Torque to 250ft-lbs (339Nm).
- Tap the locknut ⁽²⁰⁾ evenly all the way around its circumference and re-torque again to 250ft-lbs (339Nm).
- **NOTE:** Repeat this step 3 times; this is extremely important!



28 Replace the lock plate ⁽¹⁹⁾.

- Align tang of lock plate ⁽¹⁹⁾ with the adapter sleeve slot ⁽²⁵⁾.

29 **TIGHTEN, NOT LOOSEN** the locknut ⁽²⁰⁾ until the lock plate ⁽¹⁹⁾ slot overlaps the button head screw ⁽¹⁸⁾ holes.

30 Replace the button head screws ⁽¹⁸⁾.

31 Confirm axial play in the drum falls within range; if not, loosen idle side bearing, make necessary adjustments, and then retighten the idel side bearing.


- Drum axial play range is from 0.015" to 0.045".

CONTINUED ON NEXT PAGE

DRUM BEARING REPLACEMENT




- 32** Replace remote grease hoses ⁽¹⁷⁾ and their elbows for both bearings.
- Route the grease hoses through their brackets (if applicable), confirming the hoses / elbows are orientated as observed and noted earlier.
- 33** Grease both bearings until grease is observed purging from the bearings.
- Use synthetic / blend #2 lithium based grease.
 - Spin the drum ⁽¹⁵⁾ while greasing to evenly distribute the grease in the bearings.




BELT & PULLEYS

- 34** Tap the tapered collar ⁽¹¹⁾ with its shear key ⁽¹²⁾ and the pulley ⁽¹³⁾ onto the drum shaft.
- 35** Thread the set-screws ⁽⁹⁾ into the (2) holes (not in hole ⁽¹⁰⁾) to pull together the tapered collar ⁽¹¹⁾ and pulley ⁽¹³⁾.



- 36** Use a straight edge ⁽²⁷⁾ to confirm the drum pulley ⁽¹³⁾ is aligned with the drive pulley.
- If the pulleys are not straight, loosen the tapered collar ⁽¹¹⁾ with its shear key ⁽¹²⁾ from the drum pulley ⁽¹³⁾ as described in steps 7-8, move the drum pulley ⁽¹³⁾ and tapered collar ⁽¹¹⁾ with its shear key ⁽¹²⁾ the desired direction and amount, and repeat steps 35-37.
 - Repeat as needed until the pulleys are aligned.


- 37** Reinstall the belt ⁽⁸⁾.
- **NOTE:** Replace the belt if wear or damage is noted.



- 38** Tighten the tension adjustment ⁽⁶⁾ bolt until the belt ⁽⁸⁾ is taught.
- Loosen the lock nut on the tension adjustment ⁽⁶⁾ bolt first.
- 39** Pulling upward on the belt in the location illustrated, belt ⁽⁸⁾ deflection should be within the notched cutout ⁽²⁷⁾ of the tension gauge when the belt is cold (not been running).
- **NOTE:** Older units without the notched cutout:
 - Deflect the belt ⁽⁸⁾ in-between the pulleys up and down.
 - Total deflection ⁽²⁸⁾ should be in-between 1- $\frac{1}{4}$ - 1- $\frac{3}{16}$ " (32-46mm) when the belt is cold (not been running).
 - Adjust the tension adjustment ⁽⁶⁾ bolt as needed.


CONTINUED ON NEXT PAGE

DRUM BEARING REPLACEMENT




ANTI-WRAP PLATES

- 40** Tighten the motor mount ⁽⁵⁾ bolts.
- Re-check belt ⁽⁸⁾ deflection and repeat steps 38-40 as needed.
- 41** Tighten the lock nut on the tension adjustment ⁽⁶⁾ bolt.



- 42** Replace the anti-wrap plates ⁽²⁾.
- Anti-wrap plates ⁽²⁾ are in (2) halves on each side (rear and front).
 - Mounting bolts ⁽³⁾ are located around the bearings for each anti-wrap plate ⁽²⁾.



- 43** Replace the side covers ⁽¹⁾ for each side of the machine.

