


## Hickory Timer Tips



### Setting / Resetting the Time of Day

In the event of a power failure the timer display will be flashing. To reset the Time of Day, press both buttons "B" & "C" simultaneously and while holding these buttons depressed; toggle the plus and minus buttons "D" & "E" to set the time of day.

### Entering Manual Mode

To insure that the timer does not interrupt the cooking cycle(s), you must make sure that the cook pot symbol is always illuminated on the timer. No other icons should be illuminate i.e. a steady or flashing "A". To enter this manual mode; press both buttons "B" & "C" simultaneously. This will clear any accidental programming stored in the timer and place the timer into the manual cooking mode.

### Bell/Time Function

To use the timer as a count down timer; press and release the bell button "A". Immediately press the plus (+) button "E" and set the cook time desired. (i.e. 1hr 30 minutes). After the time has elapsed, the timer will beep. You can add additional time by repeating the above-mentioned process. You can also decrease the cooking time by pressing the minus (-) button "D" instead of the plus button "E".

### Louder Beep/Buzzer

Occasionally, if the wrong button is depressed it will quiet the beep/buzzer. The audible tone may change to a much lower tone. To get the loudest tone available; press both the plus (+) and minus (-) buttons "D" & "E" simultaneously. Continue to press and release both buttons until you have reached the desired tone. The unit is programmed with one loud and two low tones.

### Silencing the Beep/Buzzer

Press the bell button "A".