

Kaadas

Q9 FVP User Manual

www.kaadasgroup.com

Shenzhen Kaadas Intelligent Technology Co.; Ltd
reserves all rights for the final interpretation to this user manual.

All design and specifications are subject to change without notice.

Cautions:

This section contains important information to ensure the user's safety and prevent potential damage to property. Please, read this section carefully and use the product accordingly.

Contents

1 Important information

Security

Warning

Disposal of old products and batteries

2 Installing your smart lock

Product content

Lock explosive view

Before installing

Change latch bolt direction

Installation steps

3 Know your smart lock

Front panel

Back panel

4 Set up your smart lock

Before setting

Access into master mode

User settings

System settings

Network configuration

Installation settings

5 Use your smart lock

Outdoor unlocking

Mechanical key unlocking

Electronic unlocking/locking

Quickly open the handle to unlock

Indoor anti-lock

Silent mode

Remote doorbell

6 Other functions

Restore factory Settings

Emergency power supply

Battery replacement method

1 Important information

Security

- ◆ Please read and understand all instructions before using this smart lock. Damage caused by failure to comply with the instructions is not covered by the warranty.
- ◆ It is recommended to use the accessories and fittings specified by our company.
- ◆ Use only the batteries provided with this product.
- ◆ Do not forcibly disassemble the product as this may cause an alarm or damage the product.
- ◆ Do not scratch the finger vein sensor with sharp objects, as this may cause permanent damage.
- ◆ Do not expose the product to corrosive substances that could damage the protective layer of the finger vein sensor.
- ◆ Do not hang objects on the handle/grip, as this may affect the normal use of the door lock.
- ◆ To clean the product, please use a cleaning cloth.
- ◆ Do not disassemble the battery while the device is in operation.
- ◆ Please choose a professional engineer to install the door lock and follow our installation standard, do not disassemble and install it by yourself.
- ◆ After the door lock installation and commissioning, please modify the default management password set by the factory at the first time and keep the mechanical key properly, do not easily disclose the password information.
- ◆ After the door lock triggers low battery alarm, please replace all the batteries in time and ensure the correct installation.

Warning

- ◆ Do not put the battery near the fire source to avoid explosion.
 - ◆ Do not use an emergency power source that does not meet safety regulations to power this product.
 - ◆ Do not use metal to short-circuit the two poles of the battery leads to avoid an explosion.
 - ◆ Ensure that a Kaadas or Kaadas-authorized service center or professional repair person performs the replacement.
 - ◆ Use of accessories or parts made by other manufacturers, or not specifically recommended by Kaadas, may void your warranty.
-


Disposal of used products and batteries

- ◆ Please inform yourself about the local collection system for sorting electronic products.
- ◆ Please follow local regulations and do not dispose of used batteries in the general household garbage.
- ◆ Please dispose of old batteries properly to help avoid potential negative impacts on the environment and human health.
- ◆ Batteries should not be disposed of with regular household garbage.


2 Installing your smart lock

Product content


This Product content is for reference only, everything is subject to the contents of the physical package.




Front panel
(with rubber gasket)




Back panel
(with rubber gasket)




Drilling template




Mortise



Strike Plate
Assembly



Mechanical key
& lock cylinder



Lithium Battery &
User Card




Screw pack



User Manual

Lock explosive view

This lock explosive view is helpful to learn lock's structure.




- 1、 Battery cover
- 2、 Battery
- 3、 Back panel top cover
- 4、 M6 cross slot countersunk head screws(3pcs)
- 5、 Tower spring
- 6、 Fixed plate (Install the two lower screws without installing the fixing plate)
- 7、 M4 cross recessed countersunk head screws (4 pcs.)
- 8、 M6 solenoid tube (3 pieces)
- 9、 Front panel components
- 10、 Plastic rear panel lower cover
- 11、 Back panel components
- 12、 Iron knob pick
- 13、 Lock cylinder
- 14、 Square shaft
- 15、 Plastic cylinder protector
- 16、 M6 hexagon socket set screw (1 piece)


Before installing

Determine the position of the smart lock on the door before installing.

On the left side of the door




On the right side of the door



Change latch bolt direction

2、 Rotate the oblique tongue 180° in the direction of the arrow.


1、 Toggle the reversing paddle in the direction of the arrow.




3、 Press in the oblique tongue in the direction of the arrow.

4、 Toggle the reversing paddle in the direction of the arrow.


Installation steps




Drill holes on the door according to the hole template, put the lock body into the door frame.



Tighten the four fixing screws on the lock body .




Install the lock cylinder and cylinder protector (the lock cylinder is installed lower than the door surface).




Install the connecting tube into the corresponding position as shown in the figure and lock it.

⚠ Note: The top connecting screw bolt can be selected according to the actual situation.




Pass the connecting cable through the cable opening above the door, with the front panel facing. Insert the lock core hole of the front plate, lock the fixing plate, and make the outside The board fits snugly to the outside of the door.

⚠ Note: Without the top screws, the mounting plate can be left in place.




Assemble the rear panel components and install the solid limit tapping square steel, pagoda spring, and iron knob pick.


⚠ Note: Iron knob toggle wrenches to desired length.




Snap off the plastic rear panel cover and battery cover assembly and rear panel trim.




Install the rear panel assembly and tighten the corresponding screws.




Insert the corresponding wire into the corresponding socket .




Snap on the battery cover assembly and plastic back panel lower cover.



Snap on the battery and plastic back panel top cover.




Assembly completed.




Push and pull the inner and outer handles and mechanical key to check whether all components are connected properly.

3 Get to know your smart lock

Front panel



Back panel



⚠ Note : This schematic diagram is for illustrative purposes only, please refer to the actual product.

4 Set up your smart lock

4.1 Before setting

Default master PIN code is 12345678, you need to change the master PIN code before you can perform other operations

The operation of modifying the master PIN code for the first time:


1. Wake up touchscreen keypad with palm.
2. Press [*] twice, input master PIN code, and press[#] confirm.
3. Voice prompt: PIN code is too simple, change master PIN code, end with pound key.

△Note: In the initial state, you need to modify the administrator password to perform other operations.

	Security mode	Normal mode
Master PIN code	Security mode supports master password participation authentication / Master passwords can verify to unlock in Security mode,	Initial state master password: 12345678
Password	One-time passwords are forbidden	One-time passwords can be used
User fingerprint	Support	Support
User finger vein	Support	Support
User face	Support	Support
User card	Support	Support
Enter management pattern square Law	By entering the admin password Manage finger veins by typing Manage fingerprints by typing Avoid setting and managing finger veins and fingerprints to be the same as user finger veins and fingerprints	By entering the admin password Manage finger veins by typing Manage fingerprints by typing

△ Before setting the security mode, you must first enter more than two users; double verification: user password. Dummy passwords are supported both before and after the code (the user password and dummy password together do not exceed 20 digits) .

4.2 Access into master mode



1. Wake up touchscreen keypad with palm;
2. Press the [*] twice, input master PIN code, and press[#] confirm;
3. Voice prompt: Master mode, for user settings, press 1, for system settings, press 2, connecting settings, press 4; installation settings, press 5.

4.3 User settings

Add a normal user:

When adding a user, the door lock automatically recognizes and adds password, fingerprint, finger vein, and card. The user can directly add the corresponding key type.

in master mode:



Press the 1 button to enter the user settings, then press the 1 button to enter the addition of ordinary users, follow the voice prompts to enter the fingerprint or finger vein or enter the password or swipe the card until the voice prompts: Added successfully.

△Note: When inputting and verifying, fingers need to touch the raised contacts at both ends of the finger vein module.

Add a one-time temporary password:

in master mode:



Press the 1 button to enter the user settings, and then press the 2 button to add a one-time temporary password.

The voice prompts you to enter a new temporary password and ends with the # key until the voice prompts: Added successfully .

Add face

in master mode:



Press the 1 button to enter the user settings, and then press the 3 button to enter the adding face. Follow the voice prompt: Please face the door lock camera until the voice prompt: Added successfully.

Add (modify) master fingerprint

in master mode:



Press 1 button to enter user settings, then press 4 button to enter adding (modifying) fingerprint management, according to the language The voice prompts you to enter the new management fingerprint until the voice prompts: Added successfully.

Add (modify) master finger vein

in master mode:



Press the 1 button to enter the user settings, and then press the 5 button to enter the add (modify) master finger vein. Follow the voice prompts to enter the new management finger vein until the voice prompts: Added successfully.

Note: When inputting and verifying, fingers need to touch the raised contacts at both ends of the finger vein module.

Modify master password

in master mode:



Press the 1 button to enter the user settings, then press the 6 button to enter the management password modification, enter the new management password according to the voice prompts and end with the # key, until the voice prompts: Setting successful.

Delete users

in master mode:



Press 1 key to enter user settings, then press 7 key to enter user deletion, then press 1 key to delete a single password , enter the password according to the voice prompts or enter a two-digit number and end with the # key until the voice prompts: Deletion successful .



Press the 1 button to enter the user settings, then press the 7 button to enter the user deletion, and then press the 2 button to delete a single fingerprint . Press the fingerprint according to the voice prompts or enter a two-digit number and end with the # key until the voice prompts: Deletion successful.



Press the 1 button to enter the user settings, then press the 7 button to enter the user deletion, and then press the 3 button to delete a single finger vein. Press the finger vein according to the voice prompts or enter a two-digit number and end with the # key. Until the voice prompt: Deletion successful .



Press 1 key to enter user settings, then press 7 key to enter user deletion, and then press 4 key to delete a single card . Follow the voice prompts to swipe the card or enter the number and end with the # key until the voice prompts : Deletion successful.



Press 1 key to enter user settings, then press 7 key to enter user deletion, and then press 5 key to delete a single face. Please verify the face or enter the number and end with the # key until the voice prompts: Deletion successful.



Press 1 key to enter user settings, press 7 key again to delete users, press 6 key again to delete all users , then press 1 key to delete all passwords, voice prompt: deletion successful, password library is empty.



Press the 1 button to enter the user settings, then press the 7 button to enter the deletion of users, then press the 6 button to delete all users, and then press the 2 button to delete all fingerprints. Voice prompt: Deletion successful, fingerprint database is empty.



Press the 1 button to enter the user settings, then press the 7 button to enter the delete user, and then press the 6 button to delete all users. User, press 3 again to delete all finger veins. Voice prompt: Deletion successful, finger vein database is empty.



Press the 1 button to enter the user settings, then press the 7 button to enter the delete user, and then press the 6 button to delete all users. account, and then press 4 to delete all cards. Voice prompt: Deletion successful, card library is empty.



Press the 1 button to enter the user settings, then press the 7 button to enter the delete user, and then press the 6 button to delete all users. account, and then press key 5 to delete all faces. Voice prompt: Deletion successful, face database is empty.

4.4 System settings

Voice settings

in master mode:



Press the 2 button to enter the system settings, and then press the 1 button to enter the voice settings.
Press 1 button to set to high volume mode;
Press the 2 button to set to low volume mode;
Press the 3 button to set it to silent mode, and there will be no voice prompts in the entire system.

Note:

In addition to the alarm sound and operation management menu.

Language settings

in master mode:



Press the 2 button to enter the system settings, and then press the 2 button to enter the language settings.

Press 1 to change to Chinese

Press 2 to change to English

Press 3 to switch to Russian

Press 4 to switch to Kazakh

Energy saving settings

in master mode:



Press the 2 button to enter the system settings, and then press the 3 button to enter the energy saving settings:

Press the 1 button to turn off (turn on) the video function, and the voice prompts: Setup successful;

Press the 2 button to turn off (turn on) the face recognition function , voice prompt: Setup successful ;

Press 3 key to enter sensor settings: press 1 key to set high sensitivity, press 2 key to set low sensitivity Sensitivity, press button 3 to set the sensor off, voice prompt: Setup successful .

Turn on /off dual verification

in master mode:



Press the 2 button to enter the system settings, then press the 4 button to turn on (or turn off) two-factor authentication, and the voice prompt Display : Setup successful.

Turn on /off automatic mode

in master mode:



Press the 2 button to enter the system settings, then press the 5 button to turn on (or turn off) the automatic mode, and the voice prompt Display : Setup successful.

4. 5 Network configuration

in master mode:



Press the 4 button to enter the network configuration settings, and then press the 1 button to join the network. The lock end voice prompts: The network distribution state has been entered.

Press the 4 key to enter the distribution network settings, and then press the 2 key to exit the network. The lock end voice prompts: Exiting the network successfully.

Network Configuration In the mobile application market, search for “Tuya Smart,” download and install it. After logging in, follow the instructions in the app to add devices for network configuration.

Note:

The door lock currently only supports connecting to WiFi routers with 2.4G frequency band (the 5G frequency band is not supported), please confirm Ensure that the visible distance between the router and the door lock does not exceed 10 meter , otherwise it will affect the signal connection effect.

4.6 Installation settings

Door opening direction setting

in master mode:



Press the 5 button to enter the installation settings, then press the 1 button to enter the door opening direction setting, and then press the 1 button to lock On the left side of the door, there is a voice prompt on the lock end: Setup successful.

Press the 5 button to enter the installation settings, then press the 1 button to enter the door opening direction setting, and then press the 2 button to lock On the right side of the door, the lock end voice prompts: Setup successful.

Lockpicking force settings

in master mode:



Press the 5 button to enter the installation settings, then press the 2 button to enter the unlocking force setting, and then press the 1 button to high twist Power, lock end voice prompt: Setting successful.

Press the 5 button to enter the installation settings, then press the 2 button to enter the unlocking force setting, and then press the 2 button to twist Power, lock end voice prompt: Setting successful.

Press the 5 button to enter the installation settings, then press the 2 button to enter the unlocking force setting, and then press the 3 button to lower the torque. Power, lock end voice prompt: Setting successful.

Latch tongue rebound time setting

in master mode:



Press the 5 key to enter the installation settings, then press the 3 key to enter the latch rebound time setting, and then enter the latch The tongue rebound time is 2~9 seconds, and the lock end voice prompts: X seconds set successfully.

Automatic lock time setting

in master mode:




Press the 5 key to enter the installation settings, then press the 4 key to enter the automatic lock time setting, and then enter the automatic The automatic locking time is 10~90 seconds, and the lock end voice prompts: X seconds set successfully.

5 How to use your smart lock


Outdoor unlocking (common mode)

Password unlocking




Touch the numeric keyboard area to call Wake up the system; on the numeric keypad area input has been added password , press # key to confirm; The sound prompts that the door has been opened. Push or pull the handle to open the door.

Fingerprint



Place the added fingerprint in the fingerprint recognition area. Voice announcement door opened, push or pull handle to open door.

Finger Vein Unlocking




Place the added finger on the finger vein sensor. Push or pull the handle to open the door.

3D face unlocking



When the user approaches the door lock, the door lock automatically starts face recognition, and the recognition is confirmed successfully; the voice prompts that the door has been opened, and the door is opened by pushing or pulling the handle.

NFC unlocking




Place the added card in the card recognition area. Voice prompts that the door has been opened, push or pull the handle to open the door.

Green: When the indicator light is green, it means the verification is successful and the lock can be unlocked;
Red: When the indicator light is red, it means a verification error or an alarm is generated.

Note: When incorrect passwords/fingerprints/finger veins/cards are entered five times in a short period of time, all functions of the smart lock will be locked for 100 seconds.

Mechanical key unlocking



in the event of an emergency such as forgotten password, battery drain, or system failure, The spare mechanical key can be used to open the lock .


Insert the mechanical key and turn it 180° to push or pull the door to unlock.

If the lock is on the left side of the door, turn the mechanical key clockwise,

If the lock is on the right side of the door, turn the mechanical key counterclockwise.


Electronic unlocking/locking

1. Click the lock button (CLOSE) to close the lock
2. Click the unlock button (OPEN) to unlock




Quickly open the handle to unlock

Turn the quick-opening handle 45° to open the door.



Indoor anti-lock


Hold the knob under the rear panel , push it in gently and rotate it at the same time. The indoor anti-lock can be opened /closed.




Silent mode

When the system is in voice mode, after waking up the door lock outdoors, press and hold  to enter silent mode.

When the system is in silent mode, after waking up the door lock outdoors, press and hold  to switch to voice mode.



Remote doorbell (visual cat-eye)



Doorbell

Press the doorbell button and the lock will sound ding-dong indoor. At the same time, the door lock sends a doorbell message to the associated App, click on the pushed doorbell message that opens the cell phone App, at this time the cell phone terminal and the door lock can be remote visual intercom, and the video process can be remotely opened the door with one key. After opening the door, the door lock will capture the beginning of a video and retain it.


⚠ Note:

When using this function, please pay attention to the safety complete. Make sure the situation outside the door is safe complete, you can open the door.

6 Other functions

Restore factory settings

If you accidentally forget the management password, you can press and hold the left and right keys on the rear panel display of the door lock for 5 seconds to change the voice prompt: " Please press the # key to continue restoring factory settings." Press the # key to confirm, the system will restore factory settings.




Press and hold the left and right buttons for 5 seconds

⚠ Note:

After restoring to factory settings , all previously set door opening passwords/fingerprints/finger veins/cards The pictures /faces will be cleared, and the management password will be restored to the default 12345678. After initialization, the management password will be forced to be changed.

Emergency power supply

When the battery voltage is insufficient to open the door from the outside, you can use a 5V rechargeable battery as an emergency power source to power up the door lock through the Type-C connector, and after opening the door lock, please replace the battery immediately.




Note:

When the battery power is too low, the system will prompt you with a voice every time it wakes up. Indicates low battery, please replace the battery; please replace the battery in time at this time.

Battery replacement method

When the system voice prompts: "Battery is low, please replace the battery", you need to Charge the battery .



Shenzhen Kaadas Intelligent Technology Co.,Ltd.

ADD: Floor 11, Building B2, Phase 2, Creative City, Xiandong Road, Xili Community, Xili Street, Nanshan District, Shenzhen, Guangdong, 518000. China