• 35mm F1.4 AS UMC **Instruction Manual**

Thank you for purchasing our lens. We believe that this new 35 mm F1.4 AS UMC lens will give you a special photographic experience.

Advantages of the 35 mm F1.4 AS UMC

close-ups. 2. A single glass aspherical lens that results in sharp images throughout,

1. A floating design that leads to sharp images both for long shots and

- even at the periphery. 3. Two high refraction lenses that are made of premium optical glass.
- 4. An ultra-multi-coating (UMC) design that suppresses ghosting and delivers clear images.
- 5. Eight aperture stops, which enables effective out-focusing.

This product is designed with its own mount. Hence, you can easily take photographs without installing an additional adaptor, mounting the lens directly onto the camera.

Read this instruction manual carefully and use it properly. * Please familiar yourself with the 'Safety Precautions' at the back of this instruction manual, and use the product according to them.

Read this instruction manual prior to use.

The 35 mm F1.4 AS UMC lens mount is uniquely designed for Nikon (Fujifilm) F, Pentax (Samsung GX) K, Sony (Minolta) α, Canon, Four-Thirds, and Samsung NX cameras.

2. Attaching and Detaching to/from Camera

. Hold the hood of the lens gently.

- 2. Align the depth of field scale of the lens with the lens attachment reference point on the camera.
- 3. Push the lens into the camera and turn the lens gently until it makes a clicking sound and the depth of field scale is positioned at the top. 4. The Nikon mount is a lens (AE) in which a CPU is installed. Turn the aperture adjustment ring on the lens until it is set to the minimum aperture value (F22). (For the lens to be able to communicate with an AF camera, the aperture adjustment ring on the lens must be turned until F22, the F-number marked on the aperture adjustment ring, is aligned exactly with the depth of field scale on the lens.)

[Detaching] Hold the hood of the lens gently, press the lens release button on the camera, turn the lens until the depth of field scale of the lens is aligned with the lens attachment reference point on the camera, and then pull the lens away.

3. Focus Adjustment

You can set the focus for a subject by turning the focus adjustment ring when

using the 35 mm F1.4 AS UMC lens, as it is a Manual Focus (MF) adjustment

- [Nikon (Fujifilm) / Pentax (Samsung GX) Mount]
- turn the focusing ring to the left (from ∞ to 1) and focus on the clearest subject using the camera's indication signal, or by checking visually. ② To change the focus from a subject that is close to a subject that is far away, turn the focusing ring to the right (from 1 to ∞) and focus on the clearest subject using the camera's indication signal, or by checking visually.

① To change the focus from a subject that is far away to a subject that is close,

- 2. Camera without contacts (Non-AF camera) ① Turn the aperture adjustment ring to set the brightness you want.
- The user can set the brightness he/she wants by turning the aperture adjustment ring when using the lens.

[Canon M/ Fujifilm X/ Sony α/ Sony E/ FT/MFT/NX Mount]

① Turn the aperture adjustment ring to set the brightness you want. The user can set the brightness he/she wants by turning the aperture adjustment ring when using the lens.

[Canon EOS Mount]

① Camera without contacts (Non CPU LENS) You can set the brightness adjusting the aperture ring.

so that you can get a proper result with appropriate light.

- ② The lens which has an electric contact (AE LENS)
- Built-in aperture operating motor in the lens helps setting the aperture value by By the communication between camera and lens, exposure is set automatically

(At M mode, you can set the aperture manually by yourself (Regarding detailed explanation about shooting mode, please refer to the user manual made by camera manufacturer or contact camera manufacturer directly)

[Aperture adjustment ring markings] ① Canon(Non cpu lens/ Canon M/ Fujifilm X/ Nikon(fujifilm) F/ Samsung NX/

Sony α/ Sony E/ FT/ MFT Mount

② Pentax(Samsung GX) K

22 16 11 8 5.6 4 2.8 2 1.4

Each number is 1 stop (1 EV) away from the next number.

A 22 16 11 8 5.6 4 2.8 2 1.4

Brightness can be set more precisely by using the stop setting in-between. (However, the Sony (Minolta) mount is only controlled in steps of 1 stop)

From F no.1.4 to 2.0 and 16 to 22 are 1 stop(1EV) based.

22 16 11 8 5.6 4 2.8 2 1.4

brightness of F1.4.

6. About Photography

an appropriate level and then take the photo.

The aperture of the 35 mm F1.4 AS UMC lens supports a maximum

Between F no.2 and 16, they are 0.5 stop(0.5EV) based.

If you take a photo outdoors exposed to sunlight, you may not get a clear image because the subject is too bright. Therefore, adjust the brightness to

22 16 11 8 5.6 4 2.8 2 1.4

Since the depth of field becomes very shallow at F1.4, if the subject is not focused correctly you may get an unclear image. Therefore, to get a clear image, focus the subject correctly and then take the photo.

7. Camera Settings


Some cameras require special settings when using this lens.

Please read the information below and set your camera accordingly.

The diaphragm of the 35mm F1.4 AS UMC Canon mount is not compatible with If the brightness is set to F8 or above, you may not be able to set the correct focus due to a difficulty in viewing the subject through the camera viewfinder. Turn the aperture adjustment ring so it is fully open when attaching the lens to the camera, and then set the depth of field and brightness you want prior to shooting

1) Set the camera mode dial to M.

O Canon Mount (Non cpu lens)



length and the brightness. With these Nikon cameras, you can use the MF lens more efficiently by entering the focal length and the brightness.

3. When an MF lens is attached, some Nikon cameras allow you to enter the focal

O Nikon (Fujifilm) F Mount

1. Set the camera mode dial to M.


2. Set the focus adjustment lever of the camera to M.

* The shutter speed of some Nikon cameras changes automatically if the focal length and the brightness are set, and the desired brightness is set in A/S/P mode by turning the aperture adjustment ring.

(The settings for the camera or the menu may vary based on the camera model or due to a menu

1. Component Names

[Figure]



(Nikon)

① Lens ring mount (camera locking area) ② Aperture value scale ③ Distance scale ⑤ Focusing ring

Aperture adjustment ring

UMC: Ultra Multi-Coating

• AS: Aspherical lens (GAS: GAS, Glass Aspherical, HAS: Hybrid Aspherical) HR: High Refraction lens

(Canon)

Focus scaling ring

© CPU (Electronic contacts)

 Hood locking tube ® Depth of field scale [Canon/Canon M/ Fujifilm X/ Sony \alpha/ Sony \alpha/ FT/MFT/NX Mount] ① To change the focus from a subject that is far away to a subject that is close, turn the focusing ring to the left (from ∞ to 1) and focus on the clearest

subject using the camera's indication signal, or by checking visually. ② To change the focus from a subject that is close to a subject that is far away, turn the focusing ring to the right (from 1 to ∞) and focus on the clearest subject using the camera's indication signal, or by checking visually.

4. Brightness Control

speed and the brightness.

[Nikon (Fujifilm) F Mount]


- 1. AF camera (Applicable for both a film body and a digital body)
- ① Brightness control in A mode (Aperture Priority mode) Turn the sub command dial at the front of the camera to adjust the
- ② Brightness control in S mode (Shutter Speed Priority mode) Turn the main command dial at the back of the camera. The shutter speed is
- changed and the brightness is adjusted according to the changed shutter ③ Brightness control in P mode (Program mode) Turn the main command dial at the back of the camera to adjust the shutter
- Brightness control in M mode Turn the sub command dial at the front of the camera to adjust the
- brightness.

(The procedure and description above are given based on the D300. The camera settings are different depending on each model and are subject to change due to functional enhancements. Therefore, for detailed information on your camera settings, please refer to your camera manual or contact your camera manufacturer.)

5. Mounting the Hood

The hood has a bayonet system, which guarantees speedy, efficient, safe and precise installation and facilitates the enjoyment of shooting that is free from ghosting or flaring.

[Figure]





Align the attachment reference point on the hood with the reference point on the lens, push the hood onto the lens and turn the hood to the right until it makes a clicking sound.

2) Adjust the shutter speed by turning the dial to achieve the appropriate exposure for the brightness



- ※ For some Canon cameras, if you set the camera mode dial to Av and set the brightness by turning the aperture adjustment ring on the lens, the camera automatically changes the shutter speed. Therefore you don't need to adjust the shutter speed as well, which is required in M mode.
- ※ If you would like to get an exposure value automatically, you can purchase 35mm F1.4 AS UMC lens (AE version) that CPU was installed.

(The procedures above are for the 40D. The settings for the camera or the menu may vary based on the camera model or due to a functional upgrade. Refer to the camera instruction manual or contact the camera manufacturer for detailed information.)

O Nikon (Fujifilm) AE Mount

Your Nikon mount has electronic contacts that allow it to communicate with Nikon AF cameras. These contacts enable the A, S, and P modes of the camera. When a subject is correctly in focus, the camera emits a beep or an indicator light comes on.

The diaphragm of the 35mm F1.4 AS UMC Four Thirds and Micro Four Thirds mounts are not compatible with the camera. If the brightness is set to F8 or above,

you may not be able to set the correct focus due to a difficulty in viewing the subject


through the camera viewfinder. Turn the aperture adjustment ring so it is fully open when attaching the lens to the camera, and then set the depth of field and brightness

1) Hold down the MODE button and turn the dial until it is set to M. (shooting conditions)


O Pentax (Samsung GX) K Mount

- 1. AV mode (Aperture Priority Mode) The 35 mm F1.4 AS UMC Pentax / Samsung mounts support Av mode.
- 1) Align the A mode indicator with the distance scale indicator mark by pressing the A button on the aperture adjustment ring of the lens.

2) Set the mode dial of the camera to Av.




3) Set the focus adjustment lever of the camera to MF.



4) Camera Settings The user sets the menu. \Rightarrow The aperture ring is used. \Rightarrow Not allowed.

5) Adjust the brightness by turning the dial at the back of the camera.



(The procedures above are for the K20D. The settings for the camera or the menu may vary based on the model or due to a functional upgrade. Refer to the camera instruction manual or contact the camera manufacturer for detailed information.)

3) Adjust the shutter speed to achieve the appropriate exposure for the



(The procedures above are for the $\alpha 350$. The settings for the camera or the menu may vary based on the model or due to a functional upgrade. Refer to the camera instruction manual or contact the camera manufacturer for detailed information.)

O Konica Minolta (Minolta), DYNA series cameras

- If this lens is used on some Konica Minolta (Minolta) or DYNA series cameras, the release lock function (misuse prevention function) of the camera must be disabled. It is required to disable the release lock function only on the first use as below.
- Procedure for disabling the release lock function ① Set the main switch of the camera to OFF ② Detach the lens from the camera body and set the main switch of the camera
- to ON by pressing the following two buttons. 9xi ··· function button + AE lock button
- 7xi ··· function button + AE lock button 5xi ··· function button + spot button 3xi ··· Modification is required at a service

807si ··· AEL button + shooting scene select

707si ··· card button + spot button 507si ··· lens exchange button + ISO lock button

DYNAX3L ··· shooting scene select button + button

 $\alpha\text{-}\mathsf{Sweet}\;\mathsf{Digital}\;\cdots\;\mathsf{Execute}\;\mathsf{the}\;\mathsf{following}\;\mathsf{operation}.$

release lock function, perform the above procedure again.


button + spot button

101si ··· self-timer button + flash button 360si · · · self-timer continuous shooting button + screen select button α -Sweet \cdots self-timer continuous shooting

303si SUPER · · · drive button + spot button


303si ··· AV button + self mode button

 $\alpha\text{-}\mathsf{Sweet}\,\mathsf{S}\,\cdots$ (set the function dial to multi light exposure) P button + self-timer button DYNAX30 ··· self-timer button + turn the left dial on the main body away from OFF.



(The procedures above are for the Canon M. The settings for the camera or the menu may vary based on the camera model or due to a functional upgrade. Refer to the camera instruction manual or contact the camera manufacturer for detailed information.)

[FUJIFILM X Mount]





2) Press the MENU/OK button, and select ON at 'Shoot without lens' in the


contact the camera manufacturer for detailed information.)

[Samsung NX Mount]

1) Set the camera mode dial to M. 2) Adjust the shutter speed by turning the dial to achieve the appropriate exposure for the brightness.

(The procedures above are for the X-Pro1. The settings for the camera or the menu may vary based


on the camera model or due to a functional upgrade. Refer to the camera instruction manual or



2) Hold down the AF button and turn the dial until it is set to MF. (focusing) AF + control dial ► MF setting (manual focusing)


MODE + control dial ► M mode setting (manual shooting)

O Four Thirds, Micro Four Thirds



you want prior to shooting.


[Four Thirds Mount]




3) Adjust the shutter speed by turning the dial to achieve the appropriate exposure for the

[Micro Four Thirds Mount]

1) Set the camera mode dial to M.





2) Adjust the shutter speed by turning the dial to achieve the appropriate exposure for the brightness.

※ For some Olympus (MFT) and Panasonic (MFT) cameras, if you set the camera mode dial to A and set the brightness by turning the aperture adjustment ring on the lens, the camera automatically changes the shutter speed. Therefore you don't need to adjust the shutter speed as well, which is required in M mode.


(The procedures above are for the E-P2. The settings for the camera or the menu may vary based on the camera model or due to a functional upgrade. Therefore refer to the camera manual or

contact the camera manufacturer for detailed information.)


 \bigcirc Sony (Minolta)lpha Mount The diaphragm of the 35mm F1.4 AS UMC Sony (Minolta) α mount is not compatible with the camera. If the brightness is set to F8 or above, you may not be able to set the correct focus due to a difficulty in viewing the subject through the camera viewfinder. Turn the

aperture adjustment ring so it is fully open when attaching the lens to the camera, and

then set the depth of field and brightness you want prior to shooting.



2) Set the focus adjustment lever of the camera to MF.



$\alpha\text{-}Sweet \ II, \ II \ L \ \cdots \ Set \ the \ camera \ to \ custom \ function \ 14 \ and \ change \ the \ selection$ $\alpha\text{--}7, -9, -\text{Ti}\cdots$ Set the camera to custom function 16 and change the selection number from 1 to 2 (N.A).

 $MENU \Rightarrow *2 \Rightarrow Release lock without the lens \Rightarrow To the right \Rightarrow N.A. \Rightarrow Execute <math>\bullet \Rightarrow MENU$

α-7 Digital ··· Execute the following operation. * If the release lock is disengaged in the above way, the state of disengagement is maintained even though the main switch is turned off. If you want to enable the

(The settings for the camera or the menu may vary based on the camera model or due to a functional upgrade. Refer to the camera instruction manual or contact the camera manufacturer for

○ Mirrorless Cameras (Canon M, Samsung NX, Sony E, Fujifilm X) The diaphragm of the 35mm F1.4 AS UMC Canon M, Samsung NX, Sony E and Fujifilm X mounts are not compatible with the cameras. If the brightness is set to F8 or above, you may not be able to set the correct focus due to a difficulty in viewing the subject through the camera viewfinder. Turn the aperture adjustment ring so it is fully open when attaching the lens to the camera, and then set the depth of field and

[Canon M Mount]

brightness you want prior to shooting.

10. Safety Precautions


detailed information)

1) Set the exposure to manual exposure (M) and change the focus mode to MF.



[Sony E Mount]

1) Set the camera mode dial to M.




* For some Samsung NX cameras, if you set the camera mode dial to A and set the brightness by turning the aperture adjustment ring on the lens, the camera automatically changes the shutter speed. Therefore you don't need to adjust the

shutter speed as well, which is required in M mode. The procedures above are for the NX200. The settings for the camera or the menu may vary based on the camera model or due to a functional upgrade. Refer to the camera manual or contact the camera manufacturer for detailed information.)




* For some Sony E cameras, if you set the camera mode dial to A and set the brightness by turning the aperture adjustment ring on the lens, the camera automatically changes the shutter speed. Therefore you don't need to adjust the

shutter speed as well, which is required in M mode (The procedures above are for the NEX-5. The settings for the camera or the menu may vary based on the model or due to a functional upgrade. Refer to the camera manual or contact the camera manufacturer for detailed information.)



* For some Four Thirds cameras, if you set the camera mode dial to A and set the brightness by turning the aperture adjustment ring on the lens, the camera automatically changes the shutter speed. Therefore you don't need to adjust the



shutter speed as well, which is required in M mode. (The procedures above are for the Olympus E-3. The settings for the camera or the menu may vary based on the camera model or due to a functional upgrade. Refer to the camera manual or contact the camera manufacturer for detailed information.)

Focal length	35mm	
Max. aperture	F1.4	
Negative size	36X 24mm	
Angular field	35mm (1:1x) APS-C (1:1.5x) APS-C (1:1.6x) Four-Thirds(1:2x)	63.1° (diagonal) 43.2° (diagonal) 40.8° (diagonal) 33.4° (diagonal)
Focusing range	∞ to 0.3m	
Filter connection	□77mm (M77X 0.75)	
Number of elements	12 elements (1GLASS ASPHERIC)	
Number of groups	10 group	
Size (without hood)	Nikon F(AE) Pentax K Sony Sony E Canon EOS(AE) Canon EOS Canon M Fujifilm X Four-Thirds Micro four- Thirds Samsung NX	109.0mm X
Weight (without hood)	Nikon F(AE) Pentax K Sony Sony E Canon EOS Canon EOS(AE) Canon M Fujifilm X Four-Thirds	690g 690g 700g 735g 710g 710g 735g 780g 720g

Samsung NX

725g

9. Troubleshooting Symptom The reference point on the lens is Align the reference point on the lens I cannot attach the lens to not aligned with the lens attachment with the lens attachment reference ence point on the camera. Incorrect rotation direction for Hold down the lens release button on detaching the lens. the camera, gently turn the lens toward I cannot detach the lens If you turn the lens while holding the the lens attachment/ detachment from my camera. camera, it may cause damage to the reference point marked on the camera, and then pull the lens away. Turn the focusing ring while checking Incorrect focusing. Shutter speed insufficient, or camera shake. the subject with the indicator in the camera or checking visually to set the Dark image focus until the subject is clear, and then press the shutter. Steady the camera and take a a photograph at a shutter speed of The aperture adjustment ring on the Turn the aperture adjustment ring to FEE (Blinking) set it to the minimum aperture value aperture value. Autofocus failed with a manual Set the focus by turning the focusing Autofocus failure control focus lens. Pictures too dark or Adjust the aperture size. too bright With a non-CPU lens, the camera flash may not be geared to some See the camera manual. cameras. The camera flash is not geared to the camera. See the camera manual or the flash This lens corresponds to the Nikon manual. This lens is not a "D-type" lens (which relays distance information to the camera There is no camera finder This lens doesn't have electronic This does not indicate that there is a contacts, so there is no electronic problem with shooting. indication or there is no communication with the camera. Zoom failure This lens is a single lens This lens is designed for a specific The lens can't be attached to other cameras. Our converter is designed for the T Use the appropriate company's own I want to attach your 2X or (M42 screw) mount only. mount converter. Therefore, it cannot be used with However, be aware that autofocus 1.4X converter lens. the 35 mm F1.4 AS UMC lens.

The following precautions are divided into two types according to the level of danger. ⚠ WARNING If this instruction is not followed, it may cause death or severe injury to the user. ⚠ CAUTION If this instruction is not followed, it may cause death or severe injury to the user. **↑** WARNING **A** CAUTION Don't look at the sun through the lens. It may cause blindness. ON WARNING! Don't get this product wet or expose it to a moist environment. It may cause a fire or electric shock. **CAUTION!**

• Don't use this product or store it close to devices that generate heat,

• Don't leave the lens in conditions where drastic temperature changes

• Don't touch the surface of the lens by hand, and avoid making contact

• Don't let the lens get wet, and avoid water splashing onto the lens.

• If there are foreign bodies on the lens, use a lens cleaning kit only.

i.e., heaters, thermal regulators, stoves, stereo amplifiers.

can occur.

with sharp objects.

· Avoid dropping the lens.

