

사용설명서 Operating Instructions
CRP-FH06 Fuzzy Series
1.08L(2~6Persons) / 1.08L(2~6인분)

NO.1 CUCKOO
CUCKOO IH PRESSURE JAR COOKER

love

CUCKOO
always new

happiness



emotion

design

Thank you very much for purchasing "CUCKOO" IH PRESSURE JAR COOKER

Read the following instruction manual before use. Save this instruction manual for future reference. This manual will be useful if you have any questions or have problems operating the rice cooker.

저희 쿠쿠 IH 압력보온밥솥을 애용해 주셔서 대단히 감사 드립니다.

이 사용설명서는 잘 보관하여 주십시오. 사용 중에 모르는 사항이 있을 때나 기능이 제대로 발휘되지 않을 때 많은 도움이 될 것입니다.

CUCKOO ELECTRONICS CO.,LTD.

CONTENTS

CONTENTS

BEFORE USING

IMPORTANT SAFEGUARDS	3
SPECIFICATIONS	4
SAFETY PRECAUTIONS	5~6
PARTS DESCRIPTION	11
HOW TO CLEAN	12~13
MENU FUNCTION OVERVIEW	14

WHEN USING

DAYTIME AND NIGHTTIME VOICE VOLUME SETTING	14
POWER SAVING / ENERGY EYE FUNCTION	15
LANGUAGE SETTING FUNCTION	15
HOW TO SET CURRENT TIME / SIMPLE SOFT FUNCTION	16
BEFORE COOKING RICE / FOR THE BEST TASTE OF RICE	17
HOW TO COOK	18~19
MY MODE(CUCKOO Customized taste function)	20
MY MODE(CUCKOO Customized cooking function)	20
HOW TO USE GABA RICE / MULTI-COOK FUNCTION	21
HOW TO USE MY RECIPE FUNCTION / RECENT COOK FUNCTION	22
HOW TO USE HOME BAKERY	23
HOW TO USE PRESET COOKING	24
POWER-SAVING STANDBY FUNCTION	24
HOW TO USE POWER SAVE SCREEN LIGHT MODE	25
PRESET REHEATING FUNCTION	25
TO KEEP COOKED RICE WARM AND TASTY	26
REMAINING COOKING TIME DISPLAY / LOCK BUTTONS	27
PRODUCT INITIALIZATION / HELP FUNCTION	27

BEFORE ASKING FOR SERVICE

CHECK BEFORE ASKING FOR SERVICE	28~30
---------------------------------------	-------

COOKING GUIDE

RECIPE	31~34
--------------	-------

目录

使用前

IMPORTANT SAFEGUARDS	3
安全警告	9~10
产品部件名称	59
清洁保养方法	60~61
控制面板名称及作用	62

使用时

白天音量设定功能 / 夜间音量设定功能	62
屏幕省电功能 / 节能眼(感应器) / 语音设定	63
时间设定 / 浸泡时间增加功能	64
煮饭前准备事项 / 如何做美味可口的米饭	65
煮饭方法	66~67
调节饭味功能 / 调节煮饭功能使用方法	68
糙米发芽 / 我的万能炖功能	69
我的食谱功能 / 近期煮饭功能	70
面包料理	71
预约煮饭方法 / 自动省电功能	72
画面(屏幕)亮度省电功能 / 预约再加热方法	73
保温方法	74
煮饭剩余时间显示功能 / 按键锁定功能	75
产品初始化功能 / 帮助功能	75

목 차

사용하기전에

IMPORTANT SAFEGUARDS	3
제품규격	4
안전상의 경고	7~8
각 부분의 이름	35
제품 손질 방법	36~37
기능 조작부의 이름과 역할	38

사용할 때

주간음량 설정기능 / 야간음량 설정 기능	38
화면 절전 기능 / 에너지 아이 기능 / 언어 설정 기능	39
현재시각 설정 / 불림시간 추가 기능	40
취사 전 준비사항 / 맛있는 밥을 드시려면	41
취사는 이렇게 하십시오	42~43
쿠쿠 맞춤밥맛 기능 / 쿠쿠 맞춤취사 기능은 이렇게 하십시오	44
현미발아 / MY만능찜 기능은 이렇게 하십시오	45
MY레시피 기능 / 최근 취사 기능은 이렇게 하십시오	46
빵 요리는 이렇게 하십시오	47
예약취사 기능 / 자동절전 대기시간 기능은 이렇게 하십시오	48
화면밝기 절전기능 / 밥 예약 재가열은 이렇게 하십시오	49
밥을 맛있게 보존하려면	50
취사 잔여시간 표시 기능 / 버튼 잠금 기능	51
제품 초기화 기능 / 도움말 기능은 이렇게 하십시오	51

고장 신고 전에

고장신고 전에 확인 하십시오	52~54
-----------------------	-------

요리안내

요리안내	55~58
------------	-------

故障咨询前

常见故障及处理方法	76~78
-----------------	-------

料理指南

料理指南	79~82
------------	-------

IMPORTANT SAFEGUARDS

1. Read all instructions before using this appliance.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against fire, electric shock and / or injury to persons do not immerse cord, plugs, or Pressure
4. Close supervision is necessary when this appliance is used by or near children.
This appliance is not intended for use by young children without supervision.
5. Unplug from outlet when not in use and before cleaning.
Allow appliance to cool before putting on or taking off parts, and before cleaning the appliance.
6. Do not operate any appliance with a damaged cord or plug, after the appliance malfunctions, or has been damaged in any manner. Return the appliance to the nearest authorized service facility for examination, repair or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, and / or injury to persons.
8. If the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or your service agent.
9. Do not use outdoors.
10. Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
11. Do not place on or near a hot gas, electric burner, or in a heated oven.
12. Always attach the plug to the appliance first, then plug the cord into the wall outlet. To disconnect, or set all control to "off", then remove the plug from the wall outlet.
13. Do not use this appliance for other than its intended use.
14. Extreme caution must be used when moving an appliance containing hot oil or any hot liquids.
15. Oversized foods, metal foil packages, or utensils must not be inserted into the appliance as they are a risk of fire or electric shock.
16. A fire may occur if the appliance is covered or touching flammable material, including curtains, draperies, walls, etc while in operation.
17. To reduce the risk of electric shock, cook only in the provided removable container.
18. This appliance cooks under pressure. Improper use may result in scalding injury.
Before operating the unit, properly secure and close the unit. See "Operating Instructions."
19. Do not cook foods such as applesauce, cranberries, cereals, macaroni, spaghetti, or other foods.
These foods tend to foam, froth, and sputter, and may block the pressure releasing device.
20. Before use always check the pressure releasing device for clogging.
21. Do not open the pressure cooker until the unit has cooled and internal pressure has been reduced.
See "Operating Instructions."
22. Do not use this pressure cooker to fry in oil.
23. Be sure that handles are assembled and fastened properly before each use.
Cracked, broken or charred handles should be replaced.

SAVE THESE INSTRUCTIONS THIS APPLIANCE IS FOR HOUSEHOLD USE ONLY

ADDITIONAL IMPORTANT SAFEGUARDS

WARNING : This appliance generates heat and releases steam during use. Use proper precaution to prevent risk of burns, fires, other injuries, or damage to property.

1. Keep hands and face away from the Pressure Release Valve when releasing pressure.
2. Take extreme caution when opening the Lid after cooking. Severe burns can result from steam inside.
3. Never open the Lid while the unit is in operation.
4. Do not use without the Inner Pot in place.
5. Do not cover the Pressure Valve with anything as an explosion may occur.
6. Do not touch the inner pot nor any heating parts, immediately after use.
Allow the unit to cool down completely first.

HOW TO USE EXTENSION CORD

Note :

- A.** A short power-supply cord (or cord set) is provided to reduce the hazards from entanglement by a longer cord.
- B.** Extension cord should be used properly.
- C.** Extension cord usage for the rice cooker :
- (1) The correct rated voltage should be used for the rice cooker.
 - (2) If the appliance is set on the ground, the extension cord should also be set on the ground.
 - (3) The cord wires and extension cord should always be arranged to prevent hazards to children.

This appliance has a polarized plug : (one blade is wider than the other).

As a safety feature, this plug will fit in a polarized outlet only one way.

If the plug does not properly fit in the outlet, turn the plug over.

If it still does not fit, contact a qualified electrician.

Please, keep this safety feature.

SPECIFICATIONS / 제품규격

Model Name (모델명)		CRP-FH06 Fuzzy Series
Power Supply (전원)		AC120V, 60Hz
Power Consumption (소비전력)		1090W
Cooking Capacity (취사용량)	GLUTIN. RICE (백미)	0.36L~1.08L(2~6cups)
	HIGH HEAT GLUTIN. RICE (백미고화력)	
	MIXED RICE (잡곡)	0.36L~0.72L(2~4cups)
	HIGH HEAT MIXED RICE (잡곡고화력)	
	SOFT GLUTIN. (SOFT백미)	0.36L~0.72L(2~4cups)
	TURBO GLUTIN. RICE (백미쾌속)	
	TURBO MIXED RICE (잡곡쾌속)	
	GABA RICE (현미발아)	
	BROWN RICE (현미)	
	HIGH HEAT BROWN RICE (현미고화력)	
	NUTRI. RICE (영양밥)	
	BLACK BEAN RICE(검은콩밥)	
	PORRIDGE (죽)	Thick porridge (된죽)
Thin porridge (묽은죽)		0.09L~0.18L(0.5~1cups)
Power Cord Length (전원 코드 길이)		1.4m
Pressure (사용압력)		98.0kPa(1.0kgf/cm ²)
Weight (중량)		6.4kg
Dimension (치수)	Width (폭)	26.5cm
	Length (길이)	37.9cm
	Height (높이)	25.8cm

* Design and Color of product may be subject to change without notice.

HOW SERVICE IS HANDLED

USA The East and the Central Districts
Tel. No. 718 888 9144
The West and the Central Districts
Tel. No. 323 780 8808

Canada TORONTO
Tel. No. 905 707 8224 / 416 878 4561
VANCOUVER
Tel. No. 604 540 1004 / 604 523 1004

SAFETY PRECAUTIONS



- Read the following product safety guide carefully to prevent any accidents and/or serious danger.
- ‘Warning’ and ‘Caution’ are different as follows.

Warning This means that the action it describes may result in death or severe injury.

Caution This means that the action it describes may result in injury or property damage.

Warning • This sign is intended to remind and alert that something may cause problems under the certain situation.
• Please read and follow the instruction to avoid any harmful situation.

Prohibition • Indicates a prohibition
Instruction • Indicates an instruction



Warning



Do Not

Do not cover the automatic steam outlet or pressure weight with your hand or face.

- It can cause burns.
- Especially be careful to keep it out of children’s reach.

Do not use the cooker near hot things such as stove, gas stove or direct ray of light.

- It can cause an electric shock, fire, deformation, malfunction, or discoloration. Please check the power cord and plug frequently.

Do not alter, reassemble, disassemble or repair.

- It can cause fire, electric shock or injury.
- For repair, contact dealer or the service center.

Use a single socket with the rated current above 15A.

- Using several lines in one socket can cause overheating or fire. Please check the power cord and plug frequently.
- Use an extension cord with the rated current above 15A.
- Use AC 120V only.

Please pay careful attention against water and chemicals

- It can cause an electric shock or fire.

Do not use a rice cooker at a place where dust is trapped or chemical material is located.

- Do not use any combustible gas or flammable materials nearby a product.
- It can cause explosion or fire.

Do not use damaged power cord, plug, or loose socket.

- Please check the power cord frequently for damage.
- Serious damage can cause electric shock or fire.
- If the plug is damaged, contact the dealer or a service center.

Do not clean the product with water or pour water in the product.

- It can cause an electric shock or fire.
- If it comes into contact with water, please separate power cord and contact dealer and service center.

Do not cover the automatic steam outlet or pressure weight with a duster, a towel, or apron, etc.

- It can cause deformation or a breakdown.
- It can cause an explosion by pressure.

Do not use pots that are not designed for the cooker. Do not use abnormal pot and do not use without the inner pot.

- It can cause an electric shock or fire.

Do not bend, tie, or pull the power cord by force.

- It can cause an electric shock or short circuit resulting in fire. Please check the power cord and plug frequently.

Do not use cooker without the inner pot.

- It can cause electric shock or malfunction.
- Do not pour rice or water without the inner pot.
- If rice or water gets in then do not turn the product over or shake it, please contact the dealer or service center.

Do not turn the Lock/Unlock Handle to “Unlock” while cooking.

- The hot steam or any hot content within the cooker can cause burns.
- After you finish the cooking do not try to open the cooker by force until the steam is completely exhausted.

Do not unplug and plug the power cord over and over.

- It can cause an electric shock or fire.

Do not insert metal objects such as pins and wires or any other external substances in the automatic steam exhaust outlet or any other slot.

- It can cause an electric shock or fire.
- Especially be careful to keep it out of reach of children.

Keep the cooker out of reach of children.

- It can cause burns, electric shock or injury.

Don't spray or put any insecticides or chemicals.

- It can cause an electric shock or fire.
- If cockroaches or any insects get inside the cooker, please call a dealer or a service center.

Don't let foreign substances such as needle, cleaning pin, or metal get in or block the in let/out let pipe or gape.

- It can cause an electric shock or fire.
- Do not put a cleaning pin in a gap or a hole of the product except when cleaning a steam outlet.

Do not open the LID while in heating and cooking.

- It can cause burns.
- If you need to open the lid while cooking, hold down the cancel button for 2 seconds and confirm internal steam released completely turning the pressure weight over.

Keep plug and power cord clean from any stains or foreign objects by cleaning regularly with a clean cloth.

- If foreign substances are attached to the cord and power plug, it may cause a fire. Regularly check the power cord and plug frequently to make sure it is clean.

To separate the rubber packing, please pull it out from the cover plate as shown in the picture.

- Damages by impact can cause an electric shock or fire. Please check the power cord and plug frequently.



SAFETY PRECAUTIONS

⚠ Caution

Do not use cooker on a rice chest or a shelf.

- Do not place the power cord between furniture. It can cause an electric shock resulting in fire. Please check the power cord and plug frequently.
- When using on furniture be cautious of steam release as it can cause damage, fire and and/or electric shock.

Do not place heavy objects on the power cord.

- It can cause an electric shock or fire.
- Please check the power cord and plug frequently

Do not change, extend or connect the power cord without the advice of a technical expert.

- It can cause an electric shock or fire.

Clean any dust or external substances off the temperature sensor and inner pot.

- It can cause a system malfunction or fire.

Do not plug or pull out the power cord with wet hands.

- It can cause an electric shock.

Do not move the product by pulling or using the power cord.

- Electric short circuit might cause fire.

Please contact a dealer or service center when there is a strange smell or smoke.

- First pull out the power cord and contact dealer or the service center.

Do not use over the maximum capacity.

- It can cause overflow or breakdown.
- Do not cook over stated capacity for cooking chicken soup and congee.

Do not touch metallic surface of the inner pot and pressure weight after cooking or warming.

- It can cause burns.
- Remaining hot steam may cause burns when you tilt the pressure weight during or after the cooking.

Don't use the cooker near a magnetic field.

- It can cause burns or breakdown.

Do not drop or impact the cooker.

- It can cause a safety problem.

Recommended detergent for inner pot cleaning (inside, outside)

Available	Unavailable
Cotton wool, Sponge wool, Microfiber, Mesh wool	Blue, Green scrubber (Abrasive material), Iron, Stain wool, Other metallic materials

- If you do not use a suitable scrubber for cleaning, the inner pot coating may be damaged and peeled off.

Use product on a flat surface. Do not use on a cushion. Please avoid using cooker on unstable location prone to falling down.

- It can cause malfunction or a fire. Please check the power cord and plug frequently.

Please pull out the plug when not in use.

- It can cause electric shocks or fire.

Please use the cooker for it's intended purpose.

- It can cause malfunction or smell.

! Remember

After you finish cooking, do not try to open the cooker by force until the steam is completely released.

- The hot steam or any hot content within the cooker can cause burns.
- Cautiously open the top cover after cooking is completely finished to avoid dangerous steam and burns.

Do not place on rough top or tilted top.

- It can cause burns or breakdowns.
- Be careful to install the power cord to pass without disruption.

Please call customer service if the inner pot coating peels off.

- Inner pot coating may wear away after long use.
- When cleaning the inner pot, do not use tough scrubber, metallic scrubber, brush, abrasive metallic etc.

Do not hold the cooker by the inner pot handle.

- It can cause problems and danger. There are portable handles on the bottom right and left side of the cooker. Hold the handles with both hands and move it carefully.

Always turn the Lock/Unlock Handle to "Lock" when not in use.

- It can cause deformation by remaining pressure.

Wipe off any excessive water on the cooker after cooking.

- It can cause odor and discoloration. Wipe off water that is left behind from dew.

Use inner pot only for intended use.

And do not heat up the inner pot on the gas stove.

- It can cause deformation of the inner pot.
- It can cause damage the inner coating.

In case of a blackout during cooking, steam from a rice cooker will be released automatically.

Thus, the quality of rice is lower than normal.

- Please start cooking with an indicated amount of rice and water.
- Water can overflow if the amount of water in a pot exceeds the indicated level of water usage.
- Please start cooking in a status that steam control cap is installed completely.

Please clean the body and other parts after cooking.

- After cooking chicken soup, multi cook dishes, and etc., the smell may be absorbed.
- Clean the cover packing, top heater plate, and inner pot every time you cook any of those.
- It can cause alteration or smell.
- Use dry kitchen cleaner or sponge to clean the inner pot, since rough scrub or metallic ones are abrasive to the coating.
- Depending on the using methods or user's circumstances inner pot coating might rise. Please call the customer service for those cases.
- Please, do not pull out the clean steam vent by force.

Be cautious when steam is being released.

- When the steam is released don't be surprised.
- Please keep the cooker out of reach of children.

If possible, only use warming function when cooking white rice. Other foods are easily discolored.

When you pull out the power plug, don't pull the power cord. Please, safely pull out the power plug.


- If you inflict impact on power cord, it can cause an electric shock or fire.

PARTS DESCRIPTION



Exterior Parts Description

Soft Steam Cap



Pressure Weight

Stabilizes steam inside oven. When cooking pressure weight will twist and rotate to release steam.

Automatic Steam Exhaust Outlet (Solenoid Valve)

Automatically releases steam after cooking / warming is completely finished.

Lock/Unlock Handle (Set the handle to lock when cooking or warming the rice)

Handle must be turned to 'Lock' in order for cooker to operate.

Lid Clamp

Turn handle to 'Unlock', and press down the lid clamp to open cooker.

Control Panel


Standby Power Blocking Switch

When the power is not supplied after the power cable is connected, check if the switch is (ON).
-Enabled: (ON) -Disabled: (OFF)
(The standby power is blocked, saving the energy)

* In case of blackout during cooking, steam from rice cooker will automatically be released.

Interior Parts Description

Pressure Packing



Lid Assy

DET. Cover

Control Plate

Packing Cover

Control Plate

Packing

Pressure Control Plate

Holder Guide

Handle

DET. Cover Holder


Dew Dish

Empty excess water from dew dish after cooking or keep warming. Leaving water in the dew dish without cleaning will result in strange odor.

Power Cord

Power Plug


Temperature Sensor




Pot Handle

Inner Pot(Oven)

Place inner pot into the body property.



Accessories




Manual & Cooking Guide




Rice Scoop



Rice Measuring Cup



Steam Plate



Cleaning Pin (Attached on the bottom of the unit)

ENGLISH




HOW TO CLEAN

- To prevent foul odor clean the lid assy after the rice cooker has cooled and the rice cooker is unplugged.
- Clean the body of rice cooker and the cover with a dry towel. Do not use benzene or thinner to clean the rice cooker. The layer of starch, which is the residue from rice cooking, may appear on the detachable cover or inside of rice cooker. This layer does not cause any health risk.
- Do not put materials like screws into holes of detachable cover. Check the back cover and front cover.

Detachable Cover & Pressure Packing


After cleaning detachable over, make sure to place it back unto the lid.

Unless detachable cover is mounted, preset cooking cannot be done. (Alarm may sound while keeping warm.)



- To remove and clean detachable cover, turn the cover holder counter clockwise to release cover.
 - Wash the cover with soft dish detergent and sponge frequently, and wipe off moisture with dry cloth.
※ Make sure to clean the edge of the rubber packing to ensure consistent cooking results and extended lifespan of the cooker.
 - When it attaching, hold the detachable cover knob and align it with the hole in the lid, then press it down firmly.
 - As shown in the figure, align the center of the detachable cover with the center of the protrusion and press the left and right sides of the detachable cover firmly so that the protrusions come out as far as possible.
 - Align the holder with the arrow mark and turn it clockwise to fix it.
- ※ As depicted in the picture, please align holder with arrow mark to open and close.

Please re-install a rubber packing into the cover plate after washing or replacing the rubber packing.




- To separate rubber packing, pull out the cover plate as shown on image.
- To re-install rubber packing, align all the rubber packing to the packing guide and press down on all 6 markers.
- After aligning rubber packing to the packing guide and pressing down on all 6 indicators, completely press down the rubber packing until it is completely inserted.
- Please check to make sure that the rubber packing is properly fitted to the cover plate. If improperly fitted, steam will leak when cooking.



Steam Vent

Make sure to clean the clean steam vent after/before use. Do not try to pull out the clean steam vent and safety packing, clean it with care. Make sure the clean steam vent and safety packing are installed completely after/before use. If the steam vent is detached, or not attached completely, please contact customer service.



Inner Pot


When washing inner pot use a soft sponge/cloth with dish detergent. Do not use harsh sponge or brushes, as it can cause scratches and damage the coating. Make sure to completely dry off excess water from the Inner Pot after cleaning.

※ To ensure your cooker lasts longer, make sure to clean and maintain your rice cooker regularly.



Pressure Packing

Use a damp cloth to wipe down the top edges of the main body interior.



Inside of the Main body

Make sure that body interior is dry and clean before and after using the cooker.

※ Caution

Do not use or place any sharp objects in the inner pot (fork, spoon, chopsticks, etc.).
- The coating of the inner pot may peel off.

Detachable Cover & Pressure Packing

- Handle must be turned to “” (Lock) during cooking.
When the Lock sign is turned on it means that it is ready to cook.
 - After cooking, turn the handle from “” (Lock) to “” (Unlock) to open lid. If there is unreleased steam inside the Inner Pot it might be hard to turn the handle. In this case twist the pressure weight and let the excess steam out. Do not open by force.
- Handle must be turned to “” (Unlock) when opening and closing.

- If the lamp does not turn on, it would not operate the “COOK/TURBO” button. Make sure the handle is located in “” (Lock).



HOW TO CLEAN




ENGLISH

How to Clean the Pressure Weight Nozzle.

If the pressure valve hole is clogged, puncture it with the cleaning pin

- The valve hole of the pressure weight allows steam to release. Check regularly to ensure that it is not blocked. If the valve hole of the pressure weight is blocked, hot steam and hot content within the cooker can cause serious injury.
- ※ Do not purpose the cleaning pin for any other purpose except to clean the valve hole of the pressure weight.




How to Disassemble Pressure Weight

- ▶ Twist the 'Lock/Unlock' handle to 'Lock' and pull the pressure weight upwards and twist counter-clockwise to unscrew and remove the pressure weight.
- ▶ Puncture the clogged valve hole with the cleaning pin and reassemble the Pressure Weight it by turning it clockwise.
- ▶ When the pressure weight is properly assembled, it can freely be turned.


How to Clean the Soft Steam Cap

Do not touch the surface of the soft steam cap right after cooking. You can get burned.



- 1 Detach the soft steam cap as shown on the image.
- 2 Press the hooks in the front in direction of arrow to detach the bottom case. Clean the parts frequently with a sponge or a neutral detergent.
※ Before reassembling the packing with the bottom case, make sure to put the packing into the packing groove.
※ In order to separate the steam cap into parts, pull bottom part downward by pressing the extrusion parts on both sides.
- 3 Before reattaching the parts, fit the bottom case into the groove of steam cap perfectly. Press the hooks according to the arrow to assemble the parts together.
- 4 After attaching the soft steam cap on the lid as shown in the image press the cap firmly to reassemble cap back into the product.

How to Clean Dew Dish



- 1 Remove the dew dish from the cooker.
- 2 Detach the dew dish by pushing down.
- 3 Clean the dew dish with soft dish detergent.
- 4 Securely fit the dew dish back to the cooker after cleaning.
- 5 Re-insert the dew dish by following the arrow found on the image above.

When Lid Does Not Close Perfectly

Do not try to close the lid by force. It can damage the cooker and cause problems.



1. Check to make sure the inner pot is placed correctly inside the main body.
2. To close the lid turn the 'Lock/Unlock' handle counter-clockwise.



3. If there is excess steam inside the inner pot it might be difficult to lock the handle. Twist the pressure weight and allow excess steam to release. Then try to turn the handle again.



MENU FUNCTION OVERVIEW / DAYTIME AND NIGHTTIME VOICE VOLUME SETTING

MENU FUNCTION DESCRIPTION

Set Button
Allows you save and set the selected mode setting.

Move Left Button

Previous Button
Allows you to navigate to the previous screen or section of the selected mode.

Warm/Reheat Button
Use to warm or reheat. (Refer to page 26)

Status LED
Color LED screen displays current cooker status. (Refer to page 15)


Display

Move Right Button

Cancel Button
Allows you to cancel current selection setting or release remaining steam inside the inner pot. (Refer page 29)

Cook/Turbo Button
Use to start cooking.

- ※ When you see a similar image like the one on the right side on the menu display, it means the cooker is in 'Waiting' mode.
- ※ Press 'Cancel' button to enter ther 'Waiting' mode.
- ※ Press down the button until you hear the buzzer sound.
- ※ The image of the plate may differ depending on model.



Daytime Voice Volume Setting Function

Control the volume of your cooker by following the instructions below.

- 1 Enter 'Setting' in the home screen by selecting the 'Volume Setting' and press the SET button.
- 2 Select 'Daytime Voice Volume' using the touch slider arrow and press the SET button.
- 3 Adjust your volume level using the touch slider arrows.
 - ▶ Volume will increase(right)/decrease(left) by one step each time you press the touch slide arrows.
- 4 Press SET button to save settings.
 - ※ If left idle for 15 seconds or during setting, you will hear voice guidance.
 - If still left idle after an additional 15 seconds, settings will be canceled without saving the changed value.



Nighttime Voice Volume Setting Function

Control the nighttime volume (10:00pm ~ 5:59am) of your cooker by following the instructions below.

- 1 Control the volume of your cooker by following the instructions below.
- 2 Select 'Nighttime Voice Volume' using the touch slider arrow and press the SET button.
- 3 Adjust your volume level using the touch slider arrows.
 - ▶ Nighttime volume level will depend on the volume set for the daytime and will be noticeable during a set time (10:00pm ~ 5:59am.).
- 4 Press SET button to save settings.



POWER SAVING / ENERGY EYE / LANGUAGE SETTING FUNCTION

Power Save Screen Light

Automatically adjusts screen brightness to reduce power consumption.

- 1 If cooker is left idle for a certain period of time while power is still on, cooker will enter screen saver mode.

▶ This function may be turned on/off in the Settings function. (Refer to page 25)

Power Save Screen Automatic

If you do not press any button for a long time, this function turns OFF the screen to reduce power consumption.

If you want to manually enter the power-saving mode, select "Power-Saving" in the home screen, and press SET button.

- 1 If you do not press any button for a long time while keep warm mode and preset, the germination (Gaba Rice) is under way, the product will enter the screen saver mode automatically.

▶ The color of the current mode is displayed in the Status LED.

– keep warm mode : KEEP WARM LED

– Preset / germination Gaba Rice mode : PRESET LED

- 2 If you do not press any button for a long time while standby mode or selecting menu is under way, the product will enter the screen saver mode automatically.

▶ The product will enter the power-saving mode after the preset standby time.

▶ "Power-Saving LED" will be displayed.

- 3 In Cook or Reheat mode, the product will not enter the screen saver mode.

- 4 If you press a button during this mode or turn the Lock/Unlock handle, screen saver mode will be canceled.

STATUS LED Display Function

Notifies current status of the product with back lit LED.

Product Status	Status LED
Keep Warm	Keep Warm LED
Preset / Germination	Preset LED
Power Save	Power Save LED
Cook / Reheating / Auto Clean	LED OFF

▶ STATUS LED will not display during COOK, REHEATING, AUTO CLEAN since the screen will always be on.

Energy Eye Function

The luminance sensor automatically recognizes ambient brightness during standby, cooking, warming and preset timer for minimizing power consumption of the product. If you want the power saving mode to start when it's darker than the current level(Step 2), set the mode to Step 1. If you want the mode to start when it's brighter than the current level, set the mode to Step 3.

- 1 Enter 'Setting' in the home screen, select the 'Energy Eye', and press SET button.
- 2 Select the step you want using the touch slider. ▶The default value is 'Step 2.'
- 3 Press SET button to save setting.


Language Setting Function

Choose between Korean and Chinese language for screen text and voice navigation.

- 1 Enter 'Setting' in the home screen, select the 'Voice setting', and press SET button.
- 2 Select the voice you want using the touch slider.
- 3 Press SET button to save setting.

※ If left idle for 15 seconds or during setting, you will hear voice guidance.

※ If still left idle after an additional 15 seconds, settings will be canceled without saving the changed value.





HOW TO SET CURRENT TIME / SIMPLE SOFT FUNCTION

How to Set Current Time

- 1 Enter 'Setting' in the home screen, select the 'current time setting', and press SET button.
- 2 You can set the hour with the touch slider and press SET button. After that you can set the minutes.
- 3 Press SET button after it's finished to save current setting.
 - ▶ Press BACK button to move from the 'minute' to 'hour' screen.
 - ▶ In case of 12:00 it is 12:00 pm.
 - ※ If left idle for 15 seconds or during setting, you will hear voice guidance.
 - ※ If still left idle after an additional 15 seconds, settings will be canceled without saving the changed value.



■ About Lithium Battery

- This product contains lithium battery for improving blackout compensation and time. Lithium battery lasts for 3 years.
- When current time is not displayed on the screen, it means the battery is expired and needs replacement.


■ What is Blackout Compensation

- This product remembers and maintains previous settings and processes. After finishing blackout, it operates immediately.
- If blackout happens during cooking, the cooking time will be delayed depending on blackout time.
- If the rice became cold because of blackout, warming will be canceled.

SIMPLE SOFT FUNCTION

You can soak grains before starting cooking by setting a desired time with this function.

- 1 Enter 'Rice' in the home screen, Select your desired menu and Press COOK/TURBO button.
 - ▶ CUCKOO started the menu for glutinous rice, mega heat glutinous rice, mixed rice, mega heat mixed rice, nutritious rice, black bean rice.
- 2 If you select Add Soaking Time in 5 seconds after starting cooking and then press SET button, it will enter the setting mode for the additional soaking time.
 - ▶ You can select among 0, 10, 30 and 60 minutes.
- 3 Adjust the soaking time with the touch slider.
 - ▶ If you press SET button after setting the soaking time, the product will immediately show the cooking status screen.
 - ▶ If you press the 'CANCEL' button while setting the time, it will shift into the cooking status screen without saving the set value.
 - ▶ If you press the 'CANCEL' button for a second or longer during soaking, it will cancel cooking and return to the home screen.
 - ▶ By adding soaking time, the selected value will be added to the default soaking time for each menu.
 - ▶ Soaking time is counted by 1 minute unit.
 - ▶ The longer the soaking time, the melanoizing effect.
 - ▶ If you unlock the Lock/Unlock Handle during the Soaking Function, the cooking will be canceled.



BEFORE COOKING RICE / FOR THE BEST TASTE OF RICE



BEFORE COOKING RICE

1 Use a dry cloth to clean inner pot.

※ Use a soft sponge/cloth to wash the inner pot.

2 Use measuring cup to measure desirable cooking amount.

▶ Make the rice flat to the top of measuring cup and it is serving for 1 person. (ex: for 3 servings → 3 cups, for 6 servings 6 cups)



3 Use another container to wash the rice.

4 Adjust water level.

▶ Place inner pot on the flat surface to adjust water level.

▶ The marked lines in the inner pot are water level.

- ① If you want to cook old or soft rice, pour more water than measured scale.
- ② Glutinous rice for 4 people (4 cups) pour water to '4'.
- ③ Overcooked rice: pour less water than measured scale.
- ④ When rice is undercooked or firm/hard: It is caused by differences in rice varieties or water content (old rice). In this case, please add 1~10% of more water.
※ GLUTIN. RICE : When using "long grain", it is recommended to cook for less than 4 servings On the basis of "MIXED RICE" water scale.



5 Please plug the power cord before inserting inner pot in the rice cooker.

Put the inner pot correctly.

- ▶ Wipe off or remove any substances on the temperature sensor or bottom of the inner pot.
- ▶ Please place the inner pot correctly into the rice cooker.

6 Plug the power cord and turn the handle to "Lock".

Cautions for Cooking

For the best taste of rice, check the following points carefully.

If possible, buy a small amount of rice and keep the rice some place where it ventilates well and avoids a direct ray of light. It can prevent evaporation of rice moisture.
If the rice has been unsealed for long, rice can be dry and stale. In this case, you should pour the half of water more. It's tastier.

If possible, do not use the preset time function when rice is too dry and pour the half of water more. If you cook over the 10 hours or dried rice, rice can be crisp or half cooked. Even worse condition, rice can be cooked different tastes each level.

Cautions for Keeping Warm

It will be hard to open the lid during warming, or right after it has finished cooking, So push the pressure weight to the side and allow the steam to release.
Make sure the handle is in the "Lock" position during warming or reheating.

It would be better to warm the rice for less than 12 hours because of odors and color change. The cooked rice, which cooked by pressure cooker, is more prone to changing color than the rice cooked by general cooker. After 24 hours of heat preservation, the lamp of heat preservation time lapse blinks, indicating that long time has passed in heat preservation condition. If you have cooked rice with a separate electric heating appliance or fire with gas, put the cooked rice in the pot and start Keep Warm mode according to the warming instruction.

It is recommended to evenly stir the cooked rice after cooking. The rice taste is improved. (For a small quantity of rice, pile up the rice on the center area of the inner pot to keep warm)

The mixed and brown rice cannot be in such good condition as white rice while in warm function due to their characteristics.

During warm mode, the rice can rise and turn white. In this case, mix the rice.

Do not keep the rice spatula inside the pot while warming the rice. When using a wooden rice spatula, it can create serious bacteria and odors.

It is recommended to evenly stir the cooked rice after cooking. The rice taste is improved. (For a small quantity of rice, pile up the rice on the center area of the inner pot to keep warm).

When Odors are Noticeable During the Warming Mode

- ▶ Clean the lid frequently. It can cause growth of bacteria and odors.
- ▶ Even though exterior looks clean, there might be germs and it can cause odor so please be sure to use automatic sterilization (steam cleaning) menu for cleaning. Clean the inner pot completely after automatic cleaning function is done. (Refer to page 18)
- ▶ Clean the inner pot properly to prevent rice from smelling after you cook and steamed dishes.



HOW TO COOK

1 Press SET button in the home screen (Rice) and the 'Rice Menu' will appear.

- Check if the removable cover is installed.
- Before cooking, check that the pressure weight well placed horizontally.
- Each time you touch the slider on the right, the menu shifts from Glutin. Rice→High Heat Glutin. Rice→Soft Glutin. Rice→Mixed Rice→High Heat Mixed Rice→Brown Rice→High Heat Brown Rice→GABA Rice(3hour)→Black Bean Rice→Nutri. Rice→Five-Frain Rice→Boiled Barley→Pea Rice→Boiled Brown Rice with Red Beans→Rice Porridge→Chinese Porridge in order.



Ex) In case of selecting Glutinous Rice.
▶ You can hear a voice, Glutinous rice.

2 Press the 'COOK/TURBO' button after selecting your desired Rice menu, and the product will start cooking.

- You must turn lid handle to lock before cooking. Then press the pressure Cook/Turbo button.
- Unless lid handle is not turned to close, you get alarm with “E01”, and sound “turn lid handle to lock”
- If you select Turbo within 5 seconds in Glutinous or Mixed Rice mode and then press the 'COOK/TURBO' button or SET button, it will shift into the Turbo Glutinous or Turbo Mixed mode and will start cooking again.
- During cooking, the expected time will be displayed on the screen.
- The actual cooking time may vary depending on the cooking capacity, water temperature, and cooking conditions.



Ex) In case of cooking Glutinous.
If you select Turbo within 5 seconds in Glutinous or Mixed Rice mode and then press the 'COOK/TURBO' button or SET button, it will shift into the Turbo Glutinous or Turbo Mixed mode and will start cooking again.

3 Cooking thoroughly.

- The cooktime remaining on the display is shown from cooking thoroughly. The cook time is different according to the menu.
- Be careful not to burn yourself from the automatic steam outlet.

Ex) When the steam starts to get discharged



4 The end of cooking.

- When cooking is completed, warming will start.
- The status LED will get turned ON.
- If you don't want to keep the cooked rice warm, press Cancel for 1 seconds.
- When cooking ends, stir rice equally and immediately. If you don't stir rice at once and keep it stagnant, rice will go bad and smell bad.
- If the lid handle is not working well, take out the steam completely out of inner pot by turning over pressure weight.
- Do not press 'Cancel' button during cooking.



How to use AUTO CLEAN (Steam Cleaning)



- Pour water up to scale 2, make sure to close and lock the cover.
- If you press the 'COOK/TURBO' Button after selecting the Automatic Sterilization mode, it starts cleaning immediately.
- If you Press SET button after selecting the Automatic Sterilization mode, you will hear the voice guidance and then press SET or COOK/TURBO button to start automatic cleaning.
- If you press the 'CANCEL' button in cleaning mode for about 1 second, the mode will be canceled and it will return to the home screen.

Melanoizing effect

The cooked rice can be light yellow at the bottom of the oven, because this product is designed to improve pleasant flavor and taste. Especially, melanoizing is more serious at the Preset Cooking than just Cooking. It does not mean malfunction.

※ When mixing other rice with Glutinous, Melanoizing effect could increase more than Glutinous cook setting.



HOW TO COOK

How to Use the Cooking Menu

GLUTIN. RICE	Used to cook sticky and nutritious rice.	SOFT GLUTIN. RICE	Used to cook a little sticky and nutritive white rice than Glutinous rice.
MIXED RICE	Used to cook a variation of mixed or brown rice.	GABA RICE	Used to cook germinated brown rice.
BLACK BEAN RICE	Used to cook Black bean rice.	BROWN RICE RICE	Used to cook variation of brown rice.
BABY FOOD	It starts cooking baby food.	HOME BAKERY	This menu is used to either ferment or bake the bread.
RICE PORRIDGE	In this mode you can make thick porridge.	NUTRI. RICE	Used to cook nutritious rice.
CHINESE PORRIDGE	In this mode you can make thin porridge.	HIGH HEAT (GLUTIN.RICE/ MIXED RICE/ BROWN RICE)	Used to cook more sticky and soothing cooked rice.
AUTO CLEAN (Steam Cleaning)	This menu is used to eliminate small soaked after cooking or warming.		
TURBO GLUTIN. RICE	<ul style="list-style-type: none"> Pressing 'COOK/TURBO' button twice will switch to quick cooking 'PRESSURE COOK' button twice will switch to quick cooking and shorten the cooking time. (It takes about 14 minutes when you cook the Glutinous rice for 2 persons.) Use this turbo cooking function only for cooking rice for less than 4persons. (The condition of the rice will not be good for more than 4 persons.) If you soak the rice in water for about 20minutes before cooking the rice and then cook the rice in turbo cooking course, the rice will taste good. 		
TURBO MIXED RICE	<ul style="list-style-type: none"> If selected turbo mixed rice, total cooking time will be reduced. (It takes about 26minutes for cooking mixed rice for 2 people.) Turbo mixed rice cooking lessens the quality of food, so only use for less than 4 people. If you soak the rice in water before cooking the rice and bean then cook, the rice will taste good. 		

※ After cooking in white rice turbo mode or cooking of small serving, discard water. In case of small servings white rice turbo cooking, more water may be required than other menu.

MENU	WATER LEVEL	CAPACITY	COOKING TIME
GLUTIN. RICE	GLUTIN. RICE	2 ~ 6 persons	Approx. 25-31 min
TURBO GLUTIN. RICE		2 ~ 4 persons	Approx. 14-19min
HIGH HEAT GLUTIN. RICE		2 ~ 6 persons	Approx. 31-42min
NUTRI. RICE		2 ~ 4 persons	Approx. 29-33min
MIXED RICE	MIXED RICE	2 ~ 4 persons	Approx. 40-46min
TURBO MIXED RICE		2 ~ 4 persons	Approx. 29-35min
HIGH HEAT MIXED RICE		2 ~ 4 persons	Approx. 43-48min
BLACK BEAN RICE		2 ~ 4 persons	Approx. 43-47min
SOFT GLUTIN. RICE	SOFT GLUTIN. RICE	2 ~ 4 persons	Approx. 49-54min
BROWN RICE RICE	BROWN RICE RICE	2 ~ 4 persons	Approx. 52-54min
HIGH HEAT BROWN RICE		2 ~ 4 persons	Approx. 51-56min
RICE PORRIDGE (Thick Porridge)	Thick porridge	1 ~ 1.5 cups	Approx. 77-104min
CHINESE PORRIDGE (Thin Porridge)	Thin Porridge	0.5 ~ 1 cups	Approx. 85-96min
BABY FOOD	-	See detailed guide to cooking by the menus.	
HOME BAKERY			
AUTO CLEAN (Steam Cleaning)	GLUTIN. RICE	Pour water up to the line 2 for GLUTIN. RICE	Approx 22min

- ※ When keeping warm, press Cancel to stop and select the desired function.
- ※ When you cook after using options like Multi Cook, Home bakery, and baby food the odor may stick. (refer to the product care method section to wipe the packing and cover and clean with the auto sterilization function).
- ※ Cooking time for each option may vary depending on user's environment such as voltage, amount/temperature of water, etc.
- ※ When you see "Edo" on display, turn the Lock/Unlock handle towards "🔓" (Unlock), and then turn it back towards "🔒" (Lock) for it to work properly. (This does not apply when you turned the handle towards "🔓" (Unlock) once or more after finishing cooking in the previous cooking.)



MY MODE(CUCKOO Customized taste function) / MY MODE(CUCKOO Customized cooking function)

What is "MY MODE"?

CUCKOO's patented technology based on variable circuit design. User can select the degree of "softness" and "glutinosity & tastiness" to meet a user's desire.

MY MODE Function

Longer "SOFT" Time : rice becomes soft and glutinous. (selectable in 4 steps)

Longer "SWEET" Time : rice becomes tastier(selectable in 4 steps) [melanoizing will occur]

※ Both functions above can be selected simultaneously or separately

How to Use "MY MODE"

- 1 Enter 'Setting' in the home screen, select 'Cook Setting' and then select 'My Mode.'**

※ 'CUCKOO Customized taste function' applies to GLUTIN. RICE, HIGH HEAT GLUTIN. RICE, MIXED RICE, HIGH HEAT MIXED RICE, BROWN RICE, HIGH HEAT BROWN RICE, GABA RICE, BLACK BEAN RICE collectively.
- 2 Select your desired menu and Press SET button.**
- 3 You may select your preferred level for each 'Soft' and 'Rich' taste with the touch slider.**

 - The level increases/decreases by one step each time you slide it. The higher the level, the softer and richer the taste gets.
 - You may select your preferred level for the 'Soft' taste with the touch slider and then press SET button to select the level for the 'Rich' taste.
- 4 Press SET button after it's finished to save the current setting.**

※ When setting your preferred taste, the cooking time may get longer depending on the selected time.
- 5 Disabling Customized Taste mode**

Selecting the level 1 (default value) would disable My Mode

※ In another 15 seconds after it's finished, it will be canceled without saving the changed value.



Cuckoo Customized Cooking Function

While cooking, you can control the heating temperature (both high and low) depending on your preference.

- 1 Enter 'Setting' in the home screen, select 'customized cooking' and then select 'My Mode.'**
- 2 Select your desired menu and Press SET button.**
- 3 Select the step you want using the touch slider.**

 - ▶ The level increases/decreases by one step each time you slide it.
 - ◀ : melanoising prevention
 - ▶ : be half-cooked prevention
- 4 Press SET button after it's finished to save the current setting.**

※ In another 15 seconds after it's finished, it will be canceled without saving the changed value.



- 'CUCKOO customized cooking function' applies to GLUTIN. RICE, HIGH HEAT GLUTIN. RICE, TURBO GLUTIN. RICE, NUTRI RICE, MIXED RICE, HIGH HEAT MIXED RICE, TURBO MIXED RICE, BROWN RICE, HIGH HEAT BROWN RICE, GABA RICE, BLACK BEAN RICE collectively.
- Set up the step of customized cooking function to taste. The scorch can occur when cooking in high level mode.
- Cook is subject to be set differently depending on the percentage of water content and the condition of rice.



HOW TO USE GABA RICE/MULTI-COOK FUNCTION

Using "GABA" Menu

1 Enter 'Rice' menu in the home screen, select the 'Gaba Rice' and press the 'COOK/TURBO' button.

- ▶ If you press the 'COOK/TURBO' button, it will start cooking immediately for the displayed germination time.
- ▶ Press SET button and then you can view the recipe.
- ▶ Press the 'COOK/TURBO' or SET button in View Recipe mode and it will start cooking.
- ▶ When starting cooking, the remaining time will be displayed with the unit of minutes.



When the "GABA" is selected, "3H" is indicated in the display


- 1 If you don't want to grow the size of the sprout germinated and want to eat earlier, select the GABA Rice while skipping the pre-germination phase, and then press the 'COOK/TURBO' button. (nutrients ingredients do not vary significantly by the size of germ).
- 2 During hot seasons, longer germination time may generate odor. Reduce germination time.
- 3 GABA cooking feeds up to 4 people.
- 4 City water can be used for germination. However, filtered or drinkable water is recommended. Germination may not be properly performed in hot or boiled water even after cooking.
- 5 Germination rate and germ growth may differ by the type of brown rice, condition, or period of storing.
 - The brown rice should be within 1 year from harvest, and not long since pounded.
- 6 In GABA mode, preset on 3H may not be possible. If you want to preset the GABA, set up BROWN RICE menu.
- 7 The taste of rice could be different depending on a kind of brown rice. Use customized taste function or control the amount of water for your taste. (Refer to Page 20)
- 8 Depending on the user's environment or the condition of the rice, the sprout may not be visible.

Multi-Cook Function

1 Enter 'Dishes' menu in the home screen, select the 'MY Multi-Cook' and press the 'COOK/TURBO' button.


2 Set your desired cooking time with the touch slider.

- ▶ Each time you press the right arrow (>), the steaming time will increase by one step.
- ▶ Each time you press the left arrow (<), the steaming time will decrease by one step. (If you keep pressing the button, it will change continuously.)
- ▶ You can set the time for Multi Cook from 10 minutes to 120 minutes.
- ▶ You can set the time from 10 minutes to 90 minutes with the unit of five minutes, and can set the time from 90 minutes to 120 minutes with the unit of 10 minutes.
- ▶ If you press the 'CANCEL' button, it will return to the home screen without saving the time.



3 Press SET and then 'COOK/TURBO' button to start cooking.

- ▶ In Multi Cook mode, the remaining time will be displayed.
- ▶ If you press SET button after selecting the cooking time, the value will be saved and you can view the recipe.
- ▶ Press the 'COOK/TURBO' or SET button in View Recipe mode and it will start cooking.





HOW TO USE MY RECIPE FUNCTION / RECENT COOK FUNCTION

My Recipe Function

This function allows you to add your favorite menu for which you could jump start cooking.

How to Use "My Recipe"


① Select 'My Recipe' in the home screen, and press SET button.

② You can select the menu added to My Recipe when you enter the mode. If you press SET button, the product will shift into the View Recipe mode, and then press the 'COOK/TURBO' button to start cooking.

(For GABA Rice/Multi Cook/Bread Fermentation/Baking mode, default time value is applied and it does not offer personalized setting option)

③ You can add up to 8 items to My Recipe.

- You may delete the default Glutinous/Mixed/Brown rice options.
- For any unsaved menu, the blank will be displayed as 'Add menu.'



Adding menu to My Recipe

① Select My Recipe in the home screen and then press SET button. In My Recipe mode, select 'Add Menu' and press SET button.

② Select the menu you want to add to My Recipe, and press SET button.


- Menu : Rice, My multi-cook, Rice dishes, Porridges, Noodles, Steamed dishes, Home bakery, Stews, Baby food
- For Multi Cook menu : Press SET button and you can change the cooking time.
- For others : Press SET button and you can view more items.

※ You can add up to 8 items for My Recipe. In this case if you want to add another menu, please delete one first before adding it.

※ In case it's overlapped, the current menu will replace the previous one.

③ Press SET button during cooking and you can add the menu to My Recipe

- ※ If you add a menu when your My Recipe list is full, it will replace automatically the one with low priority.



Delete a menu to My Recipe

① Select My Recipe in the home screen and then press SET button. In My Recipe mode, select 'Delete Menu' and press SET button.

② Select the menu you want to delete from My Recipe and press SET button.

Recent Cook Function

① Press the 'COOK/TURBO' button in the home screen (Rice) to view the meals that are cooked recently.

- ▶ Three recent items will be displayed with the most recent one being displayed on the top.
- ▶ If there is no menu cooked, the 'Glutinous rice' option will be displayed.
- ▶ Saving new options will automatically delete the ones at the bottom.

② Select the menu you want using the touch slider.

- ▶ Press SET button after selecting the menu and then you can view the recipe.
- ▶ Press the 'COOK/TURBO' or SET button in View Recipe mode and it will start cooking.

③ Press SET and then 'COOK/TURBO' button to start cooking.





HOW TO USE HOME BAKERY

ENGLISH

Using Fermentation

- 1 Enter 'Cook' in the home screen, select 'Home bakery' and then select 'Bread Fermentation.'**
- 2 Select the Fermentation time you want using the touch slider.**

 - ▶ Each time you press the right arrow (>), the Fermentation time will increase by one step.
 - ▶ Each time you press the left arrow (<), the Fermentation time will decrease by one step.(If you keep pressing the button, it will change continuously.)
 - ▶ You can set the time for Fermentation from 5 minutes to 120 minutes.
 - ▶ You can set the time from 5 minutes to 90 minutes with the unit of five minutes, and can set the time from 90 minutes to 120 minutes with the unit of ten minutes.
- 3 Press SET and then 'COOK/TURBO' button to start cooking.**

 - ▶ If you Press SET button after selecting the Fermentation time, the value will be saved and you can view the recipe.
- 4 When first fermentation is completed, press the dough softly to remove gas and repeat process 2-3 for second fermentation.**

 - ▶ After the primary fermentation is done, select 'Cook,' 'Home bakery,' and 'Bread Fermentation' in order and Press SET button. Then, a pop up saying "Move to the next phase." will show and the product shifts into the fermentation time setting mode.
 - ▶ After second fermentation, open the lid and make sure dough size is 1.5 to 2 times.
 - ▶ After the secondary fermentation is done, you will hear the voice saying "Check the progress of fermentation first and then perform additional fermentation or select the baking mode."



Using Bread Baking

- 1 Enter 'Cook' in the home screen, select 'Home bakery' and then select 'Bread Baking.'**
- 2 Select the Baking time you want using the touch slider.**

 - ▶ Each time you press the right arrow (>), the Fermentation time will increase by one step.
 - ▶ Each time you press the left arrow (<), the Fermentation time will decrease by one step.(If you keep pressing the button, it will change continuously.)
 - ▶ You can set the time for Baking from 1 minutes to 80 minutes.
 - ▶ You can set the time from 1 minutes to 20 minutes with the unit of one minutes, and can set the time from 20 minutes to 80 minutes with the unit of five minutes.
 - ▶ If you press SET button during baking, it will be saved in My Recipe.
 - ▶ Once the baking begins, the cooking icon will be displayed along with the remaining time.
- 3 Press SET and then 'COOK/TURBO' button to start cooking.**

 - ▶ If you Press SET button after selecting the Baking time, the value will be saved and you can view the recipe.
 - ▶ Press the 'COOK/TURBO' or SET button in View Recipe mode and it will start cooking.

※ When the "Bread Baking" process is complete. Immediately remove the bread from inner pot.
 ※ After the "Bread Baking" is complete, the bread is hot and you should be careful.



▼ If there is a problem of fermentation / bread baking, check the following details.

Case	Check point	Do the following
D O U G H • When dough is not inflated	• Is capacity of the material accurate? • Is the fermentation time long or short? • Does the dough become elastic or loose?	• Check the volume of the ingredients and knead the dough well.
B A K E D B R E A D • When bread is small and stiff. • When bread is dry and hard • When bread was undercooked. • When bread was overcooked.	• Are measurements and cook timing correct? • Fermentation time and kneading time set correctly? • Did you set short fermentation time or baking time? • Did you set long fermentation time or baking time?	• Follow the correct ingredient volumes and directions for fermentation and baking time.
• When the bottom of the bread is not brown or cooked • When the bread is too sticky and undercooked.	• Did you put the dough in the middle of inner pot. Did you set short baking time? • Did you remove baked bread immediately?	• When the second fermentation is complete, the dough should be left in the middle of the inner pot. Extend baking time. • When the "Bread Baking" process is complete, immediately remove the bread from the inner pot.

※ Please cook according to the Cooking Guide (Page 34) to ensure it's properly baked.



HOW TO USE PRESET COOKING / POWER-SAVING STANDBY FUNCTION



How to Preset Timer for Cooking

- 1 Check if the current time and menu are correct.
- 2 Enter 'Preset' in the Home Screen, select the Preset menu, and press SET button.

▶ You can preset cooking only for the rice menu (Turbo Glutinous, Turbo Mixed and GABA rice NOT included).

- 3 Select the Baking time you want using the touch slider.

▶ You can set the hour first with the touch slider and press SET button. After that you can set the minutes.
 ▶ Press BACK button to move from the 'minute' to 'hour' screen.
 ▶ The hour is changed with the unit of one hour, and the minute is changed with the unit of ten minutes.
 ▶ Please be careful not to change from AM to PM.



- 4 Press SET or 'COOK/TURBO' button to start cooking.

※ The preset cooking time is set for the maximum portion for each menu. Therefore, the smaller the quantities of ingredients, the earlier the cooking time may be completed than the preset time.

Precautions for Preset Cooking

- 1 In case of preset cooking

▶ If the rice is old and dry, the result may not be good
 ▶ If the rice is not well cooked, add more water by about half-scale.
 ▶ If the preset time is longer, melanization could be increased.

PRESET COOKTIME																
MENU	GLUTIN. RICE	HIGH HEAT GLUTIN. RICE	MIXED RICE	HIGH HEAT MIXED RICE	SOFT GLUTIN. RICE	BROWN RICE	HIGH HEAT BROWN RICE	NUTRI. RICE	BLACK BEAN RICE	FIVE-GRAIN RICE	BOILED BARLEY	PEA RICE	Boiled Brown Rice with Red Beans	RISE PORRIDGE (Thick Porridge)	CHINESE PORRIDGE (Thin Porridge)	Preset Reheating
PRESET COOK TIME	(36min+ My mode time) ~13hours	(47min+ My mode time) ~13hours	(51min+ My mode time) ~13hours	(53min+ My mode time) ~13hours	50min ~13hours	(59min+ My mode time) ~13hours	(61min+ My mode time) ~13hours	38min ~13hours	52min ~13hours	51min ~13hours	51min ~13hours	36min ~13hours	59min ~13hours	109min ~13hours	101min ~13hours	180min ~13hours

Power-Saving Standby Mode

If the selected time has passed in the Standby status, it will automatically enter the power saving mode.

- 1 Enter 'Setting' in the home screen, select 'Screen Setting' and then select 'Power-Saving Standby.'

- 2 Select the Power-Saving Standby time you want using the touch slider.

▶ "1 minute(default)", "3 minute", "5 minute"

- 3 Press SET button and it will be saved.

▶ If it's left idle for 15 seconds or so during setting, you will hear voice guidance. In another 15 seconds after it's finished, it will be canceled without saving the changed value.

※ Disabling Power Saving Mode

1. If you press every button, the mode will be canceled and the product will return to the home screen.
2. If you turn the handle, the power saving mode will be canceled and the product will return to the home screen.
3. If the power is supplied again after blackout, it will return to the home screen.
4. If the power cable is plugged out and then plugged in again in the power-saving mode, the mode will be canceled and the product will return to the Home Screen.





HOW TO USE POWER SAVE SCREEN LIGHT MODE / PRESET REHEATING FUNCTION

Power Save Screen Light Mode

In Standby, Cooking, Keep Warm and Preset cooking mode, this function reduces power consumption by lowering the brightness of the screen after a certain amount of time has passed.


- 1 Enter 'Setting' in the home screen, select 'Screen Setting' and then select 'Screen saver Power-Saving Standby.'
- 2 Select 'Enable' or 'Disable' with the touch slider.
 - ▶ The default value is 'Enable'.
- 3 Press SET button and it will be saved.
 - ▶ If you press the 'CANCEL' button during setting, it will return to the home screen without saving the changed value.
 - ▶ If left idle for 15 seconds or during setting, you will hear voice guidance. If still left idle after an additional 15 seconds, settings will be canceled without saving the changed value.
 - ▶ It lowers the total brightness of the LCD to 50%.
 - ▶ Screen Saver On: If it's left idle for a certain amount of time, the screen will be darker.



How to Use Preset Reheating Function

- ▶ Use this function when the cooked rice is not kept warm in the rice cooker but you still want to enjoy a hot meal at your convenience.
- ▶ It takes 100 minutes before it's fully warmed up:
Please use the function at least 100 minutes before you enjoy your meal.

- 1 Check if the current time and the menu are correct.
- 2 Enter 'Preset' in the home screen, select the Preset Reheating menu, and press SET button.
- 3 Press the touch slider to preset the completion time of reheating.
 - ▶ You can set the hour first with the touch slider and press SET button. After that you can set the minutes.
 - ▶ Press BACK button to move from the 'minute' to 'hour' screen.
 - ▶ The hour is changed with the unit of one hour, and the minute is changed with the unit of ten minutes.
 - ▶ Please be careful not to change from AM to PM.
- 4 Press SET or 'COOK/TURBO' button to start cooking.
 - ▶ The preset time will be saved whether the preset reheat process is completed or canceled in the middle. (However, if it exceeds 13 hours, the previously memorized time will be maintained.)
 - ▶ When the preset reheat process is completed, the product will enter the Keep Warm mode.



Precautions for Preset Reheating

- 1 In case of preset reheating.
 - ▶ When leaving cooked rice at ambient temperature for a prolonged period of time, moisture is evaporated from cooked rice. In such a case, the reheating preset may cause dehumidifying or melanosis (slightly burnt) of cooked rice.
 - ▶ If there is an excessive amount of cooked rice in the pot, it may not sufficiently be reheated.
 - ▶ It is recommended to set reheating for no more than 5 people. (approx. half of the inner pot)
 - ▶ Reheating of cold- or frozen-stored cooked rice may cause insufficient heating, dehumidifying or melanosis (slightly burnt) after completion of reheating.
 - ▶ Reheating of frozen-stored cooked rice shall be performed only after thawing the rice.
- 2 Changing preset time.
 - ▶ If the preset time is shorter than the available range(100 minutes), reheating will begin immediately.
- 3 If the preset time is shorter than available range.
 - ▶ If the preset time is shorter than the available range(100 minutes), reheating will begin immediately.
- 4 In case the preset time is over 13 hours.
 - ▶ "13Ho" will be displayed and the preset time will be changed to 13 hours automatically. If cooking is preset to AM07:00 of the following day at PM5:00 of the day, where preset time is 14 hours, "13Ho" will be displayed, and preset time



TO KEEP COOKED RICE WARM AND TASTY

How to Keep Warm

- 1 Press the Warm/Reheat button or select the 'Keep Warm/Reheat' mode from the home screen. After that press SET or the 'COOK/TURBO' button.
- 2 In this mode, the screen will display 'Keep Warm'.
 - ▶ The warming time is displayed with the unit of one minute.
 - ※ If the power is supplied again after blackout, it will start from Keep Warm mode again. But, when the rice is cooled down, the mode will be canceled and the product will return to the home screen.

How to Reheating

- ▶ If you want to have warm rice, press the "REHEAT/ WARM" button.
- ▶ Reheating will be done for nine minutes, and then the Keep Warm mode begins again.
- ▶ The frequent use of the "Reheat" function may cause the cooked rice to be discolored or dried. Use it once or twice per day.

- 1 Press the 'COOK/TURBO', SET or the 'Warm/Reheat' button during Keep Warm, and it will start reheating.
- 2 If you Press, however, SET or the 'Warm/Reheat' button again in the middle, Reheating will be canceled and the product will return to the Keep Warm mode.
 - ▶ If the lid combining hand grip is turned to open status during reheating, function display will show "E01". At this time, reheating will be cancelled, and heat preservation will proceed.

Keep Warm Temperature Setting Function

If the temperature in the rice cooker is not set properly, an odor or the color of the rice may change even though it is cleaned frequently and boiled up. Temperature needs to be set.

- 1 Enter 'Setting' in the home screen, select 'Keep Warm Setting' and then select 'Keep Warm Temperature'.
- 2 Select the temperature you want using the touch slider.
 - ▶ The default value is 74°C
 - ▶ Each time you press the right arrow (>), the warming temperature will increase by one degree.
 - ▶ Each time you press the left arrow (<), the warming temperature will decrease by one degree.
 - ※ The reference temperature programmed when the product is shipped may differ from the Instruction.
- 3 Press SET button to save setting.



Device Temperature Control

1. When you smell bad odors and the rice is too watery : The keep warm temperature is too low. In this case, increase the "Keep Warm" temperature by 1-2.
2. When the rice has a yellowish color or is too dry : The Keep Warm temp is too high. In this case decrease the "Keep Warm" temperature by 1-2.

Customized Taste Keep Warm Setting Function

Use it while opening the lid when there is too much water or rice becomes too soft.


- 1 Enter 'Setting' in the home screen, select 'Keep Warm Setting' and then select 'Customized Taste Keep Warm'.
- 2 Select the temperature you want using the touch slider.
 - ▶ Each time you press the right arrow (>), the controlling temperature for top heater will increase by one degree, and you can set values from Step -2 to Step 2. (Use it when the water flows excessively when you open the lid.)
 - ▶ Each time you press the left arrow (<), the controlling temperature for top heater will increase by one degree, and you can set values from Step -2 to Step 2. (Use it when you find that the rice is partially over cooked on the side.)
- 3 Press SET button and it will be saved.



How to Set "Sleeping" Function

When keeping rice warm for a long time, set up the temperature low to prevent the following quality of rice: smelly, dry, change of color; from PM10:00 ~ AM 04:00.

- 1 Enter 'Setting' in the Home Screen, select 'Keep Warm Setting' and then select 'Sleeping Keep Warm'.
- 2 Select 'Enable' or 'Disable' with the touch slider.
 - ▶ The default value is 'Disable'
- 3 Press SET button and it will be saved.
 - ※ If it enters the Keep Warm mode while you are sleeping, however, this function will not be applied.



※ If you need to keep the rice warm during sleeping, do not use this function. This function makes the rice cooler than normal. In summer, the rice can be spoiled and may smell bad because of high temperature. If possible, do not use the "Custom-Made Warming" mode while sleeping.



REMAINING COOKING TIME DISPLAY / LOCK BUTTONS / PRODUCT INITIALIZATION / HELP FUNCTION

ENGLISH

REMAINING COOKING TIME DISPLAY FUNCTION

Enter 'Setting' in the home screen, select 'Screen Setting' and then select 'Remaining cooking time display.'


- 1 Enter 'Setting' in the home screen, select 'Screen Setting' and then select 'Remaining cooking time display.'
- 2 Select whether to display remaining time with the touch slider.
 - ▶ The default value is 'Disable'
- 3 Press SET button and it will be saved.
 - ▶ If left idle for 15 seconds or during setting, you will hear voice guidance. If still left idle after an additional 15 seconds, settings will be canceled without saving the changed value.




How to Set "LOCK BUTTONS"

Lock can be set for touch button to prevent accidental touch during cleaning or by children.

▶ Setting Method



▶ How to set and unset the mode



1. If you press the 'PREV.' button for three seconds or longer in Standby, Cooking, Presetting, and Keep Warm/Reheat mode, it will enter the Button Lock mode.
2. You will here the voice guidance that says "Button Lock Activated." Here, a lock icon will be displayed as "🔒" on the top of the screen.
1. If you press the 'PREV.' button for three seconds or longer in Standby, Cooking, Presetting, and Keep Warm/Reheat mode, it will enter the Button unLock mode.
2. You will here the voice guidance that says "Button unLock Activated." Here, a lock icon will be displayed as "🔓" on the top of the screen.

- ※ If you press any other button than the 'PREV.' button while the button lock is selected, a buzzer sound will be made, and the screen notifying that it is in the locked status will be displayed.
- ※ You may unlock the buttons by pressing the 'PREV.' button for three seconds or longer.
- ※ If you pull out and put in the Power Plug again after setting the button lock, the Button Lock Function will be canceled.

How to Use "Product Initialization"

Set the default values of multiple customization functions and user option functions.


▶ How to initialize set values

- 1 Enter 'Setting' in the home screen and select Product initialization, and Press SET button.
- 2 Select 'Yes' when it says "the product will be reset to its factory default settings. Will you continue?", and press SET button.
- 3 If you initialize the product, the current time will also be initialized. Therefore, set the current time before using the product. (Refer to Page 16)



Help Function

Enter 'Help' in the home screen and select your desired category, and Press SET button. You may refer to the information listed in the selected category.



- ▶ CHECK BEFORE ASKING : The items are classified according to the characteristics of the problem. When cooking is not well, When the warm is not well, When the reservation is not well, When the operation is not well, When errors occur.
- ▶ FOR SERVICE HOW TO CLEAN DETACHABLE COVER
- ▶ HOW TO REPLACE PRESSURE PACKING
- ▶ PRODUCTION INFORMATION : You can see the Model, Service Center, Phone numbers, Website address.

CHECK BEFORE ASKING FOR SERVICE

▼ If there is a problem with your cooker, check the following details before requesting service to your dealer.
Sometimes the cooker may not operate as desired if used incorrectly.

Case	Check points	Do the following
When the rice is not cooked.	<ul style="list-style-type: none"> • 'COOK/TURBO' button is pressed? • Is there power cut while in cooking? 	<ul style="list-style-type: none"> • Press the 'COOK/TURBO' button once. • Refer to page 16 for blackout compensation.
When the rice is not well cooked.	<ul style="list-style-type: none"> • Did you use the measuring cup for the rice? • Did you put proper amount of water? • Did you rinse the rice before cooking? • Did you put rice in water for a long time? • Is the rice old or dry? 	<ul style="list-style-type: none"> • Refer to page 17 • Add water about half the notch and then cook.
Bean (other grains) is half cooked.	<ul style="list-style-type: none"> • Is bean (other grains) too dry? 	<ul style="list-style-type: none"> • Soak or steam beans and other grains before cooking in the pressure cooker in order to avoid partially cooked beans or grains. Beans should be soaked for -2-minutes or steamed for 2-minutes prior to cooking, depending on your taste.
Rice is too watery or stiff.	<ul style="list-style-type: none"> • Is the menu selected correctly? • Did you properly measure water? • Did you open the top cover before cooking was finished? 	<ul style="list-style-type: none"> • Select the correct menu. • Properly measure water. • Open the top cover after cooking finished
When the water overflows.	<ul style="list-style-type: none"> • Did you use the measuring cup? • Did you use proper amount of water? • Is the menu selected correctly? 	<ul style="list-style-type: none"> • Refer to page 17
Brown rice is not germinated Properly.	<ul style="list-style-type: none"> • Does the amount of rice exceed the specified maximum capacity? • Is bean (other grains) too dry? 	<ul style="list-style-type: none"> • Put the specified maximum capacity of brown rice. • Old rice or contaminated rice may not be germinated properly.
When the rice is badly sticky.	<ul style="list-style-type: none"> • Is there any rice or any other alien substance on the temperature sensor or the bottom surface of the inner pot? 	<ul style="list-style-type: none"> • Clean all the alien substances on the temperature sensor or the bottom surface of the inner pot.
When smell after and before cooking?	<ul style="list-style-type: none"> • Did you clean it after cooking? 	<ul style="list-style-type: none"> • Please clean it after cooking.

CHECK BEFORE ASKING FOR SERVICE

▼ If there is a problem with your cooker, check the following details before requesting service to your dealer.
Sometimes the cooker may not operate as desired if used incorrectly.

Case	Check points	Do the following
When you smell odors while warming.	<ul style="list-style-type: none"> • Did you close the top cover? • Please check if the power cord is plugged. • Did it warm over 12 hours? • Is there any other substance such as rice scoop or cold rice? 	<ul style="list-style-type: none"> • Close the top cover perfectly. • Always keep the power on while warming. • As possible, keep warming time within 12 hours. • Don't warm rice with other substance.
Warming passed time mark blinks during keeping warm.	<ul style="list-style-type: none"> • 24 hours has not passed yet after Keeping warm 	<ul style="list-style-type: none"> • This function alarms if the rice remained warm for more than 24 hours.
Rice has gotten cold or a lot of water flow during Keeping warm	<ul style="list-style-type: none"> • Keeping warm was set in "Sleeping" mode 	<ul style="list-style-type: none"> • Keep warm after cancelling or setting "Sleep Keeping Warm" mode depending on the necessity.
Alarm sounds or reheating does not work while keeping warm	<ul style="list-style-type: none"> • Detachable cover is not mounted 	<ul style="list-style-type: none"> • Mount detachable cover(Refer to page 12).
When the time cannot be preset.	<ul style="list-style-type: none"> • Is the current time correct? • Is AM or PM set properly? • Did you set the reservation time over 13 hours? 	<ul style="list-style-type: none"> • Set the current time. • Check the AM and PM. • Maximum reservation time is 13 hours.
When the top cover cannot be closed.	<ul style="list-style-type: none"> • Is the inner pot correctly inserted in the main body? • Is the Lock/Unlock handle on the top cover set to "Lock"? • Is there hot food in the inner pot? 	<ul style="list-style-type: none"> • Please put in the inner pot perfectly. • Please turn the "Lock/Unlock" handle to "Lock". • Pull the pressure handle to aside once.
When cannot turn to "Unlock".	<ul style="list-style-type: none"> • Did you turn the "Lock/Unlock" handle while cooking? • Did you turn the "Lock/Unlock" handle before exhausting steam perfectly? 	<ul style="list-style-type: none"> • Don't open the top cover while cooking. If you want to open top cover while cooking, press the "Cancel" button more than 1 seconds and release the steam. • Pull the pressure handle to the side once and allow the steam to release.
When the top cover cannot open although the Lock/Unlock handle is turned to "Unlock".		<ul style="list-style-type: none"> • Because of the pressure. • Pull the pressure handle to aside once and exhaust the steam completely.
When the steam exhausted between the top cover.	<ul style="list-style-type: none"> • Is there an external substance on the packing? • Is packing too old? 	<ul style="list-style-type: none"> • Clean the packing with duster. • Keep the packing clean. • If the steam is exhausted through the top cover, please power off and contact the service center and dealer. • Packing life cycle is 12 month, please replace the packing once a year.
When the "Cancel" button does not operate while cooking.	<ul style="list-style-type: none"> • Is the inner pot hot? • Is currently the setting to lock button mode? 	<ul style="list-style-type: none"> • Keep pressing the "Cancel" button for 1 seconds for safety reason if you want to cancel while cooking. • Be careful of hot steam emission or hot contents spattered from the automatic steam outlet during cancellation. • Please press "Set" button for over 3 seconds to release.

CHECK BEFORE ASKING FOR SERVICE

▼ If there is a problem with your cooker, check the following details before requesting service to your dealer. Sometimes the cooker may not operate as desired if used incorrectly.

Case	Check points	Do the following
When you hear weird noises during cooking and warming	<ul style="list-style-type: none"> Is there a wind blowing sound when cooking the rice? Is there a "Chi" sound when warming the rice? 	<ul style="list-style-type: none"> This is the sound of the fan motor to cool the internal parts. This is normal. The "Chi" sound during the warming process is the sound of IH cooker operating. This is normal.
If "E _{do} " sign is appears.	<ul style="list-style-type: none"> It shows on the display when pressing "Start" button again, or when the cooking has finished and you ve never turned the handle to 'Unlock'. 	<ul style="list-style-type: none"> It can be solved by turning handle to 'Unlock' and then turn to 'Lock'.
"E _{co} " sign shows up	<ul style="list-style-type: none"> Detachable cover is not mounted 	<ul style="list-style-type: none"> Mount detachable cover(Refer to page 12) If "E_{co}" sign is displayed continuously even though you already installed detachable cover, please contact customer service.
When the button cannot operate with "LJ"	<ul style="list-style-type: none"> Is the inner pot inserted? Check the rated voltage? 	<ul style="list-style-type: none"> Please insert inner pot. This product is 120V only.
When the Pressure "Cook/Turbo" Timer button does not operate with "E ₀₁ "	<ul style="list-style-type: none"> Did you turn the lid Handle to "Lock" Is "Lock" lamp on? 	<ul style="list-style-type: none"> Please turn the "lid" handle to "Lock".
If "E _u " sign is appears.	<ul style="list-style-type: none"> Micom power is out. 	<ul style="list-style-type: none"> Please cut the power and contact customer service.
When "E _p " are shown on the LCD by turns	<ul style="list-style-type: none"> The sensor is broken 	<ul style="list-style-type: none"> Please cut the power and contact customer service.
E _{uF} , E _{uF1} , E _{uF2} Signs show up.	<ul style="list-style-type: none"> Micom memory is out. 	<ul style="list-style-type: none"> Please cut the power and contact customer service.
When "H _F , H _P " are shown on the LCD by turns		<ul style="list-style-type: none"> Is there power cut while in cooking? Please cut the power and contact customer service.
"E _u ", "E _p ", "E _t " Signs show up.	<ul style="list-style-type: none"> Temperature sensor or fan motor does not work properly. 	<ul style="list-style-type: none"> Unplug the power cord and call the Service center.
"E _f " sign shows up	<ul style="list-style-type: none"> fan motor does not work properly. 	<ul style="list-style-type: none"> Unplug the power cord and call the Service center.
If "E _o " sign is appears.	<ul style="list-style-type: none"> Is there any foreign material other than inner pot inside the cooker? 	<ul style="list-style-type: none"> Unplug the power cord and call the Service center.
If "E ₀₄ " sign is appears.	<ul style="list-style-type: none"> It appears when there is a problem with touch buttons. 	<ul style="list-style-type: none"> Unplug the power cord and call the Service center.
If "E _{oP} " sign is appears.	<ul style="list-style-type: none"> It appears when there is a problem with MICOM transmission. 	<ul style="list-style-type: none"> Unplug the power cord and call the Service center.
Nothing appears on LCD screen. All the buttons except the slide touch button are blinking,	<ul style="list-style-type: none"> It appears when there is a problem with LCD transmission. 	<ul style="list-style-type: none"> Unplug the power cord and call the Service center.
The power is not on after plug in the power cord,		<ul style="list-style-type: none"> Please turn on the standby power switch button.



RECIPE

※ Please refer to our website (www.cuckoo.co.kr) for more information.

※ After cooking refer to page 12 of the notes upon the inner pot washing.

SELECT MENU	MENU TO COOK	COOKING TIME	INGREDIENTS	DIRECTIONS	
RICE	GLUTIN. RICE	Approx. 30min	Rice 4 cups The* cup*in ingredients means a measuring cup in the rice cooker. 1 cup (180cc) is for one person.	1. Put clean-washed rice in the inner pot and pour water up to the line 4 for GLUTINOUS. 2. Close the lid, select the 'Rice' or 'High heat Glutin.Rice' menu in 'Rice' from the display panel, and press the 'COOK/TURBO' button.	
	HIGH HEAT GLUTIN. RICE	Approx. 37min	Rice 4 cups		
	SOFT GLUTIN. RICE	Approx. 54min	Rice 4 cups	1. Put clean-washed rice in the inner pot and pour water up to the line 4 for Soft GLUTIN. 2. Close the lid, select the 'SOFT Glutinous rice' menu in 'Rice' from the display panel, and press the 'COOK/TURBO' button.	
	MIXED RICE	Approx. 46min	Rice 2 cups, Brown rice 2 cups	1. Put clean-washed rice in the inner pot and pour water up to the line 4 for MIXED RICE. 2. Close the lid, select the 'Mixed Rice' or 'High Heat Mixed Rice' menu in 'Rice' from the display panel, and press the 'COOK/TURBO' button.	
	HIGH HEAT MIXED RICE	Approx. 48min	Rice 2 cups, Brown rice 2 cups		
	BROWN RICE	Approx. 53min	Brown rice 4 cups	1. Put clean-washed rice in the inner pot and pour water up to the line 4 for GABA RICE. 2. Close the lid, select the 'Brown rice' or 'High heat Brown rice' menu in 'Rice' from the display panel, and press the 'COOK/TURBO' button.	
	HIGH HEAT BROWN RICE	Approx. 55min	Brown rice 4 cups		
	GABA RICE	-	Brown rice 4 cups	1. Put clean-washed rice in the inner pot and pour water up to the line 4 for GABA RICE. 2. Close the lid, select the 'GABA rice' menu in 'Rice' from the display panel, and press the 'COOK/TURBO' button.	
	BLACK BEAN RICE	Approx. 47min	Rice 4 cups, Black bean 1 cups, 1.5 tablespoons Of clear rice wine, 1.5 teaspoons of salt. *If you want softer beans, soak black beans in water or boil them. When cooking black rice, add 1/2 measuring cup of water for two people, 3/4 measuring cup for four and one cup for six people.	1. Put clean-washed rice in the inner pot and pour water up to the line 4 for GLUTINOUS. 2. Put washed black beans on top of that, additionally pour 1 cup of water, and mix the rice and the black beans. 3. Close the lid, select the 'BLACK BEAN rice' menu in 'Rice' from the display panel, and press the 'COOK/TURBO' button.	
	NUTRI. RICE	Approx. 32min	4 cups of rice, 4 roots of Fresh Ginsengs, 4 chestnuts, 4 jujubes, 12 ginkgo nuts, 2 tablespoons Of clear rice wine *Seasoning sauces : soy sauce 4 tablespoons, chopped scallion 2 tablespoons, crushed garlic 1/2 tablespoon, red pepper powder 1/2 teaspoon, ground sesame mixed with salt 2 teaspoons, sesame oil 1 teaspoon	1. Put clean-washed rice in the inner pot and pour water up to the line 4 for GLUTINOUS. 2. Close the lid, select the 'NUTRI. rice' menu in 'Rice' from the display panel, and press the 'COOK/TURBO' button.	
	FIVE-GRAIN RICE	Approx. 40min	1.5 cup of rice, millet 1/3 cup, glutinous rice 1/2cup, red beans 1/3cup, sorghum 1/3cup and salt 1 teaspoon	1. Put clean-washed rice in the inner pot and pour water up to the line 3 for Mixed Rice. 2. Close the lid, select the 'relevant menu' menu in 'Rice' from the display panel, and press the 'COOK/TURBO' button.	
	BOILED BARLEY	Approx. 40min	2 cup of rice, 1 cup of barley		
	PEA RICE	Approx. 29min	3 cups of rice, 1/2 cup of pea, 1 tablespoons Of clear rice wine, 1.5 teaspoonful of salt. *Boil pea before cooking.	1. Put clean-washed rice in the inner pot and pour water up to the line 3 for Glutinous Rice. 2. Close the lid, select the 'Pea rice' menu in 'Rice' from the display panel, and press the 'COOK/TURBO' button.	
	Boiled Brown Rice with Red Beans	Approx. 44min	Brown rice 1 cup, rice 2 cup and red beans 1/3 cup	1. Put clean-washed rice in the inner pot and pour water up to the line 3 for GABA Rice. 2. Close the lid, select the 'Boiled Brown Rice with Red Beans' menu in 'Rice' from the display panel, and press the 'COOK/TURBO' button.	
Rice porridge	Approx. 79min	Rice 1 cup	1. Put the prepared ingredients in the Inner Pot and pour water up to the appropriate water level depending on the quantity of food to be served. [Rice porridge: water up to the line 1 for Thick porridge, Chinese porridge: water up to the line 1 for Thin porridge] *Note: The maximum quantity for rice porridge is 1.5cups, and the maximum quantity for Chinese porridge is 1 cups.		
Chinese Rice porridge	Approx. 85min	Rice 0.5 cup	2. Close the lid, select the 'Rice porridge' OR 'Chinese porridge' menu in 'Rice' from the display panel, and press the 'COOK/TURBO' button.		
COOKING	MY MULTI-COOK	MY MULTI-COOK	10~120 min	You can set the time for Multi Cook from 10 minutes to 120 minutes.	1. Put the prepared ingredients in the inner pot. 2. Close the lid, select the 'My multi-cook' menu in 'Cooking' from the display panel, and press the 'COOK/TURBO' button.
	RICE COOKING	Nut Rice	Approx. 32min	4 cups of rice, 4 walnuts, pine nut 2 tablespoon, almond 2 tablespoon, cashew nut 2 tablespoon, 15 ginkgo nuts *Seasoning sauces : soy sauce 4 tablespoons, chopped scallion 2 tablespoons, crushed garlic 1/2 tablespoon, red pepper powder 1/2 teaspoon, ground sesame mixed with salt 2 teaspoons, sesame oil 1 teaspoon	1. Put clean-washed rice in the inner pot and pour water up to the line 4 for Glutinous Rice. 2. Close the lid, select the 'Rice cooking' option in 'Cooking' from the display panel, and press the 'COOK/TURBO' button.



RECIPE

SELECT MENU	MENU TO COOK	COOKING TIME	INGREDIENTS	DIRECTIONS	
COOKING	RICE COOKING	Assorted Mushroom Rice	Approx. 32min	4 cups of rice, 600g of beech mushroom, 40g of enoki mushroom, 4 button mushrooms	1. Put clean-washed rice in the inner pot and pour water up to the Line 4 for Glutinous Rice. 2. Close the lid, select the 'Rice cooking' menu in 'Cooking' from the display panel, and press the 'COOK/TURBO' button. *Seasoning sauces : soy sauce 4 tablespoons, chopped scallion 2 tablespoons, crushed garlic 1/2 tablespoon, red pepper powder 1/2 teaspoon, ground sesame mixed with salt 2 teaspoons, sesame oil 1 teaspoon
		Mushroom Bamboo shoot Rice	Approx. 32min	4 cups of rice, 200g of oyster mushroom, 100g of bamboo shoot, 10 ginkgo nuts	
		Green Tea Rice Blended with Chicken Chest Flesh	Approx. 53min	2 cups of brown rice, 3g of green tea leaf, 10g of green tea powder, 4 nuggets of chicken chest flesh, a little bit of olive oil, a little bit of salt, a little bit of pepper, 5g of celery, a little bit of lime, a little bit of rosemary	
		Mushroom Tian	Approx. 53min	2 cups of brown rice, 20g of brown gravy sauce, a little bit of salt, 2 sheets of sesame leaves, 1/3 pieces of pumpkin, a pack of shimeji mushroom	
		Saessak Bibimbap (rice with sprout and vegetables)	Approx. 53min	2 cups of brown rice and some sprouts and vegetables. * Seasoning red pepper paste : Red pepper paste 1/2cup, beef (crushed)40g, sesame oil 1 tablespoon, honey 1 tablespoon and sugar 1 tablespoon, 1/3 cup of water	
	PORRIDGE COOKING	Chicken Rice Porridge	Approx. 97min	1 cups of rice, 100g of chicken, 300 cc of chicken broth, 1ea green chili, 1ea red pepper, some salt *Seasoning sauces : chopped scallion 1 tablespoons, crushed garlic 1 tablespoon, soy sauce 2 tablespoons, red pepper powder 1/2 teaspoon, some ground sesame, sesame oil 2 teaspoon	1. Put the prepared ingredients in the Inner Pot and pour water up to the appropriate water level depending on the quantity of food to be served. [Chicken Rice Porridge: water up to the line 1 for Thick porridge, Pine Nut Porridge: water up to the line 1.5 for Thick porridge, Abalone Rice Porridge: water up to the line 1 for Thick porridge, Adzuki-Bean: water up to the line 1.5 for Thick porridge] 2. Close the lid, select the 'Porridge cooking' menu in 'cooking' from the display panel, and press the 'COOK/TURBO' button.
		Pine Nut Porridge	Approx. 95min	1 cups of rice, 1 cups Pine Nut, some salt	
		Abalone Rice Porridge	Approx. 87min	1 cups of rice, sesame oil 1 tablespoon, 1ea abalone , some salt	
	STEAM COOKING	Adzuki-Bean	Approx. 91min	1 cups of rice, 1/3 cups Adzuki-Bean, 1 cups glutinous rice flour	1. Put the prepared ingredients in the inner pot. 2. Close the lid, select the 'STEAMED cooking' menu in 'cooking' from the display panel, and press the 'COOK/TURBO' button.
		Steamed Chicken	Approx. 35min	a chicken (700g) , 50g of potato, 50g of carrot, Sugar 1 tablespoons, 1 teaspoons of chopped green onion, crushed garlic 1 teaspoon, soy sauce 3 tablespoons, ginger juice 1 teaspoon, some ground pepper, ground sesame 1/2 tablespoons, sesame oil 1 teaspoon	
Steamed Rice Cake		Approx. 45min	2.5 cups nonglutinous rice powder, 2 cups adzuki beans, salt 1/2tablespoons, Sugar 2.5 tablespoons, water 1.5 tablespoons		
Braised Short Ribs		Approx. 35min	1.2 kg of beef rib (pork rib), refined rice wine 3 tablespoons, soy sauce 5 tablespoons, chopped garlic 1 tablespoon, sesame oil 1 tablespoons, onion juice 3 tablespoons, pear juice 3 tablespoons, sugar 3 tablespoons, 5 tablespoons of chopped green onion, ground sesame 1 tablespoons, ground pepper 1/2 teaspoons, carrot 1ea, Chestnut 10ea, ginkgo nut 20ea, pine nut powder 1 tablespoons		
Five Spice Sliced Steamed Pork		Approx. 30min	400g of pork, soy sauce 1/3 cups, sugar 2 tablespoons, water 1.5 cups, a little machine cotton *five spice: six whole peppers, 7cm of whole cinnamon, 4ea star anise		
Seamed POTATO		Approx. 30min	Potato 3EA (less than 200g)		
Steamed corn		Approx. 30min	Corn 2ea		
Steamed Clam		Approx. 25min	Clam 2ea, 15g of beef, 1/2 egg white, egg 1/2ea, 1 teaspoons of chopped green onion, 1/2 teaspoon of crushed garlic, salt 1/4 teaspoons, some ground pepper		
Steamed Blue Crab		Approx. 30min	blue crab 1ea, 150g of beef, 1/4 piece of tofu, a half of green chili, a half of red pepper, a half of egg yolk, some flour		
Boiled Pork Slices		Approx. 30min	400g of pork (shin fore shank or pork belly), ginger 1ea, some garlic, onion 1ea, spring onion, 1ea, some kimchi		
Multi-Flavor Glutinous Rice	Approx. 30min	3 cups of glutinous rice, 60g of raisin, 15 chestnuts, 10 jujubes, pine nut 1 tablespoon, 100g of black sugar, thick soy 1 tablespoon, sesame oil 3 tablespoons, some salt, cinnamon powder 1/2 teaspoon	1. Put the prepared ingredients in the inner pot. 2. Close the lid, select the 'STEAMED cooking' menu in 'cooking' from the display panel, and press the 'COOK/TURBO' button.		



RECIPE

ENGLISH

SELECT MENU	MENU TO COOK	COOKING TIME	INGREDIENTS	DIRECTIONS	
C O O K I N G	STEAM COOKING	Steak	Approx. 20min	Beef(for steak) 200g, some steak sauce, some salt, some ground pepper	<ol style="list-style-type: none"> 1. Pour 1 cups of water in the inner pot and place the steam plate. Put the prepared ingredients on top of the plate. 2. Close the lid, select the 'STEAMED cooking' menu in 'cooking' from the display panel, and press the 'COOK/TURBO' button.
		Steamed Sweet Potato	Approx.25min	Sweet potato 3EA *When sweet potato is large (more than 150g), cut it into two pieces.	<ol style="list-style-type: none"> 1. Pour 1.5 cups of water in the inner pot and place the steam plate. Put the prepared ingredients on top of the plate. 2. Close the lid, select the 'STEAMED cooking' menu in 'cooking' from the display panel, and press the 'COOK/TURBO' button.
		Steamed Chestnut	Approx.20min	Chestnut 15EA	
		Steamed Fish	Approx. 25min	One sea bream, 50g of beef, One sea bream 3EA, manna lichen 2EA, red pepper 1EA, egg 1EA, some chopped green onion, some soy sauce, some sesame, some oil, some salt, some ground pepper	
		Steamed Dumpling	Approx 20min	Dumplings 20EA	<ol style="list-style-type: none"> 1. Put the prepared ingredients in the inner pot. 2. Close the lid, select the 'STEAMED cooking' menu in 'Cooking' from the display panel, and press the 'COOK/TURBO' button. a chicken (700g) , 50g of potato, 50g of carrot, Sugar 1 tablespoons, 1 teaspoons of chopped green onion, crushed garlic 1 teaspoon, soy sauce 3 tablespoons, ginger juice 1 teaspoon, some ground pepper, ground sesame 1/2 tablespoons, sesame oil 1 teaspoon
		Rice Cake Gratin	Approx. 20min	50g of rice cake for tteokguk, 1 boiled egg, 1 sweet potato, 40g of mozzarella cheese, 1 slice of cheddar cheese, some olive oil, 1/2 cup of white sauce, some parsley powder *White sauce : 10g of flour, 10g of butter, 100g of milk, pinch of salt and white pepper (Melt butter, add flour and stir it, add milk and boil it until it gets thick, and apply salt and white pepper for seasoning.)	
		Rice Pizza	Approx. 20min	* Dough ingredients : 100g of rice. * Topping ingredients : 2 slices of ham, 2 button mushrooms, canned corn 2 tablespoons, 1 tick of crabmeat, 40 of mozzarella cheese, pizza sauce 4 tablespoons	
		Boiled-Down Cuttlefish	Approx. 20min	* One squids, 70g of spinach, 80g of carrot, egg 1EA, some salt, some sesame oil, some wheat flour *Seasoning sauces : two tablespoons of red pepper paste, 1 tablespoons soy sauce, 1 tablespoons sugar, 1/2 teaspoons of sesame oil, 1/2 teaspoons of pepper powder.	
		Steamed Egg	Approx.15min	2 eggs, 1 cup of water or kelp water, salted shrimps 1/2 teaspoon, some salt, 10g of carrot, 10g of green onion .	
		Tteokbokki (spicy and sweet rice cake)	Approx. 15min	200g of rice cake bars (soft), 2 pieces of fish cake, 1/4 onion, 1/4 green onion, 40g of carrot Seasoning sauce : red pepper paste 2 tablespoons, starch syrup 1.5 tablespoon, sugar 1 tablespoon, soy sauce 1/2 teaspoon, 1/3 cup of anchovy water, some sesame salt	
		Shrimp stir the ketchup	Approx. 15min	Medium size shrimp 10EA, green onion 1/4EA, 20g of onion, 20g of carrot *Seasoning sauces : ketchup 3 tablespoon, sugar 1 tablespoon, Starch flour 1 tablespoon, some salt, some soy sauce, some ground pepper	
		Steamed Tofu	Approx. 15min	1 piece of tofu, some salt Seasoning Sauces: 1 tablespoon thick soy, 1/2 red pepper, 1/2 green chili, 1/2 tablespoon of red pepper powder, 1/2 tablespoon of vinegar, a little bit of ground sesame mixed with salt, 1/4 pieces of Welsh onion, 2 pieces of garlic, 1 teaspoon of sugar	
		Steamed Eggplant/ Steamed Pumpkin	Approx. 15min	Eggplant 2EA / Pumpkin 1/2EA	
		Boiled Egg	Approx. 20min	6 eggs, 2 cups of water, 1~2 drops of vinegar	
Bread Fermentation	Fist (40min)	200g of wheat flour (strong flour), 2g of yeast, 5g of sugar, 2g of salt, 15g of butter, 8g of milk powder, 100g of water	<p>[First fermentation]</p> <ol style="list-style-type: none"> 1. Sift wheat flour (strong flour). 2. Leave butter at the room temperature to make it softer. 3. Put wheat flour (strong flour) into a bowl, put nonfat dry milk, sugar, yeast, and water, butter, and knead the dough. 		



RECIPE

SELECT MENU	MENU TO COOK	COOKING TIME	INGREDIENTS	DIRECTIONS	
C O O K I N G	Bread cooking	Bread fermentation	Second (40min)	200g of wheat flour (strong flour), 2g of yeast, 5g of sugar, 2g of salt, 15g of butter, 8g of milk powder, 100g of water	(Knead the dough by repeating extending and folding the dough. Finish when the surface of the dough is smooth and is not cut, and when the dough can be extended to be thin.) 4. Roll the dough and put it into the center of the Inner Pot. 5. Close the lid, and select 'Bread Fermentation' in the 'Home baking' option in 'Cooking' from the display panel. 6. Set your desired fermentation time, and press the 'COOK/TURBO' button. First fermentation] 1. After the primary fermentation is done, open the lid, lightly press the dough, and discharge gas. 2. Roll the dough again and put it into the center of the Inner Pot. 3. Close the lid, and select 'Bread Fermentation' in the 'Home baking' option in 'Cooking' from the display panel. 4. Set your desired fermentation time, and press the 'COOK/TURBO' button.
		Bread baking	40min	fermentation is completed daugh	1. When the fermentation is completed by the 'Bread Fermentation' menu, open the lid to check if the dough is expanded to be around double the size before the second fermentation. 2. Close the lid, and select 'Bread Baking' in the 'Home baking' option in 'Cooking' from the display panel. 3. Set your desired baking time and press the 'COOK/TURBO' button. 4. When the baking is completed, take the bread out and cool it down.
	Cream cake	Approx. 40min	1/2cups of wheat flour (soft flour), Egg 2EA, 1/2 tablespoon butter, 1/2 tablespoon milk, some vanilla flavor, 1/2cup of sugar, some salt	1. Put the prepared ingredients in the inner pot. 2. Close the lid, select the 'Bread cooking' menu in 'Cooking' from the display panel, and press the 'COOK/TURBO' button.	
		Butter Chocolate cake	Approx. 45min		200g of butter, 90g of sugar, egg 2EA, 110g of pancake powder, 70g of chocolate
	noodle dishes	Japchae (stir-fried vegetables, and shredded meat)	Approx. 20min	250g of cellophane, paprika (green, red) each 1EA, 100g of carrot, 100g of onion, some spinach, 100g of enoki mushroom, oil 2 tablespoon, 1/2 cup water Seasoning sauce : some sugar, some soy sauce, some sesame oil, some sesame salt	1. Put the prepared ingredients in the inner pot. 2. Close the lid, select the 'Noodle dishes' menu in 'Cooking' from the display panel, and press the 'COOK/TURBO' button.
	baby food	Sweet Potato Apple Porridge	Approx. 15min	70g of Sweet potato, 70g of apple, 2 tablespoons water, some honey	1. Put the prepared ingredients in the inner pot. 2. Close the lid, select the 'Baby food' menu in 'Cooking' from the display panel, and press the 'COOK/TURBO' button.
		Sweet Pumpkin Soup	Approx. 10min	100g of sweet pumpkin, bread crumbs 1 tablespoon, 1/3 cup water, some salt, some milk	
		Tuna-vegetable Soft Rice	Approx. 15min	50g of rice, 30g of tuna(can), 10g of paprika, 10g of carrot, 1/2 cup of water, some butter, Some laver powder	
		Steamed Rice, Tofu, and Vegetables	Approx. 10min	50g of rice, 30g of bean curd, 10g of carrot, 10g of green pumpkin, 1/2 egg, Milk 4 tablespoons	



MEMO



CUCKOO ELECTRIC RICE COOKER/WARMER LIMITED WARRANTY

KEY Company, P&K USA TRADING CORP and Cuckoo Trading Canada. will repair at its option replace, without charge, your product which proves to be defective in material or workmanship under normal use, during the warranty period listed below from the date of original purchase. This warranty is good only to the original purchaser of the product during the warranty period. P&K USA TRADING CORP covers the east and the central districts, KEY Company covers the west and the central districts, Cuckoo Trading Canada covers the whole Canada.

WARRANTY PERIOD

MODEL#	#LABOR	PARTS	HOW SERVICE IS HANDLED
CRP-FH06	1YEAR	1YEAR	<p>The East and the Central Districts Call : 718 888 9144 Address : 5-48 46th Road Long Island City, NY 11101, USA</p> <p>The West and the Central Districts. Call : 323 780 8808 Toll Free : 877 481 9828 Address : 1137 E. 1st Street, L.A, CA 90033, USA</p> <p>Canada (TORONTO) Call : 416 878 4561 / 905 707 8224 Address : #D8-7398 Yonge Street Thornhill Ontario Canada L4J 8J2</p> <p>Canada (VANCOUVER) Call : 604 540 1004 / 604 523 1004 Address : 945 Lougheed Hwy Coquitlam BC Canada V3K 3T4</p>

No other express warranty is applicable to this product. **THE DURATION OF ANY IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY, IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY HEREIN. CUCKOO ELECTRONICS CO.,LTD, SHALL NOT BE LIABLE FOR THE LOSS, THE USE OF THE PRODUCT, INCONVENIENCE, LOSS OR ANY OTHER DAMAGES, DIRECT OR CONSEQUENTIAL, ARISING OUT OF THE USE OF, OR INABILITY TO USE, THIS PRODUCT OR FOR ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY APPLICABLE TO THIS PRODUCT.**

Some states do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts : so these limitations or exclusions may apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

THE ABOVE WARRANTY DOES NOT APPLY IN THESE CASES :

- * To damages problems which result from delivery or improper installation.
- * To damages problems which result from misuse, abuse, accident, alteration, or incorrect electrical current or voltage.
- * To serve call which do not involve defective workmanship or material and explaining the operation of the unit.

Therefore, these costs are paid by the consumer. Customer assistance numbers :

To Prove warranty Coverage :

- ▶ **Retain your Sales Receipt to prove date of purchase**
- ▶ **Copy of your Sales Receipt must submitted at the time warranty service is provided.**

**To Obtain Product, Customer, or Service Assistance and Nearest Authorized service center ,
Parts Distributor or Sales Dealer:**

The East and the Central Districts
Call : 718 888 9144
Address : 5-48 46th Road Long Island City,
NY 11101, USA

The West and the Central Districts.
Call : 323 780 8808
Toll Free : 877 481 9828
Address : 1137 E. 1st Street, L.A,
CA 90033, USA

Canada (Toronto)
Call : 416 878 4561 / 905 707 8224
Address : #D8-7398 Yonge Street
Thornhill Ontario Canada
L4J 8J2

Canada (Vancouver)
Call : 604 415 9858/604 524 8282
Address : 103-4501 North Road
Burnaby BC Canada
V3R 4R7

